

David Brown®

Service Repair Manual

FOUR - CYLINDER DIESEL ENGINE

(SERIES AD4/47)

SECTION A1 (Pub. 9-38114) January 1971

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J. I. Case



Introduction

The engine fitted to 990 Agricultural Tractors is designated AD4/47 and is a four-cylinder unit of $3\frac{5}{8}$ in. bore and $4\frac{1}{2}$ in. stroke, fitted with wet cylinder sleeves. As the engine must have a flywheel suitable for the clutch (Livedrive or Non-Livedrive) the suffix A or B is included in the designation to indicate the type of flywheel fitted and therefore the tractor model on which the engine is used.

The engine fitted to 990 Industrial Tractors is designated ID4/47 and is basically identical to the AD4/47 engine, the only difference being that the ID4/47 engine is fitted with a flywheel suitable for the twin-plate clutch and has a splined coupling flange attached to the longer flywheel bolts.

Engine Designation and Tractor Models

<i>Engine Series</i>	<i>Tractor Model</i>	<i>Tractor Number</i>
AD4/47A	990 Implematic Livedrive	440001 to 481999
	990 Selectamatic Livedrive	482001 to 505286
AD4/47B	990 Implematic Non-Livedrive	440001 to 481999
	990 Selectamatic Non-Livedrive	482001 to 505286
ID4/47	990 Industrial Models	440001 to 505286

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

CONTENTS

SECTION	Page
Maintenance	1
Fuel System	5
Lubrication System	12
Cooling System	16
Repair Operations	
Engine Tune	18
Decarbonising	19
Pistons and Connecting Rods	21
Crankshaft and Bearings	23
Cylinder Sleeves	24
Timing Gears	25
Valve Mechanism	27
Engine Removal	27
Dimensional Data	32
Summary of Design Changes	37
Approved Lubricants and Test Oils	39

MAINTENANCE

Daily

Check engine oil level. Top up if necessary.

Check air cleaner. Remove filter bowl and examine the oil. In dusty conditions the air cleaner oil should be changed frequently, the detachable wire mesh element removed, washed in diesel fuel, and allowed to stand until all fuel has drained off. (See note regarding air cleaner maintenance.)

If a paper element pre-cleaner is fitted, remove the cover and examine the element. If it is dirty, remove the element and tap it on the side to shake off dust. **Do not attempt to wash a paper element.** Examine for any water, fuel or lubricating oil leaks.

Every 60 hours

Check engine oil level. Top up to the "full" mark on dipstick if required.

Check radiator water level and top up to within 1 in. (2.5 cm) from top if required. If the engine is hot, remove radiator cap slowly as the system is pressurised and may scald the hand if opened quickly.

Visually check the feed pump sediment bowl. Remove and clean if there is any accumulation of dirt or water.

Air Cleaner

Air Cleaner Oil: Air cleaner oil should be changed and the detachable wire mesh element removed and in dusty conditions washed frequently. The maximum dust deposit in the cleaner bowl should never be allowed to exceed $\frac{1}{2}$ in., checked after standing overnight, otherwise oil pullover into the induction manifold will take place, due to the raised oil level.

Oil in the induction manifold, which indicates oil pullover, can be easily checked through the ether plug aperture in the inlet manifold. This pullover will cause rapid engine wear and must be prevented by adequate cleaner maintenance. An SAE 30 grade of straight mineral oil is less susceptible to frothing, and usually cheaper, than the detergent oils used in the engine. In climates where the ambient temperature often exceeds 32° C (90° F) an SAE 50 grade oil may be used. Care should be taken not to overfill the bowl. Only fill to the level mark — not above or below it.

Before assembling the air cleaner thoroughly clean the inside of the pre-cleaner and the inside of the pipe through the centre of the air cleaner. Ensure that the 'O' rings between the cleaner body, lower element and oil bowl are correctly fitted to ensure an air-tight seal. The fit of these 'O' rings is particularly important, as the upper ring may be easily displaced when the oil bowl and lower element are being fitted. The 'O' ring should not be twisted and should fit securely on the small notched register on the lower edge of the air cleaner body. If the 'O' rings are damaged during assembly new rings must be fitted.

Paper Element Pre-cleaner

This is an alternative fitting to the centrifugal type pre-cleaner and incorporates a replaceable paper element. Frequency of attention depends on working conditions and in dusty climates the cover should be removed every few hours of use and the element examined. The element can be cleaned by tapping its side to shake off the loose dust. If the element becomes very dirty, or contaminated with oil or water, it should be renewed. **Do not attempt to wash an element.**

Every 125 Hours

Engine Oil: Drain the oil, while it is still warm, through the sump plug on the underside of the sump plate. Refill with approved oil to within the safe marks on the dipstick. For list of approved lubricants see Page 39. In dusty conditions clean or replace engine breather (see Engine Breather, Page 2).

Every 250 Hours

Engine Oil and Filter: Drain the oil when warm and remove filter bowl. Discard the old element and clean bowl out with clean diesel fuel, using a brush to make sure that the by-pass valve is perfectly clean. Fit a new element and check the sealing ring in the cylinder block groove; fit a new ring if it is damaged or distorted. Do not overtighten the bowl securing bolt — 10 lb ft (1.4 kg metres) is sufficient.

Refill the sump with new oil, start engine to fill the filter then recheck the oil level.




Figure 1. ENGINE BREATHER

A. Cover B. Element
C. Sealing ring

Engine Breather: Remove the domed nut from top and remove the pipe. Lift the cover off and remove breather element. Clean the top of rocker cover and fit a new element. Replace breather cover, ensuring that the 'O' ring is correctly located in the cover lip and replace pipe and nut. Failure to change the breather element could cause excessive pressure to build up in the crankcase with resulting oil leakage from the crankshaft seals. (Fig. 1.)




Figure 2. FUEL FEED PUMP SEDIMENT BOWL

- A. Bowl securing nut
- B. Sediment bowl
- C. Sealing ring
- D. Filter gauze
- E. Priming lever

Every 500 Hours

Remove sediment bowl and filter, as shown in Fig. 2, and wash in diesel fuel.

Injectors: Remove injectors for cleaning (see Page 7).

Procedure for removal of injectors:

1. Thoroughly clean off all external dirt.

2. Disconnect and remove leak-off pipe.
3. Disconnect high-pressure pipes at injector unions.
4. Slacken nuts holding down the injectors in stages, to prevent distortion.
5. Withdraw injectors carefully. Blank off inlet unions with caps. A protection sleeve should be fitted to nozzle tip.
6. Clean injector bores and remove copper washers. Plug the bores with clean rag to prevent dirt entering engine.

When replacing injectors refit copper washers — new ones if old ones were damaged — and tighten the injector down evenly. Reconnect leak-off pipe and high-pressure pipes leaving the injector unions slack. Turn engine, with stop control in the "run" position and throttle lever full open, until all air is expelled from high-pressure pipes, then tighten the unions. Start engine and check for any leaks.

Valve Clearance

Remove valve rocker cover and check valve clearances when engine is cold. The valve clearance should be set cold to the dimensions on Page 33, Dimensional Data. The clearance between the tip of rocker arm and the end of valve stem should be checked with a feeler gauge as shown on Fig. 3 and adjusted, if necessary, to the correct clearance. Adjustment is made by slackening the locknut and turning the adjusting screw until correct clearance is obtained. When tightening the locknut hold adjusting screw firmly with a screwdriver, then recheck the clearance.

Relative position of valves is as follows:

No. 1 Cylinder (Front)		No. 2 Cylinder		No. 3 Cylinder		No. 4 Cylinder (Rear)	
Exhaust	Inlet	Inlet	Exhaust	Exhaust	Inlet	Inlet	Exhaust
No. 1	No. 2	No. 3	No. 4	No. 5	No. 6	No. 7	No. 8




Figure 3. SETTING THE VALVE CLEARANCE

- A. Adjusting screw
- B. Locknut
- C. Feeler gauge

Valve adjustment is easier if carried out when the injectors have been removed for servicing as the engine can then be turned by means of the fan. If the injectors are not removed, or the holding-down nuts released, it will be necessary to use a box-spanner (Service Tool 960995) on the crankshaft nut to turn the engine.

To ensure the valve tappets are at the base of the cam, adjust the valves in the following order:

Adjust No. 1 valve when No. 8 valve is fully open
 Adjust No. 6 valve when No. 3 valve is fully open
 Adjust No. 4 valve when No. 5 valve is fully open
 Adjust No. 2 valve when No. 7 valve is fully open
 Adjust No. 8 valve when No. 1 valve is fully open
 Adjust No. 3 valve when No. 6 valve is fully open
 Adjust No. 5 valve when No. 4 valve is fully open
 Adjust No. 7 valve when No. 2 valve is fully open




Figure 4. FAN BELT ADJUSTMENT
 A. Deflection B. Mounting bolts

Fan Belt

Check tension by deflecting belt midway between the fan and crankshaft pulleys. It should deflect approximately 1 in. (25 mm) and if necessary may be adjusted by releasing the three dynamo mounting bolts and swinging dynamo on the two upper bolts. Tighten lower bolt first, as this will hold dynamo in position whilst the upper bolts are tightened. Do not overtighten the belt. A taut belt will place excessive load on the dynamo and water pump bearings and cause rapid belt wear. If the belt has insufficient tension when dynamo has been adjusted so that the lower mounting bolt is at end of arm slot, the belt should be renewed. (Fig. 4.)




Figure 5. FUEL FILTER
 A. Element securing bolt B. Element
 C. Filter base

Fuel Filter

Fit a new element in the first fuel filter but do not disturb the second filter. Clean the outside of filter then remove the bolt securing base of first filter to filter head, whilst holding base and element with the other hand. Remove base and discard element. Flush out base and fit a new element, ensuring that it seats correctly on the sealing rings in base and head. Fit a new sealing washer on to the retaining bolt. Replace the bolt and tighten firmly, but not excessively.

Do not attempt to clean fuel filter elements and do not change elements from one filter to another.

Remove and flush out fuel feed pump sediment bowl. As the fuel pump is lower than the tank it will be necessary to turn fuel tap off or, if a fuel tap is not fitted, slacken outlet union on fuel tank, so that fuel will not siphon out. Clean filter gauze with an air blast, or wash in clean fuel. Replace gauze and bowl, ensuring that it seats correctly on the sealing ring. After refitting sediment bowl and tightening the tank outlet union, or turning on fuel tap, vent system to remove air. (See Page 5.) (Fig. 5.)

Water Pump

Apply high-melting-point grease sparingly to the pump grease nipple. A few strokes of the grease-gun are all that is required. Over-greasing will damage the seals and cause eventual bearing failure.

Dynamo

Remove small rubber plug from the centre of dynamo rear end-plate, inject a few drops of engine oil through the hole and replace the plug.

Every 1000 Hours

Engine Oil Pump: Drain the oil and remove sump cover. Remove setscrew attaching gauze to pump. Remove and clean the wire gauze with diesel oil. Do not use a cloth. Refit gauze, sump cover and plug; fill with correct oil (see Page 39).




Figure 6. REMOVING THE OIL PUMP GAUZE FILTER

Fuel Filter: Using the same procedure as in 500 hours service, fit new elements in both first and second filters. Do not attempt to clean or interchange the filter elements.

FUEL SYSTEM

Introduction

A thoroughly clean fuel system is essential. Too much emphasis cannot be made on this point and the necessity for correct storage of fuel, proper attention to filter renewal, cleaning the exterior of the tractor before slackening any connections on the fuel system, and care when filling the fuel tank not to allow dirt to enter, must be impressed upon the user. Cotton waste or cloths must not in any circumstances be used in conjunction with fuel injection equipment.

Every care should also be exercised in the workshop. The bench used for servicing of fuel equipment should be situated in a well-lit and separate part of the workshop. If it is possible, an insulated dust-proof room should be provided in which the equipment can be permanently installed.

Some of the tools and test gear necessary for servicing injectors are shown in Category 'C' Tool Leaflets. The minimum essentials consist of the following: Two Safety Containers — one filled with petrol for soaking dirty nozzles and the other filled with test oil (see Page 40), or clean diesel fuel, for assembly of the cleaned components. A nozzle bench plate should be screwed to the bench with the jig end overhanging so that an injector can be located on it while the dome nut and lockwasher are slackened or tightened. A Nozzle Setting Outfit should also be securely bolted to the bench with a suitable canister to collect the spray and protect the operator against accidental contact with the spray.

The Flushing device used in conjunction with the Nozzle Setting Outfit is essential. The Nozzle Cleaning Kit (Fig. 13) includes a probing tool but not needles; correct diameter needles can be obtained separately as required. Although the above items are an essential minimum for injector servicing, more complex apparatus or additional items are available where the volume of work makes their purchase worthwhile.

Venting the System

Venting the system is necessary to remove air, as the system cannot operate correctly if air is present. If the system is allowed to run dry, or if any components are disturbed, venting should be carried out as follows:

1. Fill tank to a minimum of 2 gallons — 9 litres of fuel.
2. Clean sediment bowl and filter on lift pump before venting the system to prevent carry over of sludge or water, noting that if a fuel tap is not fitted it will be necessary to release the fuel tank outlet union to prevent fuel siphoning out. Ensure that no air is trapped in the bowl when refitting by filling it to the top with clean fuel.
3. Clean the outside of the fuel filters. Remove the plug G and slacken the connection H. Operate the feed pump priming lever and tighten in the order G then H as fuel appears at each point.




Figure 7. DIAGRAM OF FUEL SYSTEM

- | | | |
|-----------------------|----------------------------|---------------------|
| A. Fuel sediment bowl | B. Feed pump priming lever | C. Injectors |
| D. First fuel filter | E. Second fuel filter | F. Injection pump |
| G. Filter vent plug | H. Filter leak-off union | I. Pump inlet union |
| J. Pump vent plug | K. Pump vent plug | |

4. Slacken the injection pump plug J and prime until all air is expelled then tighten the plug and repeat the operation with plug K.




Figure 8. FUEL INJECTION PUMP VENT PLUGS

- A. Governor housing vent plug
- B. Pump barrel vent plug

5. Slacken the union I and prime until free from air then tighten.
6. Slacken the high-pressure pipes at the nozzle end then, with the engine stop control in the

"run" position and the throttle fully open, turn the engine with the starter until fuel is ejected. Tighten the pipe unions and operate the starter: the engine should then start.

7. Having started the engine, check tightness of all the connections, check for any fuel leaks and wipe clean all spilt fuel.

Fuel Feed Pump

The fuel feed pump is mounted on the right-hand side of the engine crankcase and is actuated by a push rod from an eccentric formed on the camshaft.

To remove the fuel feed pump, disconnect fuel pipes at the pump and release the two bolts securing the pump to the engine crankcase. When the pump is removed the push rod may be withdrawn from crankcase.

Renewal of Diaphragm: Clean exterior of the pump and mark top and bottom halves so that they can be replaced in the same position. Remove six cheese-headed screws securing the upper half of the pump to the base and lift off the pump top.

Remove diaphragm complete with pull-rod by turning these through an angle of 90° which should release the pull-rod from the connecting link. Fit new diaphragm and pull-rod over the spring with the tab in the position shown in Fig. 10. Press the centre down until the "T" of pull-rod enters slot in connecting link and turn diaphragm through 90° as shown in Fig. 10 so that they lock together. The upper housing may then be replaced. Press priming lever and keep it pressed whilst the cheese-headed screws securing the housing are tightened. This ensures the diaphragm is not taut.




Figure 9. FUEL FEED PUMP

- A. Diaphragm
- B. Diaphragm pull-rod
- C. Connecting link
- D. Diaphragm spring
- E. Body
- F. Outlet valve
- G. Inlet valve
- H. Filter gauze
- I. Sediment bowl
- J. Hand primer




Figure 10. REFITTING FEED PUMP DIAPHRAGM

With the diaphragm tab at position A, fit the diaphragm on to the pump body until the pull-rod enters the link slot, then turn the diaphragm 90°, so that the tab is at position B, to lock the pull-rod in the link slot.

Injector Servicing

Nozzle Testing: The hand tester shown in Fig. 11 is adequate for testing and pressure setting injectors.

Attach the injector to the spray tester and place a canister round the nozzle to ensure that spray does not contact the body. The force of the spray is such that it will easily penetrate the skin, even through clothing. The resultant oil under the skin is very difficult to treat and can be a very uncomfortable wound. The canister will also help to condense the very fine spray which forms an objectionable atmosphere. If regular nozzle testing is contemplated a totally enclosed test chamber with exhaust is advocated.

Pressure Test: With injector mounted in the test outfit, depress hand lever several times to fill the injector and expel any air. Depress lever very slowly and observe highest pressure reading that is obtained before needle on pressure gauge flicks. This is the pressure at which injection takes place. The correct pressure for new injectors is 185 atmospheres, and for used injectors 175 atmospheres.

If the pressure is incorrect but the nozzle is clean and otherwise satisfactory, it should be set to the correct figure as follows: Remove dome cap and slacken locknut, and using a large screwdriver in the pressure adjusting screw D (Fig. 12) adjust the pressure. Only a very small movement will be required unless the nozzle has only just been assembled and the pressure not previously set. When the screw has been adjusted, tighten locknut and recheck pressure.

Back Leakage Test: Operate hand pump until pressure is about 170 atmospheres. Release the handle quickly and measure, with a stop-watch, the

time taken between pressure gauge pointer passing the marks for 150 and 100 atmospheres as it gradually falls. For a satisfactory nozzle the time taken should be between 6 and 25 seconds.

Dry Seat Test: Carefully wipe nozzle dry. Build up pressure to 10 atmospheres below the injection pressure. Examine nozzle whilst under this pressure. It should be dry and free from leakage. If the nozzle is inadvertently caused to inject, the tip should be re-wiped dry and tested again.




Figure 11. INJECTOR TESTING
Using Service Tool 7044/122FF

Atomisation Test: Isolate pressure gauge by closing valve. Apply eight quick jerks and examine the spray quality. The sprays should be free from coarse or solid streaks and the tip should remain dry. There should be four sprays equally spaced at an inclusive angle of 140°. They are offset 10° to allow for the tilt of the injector in the cylinder head.

Examine injector for signs of leakage at nozzle cap nut, spring adjusting nut, and copper sealing washers.

Nozzle Cleaning: If the injector fails to pass any of the above tests it must be dismantled, cleaned and retested. Note the spring pressure must be released before removing a nozzle. Unscrew the nozzle cap (Fig. 12), using a close-fitting spanner on the flats provided, and remove nozzle, noting that it will only fit in one position because of the locating dowels. Remove needle valve and place in petrol to soften the carbon. Examine nozzle and needle for damage overheating or scratch marks on the lapped working surfaces. If excessive overheating has occurred, denoted by a dark blue colour of the needle, or if the seat or working surfaces are damaged, re-conditioning will be required and a new nozzle should be fitted.




Figure 12. EXPLODED VIEW OF INJECTOR

- | | | | |
|-----------|-------------------|------------|--------------------------|
| A. Cap | B. Sealing washer | C. Locknut | D. Adjusting screw |
| E. Spring | F. Plunger | G. Holder | H. Fuel inlet connection |
| | I. Nozzle nut | J. Nozzle | |

If the nozzle is not damaged it should be cleaned using the special tools provided in the nozzle cleaning kit shown in Fig. 13 and Tool Leaflet C2. Firstly clean fuel oil channels and bores in the nozzle. Scrape carbon from valve seat with the brass scraper.




Figure 13. C.A.V. NOZZLE CLEANING KIT

- | | |
|--------------------------------|-------------------------------|
| A. Brass wire brush | B. Nozzle body groove scraper |
| C. Nozzle plunger cleaner | D. Nozzle body seat scraper |
| E. Holder—probing needle | F. *Pintle hole cleaner |
| G. *Probes—pintle hole cleaner | |

* Not required for D.B. nozzles.

Using the special groove scraper clear carbon deposits from oil gallery. Clean spray holes with probing tool fitted with a probing wire of the correct diameter.

If a wire is broken off in the hole it is often impos-

sible to remove it, and the nozzle is then useless. Great care should be exercised when using the probing wires. After clearing the holes scrape carbon from valve seat with the V-tipped brass tool. Next use the tool with the thin blade radiused at its tip to clean carbon out of the sac. After cleaning with the tools, the nozzle should be thoroughly cleaned with fuel. This should be done by placing the nozzle, without needle, in the reverse flushing attachment and connecting to the nozzle pressure tester in place of an injector. Operation of the tester will then thoroughly flush all particles of loose carbon from the nozzle.

With the brass wire brush, gently clean needle valve, paying particular attention to valve seat and needle tip. Brush carbon from nozzle stem and tip.

Reassembly: The needle valve should be fitted to nozzle whilst both are under the surface of clean fuel oil or test oil. Only in this way can dust be excluded from assembly. The needle should slide smoothly in the nozzle and this should be tried several times whilst under the surface of fluid. Needle and nozzle are assembled as a pair and under no account should they be interchanged.

The nozzle should then be assembled on to injector body. In order to avoid distorting needle or plunger the pressure on pressure spring should be released. Remove dome cap, slacken locknut and slacken pressure adjusting screw right back until there is no pressure on spring. Make sure that mating surfaces between nozzle and injector body are perfectly clean. Place nozzle on body with the dowels in correct engagement so that the two faces are in perfect contact, i.e., not held apart by spring pressure. Place the cap over nozzle and tighten adequately but not overtight. Retighten pressure adjusting screw and reset the pressure on spray tester. Test the spray, leak back, etc. If the injector is not required for immediate use it should be stored in a sealed plastic bag or similar container. (Fig. 14.)

It is essential that the copper washer be used under




Figure 14. SECTIONED INJECTOR

A. Leak-off connection	B. Cap	C. Adjusting screw
D. Locknut	E. Spring	F. Fuel inlet connection
G. Holder	H. Plunger	I. Nozzle nut
	J. Needle	K. Nozzle

injector when refitting to engine. Check that the seat in head is clean and that the old washer has not been left in the recess. The use of two washers will raise nozzle tip so that the spray impinges on cylinder head. This causes a loss of efficiency and excessive exhaust smoke.

Injection Pump

The injection pump is attached by three studs on the engine carrier plate, and the pump mounting holes are slotted to permit pump body to be turned for injection timing adjustment. To assist in obtaining the correct timing position the pump flange is marked with a groove and when the timing is set during assembly a mark is made on the carrier flange in line with the mark on pump. Any pump can thus be fitted and the original timing obtained by placing the two marks in alignment. (See Fig. 15.)

The pump is driven from the camshaft by means of an intermediate gear and correct timing of the injection pump can only be obtained if all the timing gears are meshed correctly (see Fig. 44).

Removing the Pump

1. Disconnect all fuel pipes from pump.
2. Disconnect throttle and stop control cables from pump.
3. Check that timing-mark on pump drive housing is visible. If not, scribe a new line in line with the mark on pump.
4. Unscrew holding-down nuts on pump flange.
5. Lift pump away from housing. The quill shaft will probably remain in the pump and should be withdrawn and retained until required.

Refitting the Pump

1. Before refitting the pump check the position of the master spline in the driving gear then fit the quill shaft into the pump (chamfered end of shaft towards pump) and turn the pump so that the master spline on the quill shaft is in line with the gear spline.
2. Fit pump to housing.
3. Rotate pump body until timing marks line up (see Fig. 15) and tighten the three holding nuts.
4. Reconnect all fuel pipes and control cables. Vent fuel system (see Page 5).




Figure 15. INJECTION PUMP TIMING-MARKS
A. Pump body mark aligned with engine flange




Figure 16. SETTING THE INJECTION PUMP

Retiming the Injection Pump

If the timing-line on pump becomes obliterated the pump can be retimed to the engine as follows:

1. Attach stirrup pipe, Service Tool CAV 7144/262, to Nos. 1 and 4 injector pipe connections and connect the pipe to an injector tester. Set the pump so that the master spline is towards the top of the pump then operate the tester handle to build up a pressure of 30 atmospheres.
2. Fit Service Tool CAV 7144/112U on to the pump quill shaft and turn the pump until it becomes rigid. This will be the point at which injection commences on No. 1 cylinder.
3. Measure $69\frac{1}{2}^{\circ}$ from the blank spline by means of the scale on the tool and mark the pump flange (Fig. 16).
4. Remove the tool, disconnect the tester and refit the pump on the engine, aligning the timing-marks before tightening the mounting nuts.

Fuel Setting

Once the fuel setting has been set for an engine it is most unlikely that it requires adjustment. If adjustment is required then the pump should be removed from the engine and tested for delivery on a Hartridge Test Bench. For details of injection pump fuel setting see Page 34.

Injection Pump Controls

The front lever on injection pump operates the fuel cut-off to stop the engine. The rear lever operates the governor to give required engine speed and is fitted with two adjustable stops. The front stop is for setting idling speed and this should be set so that the engine runs at 650–700 rev/min with throttle lever in shut-off position. The rear stop is for setting maximum speed and should be set at: 2350 rev/min no load to give 2200 rev/min full load.

Fuel Filters

The double fuel filter mounted on the left-hand side of the engine contains two replaceable paper elements. These are connected in series, so that all fuel must pass through both elements before it is fed to the injection pump. Always wipe the outside of filter clean before removing the elements and fit new elements at the time specified. New elements should also be fitted whenever a new, or reconditioned, fuel injection pump is fitted. Do not attempt to clean elements and do not change elements from one filter to another.

Fuel Tank Removal

The easiest way of removing the fuel tank is to remove the tank complete with instrument panel, then remove instrument panel from tank.

First drain tank by unscrewing union nut on fuel tap outlet and allowing fuel to flow by gravity into a suitable, clean container. If tractor is not fitted with a fuel tap, remove union from fuel feed pump inlet and allow the fuel to siphon through pipe into a suitable, clean container. Do not release the union at the tank end of pipe as this will allow air into pipe and prevent the siphon action from taking place. Disconnect tractor meter drive cable and wiring. Some of the wires are fitted with snap connectors, but others, such as oil warning switch wire, will have to be disconnected at their terminals.

Remove fuel tank mounting bolts and fuel cut-off control-rod spring bracket, unscrew fuel outlet and leak-off pipes from tank and lift tank assembly from its support.

Replace the tank in reverse order of removal ensuring that seating pads are in position and wires are replaced in their correct connectors.

STARTING AIDS

For use in cold weather

Manual retard device on injection pump: The wing-nut on the under-side of pump should be screwed in before trying to start engine. As soon as engine is running the wing-nut must be screwed out, otherwise erratic running with black exhaust smoke and loss of power will occur. Do not screw manual retard nut in immediately after an unsuccessful attempt to start engine. If you attempt to start engine prior to screwing in manual retard, wait 15 to 20 seconds to allow pressure inside




Figure 17. INJECTION PUMP RETARD CONTROL
A. Wing nut

pump to fall; otherwise pump will be locked in the advanced position and engine will not start. It is advisable to screw the wing-nut in **before** attempting to start engine. (Fig. 17.)

For use in sub-zero temperatures

Ether plug: In the inlet manifold there is a plastic plug with a felt pad on the end. Unscrew plug and dip felt pad into ether or a proprietary starting fluid, replace plug in manifold and start engine immediately. (Fig. 18.)




Figure 18. ETHER STARTING PLUG
A. Inlet manifold B. Plug

Warning

Serious damage can be caused to an engine by the use of an excessive amount of ether. The plug should be removed, the felt soaked in ether and then replaced. **Ether in excess of the quantity absorbed by the felt must not be added.**

It must be noted that other aids do exist, namely that correct oil should be used (see Page 39) and the battery should be kept charged by running the engine for adequate periods of time.

LUBRICATION SYSTEM




Figure 19. LUBRICATION SYSTEM

- | | | | |
|--------------------|---------------------------|--------------------------|-------------------------|
| A. Inlet gauze | B. Oil pump | C. Filter | D. Warning light switch |
| E. Oil gallery | F. Crankshaft oil passage | G. Camshaft rear bearing | |
| H. Valve gear feed | I. Rocker shaft | | |

Engine Lubrication

Oil is drawn from the sump by the gear-driven rotary oil pump and delivered under pressure to the oil filter. After filtration the oil passes to the main oil gallery in the cylinder block and so, via oilways in the block webs, to the crankshaft main journals and then on, through further oilways in the cylinder block, to pressure lubricate the camshaft bearings. The big-end bearings are lubricated by drillings in the crankshaft webs.

The rocker shaft and valve rockers are intermittently fed with oil from the camshaft rear bearing through oilways in block and head and an external connecting pipe. The camshaft is drilled off-centre so that the oilways are connected only once in each revolution. (See Fig. 20.) The oil lubricates the tappets and push rods as it returns to the sump.

The intermediate gear is pressure fed via its hollow shaft and an oil-way in the cylinder block. A connection at the front end of the main oil gallery supplies a reduced flow of oil to the injection pump drive gear. Surplus oil in the timing cover forms an oil bath which splash lubricates the timing gears.

A full-flow oil filter is mounted on the left-hand side of the cylinder block. The filter incorporates a by-pass valve so that if the pressure difference between the filter inlet and outlet exceeds 10 lb/sq in. the valve opens and allows oil to by-pass the element and flow straight into the oil gallery. The engine is not, therefore, starved of oil if the element is allowed to become choked, but it is supplied with unfiltered oil. The replaceable paper element should be renewed at the intervals specified on Page 1. A new element should also be fitted when an engine is overhauled and also if a cylinder head gasket fails.




Figure 20. VALVE GEAR OIL FEED

A. Camshaft B. Rear journal C. Oil passage

If engine oil and filter element are not changed when a failed cylinder head gasket is replaced, any water which has leaked into sump will cause the paper filter element to swell and fail to pass oil. (Fig. 21.)

Do not attempt to clean a filter element.

Oil Warning Light

The oil warning light on the instrument panel is earthed by a switch in the cylinder block and when the switch opens the light is extinguished. The switch is connected into the main oil gallery and should open at 9 to 13 lb/sq. in. (0.6 to 0.9 kg/sq. cm) but if not, it must be replaced because no adjustment is possible. If incorrect oil pressure is suspected the oil switch can be removed and a pressure gauge connected into the cylinder block, which is threaded $\frac{1}{8}$ BSP, so that the actual oil pressure will be shown when the engine is started.

Oil Pump

The gear type oil pump is located in the engine sump and contains a relief valve which is set to open at 40 lb/sq. in. (2.8 kg/sq. cm).

To Remove the Pump

1. Drain engine oil and remove sump.

2. Disconnect outlet pipe from pump to cylinder block.
3. Disconnect the tractometer cable.
4. Release locknut and remove pump locating screw, which is situated on the right-hand side of block, and withdraw pump downwards.

The oil pump must be dismantled to check gear wear, gear end-float, and the condition of the upper bearing.




Figure 21. SECTION THROUGH OIL FILTER

A. Oil feed from pump B. Bowl C. Element
D. Outlet to oil gallery E. Plug F. By-pass valve

To Dismantle Pump

1. Remove the two setscrews and two bolts securing pump cover, noting that the two bolts are special locating bolts and must be fitted in their correct places when re-assembling.
2. Remove cover, complete with relief valve, and filter.
3. Check backlash between gears — this should be 0.020 to 0.026 in. (0.51 to 0.66 mm).




Figure 22. LUBRICATING OIL PUMP

A. Oil inlet gauze
D. Relief valve screw

B. Pump body
E. Spiral pinion

C. Driveshaft
F. Oil-outlet connection




Figure 23. OIL PUMP DRIVE

- A. Camshaft B. Spiral pinion C. Driveshaft
D. Pump bracket E. Locating screw F. Pump body

4. Remove driven gear and shaft.
5. Use a drift to force driving shaft from driving gear.
6. Check rotor and housing dimensions.
Rotor width: 1.1865 – 1.1855 in. (30.13 – 30.11 mm)
Housing depth: 1.1890 – 1.1875 in. (30.19 – 30.16 mm)
Rotor side clearance: 0.001 – 0.0035 in. (0.025 – 0.089 mm)
If end-float is excessive but backlash is within limits and the gears are not worn, it is permissible to grind the face of the housing to reduce end-float. If the gears are damaged, both gears should be replaced. Never replace one gear only.
7. Check the upper bearing for wear.
Bush internal diameter: 0.4905 – 0.4925 in. (12.46 – 12.51 mm)
Shaft diameter: 0.4895 – 0.490 in. (12.43 – 12.45 mm)




Figure 24. REPLACING OIL PUMP BRACKET BUSH
(Using Service Tool 901701)

- A. Long drift B. Pilot C. Replacer drift
D. Centraliser guide

Clearance: 0.0005 – 0.003 in. (0.02 – 0.08 mm)

If wear is excessive, remove the bush and replace using Service Tool 901701 as detailed below:

1. Slip special pilot bush B through slot in pump bracket to locate in driveshaft bush.
2. Stand pump bracket on a suitable hollow anvil or press base.
3. Place drift A in position.
4. Drive or press out pump bracket bush.

To replace the new bush:

1. Place new bush on the replacer drift C.
2. Push centraliser D over new bush and drift C until oil-hole in bush just shows at bottom edge of centraliser, ensuring that the oil-holes in bush and bracket are in line.
3. Start new bush in pump bracket and slide of centraliser, ensuring that the oil-holes in bush and bracket are in line.
4. Stand the pump bracket on a flat anvil or press base; drive or press C until it butts firmly against D. The bush is now in its correct position in pump bracket. The driven rotor shaft may be removed using drift A.

Relief Valve

If the valve is to be removed for cleaning purposes take note how many threads are showing above the




Figure 25. OIL PUMP TEST RIG

A. Oil pump B. Pressure gauge C. Shut-off valve
D. Swivelling outlet

locknut before removal. This is necessary so that the valve may be set in its original setting if a test rig is not available.

Approximate figures to use as a guide when setting the valve are: four threads showing above locknut give approximately 40 lb/in.²; one full turn produces a 6 lb/in.² variation in pressure.

To check the pressure, the oil pressure warning switch should be removed and a gauge fitted into the $\frac{1}{8}$ BSP hole in the cylinder block.

If a test rig is available the following procedure should be adopted:

1. Use Shell Fortisal 5W at room temperature of 20°C (68°F) or 20/20W at 46°C (115°F), which is equivalent to hot engine oil.
2. Pump to be driven at 750 rev/min or 330 rev/min.
3. Relief valve set to open at 40 lb/sq. in. (2.8 kg/sq. cm).
4. Pump flow at 20 lb/sq. in. should be 19.2 pints/min (10.9 litres/min) at 750 rev/min and 8.4 pints/min (4.7 litres/min) at 330 rev/min.
Delivery in pints/min = $\frac{480}{\text{time in seconds for one gallon to flow.}}$

Maximum time for one gallon should be:

25 seconds at 750 rev/min.

57 seconds at 330 rev/min.

To Replace the Pump

Reverse the removal procedure. Coat the locating screw with Wellseal, or a similar jointing compound, screw tightly into the cylinder block then tighten locknut.

COOLING SYSTEM




Figure 26. COOLING SYSTEM

- | | | | |
|-------------------|-------------------------------|---------------------------|---------------|
| A. Pump impeller | B. Passage into cylinder head | C. Jets on to valve ports | D. Thermostat |
| E. Radiator inlet | F. Radiator outlet | G. By-pass connection | |

Path of Water

Cold water is drawn into the water pump from the bottom of the radiator and is then pumped through a passage in the cylinder block to the cylinder head, where it is directed, in the form of jets, on to the injector bosses and integral valve guides. The water is able to pass, by thermo-siphon, into the block through the mating passages in the cylinder head and block to cool the cylinders. The hot water returns from the head to the top of the radiator through a thermostat which is only fully open when the engine reaches its working temperature.

When the thermostat is closed the water passing out of the cylinder head cannot pass into the radiator and therefore circulates through the by-pass into the inlet side of the water pump, thus ensuring that working temperature is reached as quickly as possible.

The system is pressurised by a spring plunger in the radiator cap, which allows steam to escape through the overflow pipe if the pressure exceeds 4 lb/sq. in. (0.28 kg/sq. cm).

The fan is mounted on the same spindle as the water impeller and is driven by a 'V' belt from the crankshaft at $1\frac{1}{2}$ times engine speed. (Fig. 26.)

Removal of Water Pump

This operation can be accomplished, without removing the radiator, in the following manner:

1. Drain the water from radiator and cylinder block.
2. Remove waste pipe from radiator to pump.
3. Remove fan belt.
4. Remove fan blades (ensuring that they are marked in such a way that they can be refitted in the same position, thus safeguarding against the possibility of them getting out of balance).
5. Slacken clip securing by-pass hose. Unscrew the five bolts fixing pump to cylinder block and remove pump.




Figure 27. ARRANGEMENT OF WATER PUMP

- | | | |
|----------------------|---------------------------|---------------|
| A. Body | B. Impeller | C. Gland seal |
| D. Bearing and shaft | E. Bearing locating screw | |
| F. Pulley | G. By-pass connection | |

Fitting a New Seal or Bearing

Remove bearing location screw E (Fig. 27) from pump body. Place pump, impeller upwards, on the bed of a press and suitably support it with packing. Press spindle and bearing assembly out, taking care not to damage impeller or pump body.

After spindle and bearing assembly has been removed the impeller may be lifted out and the seal prised out of end of impeller. The seal is supplied as a self-contained assembly and no attempt should be made to dismantle it. A new seal should be carefully pressed into impeller bore using a little Pressoline No. 2 compound (one part Pressoline to three parts water) as a lubricant. Press the seal in until the shoulder touches the end of the impeller, taking care not to cut or damage the seal. Coat the contact face of the seal with anti-scuffing paste to prevent the seal sticking to the pump body.

Examine the spindle and bearing assembly and, if this is to be renewed, remove pulley with a suitable extractor or press.

As gland seals are affected by light they should be stored in a light-tight drawer or box. The wax wrapping paper is not sufficient and seals will deteriorate if exposed to light during storage.

Reassembly of Water Pump

Position bearing-locating hole so that it is in line with the screw-hole in pump body then push bearing into the body and fit the locating screw. After tightening locating screw, lock the screw with the tabwasher.

Press pulley on to spindle until the end of spindle is level with the end of pulley bore. Do not fit pulley by hammering it on to spindle but press the spindle into pulley by pressing against the impeller end of spindle.

Press impeller on to spindle until the sides of impeller blades are 0.005 in. (0.13 mm) clear of the pump body. Ensure that the seal is not damaged when fitting the impeller and do not support the pump on the pulley when pressing impeller into position. Support pulley end of spindle on a short piece of $\frac{7}{8}$ in. (22 mm) diameter bar, so that the thrust is taken on the end of spindle and does not tend to push the pulley further on to spindle.

Before replacing water pump, check the condition of by-pass hose; if this is at all suspect it is advisable to renew it, as renewal is more difficult when both pump and cylinder head are in place.

A new gasket should always be used when refitting the pump and plain washers fitted on the fan blade setscrews, to avoid any possibility of blade failure due to fatigue.

Thermostat

To test the thermostat, remove it and place it in cold water together with an accurate thermometer. Heat the water and as the temperature rises note at what stage the thermostat begins to open. This should be at between 174°F and 183°F (79°C - 84°C). At 200°F (94°C) it should be fully open. If placed in boiling water the thermostat should be fully open within 60 to 90 seconds.

On the base of the thermostat the figure 180 signifies the temperature at which it should start to open.

REPAIR OPERATIONS

Engine Tune

- 1. Compression:** To check the compression use a Test Gauge such as is shown in the Service Tools List. Remove all injectors and, using the correct length of extension, fit the gauge into No. 1 injector bore. Tighten down with injector nuts to give an airtight seal and with the stop control in the "stop" position turn engine with starter. It is advisable to use a fully charged battery. Note the compression reading and repeat the procedure for the remaining cylinders. If the four readings are approximately the same then proceed with the engine tune. If there is an appreciable difference in readings then it will be necessary to de-carbonise cylinder head, as the loss of compression is probably due to faulty valves or valve seats.

Crankshaft Speed	Pressure lb/in ²	Pressure kg/cm ²
150 rev/min	380 - 400	26.6 - 28.0
250 rev/min	415 - 435	29.0 - 30.5

- 2. Injectors:** Service and set before replacing. (See Page 7.) Take care to fit copper sealing washers and tighten nuts down evenly to avoid distortion.
- 3. Fuel:** Clean fuel sediment bowl and replace fuel filter elements as necessary. (See Page 3.) Vent the system, finishing with tightening the injector unions (as in Fuel System, Page 5).
- 4. Breather:** Fit a new breather element as instructed under Maintenance, Page 2.
- 5. Valves:** Check valve clearances, taking care to follow instructions on Page 2.
- 6. Timing:** Check timing marks on pump and pump drive housing. If necessary loosen the mounting nuts and rotate the pump to align the marks.

Compression Figures

Compression ratio 17:1. Air temperature 68°F (20°C)




Figure 28. ARRANGEMENT OF VALVES

- | | | | |
|--------------------------|------------------------|-------------------------|-------------------------|
| A. Exhaust valves | B. Inlet valves | C. Exhaust seat inserts | D. Inlet valve seats |
| E. Inlet valve stem seal | F. Inlet valve cotters | G. Inlet valve cup | H. Springs |
| I. Exhaust valve cotters | J. Exhaust valve cup | K. Stem end-cap | L. Exhaust valve rocker |
| M. Inlet valve rocker | N. Rocker shaft | O. Bracket | |

7. **Air Cleaner:** Clean out oil bath and replenish with the correct oil. Wash out gauze filter and clean tube and pre-cleaner. If a paper pre-cleaner is fitted, clean or renew the element. (See Page 1.)

Decarbonising the Engine

When compression is low or engine is down in power due to an accumulation of carbon inside combustion chamber, the cylinder head should be removed, cleaned of carbon deposits and the valves re-seated.

To Remove Cylinder Head

1. Remove the bonnet, disconnect the battery and drain the cylinder block.
2. Remove injector leak-off pipe and four high-pressure injector pipes.
3. Remove injectors and copper sealing washers. Before refitting, injectors will require servicing and testing. (See Page 7.)
4. Remove breather pipe from air cleaner and unscrew the four domed nuts and remove rocker cover and gasket.
5. Slacken clips on by-pass hose.
6. Remove rocker shaft oil-feed pipe.
7. Remove rocker shaft assembly and push-rods.
8. Remove the ten nuts, seven bolts and two lifting nuts, holding the head to cylinder block, in reverse order to tightening procedure, to prevent distortion of head.
9. Lift off cylinder head and place on the bench.
10. Remove gasket, clean cylinder-block face and oil the bores before covering over with a cloth or sheet of paper for protection.

Dismantling the Cylinder Head and Cleaning

1. Remove inlet and exhaust manifolds, scraping out ports in exhaust manifold and washing to clean away carbon.
2. Mark all valves on head with a number to ensure re-assembly in same order.
3. Remove valve springs, cotters, collars and inlet valve seals and wash in paraffin.
4. Clean the head, scraping all carbon from valve ports, then wash and clean with an air jet.

Valves and Seats

The valve stems operate direct in micro-finished bores in the cylinder head (no separate guides). The inlet valves are fitted with taper cotters which grip the valve stem and prevent it from rotating, but the exhaust valve cotters are parallel and the valve has a loose cap on the end of the stem. The valve rocker does not, therefore, operate directly on the valve stem but operates against the cap so that the valve

is free of pressure at the beginning and end of each opening period. This allows the valve to rotate, keeping it free of carbon and prolonging seat life.

Clean the valves and reface if necessary, using a suitable valve grinder. The valve faces should be ground at 45° and care must be taken not to remove too much metal as the exhaust valves will overheat if heads are ground to a knife-edge finish.

Examine the ends of the inlet valve stems and if worn, lightly skim on a valve refacing machine, using the V-support guide to ensure that the end is ground square with the valve stem.




Figure 29. INLET AND EXHAUST VALVES

A. Exhaust valve B. Inlet valve
C. Seat angle 45°

Examine valve seats. If seats are in good condition but only discoloured, lapping-in the valves will be sufficient to obtain a good seat, but if seats are pitted it may be necessary to recut them before lapping-in the valves. Use a valve seat cutter, or grinder, with a pilot of the correct diameter, to ensure an accurate seat (see Tool Leaflet B9). Do not remove more metal than is necessary. If valve seat becomes wider than 0.065 in. (1.65 mm), the seat insert should be removed and a new insert fitted. To remove the insert, weaken by drilling almost through then crack it with a sharp chisel, taking care not to damage cylinder head, and covering insert with a piece of cloth to prevent injury from flying particles. Clean the head counterbore and after cooling new insert with dry ice (solid carbon dioxide) quickly tap it into position using Service Tool 960602. The seat must be fitted with its chamfered edge into the head counterbore and then ground flush with the head face before the seat is cut.

Oversize Valves

The valve guides are cast integral with cylinder head and if excessive wear takes place the guide can be reamed true and new valves with oversize stems fitted. Valves with 0.010 in. and 0.020 in. oversize stems are available and the appropriate size reamer

should be used (see Service Tool Leaflet A28) to obtain an accurate bore. It is also important that the bore has a good surface finish and special care should be taken when reaming; use a liberal quantity of cutting fluid and a very slow-running pillar drill. When bore has been reamed to the correct size, fit new valve and check valve seat with marking blue. If valve head touches seat all the way round, lapping-in will be sufficient, but if valve head only touches seat at one side the seat is not concentric with guide bore and will require cutting before lapping-in.

Valve Springs

If suitable equipment is available, check spring lengths when under load, but if such equipment is not available check the free length. (See Page 33.)

If any spring is weak, broken or corroded, and engine has run for a large number of hours it is advisable to fit a complete set of new springs.

Cylinder Head Face

The face of cylinder head should be smooth and free from distortion and damage, otherwise the cylinder head gasket may be unable to provide an effective seal.




Figure 30. CYLINDER HEAD FACE GAUGES
A. Depth gauge (960938) B. Slip gauge (960940)

If the cylinder head face is reground care must be taken to obtain a smooth finish: a fine stone should be used with a slow feed. Before surface grinding check how much metal can be removed by using Service Tools 960938 and 960940. Insert depth gauge into injector recess, ensuring that both recess and tool are clean, then check protrusion of depth gauge above head face with slip gauge. If face G of slip gauge beak fouls end of depth gauge the cylinder head face has been previously ground to the limit and no further grinding is permissible. If beak face G passes over end of depth gauge the head face can be ground and the thickness of feeler gauge which can be fitted between tip of depth gauge and face G will indicate the maximum amount of metal that should be removed.

Valve Lapping

Using a suitable tool to hold the valves and rough grinding paste, lap-in all the valves to obtain full-circle contact between valve and seat, then lap-in again with smooth grinding paste, and wipe clean.




Figure 31. CHECKING THE CYLINDER HEAD BEFORE REFACING

A. Depth gauge B. Slip gauge C. Cylinder head

To Reassemble and Replace the Cylinder Head

1. Renew inlet valve seals (see Fig. 28) using Service Tool 961236, making sure there are no burrs on the chamfer in cylinder head recess. Put seal on to the tool, smear with grease and place tool in the recess. Two or three sharp taps with a copper hammer are sufficient to drive seal home. Do not fit seals until cylinder head is ready for assembling and do not withdraw a valve once it has been fitted through a seal. As pulling valve stem through seal causes the cotter groove to trap and damage the sharp edge of the seal, it is necessary to fit a new seal whenever a valve is removed.
2. Smear valve stems with a little oil and reassemble with the springs, collars and cotters, using a suitable tool to compress springs and ensuring that valves are fitted in their correct positions.
3. Refit inlet and exhaust manifolds using new gaskets.
4. If the new gasket is copper and asbestos, coat both sides evenly with Wellseal. Allow gasket to dry for five minutes, keeping clear of dirt, then fit on to cylinder block with beaded side of gasket towards cylinder head. If the new gasket is graphite-finished asbestos with tin-plate inserts do not use Wellseal but fit the gasket dry (side marked "Top" towards cylinder head), after ensuring that block and head face are clean.




Figure 32. CYLINDER HEAD TIGHTENING SEQUENCE

Tighten the bolts in the order shown and in three stages of 30, 60 and 90 lb ft (4, 8 and 12.5 kg metres)

5. Fit a new by-pass hose and lower cylinder head on to block. Following the tightening sequence shown in Fig. 32, progressively tighten down all head bolts and nuts in stages of 30, 60 and 90 lb ft (4, 8 and 12.5 kg metres).
6. Tighten by-pass hose clips and replace push-rods in their original positions. Ensure that the push-rods are not bent and check that they are correctly seated in the tappets.
7. Refit rocker shaft assembly and rocker lubrication pipe.
8. Oil the rockers liberally and then proceed to set valve clearances. (See Page 2.)
9. Replace injectors, fitting new copper sealing

washers. Replace high-pressure injector pipes and leak-off pipe.

10. Replace gasket and rocker cover and then refit breather pipe.
11. Refill radiator, start engine and check for any fuel, oil or water leaks. It is advisable to check tightness of cylinder head bolts and check valve clearances after the engine has been run for half-an-hour.

Pistons and Connecting Rods

The pistons cannot be removed through sump when crankshaft is in position, but by removing cylinder head and bearing caps they can be withdrawn through the top of bores.




Figure 33. PISTON AND CONNECTING ROD

- | | | |
|---------------------------|-------------------------|-----------------------------------|
| A. Piston | B. Top compression ring | C. Nos. 2 and 3 compression rings |
| D. Oil scraper ring | E. Gudgeon pin | F. Circlips |
| G. Bush — connecting rod | H. Connecting rod | I. Connecting rod cap |
| J. Big-end bearing shells | K. Connecting rod bolts | L. Self-locking nut |

Removing the Pistons

The bearing cap bolts must be removed to prevent possible damage to the bore as the connecting rod is pulled up through the bore. Having removed piston, check that connecting rod and bearing caps are marked and mark piston so that it can be replaced in same cylinder.

Gudgeon Pins

The fully floating gudgeon pins are retained by two circlips, one at each end of the pin, and to remove the gudgeon pin remove both circlips, then immerse piston in hot oil. This will cause piston to expand and allow the pin to be pushed out. Refit pin in same manner using hot oil, then replace circlips, ensuring that they are fully seated in their grooves. When the gudgeon pin has been refitted check that the piston has been replaced in its original position by noting that the valve recesses in the piston crown are towards the same side as the identification mark on the connecting rod.

Connecting Rods

The small end of connecting rod is bushed and this can be replaced if worn. Press out worn bush, using a suitable sized mandrel, and press in new bush, ensuring that oil hole in the bush is opposite hole in the end of connecting rod. Hone, or ream, new bush after fitting until gudgeon pin is a light push-fit.

Connecting rods should always be checked for alignment whenever they are removed and especially if the piston skirt marking is not even. The easiest way of checking connecting rods is by means of a proprietary aligning tool such as is shown in Service Tool Leaflet B5, but if such a tool is not available, mandrels and 'V' blocks can be used.

If connecting rods are not more than 0.010 in./in. (0.1 mm/cm) out of alignment they should be straightened to bring them within the limits shown on Page 35. If a rod is more than 0.010 in./in. (0.1 mm/cm) out of alignment it should not be straightened but must be renewed.

When replacing pistons check that the ring gaps are spaced round piston so that no two are in line, i.e., one above the other. Check that piston is the right way round: valve recesses to camshaft side of cylinder block. Replace piston through top of the bore, using a ring clamp to compress piston rings.

Smear oil on bearing surfaces and replace cap and bolts. Fit new nuts if self-locking ring in nuts can be screwed on to bolts with the fingers, and tighten to specified torque. (See Page 32.)

Pistons and Rings

There are three compression rings and one oil scraper ring on each piston. The top compression ring is plain on early engines, but is chromed on later engines. Numbers 2 and 3 compression rings are of the stepped type; these help to return oil back down the bore as well as acting as compression rings, and must be fitted correctly, i.e., cut-away section uppermost, otherwise oil will be pumped up the cylinder.




Figure 34. PISTON RINGS

- A. Top ring with chrome insert
- B. Nos. 2 and 3 stepped compression rings
- C. Oil scraper ring

(See Fig. 34.) Number 4 ring is a single-piece cast iron scraper ring. This ring's function is purely to scrape oil down the bore, and the piston is drilled behind the ring to allow oil to pass through the piston skirt and back down to the sump.

After removing carbon from the top, unworn part of the bore, place the rings in position and check piston ring gaps. New rings will be required if the gaps exceed 0.060 in. (1.5 mm). For further guidance on bore wear see Guidance of Wear Limits on



Figure 35. CHECKING PISTON RING GROOVE CLEARANCE

Page 32. Excessive top ring wear may be attributed to the ingress of dusty air, due to lack of air cleaner maintenance, and excessive lower ring wear may be attributed to dirty engine oil, due to infrequent oil and filter changes.

If the cylinder sleeves are worn, but not sufficiently for renewing, oil control rings can be fitted. These sets include special top rings, which have a shoulder at the top so that the rings do not foul the ridge at the top of the bores, and spring-loaded steel scraper rings.

Pistons used with high-lift camshafts have slightly deeper valve recesses and pistons with shallower recesses must not be fitted to engines having a high-lift camshaft as the valve heads would foul the piston.

High-lift camshafts were fitted to engines from
AD4/47A/60390 AD4/47B/40725

When fitting new pistons to AD4/47 engines subsequent to the above serial numbers ensure that they are of the later type, otherwise the pistons will foul the valve heads.



Figure 36. CHECKING PISTON RING GAP

Crankshaft and Bearings

Crankshaft Bearings: The shell type crankshaft bearings are steel backed and faced with a thin coating of soft, anti-friction material. The upper and lower big-end shells and the lower main bearing shells are faced with aluminium-tin, but the upper main bearing shells are faced with white metal.

Bearing shells are not interchangeable once they have been fitted and if not renewed must be replaced in their original position.

The bearing caps and shells are very accurately machined and no attempt should be made to file a bearing cap or scrape a bearing. Connecting-rod caps must only be used with their original connecting rods and main bearing caps must only be fitted to their original cylinder blocks.

Crankshaft Regrinding

If crankshaft journals are worn, or scored, the shaft should be reground and suitable undersize bearings fitted. Regrind the shaft journals to the appropriate undersize (see Page 35) and ensure that the correct fillet radii is maintained. A fillet that is incorrectly radiused, roughly finished or not smoothly blended weakens a shaft and may cause fatigue failure during service.




Figure 37. EXAMPLES OF REGROUND FILLET RADII

- | | | |
|-----------|---|---|
| Incorrect | { | A. No radius |
| | | B. Radius not smoothly blended |
| | | C. Radius too large |
| | | D. Radius too small |
| | | E. Radius too small |
| | | F. Radius roughly finished |
| Correct | { | G. Correct radius smoothly finished and correctly blended |

Crankshaft Rear Oil Seal

Oil leaks from the rear of the engine are prevented by an oil flinger on the crankshaft and a removable aluminium oil retainer incorporating a scroll. This retainer, which is in two halves — one half bolted to the block and the other half to the main bearing cap — is now fitted with paper gaskets. The gaskets are slightly oversize and should be trimmed on fitting. It is advisable to apply a gasket sealing compound. The two cap-head screws clamping the two halves of the retainer together and the four setscrews which hold the retainer to the cylinder block should be tightened together to ensure an oil-tight seal.

There is 0.008–0.012 in. (0.20–0.30 mm) clearance between scroll and crankshaft. The scroll must not touch the crankshaft, otherwise oil leakage will take place.




Figure 38. OIL RETAINER GASKET

Temporarily fit the gasket to the retainer and trim each half flush with the retainer face "A", so that when installed the two halves of the gasket will touch but not overlap.

Cylinder Sleeves

The wet cylinder sleeves are sealed at their lower ends by two rubber rings and at their upper ends by the cylinder head gasket. The upper ends of the sleeves have a shoulder which is firmly clamped into a recess in the cylinder block when the cylinder head is bolted in position. The sleeves are a light press-fit in the cylinder block but as the outsides of the sleeves are immersed in the cooling water any build-up of deposit round the lower end of a sleeve will tend to "cement" the sleeve in position. The force required to remove the sleeve may, therefore, be quite high and it is essential that correct equipment is used when removing tight sleeves, otherwise damage to the sleeve or cylinder block may occur.

If the sleeves are worn, or the lower seals are leaking and allowing water to pass into the engine sump, withdraw the sleeves using the sleeve remover (Service Tool 901729). With the extractor pad attached to the centre screw so that the $3\frac{5}{8}$ in. diameter shoulder (the $3\frac{1}{2}$ in. diameter shoulder is for the $3\frac{1}{2}$ in. bore sleeves fitted on AD4/25 engines) is uppermost, tilt the pad on one side and lower the bore until the pad is positioned squarely underneath the sleeve (Fig. 39). Whilst holding extractor pad firmly against lower end of sleeve, lower the centralizer pad — larger diameter shoulder downwards against the sleeve — and tighten the butterfly-nut until sleeve is clamped between thrust pad and centralizer pad. After checking that the thrust pad is held squarely against lower end of sleeve, lower the bridge piece down until side rod feet rest firmly on cylinder block and run the ratchet down until it comes up against bridge piece. Holding the centre screw stationary with the tommy-bar, operate ratchet handle to pull sleeve out of block.

After removing sleeve, clean all traces of deposit from upper and lower cylinder block registers. If sleeve has been removed with the engine in position clean off any dirt which has fallen on to crankshaft.

Always fit new rubber sealing rings when replacing sleeves and ensure that the sleeve and cylinder block are clean. Thoroughly clean cylinder block recess and




Figure 39. CYLINDER SLEEVE REMOVAL

- | | | |
|--------------------|------------------|--------------------------|
| A. Centre screw | B. Tommy bar | } Service Tool
901729 |
| C. Ratchet handle | D. Bridge piece | |
| E. Side rod | F. Butterfly nut | |
| G. Centralizer pad | H. Extractor pad | |

carefully fit the rubber seals into sleeve grooves, taking care that the seals are not twisted. Smear underside of sleeve shoulder with Wellseal and apply an even coating of Pressoline No. 2 compound — one part Pressoline (Part No. 900185) mixed with three parts of water — on the seals and lower end of the sleeve.

Push the sleeve into block as far as possible by hand, positioning sleeve so that the flat in the shoulder is in line with the flat in adjacent sleeve. Using sleeve protrusion checking tool (Service Tool 902169), fit the replacer pad on top of sleeve, positioning the pad with the larger diameter recess against the sleeve and the flats in the pad aligned with the sleeve flats.

Attach the press body to cylinder block, using the original cylinder head studs and bolts. Fit the three distance pieces between the body and block and place a flat washer under each nut and bolt. After centring the body so that the ball in the end of pad rests in the dimple at pad centre, tighten the nut and bolts to 90 lb ft (12.5 kg metres).

Tightening the centre screw will push sleeve into block and when the screw has been tightened to a torque of 35 lb ft (4.8 kg metres) check the sleeve




Figure 40. CYLINDER BLOCK AND SLEEVE

- | | |
|----------------------------------|----------------------------------|
| A. Sleeve shoulder | B. Sleeve seals |
| C. Cylinder block face | D. Cylinder block upper register |
| E. Cylinder block lower register | |




Figure 41. REPLACING CYLINDER SLEEVE

- | | | |
|-----------------------|----------------------|-----------------------------|
| A. Replacer pad | B. Centre screw | } Service
Tool
902169 |
| C. Socket | D. Body | |
| E. Distance piece | F. Flat washer | |
| G. Cylinder head bolt | H. Cylinder head nut | |

protrusion above block face by inserting a feeler gauge between pad and block face. The sleeve and block are machined to give a protrusion of 0.002–0.005 in. (0.05–0.13 mm) and if the protrusion is greater than this the sleeve should be removed and the block recess cleaned as dirt, or carbon, must be preventing the sleeve shoulder from being fully seated.

Remove the tool from block, clean the sleeve and check that the ridge on the top edge of the sleeve has not been damaged during fitting.

Cylinder Block

After stripping the cylinder block, clean out all the oil passages and check that they are clear by blowing through with compressed air. Ensure that the plugs from rear of oil gallery and the oil filter mounting boss are replaced. If the plug is omitted from the oil filter boss (Fig. 21) unfiltered oil will pass into the oil gallery.

Timing Gear

To remove timing-gear cover with engine *in situ* it is advisable to remove the radiator to provide sufficient room for working at the front end of the engine.

Disconnect dynamo mounting and remove fan belt. Before removing crankshaft-pulley bolt, remove valve-rocker cover and turn the engine, using Service Tool 960995, until the valves on No. 4 cylinder are "rocking"; this will assist re-assembly by aligning the gear markings. Remove crankshaft pulley; this is splined on to the shaft and should not be very tight. Withdraw timing case, after removing the bolts. A small quantity of oil will be released when the cover joint is "broken".

Cut the locking wire and remove camshaft-gear bolt: do not allow camshaft to turn when releasing the bolt as a valve head may foul against a piston. Do not remove the three bolts visible through the holes in camshaft gear. These bolts attach the locating plate and if removed will allow the camshaft to move forward and jam against the tappets. The gear is keyed on to a parallel shaft and if tight may be withdrawn by using an extractor such as Service Tool 960901. Do not attempt to remove the gear by striking the end of camshaft with a hammer.

Remove the four bolts from the intermediate gear shaft support bracket, taking care of the shims fitted between bracket and carrier plate. The gear may be slid off the shaft, but the shaft is a push-fit in cylinder block and may be tight. If shaft is too tight to be pulled out by hand it may be extracted by cutting the head off a $\frac{5}{16}$ UNC bolt and threading the bolt shank $\frac{3}{8}$ BSF. The UNC thread can then be screwed into the shaft plug-hole and the BSF thread screwed into the slide hammer, Service Tool 4235A.

Cut the locking wire on injection-pump drive gear and remove the three coupling bolts. Mark position of the coupling and gear: then remove the coupling; this will expose the split thrust washer and allow the washer and gear to be removed.




Figure 42.
INJECTION PUMP DRIVE

- A. Intermediate gear
- B. Drive gear
- C. Coupling
- D. Quill shaft
- E. Thrust washer
- F. Support flange
- G. Connector
- H. Oil feed

The injection pump gear support flange is fitted on the injection pump mounting studs and is attached by two bolts. The upper bolt is fitted on front of carrier plate and passes through a connector which receives oil from the main gallery and lubricates the gear bore through the drillings in the support flange. The bolt attaching the connector to oil gallery incorporates a restricting tube, so that a reduced flow of oil is supplied to the injection pump gear and it is advisable to remove this bolt to ensure that the restrictor is clear and not choked with sludge. Ensure the connector is refitted with the groove against the carrier plate and both bolts are firmly tightened before being wired together.

The crankshaft gear is keyed on the shaft and should not be removed unless it is to be renewed. Using Service Tool 960604, unscrew the extractor bolt so that when the tool is placed over the end of crankshaft the extractor body touches the face of gear. Place the two halves of split ring over the gear and, whilst holding split ring over the body until it is gripped by the chamfer on body shoulder, tighten extractor bolt to draw the gear off shaft.

Replace the gears in reverse order of removal, meshing the gears so that the teeth marks are aligned as shown in Fig. 44.

Smear injection pump gear with anti-scuffing paste before fitting in position. Replace the two halves of thrust washer and refit coupling: note that quill shaft is in position and the two marks on coupling are towards the mark on gear. Fit retaining plate and replace the bolts. Tighten the bolts to 20 lb ft (2.76 kg metres) and wire together. (Fig. 42.)

Smear plugs with Loctite and screw tightly into each end of the intermediate gear before pushing the grooved end of the shaft into cylinder block. Smear the intermediate gear bore with anti-scuffing paste and fit the gear on the shaft — teeth marks aligned and longest side of gear boss to carrier plate. Fit support bracket on to gear shaft and bolt in position, replacing the shims between carrier plate and bracket before fitting the bolts. With the bolts fully tightened insert a feeler gauge between bracket and gear to check the clearance. The gear should have 0.002–0.004 in. (0.05–0.10 mm) end-float and if necessary the bracket should be removed and shims added, or removed, as required.




Figure 43. CRANKSHAFT GEAR REMOVER
A. Extractor screw B. Body C. Split ring
(Service Tool 960604)




Figure 44.
TIMING GEAR MARKINGS

- A. Crankshaft gear
- B. Intermediate gear
- C. Camshaft gear
- D. Injector pump drive gear

Before replacing timing cover, check that gear marks are all correctly aligned and the crankshaft oil flinger, if originally fitted, is replaced. When the face width of crankshaft gear was increased to 1 in. (25.4 mm) the fitting of an oil flinger was discontinued.

Lever the oil seal out of timing case and carefully press in a new seal. Position the seal so that the seal lip points towards inside of case and take care not to distort the seal. Use Service Tools 901700 and 900211.

Fit timing cover in position, using a new gasket, and after screwing the bolts loosely into position fit crankshaft pulley. This will position oil seal centrally over pulley land before the bolts are tightened. Replace crankshaft pulley washer and nut. Refit dynamo and replace fan belt.

Valve Mechanism

The camshaft is fitted from the front of the cylinder block and is retained in position by means of the locating plate behind the gear. As the tappets will fall and jam against the shaft journals when the shaft is moved forward it is necessary to invert the cylinder block or, if the engine is *in situ*, to hold the tappets up with 'O' rings, or spring clips, when removing the shaft. The shaft bearings are pressure fed from the oil gallery and the journals run directly in the cylinder block, the rear journal being drilled to supply a reduced flow of oil to the valve rocker shaft.

High-lift camshaft, Part No. 914673, is fitted to all engines from Nos. A/60390 and B/40725 and may be identified by the part number cast on the shaft between No. 1 cylinder cam lobes. When fitting a new camshaft ensure that this is the same number as originally fitted. A 902050 shaft must not be replaced by a 914673 shaft unless later type pistons (915308) are also fitted, otherwise the valve heads may foul the pistons.

To Rebush Valve Rockers

Remove rocker shaft assembly and place on the bench. Unscrew the brass plugs from the ends of shaft and remove springs, rockers and shaft brackets, placing them in order on the bench.

Press out worn bush and fit new bush, ensuring that oil-hole is opposite hole in rocker. Hone or ream the bush until rocker is free to slide on the shaft.

If rocker end faces are worn, lightly skim on a smooth grindstone, taking care to maintain the original profile. Do not remove more metal than necessary: grind only until the wear mark is almost, but not fully, removed.

Assemble rockers, springs and brackets on to shaft. Fit locating screw into rear bracket, noting that the shaft is positioned with oil-feed holes towards the bottom, then peen the bracket over screw-hole to retain the screw.

Engine Removal

On twelve-speed tractors the engine cannot be lifted out of the frame and the tractor must, therefore, first be "split" so that the clutch is clear of the driveshaft.

On six-speed gearboxes the engine can be lifted from main frame if the muff coupling can be slid far enough forward on clutch driveshaft to clear the gearbox. This is possible on all tractors fitted with the friction-pad type clutch stop and on tractors fitted with the band-type clutch stop from Serial No. 487807. Commencing at this number the width of the clutch-stop drum was reduced to allow sufficient clearance for sliding the muff coupling forward on the driveshaft, but on Livedrive tractors from Nos. 479539 to 487806 the width of the clutch-stop drum prevents the muff coupling from sliding far enough forward to clear the gearbox.




Figure 45. ENGINE LIFTING BRACKET

Nut and distance piece to be welded to stud allowing $\frac{1}{8}$ in. (0.158 cm) clearance between nut and angle bracket

A. 6 in. (15.24 cm)	B. $5\frac{1}{8}$ in. (12.86 cm)	C. 4 in. (10.16 cm)	D. $3\frac{1}{8}$ in. (9.366 cm)
E. $2\frac{1}{2}$ in. (6.350 cm)	F. 2 in. (5.080 cm)	G. $1\frac{1}{2}$ in. (4.445 cm)	H. $1\frac{1}{2}$ in. (3.810 cm)
J. 1 in. (2.54 cm)	K. $\frac{7}{8}$ in. (2.222 cm)	L. $\frac{5}{8}$ in. (1.587 cm)	M. $\frac{1}{8}$ in. (1.428 cm)
	N. $\frac{3}{8}$ in. (0.952 cm)		

Engine removal procedures may be summarised as follows:

Non-Livedrive Models

All numbers — Lift engine (Method 'A').

Livedrive Models — Six-Speed

Nos. 440001 to 479538 — Lift engine (Method 'A').

Nos. 479539 to 487806 — "Split" tractor (Method 'B').

Nos. 487807 onward — Lift engine (Method 'A').

Livedrive Models — Twelve-Speed

All numbers — "Split" tractor (Method 'B').




Figure 46. TRACTOR WITH ENGINE REMOVED

A. Muff coupling B. Support snout C. Engine oil pump

Engine Removal — Method 'A'

Remove pre-cleaner, silencer and bonnet. Disconnect battery terminals and main lead to starter. Drain radiator and cylinder block, disconnect hoses and remove radiator. Disconnect throttle and stop-control linkage from injection pump. Remove the fuel pipe from tank to fuel feed pump and remove the short pipe connecting the leak-off to tank.

Disconnect the wiring and tractormeter cable. Remove fuel-tank mounting nuts and remove tank complete with instrument panel.

Remove steering drop-arm from its shaft and remove the steering-box, complete with column and wheel. This will expose the clutch-housing bolts inside the steering-box and enable gearbox cover and clutch housing to be removed.

On Livedrive tractors it is necessary to drain the transmission oil and remove the power take-off unit so that the cardan shaft can be withdrawn clear of clutch driveshaft.

If the tractor is fitted with a band-type clutch-stop remove the pins from each end of the band so that the band can be removed. Release the circlips on clutch driveshaft so that the drum and muff coupling can be slid far enough forward on the shaft to clear the gearbox.

If the tractor is not fitted with a band-type clutch-stop, release the circlip at the front of the muff coupling and slide the coupling fully forwards.

Remove the three bolts attaching the support snout to the axle case and remove the clutch-stop bracket, if fitted. Remove the two figure-of-eight spring clips from clutch fork so that the release bearing can be lifted clear of the fork.

Remove the cylinder-block-to-main-frame bolts (four of these are long bolts fitted from the underside of the main frame) and remove valve rocker cover. Fit a lifting bar (Fig. 45) on to the two cylinder-head lifting nuts, or place suitable slings round the engine, and lift the engine complete with clutch and clutch driveshaft vertically out of the frame. Ensure that the support snout is lifted clear of frame and lift the engine carefully until oil pump is clear of frame.

Replace engine in the reverse order to removal, using new gaskets and seals. Clean main frame and cylinder block faces, ensuring that all traces of the old gasket are removed. Smear main frame face with jointing compound, also both sides of the gaskets before placing them in position. A rubberised jointing compound such as Hylomar (962184) should be used. Fit new bearing-cap seals, pushing ends of seals into holes in block so that seals fit closely in bearing cap grooves.

Two $\frac{3}{8}$ UNC studs temporarily screwed into main frame at opposite points will assist in locating the engine and allow it to be lowered into position without disturbing the gaskets. Note that the clutch shaft is inserted in the clutch, and the support snout and muff coupling are in position on the shaft, before lowering the engine into position.




Figure 47. TRACTOR SPLIT FOR ENGINE REMOVAL

When refitting the steering drop-arm on to its shaft ensure that it is fitted on its correct spline, otherwise the steering lock will be restricted on one side. Shafts and arms are marked during assembly and should be refitted so that the centre-punch mark on the arm is opposite the mark on the end of the shaft.

Engine Removal — Method 'B'

As the two halves of the tractor are heavy and require to be maintained in alignment during assembly, this operation should be carried out with the tractor standing on firm and reasonably level ground.

Place a trolley-jack under rear of tractor so that it can support the rear half of tractor when the main

frame is "split". Place the jack-pad immediately behind the clutch-pit cover and raise the jack so that it takes weight but does not lift the frame. Drive wooden wedges between each side of the front extension and axle beam so that the engine unit will remain upright when it is not attached to the rear half of tractor. The wedges should be of hard wood and approximately 5 in. (12 cm) long so that they can be driven firmly into position without any possibility of becoming dislodged. Chock the front wheels so that they cannot move either way and place a jack under the front main frame positioned just in front of the rear flange. Extend the jack so that it takes weight but does not lift the frame.

Remove the bonnet and drain radiator and cylinder block. Disconnect throttle and stop-control linkage. Disconnect instrument panel and wiring and tractor-meter cable.




Figure 48. CLUTCH PLATE PILOT

A. 0.874 in. (22.20 mm)

B. 0.915 in. (23.24 mm)

C. 1.420 in. (36.07 mm)

D. 1.771 in. (44.98 mm)

E. $\frac{1}{8}$ in. (15.88 mm)

F. $1\frac{1}{2}$ in. (38.10 mm)

G. $1\frac{1}{2}$ in. (44.45 mm)

H. 5 in. (127 mm)

Remove fuel pipe from tank to feed pump and remove the pipe connecting the leak-off to tank.

Remove steering drop-arm from its shaft. Remove starter and remove bolts attaching the main frame and clutch housing to front half of tractor. Using the two jacks to support the two halves of frame in alignment, draw the rear half away until PTO cardan shaft is clear of the clutch.

Having separated the two halves of tractor, remove the radiator and the cylinder-block-to-main-frame bolts — four of which are on the underside of the main frame. Attach a lifting bar (Fig. 45) to the two cylinder head lifting nuts, or place suitable slings round the engine, and lift the engine vertically until the oil pump is clear of the frame.

Replace engine in reverse order of removal, using new gaskets and seals. Clean main frame and cylinder block faces, ensuring that all traces of the old gasket are removed. Smear main frame face and both sides of the gaskets with jointing compound before placing the gaskets in position. A

rubberised jointing compound such as Hylomar (962184) may be used. Fit new bearing-cap seals, pushing ends of seals into holes in cylinder block so that seals fit closely in bearing-cap grooves.

Two $\frac{3}{8}$ UNC studs temporarily screwed into main frame at opposite points will assist in locating the engine and allow it to be lowered into position without disturbing the gaskets.

If the clutch assembly has been removed from flywheel it will be necessary for the clutch plates to be centralised so that the clutch shafts can be entered. When fitting clutch assembly on to flywheel a pilot shaft (Fig. 48) should be used to hold the plates central until the cover bolts are fully tightened.

When refitting the steering drop-arm on to its shaft ensure that this is on the correct spline, otherwise the steering lock will be restricted on one side. Shafts and arms are marked during assembly and should be refitted so that the centre-punch mark on the arm is opposite the mark on end of the shaft.

DIMENSIONAL DATA

Torque Figures

Big-end bearing nuts	50 lb ft	6.92 kg metres
Breather filter cover nut	10 lb ft	1.38 kg metres
Camshaft gear bolt	40 lb ft	5.53 kg metres
Cylinder head nuts and bolts	90 lb ft	12.4 kg metres
Cylinder head studs into block	35 lb ft	4.84 kg metres
Flywheel housing to engine bolts	30 lb ft	4.14 kg metres
Flywheel nuts	50 lb ft	6.92 kg metres
Front extension to main frame bolts	50 lb ft	6.92 kg metres

Fuel Injection Pump:

Automatic retard fixing bolt	120 lb in	1.38 kg metres
Governor housing nuts (Permanite gasket)	40 lb in	0.46 kg metres
Governor housing nuts (cork gasket)	30 lb in	0.35 kg metres
Head-side fixing bolts	170 lb in	1.96 kg metres
Inspection cover nuts	30 lb in	0.35 kg metres
Inspection pipe banjo bolts	270 lb in	3.11 kg metres
Manual lock fixing bolt	350 lb in	4.02 kg metres
Throttle and stop lever nuts	30 lb in	0.35 kg metres

Main bearing cap bolts	140 lb ft	19.3 kg metres
Main frame to engine bolts	30 lb ft	4.14 kg metres
Main frame to flywheel housing bolts	50 lb ft	6.92 kg metres
Oil filter bowl bolt	10 lb ft	1.38 kg metres
Sump to main frame bolts	20 lb ft	2.76 kg metres
Valve rocker adjusting nuts	14 lb ft	1.94 kg metres

The following figures apply to bolts of standard material with either coarse (UNC) or fine (UNF) threads and may be used for all bolts and nuts not listed in the previous table.

Thread Diameter	Torque
$\frac{1}{4}$ in ..	7 lb ft 0.97 kg metres
$\frac{5}{16}$ in ..	15 lb ft 2.07 kg metres
$\frac{3}{8}$ in ..	25 lb ft 3.46 kg metres
$\frac{7}{16}$ in ..	45 lb ft 6.22 kg metres
$\frac{1}{2}$ in ..	65 lb ft 8.98 kg metres
$\frac{9}{16}$ in ..	110 lb ft 15.2 kg metres
$\frac{5}{8}$ in ..	140 lb ft 19.3 kg metres

Capacities

Cooling system	3 gal	12.6 litres
Engine lubricating oil	13 pints	7.4 litres
Steering-box oil	2 pints	1.1 litres
Air cleaner oil bath	1½ pints	0.7 litres
Fuel tank	13½ gal	61.4 litres

Wear Limits

The following figures are only intended to serve as a guide to determine when a component should be renewed:

Crankshaft big-end journals should be reground if ovality exceeds 0.005 in. (0.127 mm).

Crankshaft main-bearing journals should be reground if wear exceeds 0.005 in. (0.127 mm).

Piston rings should be replaced if the ring gap exceeds 0.060 in. (1.524 mm) when checked in the unworn part of the cylinder.

When there is evidence of ring and slight bore wear causing oil consumption, fit oil control rings. These should control oil consumption if the bore wear is not greater than 0.010 in. (0.25 mm) and are available to suit either standard or oversize bores. If oil consumption exists and oil control rings have already been fitted it will be necessary to renew the cylinder liners and pistons.

Piston groove clearance should not exceed 0.010 in. (0.25 mm) when checked with a new ring.

Oversize valves should be fitted if the bore in the cylinder head is worn in excess of 0.006 in. (0.15 mm). For details of oversize reamers and seat cutter pilots see Service Tool Leaflet A28.

Piston Dimensions (new)

Nominal diameter	3 $\frac{5}{8}$ in	92.075 mm
Piston skirt diameter (at right-angles to gudgeon pin bore)	3.619 — 3.618 in	91.93 — 91.91 mm
Piston weight variation (maximum in one set)	$\frac{1}{2}$ oz	14 gm
Piston ring side clearance	0.002 — 0.0035 in	0.050 — 0.088 mm
Piston ring gap	0.010 — 0.015 in	0.254 — 0.374 mm
Gudgeon pin diameter	1.2503 — 1.250 in	31.757 — 31.750 mm
(Push-fit in connecting rod bush, light-drive fit in piston)		

Sleeve Dimensions (new)

Bore	3.655 — 3.6250 in	92.088 — 92.076 mm
Taper (maximum)	0.0005 in	0.0127 mm
Ovality (maximum)	0.0005 in	0.0127 mm
Protrusion (excluding ridge)	0.002 — 0.005 in	0.0508 — 0.127 mm

Valve Clearance (set cold)

Inlet {to AD4/47A 60389 }	0.015 in	0.35 mm
Exhaust {and AD4/47B 40724 }	0.012 in	0.30 mm
Inlet {from AD4/47A 60390 }	0.010 in	0.25 mm
Exhaust {and AD4/47B 40725 }	0.007 in	0.18 mm

Valve Springs (inlet and exhaust)

Free length	1.970 in	5.0 cm
Length at 40 lb load	1.530 in	
Length at 80 lb load	1.102 in	
Length at 15 kg load		4.08 cm
Length at 30 kg load		3.15 cm

Valve Stem Diameters (inlet and exhaust)

Standard	0.3732 — 0.3722 in	9.479 — 9.454 mm
Oversize 0.010 in. (0.007 mm)	0.3832 — 0.3822 in	9.733 — 9.708 mm
Oversize 0.020 in. (0.014 mm)	0.3932 — 0.3922 in	9.987 — 9.962 mm
Valve seat angle	45°	45°
Valve guide bore	0.375 — 0.374 in	9.525 — 9.499 mm
Valve tappet diameter	0.624 — 0.623 in	15.850 — 15.824 mm

Valve Timing

Inlet opens	8° before top dead centre
Inlet closes	38° after bottom dead centre
Exhaust opens	36° before bottom dead centre
Exhaust closes	10° after top dead centre

8° Inlet opens

10° Exhaust closes

38° Inlet closes

36° Exhaust opens




Figure 49. VALVE TIMING DIAGRAM

Fuel System

Injector setting pressure 175 atmospheres (1810 kg/cm²)

Spill timing (static) 11° before top dead centre

Spill timing mark: Pump flange and engine mounting flange are marked, and correct pump timing is obtained when these marks are in alignment.

Spill timing adjustment: Elongated holes in the injection pump mounting flange permit the pump body to be rotated when the three securing nuts are released.

Injection Pump Flange Mounting

AD4/47 69½° from blank spline when at point of injection

Injection Pump Fuel Setting

AD4/47 10.4 — 10.6 cc per 200 shots at 850 rev/min

Injector Nozzle Hole Diameter

AD4/47 0.28 — 0.30 mm

Injection Pump and Injectors

Pumps		Injectors		
DB No.	CAV No.	DB No.	Holder	Nozzle
906899	3243090	904442	BKBL 97S5152	BDLL 140S6276
909458	3243860			
910521	3243960	910530	BKBL 97S5152	BDLL 140S6417
910521	3248260			
918912	3248680			

Oil Pump

Spindle diameter	0.4895 — 0.490 in	12.43 — 12.45 mm
Spindle bush bore	0.4905 — 0.4925 in	12.45 — 12.509 mm
Rotor width	1.1865 — 1.1855 in	30.137 — 30.112 mm
Housing depth	1.1890 — 1.1875 in	30.191 — 30.162 mm
End float	0.001 — 0.0035 in	0.025 — 0.088 mm
Pump rotor backlash	0.020 — 0.026 in	0.511 — 0.66 mm

Crankshaft

Main journal diameter

Standard size	2.4995 — 2.4990 in	63.487 — 63.474 mm
Undersize 0.010 in. (0.254 mm)	2.4895 — 2.4890 in	63.233 — 63.220 mm
Undersize 0.020 in. (0.508 mm)	2.4795 — 2.4790 in	62.979 — 62.966 mm
Undersize 0.030 in. (0.762 mm)	2.4695 — 2.4690 in	62.725 — 62.712 mm




Figure 50. CRANKSHAFT DIMENSIONS

- A. Main journal diameters
- B. Big end journal diameter
- C. Centre journal width
- D. Fillet radius

When regrounding crankshaft it is important that the original bearing fillet radius is maintained. It is also important that the surface of the radius is as smooth as the surface of the journal and that the radius is smoothly blended into both surfaces. A fillet that is incorrectly radiused, roughly finished or not smoothly blended, weakens a shaft and may cause fatigue failure during service.

Big-end journal diameter

Standard size	2.2485 — 2.2480 in	57.111 — 57.099 mm
Undersize 0.010 in.	2.2385 — 2.2380 in	56.848 — 56.845 mm
Undersize 0.020 in.	2.2285 — 2.2280 in	56.604 — 56.591 mm
Undersize 0.030 in.	2.2185 — 2.2180 in	56.350 — 56.337 mm

Centre journal width

Standard size	2.126 — 2.124 in	54.00 — 53.95 mm
Oversize 0.010 in.	2.136 — 2.134 in	54.254 — 54.204 mm
Oversize 0.040 in.	2.176 — 2.174 in	55.270 — 55.220 mm

Bearing fillet radius	0.16 — 0.15 in	4.06 — 3.81 mm
Big-end bearing clearance	0.0015 — 0.0025 in	0.038 — 0.063 mm
Main bearing clearance	0.002 — 0.004 in	0.051 — 0.102 mm
End-float of crankshaft	0.002 — 0.010 in	0.051 — 0.258 mm

Thrust Washer thickness

Standard	0.091 — 0.093 in	2.3114 — 2.3622 mm
Oversize 0.005 in. (0.127 mm)	0.096 — 0.098 in	2.4384 — 2.4892 mm
Oversize 0.020 in. (0.508 mm)	0.111 — 0.113 in	2.8194 — 2.8702 mm

Connecting Rod Alignment

Maximum out of parallel	0.001 in/in	0.01 mm/cm
Maximum twist	0.001 in/in	0.01 mm/cm
Maximum weight variation in set of three rods	0.25 oz	7.1 gm

Rocker Shaft

Diameter	0.748 — 0.749 in	18.99 — 19.02 mm
Bush bore reamed in position ..	0.7500 — 0.7505 in	19.05 — 19.06 mm

Compression Pressures

Average pressure obtained when the engine is cranked, by means of the starter motor, with all injectors removed and at an ambient temperature of 20°C (68°F).

Cranking Speed rev/min	Pressure	
	lb/in ²	kg/cm ²
150	380 — 400	26.6 — 28.0
250	415 — 435	29.0 — 30.5

Camshaft Journal Diameters

Front	1.872 — 1.870 in	47.55 — 47.50 mm
No. 2	1.827 — 1.825 in	46.41 — 46.35 mm
Nos. 3 and 4	1.811 — 1.810 in	46.00 — 45.97 mm
No. 5	1.765 — 1.763 in	44.83 — 44.78 mm
No. 6	1.749 — 1.747 in	44.42 — 44.37 mm
Camshaft thrust washer thickness ..	0.245 — 0.240 in	6.223 — 6.096 mm
Camshaft end-float	0.010 — 0.020 in	0.254 — 0.508 mm

SUMMARY OF DESIGN CHANGES

Details of change	When introduced
Across-flats dimension of crankshaft nut reduced from 1.670–1.658 in. (42.42–42.11 mm) to 1.500–1.488 in. (38.10–37.80 mm). Part No. 623300 unchanged.	AD4/47A/32776 AD4/47B/31181 (July 1962)
Exhaust valve spring (907895) also fitted on inlet valve. The previous inlet-valve spring (905215), which is marked with red paint, is weaker than the 907895 spring and should not be used for replacements.	AD4/47A/31773 AD4/47B/32002 (July 1962)
Length of thread on injection-pump coupling bolts reduced to $\frac{1}{2}$ in. (12.5 mm). Part No. of bolts, 600353, unchanged.	AD4/47A/34476 AD4/47B/31901 (July 1962)
Changes to reduce amount of oil leakage down valve guides. Rocker shaft oil-holes reduced. Part No. of shaft changed from 904192 to 909622, and 30° chamfer machined at top of exhaust valve stem bore.	AD4/47A/34932 AD4/47B/32082 (August 1962)
Position of injection cut-off lever turned through 180° and control rod changed so that operation of engine control stop is reversed, i.e., the engine being stopped when the control is in the forward position. Part No. of pump unchanged but Part No. of stop control rod changed from 908221 to 908524.	AD4/47A/34065 AD4/47B/31734 (September 1962)
Injection pump changed from 906899 (CAV 3243090) to 909458 (CAV 3243860). As the new pump has a slightly different internal timing the pump drive gear marking has been retarded one tooth. Part No. of gear changed from 902006 to 909457. Pumps and gears are interchangeable if the gears are meshed one tooth advanced, or retarded, in order to obtain the correct timing.	AD4/47A/35277 AD4/47B/32248 (September 1962)
Drain-hole drilled in water pump body (902029) to prevent any water which leaks past the gland seal from damaging the bearing and provide a visible indication that the seal is leaking.	AD4/47A/32074 AD4/47B/30917 (January 1963)
Dynamo 35521 (Lucas C39-2) replaced by dynamo 908882 (Lucas C40A). The new dynamo, which is fitted with Lucar connectors, is interchangeable with the previous dynamo if suitable connectors are used.	AD4/47A/36228 AD4/47B/32834 (January 1963)
Fitting of injection pump 909458 (CAV 3243860) discontinued and 906899 (CAV 3243090) re-introduced. Pump drive gear 909457 also changed back to previous gear 902006.	AD4/47A/36230 AD4/47B/32832 (January 1963)
Crankshaft breather changed so that overtightening the nut does not compress the breather element and cause pressure build-up in the crankcase. Parts not interchangeable unless fitted complete.	AD4/47A/37593 AD4/47B/33527 (February 1963)
Injection pump 906899 (CAV 3243090) changed to 910521 (CAV 3243960) and injectors changed from 904442 to 910530.	AD4/47A/43672 AD4/47B/36677 (January 1964)
Timing gear cover changed from cast iron to pressed steel. Part No. of cover changed from 904056 to 910057. Covers interchangeable if the appropriate bolts are used.	AD4/47A/44311 AD4/47B/37572 (July 1964)
Distance piece, Part No. 912812, fitted between water-pump pulley (900476) and fan in order to comply with U.K. safety requirements.	AD4/47A/46417 AD4/47B/37384 (July 1964)

Details of change**When introduced**

Oil flinger, Part No. 913369, fitted between the crankshaft gear and pulley.

AD4/47A/46481
AD4/47B/37378
(July 1964)

Gasket, Part No. 914404, fitted between crankshaft oil retainer and cylinder block.

AD4/47A/49989
AD4/47B/37876
(September 1964)

Two $\frac{7}{8}$ in. (7.8 mm) diameter holes drilled through rear main-bearing cap to assist oil drainage into sump when operating on severe gradients.

AD4/47A/51137
AD4/47B/38316
(October 1964)

Length of water-pump pulley-hub increased to make the fitting of distance piece (912812) unnecessary. Part No. of pulley changed from 900476 to 914335.

AD4/47A/57582
AD4/47B/40057
(October 1964)

Injection pump changed from CAV 3243960 to CAV 3248260. Part No. of pump, 910521, unchanged.

(November 1964)

Water pump pulley, Part No. 914335, changed back to 900476. Distance piece 912812 re-introduced on U.K. tractors only.

AD4/47A/60986
AD4/47B/40825
(November 1965)

Camshaft, Part No. 902050, replaced by camshaft 914673, which has higher lift inlet cams. To accommodate the increased valve opening the valve recess in the pistons has been made deeper, the valve heads slightly thinner, and stronger valve springs fitted. With the exception of the camshaft, which must not be fitted unless the other parts are also fitted, the new parts may be used as replacements for earlier engines. The introduction of this change has required a reduction in valve clearances to inlet — 0.010 in. (0.25 mm) — and exhaust — 0.007 in. (0.18 mm).

AD4/47A/60390
AD4/47B/40725
(November 1965)

Retaining plate, Part No. 919660, fitted on fan bolts and bolt-holes in fan blade repositioned, to prevent any possibility of blade fracture.

AD4/47A/68495
AD4/47B/41696
(October 1966)

Face width of crankshaft gear (901989) and intermediate gear (904074) increased to 1 in. (25.4 mm). Part No. of gears changed to 917898 and 917904 respectively. Fitting of a crankshaft oil flinger discontinued.

AD4/47A/69515
AD4/47B/41792
(September 1966)

Injection pump 918912 (CAV 3248680), with direct mounted gear used as an alternative pump to quill-shaft driven pump 910521 (CAV 3248260) on a number of tractors not fitted with power-assisted steering.

AD4/47A/69515 and
AD4/47B/41792 to
AD4/47A/71241 and
AD4/47B/42115
(November 1966)

Tappet cover studs (608206) changed to bolts (600408) and material of tappet cover gaskets (10030) changed from cork/aluminium to cork only.

AD4/47A/71160
AD4/47B/42116
(December 1966)

Material of cylinder head gasket (902040) changed from copper and asbestos sandwich to graphite-surfaced asbestos. Part No. of gasket unchanged. Wellseal should not be used when fitting gaskets of the later material.

AD4/47A/74181
AD4/47B/42612
(January 1967)

Cap nut, Part No. 607516, fitted on the oil pump locating screw (900748) in place of the locknut (607053) fitted previously.

AD4/47A/76496
AD4/47B/42941
(April 1967)

APPROVED LUBRICANTS AND TEST OILS

Classification and Grading of Engine Oils

Several different classifications of engine crankcase oils are in use throughout the world, and therefore the following notes have been compiled to explain the grades and classifications used in the table on Page 42.

Principally there are two important aspects to be taken into consideration when selecting the correct grade of lubricating oil. First is viscosity, which is its body or thickness. Secondly its additive content which determines detergency, control of deposits, resistance to oxidation, film strength and resistance to scuffing.

Viscosity is specified by the SAE number of the oil. The additive content by the A.P.I. classification, or reference to the U.S. Military Service Specification Series MIL-L-2104 or its British equivalent, DEF 2101 Series, from which come the references to Supplement I, Supplement I Endorsement and Series III.

S.A.E. Viscosity Grading (Society of Automotive Engineers)

The Society of Automotive Engineers grades engine oils by viscosity using a system of SAE grade numbers.

Viscosity numbers with an additional symbol "W" are based on viscosity measured at 0°F. Viscosity numbers without a symbol are based on viscosity measured at 210°F.

Note that the SAE grade numbers of gear oils cannot be directly compared with the equivalent grade numbers of an engine oil, i.e. an SAE 80G gear oil may have similar viscosity characteristics to an SAE 20/30 engine oil, or an SAE 90G gear oil may have similar viscosity characteristics to an SAE 40/50 engine oil. Grade numbers of engine oils range from SAE5 to SAE50. To minimise the possibility of confusion, grade numbers of gear oils include the symbol "G" and range from SAE75G to SAE250G.

A.P.I. Classification (American Petroleum Institute)

A system of standards has been evolved to classify the performance characteristics of crankcase oil in accordance with the severity of service for which it is recommended.

Note: A revised system of classification was introduced by the American Petroleum Institute's division of marketing in Autumn 1970. The new A.P.I. system describes in non-technical language, operating conditions for which (to start with) eight different types of lubricating oil are suitable. The system is devised so that new classifications may be added should they be required.

The old classifications will obviously still be quoted in existing literature which can be in use for some time, therefore both systems are quoted below.

Definitions of Service Classifications (Old)

(a). Service DG — Moderate Conditions — Diesel

Service typical of Diesel Engines in any operation where there are no severe requirements for wear or deposit control due to fuel lubricating oil or to engine design characteristics.

Related load, continuous output, or intermittent operation under normal atmospheric temperature conditions can be considered as normal service requirements for Service DG in the absence of any special design features tending to increase service severity or sensitivity to high sulphur fuels. The lubrication requirements for Service DG are less severe than for Service DM.

(b). Service DM — Severe Conditions — Diesel

Service typical of Diesel Engines operating under severe conditions or using fuel of a type normally tending to promote deposits and wear, but where there are design characteristics or operating conditions which may make the engine either less sensitive to fuel effects or more sensitive to residues from lubricating oil.

Under this service classification, the factors of operating conditions, fuel character, especially sulphur content, and design features combine in various ways to make the service and hence the lubrication requirements less severe than for Service DS. Some designs are critical with respect to lubricating oil residues; for these designs some oils suitable for Service DS are not satisfactory.

Footnote: The characteristics of oil in this rating are similar to Supplement 1 oils I.C.E.I. (Internal Combustion Engine Institute) rating.

(c). Service DS — Extreme Conditions — Diesel

Service typical of Diesel Engines operating under very severe conditions, or having design characteristics, or using fuel tending to produce excessive wear or deposits.

The service requirements in this classification are the most severe encountered in the operation of diesel engines. High-load operation at high temperatures, design factors, especially super-charging or engine installation details causing unusually high temperatures within the engine, constitute severe service, as does intermittent operation at low temperatures, since both promote wear and deposit formation. Cooling system and crankcase ventilating system design, also exhaust line arrangement, can aggravate or minimise the severity in either case. The use of high-sulphur content fuels increases service severity with respect to wear and deposits, depending upon design, maintenance and operating conditions. Hence, frequently their use is considered to constitute severe service, especially in low temperature operation.

Note: The characteristics of oil in this rating are similar to Supplement 3 I.C.E.I. rating or Series 3 "Caterpillar rating" oil.

(d). Service ML — Least Severe Conditions — Petrol

Service typical of Gasoline and other Spark Ignition Engines used under light and favourable operating conditions, the engines having no special lubrication requirements and having no design characteristic sensitive to deposit formation.

This is the least severe condition. It includes moderate speed driving or moderate load operation most of the time, with no severe low or high engine temperature operation. It also includes operation of engines insensitive to sludge, deposit formation, bearing corrosion, wear or fuel characteristics.

(e). Service MM — Moderate Conditions — Petrol

Service typical of Gasoline and other Spark Ignition Engines used under moderate to severe operating conditions, but presenting problems of deposit or bearing corrosion control when crankcase oil temperatures are high.

This is a more moderate service requirement than Service MS. Vehicles powered by engines which are relatively insensitive to deposit formation or wear when operated at high speeds or under heavy loads are included in this service, particularly when using fuels of suitable characteristics. It does not include extensive operation under the severe type of low engine temperature service such as start-and-stop driving or prolonged idling described under Service MS.

(f). Service MS — Severe Conditions — Petrol

Service typical of Gasoline and other Spark Ignition Engines used under unfavourable or severe types of operating conditions, and where there are special lubrication requirements for deposit, wear or bearing corrosion control, due to operating conditions or to engine design or fuel characteristics.

This class of oil also covers operation in extremes of temperature, stop/start or prolonged idling conditions and the resulting crankcase condensation and dilution which causes the formation of sludge, being taken into consideration.

Definitions of Service Classifications (New)

The eight types of oil are separated into two groups:—

"S" series for passenger cars and light trucks.

"C" series for heavier vehicles, farm equipment and stationary plants.

The eight classes are:—

SA — for utility gasoline and diesel engine service. Service typical of engines operated under such mild conditions that the protection afforded by compounded oil is not required. This classification has no performance requirements.

SB — for minimum duty gasoline engine service. Service typical of engines operated under such mild conditions that only minimum protection afforded by compounding is desired. Oils designed for this service provide only anti-scuff capability and resistance to oil oxidation and bearing corrosion.

SC — for 1964 gasoline engine warranty service. Service typical of gasoline engines in 1964–1967 car and truck models operating under engine manufacturers' warranties. Oils designed for this service provide control of high and low temperature deposits, wear, rust and corrosion in gasoline engines.

SD — for 1968 gasoline engine warranty service. Service typical of gasoline engines in cars and trucks beginning with 1968 models and operating under engine manufacturers' warranties. Oils designed for this service provide more protection from high and low temperature engine deposits, wear, rust and corrosion in gasoline engines than SC oils.

CA — for light duty diesel engine service. Service typical of diesel engines operated in mild to moderate duty with high quality fuels. Occasionally has included gasoline engines in mild service. These oils provide protection from bearing corrosion and from high temperature deposits in normally aspirated diesel engines when using fuels of such quality that they impose no unusual requirements for wear and deposit protection.

CB — for moderate duty diesel engine service. Service typical of diesel engines operated in mild to moderate duty, but with lower quality fuels which necessitate more protection from wear and deposits. Occasionally has included gasoline engines in mild service. Oils designed for this service were introduced in 1949. Such oils provide necessary protection from bearing corrosion and from high temperature deposits in normally aspirated diesel engines with high sulphur fuels.

CC — for moderate duty diesel and gasoline engine service. Typical of lightly supercharged diesel engines operated in moderate to severe duty and has included certain heavy-duty, gasoline engines. Oils designed for this service were introduced in 1961 and used in many trucks and in industrial and construction equipment and farm tractors. These oils provide protection from high temperature deposits in lightly supercharged diesels and also from rust, corrosion and low temperature deposits in gasoline engines.

CD — for severe duty diesel engine service. Service typical of supercharged diesel engines in high-speed, high output duty requiring highly effective control of wear and deposits. Oils designed for this service were introduced in 1955, and provide protection from bearing corrosion and from high temperature deposits in supercharged diesel engines when using fuels of a wide quality range.

APPROVED LUBRICANTS

WORLD WIDE - EXCEPT BRITISH ISLES

Lubricants

Applica- tion	A.P.I. Classn. *	Air Temp.	GRADE		AMOCO	B.P.	CASTROL	ESSO	MOBIL	SHELL
			Recomm.	Alternative						
Engine and Air Cleaner	DG, MS, DM (SA-SB/ CA-CB)	Below -7°C (20°F)	Multi- purpose 10W/30	SAE 10W	AMOCO HD - M Engine Oil 10W - 30	Tractor Oil Universal	Agricastrol Multi-use 10W/30	Esso Tractorlube Universal 10W/30	Mobiloil Special 10W/30	Rotella M Multigrade 10W/30
	DG, MS, DM (SA-SB/ CA-CB)	-7°C to 32°C (20°F to 90°F)	Multi- purpose 20W/30 or 20W/40	SAE 20W	AMOCO HD - M Engine Oil 20W - 30	Tractor Oil Universal	Agricastrol Multi-use 20W/30 or 20W/40	Esso Tractorlube Universal 20W/30	Mobiloil Special 20W/40	Rotella M Multigrade 20W/40
	DG, MS, DM (SA-SB/ CA-CB)	Above 32°C (90°F)	Multi- purpose 20W/30 or 20W/40	SAE 30						
Details of Alternative Grade Oils			SAE 10W		AMOCO HD - M Engine Oil 10W	Vanellus SAE 10W	Castrol CRI10 or Agricastrol 10	Essolube HD 10W	Mobiloil 10W or Delvac Oil 1110	Rotella S 10W
			SAE 20W		AMOCO HD - M Engine Oil 20-20W	Vanellus SAE 20W	Castrol CRI20 or Agricastrol 20	Essolube HD20	Mobiloil Arctic or Delvac Oil 1120	Rotella S 20/20W
			SAE 30		AMOCO HD - M Engine Oil 30	Vanellus SAE 30	Castrol CRI30 or Agricastrol 30	Essolube HD30	Mobiloil A or Delvac Oil 1130	Rotella S30

Engine oil: Under normal operating conditions the engine oils should be marked with viscosity grade and API classification as shown in the above table. Oils marked with service classification DM (CB) are recommended when one or more of the following conditions is present:—abnormally high operating temperatures, intermittent operation at low temperatures or fuel contains more than 1% sulphur. Service DS (Series 3) (CC-CD) oil is not listed as it has super-detergent qualities which are not considered essential for D.B. tractor engines operating in normal field conditions.

Air cleaner: All M and D (SA-SB) classifications with the exception of DS are recommended for use in oil-washed air cleaners fitted to D.B. tractors. DS (CC-CD) is not recommended due to its frothing characteristics. Where possible a straight mineral oil should be used as an alternative to engine oil to avoid frothing.

**New Classifications shown in brackets.*

Fuel, Grease and Anti-Freeze

Diesel fuel: For temperature above 0°C (32°F) use No. 2D fuel (ASTMD 975) with a minimum cetane rating of 45.

For temperature below 0°C (32°F) use No. 1D fuel (ASTMD 975) with a minimum cetane rating of 50.

Note: For low temperature operation a fuel with a pour point 6°C (10°F) below lowest starting temperature should be specified. Fuels with not more than 0.5% by weight sulphur should be used when available. A high sulphur content fuel requires an engine lubricating oil with high detergent characteristics to prevent carbon build up in the nozzles and combustion chambers and to neutralise the acid created by sulphur.

Greasing points: A good quality multi-purpose grease should be applied to all grease fittings (except water pump which requires a high-melting-point grease applied sparingly every 500 hours). High-melting-point grease may be used for all fittings except those which require oil.

Anti-freeze solutions for engine coolant: Use only a brand formulated for use in diesel engines to British Standard 3151 (1959) type B (or equivalent) which specifies a corrosion inhibited ethanediol anti-freeze. (Sodium benzoate and sodium nitrite inhibited.)

BRITISH ISLES

Lubricants

APPLICATION	GRADE		AMOCO	B.P.	CASTROL	ESSO	MOBIL	SHELL
	Recommended	Alternative						
Engine & Air Cleaner	Multi-purpose Oil	20/20W	AMOCO 100 Engine Oil 20W-30 or Vitamatic Engine Oil 20W-30	Tractor Oil Universal	Agricastrol Multi-use	Esso Tractorlube (Universal)	Mobiland Universal	Tractor Oil Universal
Alternative Grade Oils	20/20W		AMOCO 200 Engine Oil 20-20W	Energol DD 20W	Castrol CR120 or Agricastrol 20	Essolube HD20	Mobiloil Arctic or Delvac Oil 1120	Rotella S 20/20W

Fuel Grease and Anti-freeze

Diesel fuel: Farm diesel fuel of high quality is recommended for use in David Brown engines. Fuels with not more than 0.5% by weight sulphur should be used when available. A high sulphur content fuel requires an engine lubricating oil with high detergent characteristics, to prevent carbon build up in the nozzles and combustion chambers, and to neutralise the acid created by sulphur.

Greasing points: A good quality multi-purpose grease should be applied to all grease fittings (except water pump which requires a high-melting-point grease applied very sparingly every 500 hours). A high-melting-point grease may be used for all fittings except those which require oil.

Anti-freeze solution for engine coolant: Use only a brand formulated for use in diesel engines to British Standard 3151 (1959) type B (or equivalent) which specifies a corrosion inhibited ethanediol anti-freeze. (Sodium benzoate and sodium nitrite inhibited.)

Fuel Injection Equipment Test Oils

New oils made from a refined mineral oil with the addition of oxidation and corrosion inhibitors have recently been introduced for use when testing fuel injection equipment.

The oils previously approved have therefore been superseded by the new oils as follows:

Previously Approved
Shell — Fusus 'A' Oil

Esso — TSD Oil 815
Wakefield — Calibration Oil 8327

New Recommendation
Shell Calibration Fluid 'C' (obtainable in the U.K.)
Shell Calibration Fluid 'B' (obtainable overseas)
Esso — Calibration Fluid IL/1838
Castrol — Calibration Oil 'C'

Note: As Shell Fusus 'A' Oil does not now include a viscosity control but will still be available for other industries, e.g., for use as a burning or drying oil, it is important that Fusus 'A' Oil is not now used as a test oil.
The two Shell grades 'B' and 'C' are interchangeable.

David Brown®

Service Repair Manual

Three-Cylinder Diesel Engine

Section A2 (Pub. 9-37102) April 1979

Written In **Clear
And
Simple
English**

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case




David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made. Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual may give details of items which are not part of any specific tractor.

CONTENTS

	Page		Page
IDENTIFICATION OF THE ENGINE	1	Valve Seats	26
SAFETY SYMBOL	2	Valve Stem Bores	26
SPECIFICATIONS	3	Valve Springs	26
MAINTENANCE		Valves	27
Air Cleaner	6	Inlet Valve Seals	28
Fan Belt	6	Reconditioning the Cylinder Head	29
Oil Filter	7	Notes on Reconditioning	29
Cylinder Head Tightening	8	Valve Rockers and Shaft	35
Cylinder Head Nuts	8	Pistons	35
Valve Clearances	8	Piston Rings	36
Fuel System	9	Cylinder Bores	37
Injectors	11	Glazed Cylinder Bores	37
REPAIR		Cylinder Liners	37
Fuel Feed Pump	12	Connecting Rods	38
Injectors	13	Connecting Rod Bearings	38
Fuel Injection Pump	15	Main Bearings	38
Timing the Fuel Injection Pump	16	Crankshaft Reconditioning	38
Lubrication System	17	Crankshaft Rear Oil Seal	40
Oil Warning Lamp	17	Front Main Bearing Cap	44
Oil Pump	17	Timing Cover and Seal	45
Cooling System	20	Injection Pump Drive Housing	45
Water Pump	21	Tractormeter Drive	47
Thermostat	23	Timing Gears	47
Compression Testing	24	Camshaft	48
Cylinder Head	25	Exhaust Flange and Silencer	48
Cylinder Head Gasket	25	Removing the Engine	49
		Installing the Engine	50
		Engine Lifting Bracket	51

11



IDENTIFICATION OF THE ENGINE

There is a number on the right-hand side of the cylinder block. This number is used in the following way:

First number: Amount of cylinder.

Second and third numbers: These numbers show the capacity of ONE cylinder in cubic inches. When you multiply this amount by the first number, the result is the capacity of the engine.

Fourth number: Type of fuel used.

0 = diesel

1 = gasoline

Fifth number: Design series

0 = first series

1 = second series etc.

Sixth number: Type of clutch

1 = livedrive

2 = not livedrive

5 = twin plate

The next series of numbers are for the identification of a specific engine.

EXAMPLE:

No. 3 5 5 0 1 1/1 0 0 1

3 cylinders

55 cu in

Diesel

Design Series

Livedrive

This engine is a 3 cylinder, 165 cu.in capacity, diesel fuel, second series, livedrive model, serial number 1001.



This safety alert symbol indicates important safety messages in this manual.

When you see this symbol, carefully read the message that follows and be alert to the possibility of personal injury.

SPECIFICATIONS

TORQUES:

Connecting rod nuts	68 Nm	50 lb ft	6.9 kgm
Camshaft gear bolt	54 Nm	40 lb ft	5.5 kgm
Crankshaft balance weight bolts	54 Nm	40 lb ft	5.5 kgm
Cylinder head nuts	136 Nm	100 lb ft	13.8 kgm
Cylinder head studs	34 Nm	25 lb ft	3.5 kgm
Flywheel nuts	68 Nm	50 lb ft	7.0 kgm
Main bearing cap bolts	163 Nm	120 lb ft	16.6 kgm
Main frame to engine bolts	41 Nm	30 lb ft	4.2 kgm
Oil filter bowl bolt	14 Nm	10 lb ft	1.4 kgm
Sump to main frame bolts	27 Nm	20 lb ft	2.8 kgm
Sump to main frame bolts	27 Nm	20 lb ft	2.8 kgm
Valve rocker locking nuts	19 Nm	14 lb ft	1.9 kgm

For all other bolts and nuts with either UNC or UNF threads, use the following chart:

Thread Diameter	Torque		
$\frac{1}{4}$ in	9.5 Nm	7 lb ft	0.97 kgm
$\frac{5}{16}$ in	20 Nm	15 lb ft	2.1 kgm
$\frac{3}{8}$ in	34 Nm	25 lb ft	3.5 kgm
$\frac{7}{16}$ in	61 Nm	45 lb ft	6.2 kgm
$\frac{1}{2}$ in	88 Nm	65 lb ft	9.0 kgm
$\frac{5}{8}$ in	150 Nm	110 lb ft	15.2 kgm
$\frac{3}{4}$ in	190 Nm	140 lb ft	19.4 kgm

CAPACITIES

Cooling system	8.5 l	15 pt
Lubricating oil	6.25 l	11 pt
Air cleaner oil bath	0.7 l	1½ pt

DIMENSIONS:

Bore (see page 4)	100 mm	3 $\frac{1}{8}$ in
Stroke	114.3 mm	4½ in
No. of cylinders	3	
Total capacity	2694 cm ³	164.4 in ³
Rated speed	1800 r/min	
Maximum full load speed	2200 r/min	
Maximum no load speed	2350 r/min	
Compression ratio	17 : 1	
Firing sequence	1, 2, 3	

VALVE CLEARANCES:

The correct clearance for all valves is 0.25 mm (0.010 in) when the engine is cold.

VALVE SPRINGS:

Length:

No load	50 mm	1.970 in
40 lb load	38.8 mm	1.530 in
80 lb load	28 mm	1.102 in
15 kg load	40.8 mm	1.608 in
30 kg load	31.5 mm	1.24 in

VALVE STEMS:

Diameters:

Normal	9.479 to 9.454 mm	0.3732 to 0.3722 in
Oversize 0.25 mm (0.010 in)	9.733 to 9.708 mm	0.3832 to 0.3822 in
Oversize 0.5 mm (0.020 in)	9.987 to 9.962 mm	0.3932 to 0.3922 in

SPECIFICATION

VALVE SEAT ANGLE:

45°

VALVE TIMING:

Inlet opens	8° before top dead centre
Inlet closes	38° after bottom dead centre
Exhaust opens	36° before bottom dead centre
Exhaust closes	10° after top dead centre

INJECTORS:

Operating pressure	2573 lb in ²	180 kg cm ²	175 Atm.
New injectors or injectors with new springs	2720 lb in ²	191 kg cm ²	185 Atm.

FUEL INJECTION PUMP

Distributor Type (CAV 3233000)

The static timing is 16° before top dead centre.

The pump flange and drive housing each have a mark and the timing is correct when the two marks are in alignment.

CONNECTING ROD ALIGNMENT:

Maximum out of parallel	0.0127 mm per cm	(0.0005 in per in)
Maximum twist	0.0127 mm per cm	(0.0005 in per in)
Maximum weight difference in set of three rods	7.1 g	(0.25 oz)

ROCKER SHAFT:

Diameter	18.99 to 19.02 mm	0.748 to 0.749 in
Bushes	19.05 to 19.06 mm	0.7500 to 0.705 in

CAMSHAFT JOURNALS:

Front	60.2869 to 60.2615 mm	2.3735 to 2.3725 in
No. 2	47.5488 to 47.5158 mm	1.8720 to 1.8707 in
No. 3	46.7919 to 46.7588 mm	1.8422 to 1.8409 in
No. 4	45.6032 to 45.5676 mm	1.7954 to 1.7940 in
No. 5	44.4195 to 44.3865 mm	1.7488 to 1.7475 in
End clearance	0.05 to 0.15 mm	0.002 to 0.006 in

CRANKSHAFT

Main journal diameter

Standard size	63.487—63.474 mm	2.4995—2.4990 in
Undersize 0.254 mm (0.010 in)	63.233—63.220 mm	2.4895—2.4890 in
Undersize 0.508 mm (0.020 in)	62.979—62.966 mm	2.4795—2.4790 in
Undersize 0.762 mm (0.030 in)	62.725—62.712 mm	2.4695—2.4690 in

BORE SIZES (New) AD 3/49 and AD 3/55

Standard	100.07—100.05 mm	3.9396—3.9388 in
Oversize 0.020 in	99.81—100.55 mm	3.9596—3.9588 in
Oversize 0.040 in	101.08—101.06 mm	3.9796—3.9788 in

AD 3/40 and AD 3/30

Sleeve diameter	96.86—96.84 mm	3.8135—3.8125 in
Taper—maximum	0.0127 mm	0.0005 in
Ovality—maximum	0.0127 mm	0.0005 in
Protrusion (excluding ridge)	0.058—0.0127 mm	0.002—0.005 in

PISTONS

AD3/40, nominal diameter	96.8 mm	3 $\frac{11}{16}$ in
AD3/55, nominal diameter	100.0 mm	3 $\frac{11}{16}$ in
AD3/30, nominal diameter	96.8 mm	3 $\frac{11}{16}$ in
AD3/49, nominal diameter	100.0 mm	3 $\frac{11}{16}$ in
355011, nominal diameter	100.0 mm	3 $\frac{11}{16}$ in
AD3/40, skirt diameter	96.68—96.66 mm	3.8063—3.8055 in
AD3/55, skirt diameter	99.9—99.8 mm	3.9323—3.9315 in
AD3/30, skirt diameter	96.68—96.66 mm	3.8063—3.8055 in
AD3/49, skirt diameter	99.9—99.8 mm	3.9323—3.9315 in
355011, skirt diameter	99.9—99.8 mm	3.9323—3.9315 in
355011, skirt diameter	99.9—99.8 mm	3.9323—3.9315 in
AD3/40, height	101.6 mm	4 in
AD3/55, height	101.6 mm	4 in
AD3/30, height	114.3 mm	4 $\frac{1}{2}$ in
AD3/49, height	114.3 mm	4 $\frac{1}{2}$ in
355011, height	101.6 mm	4 in

PISTON RINGS AND GUDGEON PIN

Ring gap	0.28—0.406 mm	0.011—0.016 in
Compression ring, clearance in groove	0.057—0.078 mm	0.00225—0.00375 in
Scraper ring, clearance in groove	0.0508—0.0762 mm	0.002—0.003 in
Gudgeon pin diameter	31.750—31.745 mm	1.250—1.2495 in

(Push-fit in connecting rod bush, light-drive fit in piston)

OIL FILTER

Early Engines: Paper Element
Late Engines: Cartridge (Spin-on) Type

MAINTENANCE

AIR CLEANER

Air to the engine is first cleaned by a centrifugal filter or a paper filter element. The second part of the cleaning operation is an oil bath, and this is followed by a mesh screen.

IMPORTANT: Use only the correct grade of oil in the oil bath. If any other type of oil is used, the engine speed can get out of control and damage will be caused to the engine.

Service:

1. Remove the bowl, the screen mesh and the centrifugal filter. Clean them with fuel oil or kerosene.
2. Add new engine oil to the filter bowl up to the level shown inside the bowl.
3. Install the mesh screen, the bowl and the pre-cleaner. If a paper element is installed instead of a pre-cleaner, do the following.
4. Remove the centre bolt, the cover and the filter element.
5. Remove any dust or dirt from the element and look for damage. If there is any damage the element must be replaced.
6. Install the element, cover and centre bolt.

NOTE: A large amount of dirt in the bowl shows that the paper element is broken. An increase in the amount of black smoke from the exhaust shows that there is a restriction in the paper element.

FAN BELT:

The correct tension for the fan belt is as shown in Figure 1. To make the adjustment:

1. Loosen the bolts A and move the alternator until the tension is correct.
2. When the tension is correct, tighten the bolts.

NOTE: If you can not get the correct tension, replace the fan belt.




FIGURE 1 FAN BELT ADJUSTMENT

A. Securing Bolts




FIGURE 2 PRE-CLEANER

A. Cover B. Element C. Base




FIGURE 3 AIR CLEANER

A. Pre-Cleaner
B. Body
C. Element (Mesh)
D. Bowl with Clips
E. Clamp
F. Bowl } Early Engines

OIL FILTER:

It is a recommendation that the paper element is replaced every 250 hours. This is the maximum life of the element, and in some conditions the life can be much less. If you are not sure about the condition of the element, replace it. To replace the element do the following:

1. Clean the area around the filter.
2. Hold the filter case and remove the securing bolt.
3. Remove the case and the element.
4. Remove the sealing ring from the cylinder block.
5. Destroy the element and the sealing ring.
6. Clean the case with fuel oil using a brush. Clean the cylinder block and main frame.
7. Install a NEW sealing ring in the cylinder block.
8. Put the securing bolt in the case and a NEW element in position on the bolt.
9. Install the case with the element on the engine.
10. Tighten the securing bolt.

When you do this, make sure that the case is in the correct contact with the sealing ring.

11. Tighten the securing bolt to 13 Nm (10 lb ft).
12. Turn the engine with the starter for five seconds to fill the filter case with oil.
13. Check the level of oil with the dipstick and add oil if necessary.

14. Start the engine and check for leakage.

NOTE: Late model engines have a cartridge type filter. Installation instructions are as follows:

1. Use a strap wrench (K965917) to remove the old filter.
2. Clean the filter seat on the cylinder block and the area around it.
3. Check that the seal on the new filter cartridge is in good condition. Put a small amount of oil on the faces of the seal.
4. Install the cartridge on the screwed adaptor. Turn the cartridge until the seal is against the face of the block. Then tighten the cartridge $\frac{1}{4}$ to a turn more.
5. Start the engine and check for leaks. Stop the engine, check the oil level and add oil if necessary up to the correct level on the dipstick.




FIGURE 4 ENGINE OIL FILTER

A. Securing Bolt

B. Filter Element




FIGURE 5 BLOCK WITH FILTER REMOVED

A. Filter seat

B. Screwed adaptor




FIGURE 6 BLOCK WITH FILTER INSTALLED

CYLINDER HEAD TIGHTENING SEQUENCE:

The sequence for tightening the cylinder head nuts is shown in Figure 7. Do this job in the following steps:

First step: Tighten all the nuts to 41 Nm (30 lb ft) 4.15 kgm.

Second step: Tighten all the nuts to 81 Nm (60 lb ft) 8.3 kgm.

Third step: Tighten all the nuts to 122 Nm (90 lb ft) 12.4 kgm.

Fourth step: Tighten all the nuts to 136 Nm (100 lb ft) 13.8 kgm.

Fifth step: Check all the nuts at 136 Nm (100 lb ft) 13.8 kgm.

IMPORTANT: After tightening the cylinder head, you must check the valve clearances.




FIGURE 7 CYLINDER HEAD TIGHTENING SEQUENCE

CYLINDER HEAD NUTS

The five short nuts have now been replaced by nuts of a different type.

At the same time the torque specification was increased to 136 Nm (100 lb/ft).

This change was made to all engines after April 1976.

VALVE CLEARANCES:

The setting of the valve clearances must be done when the engine is cold. The correct clearance is 0.25 mm (0.010 in) for all the valves. Before making an adjustment, make sure that you measure the clearance when the tappet is on the base of the cam. The position of the valves in the cylinder head is as follows:

No. 1 Cylinder (Front)	No. 2 Cylinder (Centre)	No. 3 Cylinder (Rear)
---------------------------	----------------------------	--------------------------

Exhaust	Inlet	Exhaust	Inlet	Exhaust	Inlet
---------	-------	---------	-------	---------	-------

To make the adjustment to the valve clearances do the following procedure:

1. Remove the cover from the cylinder head.
2. Turn the engine by hand in its normal direction of rotation and see which exhaust valve is closing. Turn the engine again until the inlet valve of the same cylinder starts to open. This position is the "valve rocking" position of that cylinder.
3. Measure the clearances of the valves shown in the chart and make any necessary adjustment.
4. Turn the engine until the next set of valves are in the "rocking" position.
Use the chart to find which valve clearances to measure.
5. Do the same procedure for the last set of valves.
6. Install the cover with a new gasket.

Rocking Position	Valves to Check
No. 1 Cylinder	No. 2 Inlet No. 3 exhaust
No. 2 Cylinder	No. 3 inlet No. 1 exhaust
No. 3 cylinder	No. 1 inlet No. 2 exhaust




FIGURE 8 SETTING THE VALVE CLEARANCE

A. Adjusting Screw
B. Locknut

C. Feeler Gauge

FUEL SYSTEM:

Water Trap:

1. Remove the bowl and filter and clean them with diesel fuel oil.
2. Check the sealing ring for damage and replace if necessary.
3. Install the filter and bowl.




FIGURE 9 WATER TRAP AND SEDIMENT BOWL -

- A. Filter
- B. Sealing ring
- C. Securing screw
- D. Bowl
- E. Fuel pump priming lever

Fuel Filters:

Two fuel filters are installed in series. The paper elements must be replaced at regular intervals. If clean fuel has been used all the time, the minimum life of an element is approximately 500 hours. Using dirty fuel, especially fuel with water in it, will decrease the life of an element to less than 100 hours.

IMPORTANT: The rust inhibitor mixed with the fuel for storage purposes can cause a restriction in the filter elements. Because of this, both the filter elements must be replaced at the 50 to 100 hour service.

To replace a filter element, do the following:

1. Clean the outside of the filter.
2. Hold the base and remove the securing bolt.
3. Remove the base with the filter element.
4. Destroy the element, the two element sealing rings, and the 'O' ring.
5. Clean the base. Install the new element on the base with a new sealing ring, 78 mm diameter.
6. Install a new 'O' ring in the centre of the element and a new sealing ring in the head of the filter. This ring has a blue stripe.
7. Hold the base and element in position and install the securing bolt.




FIGURE 10 FUEL FILTERS

- A. Securing Bolt
- B. Filter Element
- C. Base

Fuel Injection Pump:

No maintenance is needed. The only adjustments are for the maximum and idling speed. These are adjusted before delivery of the tractor. **DO NOT** try to make any repairs or adjustments unless you have the correct equipment.

Removing Air from the System:

1. Make sure there is a minimum of 9 litres (2 gallons) of fuel in the tank.
2. Check the condition of the water trap and clean the bowl and filter if necessary.
3. Remove the plug G.
4. Operate the priming lever E until fuel flows from the plug hole.
5. Install and tighten the plug G.
6. Loosen plug J on the fuel injection pump. Operate the priming lever until fuel flows from the hole. Tighten the plug.
7. Do the same operation with plug K.
8. Loosen the connections from the high pressure pipes to the injectors.
9. Put the engine 'Stop' control in the 'Run' position and the throttle in the maximum speed position.
10. Turn the engine with the starter until fuel comes from the connections.
11. Tighten the connections.
12. Start the engine and check for fuel leakage.




FIGURE 11 DIAGRAM OF FUEL SYSTEM

- | | |
|----------------------------|------------------------|
| A. Sediment Bowl | F. Fuel Injection Pump |
| B. Fuel Pump Priming Lever | G. Vent Plug |
| C. Injectors | H. Vent Plug |
| D. 1st Fuel Filter | K. Vent Plug |
| E. 2nd Fuel Filter | |




FIGURE 12 FUEL INJECTION PUMP VENT PLUGS

- J. Governor housing vent plug
K. Pump barrel vent plug.




FIGURE 13 CONNECTIONS TO HIGH PRESSURE FUEL PIPES

INJECTORS:

The injectors are precision parts. Remove and install them carefully. When you have removed them, give the nozzles and the threads protection by using the correct caps. If caps are not available use paper and adhesive tape. It is a recommendation that the injectors are checked with an Injector Testing and Setting Outfit every 500 hours.

Removing the Injectors:

1. Clean the area around the injectors.
2. Remove the leak off pipe.
3. Disconnect the high pressure pipes at the injector end.
4. Loosen each nut a small amount at a time until the nuts can be removed by hand.
5. Remove the injectors carefully. If the injectors are held in position by carbon deposits, use a lever between the injector lugs and the cylinder head.
6. Use caps or tape to give protection to the nozzles and threads.
7. Remove the copper washers from the injector seats. Clean the injector seats and put plugs in position to prevent dirt getting in the engine.

Installing the Injectors:

1. Remove the plugs and install NEW copper washers.
2. Install the injectors and the nuts.
3. Tighten each nut a small amount at a time to a torque of 20 Nm (15 lb ft).
4. Install the leak off pipe.
5. Put the engine stop control in the "Run" position. Put the throttle control in the maximum engine speed position.
6. Use the starter to turn the engine until fuel flows from the high pressure pipes.
7. Connect and tighten the pipes to the injectors.
8. Start the engine. Check that the engine is running correctly and that there is no leakage.

Injector Pipes:

Engines made after August 1974, have smaller diameter injector pipes.

When a new olive is to be fitted to an injector pipe, the correct size must be used. Details of injector pipes and olives are as follows:-

Late Type:

External diameter of pipe 5.5 to 5.41 mm (0.219 to 0.217 in).

Internal diameter of olive 5.60 to 5.58 mm (0.2207 to 0.2192 in).

Early Type:

External diameter of pipe 5.82 to 5.76 mm (0.229 to 0.227 in).

Internal diameter of olive 5.86 to 5.82 mm (0.2307 to 0.2292 in).

Install an olive as shown in Figure 15.




FIGURE 14 REMOVING INJECTORS

- A. Leak-off Pipe Connection
- B. Securing Studs
- C. High Pressure Fuel Pipe




FIGURE 15 INSTALLING OLIVE

- A. 0.80 mm (0.030 in)

REPAIR

FUEL FEED PUMP

The fuel feed pump is installed on the right-hand side of the cylinder block. It is operated by a push rod which makes contact with the camshaft.

Removing:

1. Disconnect the inlet and outlet fuel pipes from the body.
2. Remove the two setscrews which fasten the pump body to the cylinder block.
3. Remove the fuel pump.

Replacement of Diaphragm:

1. Clean the outside of the pump.
2. Put a mark on the pump so that the upper and lower housings can be installed in the same position.
3. Remove the six screws and remove the top part of the pump.
4. Hold the pump with one hand and with the fingers of the other hand turn the diaphragm in either direction 90 degrees.
5. Remove and destroy the old diaphragm.
6. Put the new diaphragm in the body with the tab in the position shown at A in Figure 16.
7. Push the centre of the diaphragm down until the end of the pull rod enters the slot in the connecting link.
8. Turn the diaphragm counterclockwise until the tab in position B in Figure 16.
9. Install the top part of the pump with the marks in alignment.
10. Install, but do not tighten the screws.
11. Lift the hand priming lever to put the spring in compression.
12. Keep the priming lever in this position while you tighten the screws.

Installing:

1. Put a new gasket in position on the cylinder block. Use a small amount of grease to keep the gasket in position.
2. Install new copper washers on the setscrews.
3. Put the fuel pump in position on the cylinder block. Make sure that the push rod is engaged correctly.
4. Install and tighten the setscrews to 20 Nm (15 lbs ft) 2.1 kgm.
5. Connect the inlet and outlet pipes to the body.
6. Remove any air from the system.
See the operation Removing Air from the System.




FIGURE 16 INSTALLING FEED PUMP DIAPHRAGM




FIGURE 17 FUEL FEED PUMP

- | | | |
|---------------------|-----------------------|--------------------|
| A. Diaphragm | B. Diaphragm push rod | C. Connecting link |
| D. Diaphragm spring | E. Body | F. Outlet valve |
| G. Inlet valve | H. Filter gauze | I. Sediment bowl |
| J. Hand primer | | |

INJECTORS

Tools and Equipment:

Special equipment is needed to make tests and repairs to injectors. Do not try to make repairs unless you have this equipment. Send any injectors that are not working correctly to your David Brown, Case or C.A.V. agent for repairs.



WARNING: Diesel fuel comes out of the nozzle at a very high pressure. It has enough force to go through the skin into the tissues. When you make tests or adjustments to fuel injectors, put a screen around the injector and do not put any part of your body near the nozzle. Failure to follow these rules can result in severe injury.

The design of the caps of the injectors was changed in December 1977.

The new type of cap has a female thread for the connection to the leak off pipe instead of a male thread. An adaptor is installed with a copper washer on the injector cap, which raises the leak off pipe 5mm ($\frac{1}{4}$ in).

IMPORTANT: If it is necessary to install new injectors, they must be replaced as a set. The cap is also the locknut for the pressure setting. If a cap is changed from one injector to another, the pressure setting of the injector must be checked and adjusted if necessary.

Pressure Test and Adjustment:

1. Install the injector on the test equipment.
2. Push down on the lever several times to remove any air.
3. Push down slowly on the lever and look at the pressure gauge. When the needle of the gauge makes a sudden movement, the pressure that is shown is the working pressure of the injector.

The correct working pressure is 185 atmospheres for new and 175 atmospheres for old injectors. To make an adjustment, do the following:

1. Remove the cap L and loosen the locknut K.
2. Put a large screwdriver in the slot in the adjusting screw B and turn the adjusting screw either clockwise to increase the pressure or counter-clockwise to decrease the pressure.
3. Tighten the locknut and check the working pressure again.
4. When the working pressure is correct, install and tighten the cap L.

Dry Seat Test:

1. Clean the nozzle.
2. Press down on the lever until the gauge shows a pressure of 165 atmospheres. Hold the lever in this position.
3. Check that the nozzle is dry and there is no leakage.




FIGURE 18 DETAILS OF INJECTOR

- | | |
|--------------------------|------------|
| A. Leak off connection | G. Nozzle |
| B. Adjusting screw | H. Holder |
| C. Fuel inlet connection | J. Spring |
| D. Plunger | K. Locknut |
| E. Needle | L. Cap |
| F. Nozzle nut | |

R79 68

Cleaning:

If any of these tests show a defect, the injector must be disassembled and cleaned as follows:-

1. Remove the cap, loosen the locknut and the adjusting screw.
2. Remove the nozzle cap.
3. Remove the nozzle.
4. Remove the needle valve from the nozzle and check for wear and damage.

NOTE: The needle valve and the nozzle are made as a unit and must be kept together.

5. Check the colour of the needle valve. If the valve is blue, or you can see any wear or damage, replace the nozzle.
6. If there is no damage to the needle valve, clean the nozzle using the tools in the cleaning kit. Be careful when you clean the small holes in the nozzle and make sure that you use a wire of the correct size.
7. Reverse flush the nozzle with clean fuel oil.
8. Clean the needle valve with the brass brush.

Assembling:

1. Put the needle valve and the nozzle in clean fuel oil. Install the valve in the nozzle.
2. Put the nozzle in position on the holder G. Install and tighten the nozzle nut.
3. Do again the Pressure Test and Adjustment, the Leakage Test, the Atomizer Test and the Dry Seat Test. If any of these tests shows a defect, replace the injector nozzle.

Leakage Test:

1. Push down on the lever until the gauge shows a pressure of 170 atmospheres.
2. Release the lever.
3. Measure the time in seconds for the needle of the gauge to move from the 150 to the 100 atmosphere mark.
The time taken must be between 6 and 25 seconds.

Atomizer Test:

1. Close the valve to the pressure gauge.
2. Push down on the lever eight times with a rapid movement. At the same time look at the shape and condition of the fuel as it comes from the injector nozzle.
3. When an injector is working correctly, fuel leaves each of the four holes in the nozzle as a spray. The four sprays must be the same size and shape, and all the fuel must be in particles.




FIGURE 19 INJECTOR SPRAY PATTERN

NOTE: The spray guard has been removed to show the spray pattern clearly.



WARNING: When testing or adjusting injectors use a spray guard. DO NOT put any part of your body near the fuel spray. The spray has enough force to penetrate the skin and destroy tissue. If the fuel enters the blood stream it can cause poisoning.

FUEL INJECTION PUMP:

Removing:

1. Check that the timing marks on the injection pump and the housing can be easily seen.
If the mark on the housing is not clear, use a scribe to make a new mark on the housing in alignment with the mark on the pump.
2. Disconnect all the fuel pipes to and from the pump.
3. Disconnect the stop and throttle controls.
4. Remove the nuts and washers from the pump flange.
5. Lift the pump away from the housing.

Installing: (See Figure 21).

If you are not sure that the engine timing is correct, check the position of the master spline in the injection pump drive housing as shown on page 45.

1. Install the thrust spring B in the driving shaft of the drive housing.
2. Turn the quill shaft of the fuel injection pump until the master spline is aligned with the master spline of the driving shaft.
3. Lower the fuel injection pump complete with the quill shaft into position.
4. Install the washers and nuts.
5. Turn the body of the fuel injection pump until the marks are aligned. See A. Figure 20.
6. Tighten the nuts.
7. Connect all the pipes to the fuel injection pump.
8. Connect the stop and throttle controls.
9. Remove all the air from the system. See the Section: Removing Air from the System.





FIGURE 20 FUEL PUMP MARKS

A. Alignment Marks



† FIGURE 21 INSTALLING THE FUEL INJECTION PUMP

A. Master spline
B. Spring

TIMING THE FUEL INJECTION PUMP

The spill method of timing the pump to the engine is now to be used instead of the timing peg in the flywheel method.

The basis of this method is setting the pump so that injection of the fuel occurs at a specific amount of piston travel before Top Dead Centre. The timing information for the 3 cylinder engine is as follows:

Engine Type: 355011, Stroke: 114 mm (4½ in), Degrees before T.D.C.: 16°, Piston Travel before T.D.C.: 2.834 mm (0.1116 in).

Setting Procedure:

1. Remove No. 1 injector pipe from the injector and the pump.
2. Remove the hollow bolt which fastens the No. 1 connector to the pump. Install a standard hollow bolt which does not have an internal non-return valve.
3. Install the tubing on the No. 1 connector as shown in Figure 22.

NOTE: The diameter and length of glass capillary tube is very important and must be as given in Figure 22.

4. Start the engine to fill the capillary tube with fuel. When the fuel is just to the top of the capillary tube, stop the engine. Put the engine stop control in the "RUN" position.
5. Remove the cylinder head cover.
6. Turn the engine by hand to the top dead centre firing stroke on No. 1 cylinder.
7. Loosen the No. 1 inlet rocker adjusting screw and remove the push rod.
8. Remove the cotters from the No. 1 inlet valve. Remove the collar and spring.
9. Fasten a dial indicator gauge to the cylinder head so that vertical movement of the valve, which is against the top of the piston, can be measured.
10. Turn the engine slowly by hand a small amount in each direction until you can see by the gauge the top dead centre position of the piston.
11. With the piston in this position, make a note of the reading of the gauge.
12. Turn the engine counterclockwise so that the piston is approximately 12 mm (½ in) before top dead centre. Do not turn the engine more than this or the valve will go into the cylinder.
13. Carefully turn the engine in a clockwise direction and look at the capillary tube.
The fuel level in the capillary tube will first go down and then up.
The piston position when the fuel starts to go up the capillary tube must be 2.834 mm (0.1116 in) before top dead centre.
14. If the fuel level does not go up at the correct position of the piston, loosen the nuts which fasten the injection pump to the housing.

15. Then turn the pump either clockwise or counterclockwise until fuel goes up the tube at the correct position of the piston.

16. Tighten the nuts and check the timing again.

17. Remove the tubing and the standard hollow bolt.

18. Install the original hollow bolt which has an internal non-return valve.


19. Install the injector pipe.

20. Install the push rod, the valve spring, collar and the cotters.

Adjust the valve clearance.

NOTE: Turn the engine to the No. 1 top dead centre position before installing the valve cotters.

21. Install the cylinder head cover.



† FIGURE 22 EQUIPMENT FOR SPILL TIMING

- A. No. 1 Injector pipe connection
- B. Piece of high pressure fuel pipe
- C. Plastic or rubber sleeve
- D. Glass capillary tube 8 in (203mm) x 1.5mm bore
- E. Plastic tube
- F. Plug



TIMING THE FUEL INJECTION PUMP

The spill method of timing the pump to the engine is now to be used instead of the timing peg in the flywheel method.

The basis of this method is setting the pump so that injection of the fuel occurs at a specific amount of piston travel before Top Dead Centre. The timing information for the 3 cylinder engine is as follows:

Engine Type: 355011, Stroke: 114 mm (4½ in), Degrees before T.D.C.: 16°, Piston Travel before T.D.C.: 2.834 mm (0.1116 in).

Setting Procedure:

1. Remove No. 1 injector pipe from the injector and the pump.
2. Remove the hollow bolt which fastens the No. 1 connector to the pump. Install a standard hollow bolt which does not have an internal non-return valve.
3. Install the tubing on the No. 1 connector as shown in Figure 22.

NOTE: The diameter and length of glass capillary tube is very important and must be as given in Figure 22.

4. Start the engine to fill the capillary tube with fuel. When the fuel is just to the top of the capillary tube, stop the engine. Put the engine stop control in the "RUN" position.
5. Remove the cylinder head cover.
6. Turn the engine by hand to the top dead centre firing stroke on No. 1 cylinder.
7. Loosen the No. 1 inlet rocker adjusting screw and remove the push rod.
8. Remove the cotters from the No. 1 inlet valve. Remove the collar and spring.
9. Fasten a dial indicator gauge to the cylinder head so that vertical movement of the valve, which is against the top of the piston, can be measured.
10. Turn the engine slowly by hand a small amount in each direction until you can see by the gauge the top dead centre position of the piston.
11. With the piston in this position, make a note of the reading of the gauge.
12. Turn the engine counterclockwise so that the piston is approximately 12 mm (½ in) before top dead centre. Do not turn the engine more than this or the valve will go into the cylinder.
13. Carefully turn the engine in a clockwise direction and look at the capillary tube. The fuel level in the capillary tube will first go down and then up. The piston position when the fuel starts to go up the capillary tube must be 2.834 mm (0.1116 in) before top dead centre.
14. If the fuel level does not go up at the correct position of the piston, loosen the nuts which fasten the injection pump to the housing.

15. Then turn the pump either clockwise or counterclockwise until fuel goes up the tube at the correct position of the piston.
16. Tighten the nuts and check the timing again.
17. Remove the tubing and the standard hollow bolt.
18. Install the original hollow bolt which has an internal non-return valve.
19. Install the injector pipe.
20. Install the push rod, the valve spring, collar and the cotters.

Adjust the valve clearance.

NOTE: Turn the engine to the No. 1 top dead centre position before installing the valve cotters.

21. Install the cylinder head cover.




FIGURE 22 EQUIPMENT FOR SPILL TIMING

- A. No. 1 Injector pipe connection
- B. Piece of high pressure fuel pipe
- C. Plastic or rubber sleeve
- D. Glass capillary tube 8 in (203mm) × 1.5mm bore
- E. Plastic tube
- F. Plug

LUBRICATION SYSTEM:

Introduction:

When the engine is running, oil from the sump is sent under pressure to the oil filter. The clean oil then flows to the main oil gallery and through holes in the cylinder block to the main bearings and the camshaft bearings. There are holes in the crankshaft through which oil flows to the connecting rod bearings. The rear bearing of the camshaft has a hole through which oil flows to the rocker shaft and lubricates the valve gear before flowing back to the sump. The front bearing housing has a hole through which oil flows on to the drive gears for the fuel pump, and oil leakage from the front of the bearing lubricates the timing gears.

The oil filter is the full flow type and has a bypass valve installed. This valve opens if the difference in pressure between the inlet and outlet is more than 70 kPa (10 lb in²). This gives protection to the engine if there is a restriction in the oil filter.

OIL WARNING LAMP:

The oil warning lamp is operated by a pressure switch connected to the main oil gallery. The switch opens at 62 to 90 kPa (9 to 13 lb in²). There is no adjustment and if there is any defect, the switch must be replaced.

OIL PUMP:


Removing:

1. Remove the engine oil.
2. Remove the sump.
3. Remove the pipe from the oil pump to the cylinder block.
4. Loosen the locknut and remove the locating screw.
5. Pull the pump down out of the housing. Be ready to hold the quill shaft which may come out of the housing when you remove the pump.

Installing:

If the quill shaft moved out of position when the oil pump was removed, it will be necessary to remove the fuel injection pump to install the quill shaft correctly. See the Sections: Removing the Fuel Injection Pump and Timing the Engine.

1. Push the oil pump into the housing.
2. Put a small amount of Wellseal or a similar joint compound on the locating screw. Install and tighten the locating screw. Install and tighten the locknut.
3. Install the pipe from the oil pump to the cylinder block and the suction pipe.



† FIGURE 23 OIL PUMP DRIVE

- | | |
|--------------------------|---------------------|
| A. Drive shaft | E. Spring |
| B. Pump body | F. Adjusting screw |
| C. Oil outlet connection | G. Locknut |
| D. Relief valve plunger | H. Oil inlet screen |

Disassembling:

1. Remove the two bolts and the two setscrews.
- NOTE: The two setscrews keep the parts of the pump in position. Make sure that you know the holes to use when you assemble the pump.
2. Remove the cover with the inlet filter and the relief valve in position.
3. Measure the amount of backlash between the rotors. Make a note of this measurement.
4. Remove the driven rotor.
5. Push the driving shaft with the rotor out of the housing.
6. Use a puller to remove the driving rotor.
7. Remove the Woodruff key.
- Remove the driving shaft.
8. Use a press and a piece of shaft to push the shaft for the driven rotor out of the housing.
9. Check the rotors, housing, driving shaft, driven shaft and the bush for wear or damage. Use the table below to find the permissible amount of wear.

NOTE: If there is any damage or wear to either of the rotors, BOTH rotors must be replaced.
From Engine 48270 on, both rotors are made of sintered iron and the driving shaft has been changed.

Backlash between rotors:

0.51 to 0.66 mm (0.020 to 0.026 in)

Rotor width:

30.14 to 30.11 mm (1.1865 to 1.1855 in)

Housing depth:

30.20 to 30.16 mm (1.189 to 1.1875 in)

Rotor end clearance:

0.025 to 0.089 mm (0.001 to 0.0035 in)

Bush inside diameter:

12.46 to 12.51 mm (0.4905 to 0.4925 in)

Shaft diameter:

12.43 to 12.45 mm (0.4895 to 0.490 in)

Clearance:

0.013 to 0.08 mm (0.0005 to 0.003 in)

Replacing the Bush: Figures 24 and 25.

1. Put the pilot bush through the slot in the rotor housing on to the old bush.
2. Put an old driving shaft through the bracket against the pilot bush.
3. Use a press to remove the bush.
4. Put the new bush in position on the bracket. Make sure that the oil holes are in alignment.
5. Use the old bush to push the new bush in position.

Relief Valve:

Before you remove the relief valve for any purpose, make a note of the number of threads that are above the locknut for the adjusting screw. You can then install the adjusting screw to the same setting if test equipment is not available. An approximate setting is as follows:

Four threads above the locknut is 280 kPa (40 lb in²).

One turn of the adjusting screw is 42 kPa (6 lb in²).




FIGURE 24 PILOT BUSH




FIGURE 25 REPLACING OIL PUMP BRACKET BUSH

A. Old driving shaft
B. Pilot bush

C. Old bush
D. New bush

Assembling:

1. Use a press to install the shaft for the driven rotor.
2. Install the driving shaft.
Install the Woodruff key.
3. Use a press to install the driving rotor on the driving shaft.
4. Install the driven rotor.
5. Install the rotor housing.
6. Use a straight edge and feeler gauges to measure the end clearance between the faces of the rotors and the edge of the rotor housing.

NOTE: If there is too much end clearance on the rotors, the face of the housing can be machined. If there is not enough end clearance it is permitted to install a gasket of the correct thickness between the face of the housing and the cover.

6. Install the cover, the bolts and the setscrews.

Test Procedure:

If testing equipment is available, do the following procedure:

1. Use a 5W grade oil at a temperature of 20°C (68°F), or a 20W20 grade at a temperature of 46°C (115°F).
2. Adjust the relief valve to open at 280 kPa (40 lb in²).
3. Adjust the speed to 750 r/min or 330 r/min.
4. Check the flow using the information given below.

Oil Flow

Pressure	Speed	Minimum in 1 Min.
140 kPa (20 lb in ²)	750 r/min	10.9 litres (19.2 pt)
1.4 kgcm ²		
140 kPa (20 lb in ²)	330 r/min	4.7 litres (8.4 pt)
1.4 kgcm ²		

The oil flow in pt/mins is:

$$\frac{480}{\text{time in seconds for one gallon}}$$

The oil flow in litre/min is:

$$\frac{300}{\text{time in seconds for five litres}}$$

The maximum time for one gallon must be:

25 seconds at 750 r/min.

57 seconds at 330 r/min.

The maximum time for five litres must be:

28 seconds at 750 r/min.

63 seconds at 330 r/min.




FIGURE 26 OIL PUMP TEST EQUIPMENT

- A. Oil pump
B. Pressure gauge
C. Valve
D. Outlet

R79-76

COOLING SYSTEM

Introduction:

When the engine is running, the water pump causes cold water to flow from the bottom of the radiator through an opening in the cylinder block to the cylinder head. After coming in contact with the cooling surfaces of the fuel injectors and the valve guides, the water flows into the passages in the cylinder block. As the water gets hot, it rises to the cylinder head and flows in the top of the radiator.

A thermostat valve is installed between the cylinder head and the top of the radiator. This prevents water from the cylinder head flowing to the radiator until the engine is at the correct running temperature.

The radiator has a pressure type radiator cap rated at 28 kPa (4 lb in²) 0.28 kgcm².

A fan with seven blades is installed on the shaft of the water pump and turns at one and a half times the speed of the engine.




FIGURE 27 DIAGRAM OF COOLING SYSTEM

- | | | |
|------------------------|--------------------------|---------------|
| A. Inlet to radiator | D. Water pump impeller | G. Thermostat |
| B. Jets to valve ports | E. Port to cylinder head | |
| C. Outlet to radiator | F. Bypass seal | |

WATER PUMP

Removing:

1. Remove the coolant from the radiator and the cylinder block.
2. Remove the radiator.
3. Loosen the bolts which hold the alternator in position. Remove the fan belt.
4. Remove the setscrews which hold the fan on to the water pump shaft.
Remove the retainer and the fan.
5. Remove the five setscrews which hold the pump to the cylinder block.
6. Remove the pump.
Remove the seal which is installed between the pump and the cylinder head.
Remove the old gasket and clean the face of the cylinder block.

Installing:

1. Put a new gasket in position on the body of the water pump.
2. Put two or more setscrews through the body to keep the gasket in position.
3. Put a new rubber seal in the groove of the pump body.
4. Raise the water pump in position on the cylinder block.
5. Push the pump toward the cylinder head until the setscrews will enter the holes in the cylinder block.
6. Tighten the setscrews to 20 Nm (15 lb ft) 2.1 kgm.
7. Install the fan, the retainer and the setscrews.
Tighten the setscrews to 34 Nm (25 lb ft) 3.46 kgm.
8. Install the fan belt.
Adjust the fan belt to the correct tension.
See the Maintenance Section: Fan Belt.
9. Put the hose in position on the pump.
Tighten the hose clip.
10. Put the coolant in the radiator.
11. Start the engine and check for leakage.




FIGURE 28 ARRANGEMENT OF WATER PUMP

- | | |
|----------------------|-------------------|
| A. Seal | E. Pulley |
| B. Impeller | F. Locating screw |
| C. Seal | G. Body |
| D. Bearing and shaft | |

R79-78

Types of Seal:

Two different methods of sealing the water pump have been used. On early model engines the seal was installed in the impeller and sealed against the pump body. On later models the seal is installed in the pump body and seals against the impeller. The seals, impeller and pump bodies of the two types are not interchangeable.

IMPORTANT: When a late type water pump is being reconditioned, measure the diameter of the seal housing, A in Figure 29. This measurement must be 29.97 mm (1.180 in). If the measurement is 30.22 mm (1.190 in) the pump body must be replaced. Then check the seal. If the seal has the number SCD927 on its circumference, replace it with the correct seal, K949550.

Replacing the Seal: Engines before No. 29639:


1. Remove the locating screw for the bearing.
2. Put the pump in position on a press with the impeller to the top.
3. Put a piece of shaft 12 mm ($\frac{1}{2}$ in) diameter and approximately 74 mm (3 in) long on the pump shaft. Use the press to push the shaft out of the impeller and the pump body.

NOTE: Impellers can be either cast iron or plastic.

4. Remove the impeller from the pump body. Use a tool similar to a screwdriver to remove the seal from its housing in the impeller.
5. Put the new seal assembly in position on the impeller. Use the press to push the seal into the housing until the shoulder of the seal contacts the end of the impeller.
6. Put a small amount of molybdenum base lubricant on the face of the seal.

Replacing the Seal: From Engine No. 29639:


1. Remove the locating screw for the bearing.
 2. Put the pump in position on a press with the impeller to the top.
 3. Put a piece of shaft 12 mm ($\frac{1}{2}$ in) diameter and approximately 74 mm (3 in) long on the pump shaft. Use the press to push the shaft out of the impeller and the pump body.
 4. Remove the impeller from the pump body. Use a screwdriver to remove the seal from the pump body.
 5. Put the new seal in position on the pump body. Use the press to push the seal in the pump body until the shoulder of the seal is against the face of the body.
- Put a small amount of molybdenum base lubricant on the face of the seal.



R79-79

FIGURE 29 SEAL HOUSING


A. Housing diameter B. Seal



R79-80

FIGURE 30 SEAL: EARLY MODELS

A. Seal B. Impeller



R79-81

FIGURE 31 SEAL: LATER MODELS

A. Seal C. Impeller
B. Clearance, impeller to body, 0.13mm (0.005in)

Replacing the Bearing:

1. Use a press and the piece of shaft to push the bearing and shaft out of the fan pulley.
2. Use the press to push a new bearing and shaft in the fan pulley until the end of the shaft is level with the edge of the hole.

Assembling the Pump:

1. Align the hole in the bearing with the hole for the locating screw in the pump.
2. Use a press to push the shaft and bearing in the pump body until the hole in the bearing is in the centre of the hole for the locating screw.
3. Install the locating screw.
4. Use the piece of shaft as a support for the water pump shaft at the fan pulley end.
Put the pump body on a press with the fan pulley towards the bottom.
5. Put the impeller on the shaft.
Push the impeller on to the shaft until the end of the shaft is aligned with the face of the impeller.

Installing:

1. Put the thermostat in position in the cylinder head.
2. Install a NEW 'O' ring.
3. Install the outlet pipe and the two setscrews.
4. Move the radiator inlet hose into the correct position.
5. Tighten the hose clips.
6. Fill the radiator with coolant.
7. Check for leakage.

THERMOSTAT**Removing:**

1. Remove the coolant from the radiator.
2. Loosen the hose clips on the radiator inlet hose and move the hose toward the radiator.
3. Remove the two setscrews from the outlet pipe from the cylinder head and remove the pipe.
4. Remove the 'O' ring and the thermostat.

Test Procedure:

1. Put the thermostat in a small container full of cold water. Use wire as a support to prevent the thermostat coming in contact with the bottom of the container.
2. Heat the water and use a thermometer to measure the water temperature.
3. As the water gets hotter, make a note of the temperature at which the thermostat valve starts to open.
The correct temperature must be between 79° to 84°C (174° to 183°F).
4. Continue to heat the water until the thermostat valve is open the maximum amount.
The temperature in this position must be 94°C (200°F).

5. If there is any defect in the thermostat, replace it.
NOTE: There is a figure on the bottom of every thermostat.
This is the temperature at which the valve starts to open.




FIGURE 32 THERMOSTAT

A. Water outlet pipe
B. Thermostat

C. Cylinder head
D. 'O' ring

R79-82

COMPRESSION TESTING

1. Make sure that the battery has a maximum charge.
2. Remove all the injectors. See the Maintenance Section: Removing the Injectors.
3. Install a compression gauge that has a capacity of not less than 3200kPa (450 lb in²) in No. 1 injector hole.
4. Put the engine stop control in the STOP position.
5. Turn the engine with the starter and make a note of the pressure shown by the gauge.
Put the gauge needle to zero and do the test again to be sure of accuracy.
6. Do a similar test on the other cylinders.
7. Compare the results with the chart shown below.

Diagnosis of the Compression Test:

Pressure higher than normal is an indication of carbon deposits in the cylinder head. The necessary action is to remove the cylinder head and remove the carbon.

If the pressure is lower than normal, put 4 ml (1½ fl. oz) of engine oil into each cylinder and do the compression test again.

If the pressure increases to almost normal, there is wear in the piston rings or cylinders. If the pressure does not increase, the valves are not seating correctly.




FIGURE 33 COMPRESSION PRESSURES

CYLINDER HEAD:

Removing:

1. Remove the coolant from the system.
2. Remove the top radiator hose.
3. Remove the coolant outlet pipe from the cylinder head.
Remove the thermostat.
4. Remove the injector leak off pipe and the pipe to the fuel tank.
5. Remove the fuel pipes from the injectors.
6. Remove the injectors and the copper washers from the injector ports.
7. Remove the pipe from the breather of the cylinder head cover.
8. Remove the four nuts which fasten the cover to the cylinder head.
Remove the cover and the gasket.
9. Remove the bolt from the inlet manifold which holds the pipe clip in position.
10. Remove the oil pipe between the cylinder block and the cylinder head.
11. Remove the rocker shaft and the push rods.
12. Remove the nine bolts and six nuts which fasten the cylinder head to the block.
13. Remove the cylinder head complete with manifolds.
14. Put a small amount of oil on the cylinder bores.
Put a cover over the block to prevent dirt getting into the cylinders.

Cylinder Head Gasket:

All the water flow holes in the top face of the cylinder block are now made 14.28 mm ($\frac{9}{16}$ in) diameter. This change was made after Engine No. 29525. To keep the same characteristics of water flow it was necessary to use a new type cylinder head gasket with two 9.13 mm ($\frac{3}{8}$ in) holes. The new type gasket, Part No. K949874, can be used on all 3 cylinder engines. The old type gasket, Part No. K942006, can only be used on engines made before this change.

Installing:

1. Clean the cylinder bores and the face of the cylinder block.
2. Put a new gasket in position on the cylinder block. Make sure that if there is a mark TOP on the gasket, this mark is toward the cylinder head.
3. Install a new rubber seal on the top face of the water pump.



WARNING: When you do the next job, make sure that you do not hold the cylinder head with your fingers under the head. Hold the inlet and exhaust manifolds to put the head in position. Failure to do this can result in serious injury.

4. Install the cylinder head, the bolts and the nuts.
5. Tighten the bolts and the nuts. See the Maintenance Section: Cylinder Head Nuts.
6. Install the push rods and the rocker shaft.
7. Install the bolts, washers and spring washers which fasten the rocker shaft to the cylinder head.
Tighten the bolts to 61 Nm (45 lb ft) 6.2 kgm.
8. Adjust the valve clearances. See the Maintenance Section: Valve Clearances.
9. Install the oil pipe between the cylinder block and the cylinder head.
10. Install the bolt in the inlet manifold which holds the pipe clip in position.
11. Install the thermostat and the coolant outlet pipe.
Install the top radiator hose.
12. Put a new cover gasket in position.
Install the cylinder cover.
Install the domed nuts.
13. Install the breather pipe.
14. Install the injectors. See the Maintenance Section: Installing the Injectors.
15. Install the injector leak off pipe and the pipe to the fuel tank.
16. Remove the air from the fuel system. See Maintenance Section.
17. Add coolant to the radiator up to 25 mm (1 in) from the bottom of the filler neck.




FIGURE 34 CYLINDER BLOCK AND CYLINDER HEAD GASKET

- A. Cylinder head
B. Cylinder head gasket
C. Cylinder block

Disassembling:

1. Remove the inlet and exhaust manifolds.
2. Put a number, 1 to 6 on the head of each valve so that each valve can be installed in its original position.
3. Use an acceptable tool (Churchill 900200) to remove the valve cotters, collars, springs and valves.

Cleaning:

Use a soft metal tool, aluminium or brass, to clean the following:

1. Inside the exhaust manifold.
2. The combustion chambers and valve ports inside the cylinder head.
3. The injector ports.
4. The valves.

Exhaust Manifold Gaskets:

The material and thickness of the manifold gaskets was changed after March 1973.

IMPORTANT: The different types of gasket must only be installed as a set.

VALVE SEATS:

1. Check the seats for wear, damage, loose fitting and width of seat.
2. If the seats are in good condition, use grinding paste to seat the valves correctly. If the seats are in bad condition, use a seat cutting tool to put a new face of 45° on the inserts.
DO NOT remove more material than is necessary.
3. Check the width of the seats. This width must not be more than 1.65 mm (0.065 in). If necessary, use a cutting tool to decrease the width of the seat.

VALVE STEM BORES:

The valves work in the cylinder head and there are no separate valve guides.

1. Put a new valve in each bore and measure the clearance between the valve stem and the bore. If the clearance is more than 0.152 mm (0.006 in) it will be necessary to increase the size of the bore by 0.254 mm (0.010 in) or 0.508 mm (0.020 in).
Do the procedure as follows:
2. According to the amount of wear and the size of the bore, use reamer Part No. K960989 or reamer Part No. K961824.
Use a machine running at its slowest speed and lubricate the reamer with cutting fluid. Be careful and do not cause damage to the top edge of the exhaust bores.
3. After the bores have been machined it will be necessary to cut the valve seats. See the section: Valve Seats.

VALVE SPRINGS:

If equipment is available check the length of all valve springs under load. If equipment is not available, do the following procedure.

1. Take one spring from a set of NEW springs.
2. Make a comparison of the length of the old springs with the new spring.
Discard any spring which is 1.5 mm ($\frac{1}{16}$ in) shorter than the new spring.
3. Make a comparison of the length of each spring under load as shown in Figure 35.
4. Put a piece of shaft inside both springs to prevent the springs moving out of position. Put a washer between the end of the springs.
5. Tighten the vice until the new spring is at the length shown in the Data Section.
6. Measure the difference between the old springs and the new spring.

If any old springs are more than 1.5 mm ($\frac{1}{16}$ in) shorter than the new spring, discard them.

NOTE: If the record shows that the engine has run for a large number of hours, install a set of new springs.




FIGURE 35 CHECKING VALVE SPRINGS

- | | |
|---------------|---------------|
| A. New spring | C. Old spring |
| B. Spacer | D. Rule |

VALVES

The valves were changed at the following engine and serial numbers:

780 Tractor





Exhaust valve	Inlet valve	Serial number
928622	928622	6039 onwards
921434	921433	5584 to 6038
900417	914528	1001 to 5583

880 Tractor



Exhaust valve	Inlet valve	Serial number
928622	928622	25306 onward (Livedrive) 2984 onward (non-Livedrive)
921434	921433	24645 to 25309 (Livedrive) 2984 onwards (non-Livedrive)
900417	914528	1001 to 24644 (Livedrive) 1001 to 2983 (non-Livedrive)

770 Tractor



Exhaust valve	Inlet valve	Serial number
921434	921433	9970 onwards (Livedrive) 1879 onwards (non-Livedrive)
900417	914528	up to 9969 (Livedrive) up to 1878 (non-Livedrive)



921247



921247



62034

R79-86

- A. 88.52 mm (3 $\frac{1}{2}$ in.)
- B. 82.55 mm (3 $\frac{1}{4}$ in.)
- C. 80.17 mm (3 $\frac{1}{8}$ in.)
- D. 124.21 mm (4.890 in.)
- E. 122.81 mm (4.835 in.)
- F. 121.87 mm (4.798 in.)
- G. 38.23 mm (1.505 in.)
- H. 36.98 mm (1.456 in.)
- J. 34.59 mm (1.362 in.)
- K. 33.34 mm (1 $\frac{1}{8}$ in.)
- L. 30.96 mm (1 $\frac{1}{2}$ in.)
- *M. 41.43 mm (1.631 in.)
- ! M. 41.364 mm (1.6285 in.)
- N. 39.83 mm (1.568 in.)

* Early models

! Late models

FIGURE 36 DETAILS OF EXHAUST VALVES

REPAIR

Oversize valves are available in two sizes, 0.254 mm (0.010 in) and 0.508 mm (0.020 in).

1. Check the valves for wear on the stems and in the cotter grooves. Discard any valves that show wear.
2. Check the valve seats for wear or damage.
3. If necessary, the valve seats can be machined to 45°.

When you do this, make sure that when the seat is correct, there is not a sharp edge on the circumference of the head of the valve. If there is a sharp edge, discard the valve.

INLET VALVE SEALS:

Seals are not installed on the inlet valves of engines after the following Model and Serial Numbers:



Model	Serial Number
355001	33361
355005	2019
355011	20198
355012	1049

Seals are available for early type engines from the parts Department.



FIGURE 37
INLET VALVES AND SEAT
INSERTS

- A. 88.52 mm (3 $\frac{1}{2}$ in.)
- B. 95.25 mm (3 $\frac{3}{4}$ in.)
- C. 96.84 mm (3 $\frac{7}{8}$ in.)
- D. 124.21 mm (4.890 in.)
- E. 123.44 mm (4.860 in.)
- F. 122.94 mm (4.840 in.)
- G. 38.23 mm (1.505 in.)
- H. 37.46 mm (1.475 in.)
- J. 35.05 mm (1.380 in.)
- K. 34.92 mm (1 $\frac{1}{4}$ in.)
- L. 35.54 mm (1 $\frac{1}{8}$ in.)
- *M. 41.43 mm (1.631 in.)
- !M. 41.364mm (1.6285 in.)
- N. 39.83 mm (1.568 in.)



*Early Models
!Late Models.



921246



921246



905202

R78-87

FIGURE 37 DETAILS OF INLET VALVES

NOTE: Valve, Part No. K928622 is now used for both inlet and exhaust on AD3/55, AD3/49 and 355011 engines. This valve can be used to replace inlet valve K921443 and exhaust valve K921434. If it is used to replace exhaust valve K921434, the late type valve cotteners must be used.

Valve, Part No. K928622 can not be used to replace inlet valve K914528 or exhaust valve K90047.

NOTE: When installing valve No. K928622 make sure that the width of seat is not less than 1.14mm (0.045in).

RECONDITIONING THE CYLINDER HEAD:**Cylinder Head Face:**

1. Clean the face of the cylinder head with a fine grade of emery cloth.
2. Use a surface plate and marking material, or a straight edge and feeler gauges to make sure that the cylinder head face is flat.
If the face is not flat, grinding will be necessary. Before this is done, the valve seats must be removed.

IMPORTANT: The amount of material removed must not be more than necessary to get a flat surface. The maximum amount that can be removed is 0.76 mm (0.030 in).

Removing the Valve Seat Inserts:

1. Hit the seat insert with a steel chisel and a hammer. Then remove the seat insert with a prybar or the jaw of an open end spanner.

Depth of Bore for the Valve Seat Insert:

1. Measure the depth of the bore with a vernier or micrometer depth gauge. If necessary the seat must be machined to the dimension shown in Figure 38.

NOTE: The seat of the bore must be at 90 degrees to the axis of the valve guide and must have a smooth surface.

Installing the Valve Seat Inserts:

Standard inserts are 41.364 to 41.338 (1.6285 to 1.6275 in) in diameter. They are an interference fit in the cylinder head of 0.0889 to 0.0381 mm (0.0035 to 0.0015 in).

There are two methods of installation:

1. Use dry ice to decrease the diameter of the inserts, or
2. Heat the cylinder head to increase the diameter of the bore.
3. Use the tool shown in Figure 39 and a hammer to install the valve seat inserts.
Do this job as quickly as possible.

NOTE: To make sure that the inserts have been installed correctly, check that the top face of the insert is 0.28 mm (0.010 in) below the face of the cylinder head. See Figure 41.

4. Use the tool shown in Figure 39 and a hammer to press the metal of the cylinder head over the edge of the insert. See Figure 42.

Valve Seat Dimension and Angle:

The valve seat inserts must be machined as shown in Figure 42.

Width of seat 1.78 to 1.52 mm (0.070 to 0.060 in).

Included angle of seat 87 degrees.

NOTES ON RECONDITIONING:

1. If there is wear in the valve guides and oversize valves are to be installed, the valve guides must be reamed to the correct size **BEFORE** the valve insert seats are machined.
2. After this has been done, or if the cylinder head has already had oversize valves installed, the pilot used with the tools shown must also be made to the same size as the valve guide.
That is either 0.254 mm (0.010 in) or 0.508 mm (0.020 in) oversize.
3. If the valve seat insert is broken or loose in the bore, an oversize valve seat insert must be made. When the bore is machined, the same interference fit of 0.0889 to 0.0281 mm (0.0035 to 0.0015 in) must be used.
The tool used to install the inserts must also be made to a similar oversize on the 42.862 mm (1 $\frac{1}{8}$ in) and the 40.479 mm (1 $\frac{1}{2}$ in) diameters.






FIGURE 38 DIMENSIONS OF BORES FOR VALVE SEAT INSERTS


R70-86



	DIMENSION A	DIMENSION B
INLET INSERT	34.67/34.65	41.28 DIA
EXHAUST IN'RT	33.08/33.06	41.28 DIA

R79-105



FIGURE 39 TOOL FOR INSTALLING VALVE SEAT INSERTS



R79-89

FIGURE 40 VALVE SEAT INSERT AFTER INSTALLATION

ITEM 2. MATERIAL: $3\frac{1}{2}\%$ Nickel Chrome Molybdenum Steel to BS 970 Part 3 1971 832 M13 (En 36c). Harden by oil quench from 780°C (Cherry Red). Temper at 300°C (Blue) for 1 hour. Alternative treatment using oxy-acetylene torch following the temperature colour guide. Make sure that the rate of heating is even.



ASSEMBLE AS SHOWN
WITH $\frac{1}{4}$ UNC GRUB SCREW





FIGURE 41 PEENING TOOL FOR CYLINDER HEAD



R79-80

FIGURE 42 MACHINING DIMENSIONS FOR VALVE SEAT INSERTS

VALVE ROCKERS AND SHAFT:

Disassembling:

1. Remove the plugs from both ends of the rocker shaft.
2. Remove the springs, valve rockers and brackets from the shaft.
3. Remove the locating screw from the rear bracket. Remove the rear bracket.

Inspection:


1. Check all the springs for wear or damage.
2. Check the shaft for wear.
3. Check the rocker ends and bushes for wear.

Replacing a Bush:

1. Use a press to remove the old bush.
2. Make sure that the oilholes in the new bush and the rocker are aligned.
Use a press to put the new bush in position.
3. Use an expanding type of reamer in the bush until the rocker can be turned easily on the shaft.

Assembling:

1. Install the shaft in the rear bracket.
Make sure that the hole in the bracket is aligned with the hole in the shaft.
2. Install and tighten the locating screw.
3. Install the brackets, springs, rockers and plugs.



R79-91

FIGURE 43. PISTON AND CONNECTING ROD

- A. Top compression ring
- B. Nos. 2 and 3 compression rings
- C. Piston
- D. Gudgeon pin
- E. Circlip
- F. Oil scraper ring
- G. Connecting rod bush
- H. Connecting rod
- J. Bearing shells
- K. Connecting rod cap
- L. Self locking nut
- M. Bolt

PISTONS:

The pistons in AD3/30 and AD3/40 engines are the same diameter but different heights.

The pistons in AD3/55, AD3/49 and 355011 engines are the same diameter but different heights.

For details of dimensions see the Specification Section.

Pistons installed in engines with high lift camshafts have a deeper recess for the valves.

High lift camshafts were used on all AD3/49, AD3/55 and 355011 engines. Also on AD3/40 engines from AD3/40A/3424 and AD3/40B/1495.

Make sure that the correct type of pistons are used or damage will be caused by the valves hitting the pistons.

Removing:

Before this operation can be done, the engine must be removed from the tractor.

1. Remove the cylinder head.
2. Put a mark, No. 1 to the front of the engine, on the pistons and connecting rod caps. You can then be sure that each piston and connecting rod can be installed in its correct cylinder.

NOTE: The connecting rods and caps have a mark to show correct assembly. These marks are on the camshaft side of the engine.

3. Remove the nuts from the bearing caps.
Remove each bearing cap.
Remove the bolts from the connecting rods to prevent damage to the cylinder bores.
4. Use a soft piece of wood to push each piston out of the cylinder head.
5. Use circlip pliers to remove the circlips from each side of the piston pin.
6. Put the piston in hot oil, 150°C (302°F) for two minutes.
7. Use gloves for this operation.
Remove the piston from the oil and push the pin out of the piston.

Installing:

NOTE: Before installing the pistons in the cylinders see the Sections: Glazed Cylinder Bores and Removing the Glaze.

NOTE: Gloves must be used for holding the hot piston.

1. Install a circlip in one side of the piston.
2. Put the piston in hot oil, 150°C (302°F) per two minutes.
3. Put the connecting rod in a vice that has soft metal or fibre jaws.
4. Remove the piston from the oil. Put it in position on the connecting rod with the valve recesses on the same side as the identification marks on the connecting rod.
5. Install the gudgeon pin through the bush until it is against the circlip in the piston.
Install the second circlip.
6. Turn the piston rings so that the ring gaps are evenly spaced around the piston.
7. Install the connecting rod and piston in the block. Make sure that the recesses in the piston are toward the camshaft side of the engine.
8. Use a clamp to put the piston rings in compression.
Use a soft piece of wood to push the piston into the cylinder.
9. Put a small amount of oil on the bearings.
10. Install the bolts, bearing cap and the nuts. Make sure that the marks on the bearing caps and the connecting rods are aligned.
11. Tighten the nuts to 68 Nm (50 lb ft) 6.9 kg/m.
12. Install the cylinder head.

PISTON RINGS:

Description:

There are three compression rings and one oil scraper ring on each piston.

The three compression rings are made with a taper face and the top ring has a chrome insert.

IMPORTANT: The compression rings must be installed with the word TOP toward the crown of the piston.

Checking for Wear:

1. Clean the tops of the bores where there is no wear.
2. Remove the rings from No. 1 piston.
3. Put each ring separately in the top of No. 1 bore, and measure the gap.
Repeat this operation with the rings from No. 2 and No. 3 pistons in their correct bores.
4. When any rings have a gap of more than 1.524mm (0.060 in), new rings must be installed.
5. Check the clearance of each ring in its correct groove of the piston with a feeler gauge.
If this clearance is more than 0.127 mm (0.005 in), replace the piston.




FIGURE 44 CHECKING PISTON RING GROOVE CLEARANCE

R79-92

CYLINDER BORES:

Checking for wear:

1. Measure each bore at the top to find if the bores are standard or oversize.
2. Measure the maximum amount of wear in each bore.
3. Make an inspection of each bore for damage.

Reconditioning:

If the wear on any bore is more than 0.254 mm (0.010 in) or if there is damage to any bore, the cylinder block must be rebored to the next size and oversize pistons installed.

If the bores are already at the maximum oversize cylinders liners are available. See the Section: Cylinder Liners.

If there is less than 0.254 mm (0.010 in) of wear in the bores, oil control piston rings can be installed. See the Sections: Piston Rings and Glazed Cylinder Bores.

GLAZED CYLINDER BORES:

With use, the working surface of the cylinder bore becomes hard and similar to glass. This condition is known as glazed. Before new piston rings are installed this hard surface must be removed. If this is not done, the rings will not make a correct seal on the cylinder bores. The result will be that the engine will use more oil than normal and will not give its rated performance.

Removing the Glaze:

Tool Recommendation and Use:

It is a recommendation that you use the Flex Hone Type GB 4 $\frac{1}{8}$, 120 grit and do the following procedure.

1. Use tape or similar material to give protection to the crankshaft journals.
2. Put a small amount of 10W30 grade engine oil on the bores.
3. Fasten the Flex Hone in a drilling machine that has a capacity of 10 to 15 mm ($\frac{3}{8}$ to $\frac{1}{2}$ in) and a speed of 300 to 750 r/min.

IMPORTANT: Read all the following instructions before you do the next operation. Be careful when you do each operation.

4. Put the Flex Hone in position in contact with the top of the bore.
5. Start the machine and at the same time push the Flex Hone into the bore.
6. While the machine is running, move the Flex Hone up and down the length of the bore. Do this for 20 to 40 seconds at a rate of one second for each direction.
7. Remove the Flex Hone while the machine is running. Stop the machine.

8. Clean the cylinder bore with a soap and water solution.

Make sure that the bore is clean by using white paper to remove the soap and water solution.

Continue to clean the bore until no dirt can be seen on the white paper.

9. Repeat this procedure with the remainder of the bores.

CYLINDER LINERS:

Cylinder liners are available and can be used when the bores are already at the maximum oversize or when there is damage to a bore. It is not necessary to install liners in all the cylinders, but when the overhaul is complete, all cylinders must be the same diameter.

Cylinder liners can be rebored in the same way as the original cylinder bore to 0.508 mm (0.020 in) oversize.

Sealing Rings:

A sealing ring is not installed in the top of the bore in engines made after August 1972. Because of this change the top of the bore is not machined to hold a sealing ring.

When reconditioning an early type 880 tractor with an engine type 3/40 that needs a replacement cylinder block, discard the cylinder liners and install pistons Part No. K943880. Cylinder Liners Part No. K912776 are available from the Parts Department if it is necessary to replace the liners only.

Installing Liners:

Use a boring bar and a honing machine to increase the cylinder bore to 104.99 to 105.00 mm (4.1334 to 4.1339 in).

NOTE: During this operation the boring tool may go into the water jacket. This is not important if the tool is kept correctly aligned.

2. Clean the bore and then wash the bore with a solution of soap and water.
3. Put a small amount of Pressolene or a similar lubricant on the new liner.
4. Put the liner in position on the bore with the chamfered end toward the bottom of the bore.
5. Use an acceptable press to push the liner in the bore until the top of the liner is 0.13 to 0.25 mm (0.005 to 0.010 in) above the face of the cylinder block.
6. Use a surface grinding machine to grind the liner level with the top face of the cylinder block. Do not remove metal from the block.
7. Put a chamfer on the top of the liner of 0.76 mm (0.030 in) at an angle of 45°.
8. Use a honing machine inside the bore to get a smooth surface, 20 to 40 micro inches CLA, and a diameter of 100.05 to 100.06 mm (3.9388 to 3.9396 in).
9. Clean and wash the bore as in Operation 2.

NOTE: Correctly installed cylinder liners have an interference fit of 0.08 to 0.11 mm (0.0031 to 0.0046 in).

CONNECTING RODS:

Alignment:

It is recommended that all connecting rods are checked for distortion when they have been removed from the engine.

This is most important when the wear marks on the piston are not even.

Use an alignment tool as shown in the Service Tool Leaflet B5.

The following chart gives the permissible distortion.

If any connecting rod has more distortion than shown, it must be replaced.

IMPORTANT: DO NOT try to make repairs to a connecting rod.

Maximum out of parallel: 0.005 mm per centimetre
0.0005 in per inch

Maximum twist: 0.005 mm per centimetre
0.0005 in per inch

Replacing the Bush:

1. Use a press and an acceptable piece of shaft to remove the old bush.
2. Put the new bush on the bore of the connecting rod and align the oil hole in the bush with the hole in the bore of the connecting rod.
3. Use a press to push the new bush in position.
4. Use a reamer that you can adjust to increase the bore of the bush until the gudgeon pin can be pushed in the bush using a small amount of hand pressure.

CONNECTING ROD BEARINGS:

The connecting rod bearings are of the steel shell type. The bearing material is aluminium and tin. After they have been installed, they must not be moved to a different position.

Each connecting rod and cap must be kept together as a unit. Do not use a file or scraper on the bearings, caps or connecting rods.

MAIN BEARINGS:

The main bearings are of the steel shell type. The bearing material is aluminium and tin.

Before removal, put a mark on each cap so that the caps can be installed in the same position. After they have been installed, they must not be moved to a different position.

When you install the caps, make sure that they are installed in their original positions.

Do not use a file or scraper on the bearings or the caps.

A range of bearings is available if reconditioning is necessary. For details of the sizes, see the Specification Section.

CRANKSHAFT RECONDITIONING:

If the crankshaft journals have wear or damage the crankshaft must be reconditioned and new bearings installed.

Permissible Wear:

The following recommendations are only to be used as guide to the maximum permissible amount of wear before reconditioning is necessary.

Connecting rod journals: 0.127 mm (0.005 in)

Main bearing journals: 0.127 mm (0.005 in)

End clearance: 0.38 mm (0.015 in)

Balance Weights:

Before any work is done on a crankshaft, the balance weights must be removed. The procedure for removing and installing the balance weights is as follows:

1. Put a mark on each balance weight so that it can be installed in the same position.
2. Bend the tabwashers away from the heads of the bolts.
3. Remove the bolts and the balance weights.
4. Before you install the balance weights, remove any sharp edges that will prevent the weights from making a good seat on the crankshaft.
5. Put the weights in position on the crankshaft. Install NEW bolts and NEW tabwashers. Tighten the bolts to 54 Nm (40 lb ft) 5.5 kgm.
6. Use a 0.05 mm (0.002 in) feeler gauge to make sure there is no gap between the faces of the balance weights and the crankshaft. This is important.
7. Bend the tabwashers against the heads of the bolts.




FIGURE 45 CHECKING BALANCE WEIGHTS AFTER INSTALLING

- A. Crankshaft
B. Check gap here
C. Balance weight
D. Bolts

Grinding the Crankshaft:

The dimensions and tolerances are as shown below:

Main journal diameters:

Standard size

63.487 to 63.474 mm (2.4995 to 2.4990 in)

Under size 0.254 mm (0.010 in)

63.233 to 63.220 mm (2.4895 to 2.4890 in)

Under size 0.508 mm (0.020 in)

62.979 to 62.966 mm (2.4795 to 2.4790 in)

Under size 0.762 mm (0.030 in)

62.725 to 62.712 mm (2.4695 to 2.4690 in)

Connecting rod journal diameters:

Standard size

60.2869 to 60.2742 mm (2.3735 to 2.3730 in)

Under size 0.254 mm (0.010 in)

60.0329 to 60.0202 mm (2.3635 to 2.3630 in)

Under size 0.508 mm (0.020 in)

59.7789 to 59.7662 mm (2.3535 to 2.3530 in)

Under size 0.762 mm (0.030 in)

59.5249 to 59.5122 mm (2.3435 to 2.3430 in)

No. 3 main journal width:

Standard size

41.3004 to 41.249 mm (1.626 to 1.624 in)

Oversize 0.254 mm (0.010 in)

41.5544 to 41.503 mm (1.636 to 1.634 in)

Oversize 1.016 mm (0.040 in)

42.3164 to 42.2656 mm (1.666 to 1.664 in)

Journal fillet radius:

All journals 4.06 to 3.81 mm (0.16 to 0.15 in)

IMPORTANT: When you recondition a crankshaft, make sure that you grind the radius of the journals correctly. They must be to the correct size and have a finish similar to the journal. There must be no steps between the journal and the radius.

If this operation is not done correctly, there will be a failure of the crankshaft.




FIGURE 46 EXAMPLES OF REGROUND FILLET RADII

- | | |
|---------|------------------------------------|
| | A. No radius |
| | B. Radius not evenly finished |
| Wrong | C. Radius too large |
| | D. Radius too small |
| | E. Radius too small |
| | F. Radius roughly finished |
| Correct | G. Correct radius, evenly finished |




FIGURE 47 CRANKSHAFT DIMENSIONS

- | | |
|----|----------------------------|
| A. | Main journal diameters |
| B. | Big end journal diameter |
| C. | Number three journal width |
| D. | Fillet radius |

CRANKSHAFT REAR SEAL

Diagnosis of Oil Leaks:

It is very important that the exact location of an oil leak is found before removing the oil seal retainer from the engine.

An accurate diagnosis can be made using air pressure inside the engine crankcase after the flywheel has been removed.

Test Procedure:

1. Remove the flywheel.
2. Put a plug made of cloth into the breather pipe to prevent air leaking from the crankcase. Turbo-charged engines: Remove the breather body, cover and diaphragm and put the plug in the base of the breather.
3. Remove the dipstick.
4. Adjust the pressure in an air hose to 69 kPa (10 lb/in²) 0.7 Kg/cm². Hold the air hose on the dipstick sleeve so that air will flow into the engine crankcase.
5. While there is air pressure inside the crankcase move a piece of slow burning material (or a burning cigarette) around the oil seal retainer. Check for leaks as shown in Figure 48. If there are any faults, the air from the crankcase will come in contact with the burning material. When this occurs there will be an increase in the rate of burning which will show the exact position of any leakage.




FIGURE 48 LEAK PATTERN: OIL RETAINER

Action:

1. *Leakage at Point 1 Figure 48:* Remove the engine and install new 'O' rings on the main bearing cap and new gaskets between the engine and the frame.

NOTE: This is not an oil retainer leak and installing a new oil retainer will not prevent leakage from this point.

2. *Leakage from Points 2 to 6. Figure 48.* Remove the oil retainer from the engine. Then carefully do the following procedure.

NOTE: If a new oil retainer is to be installed, also use the following procedure for checking the oil retainer and installing the packings.

Leakage from Point 2 Figure 48:

This is caused by the retainer not seating correctly on the cylinder block.

1. Check the retainer for the faults A, B, C and D Shown in Figure 49.
2. If necessary use a smooth file with chalk on the cutting edge to make the surface of the retainer flat.
3. Check that the seat of the socket head screw is parallel to the joint face of the retainer. See fault D, Figure 49. If the seats are not parallel, the retainer will bend when the screws are tightened. If necessary use a file as in Operation 2 to make the faces parallel.

NOTE: The latest type of oil retainers do not have a locating lip. These can be made flat using a sheet of smooth emery cloth and a similar size piece of plate glass.




FIGURE 49 OIL RETAINER FAULTS

Leakage from Points 3 and 4 Figure 48:

This is caused by the following faults:

The two parts of the retainer are not parallel. See Figure 50. Loose ends of the packings are between the faces.

1. Remove the retainer from the cylinder block.
2. Remove the socket screws, separate the two parts and remove the packings.
3. Put the two parts of the retainer together. Install and tighten the socket screws.
4. Hold the retainer up to a good light and look at the joint faces.
5. If this check shows a gap between the joint faces, use a file as before to make the faces flat.
6. Put the two parts together. Install and tighten the socket screws.
7. Important: Check the face of the retainer that is fastened to the cylinder block.
8. If necessary, use a smooth file to make this face flat.




FIGURE 50 JOINT FACE FAULT




FIGURE 51 PACKING FAULT

Leakage from point 4. Figure 48:

This is caused by the ends of the packings not in correct contact and oil flowing through the gap.

1. Install new packings. See the Assembly Procedure.

Leakage from Point 5. Figure 48:

This is caused by the packings not sealing correctly on the crankshaft. Check the following:

1. Wear or damage to packings.
 2. A restriction in the engine breather.
- NOTE: On turbocharged engines there must be a hole in the breather body as shown in Figure 52.
3. Wear in piston rings which causes too much pressure in the crankcase.
 4. Too much end movement on the crankshaft.
 5. Wear on the main bearings.

Leakage from Point 6. Figure 48:

This is caused by oil flowing through the bolt threads.

1. Replace the spring washers with rolled copper washers, Part No. K15489.

Assembly Procedure

1. Clean the two parts of the oil retainer, remove the packings and clean the packing grooves. Make sure that all the old jointing material is removed.
2. Hold the top part of the oil retainer, packing groove up, in a vice that has soft jaws.
3. Put a small amount of Evostick impact adhesive in the bottom of the packing groove. This will keep the packing in its correct position when the engine is started.
4. Put a packing on the retainer and then push it into the groove with the smooth handle of a screwdriver. Push the handle down on the centre of the packing and slide the handle from the centre to each end of the packing. DO NOT roll the handle when pushing the packing into the groove. See Figure 53.
5. Use a screwdriver blade that is not sharp to push the ends of the packing below the joint face of the retainer. See Figure 54.

IMPORTANT: DO NOT cut the ends of the packings. These are made to the correct length and the seal will fail if the length is decreased.




FIGURE 52 BREATHER HOLE POSITION

A. Breather hole




FIGURE 53 INSTALLING PACKING




FIGURE 54 INSTALLING PACKING

6. Remove any loose fibres with a very sharp knife. See Figure 55.
7. Use the same method to install the packing in the bottom part of the retainer, BUT DO NOT use Evostik contact adhesive in the groove.
8. Put the two parts of the oil retainer around a smooth piece of shaft that has been machined to the following dimensions:
Turbo-charged engines 66.50 mm (2.620 in)
Other models 63.50 mm (2.500 in)
9. Install and tighten the socket screws. This will push the packings into the correct contact with the packing grooves and the correct diameter for installing in the crankshaft. See Figure 56.
10. Remove the socket screws. Carefully remove the two parts of the retainer from the shaft.
11. Check that the packings are seated correctly. If for any reason the seating is not correct, the retainer must be discarded and a new oil retainer assembly installed.

Before Installing the Oil Retainer:

1. Use worn 320 grade emery tape to remove any marks from the part of the crankshaft which is in contact with the packings.
2. Clean the face of the cylinder block. Use cleaning fluid if necessary and make sure that any old jointing material is removed.

Installing the Oil Retainer:

Method A: Using gaskets:

1. Put a small amount of Evostik impact adhesive on the retainer faces which fit against the cylinder block. Put the gaskets in position on the retainer. Use a sharp knife to cut the ends of the gaskets level with the ends of the retainer faces.
 2. Put an even layer of Wellseal joint compound on the face of the cylinder block.
- IMPORTANT:** Do not use a thick type of joint material as this will cause the retainer to bend when the bolts are tightened.
3. Put a thin strip of Loctite Superfast Flange Sealant 573, Part No. K965910 on each side of one part of the retainer. See Figure 57.
 4. Replace the spring washers on the hexagon head bolts with copper washers. Part No. K15489.
 5. Put a small amount of engine oil on the packings. Put the two parts of the retainer in position on the crankshaft and install the socket screws finger tight. Install the hexagon head bolts.




FIGURE 55 CUTTING THE PACKING

A. Correct B. Wrong




FIGURE 56 RETAINER INSTALLED ON SHAFT




FIGURE 57 POSITION OF SEALANT

A. Loctite Superfast Flange Sealant 573

6. Tighten the bolts and socket screws in the following sequence.

- i. Tighten the socket screws evenly, then loosen both socket screws one half turn.
- ii. Tighten the hexagon head bolts.
- iii. Tighten the socket screws.
- iv. Loosen the hexagon head bolts one half turn. Wait for 30 seconds, then tighten the hexagon head bolts.

Do this procedure to make sure that there are no gaps between the two parts of the retainer and between the face of the retainer and cylinder block.

Method B: Not using gaskets:

NOTE: When Loctite Superfast Gasket Eliminator 504, Part No. K965909 is used instead of gaskets, all oil must be removed from the joint surfaces. Make sure there is no oil in bolt or drain holes which can get on to the joint surfaces before the seal material has become hard.

The strength and gap filling characteristics of this seal material will be increased if the joint surfaces are sprayed with Loctite Superclean Safety Solvent before the seal material is applied.

1. Put a thin strip of Loctite Superfast Flange Sealant 573 on each side of one part of the retainer. See Figure 57.
2. Put a thin strip of Loctite Superfast Gasket Eliminator 504 on the face of the retainer. See Figure 58.

Then follow the same procedure as in Method A, Operations 4, 5 and 6.

NOTE: On later engines the oil retainer is made without a lip. An extra hole is drilled at the bottom of the retainer as shown in Figure 56.

Oil retainer assembly, Part No. K964994 is available for earlier engines. This oil retainer has no lip but only four holes. When installing, use copper washers instead of spring washers on the bolts.

FRONT MAIN BEARING CAP:

When you install the front bearing cap use a sealant between the bearing cap and the cylinder block. It is a recommendation that you put Wellseal on the front edges of the bearing cap. Wait five minutes for the Wellseal to harden before you install the bearing cap. See Figure 59.




FIGURE 58 POSITION OF GASKET ELIMINATOR

A. Loctite Superfast Gasket Eliminator 504




FIGURE 59 FRONT MAIN BEARING CAP

A. Wellseal joint material

TIMING COVER AND SEAL:

Removing:

1. Remove the setscrew from the front of the crankshaft.
Remove the flat washer.
2. Use a puller to remove the crankshaft pulley.
3. Remove the ten setscrews which fasten the timing cover to the cylinder block.
Remove the timing cover.
Remove the old gasket and clean the faces of the cover and the carrier plate.

Replacing the Oil Seal:

The dowels in the timing cover and the holes for the dowels in the cylinder block are not now used. If a timing cover has dowels, these must be removed before installing the timing cover.

1. Put the timing cover with the outside (front) on two pieces of wood.
Use a hammer and punch to remove the oil seal from its housing.
2. Put a new gasket in position on the carrier plate.
3. Put the timing cover in position and install the setscrews loosely.
4. Put Service Tool No. K962560 on the end of the crankshaft.
Push the tool along the crankshaft until it is inside the seal housing.
5. Tighten the setscrews evenly to 20.4 Nm (15 lb ft) 2.1 kg/m.
6. Remove the tool.
7. Put a new oil seal, seal lip toward the cylinder block, in position at the edge of the seal housing.
8. Use the spigot of the tool to push the seal in the housing.
Hit the end of the tool with a soft faced hammer to make sure the seal is in its correct position.
9. Install the crankshaft pulley 'O' ring, washer and setscrews.
10. Tighten the setscrew to 150 Nm (110 lb ft) kg/m.




FIGURE 60 INSTALLING THE OIL SEAL

A. Special tool No. K962560

INJECTION PUMP DRIVE HOUSING:

Removing:


1. Remove the fuel injection pump.
2. Use a small lever to loosen the housing.
Pull the housing out of the cylinder block.

Installing:

1. Turn the engine in the normal direction of rotation until the No. 1 inlet valve is closing.
When the valve is in this position, stop turning.
2. Put the timing peg in the hole SP in the flywheel housing.
3. Continue to turn the engine slowly until the timing peg will go in to the hole in the engine flywheel.
4. Clean the faces of the cylinder block and the housing. Install a new gasket.
5. Put the master spline of the drive shaft in position A as shown in Figure 61.
6. Push the housing into the cylinder block.

NOTE: When the housing is in position, the master spline must be in position B as shown in Figure 61. If it is not possible to get the master spline exactly in this position, use a position after the one that is shown.

DO NOT install the drive shaft with the master spline in a position before the one that is shown.



† FIGURE 61 POSITION OF MASTER SPLINE

Disassembling:

1. Remove the circlip which holds the driven gear in position.
2. Use a soft metal punch and a hammer to remove the driven gear from the housing.
3. Carefully pull the needle roller bearing out of the housing.
4. Remove the bottom circlip.
Use a punch and a hammer to remove the ball bearing.

IMPORTANT: The needle roller bearing in the housing has been changed from an extra precision type to a precision type.

The bore of the housing has also been increased in diameter so that the new type bearing can be installed. It is most important to use the correct bearing for the type of housing. If the wrong bearing is installed it will fail rapidly.

Identification of the different bearings and housing is as follows:

Extra Precision Bearing: The outside diameter of the bearing case has a ground finish. The bearing has the marks GB 2812.

Precision Bearing: The outside diameter of the bearing case does not have a ground finish. The bearing has the marks B 2812.

Late Type Housing: The marks K948193 are on the housing.

Assembling:

1. Install the top circlip.
Install the ball bearing.
Install the bottom circlip.
2. Install the needle roller bearing using the special tool.
3. Carefully install the driven gear. Use a soft faced hammer to put the driven gear in position.
4. Install the circlip to hold the driven gear in position.





FIGURE 62 NEEDLE ROLLER BEARING TOOL

- A. Diameter 44.347 mm (1.746 in.)
- B. Diameter 53.772 mm (2.117 in.)
- C. 60.325 mm (2 3/8 in.)
- D. Recess 7.112 mm (0.280 in.)
- E. Chamfer 15°



† FIGURE 63 SECTION THROUGH INJECTION PUMP DRIVE

- A. Camshaft skew gear
- B. Oil pump bracket
- C. Oil pump locating screw
- D. Oil pump driveshaft
- E. Driven gear
- F. Needle roller bearing
- G. Ball bearing
- H. Injection pump driveshaft

TRACTORMETER DRIVE:

Removing:

1. Remove the nut which connects the outer cable to the drive housing.
Pull the inner cable out of the spindle.
2. Loosen the locknut of the locating screw.
Remove the locating screw.
3. Carefully pull the housing out of the cylinder block.

Installing:


1. Install a new 'O' ring on the housing.
2. Carefully push the housing in the cylinder block.
3. Install and tighten the locating screw. Tighten the locknut.
4. Push the inner cable in the spindle.
5. Connect the outer cable to the housing with the nut.

Disassembling:

1. Hold the housing in a vice that has soft metal jaws.
2. Remove the adaptor from the top part of the housing.
3. Remove the spring pin which fastens the gear to the spindle.
4. Hit the spindle at the gear end with a soft metal punch until the spindle is away from the gear.
5. Remove the gear and spindle.

Assembling:

1. Install a NEW 'O' ring in the spindle housing.
2. Install the spindle.
3. Install the adaptor.
4. Align the holes in the gear with the hole in the spindle.
Install the gear and the spring pin.



R79-100

FIGURE 64 TRACTOMETER DRIVE

- | | |
|-------------|-------------------|
| A. Adaptor | D. Spindle |
| B. Camshaft | E. Locating screw |
| C. Gear | F. 'O' ring |
| | G. Body |


TIMING GEARS:

IMPORTANT: Before you remove either of the timing gears, turn the engine to the No. 1 top dead centre position. In this position the timing marks are aligned, which will make installation easier. **DO NOT** turn the crankshaft or the camshaft after the timing gears have been removed or damage will be caused to the valves and pistons.

Timing the Engine:

1. Check that the No. 1 piston is in the top dead centre position.
2. Install the camshaft gear on the camshaft. Move the camshaft if necessary so that the keyway is in the six o'clock position and the punch mark is toward the crankshaft.
3. Install the crankshaft gear so that the marks on the gear and the crankshaft are aligned.
4. Push the crankshaft gear on the crankshaft so that the marks on the circumference of the crankshaft gear and the camshaft gear are aligned.

See Figure 65.



R79-101

FIGURE 65 TIMING GEAR MARKING

- | | |
|-----------------------|--------------------|
| A. Camshaft gear | C. Crankshaft gear |
| B. Camshaft gear mark | D. Spline mark |

CAMSHAFT:

Removing:

1. Remove the rocker shaft complete with the rockers, and the pushrods.
2. Remove the tappet covers.
3. Raise the tappets away from the camshaft.
Use small 'O' rings, 12 mm ($\frac{1}{2}$ in) in diameter to keep the tappets in position.
4. Remove the fuel feed pump and the push rod.
5. Remove the timing cover.
6. Remove the injection pump drive housing.
7. Cut the lock wire and the bolt which fastens the gear to the camshaft. See the section Timing Gears before you remove the gear.
8. If the correct puller is available, remove the gear from the camshaft. DO NOT use levers to remove the gear as this will cause damage to the camshaft.
If the correct puller is not available see Operation No. 10, 11 and 12.
9. Remove the setscrews which fasten the locating housing to the cylinder block.
10. Pull the camshaft out of the cylinder block.
11. Turn the engine until a hole in the camshaft gear is aligned with one of the locating housing setscrews.
Remove the setscrew.
Turn the engine and remove the remainder of the setscrews in a similar way.
12. Pull the camshaft complete with the gear out of the engine.
13. Use a press to remove the gear from the camshaft.
Remove the locating housing.

Installing:

1. Put the camshaft in position in the cylinder block.
 2. Install the locating housing.
- NOTE: The housing can only be installed in one position.
3. Install the setscrews.
Tighten the setscrews to 20 Nm (15 lb ft) 2.1 kg/m.
 4. See the section Timing Gears before you install the camshaft gear.
Install the gear. Use a soft faced hammer to put the gear on the camshaft.
 5. Install the bolt and washer.
Tighten the bolt to 88 Nm (65 lb ft) 9 kg/m.
 6. Install a lock wire.
 7. Install the timing cover.
 8. Install the fuel pump and push rod.
 9. Install the injector pump drive housing.
 10. Remove the 'O' rings from the tappets.
 11. Install the tappet covers.
 12. Install the push rods and rocker shaft.
 13. Adjust the valve clearances.
 14. Install the fuel injection pump.
 15. Install the cylinder head cover.

EXHAUST FLANGE AND SILENCER:

A new type of silencer and exhaust flange was installed from Engine No. 43947. See Figure 66. The new type silencer, flange and studs can be installed on earlier engines if the hole in the bonnet is increased to 82.5mm ($3\frac{1}{4}$ in) diameter.




FIGURE 66 EXHAUST FLANGE AND SILENCER

- A. Silencer
- B. Shroud
- C. Flange

REMOVING THE ENGINE:

1. Remove the front cab mounting bolts. Loosen the rear cab mounting bolts.
2. Use jacks to raise the front of the cab approximately 25mm (1in).
Put pieces of wood between the cab floor and the gearbox cover to keep the cab in this position.
3. Remove the silencer and the bonnet.
4. Remove the starter motor.
5. Disconnect the tractormeter cable, the engine stop and throttle controls and the wiring from the instrument panel.
6. Remove the fuel from the fuel tank and remove the fuel tank complete with the instrument panel.
7. Disconnect the hydraulic pipes for the steering at the connectors near the flywheel housing.
8. Remove the coolant from the radiator and cylinder block.
9. Disconnect the hoses and remove the radiator.
10. Remove the oil from the engine sump.
11. Remove the sump cover.
12. Remove the two cylinder block bolts from inside the tractor frame on the right-hand side.
13. Remove the cylinder block bolt from inside the tractor frame below the fuel injection pump.

Using Special Tractor Support Tool:

14. Fasten the support wheels to the front part of the tractor.
15. Put wood blocks under the front and rear of each rear wheel to prevent any movement.
16. Remove the cover from under the flywheel housing.
17. Push a trolley type jack between the centre of the rear wheels until the lifting pad is just behind the rear frame joint.
Put a block of wood on the lifting pad and raise the jack until it is holding the weight of the rear of the tractor.
18. Remove the bolts which fasten the flywheel housing and the clutch housing to the main frame.
19. Remove the four internal frame bolts, two at each side, from inside the clutch housing.
20. Move the front part of the tractor forward to separate the two parts.
21. Check the alignment and if necessary raise or lower to rear part of the tractor.
22. Move the front part of the tractor forward until there is enough space to remove the clutch.
23. Remove the clutch, flywheel and clutch housing.
24. Remove the bolts from the flange of the cylinder block.
25. Fasten an acceptable lifting tool to the engine.
Use a hoist to lift the engine out of the frame.




FIGURE 67 TRACTOR SEPARATED FOR ENGINE REMOVAL


Without Special Tractor Support Tool:

1. Do operations 1 to 13 as shown in Section: Removing the Engine.
2. Put wood wedges between both sides of the tractor frame and the front axle.
Put wood blocks under the front and rear of each rear wheel to prevent any movement.
3. Put supports under the rear half of the main frame to keep the frame in alignment.
4. Remove the cover from under the flywheel housing.
5. Push a trolley type of jack between the front wheels until the lifting pad is below the flywheel housing.
Put a block of wood on the lifting pad and raise the jack until it is holding the weight of the front of the tractor.
6. Remove the bolts which fasten the flywheel housing and the clutch housing to the main frame.
7. Move the trolley jack forward carefully to separate the two parts of the tractor.
8. Check the alignment of the two parts. If necessary, raise or lower the jack until the alignment is correct.
9. Move the front part of the tractor forward until there is enough space to remove the clutch.
10. Put supports between the frame and the ground.
Lower and remove the trolley jack.
11. Remove the clutch, flywheel and clutch housing.
12. Remove the bolts from the flange of the cylinder block.
13. Fasten an acceptable lifting tool to the engine.
Use a hoist to raise the engine out of the frame.

INSTALLING THE ENGINE:

1. Clean the faces of the main frame and the cylinder block.
Remove the old bearing cap seals.
Clean the grooves and the holes in the cylinder block.
 2. Install new bearing cap seals. Put a small amount of Wellseal or a similar joint material on the faces of the main frame.
 3. Put a small amount of Wellseal on both faces of the new gaskets.
Put the gaskets in position on the main frame.
 4. Install one $\frac{3}{8}$ UNC stud on each side of the main frame. These studs will be guides for the cylinder block and will prevent the gaskets moving out of position.
 5. Use a hoist to put the engine in position on the main frame.
 6. Remove the studs and loosely install the bolts which fasten the cylinder block flange to the main frame.
 7. Install the clutch housing.
Tighten the bolts to 34Nm (25 lb/ft) 3.46 kg/m.
 8. Tighten the cylinder block to main frame bolts to 34Nm (25 lb/ft) 3.46 kg/m.
 9. Install the flywheel. Install new tabwashers and tighten the nuts to 61Nm (45 lb/ft) 6.2 kg/m.
 10. Install the clutch using a pilot shaft to align the clutch plates.
 11. Install a long $\frac{7}{8}$ UNC stud at each side of the front part of the main frame as a guide.
 12. Put the trolley jack in position with the lifting pad just behind the rear frame joint. Raise the jack and remove the supports.
 13. Push the front part of the tractor toward the rear part. Raise or lower the jack until the two parts are correctly aligned. In this position the guide studs will go in to the correct holes in the rear main frame.
 14. When the studs are in the holes, continue to push the front part toward the rear until the two parts are in contact.
- NOTE: During this operation it will be necessary to turn the engine by hand so that the gearbox driveshaft and the PTO cardan shaft engage in the splines of the clutch plates.
15. Remove the guide studs and install the bolts which fasten the two parts of the main frame together. Tighten the bolts to 61Nm (45 lb/ft) 6.2 kg/m.
 16. Remove the jack, the supports under the rear frame, the blocks from the wheels and the wedges from between the main frame and front axle.
 17. Install the bolts inside the main frame.
 18. Install the sump cover with a new gasket.
 19. Connect the hydraulic oil pipes.
 20. Install the radiator and connect the hoses.
 21. Install the fuel tank with the instrument panel.
 22. Install the starter motor.
 23. Connect the tractormeter cable.
 24. Connect the wiring.
 25. Use jacks to raise the cab.
Remove the wood from between the cab floor and the gearbox cover.
 26. Install and tighten the front cab mounting bolts.
Tighten the rear cab mounting bolts.
 27. Start the engine and check for leaks.

3-CYLINDER ENGINE LIFTING BRACKET



Nut and distance piece to be welded to stud allowing $\frac{1}{16}$ in. (0.158 cm) clearance between nut and angle bracket.

Position 'X' to be used for Engine only.

Position 'Y' to be used for Engine, Sump Frame, Flywheel and Flywheel Housing.

Dimension	A	B	C	D	E	F	G	H	J	K	L	M	N
mm	203	178	25	54	52	50	38	95	22	20	17	12	6
in	8	7	1	2 $\frac{1}{8}$	2 $\frac{1}{8}$	2	1 $\frac{1}{2}$	3 $\frac{1}{2}$	$\frac{7}{8}$	$\frac{3}{4}$	1 $\frac{1}{8}$	$\frac{1}{2}$	$\frac{1}{4}$

Shackle: — Screw Pin "D" Type: —
Shackle Diameter 12mm ($\frac{1}{2}$ in)
Pin Diameter 16mm ($\frac{5}{8}$ in)

For all engines built after September 1973 two special nuts, K906898 must be used. These nuts have been tested to lift the weight of a complete engine.

FIGURE 68 LIFTING BRACKET FOR ENGINE



Service Repair Manual

**Four -Cylinder Diesel Engine
(AD4/49, AD4/55)**

Section A4 (Pub. 9-37122) April 1971 (Reprinted January 1984)

J I Case
A Tenneco Company



Case policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the Case tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

2J1 Case

First Reprint April 1977

Second Reprint October 1980 (including updated pages 16-16d—Pub. 9-38195)

Introduction

All engines are stamped on the right-hand side of the cylinder block with a type designation and serial number, e.g. 455001/4001 or 449002/1001, etc. The engine designation number is built up according to the following formula, commencing at the left:

First digit — number of cylinders.

Second and third digits — together these give the nominal capacity, in cubic inches, of one cylinder. (The approximate capacity, in cubic inches, of an engine can be obtained by multiplying the first digit by the second and third digits, e.g.: $4 \times 55 = 220$ cu. in. and $4 \times 49 = 196$ cu.in.)

Fourth digit — type of fuel: 0 for diesel (1 would be gasoline).

Fifth digit — design series: 0 is the first series and 1 is the second, etc. This number is used to identify engines which are in different forms to suit different tractor frames.

Sixth digit — type of clutch: 1 Livedrive, 2 single plate, 5 twin-plate.

The designation is then followed by the engine serial number; these are consecutive and allow individual engines in each type to be identified.

Examples:

4 5 5 0 0 1 / 4 0 0 1
 4-cylinder { 55 cu in. diesel first series Livedrive

is a 4-cylinder, 200 cu. in. capacity, diesel, first series, Livedrive model, serial number 4001

4 4 9 0 0 2 / 1 0 0 1
 4-cylinder { 49 cu in. diesel first series Non-Livedrive

is a 4-cylinder, 196 cu. in. capacity, diesel, first series, Non-Livedrive model, serial number 1001.

Engine Designations and Tractor Models

Engine Type	Tractor Model	Tractor Number
455001	1200 Selectamatic Livedrive	700001 onward
455002	1200 Selectamatic Non-Livedrive	
449001	990 Selectamatic Livedrive	800001 onward
449002	990 Selectamatic Non-Livedrive	
449005	990 Non-Livedrive (Twin-plate clutch)	

CONTENTS

Section	Description	Page
	MAINTENANCE	1
	REPAIR OPERATIONS (in same order as Schedule of Repair Times TP670)	3
A1	Engine Tune	3
A2	Engine Removal and Replacement	3
B1	Adjusting Valve Clearance	8
B2	Removing and Replacing Cylinder Head	8
B3	Decarbonising Cylinder Head	9
C2	Pistons and Connecting Rods	14
C4	Camshaft	15
D1	Injectors	17
D2	Fuel Feed Pump	20
D3	Fuel Filter	20
D4	Venting Fuel System	21
D8	Fuel Injection Pump	23
D9	Fuel Tank	26
E1	Lubricating Oil Filter	28
E3	Lubricating Oil Pump	28
F3	Air Cleaner	31
G1	Timing Cover	31
G3	Timing Gears	32
H6	Water Pump	35
	DIMENSIONAL DATA	36
	SUMMARY OF DESIGN CHANGES	40

MAINTENANCE

Daily

Engine Oil: Check oil level in engine sump and top up if necessary.

Air Cleaner: Remove filter bowl and examine condition of oil. In dusty conditions the oil should be changed frequently, the detachable wire element removed, washed in diesel fuel, and allowed to stand until all fuel has drained off. (Fig. 1.)

Paper Element Pre-Cleaner: This is an alternative fitting to the centrifugal type pre-cleaner and incorporates a replaceable paper element. Frequency of attention depends on working conditions and in dusty climates the cover should be removed every few hours of use and the element examined. The element can be cleaned by tapping its side to shake off the loose dust. If the element becomes very dirty, or contaminated with oil or water, it should be renewed. *Do not attempt to wash an element.* (Fig. 2.)




Figure 1. AIR CLEANER

- | | | |
|-----------------------|-----------------|------------------------|
| A. Oil bowl | B. Wire mesh | C. Rubber sealing ring |
| D. Cleaner inlet pipe | E. Cleaner body | |

Every 60 Hours

Engine Oil: Check oil level in engine sump and top up to within "safe" range if required.

Cooling System: Check radiator water level and top up to within 1 in. (2.5 cm) from top of filler neck if required. *If engine is hot, remove radiator cap slowly as system is pressurised and may scald hand if opened quickly.*

Sediment Bowl: Visually examine feed pump sediment bowl. Remove and clean if there is any accumulation of dirt or water. (Fig. 3.)



Figure 2. PAPER ELEMENT PRE-CLEANER

Air Cleaner: Remove bowl and detachable wire mesh element. Clean out bowl and refill with new, clean oil.

The depth of dust deposit in cleaner bowl must not be allowed to exceed $\frac{1}{4}$ in. (6.3 mm) when checked after standing overnight, otherwise oil pull-over into induction manifold will take place due to raised oil level. Oil in the induction manifold, which indicates oil pullover, can be checked through ether plug in manifold. Oil pullover will cause rapid engine wear and must be prevented by adequate cleaner maintenance.




Figure 3. FEED PUMP SEDIMENT BOWL

- | | |
|----------------------|------------------|
| A. Bowl securing nut | B. Sediment bowl |
| C. Sealing ring | D. Filter screen |
| E. Priming lever | |

Every 125 Hours

Engine Oil: Drain oil, when engine is warm, through plug on underside of sump. Refill with approved oil to upper mark on dipstick.

Injection Pump (1200 Tractors only): Drain lubricating oil from injection pump, by means of drain plug in pump base, and refill with new engine oil until it commences to run out of level plug. (Fig. 37.)

Every 250 Hours

Oil Filter: Fit new element in engine lubricating oil filter. Do not attempt to wash a filter element. (See page 28.)

Every 500 Hours

Fuel Filter: Fit a new element in the first fuel filter but do not disturb second fuel filter. (See Page 20.)

Do not attempt to clean fuel filter elements and do not change elements from one filter to another.

Sediment Bowl: Remove and flush out feed pump sediment bowl, remove filter screen and clean with air blast. As the feed pump is lower than the fuel tank it is necessary to slacken outlet union on fuel tank, so that fuel will not siphon out when bowl is removed. Replace screen and bowl, ensuring that it seats on sealing ring in pump body then retighten fuel pipe union.

Injectors: Remove injectors for cleaning. Failure to clean injectors will result in the nozzle carbon deposit becoming so hard that it cannot be removed and a new nozzle will be required. (See Page 17.)

Valve Clearances: This should be done whilst injectors are removed and engine is cold. (See Page 8.)

Dynamo: Remove small rubber plug from centre of dynamo rear end-plate and inject a few drops of engine oil through hole and replace plug.




Figure 4. FAN BELT ADJUSTMENT

A. Dynamo mounting bolts

Fan Belt: Check fan belt tension by deflecting belt midway between fan and crankshaft pulleys. Belt should deflect approximately 1 in. (25 mm) and if necessary may be adjusted by releasing the three dynamo mounting bolts and swinging dynamo on two upper mounting bolts. Tighten lower bolt first as this will hold dynamo in position whilst upper bolts are tightened. Do not overtighten the belt. A taut belt will place excessive load on dynamo and water pump bearings and cause rapid belt wear. Renew belt if it has insufficient tension when dynamo lower mounting bolt is at end of adjusting slot. (Fig. 4.)

Every 1000 Hours

Fuel Filter: Using the same procedure as in 500 hours' service, fit new elements in both first and second fuel filters. Do not attempt to clean or interchange filter elements.

REPAIR OPERATIONS

● OPERATION A1

Engine Tune

If engine becomes difficult to start, or does not develop full power, carry out the following engine tune:

1. **Compression Test:** Use a test gauge as shown in the Service Tool List. Remove all injectors and, using a correct length of extension, fit gauge into No. 1 injector bore. Tighten down with injector nuts to give an airtight seal, and with the stop control in the "stop" position spin engine with starter motor. It is advisable to use a fully-charged battery as the higher the cranking speed the better. Note the gauge reading then repeat the procedure on the remaining cylinders. If the four readings are approximately the same, proceed with the engine tune. If there is a difference of more than 50 lb/sq. in. (3.5 kg/sq. cm) it will be necessary to remove the cylinder head as the loss of performance is due to weak compression and an engine tune will not be fully effective.
2. **Valve Clearance:** Whilst the injectors are out, remove valve rocker cover and check valve clearance (see Page 8). Adjust if necessary, noting that exhaust valves with a cap on the stem end (Fig. 20) should have 0.007 in. (0.18 mm) clearance, but exhaust valves not fitted with caps (Fig. 20) and all inlet valves should have 0.010 in. (0.25 mm) clearance.
3. **Injectors:** Service the injectors (see Page 17) before replacing. Take care to fit copper sealing washers on injector nozzles and tighten nuts down evenly to avoid distortion.
4. **Air Cleaner:** Clean out oil bath and refill to correct level with new oil. Wash wire mesh element, clean out inside of inlet pipe and pre-cleaner. If a paper element pre-cleaner is fitted clean or renew the element (see Page 31).
5. **Fuel Filters:** Clean out fuel sediment bowl and replace fuel filter elements as necessary (see Page 20). Vent fuel system (see Page 21).
6. Start engine, allow to reach working temperature then check idling and maximum speeds. Re-set if necessary (see Page 22).

● OPERATION A2

Engine Removal and Replacement

1200 Tractors and 990 6-speed Tractors

Place tractor on firm and reasonably level ground and within reach of suitable lifting equipment.

Remove silencer and bonnet. Drain cooling system and disconnect battery earth lead.




Figure 5. HYDRAULIC FILTER SWITCH — 990 Tractors

A. PTO case B. Adaptor C. 'O' ring—adaptor

Disconnect hoses and remove fan. Remove radiator on 990 Tractors; on 1200 Tractors the radiator and bonnet front need not be removed but the hydraulic pump driveshaft must be disconnected by releasing coupling from crankshaft pulley and removing rubber distance piece.

Disconnect fuel and leak-off pipes from tank; if tank is full it is advisable to drain the fuel to lighten tank. Remove hand throttle lever, disconnect instrument panel wiring and engine speed indicator drive cable. Remove fuel tank mounting bolts and remove tank complete with instrument panel.

Clean gearbox cover, top of rear axle case and adjacent areas to prevent dirt entering main frame when gearbox cover is removed.

Remove steering-box, complete with column and wheel; on 1200 Tractors the box should first be drained of oil. If tractor is fitted with hydrostatic steering, disconnect and drain oil reservoir, then disconnect pipes from servo valve and pump. Remove pump reservoir and servo valve complete with column and mounting bracket. Remove all pipes and *seal all pipe ends and unions* to prevent dirt entering system.

Remove starter and cable from battery to starter. Remove clutch housing — four bolts are positioned inside steering-box cavity — taking care of wedge and shims.

Release seat adjustment and slide seat fully rearwards. Remove gearbox cover bolts and lift off cover.

On Livedrive tractors it is necessary to drain the transmission oil into *clean containers*, remove PTO unit and withdraw cardan shaft clear of clutch. On 990 Tractors the hydraulic filter switch adaptor passes through underside of PTO case and *this adaptor must be removed* before PTO unit is withdrawn. (Fig. 5.)




Figure 6. 1200 TRACTOR WITH CLUTCH HOUSING AND GEARBOX COVER REMOVED

- | | | |
|--------------------|------------------------------|-----------------------------|
| A. Clutch assembly | B. Transmission release fork | C. PTO release fork |
| D. Support snout | E. Muff coupling | F. Bolts—clutch to flywheel |

Disconnect clutch stop brake band, by removing pins from each end of band. Remove bolts attaching stop assembly to main frame and allow assembly to rest in bottom of frame

Early 1200 Tractors have a plunger in each end of muff coupling and these should be removed by sliding spring clip to one side and then extracting plungers.

Release clutch driveshaft circlip from groove and slide muff coupling forward clear of gearbox shaft. On 990 Tractors the clutch-stop drum must be slid fully forward on shaft, to allow sufficient movement of muff coupling. On 1200 6-speed tractors slide muff coupling rearwards clear of clutch shaft.

On 1200 Tractors disconnect PTO release bearing housing from its fork by removing pivot bolt from left-hand side and split pin from right-hand side (Fig. 6). Disconnect bearing lubrication pipe if fitted.

On 990 Tractors remove the two figure-of-eight spring clips attaching clutch release bearing to its fork.

Remove bolts attaching cylinder block to main frame and fit lifting bracket (Fig. 7) on cylinder-head lifting nuts then lift engine unit, complete with clutch driveshaft and support snout, vertically out of frame. Guide muff coupling clear of gearbox as engine is raised and take care not to damage oil pump when lowering engine on to stand on bench. (Fig. 8.)

Refit engine in reverse order of removal, using new gaskets and seals, etc. Clean main frame and cylinder block faces, removing all traces of old gasket. Smear main frame and both sides of gasket with jointing compound before placing them in position. Fit new bearing-cap seals, pushing ends of seals into holes in block so that seals fit closely in bearing-cap grooves.

Two $\frac{3}{8}$ UNC studs temporarily screwed into main frame at opposite points will assist in locating engine and allow it to be lowered into position without disturbing the gaskets.

Fit clutch driveshaft, complete with release bearing, support snout, circlips, clutch-stop drum and muff coupling, into clutch assembly.

On 1200 Tractors the transmission release fork engages with slots in bearing sleeve and *care must be taken to position sleeve so that slots fit over fork when engine is lowered into position.* (Fig. 9.)

After lowering engine into position check that cylinder block is correctly seated on main frame, with both locating dowels engaged, and support snout is in line with frame holes. Connect the clutch release bearings to their forks and check that they operate quite freely.

Ensure that gearbox and clutch shafts are in line by checking that muff coupling can be freely engaged on shaft splines in all positions through full 360°.




Figure 7. ENGINE LIFTING BRACKET

Nut and distance piece to be welded to stud allowing $\frac{1}{16}$ (1.6 mm) clearance between nut and angle bracket.

A. 6 in. (15.24 cm)	B. $5\frac{1}{8}$ in. (12.86 cm)	C. 4 in. (10.16 cm)	D. $3\frac{1}{4}$ (9.366 cm)
E. $2\frac{1}{2}$ in. (6.350 cm)	F. 2 in. 5.080 cm)	G. $1\frac{1}{2}$ in. (4.445 cm)	H. $1\frac{1}{2}$ in. (3.810 cm)
J. 1 in. (2.54 cm)	K. $\frac{7}{8}$ in. (2.222 cm)	L. $\frac{5}{8}$ in. (1.587 cm)	M. $\frac{1}{8}$ in. (1.428 cm)
N. $\frac{3}{8}$ in. (0.952 cm)			

Slide muff coupling on to gearbox shaft and, after locating with circlip, check that coupling has not less than 0.008 in. (0.20 mm) end-float. To increase end-float slide coupling forward and remove shims from gearbox shaft.

The spring plungers fitted on early 1200 Tractors must be fitted so that plunger chamfer is on non-driving side and is against the shaft spline which has a chamfered corner. On these tractors, therefore, the coupling must not be fitted in any position but must be positioned so that chamfered spline on shafts are in line with plunger holes in coupling and plungers fitted opposite way round: front plunger with chamfer on leading side and rear plunger with chamfer on trailing side.

Before refitting gearbox cover, assemble and set clutch-stop as described in Clutch Section of Repair Manual. Replace gearbox cover, check that gear levers are correctly engaged in their selectors, then lightly tighten main bolts. Replace and fully tighten bolts through rear axle case then finally fully tighten cover-to-main-frame bolts.

Push PTO cardan shaft into clutch until it passes through clutch plate and enters flywheel spigot bearing. If cardan shaft cannot be pushed "fully home", release PTO clutch and turn shaft whilst pushing it into place.

Refit PTO unit. Fit new element in hydraulic filter, or clean screen if early type, replace transmission oil




Figure 8. REMOVING ENGINE UNIT

- | | |
|------------------------------|--------------------|
| A. Hydraulic pump driveshaft | B. PTO clutch fork |
| C. Transmission clutch fork | D. Muff coupling |




Figure 9. CLUTCH RELEASE MECHANISM — 1200 TRACTORS

- | | | | | |
|----------------|-----------------------|--------------------|--------------|-----------------------|
| A. Cross shaft | } Transmission clutch | D. Cross shaft | } PTO clutch | G. Friction washer |
| B. Fork | | E. Fork | | H. Special washer |
| C. Sleeve | | F. Bearing carrier | | J. Belleville washers |

except for last gallon, which will have accumulated most of the sediment, and top up with new oil.

When re-assembly is complete, carry out a full engine tune. (See Page 3.)

990 12-Speed Tractors

As these tractors do not have a muff coupling — the clutch driveshaft fits directly into the gearbox — the engine cannot be lifted from main frame with the clutch in position. To remove the engine it is therefore necessary to first "split" the tractor, to disengage clutch from driveshaft, then lift engine from front half of frame.

With the tractor standing on firm, level ground and positioned within reach of lifting equipment, remove bonnet and disconnect battery.

Remove hand throttle lever, disconnect engine controls. Disconnect engine speed indicator cable and instrument panel wiring. Disconnect leak-off and fuel pipes from tank, then remove fuel tank, complete with instrument panel. Place a jack under front end of main frame to support rear half of tractor when front half is withdrawn. Place a wooden block between jack and main frame and extend jack so that it takes weight but does not lift tractor. Drive two suitable wooden wedges between each side of front extension and axle beam, to ensure that front half of tractor will remain upright when separated. Drive wedges firmly into position to prevent any possibility of them becoming dislodged.

Place a trolley-jack under flywheel housing so that front half of frame can be eventually drawn forward.

Remove drop-arm from steering-box shaft and remove starter motor.

If tractor is fitted with hydrostatic steering disconnect and remove pipes from servo valve. Seal all pipe ends and unions to prevent dirt entering system.

Adjust height of trolley-jack so that it takes weight but does not lift tractor, then remove bolts attaching clutch housing and rear main frame to front half of tractor. Adjust so that they support tractor level, with main frame faces parallel, then draw front half of tractor forward until it is clear. Drain cooling system, remove radiator hoses and fan. Attach lifting bracket (Fig. 10) to lifting nuts on cylinder head, remove bolts holding engine to main frame then lift engine unit, complete with flywheel and clutch. Take care not to damage oil pump when lowering engine on to stand or bench.

Replace engine in reverse order of removal, using new gaskets, etc. Clean main frame and cylinder block faces, removing all traces of old gasket. Smear main frame and both sides of gaskets with jointing compound then place gaskets in position on frame. Fit new bearing cap seals, pushing ends of seals into holes in block so that seals fit into bearing cap grooves.

Lower engine carefully on to main frame; two $\frac{3}{8}$ UNC studs screwed into main frame at opposite points will assist in locating engine and allow it to be lowered into position without disturbing the seals.

Before pushing halves of tractor together check clutch release bearing and PTO cardan shaft. Push and turn shaft to ensure that it is engaged on PTO




Figure 10. 990 TRACTOR 'SPLIT' FOR ENGINE REMOVAL




Figure 11. CLUTCH PLATE-PILOT - 990 TRACTORS

A. 0.874 in. (22.20 mm)	B. 0.915 in. (23.24 mm)	C. 1.420 in. (36.07 mm)	D. 1.771 in. (44.98 mm)
E. $\frac{1}{8}$ in. (15.88 mm)	F. $1\frac{1}{2}$ in. (38.10 mm)	G. $1\frac{1}{2}$ in. (44.45 mm)	H. 5 in. (127 mm)
	J. $\frac{3}{8}$ in. (9.5 mm) dia.	K. $3\frac{1}{2}$ in. (82.55 mm)	

shaft splines. If clutch has been disturbed — and it is advisable to service clutch unit whilst it is accessible — ensure that clutch plates have been centralised by using a clutch pilot (Fig. 11) when clutch assembly is fitted to flywheel.

Bring two halves of tractor together, adjusting height of jacks to bring gap between frames parallel. Two $\frac{1}{2}$ UNC studs screwed into frame at opposite points will assist in centralising the two halves. When driveshafts enter clutch, engage low gear and turn engine until transmission plate splines engage on driveshaft. At the same time, engage PTO high ratio and turn PTO shaft until cardan shaft splines enter clutch plate. When frames are together and dowels entered, fit bolts and tighten evenly to avoid distorting frame flanges.

When re-assembly is completed, and cooling system refilled with water, tune engine as described on Page 3.

● OPERATION B1

Valve Clearance Adjustment: As the valve clearance must only be checked when the valve is at the back of cam — this position is reached when the opposite valve is full open — remove valve rocker cover and adjust valves in the following order:

- Adjust No. 1 valve when No. 8 valve is full open.
- Adjust No. 6 valve when No. 3 valve is full open.
- Adjust No. 4 valve when No. 5 valve is full open.
- Adjust No. 2 valve when No. 7 valve is full open.
- Adjust No. 8 valve when No. 1 valve is full open.
- Adjust No. 3 valve when No. 6 valve is full open.

Adjust No. 5 valve when No. 4 valve is full open.
Adjust No. 7 valve when No. 2 valve is full open.

Check clearance between tip of rocker arm and end of valve stem and if incorrect adjust by means of adjusting screw on rocker arm. Firmly tighten lock-nut after resetting screw then recheck clearance. (Fig. 12.)

All inlet valves, and also exhaust valves not fitted with a stem end cap (Fig. 20) should have 0.010 in. (0.25 mm) clearance, but exhaust valves with a cap on the stem end (Fig. 20) should have 0.007 in. (0.18 mm) clearance.

Check tightness of all adjusting-screw locknuts before replacing rocker cover.

● OPERATION B2

Cylinder Head Removal: Drain cooling water from radiator and cylinder block. Remove air inlet pipe and both manifolds. Remove top water hose and valve rocker cover. Disconnect oil feed pipe to cylinder head, remove rocker shaft and push rods.

Remove cylinder head nuts and bolts in the reverse order of tightening (Fig. 13). Remove gasket, clean block face and oil cylinder bores before covering with a cloth for protection.

Refitting Cylinder Head: Refit the head in the reverse order of removal, paying attention to the following:

1. Check thermostat and renew if necessary (see Page 34). Fit a new sealing ring on water pump by-pass connection.




Figure 12.

SETTING THE VALVE CLEARANCES

- A. Adjuster screw
- B. Locknut
- C. Feeler gauge

2. Clean and lightly oil the cylinder bores.
3. Coat both sides of head gasket with Wellseal, or a good brand of thin non-hardening jointing compound. The use of an unsatisfactory jointing compound may allow water seepage.
4. Ensure that head and block faces are clean and the gasket is fitted with the word "Top" towards the cylinder head.
5. Tighten head bolts and nuts in the order shown in Fig 13 and in three stages of 30, 60 and 90 lb ft (4, 8 and 12.5 kg metres).
6. Renew any bent push rods and if exhaust valves have stem end caps do not forget to replace these. Firmly tighten the rocker shaft pedestal bolts.
7. Carry out a full engine tune (valve clearances, air cleaner, etc.) as described on Page 3.
8. After the engine has run for approximately 1½ hours check rocker shaft bolts, tighten head bolts to 90 lb ft (12.5 kg metres) then check valve clearances.

CAUTION: Never run an engine without cooling water as this may cause cylinder glazing and subsequent high oil consumption.

● OPERATION B3

Decarbonising the Engine: When compression is low, or engine is down in power due to an accumulation of carbon inside combustion chamber, the cylinder head should be removed, cleaned of carbon and the valves re-seated

Remove injectors for servicing. Mark valves lightly for identification and, using a suitable compressor, remove valve cotters, cups and springs. Remove inlet valve seals, clean carbon from cylinder head and inspect head face, valve seats and guides.

● OPERATION B3a

Valves: Remove all carbon and examine the valve heads and stems. Discard valves if cotter location or valve stem is worn. If seat is pitted valves may be refaced at 45° provided that sufficient metal remains to avoid a sharp edge on valve head.

Valve Changes: The current valve, Part No 928622, is now fitted to both inlet and exhaust on 4/55 and 4/49 engines. This valve may be used to





Figure 13. CYLINDER HEAD TIGHTENING SEQUENCE

Tighten bolts and nuts in order shown and in three stages of 30, 60 and finally 90 lb. ft. (4, 8 and 12.5 kg metres)

Figure 14.

INLET VALVES AND SEAT INSERTS

- A. $3\frac{1}{2}$ in. (88.52 mm)
- B. $3\frac{1}{2}$ in. (95.25 mm)
- C. $3\frac{1}{2}$ in. (96.84 mm)
- D. 4.890 in. (124.21 mm)
- E. 4.860 in. (123.44 mm)
- F. 4.840 in. (122.94 mm)
- G. 1.505 in. (38.23 mm)
- H. 1.475 in. (37.46 mm)
- J. 1.380 in. (35.05 mm)
- K. $1\frac{3}{8}$ in. (34.92 mm)
- L. $1\frac{3}{32}$ in. (32.54 mm)
- M. 1.631 in. (41.43 mm)
- N. 1.568 in. (39.83 mm)



replace inlet valve 921433, previously used on all 4/49 engines from commencement of production, and 4/55 engines fitted with high-lift camshaft and larger diameter valves, but cannot be used to replace 914528 inlet valves, which were used on 4/55 engines up to No. 4912. (Fig. 14.)

The 928622 valve may be used to replace exhaust valves 921434, which were fitted on all 4/49 engines from commencement of production, and 4/55 engines fitted with high-lift camshaft and larger

diameter valves, provided that the original stem end caps, cotters and cup are discarded and the latest type cotters and cups are fitted. The 928622 valve should not be used to replace 900417 exhaust valves, which were fitted to 4/55 engines up to No. 4912. (Fig. 15).

When fitting 928622 valves ensure that the width of seat in the head insert is not less than 0.045 in. (1.14 mm) wide, to ensure that the valve does not seat at the edge of the valve head.




Figure 15.

EXHAUST VALVES AND SEAT INSERTS

- A. $3\frac{1}{2}$ in. (88.52 mm)
- B. $3\frac{1}{2}$ in. (82.55 mm)
- C. $3\frac{5}{8}$ in. (80.17 mm)
- D. 4.890 in. (124.21 mm)
- E. 4.835 in. (122.81 mm)
- F. 4.798 in. (121.87 mm)
- G. 1.505 in. (38.23 mm)
- H. 1.456 in. (36.98 mm)
- J. 1.362 in. (34.59 mm)
- K. $1\frac{5}{8}$ in. (33.34 mm)
- L. $1\frac{1}{2}$ in. (30.96 mm)
- M. 1.631 in. (41.43 mm)
- N. 1.568 in. (39.83 mm)




Figure 16. CYLINDER HEAD FACE GAUGES

A. Depth gauge (960938) B. Slip gauge (960940)

● OPERATION B3b

Valve Seat Inserts: Examine the seats for pitting, cracking, looseness and excessive seat width. If the seats are in good condition, grinding in the valves will be all that is required, but if the seats are pitted they may be recut to 45° after using a glaze breaker. Seat width should not be more than 0.065 in. (1.7 mm) and may be reduced slightly using 15° and 75° cutters.

Cracked or loose inserts should be renewed. Do not attempt to secure a loose insert by centre-punching the cylinder head face.

Removing a Seat Insert: Very carefully drill the insert at two opposite points, without damaging the cylinder head, then split the insert so that it can be removed without enlarging the head counterbore.

Fitting a Seat Insert: New standard inserts may be fitted if the diameter of the head recess is not greater than the initial machining dimensions shown on Page 37, otherwise a special insert will have to be made to maintain the original interference fit.

The cylinder head must be very clean and heated in water to near boiling point: a steam jenny is ideal for this purpose. Cool the insert in dry ice (solid carbon dioxide) then place it on a suitable mandrel, or guide, and quickly tap it into the head recess: chamfer on outside of insert towards cylinder head.

After fitting the insert, lightly cut at 45° until the seat is 0.045–0.055 in. (1.14–1.40 mm) wide and within 0.0015 in. (0.04 mm) of being concentric with valve stem bore.

● OPERATION B3c

Valve Guide Bores: The valve stems operate directly in the cylinder head (no separate guides) and if, after cleaning, the bores are found to be larger than 0.381 in. (9.68 mm) — or 0.006 in. (0.152 mm) clearance with a new valve — the bores should be reamed oversize and appropriate oversize valves fitted. Use the reamer, Part No. 960989 (0.010 in. oversize), or 961824 (0.020 in. oversize),

in a vertical pillar drill, running at its slowest speed; apply a liberal quantity of cutting fluid and take special care not to damage the sharp edge at top of exhaust bores.

Cylinder Head Face: This should be free from distortion or damage, otherwise the gasket will be unable to provide an effective seal. Check the face with a straight-edge and feeler gauge and reface if distorted more than 0.003 in. in any 6 in. (0.075 mm in any 150 mm).

As the maximum amount of metal that should be removed from the head face is 0.030 in. (0.76 mm) use Service Tools 960938 and 960940 (Fig. 16) to check how much metal can be removed. Insert depth gauge into injector bore, ensuring that both bore and gauge are clean, then check protrusion of depth gauge above head face with slip gauge. If face G of slip gauge beak fouls end of depth gauge the cylinder head face has been previously ground to the limit and no further grinding is permissible. If beak face G passes over the end of depth gauge the head face can be ground and the thickness of the feeler gauge which can be fitted between tip of depth gauge and face G is the maximum amount of metal that should be removed. (Fig. 17.)




Figure 17. CHECKING CYLINDER HEAD BEFORE REFACING

A. Depth gauge B. Slip gauge C. Cylinder head

If the head face is reground, care must be taken to obtain a smooth finish: use a fine stone with a slow feed.

Valve Grinding: If rectification of valves and seats has been carefully carried out only light regrounding will be necessary to obtain a good airtight seat.

Distorted valves, eccentric seats, irregular seats, excessive seat width, excessive refacing of valves and excessive valve stem clearance will all cause compression loss and result in shortened valve life.




Figure 18. CHECKING VALVE SPRINGS

- | | |
|---------------|---------------|
| A. New spring | B. Old spring |
| C. Spacer | D. Rule |

When all valves have been ground-in, wash the head and valves in kerosene until all traces of grinding compound has been removed, then dry with an air-line.

Valve Springs: If suitable equipment is available, check spring lengths when under load. If equipment is not available check springs by comparing their

tension with the tension of new springs. (Fig. 18.)

1. Select an average length spring from a set of new springs to use as a guide.
2. First compare free-length of new spring against old springs and discard any springs whose free-length is over $\frac{1}{8}$ in. (1.5 mm) shorter than the new spring.
3. Finally compare loaded length of springs by compressing the new spring and each old spring in turn, in series between vice jaws. For safety fit a short piece of bar, slightly smaller than inner diameter of springs, inside the springs and fit a short spacer between the spring ends. Compress springs between vice jaws until new spring is reduced to its loaded length (see data page) then measure length of old spring. If old spring is within $\frac{1}{8}$ in. (1.5 mm) of length of new spring it is satisfactory and can be refitted but any spring whose compressed length is more than $\frac{1}{8}$ in. (1.5 mm) shorter than new spring is weak and must be discarded.

Replace any weak, broken or corroded springs. If the engine has been run for a large number of hours it is advisable to replace the complete set of springs.

Valve Rockers: Remove rocker shaft assembly and place on bench. Unscrew brass plugs from ends of shaft and remove springs, rockers and shaft brackets, placing them in order on bench.




Figure 19. ROCKER SHAFT ASSEMBLY

- | | | |
|-----------------------|-----------------|------------------------|
| A. Rocker shaft | B. End plug | C. Rocker, left-hand |
| D. Rocker, right-hand | E. End spring | F. Intermediate spring |
| G. Centre spring | H. Rear bracket | |




Figure 20. CYLINDER HEAD AND VALVES

A. Exhaust valve	} Late type valve	E. Exhaust valve	} Early type valve	J. Inlet valve
B. Cotters		F. Cap—stem		K. Cotters
C. Collar		G. Cotters		L. Cup
D. Cup		H. Cup		M. Seal

● OPERATION B3d

Renew any rockers that are excessively worn on the tip. If rocker bushes are worn, these can be renewed. Press out worn bush and press new bush into position, ensuring that oil-holes are aligned. Hone or ream bush after fitting until rocker is free to slide on shaft.

Clean out the rocker shaft, ensuring that all the oilways are clear. Check that rocker bracket faces are completely flat where they seat on the cylinder head. Renew any brackets that are distorted or worn.

Assemble rockers, springs and brackets on shaft in same order as removed. Fit locating screw into rear bracket — oil-holes in shaft are towards bottom of brackets — then lock screw by peening bracket over screw-hole. (Fig. 19.)

Inlet Valve Seals: Having thoroughly cleaned the head and valves, fit new inlet valve stem seals. Ensure there are no burrs in the head chamfer and use Service Tool 961236, or a hollow drift. *Do not use a drift that touches the sharp edge of the seal.* Place seal on tool, smear seal with grease and place in recess, then drive seal home with two or three sharp taps with a copper hammer. Do not use undue force.

Do not fit seals until cylinder head is ready for assembling and do not withdraw a valve once it has

been fitted through a seal. Pulling a valve stem through a seal causes the cotter groove to trap and damage the sharp edge of the seal and it is therefore necessary to fit a new seal once a valve is removed.

Assembling Cylinder Head: Smear valve stems with clean oil and fit into their correct positions in cylinder head. Replace springs, collars and cotters, using a suitable tool to compress the valve springs.

Exhaust Valve Caps: If the exhaust valves are fitted with caps, check the stem-end clearance with a Plastigauge. The clearance should be 0.002 to 0.006 in. (0.05 to 0.15 mm) and can be reduced by grinding the cap, provided the cap edge remains square and the sharp corner is removed. (Fig. 20.)

Manifolds: Clean both manifolds, ensuring that the drain-hole and pipe in the exhaust manifold are clear.

Cylinder Block: If the bores are scored, or worn more than 0.010 in. (0.25 mm), they should be rebored to 0.020 in. or 0.040 in. oversize. To maintain balance, always rebore all four cylinders to the same oversize diameter.

Sealing Rings: The sealing rings at the top of the bores have 0.003 in. (0.08 mm) protrusion above the block and it is necessary to remove the rings to rebore the cylinders. New rings, with the appropriate oversize bore, should be fitted after reboring. Ensure the block recesses are clean, smear the rings with




Figure 21. CYLINDER BLOCK SEALING RINGS

A. Sealing ring B. Cylinder block face C. Protrusion

Wellseal, or similar non-hardening jointing compound, then push into place, taking care not to damage the ridge on the ring top edge. Wipe off all surplus jointing compound. (Fig. 21.)

● OPERATION C2

Pistons and Connecting Rods

Piston Removal: The pistons cannot be removed through the sump when crankshaft is in position but can be withdrawn upwards after removing cylinder head. Mark pistons before removal and remove all connecting rod bolts, otherwise bolt heads may score the bore. Connecting rod bolts are $\frac{7}{8}$ BSF thread and the nuts are $\frac{3}{32}$ in. across flats.

Pistons: The pistons fitted in 4/55 and 4/49 engines are the same diameter and use the same rings, but are not interchangeable due to their different heights: 4/55 pistons may be identified by the two scallops at the bottom of the skirt.

Pistons on engines with a high-lift camshaft have slightly deeper valve recesses and pistons with

shallower recesses must not be fitted to engines having a high-lift camshaft as the valve heads may foul the piston. High-lift camshafts are fitted to all 4/49 engines, and 4/55 engines from No. 4913, and when fitting new pistons to these engines ensure that only pistons with the larger, 1.58 in. (40.1 mm) diameter, valve recesses are used. (Fig. 22.)

When refitting pistons in cylinder block, space the ring gaps so that they are as far apart as possible and ensure that the piston is fitted with the *valve recesses* towards the camshaft side of cylinder block.




Figure 23. CHECKING PISTON RING GAP

● OPERATION C2b

Piston Rings: There are three compression rings and a scraper ring on each piston. The top compression ring is chromed and the second and third rings have an internal step and must be fitted with the word "Bottom" stamped on the ring towards the piston skirt.




Figure 22. IDENTIFICATION OF PISTONS

A. Early 1200 piston
D. 1.50 in. (38.1 mm) dia.

B. Later 1200 piston
E. 1.58 in. (40.1 mm) dia.

C. 990 Piston
F. 1.58 in. (40.1 mm) dia.

After removing carbon from the top, unworn part of the cylinder bore, place the rings in position and check the ring gaps (Fig. 23). New rings will be required if the gaps exceed 0.060 in. (1.52 mm). Excessive top ring wear may be attributed to the ingress of dusty air, due to lack of air cleaner maintenance, and excessive lower ring wear may be caused by dirty oil, due to infrequent oil and filter changes.

If the cylinder bores are worn, but not sufficiently for reboring, a set of oil control rings may be fitted. These sets, which are available for both standard and oversize bores, include spring-loaded steel scraper rings and special top rings, which have a shoulder at the top, so that they do not foul the ridge at the top of the bores. For further guidance on bore wear see Page 37.

● OPERATION C2c

Gudgeon Pins: The fully floating gudgeon pins are retained by a circlip at each end of pin. To remove pin from piston: mark connecting rod and piston, remove both circlips, then immerse piston in hot oil. This will expand piston and allow pin to be pushed out. Refit pin in same manner, using hot oil, and ensure circlips are fully seated in piston grooves.

● OPERATION C2d

Connecting Rods: The small end of connecting rod is bushed and this can be replaced if worn. Press out worn bush, using a suitable sized mandrel,




Figure 24. CONNECTING ROD ALIGNMENT GAUGE

and press in new bush, ensuring that oil-hole is opposite hole in end of rod. Hone, or ream, bush after fitting until gudgeon pin is a light push fit.

Connecting rods should always be checked for alignment whenever they are removed and especially if the piston skirt marking is uneven. The easiest way of checking alignment is by means of a proprietary aligning tool such as shown in Fig. 24, but if such a tool is not available mandrels and V-blocks may be used. Renew any rod that is out of alignment (see Page 38). Do not attempt to straighten a distorted connecting rod.

● OPERATION C4

Camshaft is fitted from front of cylinder block and retained in position by locating-plate behind camshaft gear. To remove camshaft it is necessary to remove valve rockers, push rods, lubricating oil and fuel feed pumps. Bolts attaching locating-plate to cylinder block are behind camshaft gear and are accessible through holes in gear. As the tappets will fall and jam against shaft journals when shaft is moved forward it is necessary to invert cylinder block, or if engine is *in situ* to hold tappets up with spring clips or by placing a $\frac{1}{2}$ in. (12.7 mm) diameter 'O' ring on each tappet.

Camshaft bearings are pressure fed from the oil gallery and the shaft journals run directly in cylinder block. Rear journal is drilled to supply a reduced flow of oil to valve rocker shaft.

High-lift camshaft, Part No. 921769, is fitted to all 4/49 engines and 4/55 engines from Serial No. 4913, and when fitting a new camshaft on 4/55 engines prior to this number ensure that an early type shaft — this may be identified by the part number (914673) cast between the two rear cam lobes — is fitted, otherwise the valve heads may foul the pistons.

Crankshaft and Bearings

The steel-backed crankshaft bearings are faced with a thin coating of soft anti-friction material. Early bearings were faced with different material (upper shells with white metal and lower shells with aluminium tin), but later upper shells are faced with aluminium tin and the same shell is used in both upper and lower positions. The later shells are interchangeable but must always be fitted in pairs. Do not fit early white metal upper shells in the lower position.

Once they have run against a journal, bearing shells are not interchangeable and if not renewed must be refitted against the original journal. Bearing caps and shells are very accurately machined and no attempt should be made to file a bearing cap or scrape a bearing. Connecting-rod caps must only be used with their original connecting rod, and main bearing caps must only be fitted to their original cylinder block.

Crankshaft Regrinding: If the crankshaft journals are scored, or worn, the shaft should be reground to 0.010, 0.020 or 0.030 in. undersize and appropriate undersize bearings fitted. Regrind centre




Figure 25. EXAMPLES OF REGROUND FILLET RADII

- | | | |
|-----------|---|--|
| Incorrect | { | A. No radius |
| | | B. Radius not smoothly blended |
| | | C. Radius too large |
| | | D. Radius too small |
| | | E. Radius too small |
| Correct | { | F. Radius roughly finished |
| | | G. Correct radius smoothly finished and correctly blended. |

journal thrust faces to 0.010 or 0.040 in. oversize (see Wear Limits Page 37).

When regrounding crankshaft it is important that the original bearing fillet radius is maintained. It is also important that the surface of the radius is as smooth as the surface of the journal, and the radius is smoothly blended into both surfaces. *A fillet that is incorrectly radiused, roughly finished or not smoothly blended, weakens a shaft and may cause fatigue failure during service.* (Fig. 25.)

Crankshaft Rear Oil Seal: The rear main bearing is sealed by an oil retainer bolted to the block and cap. The retainer is in two halves and the method of obtaining a seal was changed from an internal scroll in the retainer to split asbestos packings, which make positive contact with the crankshaft. The two retainers are interchangeable and when overhauling an engine the latest type retainer should be fitted.

Worn or damaged packings should be replaced. Remove the old packings and clean out the retainer grooves. Smear one of the packings with adhesive to prevent it turning during service, then press packings carefully into retainer grooves. Roll packings into position with a smooth bar then trim ends flush with retainer face and press corners into a chamfer, so that they will not spread out between retainer faces. Clamp retainer on to a 2.50 in. (63.5 mm) diameter mandrel (collar, Part No.




Figure 26. CRANKSHAFT REAR OIL SEAL

- Check that Allen screws have sufficient clearance to permit both halves to be in line.
- Ensure that ends of packings do not cause gap between halves of retainer.
- Check mounting face for distortion and if necessary correct by filing.

907503, can be used) to press packings into position and check that halves of retainer seat squarely together. (Fig. 26.)

Refitting Oil Seal: To ensure that there is no possibility of oil leakage between the two halves of the retainer, or between retainer and cylinder block, refit the retainer as follows:

- Polish crankshaft with worn 320 grade emery cloth to a highly polished finish.
- If gasket is in two halves (later gaskets are in one piece) trim each half so that edges will touch but not overlap. Smear retainer faces with a medium texture, non-hardening jointing compound. *Do not use a thick, hardening type of jointing compound and do not use gaskets thicker than standard.*
- Do not fit spring washers on socket screws and setscrews, but fit copper washers (Part No. 626850) and fit retainer in inverted position, i.e., socket screw heads towards top.
- Tighten bolts in the following order:
 - Tighten socket screws then unscrew half-a-turn.
 - Tighten setscrews firmly then firmly retighten socket screws.
 - Unscrew all four setscrews half-a-turn then retighten evenly and firmly.

Leakage from Point 2 Figure 1:

This is caused by the retainer not seating correctly on the cylinder block.

1. Check the retainer for the faults A, B, C and D shown in Figure 2.
2. If necessary use a smooth file with chalk on the cutting edge to make the surface of the retainer flat.
3. Check that the seat of the socket head screw is parallel to the joint face of the retainer. See fault D, Figure 2. If the seats are not parallel, the retainer will bend when the screws are tightened. If necessary use a file as in Operation 2 to make the faces parallel.

NOTE: The latest type of oil retainers do not have a locating lip. These can be made flat using a sheet of smooth emery cloth and a similar size piece of plate glass.




Figure 2. OIL RETAINER FAULTS

Leakage from Points 3 and 4, Figure 1:

This is caused by the following faults:

The two parts of the retainer are not parallel. See Figure 3.

Loose ends of the packings are between the faces. See Figure 4.

1. Remove the retainer from the cylinder block.
2. Remove the socket screws, separate the two parts and remove the packings.
3. Put the two parts of the retainer together. Install and tighten the socket screws.
4. Hold the retainer up to a good light and look at the joint faces.
5. If this check shows a gap between the joint faces, use a file as before to make the faces flat.
6. Put the two parts together. Install and tighten the socket screws.
7. IMPORTANT: Check the face of the retainer that is fastened to the cylinder block.
8. If necessary, use a smooth file to make this face flat.




Figure 3. JOINT FACE FAULT




Figure 4. PACKING FAULT

A Correct B Wrong

Leakage from point 4. Figure 1:

This is caused by the ends of the packings not in correct contact and oil flowing through the gap.

1. Install new packings. See the Assembly Procedure.

Leakage from Point 5. Figure 1:

This is caused by the packings not sealing correctly on the crankshaft. Check the following:

1. Wear or damage to packings.
2. A restriction in the engine breather.

NOTE: On turbocharged engines there must be a hole in the breather body as shown in Figure 5.

3. Wear in piston rings which causes too much pressure in the crankcase.
4. Too much end movement on the crankshaft.
5. Wear on the main bearings.

Leakage from Point 6. Figure 1:

This is caused by oil flowing through the bolt threads.

1. Replace the spring washers with rolled copper washers, Part No. K15489.

Assembly Procedure

1. Clean the two parts of the oil retainer, remove the packings and clean the packing grooves. Make sure that all the old jointing material is removed.
2. Hold the top part of the oil retainer, packing groove up, in a vice that has soft jaws.
3. Put a small amount of Evostik impact adhesive in the bottom of the packing groove. This will keep the packing in its correct position when the engine is started.
4. Put a packing on the retainer and then push it into the groove with the smooth handle of a screwdriver. Push the handle down on the centre of the packing and slide the handle from the centre to each end of the packing. **DO NOT** roll the handle when pushing the packing into the groove. See Figure 6.

5. Use a screwdriver blade that is not sharp to push the ends of the packing below the joint face of the retainer. See Figure 7.

IMPORTANT: **DO NOT** cut the ends of the packings. These are made to the correct length and the seal will fail if the length is decreased.




Figure 5. BREATHER HOLE POSITION

A Breather Hole

R79 46




Figure 6. INSTALLING PACKING

R79 47




Figure 7. INSTALLING PACKING

R79 48

6. Remove any loose fibres with a very sharp knife. See Figure 8.
7. Use the same method to install the packing in the bottom part of the retainer, BUT DO NOT use adhesive in the groove.
8. Put the two parts of the oil retainer around a smooth piece of shaft that has been machined to the following dimensions:
 Turbo-charged engines 66.50 mm (2.620 in)
 Other models 63.50 mm (2.500 in)
9. Install and tighten the socket screws. This will push the packings into the correct contact with the packing grooves and the correct diameter for installing in the crankshaft. See Figure 9.
10. Remove the socket screws. Carefully remove the two parts of the retainer from the shaft.
11. Check that the packings are seated correctly. If for any reason the seating is not correct, the retainer must be discarded and a new oil retainer assembly installed.

Before Installing the Oil Retainer:

1. Use worn 320 grade emery tape to remove any marks from the part of the crankshaft which is in contact with the packings.
2. Clean the face of the cylinder block. Use cleaning fluid if necessary and make sure that any old jointing material is removed.

Installing the Oil Retainer:

Method A: Using gaskets:

1. Put a small amount of Evostik impact adhesive on the retainer faces which fit against the cylinder block.
 Put the gaskets in position on the retainer.
 Use a sharp knife to cut the ends of the gaskets level with the ends of the retainer faces.
 2. Put an even layer of Wellseal joint compound on the face of the cylinder block.
- IMPORTANT:** Do not use a thick type of joint material as this will cause the retainer to bend when the bolts are tightened.
3. Put a thin strip of Loctite Superfast Flange Sealant 573, Part No. K965910 on each side of one part of the retainer.
 See Figure 10.
 4. Replace the spring washers on the hexagon head bolts with copper washers. Part No. K15489.
 5. Put a small amount of engine oil on the packings. Put the two parts of the retainer in position on the crankshaft and install the socket screws finger tight.
 Install the hexagon head bolts.




Figure 8. CUTTING PACKING

A Correct B Wrong

R79 49




Figure 9. RETAINER ON SHAFT

R79 50




Figure 10. POSITION OF SEALANT

A Loctite Superfast Flange Sealant 573

R79 51

6. Tighten the bolts and socket screws in the following sequence.
 - i. Tighten the socket screws evenly, then loosen both socket screws one half turn.
 - ii. Tighten the hexagon head bolts.
 - iii. Tighten the socket screws.
 - iv. Loosen the hexagon head bolts one half turn. Wait for 30 seconds, then tighten the hexagon head bolts.

Do this procedure to make sure that there are no gaps between the two parts of the retainer and between the face of the retainer and cylinder block.

Method B: Not using gaskets:

NOTE: When Loctite Superfast Gasket Eliminator 504, Part No. K965909 is used instead of gaskets, all oil must be removed from the joint surfaces. Make sure there is no oil in bolt or drain holes which can get on to the joint surfaces before the seal material has become hard.

The strength and gap filling characteristics of this seal material will be increased if the joint surfaces are sprayed with Loctite Superclean Safety Solvent before the seal material is applied.

1. Put a thin strip of Loctite Superfast Flange Sealant 573 on each side of one part of the retainer. See Figure 10.
2. Put a thin strip of Loctite Superfast Gasket Eliminator 504 on the face of the retainer. See Figure 11.

Then follow the same procedure as in Method A, Operations 4, 5 and 6.

NOTE: On later engines, the oil retainer is made without a lip. An extra hole is drilled at the bottom of the retainer as shown in Figure 5.

Oil retainer assembly, Part No. K964994 is available for earlier engines. This oil retainer has no lip but only four holes. When installing, use copper washers instead of spring washers on the bolts.




Figure 11. POSITION OF GASKET ELIMINATOR

A Loctite Superfast Gasket Eliminator 504

FUEL SYSTEM

The performance of a diesel engine depends very largely on the fuel system and the most important factor in trouble-free operations is *cleanliness of the fuel*. Dirt and dust — particularly the very fine dust readily carried in the air and in suspension in the fuel tank — can cause rapid and extensive damage to the injection pump and injectors, resulting in bad starting, loss of power and expensive repairs.

The importance of clean fuel storage and the precautions to be taken to prevent fuel contamination when refuelling must be impressed on the operator.

Care should also be exercised in the workshop. The bench used for servicing fuel injection equipment should be situated in a well-lit and separate part of the workshop. If possible an insulated and dust-proof room should be provided in which the servicing equipment can be permanently installed.

Special equipment is required and the minimum essentials consist of the following: Two safety containers — one filled with petrol for soaking dirty nozzles and the other filled with test oil, or clean diesel fuel, for assembly of cleaned components. A nozzle bench plate, which should be screwed to the bench with the jig end overhanging, so that an injector can be slackened or tightened. A nozzle setting outfit should also be securely bolted to the bench with a suitable canister to collect the spray and protect the operator against accidental contact with the spray. The flushing device used in conjunction

with the setting outfit is essential. The nozzle cleaning kit (Fig. 27) includes a probing tool but not needles: correct diameter needles can be obtained separately as required.

Although the above items are an essential minimum for injector servicing, more complex apparatus or additional equipment are available where the volume of work makes their purchase worthwhile.




Figure 28. INJECTOR REMOVAL

● OPERATION D1

Injector removal:

1. Wipe injectors and adjacent areas.
2. Disconnect and remove leak-off pipe (Fig. 28.)
3. Disconnect high-pressure pipe unions from injectors.
4. Remove nuts holding down injectors evenly, to prevent distortion.
5. Withdraw injectors carefully. Seal inlet with cap and fit a protection sleeve on nozzle end.
6. Clean injector bores in head and remove copper sealing washers. Plug bores with clean rag to prevent dirt entering cylinders.

It is essential that the copper washer be used under injector when refitting to engine. Check that the seat in head is clean and that the old washer has not been left in the recess. The use of two washers will raise nozzle tip so that the spray impinges on cylinder head. This causes a loss of efficiency and excessive exhaust smoke.

Injector Servicing

Nozzle Testing: The hand tester shown in Fig. 29 is adequate for testing and pressure setting injectors.

Attach injector to tester and place a canister round the nozzle to ensure that spray does not




Figure 27. C.A.V. NOZZLE CLEANING KIT

- | | |
|--------------------------------|-------------------------------|
| A. Brass wire brush | B. Nozzle body groove scraper |
| C. Nozzle plunger cleaner | D. Nozzle body seat scraper |
| E. Holder—probing needle | F. *Pintle hole cleaner |
| G. *Probes—pintle hole cleaner | |

*Not required for D.B. Nozzles.




Figure 29. INJECTOR NOZZLE TESTER

- | | |
|------------------------|-------------------|
| A. Pump handle | B. Reservoir |
| C. Injector connection | D. Pressure gauge |

contact the body. The force of the spray is such that it will easily penetrate the skin, even through clothing. The resultant oil under the skin is very difficult to treat and can be a very uncomfortable wound. The canister will also help to condense the very fine spray which forms an objectionable atmosphere. If regular nozzle testing is contemplated a totally enclosed test chamber with exhaustor is advocated.

● OPERATION D1a

Pressure Test: With injector mounted in the test outfit, depress hand lever several times to fill injector and expel any air. Depress lever very slowly and observe highest pressure reading that is obtained before needle on pressure gauge flicks. This is the pressure at which injection takes place. The correct pressure for new injectors is 185 atmospheres (188 kg/cm²), and for used injectors 175 (180 kg/cm²) atmospheres.

If pressure is incorrect but nozzle is clean and otherwise satisfactory, it should be set to correct figure as follows: Remove dome cap and slacken locknut, and using a large screwdriver in pressure adjusting screw adjust the screw. Only a very small movement will be required unless the nozzle has only just been assembled and the pressure not previously set. When screw has been adjusted, tighten locknut and recheck pressure. (Fig. 30)

Back Leakage Test: Operate hand pump until pressure is about 170 atmospheres. Release the handle quickly and measure, with a stop-watch, the time taken between pressure gauge pointer passing the marks for 150 and 100 atmospheres (154 and 104 kg/cm²) as it gradually falls. For a satisfactory nozzle the time taken should be between 6 and 25 seconds.

Dry Seat Test: Carefully wipe nozzle dry. Build up pressure to 10 atmospheres below the injection

pressure. Examine nozzle whilst under this pressure. It should be dry and free from leakage. If the nozzle is inadvertently caused to inject, the tip should be re-wiped dry and tested again.

Examine injector for signs of leakage at nozzle cap nut, spring adjusting nut, and copper sealing washers.

Atomisation Test: Isolate pressure gauge by closing valve. Apply eight quick jerks and examine the spray quality. The sprays should be free from coarse or solid streaks and the tip should remain dry. There should be four sprays equally spaced at an inclusive angle of 140°. They are offset 10° to allow for the tilt of the injector in the cylinder head.

● OPERATION D1b

Nozzle Cleaning: If injector fails to pass any of the above tests it must be dismantled, cleaned and retested. Note that spring pressure must be released before removing nozzle. Unscrew nozzle cap, using a close-fitting spanner on the flats provided, and




Figure 30. SECTIONED INJECTOR

- | | | |
|------------------------|---------------|--------------------------|
| A. Leak-off connection | B. Cap | C. Adjusting screw |
| D. Locknut | E. Spring | F. Fuel inlet connection |
| G. Holder | H. Plunger | J. Needle |
| K. Nozzle | L. Nozzle nut | |




Figure 31. EXPLODED VIEW OF INJECTOR

- | | | | |
|-----------|-------------------|---------------|--------------------------|
| A. Cap | B. Sealing washer | C. Locknut | D. Adjusting screw |
| E. Spring | F. Plunger | G. Holder | H. Fuel inlet connection |
| | J. Nozzle | K. Nozzle nut | |

remove nozzle, noting that it will only fit in one position because of the locating dowels. Remove needle valve and place in petrol to soften carbon. Examine nozzle and needle for damage, overheating or scratch marks on the lapped working surfaces. If excessive overheating has occurred, denoted by a dark blue colour of the needle, or if seat or working surfaces are damaged, reconditioning will be required and a new nozzle should be fitted.

If the nozzle is not damaged it should be cleaned using the special tools provided in the nozzle cleaning kit shown in Fig. 27. Firstly clean fuel oil channels and bores in nozzle. Scrape carbon from valve seat with the brass scraper.

Using the special groove scraper, clear carbon deposits from oil gallery. Clean spray holes with probing tool fitted with a probing wire of the correct diameter.

Great care should be exercised when using the probing wires. If a wire is broken off in the hole it is often impossible to remove it, and the nozzle is then useless. After clearing the holes scrape carbon from valve seat with the V-tipped brass tool. Next use the tool with the thin blade radiused at its tip to clean carbon out of the sac. After cleaning with the tools, the nozzle should be thoroughly cleaned with fuel. This should be done by placing nozzle, without needle, in the reverse flushing attachment and connecting to pressure tester in place of an injector. Operation of the tester will then thoroughly flush all particles of loose carbon from the nozzle.

With the brass wire brush, gently clean needle valve, paying particular attention to valve seat and needle tip. Brush carbon from nozzle stem and tip.

Reassembly: The needle valve should be fitted to nozzle whilst both are under the surface of clean fuel oil or test oil. Only in this way can dust be excluded from assembly. The needle should slide smoothly in the nozzle and this should be tried several times whilst under the surface of fluid. Needle and nozzle are assembled as a pair and under no account should they be interchanged.

The nozzle should then be assembled on to injector body. In order to avoid distorting needle or plunger the spring should be released. Remove dome cap, slacken locknut and slacken pressure adjusting screw right back until there is no pressure on spring. Make sure that mating surfaces between nozzle and injector body are perfectly clean. Place nozzle on body with the dowels in correct engagement so that the two faces are in perfect contact, i.e., not held apart by spring pressure. Place cap over nozzle and tighten adequately but not overtight. Retighten pressure adjusting screw and reset the pressure on spray tester. Test the spray, leak back, etc. If the injector is not required for immediate use




Figure 32. FUEL FEED PUMP

- | | | |
|----------------|-----------------------|--------------------|
| A. Diaphragm | B. Diaphragm pull-rod | C. Connecting link |
| D. Spring | E. Body | F. Outlet valve |
| G. Inlet valve | H. Filter screen | J. Sediment bowl |
| | K. Hand primer | |




Figure 33. FITTING FEED PUMP DIAPHRAGM

With the diaphragm tab at position A, fit diaphragm on to pump body until pull rod enters link slot, then turn diaphragm 90°, so that tab moves to position 'B' to lock pull-rod in link slot.

it should be stored in a sealed plastic bag or similar container. (Fig. 31.)

Fuel Feed Pump: The fuel feed pump is mounted on right-hand side of engine crankcase and actuated by a short push-rod from an eccentric on the camshaft.

● OPERATION D2

To remove feed pump, first disconnect fuel pipe union at fuel tank end of pipe, so that fuel will not siphon out of tank when pump end of pipe is disconnected. Disconnect both pipes from pump

and remove the two bolts attaching pump to cylinder block. When the pump has been removed, the push-rod may be withdrawn from cylinder block.

● OPERATION D2a

Renewing Diaphragm: Clean exterior of pump and mark top and bottom halves so that they can be replaced in the same position. Remove the six screws attaching upper half of pump to base then remove the upper half. (Fig. 32.)

Remove diaphragm complete with pull-rod by turning diaphragm through 90°, which should release pull-rod from connecting link.

Clean both halves of the pump. Position new diaphragm with tab at position shown in Fig. 33. Press centre of diaphragm down against spring until the 'T' end of pull-rod enters slot in connecting link, then turn diaphragm through 90° so that pull-rod and connecting link are locked together. Refit upper half, ensuring that assembly marks are aligned, and replace screws. Hold the priming lever depressed whilst tightening the six retaining screws so that the diaphragm is not taut.

Fuel Filter: The double fuel filter has two paper elements connected in series so that all fuel must pass through both filters. The element in the first filter should be renewed every 500 hours and the second filter element renewed every 1000 hours. Do not change elements from one filter to another and do not attempt to clean an element: always discard the dirty element and fit a new one. (Fig. 34.)

● OPERATION D3

To Fit a New Filter Element: Clean outside of filter then remove bolt securing base of first filter




Figure 34. FUEL FILTER

- A. Element—first filter
- B. Element—second filter
- C. Bowl
- D. Retaining bolt
- E. Sealing ring—outer
- F. Sealing ring—inner




Figure 35.

FUEL SYSTEM — 1200 TRACTORS

- A. Outlet union—feed pump
- B. Hand primer
- C. Vent plug—filters
- D. Vent plug—injection pump
- E. Vent plug—injection pump
- F. Unions—injectors
- G. Injectors

to filter head whilst holding base and element with other hand. Remove base, discard element and sealing rings (new rings are supplied with element). Flush out base and fit new element, ensuring that it seats correctly on sealing rings in base and head. Fit new washer on retaining bolt. Replace bolt and tighten firmly but not excessively.


● OPERATION D4

Venting the Fuel System: It is essential that no air is trapped in the fuel system and if engine fails to start, or if the system has been disturbed, vent system as follows:

Figure 36.

FUEL SYSTEM — 990 TRACTORS

- A. Vent plug—filter
- B. Union—filter inlet
- C. Hand primer
- D. Union—injection pump inlet
- E. Vent plug—injection pump
- F. Vent plug—injection pump
- G. Union—injector






Figure 37. FUEL INJECTION PUMP — 1200 TRACTORS

- | | |
|-----------------------|-----------------------|
| A. Throttle lever | B. Maximum speed stop |
| C. Idling speed stop | D. Stop control |
| E. Excess fuel device | F. Drain plug |
| G. Level plug | H. Filler plug |

1200 Tractors — Figure 35

1. Ensure there is a minimum of 2 gallons (9 litres) of fuel in tank.
2. Check that sediment bowl is clear of water and sediment. Remove and clean bowl if necessary. (Page 1.)
3. Clean outside of filters and venting points.
4. Release fuel-feed-pump outlet union A. Operate hand priming lever B until glass bowl is full of fuel and no air bubbles are passing through, then tighten union.
5. Unscrew vent plug C on top of fuel filter. Operate hand primer until air-free fuel issues then tighten plug.
6. Release both injection-pump vent screws D and E. Operate hand primer until air-free fuel is expelled then tighten both plugs.
7. Unscrew high-pressure unions F on injectors. Open throttle, place engine stop control in "run" position and turn engine with starter motor until air-free fuel is ejected.
8. Tighten injector unions. Start engine and check that there are no fuel leaks.

990 Tractors — Figure 36

1. Ensure that there is not less than 2 gallons (9 litres) of fuel in tank.
2. Check that sediment bowl is free of water and sediment. Remove and clean bowl if necessary.
3. Clean outside of filters and venting points.
4. Remove vent plug A from filter and release pipe union B. Operate hand priming lever C until air-free fuel appears at union then

tighten. Continue pumping until air-free fuel issues from filter then replace and tighten plug.

5. Unscrew injection-pump inlet union D and operate hand primer until air-free fuel appears then tighten union.
6. Release vent plug E on injection pump. Operate priming lever until air-free fuel is discharged then tighten plug. Release plug F and continue pumping until fuel appears at the plug then retighten plug.
7. Unscrew high-pressure unions G on injectors. Open throttle, place engine stop control in "run" position and turn engine with starter motor until air-free fuel is ejected.

If difficulty is experienced in obtaining air-free fuel from injector unions this is probably due to pressurising valves inside banjo bolts at pump end of pipes. Remove one banjo bolt, replace this with a standard banjo bolt and continue venting system. Refit original banjo bolt after engine has been running.

8. Tighten injector unions. Start engine and check that there are no fuel leaks.

Injection Pump

The injection pump is attached by three studs on the engine carrier plate, and the pump mounting holes are slotted to permit pump body to be turned for injection timing adjustment. To assist in obtaining the correct timing position the pump flange is marked with a groove and when the timing is set during assembly a mark is made on the carrier flange in line with the mark on pump. Any pump can thus be fitted and the original timing obtained by placing the two marks in alignment.

The pump is driven from the camshaft by means of an intermediate gear and correct timing of the injection pump can only be obtained if all the timing gears are meshed correctly. (Fig. 53.)

Injection Pump Controls: The pump is fitted with a throttle control, which determines the maximum and minimum engine speed, and a stop control, which stops the engine by cutting off the fuel supply to the injectors.

On 1200 Tractors (Fig. 37) the throttle control lever is on the left-hand side of pump. To set the engine speeds, disconnect linkage from lever and, whilst holding lever forward against lower stop, adjust screw so that engine idles at 600–650 rev/min then lock screw with locknut. Hold lever against rear stop and set this so that maximum no-load engine speed is 2450–2475 rev/min, then tighten locknut. Connect throttle linkage; check that when hand throttle lever is fully closed, pump lever is touching lower stop, and when hand lever is fully open pump lever is against upper stop. The engine stop control is connected to the pump lever by a flexible cable. The cable should be adjusted so that when the pump lever is fully forward, and the control knob is in the "stop" position, there is $\frac{1}{8}$ in. (3 mm) slack in the cable.




Figure 38. FUEL INJECTION PUMP — 990 TRACTORS

- | | |
|-------------------|-------------------------|
| A. Throttle lever | B. Maximum speed stop |
| C. Stop control | D. Manual retard device |

On 990 Tractors (Fig. 38) the rear lever is the engine throttle. To set the engine speeds, disconnect lever from control rod and adjust so that engine idles at 600-650 rev/min, then hold lever against rear stop and set this so that maximum speed is 2325-2350 rev/min. The lever towards the front of the pump is the stop lever and the connecting rod should be set so that when the stop control handle is in the "stop" position the pump lever is fully forward and touching projection on pump case.

Cold Weather Starting: The pump incorporates a cold-starting device. On 1200 Tractors there is an excess-fuel button (Fig. 37) in the centre of the fuel cut-off shaft. When this is depressed the pump delivers additional fuel until the engine starts and it is then automatically reset.

On 990 Tractors the cold-starting device is a wing-nut on the underside of the pump (Fig. 38). When the wing-nut is screwed "in", the automatic advance mechanism is inoperative and the pump is held retarded to assist starting. As soon as the engine is running the wing-nut must be screwed "out", otherwise erratic running with black exhaust smoke will occur. Do not screw wing-nut in immediately after an unsuccessful attempt to start the engine but wait 10 to 15 seconds, otherwise pressure inside pump may not have fallen and screwing wing-nut "in" will then hold pump in advanced position and make starting more difficult.

Ether Plug: When starting in sub-zero temperatures, unscrew ether plug from inlet manifold, dip felt pad in ether, or a proprietary starting fluid, replace plug and start engine immediately.

WARNING: Serious damage can be caused to an engine by using an excessive amount of ether. The plug should be removed, the pad soaked in ether and then replaced. *Ether in excess of the quantity absorbed by the felt must not be added.*

Thermostart: This is available on tractors which operate in very cold climates and consists of an igniter unit screwed into the inlet manifold and fed by fuel from the engine leak-off pipe.

To Start an Engine Fitted with a Thermostart:

1. Place engine stop control in "run" position and hand-throttle lever "fully open".
2. Depress excess fuel button (1200) or screw manual retard device "inwards".
3. Turn starter switch key 60° clockwise and hold in this position for 10-15 seconds (this will supply current to heat the unit sufficiently to vaporise fuel).
4. Depress clutch pedal and turn switch key a further 30° clockwise (this will continue supplying current to the unit and also operate starter motor; air drawn through manifold will then mix with vaporised fuel and be ignited, to fill engine cylinders with warm air).
5. If engine does not start after fifteen seconds, return key to "heat" position for five seconds then re-engage starter.
6. As soon as engine starts, release key and allow it to return to "run" position (30° clockwise from "off" position).
7. When starting a warm engine, turn key 90° clockwise to operate starter in normal way.




Figure 39. ENGINE TIMING APERTURE

● OPERATION D8

Injection Pump Removal: The pump is attached to engine carrier plate and in order to remove pump it is necessary to first release drive gear from pump shaft. If engine timing cover does not incorporate an access plate it is necessary to remove the complete timing cover (see Page 31).

1. Remove valve rocker cover, turn engine until No. 1 inlet valve closes and insert timing pointer into SP hole (Fig. 39) and continue turning engine until pointer drops into flywheel indentation. Place tractor in gear, to prevent engine being turned whilst pump is removed

2. Drain cooling system and remove bottom radiator hose. Disconnect controls and fuel pipes from pump.
3. Remove access plate from timing cover, unless timing cover has already been removed because it does not have a plate. Clean and mark idler gear and pump gear with a felt-tipped pen, or pencil.
4. **1200 Tractors:** Unlock tabwasher and remove nut from injection pump shaft. Using a short extractor—this must not be longer than $3\frac{1}{2}$ in. (89 mm)—engaged in the holes in gear, release gear from shaft taper, then remove extractor. A three-legged extractor is required for 12 DP gears and a two-legged extractor for 8 DP gears.
5. **990 Tractors:** Unlock tabwasher and remove the three bolts attaching gear to pump. The gear is not a tight fit on pump shaft and will remain in case when pump is removed.
6. Check that marks on pump flange and carrier plate are aligned, or scribe a line across flange and plate. Remove nuts attaching pump to carrier plate then withdraw pump and allow gear to remain in timing case.

Pump Replacement: First check that pump gear has not been moved, by noting that the mark across intermediate and pump gear teeth has not been disturbed, then note position of gear hub and set pump shaft in the same relative position. On 1200 Tractors the key in pump shaft should be at approximately 2 o'clock position and on 990 Tractor pumps the slot in pump shaft should be at approximately 4 o'clock position. Fit the pump in position, ensuring that the key or dowel is correctly engaged. Fit a new tabwasher and replace shaft nut or bolts. Align pump and carrier plate marks before bolting pump in position, then tighten nut (1200) to 45 lb ft (6.22 kg metres) and bolts (990) to 20 lb ft (2.76 kg metres) before locking with tabwasher. Replace access plate, or timing cover (see Page 31), connect pump controls and fuel pipes. If pump has been reconditioned, or a new pump is being fitted, replace elements in both fuel filters before venting fuel system.

On 1200 Tractors the pump cambox must be filled with clean engine oil to the level plug shown in Fig. 37.

Replace valve rocker cover and bottom hose, refit cooling system.

Pump Timing: If the timing-mark on pump flange becomes obliterated, or if new components are fitted in pump, the pump flange should be re-marked as follows:

1200 Pump: With the pump mounted on the test machine and pump fuel inlet connected to test tank, remove No. 1 (front) valve holder. Remove delivery valve, volume reducer and spring, then replace holder and fit a swan-necked spill pipe—this can be made from a scrap injector pipe. Turn the fuel "on", so that it flows by gravity into pump and slowly turn pump shaft until fuel commences to drip out of pipe. Allow fuel to drip out of pipe until




Figure 40. INJECTION PUMP TIMING — 1200

Timing mark on periphery of pump flange to be 11° anti-clockwise from centre line of shaft keyway when inlet port is closing on No. 1 element.

there are no air bubbles, then very slowly turn pump in direction of rotation (clockwise when looking at drive end) until fuel ceases to drip from pipe; this is the point at which the plunger has risen to commence injection and is therefore SP point on No. 1 cylinder. With the pump camshaft in this position, measure 11° from centre-line of shaft keyway then mark pump flange (Fig. 40). Ensure that pump mark is quite clear and cannot be confused with any previous mark then remove pipe and holder, replace delivery valve, spring and volume reducer. Tighten valve holder to 30 lb ft (4.15 kg metres) and fit locking clamp.

990 Pump: Attach stirrup pipe, CAV tool 7144/262 to Nos. 1 and 4 injector pipe connections and connect other end of pipe to an injector tester. Set pump so that the shaft slot is towards the top of pump then operate tester handle to build up a pressure of 30 atmospheres. Fit CAV service tool 7144/112U on to the pump shaft and slowly turn pump shaft in the direction of rotation (clockwise when looking at drive end) until pump becomes rigid. This is the point at which injection commences and is therefore SP point on No. 1 cylinder. With the pump in this position, use the tool disc to measure 66° past the centre line of the shaft slot and mark the pump flange (Fig. 41). Ensure that the flange mark is quite clear and cannot be confused with any previous mark, then remove stirrup pipe and marking disc.

Checking Engine Spill Timing: If it is necessary to check the timing of the injection pump to the engine this can be carried out as follows:




Figure 41. INJECTION PUMP TIMING — 990

Timing mark on pump flange to be 66° anti-clockwise from rotor slot when pump is at point of injection on No. 1 cylinder.

1200 Tractors: Remove No. 1 (front) valve holder. Extract delivery valve, volume reducer and spring, then replace holder and fit a swan-necked spill pipe — this can be made from a scrap injector pipe. (Fig. 42.)

Place engine stop control in "run" position and whilst operating feed pump priming lever turn engine in direction of rotation: if injector nuts are released and injectors are raised slightly, to release compression, engine can be turned with the fan. Grind a blunt point on the end of a short piece of $\frac{3}{16}$ in. (8 mm) rod and insert this into the hole marked "SP" on left-hand side of clutch housing. (Fig. 39.) Whilst an assistant is slowly turning the engine and operating the priming lever, rest a finger against the rod and observe the fuel dripping out of the pipe. The point at which injection commences will be reached when fuel ceases to drip out of pipe and this should coincide with the rod dropping into flywheel indentation. If the fuel flow ceases before, or after, the rod is felt to fall into the flywheel indentation, release pump mounting nuts and turn the pump body slightly — direction of engine rotation to retard and opposite to engine rotation to advance. Fully tighten mounting nuts then recheck timing.

When timing is correct, remove spill pipe, replace delivery valve, volume reducer and spring, then replace valve holder and injection pipe.

990 Tractors: Make a capillary tube as shown in Fig. 43 and attach this to the injection pump in place of No. 1 injector pipe. With engine stop control in "run" position, turn engine slowly until fuel rises




Figure 42. TIMING 1200 INJECTION PUMP

A. No. 1 injector pipe connection B. Swan-necked pipe

midway up the capillary tube. Place the engine stop control in the "stop" position and continue turning engine. As the ports in the rotor head line up ready for injection the pressure of air trapped in the blanked off portion of the tube will force fuel out of the capillary tube to charge the plungers. Turn engine slowly from this point and watch fuel level in capillary tube; level will fall as plungers are charged




Figure 43. TIMING 990 INJECTION PUMP

A. No. 1 injector pipe connection B. Sawn-off injector pipe
C. Plastic sleeve D. Glass capillary tube
E. Plastic tube F. Plug

but as soon as plungers move inwards, to commence injection, the fuel level will start to rise. The fuel level should therefore start to rise when the engine reaches spill point.

Grind a blunt point on a short piece of $\frac{5}{16}$ in. (8 mm) diameter rod and insert this into the hole marked "SP" on left-hand side clutch housing. (Fig. 39.) Whilst an assistant is slowly turning engine, rest a finger against end of rod and watch fuel level in capillary tube. Initially set the pump so that fuel level in tube commences to fall at the same time as pointer is felt to fall into flywheel indentation, then measure $\frac{1}{8}$ in. (3 mm) anti-clockwise from pump flange timing-line and scribe a line on engine carrier plate. Check that scribed line is quite clear, in the correct direction and the correct distance from pump mark, then release the mounting bolts and turn pump body to align pump and carrier plate marks. Retighten mounting bolts and refit injector pipes.

If the pump is not advanced as described but is set to "SP" mark on flywheel the spill timing will be set to 11° B.T.D.C., which would be correct for a 4/47 engine but is 6° retarded for 4/49 engines. As 4/49 engines have the same flywheel as 4/47 engines it is necessary to advance the pump 6° — which is equivalent to $\frac{1}{8}$ in. (3 mm) on pump flange — in order to obtain the correct spill timing of 17° B.T.D.C.

Injection Pump Fuel Setting: Once the fuel delivery has been set on a pump it is most unlikely that it will require subsequent readjustment. If incorrect setting is suspected, do not attempt to reset the pump on the engine but remove pump and check fuel delivery on a Hartridge Test Bench. For details of delivery settings see Page 39.

● OPERATION D9

Fuel Tank Removal: The easiest way of removing the fuel tank is to remove the tank complete with instrument panel and then separate tank from panel.

First drain tank by unscrewing union at pump end of pipe and then allowing fuel to siphon into a *clean* container. Do not release union at tank end of pipe as this will allow air into pipe and prevent fuel siphoning out of tank. Disconnect engine-speed-indicator drive cable and wiring to panel. Some of the wires are fitted with snap connectors, but others, such as oil warning switch wire, will have to be disconnected at their terminals.

Remove tank mounting bolts and disconnect engine stop control. Disconnect fuel outlet and fuel leak-off pipes from tank then remove tank and panel.

Replace tank in reverse order of removal, ensuring that seating pads are in position and wires are replaced in their correct connections.

LUBRICATION SYSTEM




Figure 44. LUBRICATION SYSTEM

- | | | | |
|----------------|---------------------------|--------------------------|-------------------------|
| A. Inlet gauze | B. Oil pump | C. Filter | D. Warning light switch |
| E. Oil gallery | F. Crankshaft oil passage | G. Camshaft rear bearing | |
| | H. Valve rocker shaft | | |

Engine Lubrication

Oil is drawn from the sump by the gear-driven rotary oil pump and delivered under pressure to the oil filter. After filtration the oil passes to the main oil gallery in the cylinder block and so, via oilways in the block webs, to the crankshaft main journals and then on, through further oilways in the cylinder block, to pressure lubricate the camshaft bearings. The big-end bearings are lubricated by drillings in the crankshaft webs.

The rocker shaft and valve rockers are intermittently fed with oil from the camshaft rear bearing through oilways in block and head and an external connecting pipe. The camshaft is drilled off-centre so that the oilways are connected only once in each revolution. (Fig. 44.) The oil lubricates the tappets and push rods as it returns to the sump.

The intermediate gear is pressure fed via its hollow shaft and an oil-way in the cylinder block. Surplus

oil in the timing cover forms an oil bath which splash lubricates the timing gears.

A full-flow oil filter is mounted on the left-hand side of the cylinder block. The filter incorporates a by-pass valve so that if the pressure difference between the filter inlet and outlet exceeds 10 lb/sq in. the valve opens and allows oil to by-pass the element and flow straight into the oil gallery. The engine is not, therefore, starved of oil if the element is allowed to become choked, but it is supplied with unfiltered oil. The replaceable paper element should be renewed at the intervals specified on Page 2. A new element should also be fitted when an engine is overhauled and also if a cylinder head gasket fails. If engine oil and filter element are not changed when a failed cylinder head gasket is replaced, any water which has leaked into sump will cause the paper filter element to swell and fail to pass oil. (Fig. 45.)

Do not attempt to clean a filter element.




Figure 45. SECTION THROUGH OIL FILTER

- | | | |
|--------------------------|---------|------------------|
| A. Oil feed from pump | B. Bowl | C. Element |
| D. Outlet to oil gallery | E. Plug | F. By-pass valve |

● OPERATION E1

Engine Oil Filter: Drain oil, whilst engine is warm, and remove filter bowl. Discard oil filter element and clean bowl with diesel fuel, using a brush to ensure that by-pass valve is very clean. Remove sealing ring from groove on cylinder block and fit new ring supplied with element. Carefully fit new ring into block groove, ensuring that it is not twisted or distorted and fits neatly all way round groove. Fit new element into bowl and replace bowl. Do not overtighten bowl securing bolt: a tightening torque of 10 lb ft (1.4 kg metres) is sufficient.

Refill sump with new oil, start engine to fill filter and check that it is oil-tight, then recheck oil level.

Oil Pump

The gear type oil pump is located in the engine sump and contains a relief valve which is set to open at 45 lb/sq. in. (31.6 kg/sq. cm).

● OPERATION E2a

Oil Pump Screen: Drain engine oil whilst warm




Figure 46. REMOVING OIL PUMP SCREEN

and remove sump. Remove setscrew attaching filter screen to pump and withdraw filter. Wash screen in clean diesel fuel and clean with air blast. Do not wipe with cloth. Refit screen, replace sump, using new gasket, and refill with new oil. (Fig. 46.)

● OPERATION E3

Pump Removal

1. Drain engine oil and remove sump.
2. Disconnect outlet pipe from pump to cylinder block. (Fig. 47.)




Figure 47. OIL PUMP DRIVE

- | | | |
|-----------------|-------------------|---------------|
| A. Camshaft | B. Spiral pinion | C. Driveshaft |
| D. Pump bracket | E. Locating screw | F. Pump body |

3. Disconnect the tractometer cable.
4. Release locknut and remove pump locating screw, which is situated on the right-hand side of block, and withdraw pump downwards.

The oil pump must be dismantled to check rotor wear and the condition of the upper bearing.




Figure 48. LUBRICATING OIL PUMP

A. Oil inlet gauze
D. Relief valve screw

B. Pump body
E. Spiral pinion

C. Driveshaft
F. Oil outlet connection

To Replace the Pump

Reverse the removal procedure. Coat the locating screw with Wellseal, or a similar jointing compound, screw tightly into the cylinder block then tighten locknut.

● OPERATION E3a

To Dismantle Pump

1. Remove the two setscrews and two bolts securing pump cover, noting that the two bolts are special locating bolts and must be fitted in their correct places when reassembling. (Fig. 48.)
2. Remove cover, complete with relief valve, and filter.
3. Check backlash between rotors — this should be 0.020 to 0.026 in. (0.51 to 0.66 mm).
4. Remove driven rotor and shaft.
5. Use a drift to force driving shaft from driving rotor.
6. Check rotor and housing dimensions.
Rotor width: 1.1865 – 1.1855 in. (30.13 – 30.11 mm)
Housing depth: 1.1890 – 1.1875 in. (30.19 – 30.16 mm)
Rotor side clearance: 0.001 – 0.0035 in. (0.025 – 0.089 mm)
If end-float is excessive but backlash is within limits and the rotors are not worn, it is permissible to grind the face of the housing to reduce end-float. If the rotors are damaged, both gears should be replaced. Never replace one rotor only.
7. Check the upper bearing for wear.
Bush internal diameter: 0.4905 – 0.4925 in. (12.46 – 12.51 mm)
Shaft diameter: 0.4895 – 0.490 in. (12.43 – 12.45 mm)
Clearance: 0.0005 – 0.003 in. (0.02 – 0.08 mm)

If wear is excessive, remove the bush and replace using Service Tool 901701 as detailed below:

1. Slip special pilot bush B through slot in pump bracket to locate in driveshaft bush.
2. Stand pump bracket on a suitable hollow anvil or press base.
3. Place drift A in position.
4. Drive or press out pump bracket bush.

To replace the new bush:

1. Place new bush on the replacer drift C.
2. Push centraliser D over new bush and drift C until oil-hole in bush just shows at bottom edge of centraliser, ensuring that the oil-holes in bush and bracket are in line.
3. Start new bush in pump bracket and slide off centraliser, ensuring that the oil-holes in bush and bracket are in line.




Figure 49. REPLACING OIL PUMP BRACKET BUSH
(Using Service Tool 901701)

A. Long drift

B. Pilot

C. Replacer drift

D. Centraliser guide




Figure 50. OIL PUMP TEST RIG

- A. Oil pump B. Pressure gauge C. Shut-off valve
D. Swivelling outlet

4. Stand the pump bracket on a flat anvil or press base; drive or press C until it butts firmly against D. The bush is now in its correct position in pump bracket. The driven rotor shaft may be removed using drift A.

Relief Valve

If the valve is to be removed for cleaning purposes take note how many threads are showing above the locknut before removal. This is necessary so that the valve may be set in its original setting if a test rig is not available.

Approximate figures to use as a guide when setting the valve are: four threads showing above locknut give approximately 45 lb/in.²; one full turn produces a 6 lb/in.² variation in pressure.

To check the pressure, the oil pressure warning switch should be removed and a gauge fitted into the $\frac{1}{8}$ BSP hole in the cylinder block.

If a test rig is available the following procedure should be adopted (Fig. 50):

1. Use Shell Fortisal 5W at room temperature of 20°C (68°F) or 20/20W at 46°C (115°F), which is equivalent to hot engine oil.
2. Pump to be driven at 750 rev/min or 330 rev/min.
3. Relief valve set to open at 45 lb/sq. in. (3.1 kg/sq. cm).
4. Pump flow at 20 lb/sq. in. should be 19.2 pints/min (10.9 litres/min) at 750 rev/min and 8.4 pints/min (4.7 litres/min) at 330 rev/min. Delivery in pints/min = 480

time in seconds for
one gallon to flow.

Maximum time for one gallon should be:

25 seconds at 750 rev/min.

57 seconds at 330 rev/min.

Oil Warning Light

The green oil warning light on the instrument panel is earthed by a switch in the cylinder block and when the switch opens the light is extinguished. The switch is connected into the main oil gallery and should open at 9 to 13 lb/sq. in. (0.6 to 0.9 kg/sq. cm) but if not, it must be replaced as the switch is not adjustable. If incorrect oil pressure is suspected the oil switch can be removed and a pressure gauge connected into the cylinder block, which is threaded $\frac{1}{8}$ BSP, so that the actual oil pressure will be shown when the engine is started.




Figure 51. OIL BATH AIR CLEANER

- A. Bowl B. Removable element
C. Fixed element D. Inlet pipe




Figure 52. FITTING TIMING COVER AND OIL SEAL

A. Service Tool 962560

B. Timing cover

C. Oil seal

● OPERATION F3

Air Cleaner: Remove cleaner bowl, empty oil bath and wash all sediment from bottom of bowl. (Fig. 51.)

Remove detachable wire mesh element from cleaner body, wash in clean diesel fuel and allow to stand until all fuel has drained off.

Replenish oil bath with *new* oil, taking care not to overfill bowl. Only fill to the level mark — not above or below it. An SAE 30 grade of straight mineral oil can be used in the air cleaner. This oil is less susceptible to frothing — and usually cheaper — than the detergent oils used in the engine. In climates where the ambient temperature often exceeds 32°C (90° F) an SAE 50 grade of oil may be used.

Before assembling air cleaner, thoroughly clean inside of pre-cleaner and inside of pipe through centre of air cleaner. Ensure that the rubber ring between cleaner body and bowl makes a good seal: leakage at this point will allow unfiltered air to enter engine.

● OPERATION G1

Timing Cover: This is bolted to front end of cylinder block and may be removed after removing fan belt and crankshaft pulley.

Refitting Timing Cover: Replace cover without seal and fit Service Tool 962560 over crankshaft so that it enters seal location and positions it centrally round crankshaft. Bolt cover in position then withdraw tool and use spigot end of tool to push seal into position in cover, ensuring that seal is positioned with lip facing inside of cover. (Fig. 52.)

When refitting early covers located by dowels, remove the dowels and use tool to centralise cover.

● OPERATION G1a

Timing Cover Oil Seal: A seal is fitted to prevent oil leakage from timing case, and if oil leaks from behind crankshaft pulley the seal should be renewed.




Figure 53. TIMING GEAR MARKING

A. Crankshaft gear

B. Intermediate gear

C. Camshaft gear

D. Injection pump gear.




Figure 54.

INTERMEDIATE GEAR

- A. Bracket
- B. Shaft
- C. Intermediate gear
- D. Injection pump gear.
- E. Crankshaft gear

Lever out old oil seal, taking care not to distort cover pressing, but do not press new seal into cover until cover has been refitted on engine.

● OPERATION G3

Timing Gears: These are accessible when the cover is removed, and before disturbing the gears turn engine until gear marks are aligned as shown in Fig. 53.

Do not turn crankshaft or camshaft when a gear is removed, or if gears are incorrectly meshed, otherwise damage may be caused by valve heads fouling pistons.

Camshaft gear is keyed on a parallel shaft and may be withdrawn after removing central bolt: do not remove the three setscrews visible through holes in gear — these attach locating plate and if removed will allow camshaft to move forward and jam against tappets. If gear is tight use an extractor such as Service Tool 960901. Do not attempt to remove gear by striking end of camshaft with a hammer.

Intermediate gear may be removed after removing support bracket. Take care of shims fitted between housing and carrier plate as these must be replaced.

● OPERATION G3b

Intermediate gear shaft is a push-fit in cylinder block and if tight can be removed by cutting the head of a $\frac{3}{8}$ UNC bolt and threading the bolt shank $\frac{3}{8}$ BSF. The UNC thread can then be screwed into shaft plughole and the BSF thread screwed into slide hammer, Service Tool 4235A. (Fig. 54.)

Injection Pump Drive Gear: On 1200 engines the gear is keyed on a taper shaft and retained by a

single nut. On 990 engines the gear is dowelled on a parallel shaft and retained by three bolts. Remove gear from pump shaft by using an extractor in the cored holes in gear. Do not attempt to remove gear by hammering end of pump shaft.

Crankshaft Gear: This is keyed on to shaft and should not be removed unless it is to be renewed. Using Service Tool 960604 unscrew the extractor bolt so that when the tool is placed over end of crankshaft, body of tool touches face of gear. Place the two halves of split ring over gear and, whilst holding split ring against body, tighten extractor screw so that split ring is gripped by chamfer on body shoulder and gear is drawn off shaft. (Fig. 55.)

Assembling Timing Gears: If intermediate gear spindle has been removed from cylinder block, ensure that oilway is clear of sludge and a plug is fitted in




Figure 55.

CRANKSHAFT GEAR REMOVER — 960604

- A. Extractor screw
- B. Body
- C. Split ring

each end of spindle. Smear plugs with Loctite then screw tightly into spindle.

Clean spindle then push into cylinder block. Smear intermediate gear bore with anti-scuffing paste before placing gear on spindle: teeth marking on gear aligned with marks on crankshaft gear. Refit shaft bracket, replacing the shims between bracket and carrier plate. Tighten bracket bolts then check that gear has 0.002 to 0.004 in. (0.05 to 0.10 mm) end-float and if necessary remove bracket and add, or remove, shims to obtain correct end-float. Ensure that an equal thickness of shims is fitted under each end of bracket — otherwise bracket will be distorted — and bolts are fully tightened.

Ensure that camshaft key is in position then replace

gear, aligning teeth marking with marks on intermediate gear. Replace the retaining bolt *fitted with the thick washer*. Tighten bolt to 40 lb ft (5.5 kg metres) then lock with wire. Loop wire through holes in gear then cross ends before passing through bolt-hole, so that bolt cannot work loose.

Replace injection pump gear, ensuring that key is in pump shaft (1200) or dowel is in gear (990) before fitting gear. Tighten retaining nut on 1200 pump and the three bolts on 990. After firmly tightening bolts on 990, bend corners of tabwasher against bolt heads.

Before refitting timing cover check that all gear markings are correctly aligned as shown in Fig. 53.

COOLING SYSTEM




Figure 56. COOLING SYSTEM

- | | | | |
|--------------------|------------------------|---------------|-------------------|
| A. Pump impeller | B. Jets to valve ports | C. Thermostat | D. Radiator inlet |
| E. Radiator outlet | F. By-pass connection | | |

Operation

Cool water is drawn into water pump from bottom of radiator and is then pumped through a passage in cylinder block into cylinder head, where it is directed in jets on to the injector bosses and valve ports. Water in cylinder head is able to pass, by thermosiphon, through passages in cylinder block to cool the cylinders. Hot water returns from cylinder head to top of radiator through a thermostat which opens and closes according to water temperature. (Fig. 56.)

When water passing out of cylinder head is cold the thermostat is closed and water cannot pass into radiator but returns to inlet side of water pump, via the by-pass connection, and is then re-circulated through cylinder head. As water temperature rises the thermostat commences to open and allows hot water to pass into top of radiator.

The thermostat therefore ensures that the engine warms up rapidly and runs at a satisfactory working temperature by automatically controlling the flow of water through radiator.

Anti-Freeze: In climates where the temperature falls below freezing point it is essential that the tractor cooling system is protected against frost

damage. A proprietary anti-freeze mixture, of sufficient strength to withstand the lowest temperature likely to be encountered, should be used. *Ensure that the anti-freeze is specially formulated for use in diesel engines and follow the manufacturer's instructions very carefully.*

All tractors despatched from the factory fully assembled are filled with anti-freeze mixture. This anti-freeze is of similar specification and at least equal in properties to the "permanent" anti-freeze used in the U.S.A. and Canada, although we do not recommend that any anti-freeze should be regarded as having more than a two-year life. The mixture used complies with BS 3152:1959, Type B, and will mix with ethylene glycol anti-freeze with a benzoate/nitrite type inhibitor for "topping up" purposes. *Anti-freeze mixtures with borate or mercaptol type inhibitors should NOT be used for "topping up" tractors filled with anti-freeze mixture at the factory.*

Thermostat: The thermostat is positioned in the cylinder head water outlet. If engine does not reach working temperature, or if it boils, drain cooling system and remove thermostat. Place thermostat in cold water together with an accurate thermometer. Heat the water and as the temperature rises note




Figure 57. THERMOSTAT

- A. Water outlet pipe B. Cylinder head
C. Thermostat

when the thermostat starts opening; this should be 174°–183° F (79°–84° C) and at 200° F (94° C) it should be fully open. If a thermometer is not available, place the thermostat in boiling water, when it should be fully open in 60 to 90 seconds. (Fig. 57.)

Renew the thermostat if it does not operate correctly. Do not attempt to adjust it and do not operate an engine without a thermostat. An engine without a thermostat in the cooling system will wear excessively due to being overcooled.

● OPERATION H6

Water Pump Removal:

1. Remove bonnet and drain cooling system.
2. Disconnect radiator pipes and remove radiator. On 1200 Tractors fitted with two-blade fan it is not necessary to remove radiator in order to remove water pump, but on tractors with a seven-blade fan the radiator must be removed.
3. Remove fan. Release dynamo mounting bolts and remove fan belt.
4. Remove bolts attaching pump body to cylinder block. Pivot pump body downwards until by-pass connection is clear of head then remove pump.

Refitting Water Pump: Refit pump in reverse order of removal, noting the following:

1. Examine core plug in front of cylinder block and fit new plug if there are any signs of leakage.
2. Fit new gaskets and seals, etc. Ensure that 'O' ring is fitted in recess at back of support plate.

3. If a two-blade fan is fitted ensure that flat washers are fitted under the bolt heads.

Water Pump Gland: The pump shaft is sealed by a gland seal in the impeller. This seal is spring-loaded, so that it is held in contact with pump body and faced with carbon to minimise wear; no attention is therefore required, and if the seal leaks the pump must be removed and seal renewed. The pump body has a drain hole under the bearing boss and if water drips out it is an indication that the gland is leaking.

Water Pump Bearing: The pump spindle runs on a double-row ball bearing. This is pre-packed with lubricant and does not require further attention. Renew bearing if it feels rough or dry.

● OPERATION H6a

Fitting a New Seal or Bearing: Remove pulley from spindle, using a suitable extractor, or press, so that the bearing locating screw can be removed. Place pump, impeller upwards, on the bed of a press and support body with suitable packings. Press spindle out of pump, taking care not to damage impeller or pump body, then lift impeller out of body and prise seal from recess in impeller. Renew impeller if corroded or damaged and renew bearing if any signs of roughness are apparent. Examine pump body: the seal contact face must be very smooth and free from any score-marks. (Fig. 58.)

Carefully press seal into impeller, using a little soapy water as lubricant, until seal touches end of impeller. Take care not to cut or damage seal and when in position smear seal contact faces with anti-scuffing paste to prevent it sticking to pump body.




Figure 58. WATER PUMP

- A. Pulley B. Bearing and spindle
C. Gland seal D. Impeller
E. By-pass seal

Position locating hole in bearing in line with screw-hole in pump body, then push bearing into position and fit locating screw. Lock locating screw with tabwasher when tight.

Support impeller end of spindle on a wooden block and press pulley on to spindle until end of pulley bore is level with end of spindle. Do not hammer the pulley on to the spindle and ensure pump is supported under impeller end of spindle and not under pump body.

Turn pump over and place a piece of $\frac{7}{8}$ in. (22 mm) diameter bar inside pulley recess — so that thrust is taken on end of spindle and does not push pulley further on to spindle — then carefully press impeller into place. Ensure gland seal is not damaged when fitting impeller, and press impeller on to spindle until clearance between tips of impeller blades and pump body is reduced to 0.005 in. (0.13 mm). Check that only the slight drag of seal can be felt when pulley is rotated.

DIMENSIONAL DATA

Torque Figures

Big-end bearing nuts	50 lb ft	6.92 kg metres
Breather filter cover nut	10 lb ft	1.38 kg metres
Camshaft gear bolt	40 lb ft	5.53 kg metres
Camshaft locating plate bolts	25 lb ft	3.46 kg metres
Carrier plate to cylinder block bolts	25 lb ft	3.46 kg metres
Clutch housing to main frame bolts	75 lb ft	10.5 kg metres
Crankshaft pulley nut	140 lb ft	19.3 kg metres
Cylinder block to main frame bolts	30 lb ft	4.15 kg metres
Cylinder head nuts and bolts	90 lb ft	12.4 kg metres
Cylinder head studs into block	25 lb ft	3.46 kg metres
Fan blade bolts	25 lb ft	3.46 kg metres
Flywheel nuts	50 lb ft	6.92 kg metres
Front extension to main frame bolts	65 lb ft	8.98 kg metres
Injection pump gear bolts (990)	20 lb ft	2.77 kg metres
Injection pump gear nut (1200)	45 lb ft	6.22 kg metres
Intermediate gear bracket bolts	45 lb ft	6.22 kg metres
Main bearing cap bolts	160 lb ft	22.12 kg metres
Main frame to engine bolts	30 lb ft	4.14 kg metres
Main frame to flywheel housing bolts	75 lb ft	10.5 kg metres
Oil filter bowl bolt	10 lb ft	1.38 kg metres
Sump to main frame bolts	20 lb ft	2.76 kg metres
Valve rocker adjusting nuts	14 lb ft	1.94 kg metres

The following figures apply to bolts of standard material with either coarse (UNC) or fine (UNF) threads and may be used for all bolts and nuts not listed in the previous table.

Thread Diameter	Torque
$\frac{1}{4}$ in	7 lb ft 0.97 kg metres
$\frac{5}{16}$ in	15 lb ft 2.07 kg metres
$\frac{3}{8}$ in	25 lb ft 3.46 kg metres
$\frac{7}{16}$ in	45 lb ft 6.22 kg metres
$\frac{1}{2}$ in	65 lb ft 8.98 kg metres
$\frac{9}{16}$ in	110 lb ft 15.2 kg metres
$\frac{5}{8}$ in	140 lb ft 19.3 kg metres

Capacities

Cooling system	3 gal	13.6 litres
Engine lubricating oil	13 pints	7.4 litres
Steering-box oil (990)	2 pints	1.1 litres
Steering-box oil (1200)	5 pints	2.8 litres
Air-cleaner oil bath (990)	$1\frac{1}{2}$ pints	0.7 litres

Air-cleaner oil bath (1200)	1 1/2 pints	0.85 litres
Fuel tank (990)	13 1/2 gal	61.4 litres
Fuel tank (1200)	18 gal	81.7 litres
Transmission oil (990)	5 gal	22.7 litres
Transmission oil (1200)	9 gal	41.0 litres

Wear Limits

The following figures are only intended to serve as a guide to determine when a component should be renewed:

Crankshaft big-end journals should be reground if ovality exceeds 0.005 in (0.127 mm).

Crankshaft main-bearing journals should be reground if wear exceeds 0.005 in (0.127 mm).

Crankshaft end-float should not exceed 0.015 in. (0.38 mm).

Piston rings should be replaced if ring gap exceeds 0.060 in (1.524 mm) when checked in unworn part of cylinder.

When there is evidence of ring and slight bore wear causing oil consumption, fit oil control rings. These should control oil consumption if bore wear is not greater than 0.010 in. (0.25 mm) and are available to suit either standard or oversize bores. If oil consumption exists and oil control rings have already been fitted it will be necessary to rebore the cylinder block and fit oversize pistons.

Piston groove clearance should not exceed 0.005 in. (0.13 mm) when checked with a new ring.

Oversize valves should be fitted if bore in cylinder head is worn in excess of 0.006 in. (0.15 mm).

Valve Clearance (set cold)

All inlet valves	0.010 in	0.25 mm
Exhaust valves with stem end caps	0.007 in	0.18 mm
Exhaust valves without stem end caps	0.010 in	0.25 mm

Valve Springs

Inlet (yellow spot)		
Free length	2.127 in	54.02 mm
Length at 77 lb load	1.148 in	
Length at 35 kg load		29.16 mm
Exhaust (blue spot)		
Free length	2.132 in	54.15 mm
Length at 82 lb load	1.180 in	
Length at 37 kg load		29.97 mm

Valve Stem Diameters (inlet and exhaust)

Standard	0.3732 — 0.3722 in	9.479 — 9.454 mm
Oversize 0.010 in. (0.007 mm)	0.3832 — 0.3822 in	9.733 — 9.708 mm
Oversize 0.020 in. (0.014 mm)	0.3932 — 0.3922 in	9.987 — 9.962 mm
Valve seat angle	45°	45°
Valve guide bore	0.375 — 0.374 in	9.525 — 9.499 mm
Valve tappet diameter	0.624 — 0.623 in	15.850 — 15.824 mm

Valve Seat Insert Counterbore Diameter (inlet and exhaust)

990	1.625 — 1.626 in	41.27 — 41.30 mm
1200 { AD4/55A/4913 onward..	1.625 — 1.626 in	41.27 — 41.30 mm
AD4/55A/1001 to 4912	1.5615 — 1.5635 in	39.66 — 39.71 mm

Seat Insert Interference Fit in Cylinder Head Counterbore

Inlet and exhaust	0.004 — 0.006 in	0.10 — 0.15 mm
-------------------	------------------	----------------

Valve Timing

Inlet opens	8° before top dead centre
Inlet closes	38° after bottom dead centre
Exhaust opens	36° before bottom dead centre
Exhaust closes	10° after top dead centre

Rocker Shaft

Diameter	0.748 — 0.749 in	18.99 — 19.02 mm
Bush bore reamed in position	0.7500 — 0.7505 in	19.05 — 19.06 mm

Crankshaft

Main journal diameter				
Standard size	2.4995 — 2.4990 in	63.487 — 63.474 mm
Undersize 0.010 in (0.254 mm)	2.4895 — 2.4890 in	63.233 — 63.220 mm
Undersize 0.020 in (0.508 mm)	2.4795 — 2.4790 in	62.979 — 62.966 mm
Undersize 0.030 in (0.762 mm)	2.4695 — 2.4690 in	62.725 — 62.712 mm

When regrinding crankshaft it is important that the original journal fillet radius is maintained. It is also important that the surface of the radius is as smooth as the surface of the journal and that the radius is smoothly blended into both surfaces. A fillet that is incorrectly radiused, roughly finished or not smoothly blended, weakens a shaft and may cause fatigue failure during service.

Big-end journal diameter				
Standard size	2.3735 — 2.3730 in	60.29 — 60.28 mm
Undersize 0.010 in	2.3635 — 2.3630 in	60.04 — 60.03 mm
Undersize 0.020 in	2.3535 — 2.3530 in	59.78 — 59.77 mm
Undersize 0.030 in	2.3435 — 2.3430 in	59.52 — 59.51 mm
Centre journal width				
Standard size	2.126 — 2.124 in	54.00 — 53.95 mm
Oversize 0.010 in	2.136 — 2.134 in	54.254 — 54.204 mm
Oversize 0.040 in	2.166 — 2.164 in	55.270 — 55.220 mm
Bearing fillet radius	0.16 — 0.15 in	4.06 — 3.81 mm
Big-end bearing clearance	0.0015 — 0.0025 in	0.038 — 0.063 mm
Main bearing clearance	0.002 — 0.004 in	0.051 — 0.102 mm
End-float of crankshaft	0.002 — 0.010 in	0.051 — 0.258 mm
Thrust washer thickness				
Standard	0.091 — 0.093 in	2.3114 — 2.3622 mm
Oversize 0.005 in (0.127 mm)	0.096 — 0.098 in	2.4384 — 2.4892 mm
Oversize 0.020 in (0.508 mm)	0.111 — 0.113 in	2.8194 — 2.8702 mm

Connecting Rod Alignment

Maximum out of parallel	0.0005 in/in	0.0127 mm/cm
Maximum twist	0.0005 in/in	0.0127 mm/cm
Maximum weight variation in set of four rods	0.25 oz	7.1 gm

Piston Dimensions (new)

Height (990)	4.406 in	111.9 mm
Height (1200)	4.156 in	105.6 mm
Nominal diameter	3 $\frac{1}{8}$ in	100 mm
Piston skirt diameter (at right-angles to gudgeon pin bore)	3.9323 — 3.9315 in	99.9 — 99.8 mm
Piston ring side clearance	0.002 — 0.0035 in	0.050 — 0.088 mm
Piston ring gap	0.011 — 0.016 in	0.28 — 0.41 mm
Gudgeon pin diameter	1.2503 — 1.250 in	31.757 — 31.750 mm
(Push-fit in connecting rod bush, light-drive fit in piston)				

Bore Dimensions (new)

Standard	3.9396 — 3.9388 in	100.07 — 99.76 mm
Oversize, 0.020 in	3.9596 — 3.9588 in	100.58 — 100.33 mm
Oversize, 0.040 in	3.9796 — 3.9788 in	101.09 — 100.86 mm

Sealing Ring (internal diameter) bore

Standard	3.942 — 3.944 in	100.13 — 100.18 mm
Oversize, 0.020 in	3.962 — 3.964 in	100.63 — 100.68 mm
Oversize, 0.040 in	3.982 — 3.984 in	101.14 — 101.19 mm

Fuel System

Injector setting pressure	175 atmospheres (180 kg/cm ²)
Spill timing (static) 1200 (4/55)	25° before top dead centre
990 (4/49)	17° " " " "

Spill timing mark : Pump flange and engine mounting flange are marked, and correct pump timing is obtained when these marks are in alignment.

Spill timing adjustment : Elongated holes in the injection pump mounting flange permit the pump body to be rotated when the three securing nuts are released.

Injection Pump Flange Marking

1200 (4/55)	11° from keyway when at point of injection
990 (4/49)	66° from keyway when at point of injection

Injection Pump Fuel Setting

990	10.4 — 10.6 cc per 200 shots at 850 rev/min
1200	AD4/55A/4913 onward		..	13.0 — 13.2 cc per 200 shots at 800 rev/min
	AD4/55A/1001 to 4912		..	11.8 — 12.0 cc per 200 shots at 800 rev/min

Injector Nozzle Hole Diameter

990 and 1200	0.28 — 0.30 mm
--------------	----	----	----	----------------

Injection Pump and Injectors

Pumps	Holder	Nozzle
990 — CAV DPA 32488207	BKBL 97S5152	BDLL 140S6417
1200 — Simms SPGE LM805250/1150 }		

Oil Pump

Spindle diameter	0.4895 — 0.490 in	12.43 — 12.45 mm
Spindle bush bore	0.4905 — 0.4925 in	12.458 — 12.509 mm
Rotor width	1.1865 — 1.1855 in	30.137 — 30.112 mm
Housing depth	1.1890 — 1.1875 in	30.191 — 30.162 mm
End float	0.001 — 0.0035 in	0.025 — 0.088 mm
Pump rotor backlash	0.020 — 0.026 in	0.511 — 0.66 mm

Camshaft Journal Diameters

Front	1.872 — 1.870 in	47.55 — 47.50 mm
No. 2	1.827 — 1.825 in	46.41 — 46.35 mm
Nos. 3 and 4	1.811 — 1.810 in	46.00 — 45.97 mm
No. 5	1.765 — 1.763 in	44.83 — 44.78 mm
No. 6	1.749 — 1.747 in	44.42 — 44.37 mm
Camshaft thrust washer thickness	0.245 — 0.240 in	6.223 — 6.096 mm
Camshaft end-float	0.010 — 0.020 in	0.254 — 0.508 mm

SUMMARY OF DESIGN CHANGES


Details of change	When introduced
Rear main bearing oil retainer changed from scroll type to positive contact seal. The new retainer (962319) incorporates asbestos packings (921611) and is interchangeable with the scroll type retainer (908398).	AD4/55/4570 (November 1967)
High-lift camshaft and larger diameter valves introduced, with corresponding changes to cylinder head, valve gear, pistons and fuel injection pump delivery, etc.	AD4/55/4913 (January 1968)
Cored holes in injection pump drive gear repositioned to facilitate use of gear extractor. Part number of gear, 912486, unchanged.	AD4/55/5332 (January 1968)
Material of carrier plate gasket changed from manila to Oakenstrong. Part number, 902301, unchanged although internal shape of gasket has been altered.	AD4/55/2021 (March 1968)
Pressed steel timing cover (915071) changed to aluminium cover (920957), incorporating engine oil filler. Previous oil filler in main frame deleted.	AD4/55/5917 (January 1968)
Bleed pipe (907037) fitted, connecting fuel filter to leak-off pipe. Part number of leak-off pipe changed from 917223 to 923667.	1200/705005 (February 1968)
Radiator core changed from honeycomb to gilled tube construction and metal two-blade fan changed to nylon seven-blade fan.	1200/705365 (March 1968)
Engine oil dipstick fitted with cup type shield, to prevent any ingress of water into sump. Part number of dipstick changed from 923944 to 924375.	1200/706078 (July 1968)
Plate (924397) fitted in timing cover so that injection pump can be removed without removing timing cover. Part number of cover changed from 920957 to 924396.	AD4/55A/7457 AD4/55B/1011 449001/5114 449002/1796 449005/1183 (August 1968)
Cylinder block core plugs (17192) changed to cup type plugs (623797). Part number of cylinder block unchanged, but as plug aperture machining has been changed the plugs are not interchangeable.	AD4/55A/9861 AD4/55B/1011 449001/11079 449002/2450 449005/1418 (April 1969)
Crankshaft pulley washer (626403) chamfered on inside to ensure washer tightens firmly against pulley.	AD4/55A/10259 AD4/55B/1011 449001/12127 449002/2697 449005/1466 (June 1969)
New valve (928622) fitted in place of inlet valve (921433) and exhaust valve (921434). The new valve, which is not fitted with a stem end cap, should be used as a replacement in engines fitted with high-lift camshaft and larger diameter valves.	AD4/55A/11930 AD4/55B/1013 449001/15241 449002/3038 449005/1621 (October 1969)

Main bearing and thrust washer facing material changed from white metal to aluminium tin. The new bearing, 928541, is used in both cap and cylinder block and is interchangeable with previous bearings if fitted in pairs. New thrust washers (928542/3) are fully interchangeable.

AD4/55A/13041
AD4/55B/1013
449001/18000
449002/3433
449005/1723
(January 1970)

Timing gear carrier plate modified to prevent oil leakage. Hole in plate enlarged so that plug bolt (609447) can be fitted at front end of oil gallery, and material of plate bolts changed so that they can be tightened to 25 lb ft (3.46 kg metres).

AD4/55A/13041
AD4/55B/1013
449001/16614
449002/3311
449005/1663
(February 1970)



David Brown®
Service Repair Manual
CLUTCH

Section B1 (Pub. 9-37132) October 1976



David Brown Tractors Ltd
A Tenneco Company
Affiliate of J I Case



Note: This publication includes information previously given in Pub. 9-37131 (Clutch section of TP 619, issued October 1970 with pp 22, 23, 44 to 49 updated April 1971) plus Pub.9-38158 (pp 51, 52 updated June 1976).

After the majority of this manual section was written, the current range of tractors was introduced. The information continues valid. Refer as follows:

885 tractor uses the same clutch as 880 Livedrive.

995 tractor (with live stage foot pedal) uses same clutch as 990.

996 and 995 tractors with independent hand PTO clutch, use the same clutch as 1200.

1210 (→11,154,230) and 1212 tractors use the same clutch as 1200.

1210 (11,154,230→), 1410 and 1412 tractors—refer to Update No. 1 (Pub. 9-38183), pages B1—B25.

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

CONTENTS

SECTION	PAGE
Single Plate Clutch — Non-Livedrive Tractors	
Operation	1
Adjustments	1
Servicing the Clutch Unit	2
Double Clutch — Livedrive Tractors (except 1200)	
Operation	5
Adjustments	6
Servicing the Borg and Beck Clutch Unit	8
Servicing the Laycock Clutch Unit	14
Dual Clutch — 1200 Livedrive Tractors	
Operation	15
Adjustments	16
Servicing the Clutch Unit	16
Twin-Plate Clutch	
Adjustments	21
Servicing the Clutch Unit	22
Refacing Driven Plates	24
Clutch Stop	25
Overload Release Withdrawal Mechanism (Hand Clutch)	26
Clutch Removal and Replacement	
770, 780 and 3800 Tractors	27
880 and 990 Tractors	28
1200 Tractors	31
Clutch Fault Diagnosis	37
Clutch Service Tools	40
Dimensional Data	45
Summary of Design Changes	50




Figure 1 SINGLE PLATE CLUTCH — 990/880 TRACTORS

- | | | | |
|------------------|--------------------|------------------------|-------------------|
| A. Driven plate | B. Pressure plate | C. Thrust spring | D. Cover |
| E. Release lever | F. Eye bolt | G. Release lever plate | H. Spigot bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Operating lever | P. Pedal | Q. Roller |
| | R. Adjusting screw | | |

SINGLE PLATE CLUTCH — NON-LIVEDRIVE TRACTORS

Description

The clutch is of the dry plate type and consists of a driven plate, cover assembly and withdrawal mechanism.

The driven plate consists of a thin steel disc with a splined hub riveted to the centre and friction facings riveted to each side of the outer edge. The cover assembly is built up from a steel pressing and incorporates a cast iron pressure plate loaded with thrust springs. Mounted on the pressure plate are three release levers which pivot on floating pins retained in the eyebolts and transmit movement to the pressure plate through struts.

Operation — 880 and 990 Tractors

The withdrawal mechanism shown in Fig. 1 is that used on 880 and 990 Tractors. As the clutch pedal is depressed, the lever turns the cross shaft which moves the carbon block forward by means of the fork. As movement of the carbon block is transmitted to the release levers by the lever plate, the levers pivot on the pins and draw pressure plate away from flywheel by means of the struts, thus releasing the driven plate and disengaging the drive.

Adjustment—880 and 990 Tractors

The only adjustment required in service is the maintaining of clutch pedal "free play" from 1 to 1½ in. (2.5 to 3.8 cm). To adjust pedal free-play,




Figure 2 SINGLE PLATE CLUTCH — 770 TRACTOR

A. Driven plate	B. Pressure plate	C. Thrust spring	D. Cover
E. Release lever	F. Eye bolt	G. Release lever plate	H. Spigot bearing
J. Clutch shaft	K. Support snout	L. Release bearing	M. Release fork
N. Cross shaft	O. Pedal return spring	P. Pedal	

release locknut and turn adjusting screw until correct movement is obtained. Retighten locknut.

If hand clutch is fitted (see page 26) the rod adjusting-nut should be slackened before adjusting pedal free-play and then reset afterwards to give a clearance of $\frac{1}{16}$ in. (1.5 mm).

Operation — 770 Tractors

The clutch pedal on the 770 Tractor is fitted directly on to the cross shaft, which is housed in the gearbox cover and not in the main frame as on the other models (see Fig. 2). Operation of the clutch withdrawal mechanism is, otherwise, the same as on the 880 and 990 Tractors.

Adjustment — 770 Tractors

The only adjustment required during service is the maintaining of $\frac{1}{2}$ to $\frac{3}{4}$ in. (1–2 cm) pedal free-play, to ensure that the withdrawal mechanism is disengaged when the pedal is released.

As the drive plate facings wear, pedal free-play will be reduced and when necessary should be reset by screwing the stop screw further into the main frame. When the pedal has insufficient free-play and the stop screw is screwed fully inwards, the pedal should be removed from its shaft, turned clockwise into the next serration, and refitted on shaft. The adjusting screw can then be screwed outwards until correct free-play is obtained.

As the cross shaft will turn, due to the action of the shaft return spring, when the pedal is removed, it is advisable to mark the original positions of the shaft and pedal so that the new position can be easily found.

Servicing the Single-Plate Clutch Unit

1. Mark the position of the release levers, cover plate, pressure plate, and eyebolts so that these may be refitted in the same position should new parts be unnecessary.



Figure 3. REMOVING THE RELEASE LEVERS



Figure 4. REPLACING STRUT AND RELEASE LEVER

2. Place the assembly on a press, with a block under the pressure plate positioned so that the cover is free to move down. Place a block or bar across top of the cover, resting on the spring bosses.
3. Compress the cover against pressure plate, unlock and remove eye nuts. Slowly release the pressure on cover until the thrust springs are fully extended.
4. Lift off cover, and remove thrust springs. Remove release levers (Fig. 3), clean and examine all parts.
5. To assemble clutch, place pressure plate on the block and replace release levers and struts (Fig. 4), taking note of the marks made during dismantling and applying a smear of grease to the pivot pins and struts.




Figure 5 CHECKING RELEASE LEVER HEIGHT

- | | | | |
|---------------|------------------|-----------------------------|-------------------|
| A. Base plate | B. Studs | C. Spacers — pressure plate | D. Release lever |
| E. Actuator | F. Centre pillar | G. Spacer — centre pillar | H. Setting finger |

6. Replace thrust springs on the pressure plate bosses and place cover in position on top of the springs, after ensuring that the three anti-rattle springs are in position on cover and the marks made during dismantling are in alignment.
7. With the second block placed across cover, as in dismantling, compress thrust springs until the eyebolt nuts can be replaced.
8. Remove clutch assembly from the press and depress release levers two or three times to settle the working parts.

Operations 1-8 can alternatively be carried out using the Clutch Tool (see Service Tool Leaflet A3). The clutch should be bolted on to the base plate, Part No. 912917, using the long studs and nuts in the kit. The thrust springs are released by gradually unscrewing the nuts on the long studs so allowing clutch cover to lift away from pressure plate.

After reassembly the clutch should be set up as follows, using the clutch tool (Fig. 5, Page 3):

9. Fit No. 3 Code spacers in place of the driven plate. Position a spacer opposite each release lever, bolt clutch to base plate and fit the

actuator assembly. Operate the actuator lever a few times to "bed in" the release lever mechanism.

10. Remove actuator and fit centre pillar with the correct spacer, recess downwards.
For 9 in. clutch (770 Tractor) use centre pillar spacer Code No. 8
For 10 in. clutch (880 Tractor) use centre pillar spacer Code No. 8
For 11 in. clutch (990 Tractor) use centre pillar spacer Code No. 16x.
Check release lever heights with setting finger and reset if incorrect.
11. Refit actuator and operate clutch a few times, finally rechecking the release lever heights before locking the adjusting nuts by peening the cylindrical portion of the nut into the eyebolt.
12. Fit release lever plate and secure by fitting the three retaining springs. Before moving clutch from flywheel or base plate, replace the three nuts used as packing pieces between the cover and release levers.




Figure 6 DOUBLE CLUTCH — 880/4600/990 LIVEDRIVE TRACTORS

- | | | | |
|--------------------------------|----------------------------|------------------------|-----------------------|
| A. Driven plate — transmission | B. Pressure plate | C. Thrust springs | D. Cover — outer |
| E. Cover — inner | F. Release lever | G. Release lever plate | H. Bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Operating lever | P. Pedal | Q. Roller |
| R. Adjusting screw — pedal | S. Adjusting screw — cover | T. Separator plate | U. Driven plate — PTO |
| | V. Driveshaft — PTO | | |

DOUBLE CLUTCH — LIVEDRIVE TRACTORS

Description: The double clutch is in effect two separate clutches mounted in tandem and controlled by a common pedal. The inner clutch (which is nearest the flywheel) transmits the drive to the hydraulic lift pump and power take-off and the outer clutch transmits the main drive to the gearbox. Disengagement of the main drive clutch does not, therefore, disengage the drive to the power take-off or hydraulic pump, which remain in operation until the second clutch is disengaged.

Operation — 880, 4600 and 990 Tractors

The operating mechanism shown in Fig. 6 is used on the 880, 4600 and 990 tractors. As the clutch pedal is depressed the pressure plate is drawn rearwards by the action of the release levers until the rear (transmission) drive plate is free and the adjusting screw clearance is reduced from 0.070 in. (1.78 mm) to 0.009-0.012 in. (0.23-31 mm). During this first stage the pedal roller will have moved along the cross shaft lever until it is in contact with both faces. Further movement of the clutch pedal will cause the roller to continue turning the




Figure 7. CLUTCH OPERATING MECHANISM — 780/3800 TRACTORS

- | | | | |
|----------------|--------------------|------------------------|--------------------|
| A. Pedal | B. Roller | C. Operating lever | D. Stop bolt |
| E. Cross shaft | F. Return spring | G. Fork | H. Connecting link |
| J. Lever | K. Adjusting screw | L. Shaft — clutch stop | |

cross shaft and cause the pressure plate to move further to the rear until the adjusting screw clearance is reduced to zero; this is the second stage movement. Further movement of the pedal beyond this point (third stage) will also move the inner cover to the rear as the pressure plate is now in contact with the adjusting screws. As inner cover is withdrawn the pressure on separator plate is released so that the three flywheel springs move the separator plate rearwards, thus disengaging the PTO clutch plate.

Adjustment — 880, 4600 and 990 Tractors

As the clutch linings wear during service the separator plate and pressure plate will move closer to the flywheel and reduce the amount of pedal free-play. This should be adjusted by slackening the locknut and turning the adjusting screw until free-play is 1 to 1½ in. (2.5 to 3.8 cm). If a hand clutch is fitted (see page 26) the adjusting nut on the connecting rod should be slackened before adjusting free-play and then reset afterwards to give a clearance of ¼ in. (1.5 mm). (Fig. 6.)

Note: The eccentric roller pin is set during manufacture and should not normally require resetting, unless new parts are fitted to the operating mechanism.

If difficulty is experienced in freeing PTO clutch, or if clutch unit has been removed, proceed as follows:

1. With the clutch housing fully tightened down, adjust the pedal free-play from 1 to 1½ in. (2.5 to 3.8 cm).
2. Set the three inner cover adjusting screws to give 0.070 in. (1.78 mm) clearance between the pressure plate and the end of the screws. The adjusting screw clearance can be checked by inserting a feeler gauge through the holes in the outer cover. If clutch housing is in position the adjusting screws are accessible when clutch pit cover (919568) is removed and engine turned to bring the screws opposite the cover aperture.
3. Depress clutch pedal until pedal roller is in contact with both faces on cross shaft lever then check the cover adjusting screw clear-

ance. If the adjusting screw clearance is not 0.009–0.012 in. (0.23–0.31 mm) adjust by rotating the eccentric pin to the next position. (Move clockwise to increase the clearance and anti-clockwise to decrease it.) One hole movement gives approximately 0.005 in. (0.13 mm) adjustment.

4. If the correct clearance still cannot be obtained, reset the three adjusting screws to within the limits 0.065–0.072 in. (1.65–1.83 mm) to obtain correct clearance.
5. Reset pedal free-play to 1–1½ in. (2.5–3.8 cm) If new facings have been fitted set free-play to 1½ in. (3.8 cm.) to allow for bedding in.

Adjustment — Laycock Clutch: A number of 880 Tractors are fitted with a Laycock clutch, and pedal free-play adjustment on these tractors is exactly the same as the pedal adjustment previously described for tractors fitted with a Borg and Beck clutch. The internal adjustment is, however, different and if the power take-off clutch does not fully disengage when the pedal is fully depressed the adjusting screws on the three release levers should be adjusted as described in next column for 780 Tractors.

Operation — 780 and 3800 Tractors

The operating mechanism used on 780 and 3800 Tractors is shown in Fig. 7. As the clutch pedal is depressed the roller in the cross shaft fork rolls along the pedal cam and turns the cross shaft. When the pedal is depressed approximately halfway the cross shaft is only turned sufficiently to withdraw the pressure plate, far enough to release the main drive plate but not far enough to contact the three adjusting screws on the inner cover. The power take-off clutch therefore remains engaged and only the drive to the transmission is disconnected.

When the clutch pedal is fully depressed the cross shaft is turned so far that the pressure plate is drawn past the point where it contacts the three inner cover screws. The inner cover is thus also withdrawn and both transmission and power take-off clutches are disengaged.

Adjustment — 780 and 3800 Tractors

As the clutch linings wear during service the separator plate and pressure plate will move closer to the flywheel and reduce the amount of pedal free-play, thus pedal adjustment should be checked frequently and, when necessary, adjusted by means of the stop bolt in the main frame. This bolt determines position of pedal when clutch is engaged; screwing the bolt further into frame will increase pedal travel and also increase the amount of free-play. The screw should be set so that pedal free-play is ¾ to 1 in. (1.9 to 2.5 cm) and if this amount of free-play cannot be obtained because the screw head is screwed right down on to the locknut more adjustment can be obtained by repositioning the operating lever on cross shaft. First scribe a line across the

lever and cross shaft end (this will enable the new position to be checked against the original position), then remove the two pedal springs and operating lever clamp bolt. Slide operating lever towards the end of shaft so that the splines are exposed behind the lever then firmly grip cross shaft with a pair of pliers and, whilst holding shaft clockwise against return spring inside the cover, remove lever and refit on the next clockwise spline. Check scribe marks to make sure the lever has been moved only one spline and in the correct (clockwise) direction, then refit the clamp bolt and springs and re-adjust the stop bolt.

If the amount of pedal free-play is correct, but the power take-off clutch does not fully disengage when the pedal is fully depressed, this is probably due to excessive clearance between pressure plate and inner cover adjusting screws.

To reset inner cover adjusting screws, remove cover plate from right-hand side of clutch housing and turn engine until a screw is opposite the cover aperture. Insert a feeler gauge through hole in outer cover and set adjusting screw so that it has 0.070 in. (1.78 mm) clearance then *firmly tighten the locknut*. Mark the screw with chalk so that if the engine is turned too far the same screw is not adjusted twice, then turn the engine and reset the other two screws. Finally, recheck pedal free-play and replace cover plate.

Adjustment — Laycock Clutch: A certain number of 780 Tractors are fitted with a Laycock clutch and pedal free-play adjustment on these tractors is exactly the same as the pedal adjustment previously described for tractors fitted with a Borg and Beck clutch. The internal adjustment is, however, different and if the power take-off clutch does not fully disengage when pedal is fully depressed the adjusting screws on the three clutch levers should be reset as follows:

1. Check that the clutch housing bolts are fully tightened and the pedal free-play is correct.




Figure 8. FEELER GAUGE — LAYCOCK CLUTCH

- | | |
|-----------------------|------------------|
| A. 4 in (101.6 mm) | B. ¾ in (9.5 mm) |
| C. ⅜ in (2.4 mm) | D. ¾ in (9.5 mm) |
| E. 0.056 in (1.42 mm) | |

2. Make a feeler gauge to the dimensions shown in Fig. 8 and remove cover plate from right-hand side of the clutch housing.




Figure 9.

INTERNAL ADJUSTMENT — LAYCOCK CLUTCH

- | | |
|--------------------|------------------------|
| A. Release lever | B. Roller |
| C. Adjusting screw | D. Cover thrust button |

- Turn engine until a release lever is opposite cover aperture then insert cranked end of feeler gauge through open heel of lever. (Fig. 9.) Pass end of gauge over roller and pin until it goes under the adjusting screw, then release locknut and, *taking care to note the number of flats the screw is turned*, tighten screw until it just commences to hold the gauge. Firmly tighten locknut, whilst holding screw stationary, and mark lever with chalk, so that it is not adjusted again if engine is turned too far. Reset remaining screws, *not by using the gauge but by turning the screws exactly the same amount as it was necessary to turn the first screw*. This is important as it ensures the plates and facings remain parallel.

Operation — 770 Tractors

As the clutch pedal is fitted directly on the cross shaft, and does not operate the cross shaft via a roller and double-faced lever as on 880 Tractors, the pedal has only two stages of movement. (Fig. 10.)

Depressing the pedal until the pressure plate is drawn rearwards and touches the three inner cover adjusting screws gives the first stage and disengages the transmission drive plate. Depressing pedal fully into the second stage withdraws the inner cover, due to the pressure plate pushing the three adjusting screws, and releases pressure on the separator plate. The three flywheel springs then push separator plate from flywheel and release the power take-off drive plate.

Adjustment — 770 Tractors

As the linings wear during service, pedal free-play will be reduced and this must be restored by adjusting the pedal-stop bolt. Screw the adjusting screw into main frame until pedal has $\frac{1}{4}$ to $\frac{1}{2}$ in. (1.3–2 cm) free-play. When the adjusting screw is fully screwed into main frame a further range of adjustment may be obtained by removing pedal from cross shaft and refitting on the next clockwise serration. This will give pedal a large amount of free-play and allow the adjusting screw to be screwed outwards until the correct amount of free-play is obtained. As the cross shaft will turn, due to action of the shaft return spring, when the pedal is removed, it is advisable to mark the original positions of the shaft and pedal so that the new position can be easily found.

When pedal free-play is being adjusted, after the clutch unit has been serviced, it may be necessary to remove pedal from cross shaft and refit on the next clockwise serration, to allow for the change in pedal position, due to the new plate facings.

If difficulty is experienced in freeing PTO clutch, or if clutch unit has been removed from the flywheel, the three adjusting screws in the inner clutch cover should be adjusted to give 0.070 in. (1.78 mm) clearance between the pressure plate and the end of the screw.

The adjusting screw clearance can be checked by inserting a feeler gauge through the holes in the outer cover. If gearbox top is in position the adjusting screws are accessible when the cover plate is removed from right-hand side of clutch compartment and the engine turned to bring the screws opposite the cover aperture. Ensure that the locknuts are firmly tightened after setting the adjusting screws and finally set pedal free-play.

Servicing Borg and Beck Clutch

The clutch can be dismantled by using the base plate, Service Tool 912917. (See Service Tool Leaflet A4.)

- To ensure reassembly of the parts in the same relative position, thereby preserving the balance and adjustment of the clutch, mark the following parts:
 - pressure plate and inner and outer clutch covers.
 - release levers and pressure plate lugs.
 - separator plate and flywheel.
- Remove three adjuster screws and nuts.
- Screw the long studs into the appropriate holes in the base plate — the studs have a screwdriver slot in the end for this purpose — and fit a cover spacer (912724) on each stud. Place three Code 14 spacers on the base plate, equally spaced and positioned so that the pressure plate will rest on them. Place the clutch assembly on the studs, fit the stud nuts, and tighten down progressively and by diametrical selection.




Figure 10 DOUBLE CLUTCH — 770 TRACTOR

A. Driven plate — transmission	B. Pressure plate	C. Thrust springs	D. Cover — outer
E. Cover — inner	F. Release lever	G. Release lever plate	H. Bearing
J. Clutch shaft	K. Support snout	L. Release bearing	M. Release fork
N. Cross shaft	O. Return spring	P. Pedal	Q. Adjusting screw — cover
R. Separator plate	S. Driven plate — PTO	T. Cardan shaft — PTO	

4. Disengage release lever plate by removing the retaining springs from each release lever.
5. Remove split pins from the release lever fulcrum pins; withdraw the pins and remove release levers after removing the anti-rattle springs.
6. If required, extract the pin securing the roller bearing in each release lever, preparing to catch the 19 needle rollers as each pin is removed.
7. Slowly, and by diametrical selection, unscrew nuts on the long studs securing clutch cover to base plate so that the thrust springs are under control as the cover is released. Separate the various parts of clutch.

Checking the Clutch Parts

Before reassembling the clutch unit all parts should be thoroughly cleaned and then checked over as below.

1. Check release levers for wear. Renew if flats are worn on the tips or fulcrum points. If necessary fit new roller assemblies and lubricate with anti-scuffing paste.
2. Examine the outer cover bearing and renew if tight or dry. When fitting a new bearing ensure that it is a sliding fit in the housing otherwise the bearing will not run freely and may cause clutch spin. If necessary scrape out the housing until the bearing can be pushed freely into position.




Figure 11. INSERT SWAGING TOOL

A. 0.438 in (11.11 mm)	B. 0.040 in (1.016 mm)	C. 0.025 in (0.635 mm)
D. 0.609 in (15.47 mm)	E. 0.75 in. (19.05 mm)	F. 0.312 in (7.93 mm)
	G. 0.065 in (1.65 mm)	

3. Check all the clutch springs. Replace if discoloured, rusty or weak. (See Page 50.)
4. Examine pressure plate and replace if badly scored, cracked or blued. Slight scores or cracks may be removed by resurfacing. Maximum amount which can be removed — 0.015 in. (0.38 mm.)
5. Check the condition of the separator plate. If it is only worn on the transmission side, further life may be obtained by reversing it. If badly cracked or blued, it should be replaced as the maximum which can be removed by resurfacing is 0.030 in. (0.75 mm) (total both sides). Also check that the plate is a free sliding fit in the flywheel teeth: a tight plate will cause power take-off clutch spin and a very slack plate may rattle when the pedal is fully depressed. Separator plate rattle is not, however, detrimental to clutch operation.
6. Fit the pressure plate into each cover in turn and check that the clearance between the three lugs and their respective slots is sufficient to give the covers 0.006–0.012 in. (0.15–0.30 mm) total side play on the pressure plate. If not increase the clearance by filing the cover slots. If the cover slots are filed to increase the clearance, also open out the three adjusting screw-holes in the outer cover to $\frac{1}{8}$ in. (17.5 mm) to prevent any possibility of the locknuts fouling the cover and breaking the screws.
7. Examine threaded bushes in inner cover and fit new bushes if the threads are worn or if the bushes are loose. New bushes are available under Part No. 962449, and as these are threaded $\frac{3}{16}$ UNF a set of three must be

fitted, with new screws and nuts, if they are replacing $\frac{1}{2}$ UNF nuts used on earlier clutches, otherwise the clutch would be out of balance. It will also be necessary to enlarge the three outer cover holes to $\frac{1}{8}$ in. (17.5 mm) diameter, to allow sufficient clearance for the larger adjusting nuts.

To fit the bushes successfully it is necessary to make a swaging tool to the dimensions shown in Fig. 11. Make the tool from silver steel (good quality tool steel with approximately 1% carbon) and heat treat after machining. Heat to a bright red colour then quench in oil. Polish the spigot end, reheat it to a purple colour and allow to cool naturally in air.

To fit new bushes:

- a. Drill out the existing bushes with a $\frac{1}{2}$ in. (12.7 mm) diameter drill.
- b. Countersink the holes on outside of cover to $\frac{3}{8}$ in. (15.48 mm) diameter at 90° included angle.
- c. Press or drive the new bushes in from inside the cover until the bush shoulder is pressed firmly against inside of cover.
- d. Turn cover over and whilst supporting the bush on an anvil use the round end of the tool to flare the hollow end of the bush.
- e. Reverse the tool and use the spigot end to firmly swage the bush in position.
- f. With a smooth file "dress" the bush flush with the outside of the cover.

The cover and bush must be supported on an anvil during the flaring and swaging




Figure 12. ASSEMBLING A DOUBLE CLUTCH

A. Baseplate	B. Spacers — cover	C. Studs	D. Spacers — pressure plate
E. Adaptor — centre pillar	F. Pressure plate	G. Thrust spring	H. Inner cover
J. Outer cover	K. Release lever	L. Adjuster pad	M. Actuator

operation. If a press is used this must be of at least 5 tons (5080 kg) capacity, and if carried out by hand use a 2 lb (1 kg) copper hammer to avoid damaging the tool.

8. Check the three "push-off" springs in fly-wheel.
9. Examine the drive plates (see page 24) and check that the plates slide freely on the shaft splines.

Assembling and Setting a Borg and Beck Double Clutch

1. Place the base plate Service Tool 912917 on the bench and clean the face.
2. Screw the long studs into the appropriate holes in the base plate; the screws have a screw-driver slot at one end for this purpose.
3. Screw the pillar adaptor (912723) into the centre of the base plate and place Code 14 spacers on the base plate, equally spaced and positioned so that they are under the release levers. Fit a cover spacer (912724) on each stud, so that when the stud nuts are tightened the spacers will be clamped between the cover flange and base plate.
4. Fit pressure plate on top of the spacers and, after lightly coating the lugs with anti-scuffing paste, fit the inner cover, springs, spring covers and outer cover. Tighten down the cover using the long studs and nuts. Check that all marks made when dismantling are re-aligned and tighten the nuts progressively and by diametrical selection to avoid

distorting the cover.

5. Fit release levers.
6. Screw the actuator into the adaptor and depress the handle about twelve times to settle the release mechanism. This is essential, otherwise the release lever setting may change when the clutch is put into operation. It is also important to bear in mind that the purpose of this is to operate the release levers in their normal working position, and the actuator must only be screwed into the adaptor far enough to bring the handle horizontal. If the actuator is screwed fully into the adaptor and the handle operated in an almost vertical position, damage to the actuator may occur.
7. Remove actuator and fit centre pillar in its place. Place the appropriate spacer, Code 8 on a 10/10 in. clutch and Code 16 on a 11/10 in. clutch, on the centre pillar, with the recess downwards, and then fit the single checking finger. (Fig. 13.)
8. Set release levers, by shimming the adjuster pads, to finger height, checking with a set of feeler gauges. A variation of 0.001 in. shim thickness will give a 0.0045 in. variation at the lever tip and the lever tips should be adjusted to within 0.002 in. (0.05 mm) of each other. Operate clutch after changing the shims to settle the parts, and hold the release levers down firmly by hand when checking the height.

Shims for release lever roller pads:

0.002 in. thick	Part No. 900258
0.003 in. thick	Part No. 901723




Figure 13. CHECKING RELEASE LEVER HEIGHT — BORG AND BECK

- | | | | |
|----------------------------|---------------------------|------------------|-----------------------------|
| A. Baseplate | B. Spacers — cover | C. Studs | D. Spacers — pressure plate |
| E. Adaptor — centre pillar | F. Spacer — centre pillar | G. Centre pillar | H. Setting finger |
| | J. Release lever | K. Adjuster pad | |




Figure 14. ANTI-RATTLE SPRING REPLACING TOOL

- | | | |
|-------------------------------|--------------------------------|--------------------------------------|
| A. $\frac{1}{2}$ in (19.0 mm) | B. $\frac{3}{8}$ in (9.5 mm) | C. $\frac{1}{16}$ in (2.4 mm) radius |
| D. $\frac{1}{8}$ in (3.2 mm) | E. $11\frac{1}{2}$ in (292 mm) | F. $1\frac{1}{2}$ in (38.1 mm) |
| | G. $\frac{1}{16}$ in (2.4 mm) | |




Figure 15. FITTING ANTI-RATTLE SPRINGS

0.010 in. thick Part No. 904138
0.020 in. thick Part No. 904193

9. Refit the release lever anti-rattle springs. These are of the double coil type and quite strong. The easiest way of fitting them is to make a simple tool as shown in Fig. 14. If the pins attaching the release levers to the pressure plate lugs are removed, and the springs fitted in position, the tool can be rested against the cover bearing housing and used as a lever to push the release lever outwards, against the spring, until the retaining pin can be refitted.

10. Fit the three adjusting screws and nuts into the inner cover and set them to a clearance of 0.070 in. (1.78 mm). (Note that this clearance will require resetting after the clutch is assembled on the tractor flywheel.) Refit release lever plate, securing with the spring clips.

11. Before removing the clutch from base plate, replace the $\frac{7}{8}$ in. nuts under the release levers, to prevent the thrust springs expanding too far.

Laycock Double Clutch

The Laycock double clutch is fitted to a number of 880 and 780 Tractors and as this clutch does not use the same release bearing and carrier as the Borg and Beck clutch they are not directly interchangeable.

As the clutch pedal is depressed the release levers (Fig. 16) pivot first about the fulcrum rollers and then, when the adjusting screw contacts the cover thrust button, on the outer cover. When release lever is pivoting on fulcrum roller the pressure plate is drawn rearwards to release the transmission plate but the pressure of the thrust springs is transferred to the three plungers, which are pressed against the separator plate and therefore hold the power take-off driven plate firmly in engagement. Pressing the release levers so far that they pivot on the cover thrust button withdraws pressure plate and also releases the three plungers, so that the three springs in flywheel push the separator plate away from flywheel and release the power take-off plate. Both clutches are therefore disengaged when pedal is fully depressed but only the transmission clutch is disengaged if pedal is not depressed past the point where the adjusting screw contacts cover thrust button.




Figure 16. SETTING RELEASE LEVER HEIGHT — LAYCOCK

- | | | |
|-----------------------------------|-----------------------------|--------------------------------|
| A. Baseplate | B. Spacer — cover | C. Spacers — pressure plate |
| D. Adaptor — centre pillar | E. Spacer — 961853 | F. Spacer — 962577 |
| G. Setting finger | H. Release lever | J. Adjusting screw — PTO stage |
| K. Adjusting screw — lever height | L. Plunger — pressure plate | M. Roller — release lever |

Servicing the Laycock Double Clutch Unit

The clutch unit can be dismantled by using clutch tool kits 961850 (Kit No. 1) and 961856 (Kit No. 2) which include base plate 912917 (see Service Tool Leaflet A4 or C1). The parts of the tool are identical to those for Borg and Beck clutch except that a centre pillar adaptor 962577 will also be required.

1. To ensure assembly of parts in the same relative position, thereby preserving the balance of the clutch, mark the following parts.
 - a. pressure plate and outer cover
 - b. release levers and plungers
 - c. separator plate and flywheel
2. Screw long studs into appropriate holes in baseplate — the studs have a screwdriver slot for this purpose — and fit a cover spacer 912724 on each stud. Place three code 14 spacers on baseplate, equally spaced and positioned so that the pressure plate will rest on them. Place clutch assembly on studs with release levers opposite the spacers. Fit stud nuts and tighten down progressively by diametrical selection.
3. Slacken off the adjusting screws, remove release lever pivots and spring anchor pins, remove release levers and withdraw roller pins and rollers, and extract plungers.
4. Slowly, and by diametrical selection, unscrew nuts on long studs securing cover to base plate so that thrust springs are under control as cover is released. Separate the various parts of the clutch.

Checking Clutch Parts: Before re-assembling clutch all parts should be thoroughly cleaned and then checked as below.

1. Check release levers for wear. Renew if main pivot pin holes are worn, replace adjusting screws if any flats are worn on fulcrum points. Where new adjusting screws are being fitted check that the spherical end is smooth. If there is a pip on end this should be polished away with emery cloth.
2. Examine release lever rollers and renew if any flats are apparent, fit new roller assemblies and lightly lubricate with anti-scuffing paste.
3. Examine thrust buttons (for the PTO stage). If these are excessively worn the cover should be replaced. It is not recommended that the buttons be changed in service.
4. Examine clutch cover bearing and renew if tight or dry. A new bearing should be a light push fit in cover otherwise clutch may spin because outer track will be deformed. If necessary, scrape the three housing locations until bearing can be pushed freely into

position. *It is important that an equal amount is removed from each of the locating faces.* To change the bearing it will be necessary to carefully cut the three rivets, remove retaining plate and punch the rivets out of clutch cover. On re-assembly retaining plate may be secured with three round head $\frac{3}{8}$ in. diameter rivets or alternatively three round head $\frac{3}{8}$ BSF screws and nuts, the heads of the screws should be on outer face of clutch cover and the nuts should be treated with Loctite to ensure that they do not work loose.

5. Check clutch springs, replace if discoloured or rusty. It should be noted that the free length of springs may vary up to $\frac{1}{8}$ in. (1.5 mm) and this is no indication of weak springs. It is the loaded length of the spring that is important. (See Page 50.)
6. Examine spring seat insulating washers and replace if damaged or broken.
7. Examine pressure plate and replace if badly scored, cracked or blued. Slight scores or cracks may be removed by re-surfacing. Do not reduce the thickness by more than 0.015 in. (0.38 mm).
8. Fit pressure plate into cover and check that the clearance between the three lugs and their respective slots is sufficient to give cover 0.006 to 0.010 in. (0.15 to 0.25 mm) total side play on the pressure plate. If not, increase the clearance by filing cover slots.
9. Check the condition of separator plate. If it is only worn on the transmission side, further life may be obtained by reversing it. If badly cracked or blued it should be replaced as the maximum which can be removed by re-surfacing is 0.015 in. (0.38 mm) per side.

NOTE: It is inadvisable to re-use clutch springs if any re-surfacing of pressure or separator plate has been carried out. New springs and insulating washers should be fitted to ensure the clutch clamping load is maintained.

Check that separator plate is a sliding fit in flywheel; a tight plate will cause the PTO drive plate to spin and a slack plate may rattle when pedal is fully depressed. Separator plate rattle is not, however, detrimental to the operation of clutch.

10. Check the three push-off springs in flywheel and renew if necessary. These should be of equal length.
11. Examine driven plates (see Page 24) and check that the plates slide freely on shaft splines.

Assembling and Setting Clutch Unit

1. Place baseplate 912917 on bench and clean the face.

2. Screw long studs into appropriate holes in base plate; the screws have a screwdriver slot at one end for this purpose.
3. Screw pillar adaptor (912723) into centre of baseplate and place three Code 14 spacers on baseplate equally spaced and positioned so that pressure plate will rest on them. Fit a cover spacer (912724) on each stud so that when stud nuts are tightened the spacers will be clamped between cover flange and baseplate.
4. Fit pressure plate on top of spacers and lightly coat lugs with anti-scuffing paste. Fit plungers (also lightly coated with anti-scuffing paste), springs and spring insulating washers, spring covers and then the cover. Tighten down cover using long studs and nuts. Check that all identification marks made when dismantling are aligned and tighten nuts progressively and by diametrical selection to avoid distorting cover.
5. Fit release levers.
6. Screw actuator into adaptor and depress handle about twelve times to settle release mechanism. This is essential, otherwise the release lever setting may change when clutch is put into operation. It is also important to bear in mind that the purpose of this is to operate release levers in their normal working position, and actuator must only be screwed into adaptor far enough to bring the handle horizontal. If actuator is screwed fully into adaptor and handle operated in an almost vertical position, damage to actuator may occur.
7. Remove actuator and fit centre pillar in its place. Place the spacer (Code 8) and a Laycock adaptor spacer 962577, on centre pillar with the recess downwards, and then fit setting finger.
8. Set release levers with adjuster screws K, Fig. 16, to finger height. The height of adjuster screws must be alike. Operate clutch again with actuator lever and recheck height. The release levers should be held down firmly by hand so that roller is in contact with plunger.
9. Refit release lever anti-rattle springs. These are of double coil type and can be easily fitted by hand. The tails of spring fit in the two anchor holes in cover, the hoop of spring fits over lever and the two eyes mount on release lever pivot pin.
10. Fit the three adjusting screws and nuts into release levers and set them to a clearance of 0.048 in. (1.22 mm). (*NOTE that this clearance must not be altered after clutch is assembled on tractor flywheel as due allowance has been made for the use of Borg & Beck equipment when setting the Laycock clutch.*)




Figure 17.

FITTING TRANSIT BLOCK TO LAYCOCK CLUTCH

A. Lever

B. Transit block

11. Before removing clutch from baseplate, replace transit blocks — $\frac{3}{8}$ in. \times $\frac{1}{2}$ in. \times 2 in. (2.38 \times 12.7 \times 50.8 mm) — between cover and pressure plate at the heel of release levers to prevent thrust springs expanding too far as shown in Fig. 17.

Driven Plates: When fitting the driven plates it is essential that the flanged side of plate hub faces towards flywheel. On new Borglite plate the appropriate facing will be stamped "Flywheel this Side" in red.

If for service purposes it is necessary to fit a Borg & Beck transmission drive plate, the clearance of release lever adjusting screws on baseplate must be set to 0.057 in. (1.447 mm) because the Borg & Beck drive plate is thicker than the Laycock plate.

DUAL CLUTCH — 1200 LIVEDRIVE TRACTORS

Operation: The dual clutch fitted in 1200 Livedrive Tractors has two 11 in. (27.9 cm) diameter plates assembled into a single unit but each fitted with its own release mechanism. The transmission clutch is controlled by a foot pedal and the power take-off clutch controlled by a hand lever. Each clutch can therefore be disengaged, or engaged, independently of the other clutch. (Fig. 18.)

The power take-off hand lever is fitted with a catch so that the lever can be locked in the disengaged position for temporarily disengaging drive to power-driven implements. The lever should not, however, remain in the disengaged position for long periods as this would place unnecessary strain on the release mechanism. Always put the power take-off gear lever in neutral and engage the power take-off clutch when not using the power take-off.




Figure 18. SECTIONAL ARRANGEMENT OF DUAL CLUTCH

- | | |
|--------------------|-----------------------|
| A. Driven plate | } Transmission clutch |
| B. Pressure plate | |
| C. Release lever | |
| D. Release bearing | |
| E. Support snout | |

- | | |
|--------------------|--------------|
| F. Driven plate | } PTO clutch |
| G. Pressure plate | |
| H. Release lever | |
| J. Release bearing | |
| K. Driveshaft | |

Adjustments: As the clutch facings wear during service the amount of free-play in the operating linkage will be reduced and the maintaining of sufficient free-play is the only adjustment required in the field.

Failure to maintain sufficient free-play in either the transmission or power take-off clutch linkage will cause premature wear of the release mechanism and ultimate clutch failure.

Transmission Clutch Adjustment: If the pedal free-play is less than $\frac{1}{2}$ in. (12 mm) release the locknut and unscrew the adjusting nut, to lengthen the rod, until the free-play is increased to $\frac{3}{4}$ –1 in. (1.9–2.5 cm) then tighten the locknut. (Fig. 19.)

Power Take-off Clutch Adjustment: The power take-off lever should have $1\frac{1}{2}$ in. (3.2 cm)

free-play when in the forward — engaged — position, and to increase the amount of free-play release the locknut and unscrew the adjusting nut to lengthen the rod then tighten the locknut.

When adjusting the power take-off clutch always check that the hand lever return spring has sufficient tension to hold the rod fully forward when in the engaged position. If necessary renew the pull-off spring, or fit an additional spring, to hold the lever firmly against the front of the slot. *Failure to carry out this check may result in premature wear of the release mechanism.*

Servicing the Clutch Unit

To service the dual clutch unit it is necessary to use either a baseplate kit or a flywheel kit of Service Tools. (See Page 40.)

Figure 19. CLUTCH LINKAGE — 1200 TRACTORS

- | | |
|----------------------------------|-----------------------|
| A. Free play | } Transmission clutch |
| B. Connecting rod | |
| C. Adjusting nut | |
| D. Adjusting screw — clutch stop | |
| E. Free play | } PTO clutch |
| F. Connecting rod | |
| G. Adjusting nut | |





Figure 20.

PLACING DUAL CLUTCH ON BASEPLATE

- | |
|--------------|
| A. Studs |
| B. Baseplate |
| C. Spacer |




Dismantling the Clutch:

1. Screw the nine special long bolts in the appropriate holes in baseplate, tighten firmly and lightly smear the long threaded portion with anti-scuffing paste.
2. Place three Code 3 spacers, evenly spaced, on the baseplate. Slide clutch assembly on the bolts and position the three spacers so that they are adjacent to the three PTO pressure-plate toggle lugs. (Fig. 20.) Fit a flat washer and nut on each bolt. Tighten the nuts evenly, and by diametrical selection, until clutch and baseplate are clamped firmly together.
3. To maintain balance when re-assembled mark the following components (a felt-tipped pen is ideal for this purpose): PTO and main

Figure 21.
REMOVING RETAINING
STAPLES

- A. Actuator
B. Adaptor plate



drive covers, pressure plate lugs and release levers, PTO cover yokes and release levers, main drive cover and pressure plate

4. Screw the long centre pillar adaptor into baseplate and screw actuator into adaptor. Using actuator to depress PTO release levers, remove the three retaining staples then unscrew actuator. (Fig. 21.)
5. Remove clevis pins from the ends of all release levers and remove transmission release levers from cover. Remove the six short bolts attaching cover to main housing.
6. Remove nuts from the nine long bolts. Unscrew nuts evenly, and by diametrical selection, until the thrust springs are fully expanded, then dismantle clutch from baseplate. (Fig. 22.)

Inspection of Parts

Examine all parts after cleaning, paying special attention to the following:

Transmission and PTO Pressure Plates and Separator Housing: The friction surfaces must be smooth and free from blueing or cracks and the pivot points not excessively worn. The friction surfaces may be reground provided that not more than 0.015 in. (0.38 mm) of metal is removed from any one face. Excessive removal of metal will reduce pressure and affect clutch operation.

Separator Housing Bearing: Renew bearing if it is tight, affected by dust, or if the lubricant has dried out.




Figure 22. DISMANTLING CLUTCH

- A. Separator housing B. PTO toggles
C. Cover assembly

Thrust Springs: Renew springs that are rusted, damaged or weak. As the free length varies, even on new springs, the use of a spring tester is recommended. (See Page 50.)

Spring colour	Transmission Dark blue/ light green	Power Take-off Red
Minimum load	130 lb (58 kg)	131 lb (59 kg)
Checking length	1.69 in. (43 mm)	1.41 in. (36 mm)

Renew springs whose load is below the minimum. Some early clutches were fitted with lavender/black springs on the transmission plate and these should be replaced by a set of dark blue/light green springs.

Insulating Washers: Renew any broken, or damaged, insulating washers. Fix any loose washers in place on the housing with adhesive.

Transmission Cover: Renew if release lever pivots are distorted or loose. Place the pressure plate inside the cover, assembly marks aligned, to ensure plate lugs slide freely through cover holes. File plate lugs if there is insufficient clearance.

Release Levers: Damaged or worn levers should be renewed, together with any bent or worn pivot pins.

Release Lever Springs: Check thickness of transmission release lever springs and if they are 0.104 in. (2.64 mm) diameter replace these with stronger springs, Part No. 923989, which are 0.128 in. (3.25 mm) thick.

Release Lever Adjusting Screws: If hexagonal-headed adjusting screws are fitted in the transmission release levers, replace these with socket-headed screws, Part No. 923990, which are lighter. If lighter screws are not available reduce the




Figure 23. PTO CLUTCH TOGGLE LEVERS

- A. Early toggle, $\frac{1}{8}$ UNF threads
- B. Later toggle, $\frac{3}{8}$ UNF threads

weight of the original screws, by sawing off the hexagon head and cutting a screwdriver slot in the screw end.

Release Lever Plates: Renew these if they are worn on the surface or lever tip register.

Release Lever Toggles: If the PTO lever toggles are being renewed ensure that the correct toggles are being used. A number of early clutches were fitted with $\frac{1}{8}$ UNF toggles and these must not be replaced by $\frac{3}{8}$ UNF toggles, which are thicker and would not operate freely. (Fig. 23.)




Figure 24. ASSEMBLING PTO PRESSURE PLATE

Assembly and Setting

1. Clean and dry all clutch components, baseplate and spacers. Check that adaptors screw freely into baseplate and lightly lubricate threads.
2. Place Code 3 spacers on baseplate and place PTO pressure plate on spacers; position plate so the spacers are adjacent to plate lugs. (Fig. 24.) Fit red springs on pressure plate and, after smearing plate lugs with anti-scuffing paste, place separator housing in position. Align the assembly marks and ensure that no insulating washers fall out as the housing is inverted. (Fig. 25.)




Figure 25. FITTING SEPARATOR HOUSING.

An alternative method of assembling PTO pressure plate is to lay separator housing on bench, fit thrust springs and pressure plate in housing then turn assembly over whilst holding housing and plate together and place on baseplate.

3. Place three Code 13 spacers on friction surface of separator housing then fit transmission pressure plate on the spacers. Position pressure plate so that assembly marks are aligned and place the spacers below plate lugs. Temporarily fit cover to ensure pressure plate is centralised on housing.




Figure 26. ASSEMBLING TRANSMISSION CLUTCH

4. Fit the dark blue/light green thrust springs on pressure plate and, after lightly smearing the inside of cover apertures with anti-scuffing paste, align assembly marks and place cover over springs, taking care that the cover does not bind on the pressure plate lugs. Screw a nut, with a flat washer underneath, on each of the nine long bolts. Tighten nuts evenly and by diametrical selection, until the assembly is clamped firmly against baseplate. Replace and fully tighten the short bolts attaching cover to separator housing. (Fig. 26.)

5. Fit transmission release levers and retaining springs. Smear pivot pins and contact points of release levers with anti-scuffing paste and take care not to overstretch the springs. Secure the pivot pins with split pins. Fit release lever plate and retain in position by fitting split pins: the small leaf spring in end of lever must be pressed in towards lever and the split pin fitted underneath it, so that the plate is held against the lever tips.
6. Fit PTO release lever but do not fit split pins in lever pivot pins. Temporarily fit the release lever plate on ends of lever.
7. Screw the short adaptor into baseplate and screw actuator into adaptor. Do not screw actuator too far into adaptor but screw it in so that when actuator lever is horizontal the release lever plate is depressed $\frac{1}{8}$ in. (3.2 mm). Operate actuator handle rapidly about a dozen times: this is essential to settle the moving parts, otherwise the lever settings will change when the clutch is used.




Figure 27.

SETTING TRANSMISSION RELEASE LEVER HEIGHT

8. Remove actuator and screw centre pillar firmly into adaptor. Place a spacer, Code 16X (some early spacers were marked "Code 16" only), on centre pillar — recess in spacer towards adaptor. Fit short setting finger on centre pillar and set adjusting screws on transmission levers so that when finger is rotated whilst being held firmly and squarely against spacer, it just touches lever plate all the way round. (Fig. 27.) When the levers are correctly set, hold screws stationary and firmly tighten locknuts.




Figure 28. SETTING PTO RELEASE LEVER HEIGHT

9. Remove gauge finger and centre pillar. Screw actuator into adaptor and repeat Operation 7; then refit spacer and gauge finger to recheck lever adjustment. Reset lever screws if necessary, but ensure that locknuts are fully tightened.
10. Remove short adaptor from baseplate and screw long adaptor in its place. Fit circular plate on actuator and screw actuator into adaptor until the release lever plate is pushed down $\frac{1}{8}$ in. (3.2 mm) when the lever is horizontal. Operate actuator rapidly about a dozen times: this is essential to settle the moving parts and ensure the lever setting does not alter when clutch is used.
11. Remove actuator, screw centre pillar into adaptor and fit spacer, Code 16X (some early spacers were marked "Code 16" only), on pillar — recess in spacer towards adaptor. Fit the long setting finger on centre pillar and set the three toggles so that when setting finger is rotated, whilst being held firmly and squarely against spacer, it just touches the lever plate all the way round. (Fig. 28.) When the lever setting is correct, lock toggles by firmly tightening all six locknuts.
12. Remove gauge and centre pillar. Screw actuator, with plate, into adaptor and operate actuator a dozen times, as described in Operation 10, then replace spacer and gauge to recheck lever setting. Reset toggles if necessary, but ensure that all locknuts are fully tightened.
13. Remove PTO release lever plate and withdraw lever pivot pins, so that levers and toggles can be swung outwards clear of clutch. Make three stiff wire staples, similar to the PTO retaining staples but shorter, and hook these over the transmission levers, so that when the cover is removed from separator housing the staples will prevent thrust springs pushing levers away from cover.




Figure 29. TWIN-PLATE CLUTCH

- | | | |
|------------------|----------------------------|----------------------|
| A. Flywheel | B. Separator plate | C. Pressure plate |
| D. Driven plates | E. Driveshaft | F. Thrust springs |
| G. Release lever | H. Release bearing | J. Spring — flywheel |
| | K. Spring — pressure plate | |

14. Remove short bolts from cover then unscrew nuts from long bolts evenly until spring tension is released. Lift cover from separator housing and remove spacers, centre pillar and adaptor. Place transmission driven plate on separator housing — side marked "Flywheel" towards housing — then refit cover assembly. Use pilot tool (Fig. 44), or a clutch driveshaft, to align driven plate with separator housing bearing and fit three nuts, *with flat washers underneath*, spaced evenly round the housing. Tighten the three nuts evenly to clamp cover down, then replace and firmly tighten the six short cover bolts.

15. Remove staples from transmission levers, refit PTO release levers and release plate. Fit

retaining staples on PTO levers, check that all split pins are securely locked, then remove the three nuts and lift from baseplate.

TWIN-PLATE CLUTCH

The twin-plate clutch is an optional fitting on 880 and 990 Non-Livedrive Tractors and is of similar construction to the Livedrive clutch but has both inner and outer driven plates mounted on the same driveshaft. The clutch therefore functions as a single clutch but the twin plates give it twice the facing area of a single plate unit.

Adjustment: Clutch pedal adjustment is by means of the adjusting screw on the cross shaft operating lever (Fig. 6) and this should be set to

give 1 to 1½ in. (2.5 to 3.8 cm) free-play. As no intermediate stage is required, the pedal roller has no eccentric adjustment and the cross shaft lever is not equipped with two angled faces. The maintaining of sufficient free-play is the only adjustment normally required during service.

On early clutches there are three adjusting screws on the inner cover — the screws used for PTO clutch adjustment on the Livedrive clutch and shown in Fig. 6 — and if the driven plates fail to stop when the pedal is fully depressed, this may be caused by excessive clearance between the screws and pressure plate. To set the adjusting screws, remove vent cover from clutch housing and turn engine so that one of the screws is opposite cover aperture. Release locknut, insert a 0.050 in. (1.27 mm) feeler gauge through hole in clutch cover and between screw end and pressure plate. After adjusting screw so that it just holds feeler gauge, hold screw stationary and firmly tighten locknut. Turn engine and adjust the two remaining screws in the same manner. Ensure that the locknuts are fully tightened before replacing cover.

Servicing the Twin-Plate Clutch

1. To ensure re-assembly of parts in the same relative position, mark the pressure plate, release levers and covers (a felt-tipped pen is ideal for this purpose).
2. Screw long studs into appropriate holes in clutch tool baseplate, using screwdriver slots in studs. Fit a cover spacer (912724) on each stud and place three spacers, Code 17X, on baseplate — equally spaced and positioned so that the pressure plate will rest on them. Slide clutch assembly on studs. Fit nuts on studs and tighten down evenly, and by diametrical selection, until the clutch is clamped firmly against baseplate.
3. Remove release lever thrust plate and if clutch is fitted with an inner cover, remove the three inner cover adjusting screws.
4. Remove split pins from release lever fulcrum pins. Withdraw pins and remove anti-rattle springs and release levers.
5. If required, extract pin securing roller bearing in each release lever, preparing to catch the 19 needle rollers as each pin is removed.
6. Evenly, and by diametrical selection, unscrew nuts from the long studs until thrust springs are released then remove cover and separate the various parts.

Checking the Clutch Parts

Examine all parts after cleaning, paying special attention to the following:

Release Levers: Renew if flats are worn on tips of fulcrum points. If necessary, fit new roller assemblies and lubricate with anti-scutting paste.

Cover Bearing: Renew if bearing is tight or dry. When fitting a new bearing ensure that it is a sliding fit in housing. If necessary scrape out the housing until bearing can be pushed freely into position.

Thrust Springs: Renew any springs that are weak, damaged or rusty. As the free-length varies, even on new springs, the use of a spring tester is recommended. (Page 50.)

Pressure Plate: If surface is cracked, blued or badly scored renew. If slightly scored the surface may be refaced provided that not more than 0.015 in. (0.38 mm) of metal is removed.

If a new pressure plate is fitted it is recommended that the latest type plate (962573) and three springs (625232) are fitted. The clutch can then be converted to the latest type unit by discarding the inner cover and fitting two new driven plates (928288). (Fig. 29.)

Separator Plate: If plate is cracked, blued or badly scored it should be renewed. If slightly scored the surfaces may be reground if thickness of plate is not reduced by more than 0.030 in. (0.75 mm). Also check that plate is a free sliding fit in the flywheel teeth: a tight plate will cause clutch drag and a very slack plate may rattle when the pedal is fully depressed, although separator plate rattle is not detrimental to clutch operation.

Covers: Fit pressure plate into cover and check that release lever lugs have sufficient clearance to allow 0.006 to 0.012 in. (0.15 to 0.30 mm) movement of cover; if not, file cover slots, where required, to increase clearance. On early clutches with an inner cover also check that the adjusting screw inserts are in good condition; renew these if necessary (see Page 10).

Separator Plate Springs: Clean out the three holes in flywheel and check springs. Clutches without inner cover also have three compression springs in pressure plate and it is important that these operate freely, otherwise clutch will spin when disengaged.

Driven Plates: Examine drive plates (see Page 24) and check that plates slide freely on shaft splines.

Assembling and Setting a Twin-Plate Clutch

1. Place baseplate (Service Tool 961696) on bench and clean face. Screw long studs into appropriate holes in baseplate, using screwdriver slot in stud ends. Screw adaptor (912723) into centre of baseplate and place a cover spacer (912724) on each stud.




Figure 30. SETTING RELEASE LEVER HEIGHT

A. Baseplate	B. Spacer — cover	C. Studs
D. Spacer — pressure plate	E. Adaptor — centre pillar	F. Spacer — centre pillar
G. Centre pillar	H. Setting finger	J. Release lever
	K. Adjuster pad	

- Position three spacers, Code 17X, on baseplate and fit pressure plate on top of spacers: ensure that spacers are equally spaced under pressure plate and plate is central with studs.
- Lightly smear pressure plate lugs with anti-scuffing paste and place thrust springs in position. If the clutch incorporates an inner cover, replace this and the six light springs. Replace outer cover and fit a nut on each baseplate stud. Check that assembly marks are aligned then tighten nuts down, evenly and by diametrical selection, until cover is firmly clamped against spacers on stud.
- Replace release levers, but not lever plates, and screw actuator into adaptor. Do not screw actuator too far into adaptor: screw it in so that when actuator lever is horizontal the release lever tips are depressed $\frac{1}{8}$ in. (3.2 mm). Operate actuator rapidly about a dozen times to settle working parts. This is essential otherwise release lever setting may change when clutch is put into operation.
- Remove actuator and screw centre pillar into adaptor. Place the appropriate spacer, Code 8 if early 10/10 clutch but Code 16X if a 10/10 clutch, on the centre pillar — recess in spacer downwards — then fit checking finger. Set release levers, by shimming adjuster pads, so that lever tips are within 0.002 in. (0.05 mm) of gauge finger. Hold levers down firmly by hand when checking height setting and use a feeler gauge to measure the clearance between lever and gauge finger: a 0.001 in. variation in shim thickness gives 0.0045 in. variation at lever tip. (Fig. 30.)
Shims for release lever roller pads:

0.002 in. thick	Part No. 900258
0.003 in. thick	Part No. 901723
0.010 in. thick	Part No. 904138
0.020 in. thick	Part No. 904193
- Remove gauge, spacer and centre pillar. Screw actuator into adaptor, as in Operation 4, and operate actuator rapidly a dozen times. Remove actuator, refit centre pillar, spacer and gauge finger, then recheck that all release levers are correctly set. Re-adjust if necessary, ensuring that adjuster pad screws are firmly tightened.
- Fit anti-rattle springs on release levers: these are quite strong and the easiest way of fitting them is to make a simple lever as shown in Fig. 14. If the pins attaching release levers to pressure plate lugs are removed and springs fitted in position, the lever can be rested against cover bearing housing and used to push release lever outward against spring until retaining pin can be fitted. (Fig. 15.)
- If clutch incorporates an inner cover, replace the three adjusting screws and locknuts. Insert feeler gauge through cover holes and set screws so that they are 0.050 in. (1.270 mm) clear of pressure plate then firmly tighten locknuts. Note that these screws will require resetting when clutch is assembled in tractor.

9. Smear release lever tips with anti-scuffing paste then replace lever thrust plate and secure with spring clips. Fit a $\frac{1}{8}$ in. nut under outer end of each release lever, to prevent thrust springs expanding too far, then unscrew the stud nuts evenly and remove clutch from baseplate.

Refacing Driven Plates

To remove the old facings drill out the rivets using a $\frac{1}{2}$ in. (4 mm) diameter drill inserted through the clearance hole in the opposite side facing.

The open portion of the rivet readily centres the drill enabling a speedy and clear removal to be effected.




Figure 31. BORGLITE DRIVEN PLATE

A. Hub B. Disc C. Segment D. Facing E. Rivet

Driven Plates

An examination of the various driven plates will show that they are of either the rigid or the Borglite type. The Borglite type consists of a series of segments, set alternately concave and convex, riveted to a centre plate which is itself riveted to a splined hub. The facings are riveted to the segments, each rivet being attached to only one facing. The alternate hole in each facing is drilled to give access to the rivet securing the facing on the opposite side of the plate. It is important that the side of the plate marked "Flywheel" should always be fitted towards the flywheel.

The rigid type plate is a one-piece steel disc which is cut to form segments. The disc is riveted to a centre hub and the facings are connected to alternate segments, as described above for the Borglite plate.

As rigid plates have 24 facing rivets and Borglite plates have 40 facing rivets, facings are not interchangeable, but facings are available to suit either type of plate.

When the facings have been removed examine the plate carefully. If any signs of cracking are apparent, or if the hub is loose on the rivets or worn in the splines, a new plate complete with facings is required. Also check the plate for distortion and discard it if more than 0.015 in. (0.38 mm) out of true when spun on a mandrel between centres.

Place one of the new facings in position on the disc, noting that the convex side of the plate segments are against the rivet holes in the facing.

Insert hollow steel rivets with their heads against the metal disc segment and roll rivet shank securely against the facing counterbore: this is the opposite procedure to that used with brass rivets. If a rolling tool is not available a blunt-ended punch will prove satisfactory.

Insert brass rivets, with their heads in counter-bored holes in facing, and roll the shanks securely against plate disc. If a rolling tool is not available a blunt-ended punch will prove satisfactory.




Figure 32. CLUTCH STOP — 990/880/780 LIVEDRIVE TRACTORS

- | | | | |
|-----------------------|----------------------|---------------|---------------|
| A. Clutch pedal | B. Connecting link | C. Clevis pin | D. Lever |
| E. Adjusting screw | F. Operating lever | G. Coupling | H. Shaft |
| J. Compression spring | K. Stud | L. Fork | M. Anchor pin |
| N. Tension spring | O. Brake band | P. Locknuts | Q. Drum |
| | R. Clutch driveshaft | | |

Secure the opposite side facing in a similar manner, when it will be noted that counter-bored holes in one facing coincide with clearance holes in the other facing.

Clutch Stop

With the exception of 770 Tractors, all Livedrive models are fitted with a small brake band which operates on a drum on clutch driveshaft. When clutch pedal is depressed to disengage transmission clutch the band is tightened round the drum and stops shaft revolving, thus allowing gears to be engaged without noise or damage.

All Non-Livedrive Tractors and 770 Livedrive models have a spring-loaded friction pad attached to inside of gearbox cover. The pad is in permanent contact with the muff coupling and when clutch is disengaged the slight drag of the pad brings clutch driveshaft to a standstill. There is no adjustment or setting required and the only maintenance necessary

is examination of pad whenever gearbox top is removed.

Adjustment: The only external adjustment available is by means of the operating lever adjusting screw and this should be set so that when pedal is depressed sufficiently to take up all the free-play and operating lever is turned clockwise until brake-band touches drum — this only requires light hand pressure — head of adjusting screw is $\frac{1}{8}$ in. (1.6 mm) clear of operating lever or, on 1200 Tractors, pedal pin.

Examination: This should be carried out whenever gearbox cover is removed. Examine brake band lining and renew if more than half worn. New linings are $\frac{1}{8}$ in. (3.2 mm) thick and are bonded to the band. New linings should be soaked in oil before fitting.

Internal Setting (except 1200): Disconnect pedal linkage by removing clevis pin C (Fig. 32) from connecting link and check that long stud K is nearly flush with internal face of large fork-end L.




Figure 33. CLUTCH STOP — 1200 LIVEDRIVE TRACTORS

- | | | | |
|-----------------|--------------------|--------------------|-------------------|
| A. Clutch pedal | B. Operating lever | C. Adjusting screw | D. Fork |
| F. Stud | G. Return spring | H. Brake band | J. Adjusting nuts |
| | K. Muff coupling | | |

Adjust nuts at lower end of stud K so that spring J is compressed to a length of $2\frac{3}{4}$ in. (67.4 mm). Push anchor pin down and insert a 0.070 in. (1.78 mm) feeler gauge between pin and stop. Release anchor so that it holds feeler gauge then set locknuts P so that band is only just clear of drum. Withdraw feeler gauge, refit clevis pin and set lever adjusting screw E so that it is $\frac{1}{8}$ in. (1.6 mm) clear of operating lever when pedal is depressed to take up the free-play, and lever F is turned lightly clockwise until brake-band touches drum.

Internal Setting (1200 Tractors): Check the length of the compression spring E. (Fig. 33). This should be compressed to a length of $2\frac{3}{8}$ in. (60.3 mm) and is set by means of the adjusting nuts on stud F. Screw adjusting screw C fully into the operating lever B and release pedal so that it is in the fully engaged position. With clutch stop mechanism held in the "off" position by return spring G, tighten nuts J until clearance between band and drum is just eliminated — take care not to overtighten nuts — then unscrew nuts two full turns and lock firmly. This will give correct clearance between band and drum. Finally set adjusting screw C so that when pedal is depressed to take up free-play and operating lever B is pressed lightly down, so that band is touching drum, screw head is $\frac{1}{8}$ in. (1.6 mm) clear of pedal pin.

Before refitting gearbox cover, check that the lubricating oil pipe is positioned so that it directs oil

on to clutch-stop drum: the brake lining will wear rapidly if not lubricated.

Overload Release Withdrawal Mechanism (Hand Clutch)

Models 880 and 990 Tractors can be fitted with a clutch withdrawal mechanism which is operated by an overload release cable from the top link. The resetting lever (hand clutch lever) is mounted on the left-hand side of the rear axle casing and is normally retained in the rear (engaged) position by the catch engaging with the stud. (Fig. 34.)

When the catch lever is raised by the overload release cable, or tripped by hand, the catch releases the lever and allows the tension spring to draw the lever forward, thus disengaging the clutch.

On Livedrive tractors the hand clutch disengages the main drive clutch only, the power take-off and belt pulley remaining operative until disengaged by the clutch pedal.

Adjustment of the Hand Clutch

Resetting of the clutch pedal free-play by means of the adjustment bolt also resets the free-play in the hand clutch linkage. The setting of the hand clutch rod adjusting nut should, however, always be checked when the clutch is adjusted to ensure that the hand clutch linkage does not prevent the clutch




Figure 34. HAND CLUTCH LINKAGE

- | | | | |
|-------------------|----------------------|--------------------|------------------|
| A. Hand lever | B. Guide bracket | C. Support bracket | D. Trigger |
| E. Torsion spring | F. Locking pin | G. Tension spring | H. Anchor stud |
| J. Pivot bracket | K. Clevis pin | L. Connecting rod | M. Adjusting nut |
| | N. Cross shaft lever | | |

pedal from returning to the fully engaged position. When the clutch pedal is against the stop on the clutch housing, and the hand clutch lever is locked in the engaged position, the adjusting nut should be $\frac{1}{8}$ in. (1.5 mm) clear of the pin.




Figure 35.

GEARBOX COVER — 780/770/3800 TRACTORS

- A. Steering box oil bath B. Main frame bolt hole

Clutch Removal

770, 780 and 3800 Tractors: Clutch can be removed after the combined gearbox top and clutch housing has been removed. Procedure for Livedrive and Non-Livedrive differs on one point only — on Livedrive models the power take-off unit must be removed so that the PTO cardan shaft can be withdrawn clear of clutch.

1. Remove earth lead from battery terminal. Remove fuel tank with instrument panel attached to it. Disconnect throttle control from hand lever and drag link from drop arm. If tractor is fitted with power-assisted steering, tie steering ram to tractor frame to avoid straining pipes. Remove steering box, complete with column and wheel.
2. Disconnect wiring from starter and remove starter from clutch housing. Remove the two figure-of-eight spring clips which hold clutch fork to release bearing carrier; these are accessible through aperture on underside of main frame.
3. Remove gearbox cover — 17 bolts into main frame, five bolts into rear axle. Note that one of the main frame bolts is inside the steering box oil bath. (Fig. 35.)
4. On Livedrive models, drain transmission oil into a *clean* container, remove power take-




Figure 36. REMOVING OIL FILTER SWITCH ADAPTOR
A. PTO case B. Adaptor C. 'O' ring — adaptor

off unit and withdraw cardan shaft until it is clear of clutch.

Caution: Tractors with a hydraulic filter warning lamp have a switch for this lamp under the PTO unit and it is necessary to remove switch adaptor from PTO case before PTO unit can be withdrawn. (Fig. 36.)

5. Release circlip at front of muff coupling and slide coupling forward. Detach release bearing support snout from frame by removing the three fixing bolts. If tractor is fitted with a band type clutch stop, disconnect the band and remove stop assembly out of frame.
6. Remove bolts attaching clutch cover to flywheel, placing a $\frac{7}{8}$ in. nut under each release lever at the same time, to prevent the thrust springs expanding too far. Lift clutch and driveshaft assembly out of frame; raise cover first and follow with shaft.
7. Retain the three flywheel springs until required for assembly.

Clutch Replacement

770, 780 and 3800 Tractors: After servicing the clutch unit (see appropriate page) and checking the components with reference to the fault-finding information on Page 37, replace the clutch in reverse order to removal, main points to note being listed below.

1. Fit PTO plate with hub towards flywheel and separator plate with assembly marks aligned.
2. Place the three springs in flywheel holes. Assemble release bearing and support snout on shaft, fitting new 'O' ring in snout groove.
3. Fit driveshaft assembly in clutch cover and fit transmission driven plate on shaft — hub towards flywheel — then fit assembly on to flywheel. Line up dowel holes and replace

bolts, tightening evenly and by diametrical selection until fully tightened.

4. Check muff coupling end-float. This should be not less than 0.010 in. (0.25 mm) and may be increased by removing shims from behind rear end of coupling.
5. Before fitting gearbox cover, check that clutch cross shaft spring is correctly located against fork and casting and set clutch stop, if fitted. (See Page 25.)
6. Refit the figure-of-eight spring clips to clutch fork, working through the bottom of main frame.
7. When assembly is completed, adjust pedal free-play and if necessary reset pedal, or lever, on cross shaft splines. (See Page 7.) Adjust clutch stop, if fitted.

Removing Clutch — 880 and 990 Tractors

The most convenient method of removing the clutch depends on the tractor type. All Livedrive tractors are fitted with a band type clutch brake. On early tractors this prevented the muff coupling on six-speed tractors being slid far enough forward to clear the gearbox driveshaft. This means that the clutch must be removed by splitting the tractor — as on 12-speed models.

On later models a change was introduced reducing the width of the clutch-stop drum, allowing the clutch to be removed out of the top of main frame after the gearbox cover has been removed — as on Non-Livedrive models.

Clutch removal methods for different tractors are as below:

1. **Non-Livedrive 6-speed Tractors:** Remove gearbox and clutch cover and lift out the clutch — Method 'A'.
2. **Livedrive 6-speed Tractors:** Up to Serial Numbers 990/A/487806, 880/A/533604. Split the tractor and remove the clutch from the flywheel — Method 'B'.
3. **Livedrive 6-speed Tractors:** Serial Numbers 990/A/487807 onwards, 880/A/533604 onwards, 4600/900001 onwards. Remove the gearbox and clutch cover and lift out the clutch — Method 'A'.
4. **Livedrive 12-speed Tractors:** Split the tractor and remove the clutch from the flywheel — Method 'B'.

Removing Clutch Upwards — Method 'A'

1. Disconnect fuel pipes, wiring, and throttle and stop control linkages. On 990 tractors, remove throttle lever.
2. Remove fuel tank and instrument panel. Disconnect steering drop-arm.

3. On 990 Tractors only: Remove steering-box to obtain access to the bolt beneath it which passes through the spacer wedge and into the clutch housing.
4. Remove all gearbox cover fixing bolts (five through the rear axle) and lift cover off main frame. On 880 Tractors the gearbox cover and steering-box can be removed as a unit.
5. On 990 Tractors only: Disconnect the main lead and remove starter motor.
6. Slacken clutch free-play adjusting screw and remove clutch cover.
7. On Livedrive models only: Remove clutch stop brake band by disconnecting it at both ends. Release circlips locating the brake drum and slide the drum forwards to the support snout.
8. Release circlip retaining the muff coupling and slide coupling fully forwards. Do not disturb muff coupling end-float adjusting shims on gearbox drive shaft.
9. On Livedrive models remove PTO housing and withdraw PTO cardan shaft.
Caution: Tractors with a hydraulic filter warning lamp have a switch for this lamp under the PTO unit and it is necessary to remove switch adaptor from PTO case before PTO unit can be withdrawn. (Fig. 36.)
10. Detach support housing from main frame by unscrewing the three fixing bolts and remove the two spring clips securing cross-shaft fork to release bearing carrier.
11. On Non-Livedrive models, slide the support snout and clutch shaft away from flywheel until the clutch shaft is clear of flywheel spigot bearing.
12. Remove the bolts fixing clutch cover to flywheel, wedging a $\frac{7}{8}$ in. nut under each release lever as this is done. These nuts prevent the clutch thrust spring expanding too far and so assist removal.
13. Ease clutch cover assembly off its dowels and remove the clutch and shaft assembly complete from the main frame.
On Non-Livedrive tractors this can be done by lifting the rear of the clutch shaft until it is clear of the gearbox and then lifting the whole unit rearwards and upwards. On Livedrive tractors the rear of the clutch shaft must first be lowered into the main frame and the unit then lifted out, cover assembly first.
14. Mark the clutch cover, separator plate and flywheel to ensure replacement in the same relative positions. Retain the three push-off springs for reassembly.

Clutch Replacement — Method 'A'

The clutch should be replaced in the reverse order to removal, special attention being given to the following points.

1. Examine the flywheel spigot bearing and replace if necessary. Place a small quantity of high-melting-point grease in the cavity behind the bearing.

2. Check the fit of the drive plates on the clutch shaft. The plates should slide freely on the spline without excessive slackness. Fit the plates with the hub towards the flywheel. (Borglute plates — "Flywheel" mark to flywheel.)
3. Check that the separator teeth backlash is within the following limits:
10/10 in. double clutch—0.010 in. to 0.014 in.
11/10 in. double clutch—0.007 in. to 0.011 in.

If the tolerance is above that quoted, rattle may occur when the clutch is operated but if the tolerance is below that quoted then difficulty may be experienced in engaging the PTO gears, due to the PTO clutch dragging.

4. Refit clutch cover with dowel holes in alignment with dowels in flywheel. Tighten the bolts progressively and by diagonal selection to avoid distortion of cover.
5. Check that the clutch cross shaft is not binding in the main frame.
6. Check that PTO cardan shaft is straight. If bent more than 0.005 in. (0.127 mm) it may foul on the inside of the hollow-transmission shaft.
7. Check that the support snout bearing is a clearance fit on the clutch shaft. The bearing should have a radial clearance of 0.0015 in. (0.4 mm), 6-speed or 0.006 in. (0.15 mm) 12-speed.
8. Check the muff coupling end-float, 0.010 in.—0.040 in. (0.25 mm—1.01 mm).
9. On 990 Tractors the clutch housing and gearbox cover are bolted together to increase the effective depth of the main frame. To obtain a rigid attachment a taper wedge is fitted between the housing and the cover faces. After firmly bolting the clutch housing and gearbox cover in position — tightening the gearbox cover against the rear axle before tightening the cover-to-main-frame bolts — place the wedge in the gap between the two faces and push the bolts through the holes in gearbox cover. If the wedge is not tight in the gap when the bolts are screwed in loosely, push the wedge upwards and add shims so that when the bolts are tightened the housing and cover are bolted solidly together without being distorted.
10. When the replacement is completed, readjust the clutch free-play and clutch stop, if fitted.

Removing the Clutch by Splitting the Tractor — Method 'B'

As the engine and transmission units are heavy and require to be aligned carefully when being reassembled, this operation should be carried out with the tractor standing on firm, level ground.

Place a jack under the front end of rear main frame so that it can support the rear half of tractor when the front main frame is withdrawn. Place a block of wood between the jack and main frame and extend the jack so that it takes weight but does not lift the tractor. Drive two suitable wooden wedges between each side of the front extension and axle




Figure 37. 880 TRACTOR "SPLIT" FOR CLUTCH REMOVAL

A. Supporting wedge

B. Clutch assembly

C. Flywheel housing

beam, so that the engine unit will remain upright. The wedges should be of hard wood and approximately 5 in. (12.5 cm) long so that they can be driven firmly into position without any possibility of becoming dislodged. Place a trolley jack under the flywheel housing so that the engine unit can eventually be drawn forwards.

Procedure — Method 'B'

1. Disconnect throttle and stop control linkages.
2. On 990 Tractors remove the throttle lever.
3. Disconnect fuel pipes and wiring, and remove fuel tank and instrument panel.
4. Disconnect main lead and remove starter motor (990 only).
5. Disconnect steering drop-arm.
6. Remove the bolts attaching the clutch cover and rear main frame to front section of the tractor.
7. Draw the front half of tractor forwards until it is clear of clutch driveshaft. To avoid damaging the clutch plates or driveshafts adjust the two jacks so that the front and rear main frames are withdrawn squarely away from each other.
8. Fit a $\frac{7}{8}$ nut under each release lever and unbolt the clutch unit from the flywheel.
9. Mark the separator plate and withdraw it from flywheel. Retain the three push-off springs until required for assembly.

Replacing

1. Examine flywheel spigot bearing and replace if necessary. Place a small amount of high-melting-point grease in the cavity behind the bearing.
2. Place the three push-off springs into the holes in flywheel and fit driven plate in position (hub to flywheel).
3. Fit separator plate into flywheel with the markings aligned.
4. A mandrel, or pilot clutch shaft (see Fig. 38), will be required to centralise the driven plates as the clutch assembly is fitted to the flywheel. Insert this pilot shaft through the clutch cover bearing and fit transmission plate on to it (hub to flywheel side).
5. Bolt clutch assembly to flywheel, the end of the mandrel being located in the flywheel spigot bearing. Tighten bolts progressively and by diagonal selection to avoid distortion and then withdraw the mandrel.
6. Check that the adjusting screw clearances are 0.070 in. (1.8 mm) as these are more accessible when the tractor is split.
7. Check that clutch release mechanism is in order and that cross shaft is not binding in main frame. Fully release the pedal free-play adjustment.
8. Ensure that the PTO cardan shaft is engaged on the splines of the input shaft in the PTO




Figure 38. CLUTCH PLATE PILOT — LIVEDRIVE TRACTORS (EXCEPT 1200)

A. 0.874 in (22.20 mm)	B. 0.915 in (23.24 mm)	C. 1.420 in (36.07 mm)
D. 1.771 in (44.98 mm)	E. $\frac{3}{8}$ in (15.88 mm)	F. $1\frac{1}{2}$ in (38.10 mm)
G. $1\frac{1}{2}$ in (44.45 mm)	H. 5 in (127 mm)	J. $\frac{3}{8}$ in (9.5 mm) dia. hole
	K. $3\frac{1}{2}$ in (82.55 mm)	

- housing and also that it is pushed fully to the rear.
9. Clean the faces of the two halves of the tractor and push together. (It is essential that the two faces should be parallel and in line and two guide studs temporarily screwed into the main frame will assist aligning the two halves.) When the clutch driveshaft enters the cover, turn the engine so that the splines on the driven plates can be lined up with those on the driveshaft and cardan shaft.
10. When the two sections are together and have entered into the dowels, fit the bolts and fully tighten.
11. Refit starter and throttle lever on the 990 Tractor.
12. Replace fuel tank, reconnect fuel pipes, throttle and stop controls, and steering drop-arm.
13. Adjust pedal linkage as described on page 6, and clutch stop, if fitted.
4. Drain steering box oil, disconnect hand throttle and remove steering box, complete with column and wheel.
5. Drain transmission oil into *clean containers*, capacity approximately 10 gallons (45.4 litres).
6. Remove seat and support from rear axle case. Remove drawbar and lower links.
7. After removing sensing unit, remove the twelve bolts attaching PTO case to axle case then remove PTO unit so that cardan shaft can be withdrawn clear of clutch. (Fig. 39.)
8. Remove gearbox cover — five bolts into rear axle case, four bolts into clutch housing and 14 bolts into main frame (two of these are inside steering cavity). (Fig. 40.)
9. Remove clutch housing — three bolts into starter support plate and six into main frame. Place PTO clutch lever in "disengaged" position and hook three retaining staples, Part No. 962188, between the PTO release levers and cover, then unlock hand lever and allow the staples to hold the levers towards the clutch cover. (Fig. 21.)
10. Release circlip at front of muff coupling from its groove in driveshaft and if coupling is fitted with wedge-shaped plungers, remove these by lifting retaining clip to one side so that plungers may be extracted. As the two plungers are fitted the opposite way round, note which way each plunger chamfer is fitted.

Clutch Removal

1200 Tractors:

1. Remove bonnet top, grille and tool box. Disconnect battery and remove starter.
2. Disconnect drag link from drop arm. If tractor is fitted with power-assisted steering tie ram to tractor frame, to avoid straining pipes.
3. Unscrew engine speed indicator cable, disconnect fuel pipe and instrument panel wiring so that fuel tank and panel can be removed complete.




Figure 39.

PTO CARDAN SHAFT WITHDRAWN FROM CLUTCH

A. Rear axle case B. Cardan shaft

11. Fully unscrew adjusting nut on PTO clutch connecting rod and disconnect PTO release bearing carrier by removing the special bolt from one side and pivot pin from other side of cross shaft fork.
12. Unscrew adjusting nut on transmission connecting rod to end of thread and remove the three screws attaching support snout and clutch stop to main frame.

13. Remove the nine long bolts attaching clutch assembly to flywheel, but do not remove the short bolts attaching clutch cover to separator housing. Lift clutch unit, complete with driveshaft, release bearings and support snout, out of the tractor. Raise driveshaft first, then lift complete assembly upwards and rearwards.
14. Withdraw driveshaft from separator housing and remove release bearings, etc.

Refitting Clutch Unit

Before refitting clutch unit, first check the following:

1. Examine PTO clutch linkage; lubricate hand lever catch and pivot. Check that cross shaft operates quite freely in main frame. Examine release bearing, and renew if any signs of roughness are apparent. On later tractors the bearing housing is connected by a flexible tube to the cross shaft bearing grease passage so that the bearing is lubricated at the same time as the left-hand bearings. If the bearing does not have provision for being lubricated during service, ensure that it is packed with molybdenum disulphide, lithium based grease. If the pin on the right-hand side of the release bearing housing is only 2 in. (50.8 mm) long, replace this with a later type pin, Part No. 925323, which is 2½ in.




Figure 40. 1200 TRACTOR WITH CLUTCH HOUSING AND GEARBOX COVER REMOVED

A. Clutch assembly B. Transmission release fork C. PTO release fork
D. Support snout E. Muff coupling F. Bolts — clutch to flywheel




Figure 41. CLUTCH RELEASE MECHANISM — 1200 TRACTORS

A. Cross shaft	} Transmission clutch	D. Cross shaft	E. Fork
B. Fork		F. Bearing carrier	G. Friction washer
C. Sleeve		H. Special washer	J. Belleville washer

(57.1 mm) long and the additional length of thread will allow six Belleville washers to be fitted in place of a single washer fitted on earlier, shorter, pin. (Fig. 41.) Fit tabwasher (626399) on left-hand pivot pin.

2. Examine transmission clutch linkage: lubricate pedal pivot and ensure that pedal does not foul starter switch wire conduit. Check that cross shaft operates freely. Lubricate pins in cross shaft fork with anti-scuffing paste. Renew release bearing if rough or dry: if bearing is renewed, fit latest type bearing, Part No. 620112. Clean inside of bearing carrier, smear it with anti-scuffing paste and check that carrier slides freely on support snout.

Refit clutch in reverse order of removal, taking note of the following:

Lower clutch stop into tractor frame and fit driveshaft, complete with release bearings, support snout, circlip and muff coupling into clutch unit. Fit PTO driven plate in flywheel and lower complete assembly into position, taking care to locate the two release bearing carriers in their forks. Slide cardan shaft into the clutch until it passes through PTO driven plate and enters flywheel spigot bearing, then bolt clutch assembly to flywheel.

Bolt support snout and clutch stop to main frame, slide muff coupling on to gearbox mainshaft and slide circlip into driveshaft groove. Muff couplings without plungers can be fitted on any spline but couplings with plungers must be fitted

with plunger holes opposite chamfered splines on shafts, the plunger tapers will then be against a chamfer and not against a spline corner. As the plunger tapers must be towards the non-driving side of spline ensure that front plunger is fitted with taper on its leading side and taper on rear plunger towards its trailing side.

No undue force should be required when sliding coupling on to gearbox shaft and, when retaining circlip is in position, coupling should have 0.008 to 0.040 in. (0.20 to 0.01 mm) end-float. If necessary this can be increased by removing shims from rear end of coupling.

Connect PTO release bearing carrier to its fork, fitting six Belleville washers, plain washer and two friction washers as shown in Fig. 41. Tighten the Nyloc nut to compress Belleville washers then unscrew a half-turn.

Set clutch stop (see Page 26) before replacing gearbox cover. Smear new cover gaskets with grease, to hold them in position, then fit cover and tighten bolts down into main frame only sufficient to hold cover against main frame face. Fully tighten bolts through rear axle case then fully tighten cover-to-main-frame bolts. Place spacing wedge in gap between gearbox cover and clutch housing. If wedge is not tight, add shims until wedge is so tight it has to be driven in with a copper hammer. When the bolts are fully tightened, housing and cover will then be bolted solidly together without distortion.

After replacing steering box, refill with oil to level-plug and refill transmission with oil after fitting PTO unit.




Figure 42. 1200 TRACTOR "SPLIT" FOR CLUTCH REMOVAL

- A. Transmission cross shaft B. PTO cross shaft C. Transmission release bearing sleeve
D. Hydraulic pressure pipe E. Hydraulic pump inlet pipe

Ensure that both clutches have the correct amount of free-play. (See Page 16.)

Clutch Removal by Splitting Tractor

This is an alternative method of clutch removal but as the two halves of the tractor are very heavy it *must only be carried out in a workshop with a hard, level floor and if equipment capable of safely supporting the weight of the tractor is available.*

FAILURE TO OBSERVE THESE PRECAUTIONS MAY RESULT IN PERSONAL INJURY AND SERIOUS DAMAGE TO THE TRACTOR.

As it is necessary to centralise the PTO release mechanism very carefully when joining the two halves of tractor together, this method of clutch removal should be carried out by experienced personnel only.

1. With tractor standing on firm, level ground and with ample space round it, firmly apply hand brake.
2. Remove silencer, bonnet top and grille. Disconnect battery leads and remove toolbox.
3. Drain transmission oil into *clean containers*, capacity approximately 10 gal (45 litres).
4. Remove starter motor. Disconnect main wiring harness connectors under fuel tank and wiring to oil warning lamp switch.
5. Release guide tube wiring after disconnecting engine speed indicator cable. Disconnect fuel and leak-off pipes from tank.

6. Disconnect throttle and stop cables from injection pump, then remove cable bracket from pump.
7. Disconnect steering drag link from drop arm. If tractor is fitted with hydrostatic steering, disconnect the two flexible ram pipes, also all four pipes from the servo valve and pipes from pump to reservoir. The two large pipes may then be extracted forwards from under fuel tank.

CAUTION: It is essential that all pipes and connections are sealed against ingress of dirt, otherwise serious damage may occur when the system has been assembled.

8. Remove clutch pit cover. Place hand clutch lever in "disengaged" position and place a retaining staple, Part No. 962188, over each PTO release lever: it will be necessary to turn engine to bring release levers opposite cover aperture. Return hand lever to "engaged" position and check that staples are correctly positioned.
9. Remove adjusting nuts from PTO and transmission rods. Disconnect anchor from transmission cross shaft return spring. This anchor is hooked through a hole in the underside of the main frame, 6½ in. (16.5 cm) forward of main frame joint and 5 in. (12.7 cm) towards the left-hand side of the frame centre line.
10. Disconnect hydraulic pressure pipe at union underneath right-hand foot plate and disconnect pump inlet pipe from filter housing.




Figure 43.
TRANSMISSION RELEASE FORK - 1200 TRACTORS
A. Release fork B. Cross shaft C. Return spring

Pipe is sealed by an 'O' ring inside housing and on early tractors, where pipe was fitted directly into housing, the pipe should be removed and 3 in. (76.2 mm) cut off the housing end of pipe. Thoroughly clean inside of pipe after cutting. Connecting pipe (921796), hose (917126) and clips (621960) can be fitted during assembly.

11. Remove two centre bolts from main frame joint so that trolley-jack can be located under front frame, behind oil sump. Place an adjustable stand under rear of main frame joint and extend jack and stand so that they take weight but do not lift main frame.
12. Disconnect check chains, remove bolts

attaching drawbar frame to PTO and lower frame to ground. If more convenient, the drawbar can be completely removed.

13. Remove sensing unit from PTO case, then remove PTO unit from rear axle case. Withdraw cardan shaft: if coupling is not bolted to cardan shaft, insert a bolt through hole in shaft end so the shaft can be levered out until it is clear of clutch. (Fig. 39.)
14. Drive a wooden wedge between each side of main frame and front axle to hold front end of tractor vertical (Fig. 42). Remove bolts attaching clutch cover to engine and main frame and, after ensuring that stand and jack are supporting weight of frame, remove remaining front-to-rear main frame bolts.
15. With the aid of an assistant, carefully push front of tractor forward until there is a 3 to 4 in. (8 to 10 cm) gap in frame. Remove bolt attaching return spring lever to transmission cross shaft (Fig. 43) so that shaft can turn as main frames are moved further away. If release bearing is fitted with a lubrication pipe, disconnect this from side of main frame.
16. Withdraw front of tractor until clutch is accessible then remove the nine long cover bolts and lift clutch assembly from flywheel.

Replacing the Clutch

To ensure driven plates are centralised, and thus permit driveshafts to be engaged as the two halves of tractor are brought together, a pilot tool made to the dimensions shown in Fig. 44 is required.

Insert pilot through bearing in separator housing so that it centralises transmission plate then fit PTO driven plate on pilot and fit assembly on flywheel. Engage pilot in crankshaft spigot bearing and align cover and flywheel marks. Replace the nine long bolts and tighten evenly and by diametrical selection. Withdraw pilot when bolts have been firmly tightened.




Figure 44. CLUTCH PLATE PILOT — 1200 TRACTORS

A. 0.874 in (22.20 mm)	B. 0.915 in (23.24 mm)	C. 1.374 in (34.90 mm)
D. 1.420 in (36.07 mm)	E. $\frac{3}{4}$ in (19.05 mm)	F. $2\frac{1}{2}$ in (57.15 mm)
G. $1\frac{1}{2}$ in (38.10 mm)	H. 6 in (152.4 mm)	J. $\frac{3}{8}$ in (9.5 mm) dia. hole

Examination Before Building Tractor

Before commencing to assemble tractor, check the following:

1. Examine release bearings and renew if they show any signs of roughness or are dry. If transmission release bearing is renewed, fit the latest type bearing, Part No. 620112. Clean inside of bearing carrier and check that it slides freely on support snout.
2. If the PTO clutch fork pivot is the early type with only one Belleville washer, fit the latest type pin (925323) and six Belleville washers (626723) as shown in Fig. 41. Tighten the Nyloc nut until the Belleville washers are fully compressed then unscrew half-a-turn. Fit the latest type tabwasher (626399) on the left-hand pivot pin.
3. Check that both clutch cross shafts are quite free in their bearings. Lubricate pins on transmission fork with anti-scuffing paste.
4. Lubricate pedal pivot and check that pedal does not foul starter switch wire conduit. Lubricate hand lever catch and pivot. Check that lever pull-off spring has sufficient tension to hold lever fully forward; if necessary, replace the pull-off spring or fit an additional spring.

Assembling Tractor

1. Screw two $\frac{1}{2}$ UNC \times 6 in. (15 cm) guide studs into third hole down on each side of front main frame face. Bring the two halves of

tractor together until guide studs enter appropriate holes in rear main frame. Ensure slots in transmission bearing carrier are vertical and fork inserts are positioned so that they can enter slots when cross shaft is turned, then continue bringing main frames together until cross shaft can be turned and pins engaged in carrier slots. When the frames are only 3 to 4 in. (7.5 to 10.0 cm) apart examine release fork to make sure that pins are correctly engaged in carrier slots then replace bolt in return spring lever and connect PTO bearing lubrication pipe into left-hand side of main frame.

2. Push two halves of tractor to close the gap and allow a bolt to be fitted in each side of frame but *do not tighten bolts to force frames together*. It will probably be necessary to turn engine before driven plate can be engaged on clutch shaft splines.
3. Push cardan shaft through clutch until it passes through driven plate and into fly-wheel spigot bearing. If cardan shaft cannot be pushed into spigot bearing, connect linkage and disengage PTO clutch then push shaft in whilst turning it. Refit all main frame and clutch cover bolts and firmly tighten. Connect linkage and adjust. (See Page 16.)
4. Continue assembly of tractor in reverse order of dismantling. Fit new hydraulic oil filter, or wash if earlier gauze type, before filling transmission with oil. If original oil is being replaced, pour through a funnel with a fine strainer and do not replace the last gallon, which will have accumulated any sediment. If tractor is fitted with hydrostatic steering reconnect all pipes, fill with new fluid and then bleed and check system.

CLUTCH FAULT DIAGNOSIS

The most common causes of faulty clutch operation are summarised below for easy reference and if unsatisfactory operation is experienced the appropriate section should be consulted. When a clutch is removed for examination all the points applicable should be checked, because if the fault is due to more than one cause these must all be

rectified in order to obtain satisfactory operation.

Operating conditions can also have an effect on clutch operation and these should not be overlooked when investigating clutch problems. The most common causes of clutch failure are due to the operator riding the clutch pedal or not maintaining sufficient pedal free-play.

Livedrive Clutch

Transmission Clutch Slip

1. Insufficient pedal free-play.
2. Insufficient clearance in hand clutch linkage.
3. Cross shaft tight in its bearings.
4. Plate facings worn.
5. Plate facings contaminated with oil.
If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals. The gearbox oil can also leak along the inside of the clutch driveshaft if the felt seal is misplaced or damaged.
6. Thrust springs weak (see page 45 for checking details).
7. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the flywheel.
8. Spring cups in cover damaged, causing the cups to foul the spring coils and preventing the springs from exerting their full pressure.
9. Excessive material ground from separator plate, or pressure plate, causing reduction of spring pressure.

Power Take-off Clutch Slip

1. Incorrect adjustment of the three inner adjusting screws.
2. Worn or distorted linings.
3. Separator plate tight in flywheel.
4. Thrust springs weak (see page 45 for details).
5. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the drive plates.
6. Excessive material ground from separator plate causing reduction of spring pressure.
7. Spring cups in cover damaged, causing cups to foul the spring coils and preventing the springs from exerting their full pressure.

Transmission Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of hand clutch linkage.
3. Incorrect adjustment of inner cover adjusting screws and/or pedal roller eccentric.
4. Incorrectly adjusted clutch stop.
5. Plate facings dragging due to being contaminated with oil.
If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals. The gearbox oil can also leak along the inside of the clutch driveshaft if the felt seal is misplaced or damaged.
6. Incorrect release lever setting.
7. Wear in release mechanism: release lever ends, pivots or needle rollers.
8. Drive plate tight on clutch shaft splines.
9. Drive plate distorted: the plate should not be more than 0.015 in. (0.38 mm) out of true.
10. Driveshaft not revolving freely in cover bearing. This may be due to a seized or damaged bearing, but can also be caused by the bearing being distorted by the cover bore. The bearing must not be tight in the bore and if necessary the bore should be scraped out until the bearing can be pushed into place by hand. The bearing housing must also be concentric with the clutch cover and to check this it is necessary to remove and dismantle the clutch, then replace the cover assembly on the flywheel. Bearing bore run-out can then be checked with a dial gauge: if the total dial variation exceeds 0.004 in. (0.10 mm) correct by scraping the bore. A slight increase in bore diameter will not be detrimental.
11. Power take-off shaft fouling inside of clutch shaft. There should be no contact between the cardan shaft and driveshaft except by the felt sealing ring. Straighten the cardan shaft if it is more than 0.005 in. (0.13 mm) out of true when turned between the centres. Check the

inner bore of the clutch driveshaft: if the bore is marked cardan shaft is out of true.

12. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be radial clearance between the shaft and bearing, 0.0015 in. (0.04 mm) on 6-speed and 0.006 in. (0.15 mm) on 12-speed — and check the gearbox mountings: the gearbox is not mounted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".
13. Separator plate tapered across diameter. The plate should be completely flat with a maximum of 0.002 in. (0.05 mm) surface ripple.

Power Take-off Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of cover adjusting screws.
3. Drive plate facings bonded to flywheel, due to infrequent use. It is important that the power take-off clutch is disengaged periodically, to prevent any possibility of the facings adhering to the flywheel face.
4. Incorrect release lever height setting.
5. Distorted drive plate: the plate should not be more than 0.015 in. (0.38 mm) out of true.
6. Seized flywheel spigot bearing.
7. Insufficient clearance between separator plate and flywheel. The plate teeth backlash can be checked with a feeler gauge and should be 0.007–0.011 in. (0.18–0.28 mm) on a 990 clutch, or 0.010–0.014 in. (0.25–0.35 mm) on other clutches.

Dual Clutch

Transmission Clutch Slip

1. Insufficient pedal free-play.
2. Cross shaft tight in bearings
3. Release bearing housing tight on support snout.
4. Plate facings worn.
5. Plate facings contaminated with oil. If facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to over-filling or misplaced seals. Gearbox oil may also leak along inside of clutch drive shaft if heart-shaped seal is displaced or damaged.
6. Thrust springs weak (see Page 49 for checking details).
7. Pressure plate lugs binding in cover slots and preventing pressure plate being held tightly against separator housing.
8. Spring cup in cover damaged and causing cups to foul coils and prevent springs exerting full pressure.
9. Excessive material ground from pressure plate, causing reduction of spring pressure.

4. Pressure plate lugs binding in separator housing.
5. Release levers, or toggles, binding or fouling.
6. Worn plate facings.
7. Weak thrust springs (see Page 49 for checking details).

Transmission Clutch Drag

1. Incorrect free-play adjustment.
2. Incorrectly adjusted clutch stop.
3. Plate facings dragging due to being contaminated with oil. If facings are renewed because of oil contamination, the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling or displaced front seals. Gearbox oil can also leak along inside of clutch driveshaft if heart-shaped seal is displaced or damaged.
4. Incorrect release lever setting.
5. Wear in release mechanism, release lever ends or pivots.
6. Driven plate tight on shaft splines.
7. Driven plate distorted: plate should not be more than 0.015 in. (0.38 mm) out of true.
8. Driveshaft not revolving freely in separator housing bearing. This may be caused by a seized or damaged bearing, but can also be caused by bearing being tight in housing bore. The bearing must not be tight in bore

Power Take-Off Clutch Slip

1. Insufficient free-play in linkage.
2. Cross shaft tight in bearings.
3. Hand lever pivot seized.

and bore must be concentric. If bore variation exceeds 0.004 in. (0.10 mm) when checked with dial gauge, correct by scraping bore. A slight increase in bore diameter will not be detrimental.

9. Power take-off cardan shaft fouling inside of clutch driveshaft. There should be no contact between shafts, except by the sealing ring. Straighten cardan shaft if it is more than 0.005 in. (0.13 mm) out of true when turned between centres.
10. Muff coupling end-float or alignment: coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise clutch and gearbox shafts are not in line. If shafts are not in line, check clutch support snout bearing — there should be 0.0015 in. (0.04 mm) radial clearance be-

tween shaft and bearing — and check gearbox mountings: gearbox is not mounted rigidly in frame but should have not less than 0.012 in. (0.30 mm) "float" when gearbox cover is bolted down.

Power Take-Off Clutch Spin

1. Incorrect free-play in hand lever.
2. Driven plate facings bonded to flywheel due to infrequent use. It is important that PTO clutch is disengaged periodically, to prevent any possibility of facings adhering to flywheel face.
3. Incorrect release lever height setting.
4. Distorted driven plate: plate should be not more than 0.015 in. (0.38 mm) out of true.
5. Seized flywheel spigot bearing.

Single Clutch

Clutch Slip

1. Incorrect pedal free-play.
2. Incorrect adjustment of hand clutch linkage.
3. Cross shaft tight in its bearings.
4. Drive plate facings worn.
5. Drive plate facings contaminated with oil. If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.
6. Thrust springs weak (see page 45 for checking details).
7. Pressure plate lugs binding in cover slots and preventing plate from being held tightly against the flywheel.
8. Excessive material ground from pressure plate, causing reduced pressure of thrust springs.

Clutch Spin

1. Incorrect pedal free-play.
2. Incorrect release lever height setting.
3. Clutch stop friction pad worn.

4. Plate facings dragging due to being contaminated with oil. If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.
5. Drive plate distorted: plate should be not more than 0.015 in. (0.38 mm) out of true.
6. Drive plate hub tight on clutch shaft splines.
7. Worn release mechanism: release lever ends, pivots or eyebolts.
8. Seized flywheel spigot bearing.
9. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be 0.0015 in. (0.04 mm) radial clearance between the shaft and bearing — and check the gearbox mountings: the gearbox is not bolted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".

Twin Plate Clutch

Clutch Slip

1. Insufficient pedal free-play.
2. Cross shaft tight in its bearings.
3. Plate facings worn.
4. Plate facings contaminated with oil.

If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.

5. Thrust springs weak (see page 48 for checking details).
6. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the flywheel.
7. Spring cups in cover damaged, causing the cups to foul the spring coils and preventing the springs from exerting their full pressure.
8. Excessive material ground from separator plate, causing reduction of thrust spring pressure.

Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of inner cover adjusting screws.
3. Clutch stop friction pad worn.
4. Plate facings dragging due to being contaminated with oil.

If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling or misplaced seals.

5. Incorrect release lever setting.
6. Wear in release mechanism: release lever ends, pivots or needle rollers.
7. Driven plates tight on shaft splines.

8. Drive plates distorted. Plates should be not more than 0.015 in. (0.38 mm) out of true.
9. Driveshaft not revolving freely in cover bearing. This may be due to a seized or damaged bearing, but can also be caused by the bearing being distorted by the cover bore. The bearing must not be tight in the bore and if necessary the bore should be scraped out until the bearing can be pushed into place by hand. The bearing housing must also be concentric with the clutch cover and to check this it is necessary to remove and dismantle the clutch, then replace the cover assembly on the flywheel. Bearing bore run-out can then be checked with a dial gauge: if the total dial variation exceeds 0.004 in. (0.10 mm) correct by scraping the bore. A slight increase in bore diameter will not be detrimental.
10. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be 0.0015 in. (0.04 mm) radial clearance between the shaft end bearing — and check the gearbox mountings: the gearbox is not bolted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".
11. If a rear-mounted hydraulic pump, driven directly from the flywheel, is fitted, examine the driveshaft bore to ensure that it is not contacting the pump driveshaft.

CLUTCH SERVICE TOOLS

Baseplate Kits

Basic Baseplate Kit (No. 1) can be used for all Selectamatic Tractor clutches and the various spacers and adaptors, etc., required for different clutches are available in kits so that tool requirements can be matched to the actual range of clutches being serviced.

The list of Baseplate Kits shows the full range, and contents, of kits and the tractor models, and clutches, for which they are required.

As it is essential to use the correct adaptors and spacers, etc., the List of Setting Equipment shows spacers and adaptors to use for each clutch.

Flywheel Kits

An alternative method of setting a clutch unit is to use the tractor flywheel instead of a baseplate and kits of adaptors and spacers, etc., are available to enable clutch units to be serviced by this method.

The list of Flywheel Kits shows the full range, and contents, of kits and the tractor models and clutches for which they are required.

As it is essential to use the correct adaptors and spacers, etc., the list of Setting Equipment shows which adaptors and spacers to use for each clutch.

BASEPLATE KITS

Tractor	Clutch	Kit No. and Part No.	Contents of Kit			Remarks
			Part No.	Description	Qty	
All models	All types	Kit No. 1 961850	912917	baseplate	1	Basic baseplate Kit
			961845	centre pillar	1	
			961844	actuator	1	
			961846	setting finger, short	1	
			961086	stud, $\frac{3}{8}$ UNC x $3\frac{1}{2}$ in.	9	
			19472	washer, $\frac{3}{8}$ in.	9	
			607045	nut, $\frac{3}{8}$ UNC	9	
			602806	setscrew, $\frac{1}{8}$ UNC x $1\frac{1}{2}$ in.	6	
			961087	socket, $\frac{1}{8}$ AF (ED 562)	1	
			961697	code card	1	
			961847	operating instructions	1	
			961848	fibre box	1	
Livedrive models						
770, 780, 880	Borg and Beck 10/10 in.	Kit No. 2 961856	912723	adaptor — centre pillar	1	Used with Kit 1
			961853	spacer, Code 8 — centre pillar	1	
990	Borg and Beck 11/10 in.		908888	spacer, Code 16X — centre pillar	1	
			961855	spacer, Code 14 — pressure plate	3	
3800, 4600	Borg and Beck 10/10 in.		912724	spacer — cover to baseplate	9	
780, 880	Laycock 10/10 in.		962577	spacer — pillar adaptor	1	Used with Kits 1 and 2
1200	Borg and Beck 11/11 in.	Kit No. 7 962135	920203	setting finger, long	1	Used with Kits 1, 2 and 4
			920198	adaptor — centre pillar (PTO)	1	
			920199	adaptor — centre pillar (Trans.)	1	
			962139	spacer, Code 13 — pressure plate	3	
			920202	bolt, $\frac{3}{8}$ x $\frac{1}{8}$ UNC, special	9	
			920201	nut, $\frac{1}{8}$ UNC, special	9	
			920204	adaptor plate — actuator	1	
			962188	retaining staple	3	
			962147	socket (ED 500)	1	
			962220	code card	1	
			962138	operating instructions	1	
Non-Livedrive models — Single-plate clutch						
770	Borg and Beck 9 in.	Kit No. 4 961862	961857	spacer, Code 3 — pressure plate	4	Used with Kits 1 and 2
880	Borg and Beck 10 in.					
990	Borg and Beck 11 in.					
1200	Borg and Beck 12 in.					
Non-Livedrive models — Twin- plate clutch						
880	Borg and Beck 10/10 in.	Kit No. 3 961861	961843	spacer, Code 17X — pressure plate	3	Used with Kits 1 and 2
990	Borg and Beck 10/10 in.					
990	Borg and Beck 11/10 in.					

KITS FOR USE WITH FLYWHEELS

Tractor	Clutch	Kit No. and Part No.	Contents of Kit			Remarks
			Part No.	Description	Qty	
All models	All types	Kit No. 10 961886	961845 961844 961846 13179 961877 19472 19403 961864 961865 961088 961848	centre pillar actuator setting finger, short bolt, $\frac{3}{4}$ BSF x $3\frac{1}{2}$ in. stud, $\frac{3}{4}$ BSF x $3\frac{1}{2}$ in. washer, $\frac{3}{4}$ in. nut, $\frac{3}{4}$ BSF socket, $\frac{3}{4}$ BSF (ED 600) operating instructions code card fibre box	1 1 1 2 8 10 10 1 1 1 1	Basic flywheel kit
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	Kit No. 11 961870	961867 961868 961853 961859 961855 961869	adaptor, No. 1 — flywheel adaptor, No. 9 — centre pillar spacer, Code 8 — centre pillar spacer, Code 10 — separator plate spacer, Code 14 — pressure plate setting finger, short	1 1 1 3 3 1	Used with Kit 10
770 780 880 3800 4600	Borg and Beck 10/10 in.	Kit No. 14 961873	961873	adaptor, No. 2 — flywheel	1	Used with Kits 10, 11 and 12
780 880	Laycock 10/10 in.		962577	spacer — pillar adaptor	1	Used with Kits 10 and 11
990	Borg and Beck 11/10 in.	Kit No. 12 961871	908888 961086 607045 961087	spacer, Code 16X — centre pillar stud, $\frac{3}{4}$ UNC x $3\frac{1}{2}$ in. nut, $\frac{3}{4}$ UNC socket, $\frac{3}{4}$ AF (Ed 562)	1 9 9 1	Used with Kits 10 and 11
1200	Borg and Beck 11/11 in.	Kit No. 21 962137	920199 920198 962139 920203 920204 962188 920200 920201 962147 962138 962221	adaptor — centre pillar (Trans.) adaptor — centre pillar (PTO) spacer, Code 13 — pressure plate (Trans.) setting finger, long adaptor plate — actuator retaining staple stud, $\frac{3}{4}$ UNC x $5\frac{1}{2}$ in. nut, $\frac{3}{4}$ UNC socket (ED 500) operating instructions code card	1 1 3 1 1 3 9 9 1 1 1	Used with Kits 10, 11, 12, 14 and 19
Non-Livedrive models—Single-plate clutch 770	Borg and Beck 9 in.	Kit No. 18 961851	961858 602806	spacer, Code 11 — centre pillar setscrew, $\frac{3}{4}$ UNC x $1\frac{1}{2}$ in.	1 6	Used with Kits 10, 11, 15, 17
780 880 3800 4600	Borg and Beck 10 in.	Kit No. 17 961876	961876	adaptor, No. 4 — flywheel	1	Used with Kits 10 and 11
990	Borg and Beck 11 in.	Kit No. 19 908889	908889	spacer, Code 15X — centre pillar	1	Used with Kits 10 and 11
1200	Borg and Beck 12 in.	Kit No. 22 962448	962139 912724	spacer, Code 13 — pressure plate spacer — pressure plate	4 4	Used with Kits 10, 11, 14, 17
Non-Livedrive models — Twin-plate clutch 880 990 990	Borg and Beck 10/10 in. Borg and Beck 10/10 in. Borg and Beck 11/10 in.	Kit No. 13 961872	961855	spacer, Code 14 — separator plate	3	Used with Kits 10, 11 and 12

SETTING EQUIPMENT REQUIRED WHEN USING BASEPLATE

Tractor	Clutch type	Centre pillar spacer	Centre pillar adaptor	Pressure plate spacer	Cover spacer
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	Code 8 (961853)	912723	Code 14 (961855)	912724
780 880	Laycock 10/10 in.	Code 8 (961853)	912723 + 962577	Code 14 (961855)	912724
990	Borg and Beck 11/10 in.	Code 16X (908888)	912723	Code 14 (961855)	912724
1200	Borg and Beck 11/11 in.	Code 16X (908888)	920199 (Trans.) 920198 (PTO)	Code 13 (962139) Code 3 (961857)	none none
Non-Livedrive models — Single- plate clutch 770	Borg and Beck 9 in.	Code 8 (961853)	none	Code 3 (961857)	none
780 880 3800 4600	Borg and Beck 10 in.				
990	Borg and Beck 11 in.				
1200	Borg and Beck 12 in.	Code 16X (908888)	none	Code 3 (961857)	none
Non-Livedrive models — Twin- plate clutch 880	Borg and Beck 10/10 in.	Code 8 (961853)	912723	Code 17X (961843)	912724
880 990 990	Borg and Beck 10/10 in. Borg and Beck 10/10 in. Borg and Beck 11/10 in.	Code 16X (908888)	912723	Code 17X (961843)	912724

SETTING EQUIPMENT REQUIRED WHEN USING FLYWHEEL

Tractor	Clutch type	Flywheel adaptors	Centre pillar adaptor	Centre pillar spacer	Pressure plate spacers	
					Transmission	PTO
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	No. 1 (961867) and No. 2 (961873)	No. 9 (961868)	Code 8 (961853)	Code 14 (961855)	Code 10 (961859)
780 880	Laycock 10/10 in.	Nos. 1 and 2 (961867 and 961873)	No. 9 (961868) and 962577	Code 8 (961853)	Code 14 (961855)	Code 10 (961859)
990	Borg and Beck 11/10 in.	No. 1 (961867)	No. 9 (961868)	Code 16X (908888)	Code 14 (961855)	Code 10 (961859)
1200	Borg and Beck 11/11 in.	Nos. 1 and 2 (961867 and 961873)	920199 920198	Code 16X (908888) Code 16X (908888)	Code 13 (962139) —	Code 10 (961859)
Non-Livedrive models—Single- plate clutch 770	Borg and Beck 9 in.	Nos. 1 and 4 (961867 and 961876)	—	Code 11 (961858)	Code 3 (961857)	—
880 3800 4600	Borg and Beck 10 in.	Nos. 1, 2, 4 (961867, 961873 and 961876)	—	Code 8 (961853)	Code 3 (961857)	—
990	Borg and Beck 11 in.	Nos. 1 and 4 (961867 and 961876)	—	Code 15X (908889)	Code 3 (961857)	—
1200	Borg and Beck 12 in.	Nos. 1 and 2 (961867 and 961873)	No. 9 (961868)	Code 16X (908888)	Code 13 — 912724	—
Non-Livedrive models—Twin- plate clutch 880	Borg and Beck 10/10 in.	No. 1 (961867)	No. 9 (961868)	Code 8 (961853)	Code 14 (961855)	—
990 990	Borg and Beck 10/10 in. Borg and Beck 11/10 in.	No. 1 (961867)	No. 9 (961868)	Code 16X (908888)	Code 14 (961855)	—

DIMENSIONAL DATA

Double Clutch (Livedrive) — 770

Clutch type	Borg and Beck BB10/189C
Plate type and diameter (transmission)	Borglite, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.350 in (8.89 mm)
Plate type and diameter (PTO)	rigid, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.320 in (8.13 mm)
Number of springs (transmission)	9
Spring colour (inner transmission)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer transmission)	brown
Spring pressure (at checking length)	120–130 lb (54–58 kg)
Spring checking length	2.60 in (66.04 mm)
Number of springs (PTO)	6
Spring colour (PTO)	buff
Spring pressure (at checking length)	88–94 lb (39–42 kg)
Spring checking length	2.26 in (57.40 mm)
Separator plate thickness	0.705–0.700 in (17.90–17.78 mm)
Cover adjusting screw clearance	0.070 in (1.78 mm)
Pedal free-play	$\frac{1}{2}$ – $\frac{3}{4}$ in (13–19 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of the power take-off plate and 0.349 in. (8.865 mm) spacers in place of the transmission plate	3.345 in (84.96 mm)
Pedal pad height above footplate when free-play is taken up	$3\frac{1}{2}$ – $5\frac{1}{2}$ in (95.0–135.0 mm)

Single Clutch (Non-Livedrive) — 770

Clutch type	Borg and Beck BB9/273A
Plate type and diameter	Borglite, 9 in (22.86 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.330 in (8.38 mm)
Number of springs	12
Spring colour	black
Spring pressure (at checking length)	150–160 lb (67–69 kg)
Spring checking length	1.688 in (42.875 mm)
Pedal free-play	$\frac{1}{2}$ – $\frac{3}{4}$ in (13–19 mm)
Release lever height: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0.330 in. (8.382 mm) thick spacers in place of the driven plate	1.895 in (48.13 mm)
Pedal pad height above footplate when free play is taken up	$2\frac{1}{2}$ – $3\frac{1}{2}$ in (57.0–95.0 mm)

Double Clutch (Livedrive) — 880

Clutch type	Borg and Beck BB10/167E
Plate type and diameter (transmission)	Borglite, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.350 in (8.89 mm)
Plate type and diameter (PTO)	rigid, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.320 in (8.13 mm)
Number of springs (transmission)	12
Spring colour (inner transmission)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)

Spring checking length	2.60 in (66.04 mm)
Spring colour (outer transmission) .. .	brown
Spring pressure (at checking length) .. .	120-130 lb (54-58 kg)
Spring checking length	2.60 in (66.04 mm)
Number of springs (PTO)	6
Spring colour (PTO)	buff
Spring pressure (at checking length) .. .	88-94 lb (39-42 kg)
Spring checking length	2.26 in (57.40 mm)
Separator plate thickness	0.705-0.700 in (17.90-17.78 mm)
Cover adjusting screw clearance	0.070 in (1.78 mm)
Pedal free-play	1-1½ in (25.4-38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of the power take-off plate and 0.349 in. (8.865 mm) spacers in place of the transmission plate	3.345 in (84.96 mm)

Laycock double clutch (Livedrive) — alternative fitting 780 and 880

Clutch type	Laycock No. 83939
Plate type and diameter (transmission) .. .	Borglite 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.340 in (8.63 mm)
Plate type and diameter (PTO)	rigid, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.310 in (7.87 mm)
Number of springs	12
Spring colour	pale green
Spring pressure at checking length .. .	103-113 lb (46-51 kg)
Spring checking length	1.5 in (38.1 mm)
Spring overall diameter	0.840 in (21.34 mm)
Separator plate thickness	0.705-0.700 in (17.90-17.78 mm)
Cover adjusting screw clearance:	
clutch on baseplate	0.048 in (1.22 mm)
clutch on flywheel	0.057 in (1.447 mm)
Pedal free-play, 880	1-1½ in (25.4-38.0 mm)
Pedal free-play, 780	¾-1 in (19-25.4 mm)

Release lever height, i.e. distance from head of release lever adjusting screw to baseplate face when clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of transmission plate and 912724 spacers between cover flange and baseplate. This dimension also applies when clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of power take-off plate and 0.349 in. (8.865 mm) spacers in place of transmission plate

3.720 in (94.49 mm)

Single Clutch (Non-Livedrive) — 880

Clutch type	Borg and Beck 10A6G
Plate diameter	Borglite, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.330 in (8.38 mm)
Number of springs	12
Spring colour	light green
Spring pressure (at checking length) .. .	105-115 lb (47-52 kg)

Spring checking length	1.688 in (42.875 mm)
Pedal free-play	1-1½ in (25.4-38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0.330 in. (8.382 mm) thick spacers in place of the driven plate	1.955 in (49.53 mm)

Double Clutch (Livedrive) — 990

Clutch type	Borg and Beck BB11/180E
Plate type and diameter (transmission)	Borglite 11 in (27.44 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.350 (8.89 mm)
Plate type and diameter (PTO)	rigid, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.320 in (8.13 mm)
Number of springs (transmission)	12
Spring colour (inner-transmission)	brown
Spring pressure (at checking length)	80-85 lb (36-38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer transmission)	red
Spring pressure (at checking length)	140-150 lb (63-67 kg)
Spring checking length	2.60 in (66.04 mm)
Number of springs (PTO)	6
Spring colour (PTO)	pink
Spring pressure (at checking length)	113-121 lb (51-54 kg)
Spring checking length	2.23 in (57.40 mm)
Separator plate thickness	0.715-0.760 in (19.44-19.0 mm)
Cover adjusting screw clearance	0.070 in (1.78 mm)
Pedal free-play	1-1½ in (25.4-38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of the power take-off plate and 0.349 in. (8.865 mm) spacers in place of the transmission plate	3.445 in (87.5 mm)

Single Clutch (Non-Livedrive) — 990

Clutch type	Borg and Beck 11A6G
Plate type and diameter	Borglite 11 in (27.44 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.330 in (8.38 mm)
Number of springs	12
Spring colour	yellow/light green
Spring pressure (at checking length)	135-145 lb (61-65 kg)
Spring checking length	1.688 in (42.875 mm)
Pedal free-play	1-1½ in (25.4-38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0.330 in. (8.382 mm) thick spacers in place of the driven plate	1.955 in (49.53 mm)

Twin Plate Clutch — 880 (Early clutch with inner cover)

Clutch type	special twin plate
Plate diameter	10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.350 in (8.89 mm)

} outer
plate

Plate diameter	} inner plate	10 in (25.4 cm)
Plate thickness (new)		0.350 in (8.89 mm)
Plate facing material		Capasco F30C
Number of springs on pressure plate		12
Spring colour (inner)		brown
Spring pressure (at checking length)		80-85 lb (36-38 kg)
Spring checking length		2.60 in (66.04 mm)
Spring colour (outer)		brown
Spring pressure at (checking length)		120-130 lb (54-58 kg)
Spring checking length		2.60 in (66.04 mm)
Number of springs on inner cover		6
Identification		Part No. 625149
Spring pressure (at checking length)		10 lb (4.54 kg)
Spring checking length		2.25 in (57.15 mm)
Separator plate thickness		0.705-0.700 in (17.90-17.78 mm)
Cover adjusting screw clearance		0.050 in (1.270 mm)
Pedal free-play		1-1½ in (25.4-38.0 mm)

Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.389 in. (9.880 mm) spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates.

3.345 in (84.96 mm)

Twin Plate Clutch — 990 (Early clutch with inner cover)

Clutch type	special twin plate
Plate diameter	} outer plate	11 in (27.94 cm)
Plate facing material		Mintex H19
Plate thickness (new)		0.350 in (8.89 mm)
Plate diameter	} inner plate	10 in (25.4 cm)
Plate facing material		Capasco F30C
Plate thickness (new)		0.350 in (8.89 mm)
Number of springs on pressure plate		12
Spring colour (inner)		brown
Spring pressure (checking length)		80-85 lb (36-38 kg)
Spring checking length		2.60 in (66.04 mm)
Spring colour (outer)		brown
Spring pressure (checking length)		120-130 lb (54-58 kg)
Spring checking length		2.60 in (66.04 mm)
Number of springs on inner cover		6
Identification		Part No. 625149
Spring pressure (at checking length)		10 lb (4.54 kg)
Spring checking length		2.25 in (57.15 mm)
Separator plate thickness		0.765-0.760 in (19.43-19.30 mm)
Cover adjusting screw clearance		0.050 in (1.270 mm)
Pedal free-play		1-1½ in (25.4-38.0 mm)

Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.389 in. (9.880 mm) spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates.

3.445 in (87.5 mm)

Twin Plate Clutch — 990 and 880 (Later clutch without inner cover)

Clutch type	special twin plate
Plate diameter	10 in (25.4 cm)
Plate facing material	Thermoid 11046

Plate thickness (new)	0.350 in (8.89 mm)
Number of springs on pressure plate	12
Spring colour (inner)	brown
Spring pressure (at checking length)	80-85 lb (36-38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer)	red
Spring pressure (at checking length)	140-150 lb (63-67 kg)
Spring checking length	2.60 in (66.04 mm)
Separator plate thickness - 990	0.765-0.760 in (19.44-19.30 mm)
Separator plate thickness - 880	0.705-0.700 in (17.90-17.78 mm)
Pedal free-play	1-1½ in (25.4-38.0 mm)

Release lever height, i.e.: Distance from tips of release levers to base plate face when clutch is assembled with 0.389 in. (9.880 mm) spacers in place of drive plate and 912724 spacers between cover flange and baseplate. This dimension also applies when clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates

3.445 in (87.5 mm)

Dual Clutch (Livedrive) — 1200

Clutch type	Borg and Beck 49400
Plate type and diameter (transmission)	Borglite 11 in (27.94 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.340 in (8.64 mm)
Plate type and diameter (PTO)	rigid 11 in (27.94 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.324 in (8.23 mm)
Number of springs (transmission)	12
Spring colour	dark blue/light green
Spring pressure (at checking length)	130-140 lb (58-63 kg)
Spring checking length	1.69 in (42.92 mm)
Number of springs (PTO)	12
Spring colour	red
Spring pressure (at checking length)	131-140 lb (59-63 kg)
Spring checking length	1.41 in (35.81 mm)
Pedal free-play	¾ to 1 in (22 to 25 mm)
Hand lever free-play	1½ to 2½ in (48 to 54 mm)
Release lever height, i.e.: Distance from baseplate or flywheel face to	
transmission release lever plate	5.385-5.215 in (136.78-132.46 mm)
PTO release lever plate	6.37-6.27 in (161.80-159.26 mm)

Single Clutch (Non-Livedrive) — 1200

Clutch type	Borg and Beck 12AS
Plate type and diameter	Borglite, 12 in
Plate facing material	Mintex H19
Plate thickness (new)	0.52 in (13.21 mm)
Number of springs	16
Spring colour	lavender/black
Spring pressure (at checking length)	112-122 lb (50-55 kg)
Spring checking length	1.69 in (42.92 mm)
Pedal free-play	1 in (25.4 mm)
Release lever height, i.e.: Distance from tips of release levers to flywheel face when clutch is assembled with four 0.520 in (13.2 mm) spacers in place of driven plate	2.25 in (57.15 mm)




Figure 45. CHECKING THRUST SPRINGS

- A. New spring B. Old spring
C. Spacer D. Rule

Checking Thrust Springs

If a spring tester is not available, springs should be checked as follows:

1. Select an average length spring from a set of new springs to use as a guide.
2. First compare free-length of new spring against old springs and discard any springs whose free-length is over $\frac{1}{8}$ in. (1.5 mm) shorter than the new spring.
3. Finally compare loaded length of springs by compressing the new spring and each old spring in turn, in series between vice jaws. For safety fit a 3 in. (76 mm) piece of $\frac{3}{8}$ in. (9.5 mm) diameter rod inside the springs and fit a short spacer between the spring ends. Compress springs between vice jaws until new spring is reduced to its loaded length (see data pages) then measure length of old spring. If old spring is within $\frac{1}{8}$ in. (1.5 mm) of length of new spring it is satisfactory and can be refitted but any spring whose compressed length is more than $\frac{1}{8}$ in. (1.5 mm) shorter than new spring is weak and must be discarded.

SUMMARY OF DESIGN CHANGES

Details of Change

Power take-off clutch adjusting screws on inner cover increased from $\frac{1}{2}$ UNF to $\frac{3}{4}$ UNF. Parts, except screws and nuts, are interchangeable but if a new inner cover is used with an earlier outer cover the holes in the outer cover must be increased to $\frac{1}{4}$ in. (17.5 mm), to provide clearance for the larger adjusting screws.

Drain hole drilled through support snouts, Part Nos. 89334 and 911906 to prevent any possibility of oil seepage past the clutch shaft bearing reaching the clutch.

Clutch driven plate change from rigid type to Borglite. Part number of plate changed from 906854 to 915694. As the Borglite plate has 40 facing rivets and the rigid plate only 24 rivets, facings are not interchangeable.

Width of clutch stop drum reduced from $1\frac{1}{2}$ in. to 1 in. so that on 6-speed tractors the clutch can be removed without "splitting" the tractor. Part number of the drum changed from 915582 to 917780 and these are not interchangeable unless a new clutch driveshaft is also fitted.

Clutch driveshaft ball bearing (19201) changed to single seal type bearing. The new bearing, Part No. 620033 is interchangeable with the previous bearing and must be fitted with the sealed side towards the support snout.

Stop bolt, Part No. 912855, fitted on left-hand fender to give positive stop for resetting-lever and prevent damage to guide bracket (913860).

Clutch-housing locating-dowels case hardened and increased in length from $\frac{3}{4}$ to $1\frac{1}{2}$ in. (19.0 to 28.5 mm) to give more positive location of housing. Part No. of dowel changed from 35840 to 621838.

When introduced

AD4/47A/63792
AD3/55A/2847
AD3/49A/1929
(April 1966)

990/A/484285
880/A/531626
(April 1966)

AD4/47B/41329
(April 1966)

990/A/487807
880/A/533604
(June 1966)

990/A/487807
880/A/533604
(June 1966)

880/535820
990/491847
(September 1966)

AD3/49A/4988
AD3/55A/8773
AD4/47A/72497
(January 1967)

Hole in clutch pedal, for operating starter safety switch, tapped $\frac{3}{8}$ UNC so that threaded operating peg (K920281) can be used instead of plain peg (K918618).

880/539423
990/496835
(January 1967)

Clutch-stop fork end, Part No. K916482, replaced by fork end K916481.

880/539995
990/497389
(February 1967)

Tension of PTO thrust springs increased from 41 to 53 kg (91 to 117 lb). Part number and colour marking of springs changed from K900261 (buff) to K902514 (pink). Part number of cover assembly changed from K917998 to K921273. Springs are interchangeable if fitted in sets.

AD4/47A/78292
(June 1967)

Tension of transmission thrust spring increased from 53 to 61 kg (117 to 135 lb). Part number and colour marking of springs changed from K625210 (lavender/black) to K962292 (dark blue/light green). Part number (K919860) of clutch assembly is unchanged and springs are interchangeable if fitted in sets.

AD4/55A/4665
(November 1967)

Power take-off clutch operating toggles increased in diameter. As the new toggles, which may be identified by having $\frac{3}{8}$ UNF threads, have larger eyebolts than the $\frac{1}{2}$ UNF toggles, corresponding changes to the clutch cover, pressure plate and release levers do not allow the new toggles to be fitted to earlier clutches unless all the later parts are fitted.

AD4/55A/2839
(June 1967)

Strength of clutch-pedal springs increased from 3 to 8 kg (7 to 18 lb) by increasing thickness of springs from 13 SWG to 10 SWG. Part number of springs (K921684 and K921685) and retaining pins (K921683 and K921686) unchanged.

780/600610
(December 1967)

Strength of cross shaft return spring increased by changing thickness of spring from 7 SWG to 6 SWG. Part number of spring (K921687) unchanged.

780/600745
(January 1968)

Clutch dust cover U1174 introduced to prevent build up of dust in the flywheel housing. Required only in exceptionally dry and dusty conditions.

1200
(February 1968)

Tension of transmission lever anti-rattle springs increased by changing thickness of springs from 12 SWG to 10 SWG, and lever adjusting screws changed to lighter screws with socket head. Part number of spring changed from K919863 to K923989, and number adjusting screw changed from K919864 to K923990. Parts are interchangeable but must be fitted in sets to preserve clutch balance.

AD4/55/5611
(February 1968)

Pull-off spring (K624935), hook (K916478) and anchor plate (K924167) fitted on PTO hand lever to hold lever firmly in "engaged" position and prevent unnecessary wear of release mechanism.

1200/706056
(July 1968)

Length of trunnion pin in cross shaft fork increased and six Belleville washers (K626723) fitted on pin to increase tension and hold release bearing clear of release lever plate when clutch is engaged. Part number of pin changed from K915834 to K925323.

1200/707333
(December 1968)

Power take-off release-bearing housing connected to grease channel in main frame by a nylon tube, so that release bearing is lubricated at same time as left-hand cross-shaft bearings. Part number of housing (K915837) unchanged but tapped boss incorporated for tube connection.

1200/707536
(January 1969)

Transmission release bearing changed from Part No. K19169, which has 7.9 mm ($\frac{5}{16}$ in) ball bearings, to Part No. K620112 bearing, which has 9.5 mm ($\frac{3}{8}$ in) diameter balls. Bearings are interchangeable and the K620112 bearing should be used as a replacement.

1200/708319
(March 1969)

Twin-plate clutch redesigned so that both drive plates are engaged simultaneously. Inner cover (K918606 or K918613) deleted and three springs (K625232) fitted in pressure plate so that inner driven plate is released at same time as outer plate. Earlier clutches can be changed by discarding the inner cover and fitting a new pressure plate (K962573) and three springs (K625232).

355001/22392
355005/1011
355105/1002
449005/1415
(June 1969)

Cored holes in front main frame (K915404) repositioned and clutch housing vent cover (K904246) changed to plain cover (K923650) to prevent dust entering clutch compartment.

1200/710355
(September 1969)

David Brown®
Service Repair Manual
Update No. 1 for
CLUTCH
Section B1 (Pub 9-37131)

Pub. 9-38183 October 1977

File this update in front of your Service Repair Manual, Clutch section, B1 (Pub. 9-37131).

This update comprises new pages B1 – B25, and covers 1210, 1410 and 1412 tractors (Q-Cab and Non Q-Cab models) fitted with the Laycock dual clutch.

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

CONTENTS

Section	Page
Dual Clutch — 1210 (11, 154, 230 →), 1410 & 1412 tractors	
How it Works	B1
Removal and Installation	B3
Removal and Replacement	
Clutch Release Bearing Sleeve	B7
Clutch Release Bearings	B7
Clutch Cross Shafts	B8
Clutch Pedal	B8
Hand Clutch Lever	B9
Hydraulic Clutch System: Q-Cab	B10
Unit Maintenance and Repair	
Clutch Operating Adjustments	B13
Dual Clutch Parts	B15
Special Tools	B16
Dual Clutch Dismantling	B19
Dual Clutch Re-assembly	B21
Dual Clutch Adjustments	B23
Specifications and Data	B25
Single Plate Clutch — Non-Livedrive Tractors	
Operation	1
Adjustments	1
Servicing the Clutch Unit	2
Double Clutch — Livedrive Tractors (not 1200)	
Operation	5
Adjustments	6
Servicing the Borg and Beck Clutch Unit	8
Servicing the Laycock Clutch Unit	14
Dual Clutch — 1200 (→ 11, 154, 230), Tractors	
Operation	15
Adjustments	16
Servicing the Clutch Unit	16
Twin-Plate Clutch	
Adjustments	21
Servicing the Clutch Unit	22
Refacing Driven Plates	24
Clutch Stop	25
Overload Release Withdrawal Mechanism (Hand Clutch)	26
Clutch Removal and Replacement	
770, 780 and 3800 Tractors	27
880 and 990 Tractors	28
1200 Tractors	31
Clutch Fault Diagnosis	37
Clutch Service Tools	40
Dimensional Data	45
Summary of Design Changes	50

Issued as
Update No. 1
Pub. 9-38183

Issued as
Section B1
Pub. 9-37131

After the majority of this manual section was written, the current range of tractors was introduced. This information continues valid.

Refer as follows:

885 Tractor uses the same Clutch as 880 Livedrive.

995 Tractor (with Livedrive two-stage foot pedal) uses same Clutch as 990.

996 and 995 Tractors with independent hand PTO Clutch use the same Clutch as 1200.

1210 (→ 11, 154, 230) and 1212 Tractors use the same Clutch as 1200.



DUAL CLUTCH – 1210 (11, 154, 230 →), 1410 & 1412 TRACTORS

HOW IT WORKS

The dual clutch contains two separate clutches each with its own release mechanism, assembled into a single unit.

This single unit is bolted to the engine flywheel and consists of a cover enclosing two driven plates, two pressure plates, two sets of release levers, and a set of thrust springs common to both clutches.

The two pressure plates are placed back-to-back between the driven plates, all four plates being positioned between the clutch cover and the engine flywheel. The thrust springs between the pressure plates can, therefore, clamp the PTO driven plate to the engine flywheel and also clamp the transmission driven plate to the inside of the clutch cover.

The transmission clutch release levers are connected by linkage to a foot pedal on the left-hand side of the tractor and the PTO clutch release levers are similarly connected to a hand lever at the left-hand side of the operator's seat.

When both clutches are engaged, both driven plates are clamped to their respective pressure plates by the thrust springs and both drives are transmitted by separate shafts. When the transmission clutch pedal is depressed, the release levers move the transmission pressure plate forward, thus releasing the transmission driven plate and disconnecting the drive.

When the PTO clutch lever is pulled to the disengage position, the release levers move the PTO pressure plate rearwards thus releasing the PTO driven plate and disconnecting the drive.

The thrust springs set consists of 12 colour coded coil springs and single Belleville washer. The Belleville washer augments the coil spring pressure and compensates for reduced coil spring pressure as the driven plates wear in service.




FIGURE B1

- A. Clutch Cover
- B. Transmission Pressure Plate
- C. Transmission Release Lever
- D. Transmission Drive Shaft
- E. PTO Drive Shaft
- F. PTO Release Lever
- G. PTO Pressure Plate
- H. Flywheel

REMOVAL AND INSTALLATION

Removing the Clutch — Figs. B2 to B6

To remove the clutch it is necessary to separate the two main parts of the tractor.

When the tractor is being separated into two parts to service the clutch and a reversible shaft PTO is fitted, the PTO control lever must be placed in the engaged position. This will ensure that the sliding dog clutch gear is held in position if the cardan shaft is withdrawn.

Failure to carry out this precaution will result in additional and unnecessary work as the PTO unit must be removed from the tractor to re-engage the sliding dog clutch gear.

1. Remove the silencer and the bonnet (hood). Disconnect the battery earth (ground) lead and the wiring connector located above the starter. Tractor with Q Cab: remove air pre-cleaner.

2. Remove the fuel tank complete with instrument panel.

Tractor with Q Cab: lift the front of the cab 75mm (3in) with a jack under each step, and hold in position with wood blocks between the cab and the tractor frame.

Be careful not to damage the brake cables or flexible pipes.

3. Disconnect the four pipes from the orbitrol steering valve, drain the surplus oil into a suitable container and mark position of the pipes for re-assembly.

Tractors with Q Cab: disconnect the four flexible pipes from the orbitrol steering valve at the unions positioned forward of the bulkhead. Drain surplus oil into a suitable container and mark position of the pipes for re-assembly.

4. Remove starter motor mounting bolts, lift starter forward and allow starter to rest in main frame.
5. Drain transmission oil into a clean container — capacity approximately 10 gallons (45 litres). Disconnect pump inlet pipe by releasing hose clips at filter end, and pushing short rubber hose back on pipe.
6. Disconnect pump outlet pipe at union mid-way along pipe. Note that when a tandem pump is fitted there are two pump outlet pipes which must be disconnected.




FIGURE B2

R7727




FIGURE B3

R7728

7. Disconnect the hand and foot clutch controls by removing the adjusting nuts from the rod ends.
Tractors with Q Cab: Disconnect the clutch slave cylinder return spring, remove the two bolts attaching the slave cylinder to the bracket and withdraw slave cylinder complete with push rod. Disconnect the PTO clutch cable by withdrawing the clevis pin connecting the cable to the operating lever.
8. Remove clutch pit cover plate and disengage the transmission clutch pedal pull-off spring from hole in left-hand side of frame.
9. Bolt support legs to the rear end of front frame and adjust legs so that they support but do not lift the frame.
10. Support weight of the rear main frame with a jack or crane positioned slightly forward of the oil filter housing.
11. Remove bolts attaching clutch housing to engine and main frame, also bolts attaching front and rear frame. Using a suitable punch, tap dowels (one at each side) back until they are clear of front frame.
12. Carefully lever the two halves of tractor apart, allowing the release lever to tilt forwards until it is disengaged from bearing sleeve.
13. Disconnect the lubrication pipe from the clutch release bearing housing.
14. When the two halves are separated, push front end forward to allow working space as the clutch is heavy to handle.
15. Fit transit staples between the forged release levers and the clutch cover, and evenly unscrew the six setscrews attaching the clutch to the flywheel.
16. Remove clutch assembly with care as the driven plate will drop out when clutch assembly is removed from flywheel.




FIGURE B4

- A. Hand lever adjusting nut
- B. Pedal adjusting nut




FIGURE B5

- A. Spring
- B. Bolt
- C. Slave Cylinder




FIGURE B6

- A. Clevis pin

WARNING: Transit staples must be fitted to the PTO release levers before clutch retaining setscrews are released to prevent displacement of Belleville Spring during handling.



17. Fit pilot shaft through clutch assembly and PTO driven plate ensuring that the long boss on driven plate is towards the flywheel. Replace set screws and when fully tightened withdraw pilot shaft and remove transit staples.
18. Screw a 1/2 UNC x 5in long guide stud into each side of main frame.
19. Hold PTO cross-shaft against its pull-off spring so that release fork is horizontal and will pass under the release bearing and bring the two halves of the tractor together.
20. Check that both halves are in line and as soon as they are close enough together, engage PTO fork into its bearing sleeve.
21. Turn the engine to align the clutch plate splines, re-connect the lubrication pipe to the clutch release bearing housing and push the two halves of the tractor together.
22. Replace bolts, tap dowels back into position and tighten bolts.

NOTE: Do not use force to bring the two halves of the main frames together as damage can be caused. When correctly aligned they can be easily pushed into position.

23. Check that PTO release fork is correctly located in its bearing sleeve.
24. Re-connect and adjust clutch linkage.
Tractor with Q Cab: re-fit clutch slave cylinder and spring. Re-fit clevis pin to PTO clutch cable fork. Adjust free play.
25. Re-fit transmission clutch pull-off spring. It is recommended that a strong length of cord is passed through the frame and secured to the spring hook. A large screw-driver or suitable lever can then be used to stretch the spring until the hook can be correctly located.



WARNING: *Care must be taken in this operation to avoid personal injury.*

26. Re-fit clutch pit cover plate.
27. Reverse operations 1 to 7.
28. Remove filter assembly and wash screen and clean magnetic filter before replacing.
29. Re-fill transmission with oil.

REMOVAL AND REPLACEMENT

Clutch Release Bearing Sleeve:

Removal — Fig B7

1. Remove left-hand footplate or modify gusset.
2. Pivot cross-shaft lever rearwards to disengage fork and pull sleeve forward off the support snout.

Replacement:

3. Reverse operations 1 and 2.
4. Ensure that operating forks are correctly located and the fork pins are free to rotate.
5. Lubricate fork pins with anti-scuffing paste.




FIGURE B7

R77.32

Clutch Release Bearings:

Removal — Figs B8 and 9

1. Slide transmission bearing carrier out of PTO bearing carrier.
2. Support inner race of transmission bearing on tool and press carrier out of bearing.
3. Remove circlip from inside of PTO bearing carrier, support carrier and press bearing off carrier.

Replacement:

4. Reverse operations 2 and 3.
5. Pack lubrication cavities in both bores with grease before assembling PTO bearing carrier on to transmission bearing carrier.




FIGURE B8

R77.33

Caution: When a new release bearing is to be fitted and the bearing is of the type where the inner track is shielded, it is essential to rotate the bearing as it is being pressed into position.

Failure to do this puts a heavy static load on the bearing, almost certainly resulting in damage which will lead to noisy operation and early failure.

Ensure that the location spigot on the carrier is not damaged during removal of the old bearing and that the new bearing and the carrier are correctly aligned before assembly.

Take care and do not use excessive force.




FIGURE B9

- A. Old Bearing
- B. Wood Block
- C. New Bearing

R77.34

Clutch Cross Shafts

The clutch cross shafts can only be removed when tractor is split.

PTO Cross Shaft

Removal — Fig B10

1. Remove bolts from PTO clutch fork and pull-off spring lever.
2. Remove circlip from right-hand end of cross shaft and withdraw shaft to left, tapping the release fork at the same time. Remove the two keys which locate the clutch fork to allow shaft to pass through the bearing.

Replacement

3. Lubricate shaft bearings.
4. Reverse operations 1 and 2.




FIGURE B10

R7735

Transmission Cross Shaft

Removal — Fig B11

1. Remove left-hand footplate.
2. Remove bolts from release fork and pull-off spring lever.
3. Withdraw shaft from left, tapping the release fork at the same time. Remove the two keys to allow shaft to pass through the bearing.

Replacement

4. Lubricate shaft bearings.
5. Reverse operations 1 to 3.




FIGURE B11

R7736

Clutch Pedal — Not Q Cab

Removal — Fig B12

The clutch pedal is mounted on a tube which passes through the main frame. As this tube also carries the brake cross shaft it is necessary to remove the brake rod and operating lever.

1. Remove the adjusting nut, pin and return spring and withdraw the brake rod.
2. Drive out Mills pin and remove lever.
3. Remove split pin and clevis pin.




FIGURE B12

R7737

- | | |
|------------------|--------------|
| A. Adjusting nut | B. Mills Pin |
| C. Lever | D. Spring |
| E. Pin | |

4. Remove bolts attaching left-hand footplate to frame and fender.
5. Tilt front of footplate upwards and remove pedal.

Replacement

6. Coat cross shaft tube with grease.
7. Reverse operations 1 to 5.

Hand Clutch Lever (PTO)

Removal

1. Slacken adjusting nut.
2. Remove clevis pin, anchor plate and spring and withdraw clutch rod from lower end of lever.
3. Remove right and left-hand brackets.
4. Remove the two bolts from pivot shaft and lower hand lever through footplate.
5. It may be necessary to remove latch lever to allow hand lever to pass through footplate.

Replacement

1. Ensure that pivot shaft is free in lever bore and grease hole is clear.
2. Reverse operations 2 to 5.
3. Adjust free play.

Hand Clutch Lever (PTO) — Q Cab

Removal

1. Disconnect the PTO clutch cable by removing the clevis pin at the fork end.
2. Remove the two bolts attaching the lever bracket to the cab.
3. Push cable upwards at lever end to free the cable nipple from the roller and withdraw the cable through the slot in the roller.

Replacement

1. Reverse operations 1 to 3.
2. Adjust free play. Page B14.




FIGURE B13




FIGURE B14

- A. Locknut
B. Cable Adjuster

Hydraulic Clutch System — Q Cab

NOTE: This information does not apply to Highway Tractors. The components used are similar (or identical) to the parts used in the braking system. To avoid errors, all clutch cylinders and seals are colour coded with a blue band. Ensure that any component fitted has a blue identification band as this indicates that the unit is suitable for use with mineral type oils. NO ATTEMPT MUST BE MADE TO FIT SEAL KITS OR CYLINDERS OBTAINED FROM GIRLING AGENTS. THE CORRECT COMPONENTS ARE ONLY OBTAINABLE FROM DAVID BROWN PARTS DEPARTMENT UNDER THE FOLLOWING PART NUMBERS.

Master Cylinder	K950554
Seal Kit, master cylinder	K964572
Slave Cylinder	K950550
Seal Kit, slave cylinder	K964576




FIGURE B15

- A. Push rod
- B. Fork

R77.40



WARNING The only fluids approved for use in clutch reservoirs are Shell Tellus 27 and Castrol Hyspin AWS 32. Other fluids are NOT compatible and must NOT be used.

Clutch Master Cylinder

Removal — Fig B15

1. Remove bonnet.
2. Disconnect the two pipe unions at top of cylinder.
3. Disconnect push rod from clutch pedal.
4. Remove the two bolts attaching cylinder to bulkhead.
5. Lift out cylinder complete with push rod and fork.

Replacement — Fig B16

6. Reverse operations 1 to 5.
7. Adjust threaded end of push rod so that clevis pin freely enters the hole in the pedal with the pedal in contact with the rear-stop.
8. Carefully depress the pedal until the master cylinder piston reaches the end of its travel.
9. Adjust stop bolt in pedal to contact the console and unscrew one further turn to prevent master cylinder piston bottoming in service. Tighten locknut.
10. Bleed system. Page B14.




FIGURE B16

- A. Clevis pin
- B. Stop bolt
- C. Console

R77.41

Clutch Slave Cylinder**Removal — Fig B17**

1. Disconnect the return spring.
2. Disconnect pipe union.
3. Remove two bolts attaching cylinder to bracket.
4. Withdraw cylinder complete with push rod.

Replacement

1. Reverse operations 1 to 4.
2. Bleed system (Page B14).




FIGURE B17

- A. Spring
- B. Bolt
- C. Slave cylinder
- D. Adjuster

UNIT MAINTENANCE AND REPAIR

Clutch Operating Adjustments

As the clutch facings wear during service, the amount of free-play or clearance, in pedal or hand lever is gradually reduced until it no longer exists. This results in the pressure plate being unable to clamp the driven plate with sufficient force to prevent the clutch slipping. Operating a tractor under these conditions will rapidly cause total and expensive clutch failure. It is essential to maintain the recommended free-play in the linkages, and adjustments are provided for this purpose.

Transmission Clutch Adjustment – Not Q Cab Fig B18

1. Pull clutch pedal upwards to ensure it is being fully returned to the up position, then depress pedal until the resistance of the clutch springs is felt.
2. Measure the amount of free-play.
3. Adjust to not less than 25mm (1in) by re-positioning adjusting nut and locknut.

NOTE: If pedal can be pulled upwards it indicates either a weak spring or tightness in the linkage. This must be rectified to prevent wear of the clutch release mechanism.




FIGURE B18

- A. Hand lever adjusting nut
B. Pedal adjusting nut

Power Take-off Clutch Adjustment – Not Q Cab Fig B19

1. Push hand lever forward to ensure it is being fully returned, then pull lever until the resistance of the clutch springs is felt.
2. Measure the amount of free-play.
3. Adjust to not less than 50mm (2in) by re-positioning the adjusting nut and locknut.

Alternative Method of Power Take-off Clutch Adjustment

1. Pull hand lever rearwards and engage latch.
2. Remove PTO output shaft cover and engage PTO gear.
3. Unscrew hand lever adjusting nut until PTO shaft cannot be turned by hand.
4. Tighten hand lever adjusting nut until PTO shaft can just be turned by hand. Tighten locknut.

NOTE: If hand lever is not returning to the fully forward position it indicates a weak spring or tightness in the linkage. This must be rectified to prevent wear of the clutch release mechanism.




FIGURE B19

Transmission Clutch Adjustment – Q Cab Fig B20

This should be checked at least every 60 hours of operation and the tractor must **NEVER** be operated with less than 6mm (0.22in) free-play. Adjustment is provided for on the slave cylinder push rod.

1. Ensure that piston in slave cylinder is fully retracted and if not, fit a stronger slave cylinder return spring (Part No. K624954).
2. Disconnect return spring with rod held securely to prevent turning. Loosen locknut and unscrew adjuster until there is no free play. Screw adjuster in two turns, tighten locknut and re-connect spring. Ensure that the slave cylinder piston stays fully retracted.




FIGURE B20

- A. Spring
- B. Bolt
- C. Slave cylinder
- D. Adjuster

Power Take-off Clutch Adjustment – Q Cab Fig B21

This should be checked every 60 hours of operation. Adjustment is provided for by the cable adjuster.

1. Place hand lever in forward position and disconnect spring from cross shaft lever.
2. Loosen locknut and unscrew cable adjuster until there is no free play. Screw cable adjuster in one turn. Tighten locknut and re-connect spring.




FIGURE B21

- A. Clevis pin
- B. Cable adjuster
- C. Locknut

Master Cylinder and Foot Pedal – Fig B22

If the master cylinder or clutch pedal has been re-fitted proceed as follows.

1. Adjust threaded end of push rod so that clevis pin freely enters the hole in the pedal with the pedal in contact with the rear-stop.
2. Carefully depress the pedal until the master cylinder piston reaches the end of its travel.
3. Adjust stop bolt in pedal to contact the console and unscrew one further turn to prevent master cylinder piston bottoming in service. Tighten locknut.

Clutch Hydraulic System Bleeding

1. Remove all free play from linkage and bleed in the same way as brake circuit.
2. Adjust free play.



CAUTION: Do not bottom clutch release levers when depressing clutch pedal as this could cause clutch damage.




FIGURE B22

- A. Clevis pin
- B. Stop bolt
- C. Console




FIGURE B23

DUAL CLUTCH PARTS

- | | |
|---------------------------------|---------------------------------|
| A. Clutch cover | M. Pivot pin |
| B. Setscrew, clutch to flywheel | N. Release lever, transmission |
| C. Release lever plate | P. Roller |
| D. Circlip | R. Anti-rattle spring |
| E. Transit staple | S. Driven plate, transmission |
| F. Anti-rattle spring | T. Pressure plate, transmission |
| G. Adjusting screw | U. Adjusting screws |
| H. Link pin, upper | V. Pressure plate, P. T. O. |
| J. Release lever, P. T. O. | W. Belleville spring |
| K. Pivot pin, lower | X. Fibre washer |
| L. Link | Y. Driven plate, P. T. O. |
| | Z. Thrust spring |

SPECIAL TOOLS

Replacing Clutch Assembly

Clutch Plate Pilot — Fig B24

A	22.2 mm—0.874in	F	57.15mm—2.25in
B	23.16mm—0.912in	G	38.1 mm—1.50in
C	38.1 mm—1.50in	H	152.4 mm—6.00in
D	44.93mm—1.769in	J	9.5 mm—0.375in
E	19.05mm—0.75in		




FIGURE B24

Servicing Clutch Assembly

Clutch Kit No. 1 with modified baseplate — Fig B

Clutch Kit No. 8, new kit, DB8832 consisting of the following:

Part No.	Description	Qty.
DB 8832/1	adaptor — centre pillar (transmission)	1
DB 8832/2	spacer, cover to baseplate	6
DB 8832/4	adaptor, centre pillar (PTO)	1
DB 8832/5	setscrew $\frac{1}{8}$ UNC x $\frac{5}{16}$ in	6
DB 8832/6	gauge finger, long	1
DB 8832/12	locating collar, centre pillar	1
Code 33	spacer, PTO pressure plate	3
Code 4	spacer, centre pillar	1
DB 990204	adaptor plate, actuator	1
K 89619A	wrench, $\frac{1}{2}$ in square	1
	allen key $\frac{1}{8}$ A/F	1
K 86308	transit staple	3

Baseplate Modification (not applicable to baseplates made after 1st May, 1974)

Position of Additional Holes — Fig B25

1. Mark out one hole, mount clutch assembly on centre pillar with the locating collar in position and spot drill through the remaining cover holes, using a 10.30 mm ($\frac{3}{8}$ in) drill.
2. Drill through baseplate using drill size P or 8.2mm (0.322in), tap holes $\frac{1}{8}$ UNC and counter-sink face of baseplate to 9.8mm (0.385in) at 90° included angle.
3. Alternatively mark off six holes equally spaced on 336.4-336.7mm (13.244-13.256in) pitch circle diameter, and proceed with operation 2.





FIGURE B25


Press Tool for Clutch Release Bearings

BEARING HOUSING SUPPORT

- A. 4.625in (116mm) Dia.
- B. 1/2in (6.35mm)
- C. 4.937in (125mm) Dia.
- D. 1in (25.4mm)
- E. 7 degrees
- F. 6in (152mm) Square
- G. 2in (51mm) Centres
- H. 2.3125in (59mm)
- J. 0.5in (12.5mm) Dowel x 1 in long
- K. 0.5in (12.5mm)



R7749



R7748


RELEASE BEARING REPLACER

Transmission

- A. 2.124in (53.95mm)
- B. 1.0in (25.4mm)
- C. 0.5in (12.7mm)
- D. 3.5in (89mm)
- E. 1/2 wide x 1/2 in deep (3.17 x 0.8mm)

Power take-off

- A. 2.624in (66.649mm)
- B. 1.0in (25.4mm)
- C. 0.5in (12.7mm)
- D. 2.98in (75.79mm)
- E. 1/2 wide x 1/2 in deep (0.8 x 0.8mm)



REMOVING PTO BEARING

R7733

TEMPLATES FOR CHECKING ANGLE OF LEVER RETURN SPRINGS

PTO lever springs — Fig B29

1. On a piece of stiff card draw a base line 'A' — 'B' approx. 8in long.
2. Mark a point 'C' 4in from point 'A'.
3. With the aid of a compass scribe arcs 1.25in from point 'A' and 3.5in from point 'C'.
4. Draw a line from point 'C' through the point at which the two arcs intersect. The angle made between this line and line 'C' — 'B' is the max. spring angle required i.e. 162° .
5. Place spring over the diagram as shown below. If the spring arms lie within the 162° angle it may be re-used. If the spring arms lie outside the 162° angle it must be replaced. It is useless bending it back to lie within the specified angle.




FIGURE B29

Transmission lever springs, Fig B30

1. On a piece of stiff card draw a base line 'A' — 'B' 6 in long.
2. With the aid of a compass scribe arc 2.5in from Point 'A' and 5.15in from point 'B' where the arcs intersect is point 'C'.
3. Join the points 'A' — 'C'.
4. Place the spring over the diagram as shown below. If the spring arms lie within the 58° angle it may be re-used. If the spring arms lie outside the 58° angle it must be replaced; it is no use bending it back to lie within the specified angle.




FIGURE B30

UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Clutch Service Repair Manual, section B1, Pub. 9-37131

First Published as TP619, October 1970. Re-issued as Pub. 9-37132

October 1976, with additional pages B1-B25 issued October 1977 (Pub. 9-38183)

Dual Clutch

Dismantling — Fig B31

1. Set baseplate on a firm and level surface.
2. Position the three PTO pressure plate spacers (Code 33) on the baseplate so that the spacers will be directly below the PTO release levers when clutch assembly is fitted.
3. Position the six clutch cover to baseplate spacers (DB8832/2) over the six tapped holes in the baseplate to correspond with the bolt holes in the clutch cover.
4. Place clutch assembly on baseplate taking care not to disturb the position of the spacers.
5. Assemble the locating collar (DB8832/12) on to the centre pillar (K961845) and screw the centre pillar into the baseplate.
6. Place plain washers on to the six setscrews (DB8832/5) and screw them into the baseplate through the clutch cover and the spacers.
7. Tighten the setscrews evenly and firmly and remove transit staples.
8. Mark relative positions of clutch cover and pressure plates to ensure correct re-assembly.
9. Remove upper PTO release lever pivot pins and anti-rattle springs, and swing PTO release levers outwards past the clutch cover.
10. Remove the centre pillar (K961845).
11. Remove the transmission release lever pivot pins, anti-rattle springs and transmission release levers complete with rollers.
12. Unscrew the six setscrews (DB8832/5) evenly until all spring pressure has been released.
13. Remove the locknuts and the transmission release lever adjusting screws.
14. Remove clutch cover, driven plate and pressure plate.
15. Remove Belleville spring, coil springs and insulating washers.




FIGURE B31

- | | |
|--------------------|------------------|
| A. Locating Collar | D. Centre Pillar |
| B. Spacer DB8832/2 | E. Baseplate |
| C. Spacer Code 33 | |

UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Clutch Service Repair Manual, section B1, Pub. 9-37131

First Published as TP619, October 1970. Re-issued as Pub. 9-37132

October 1976, with additional pages B1-B25 issued October 1977 (Pub. 9-38183)

16. Remove lower link pins and links.
17. Remove circlip and bearing from clutch cover.

Inspection — Fig B32

After thorough cleaning of parts EXCEPT clutch facings inspect and renew if necessary.

18. PTO release levers, pivot pins and links for wear.
19. PTO release lever adjusting screws for wear on spherical face.
20. Transmission release levers, pivot pins, rollers and adjusting screws for wear.
21. Release lever plate for wear on face or contact points.
22. Pressure plates and clutch cover for distortion, heat cracks and excessive dishing of friction faces.
23. Pressure plates and clutch cover for wear on driving lugs.

NOTE: Renew component if wear exceeds 0.13mm (0.005in) on any one face.

24. Clutch driven plate facings. If badly glazed, burnt, oil soaked, cracked, split or worn to the rivet heads, replace with the correct facings.
25. Clutch driven plate discs for loose rivets and driven plate hubs for spline wear.
26. Bearing for axial play and smooth running.
27. Thrust springs for length and Belleville spring for height. See Specifications and Data. Page B25.
28. Anti-rattle springs for tension.
29. Check fit of PTO cardan shaft in the engine fly-wheel pilot bearing. This must be a free sliding fit; if tight, polish the shaft bearing location with 180 grit emery tape.




FIGURE B32

REGRINDING LIMITS

- † A. 28.63mm (1.127in)
- † B. 23.77mm (0.936in)
- † C. 72.82mm (2.867in)

R77.53

Re-assembly – Fig B33

30. Lubricate sides of drive lugs and Belleville spring locations on both pressure plates. Coat lightly with Acheson Colloids GREDAG 15469 or an equivalent type of graphited grease with a minimum temperature range of 150°C (270°F).
31. Repeat operations 1 to 3.
32. Place PTO clutch pressure plate, friction face down, on baseplate.
33. Place twelve new fibre washers on the spring seats and replace the thrust springs and the Belleville spring in their correct locations.

NOTE: Belleville spring outside circumference will be higher than the inside when in position, and is located only by the pressure plates.

34. Assemble PTO levers and links, and connect links to PTO pressure plate. Ensure that links are fitted with the offset holes towards the centre of the clutch.
35. Place twelve new fibre washers on to the transmission pressure plate spring seats, turn plate over, align assembly marks and fit plate on top of thrust springs.
36. Check that all fibre washers are in place and that all the thrust springs are correctly seated.
37. Place the transmission driven plate, dished hub downwards, on to the transmission pressure plate.
38. Replace clutch cover bearing and circlip.
39. Place clutch cover on to transmission driven plate, aligning bolt holes in cover with spacers on baseplate and assembly marks.
40. Fit the six setscrews through the clutch cover and the spacers. Do not tighten.
41. Screw the centre pillar into the baseplate and push locating collar over centre pillar to align the clutch assembly.
42. Tighten the six setscrews evenly until clutch cover is pulled down far enough to allow the PTO release levers to be fitted to the clutch cover.




FIGURE B33

- | | |
|---------------------------------|---------------------------------|
| A. Clutch cover | N. Release lever, transmission |
| B. Setscrew, clutch to flywheel | P. Roller |
| C. Release lever plate | R. Anti-rattle spring |
| D. Circlip | S. Driven plate, transmission |
| E. Transit staple | T. Pressure plate, transmission |
| F. Anti-rattle spring | U. Adjusting screws |
| G. Adjusting screw | V. Pressure plate, P.T.O. |
| H. Link pin, upper | W. Belleville spring |
| J. Release lever, P.T.O. | X. Fibre washer |
| K. Pivot pin, lower | Y. Driven plate, P.T.O. |
| L. Link | Z. Thrust spring |
| M. Pivot pin | |

WARNING During this operation it is essential to ensure that no binding occurs between the pressure plate lugs and the clutch cover. The Belleville spring, which can be viewed through the clutch cover ventilation slots, must remain correctly located in the machined recess of the transmission pressure plate.



43. Locate anti-rattle springs over PTO release levers and refit pivot pins.
44. Firmly tighten the six setscrews and remove locating collar from centre pillar.
45. Re-fit adjusting screws and locknuts into transmission pressure plate. Do not tighten.
46. Assemble rollers into transmission clutch release levers and place in position on clutch cover.
47. With all release levers in position, place the release lever plate, so that lugs pass through the holes in the release levers.
48. Pass the longer end of the anti-rattle spring through the lever and into hole in release plate lug.
49. Align spring loop, lever and cover hole and fit pivot pins.




FIGURE B34

R7728

ADJUSTMENTS

Power Take-off Clutch Release Levers — Fig B35

1. Screw actuator assembly (K961844 part of Basic Kit No. 1) with adaptor plate (DB920204), into the PTO centre pillar adaptor (8832/4), and operate the handle at least twelve times.
2. Remove actuator assembly and plate.
3. Screw the Basic Kit No. 1 centre pillar (K961845) into the PTO centre pillar adaptor, place a Code 4 spacer on the centre pillar, and place the setting finger assembly on the spacer.
4. Press the setting finger assembly firmly and squarely on to spacer and set the PTO release lever adjusting screws to contact the face of the fingers. Tighten locknuts.
5. Remove the setting finger assembly and spacer, refit actuator assembly, operate the handle twelve times, refit setting finger assembly and check height setting. Reset if necessary and tighten locknuts.
6. Remove setting finger assembly, spacer, adaptor and centre pillar.




FIGURE B35

- A. Gauge Finger
B. Adjusting Screws

R77.54

Transmission Clutch Release Levers — Fig B36

7. Screw the transmission centre pillar adaptor (DB8832/1) into the baseplate, fit actuator assembly and operate the handle at least twelve times.
8. Remove actuator assembly, screw centre pillar into adaptor, and place a Code 4 spacer on centre pillar.
9. Fit finger (DB8832/6) to setting finger assembly and place the assembly on the spacer.
10. Press the setting finger assembly firmly and squarely on to spacer and adjust the screws in the transmission pressure plate until 360° contact is made between the finger and the release lever plate. Tighten locknuts.
11. Repeat operations 5 and 6.
12. Fit transit staples over PTO release levers, remove the six setscrews and lift clutch assembly from baseplate.




FIGURE B36

- A. Gauge Finger (long)
B. Adjusting Screws
C. Release Lever Plate

R77.55



WARNING Transit staples must be fitted to the PTO release levers before releasing setscrews to prevent displacement of Belleville spring during handling.

UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Clutch Service Repair Manual, section B1, Pub. 9-37131

First Published as TP619, October 1970. Re-issued as Pub. 9-37132

October 1976, with additional pages B1-B25 issued October 1977 (Pub. 9-38183)

LAYCOCK DUAL CLUTCH

Clutch type

Plate diameter — transmission

Plate facing material

Plate thickness — new

Plate diameter — PTO

Plate facing material

Plate thickness — new

Number of coil thrust springs

Spring identification colour

Spring free length — minimum

Spring checking length

Spring pressure at checking length

Number of Belleville springs

Spring identification colour

Spring free height — including material thickness

Spring minimum height

Spring checking height

Spring pressure at checking height

Release lever springs — transmission

Wire diameter

Angle between arms — maximum

Release lever spring PTO

Wire diameter

Angle between arms — maximum

Refacing dimensions

Depth of clutch cover — maximum

Thickness of transmission pressure plate — minimum

Thickness of PTO pressure plate — minimum

Pressure Plate lug clearance (new)

Pressure Plate lug clearance (maximum)

Pedal free-play — mechanical

Slave cylinder free-play — hydraulic

Hand lever free play — measured at cable adjuster

1412

Part No. K950876

Laycock No. 86166

1210, 1410

Part No. K951600*

Laycock No. 86762

305mm — 12in

Thermoid 11046

9.09mm — 0.358in

305mm — 12in

Capasco F30C

9.22mm — 0.363in

12

Yellow

Pink

36.45mm — 1.43in

38.35mm — 1.51in

28.88mm — 1.137in

39.44kg — 87.97lb

28.42kg — 63.92lb

ONE

Yellow

Pink

9.27-8.97mm

10.13-9.80mm

0.365-0.353in

0.399-0.386in

8.97mm — 0.353in

9.80mm — 0.386in

4.29mm — 0.169in

4.85mm — 0.191in

470-570kg

580-658kg

1033-1262lb

1280-1450lb

3.66mm — 0.144in (9 SWG)

75°

2.64mm — 0.104in (12 SWG)

162°

† 72.82mm — 2.867in

† 23.77mm — 0.936in

28.63mm — 1.127in

0.1-0.2mm — 0.004-0.009in

0.72mm — 0.029in

25-50mm — 1.0-2.0in

6.0-12.0mm — 0.236-0.472in

2.5-5.0mm — 0.098-0.197in

* Clutch assembly Part No. K951600 (marked red) replaces K950876 (marked yellow).

NOTE: The transmission driven plate in clutch assembly K947033 fitted to 1412 tractors only, incorporated spring flights. The Plate thickness is therefore different.

David Brown®

Service Repair Manual

CLUTCH ASSEMBLIES for

770 780 880 990 1200
3800 and 4600 Tractors

Section B2 (Pub. 9-37133) March 1979

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



Note: This publication includes information previously given in Pub. 9-37131 (Clutch section of TP 619, issued October 1970 with pp 22, 23, 44 to 49 updated April 1971) plus Pub. 9-38158 (pp 51, 52 updated June 1976). Pub. 9-37132 updated October 1976.

This section of the Service Repair Manual gives information for clutches fitted to the following tractors:

770	Selectamatic	1965-1970
780	Selectamatic	1967-1971
880	Selectamatic	1965-1971
990	Selectamatic	1965-1971
1200	Selectamatic	1967-1971
3800	3 cylinder Petrol	1968-1971
4600	3 cylinder Petrol	1968-1971

David Brown Tractors Ltd., will continue to improve their products. As a result, the specifications can have changed after this manual was made. Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual can give details of items that are not part of any specific tractor.

CONTENTS

SECTION	PAGE
SPECIFICATIONS	3
CLUTCH SERVICE TOOLS	9
CLUTCH FAULT DIAGNOSIS	15
How to Remove and Install	
770, 780 and 3800 Tractors	19
880 and 990 Tractors	21
1200 Tractors	25
Maintenance and Repair	
Single Plate Clutch — Non-Livedrive Tractors	31
Operation	31
Adjustments	31
Servicing the Clutch Unit	33
Twin-Plate Clutch	35
Adjustments	35
Servicing the Clutch Unit	36
Double Clutch — Livedrive Tractors (except 1200)	39
Operation	39
Adjustments	40
Servicing the Borg and Beck Clutch Unit	44
Servicing the Laycock Clutch Unit	49
Dual Clutch — 1200 Livedrive Tractors	53
Operation	53
Adjustments	54
Servicing the Clutch Unit	55
DRIVEN PLATES	59
CLUTCH STOP MECHANISM	62
OVERLOAD RELEASE WITHDRAWAL MECHANISM	64
SUMMARY OF DESIGN CHANGES	65

SPECIFICATIONS

Single Clutch — 770 Replacement Unit

Clutch type	Borg and Beck BB9/273A
Plate type and diameter	Borglite, 9 in (22·86 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0·330 in (8·38 mm)
Number of springs	12
Spring colour	black
Spring pressure (at checking length)	150–160 lb (67–69 kg)
Spring checking length	1·688 in (42·875 mm)
Pedal free-play	$\frac{1}{2}$ – $\frac{3}{4}$ in (13–19 mm)
Release lever height: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0·330 in. (8·382 mm) thick spacers in place of the driven plate	1·895 in (48·13 mm)
Pedal pad height above footplate when free play is taken up	$2\frac{1}{4}$ – $3\frac{3}{4}$ in (57·0–95·0 mm)

Double Clutch (Livedrive) — 770 and 880 Replacement Unit

Clutch type	Borg and Beck BB10/167E
Plate type and diameter (transmission)	Borglite, 10 in (25·4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0·350 in (8·89 mm)
Plate type and diameter (PTO)	rigid, 10 in (25·4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0·320 in (8·13 mm)
Number of springs (transmission)	12
Spring colour (inner transmission)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)
Spring checking length	2·60 in (66·04 mm)
Spring colour (outer transmission)	brown
Spring pressure (at checking length)	120–130 lb (54–58 kg)
Spring checking length	2·60 in (66·04 mm)
Number of springs (PTO)	6
Spring colour (PTO)	buff or pink
Spring pressure (at checking length)	88–94 lb or 113–121 lb (39–42 kg) (50–55 kg)
Spring checking length	2·26 in (57·40 mm)
Separator plate thickness	0·705–0·700 in (17·90–17·78 mm)
Cover adjusting screw clearance	0·070 in (1·78 mm)
Pedal free-play	1– $1\frac{1}{2}$ in (25·4–38·0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0·349 in. (8·865 mm) thick spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0·310 in. (7·874 mm) thick spacers in place of the power take-off plate and 0·349 in. (8·865 mm) spacers in place of the transmission plate	3·345 in (84·96 mm)

Laycock double clutch (Livedrive) — 770 and 880 Final specification

Clutch type	Laycock No. 83939
Plate type and diameter (transmission)	Borglite 10 in (25·4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0·340 in (8·63 mm)
Plate type and diameter (PTO)	rigid, 10 in (25·4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0·310 in (7·87 mm)
Number of springs	12
Spring colour	pale green
Spring pressure at checking length	103–113 lb (46–51 kg)
Spring checking length	1·5 in (38·1 mm)
Spring overall diameter	0·840 in (21·34 mm)

Separator plate thickness	0.705–0.700 in (17.90–17.78 mm)
Cover adjusting screw clearance:	
clutch on baseplate	0.038 in (0.97 mm) – Laycock driven plate 0.048 in (1.22 mm)–Borg and Beck plate
clutch on flywheel	0.048 in (1.22 mm)
Pedal free-play, 880	1–1½ in (25.4–38.0 mm)
Pedal free-play, 780	¾–1 in (19–25.4 mm)
Release lever height, i.e. distance from head of release lever adjusting screw to baseplate face when clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of trans- mission plate and 912724 spacers between cover flange and baseplate. This dimension also applies when clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of power take-off plate and 0.349 in. (8.865 mm) spacers in place of transmission plate	3.720 in (94.49 mm)

Single Clutch — 880 Replacement unit

Clutch type	Borg and Beck 10A6G
Plate diameter	Borglite, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.330 in (8.38 mm)
Number of springs	12
Spring colour	light green
Spring pressure (at checking length)	105–115 lb (47–52 kg)
Spring checking length	1.688 in (42.875 mm)
Pedal free-play	1–1½ in (25.4–38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0.330 in. (8.382 mm) thick spacers in place of the driven plate	1.955 in (49.53 mm)

Double Clutch (Livedrive) — 990

Clutch type	Borg and Beck BB11/180E
Plate type and diameter (transmission)	Borglite 11 in (27.44 cm)
Plate facing material	Thermoid 1104-6
Plate thickness (new)	0.350 (8.89 mm)
Plate type and diameter (PTO)	rigid, 10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.320 in (8.13 mm)
Number of springs (transmission)	12
Spring colour (inner-transmission)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer transmission)	red
Spring pressure (at checking length)	140–150 lb (63–67 kg)
Spring checking length	2.60 in (66.04 mm)
Number of springs (PTO)	6
Spring colour (PTO)	pink
Spring pressure (at checking length)	113–121 lb (51–54 kg)
Spring checking length	2.26 in (57.40 mm)
Separator plate thickness	0.765–0.760 in (19.44–19.30 mm)
Cover adjusting screw clearance	0.070 in (1.78 mm)
Pedal free-play	1–1½ in (25.4–38.0 mm)

Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.349 in. (8.865 mm) thick spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.310 in. (7.874 mm) thick spacers in place of the power take-off plate and 0.349 in. (8.865 mm) spacers in place of the transmission plate

3.445 in (87.5 mm)

Single Clutch — 990 Replacement unit

Clutch type	Borg and Beck 11A6G
Plate type and diameter	Borglite 11 in (27.44 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.330 in (8.38 mm)
Number of springs	12
Spring colour	yellow/light green
Spring pressure (at checking length)	135–145 lb (61–65 kg)
Spring checking length	1.688 in (42.875 mm)
Pedal free-play	1–1½ in (25.4–38.0 mm)
Release lever height, i.e.: Distance from the tips of the release levers to the base plate or flywheel face when the clutch is assembled with three 0.330 in. (8.382 mm) thick spacers in place of the driven plate	1.955 in (49.53 mm)

Twin Plate Clutch — 880

(Early clutch with inner cover, replace with later clutch without inner cover)

Clutch type	special twin plate
Plate diameter	10 in (25.4 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.350 in (8.89 mm)
Plate diameter	10 in (25.4 cm)
Plate thickness (new)	0.350 in (8.89 mm)
Plate facing material	Capasco F30C
Number of springs on pressure plate	12
Spring colour (inner)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer)	brown
Spring pressure at (checking length)	120–130 lb (54–58 kg)
Spring checking length	2.60 in (66.04 mm)
Number of springs on inner cover	6
Identification	Part No. 625149
Spring pressure (at checking length)	10 lb (4.54 kg)
Spring checking length	2.25 in (57.15 mm)
Separator plate thickness	0.705–0.700 in (17.90–17.78 mm)
Cover adjusting screw clearance	0.050 in (1.270 mm)
Pedal free-play	1–1½ in (25.4–38.0 mm)

Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.389 in. (9.880 mm) spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates.

3.345 in (84.96 mm)

Twin Plate Clutch — 990

(Early clutch with inner cover. Use later clutch parts for replacement)

Clutch type	special twin plate
Plate diameter	11 in (27.94 cm)
Plate facing material	Mintex H19
Plate thickness (new)	0.350 in (8.89 mm)

Plate diameter	} inner plate	10 in (25.4 cm)
Plate facing material		Capasco F30C
Plate thickness (new)		0.350 in (8.89 mm)
Number of springs on pressure plate		12
Spring colour (inner)		brown
Spring pressure (checking length)		80–85 lb (36–38 kg)
Spring checking length		2.60 in (66.04 mm)
Spring colour (outer)		brown
Spring pressure (checking length)		120–130 lb (54–58 kg)
Spring checking length		2.60 in (66.04 mm)
Number of springs on inner cover		6
Identification		Part No. 625149
Spring pressure (at checking length)		10 lb (4.54 kg)
Spring checking length		2.25 in (57.15 mm)
Separator plate thickness		0.765–0.760 in (19.43–19.30 mm)
Cover adjusting screw clearance		0.050 in (1.270 mm)
Pedal free-play		1–1½ in (25.4–38.0 mm)

Release lever height, i.e.: Distance from the tips of the release levers to the base plate face when the clutch is assembled with 0.389 in. (9.880 mm) spacers in place of the transmission plate and 912724 spacers between the cover flange and base plate. This dimension also applies when the clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates.

3.445 in (87.5 mm)

Twin Plate Clutch — 990 and 880 (Later clutch without inner cover)

Clutch type	special twin plate
Plate diameter	10 in (25.4 cm)
Plate facing material	Thermoid 11046
Plate thickness (new)	0.350 in (8.89 mm)
Number of springs on pressure plate	12
Spring colour (inner)	brown
Spring pressure (at checking length)	80–85 lb (36–38 kg)
Spring checking length	2.60 in (66.04 mm)
Spring colour (outer)	red
Spring pressure (at checking length)	140–150 lb (63–67 kg)
Spring checking length	2.60 in (66.04 mm)
Separator plate thickness — 990..	0.765–0.760 in (19.44–19.30 mm)
Separator plate thickness — 880..	0.705–0.700 in (17.90–17.78 mm)
Pedal free-play	1–1½ in (25.4–38.0 mm)

Release lever height, i.e.: Distance from tips of release levers to base plate face when clutch is assembled with 0.389 in. (9.880 mm) spacers in place of drive plate and 912724 spacers between cover flange and baseplate. This dimension also applies when clutch is assembled on a flywheel and fitted with 0.349 in. (8.865 mm) spacers in place of both drive plates

3.445 in (87.5 mm)

Dual Clutch (Independent) — 1200 Replacement unit

Clutch type	Borg and Beck 49400
Plate type and diameter (transmission)	Borglite 11 in (27.94 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.340 in (8.64 mm)
Plate type and diameter (PTO)	rigid 11 in (27.94 cm)
Plate facing material	Capasco F30C
Plate thickness (new)	0.324 in (8.23 mm)
Number of springs (transmission)	12
Spring colour	Buff/Black or Light green/Black
Spring pressure (at checking length)	185 lb (84 kg) or 150 lb (68 kg)

Spring checking length	1.69 in (42.92 mm)
Number of springs (PTO)	12
Spring colour	red
Spring pressure (at checking length)	131-140 lb (59-63 kg)
Spring checking length	1.41 in (35.81 mm)
Pedal free-play	$\frac{7}{8}$ to 1 in (22 to 25 mm)
Hand lever free-play	$1\frac{1}{8}$ to $2\frac{1}{8}$ in (48 to 54 mm)
Release lever height, i.e.: Distance from baseplate or flywheel face to	
transmission release lever plate	5.385-5.215 in (136.78-132.46 mm)
PTO release lever plate	6.37-6.27 in (161.80-159.26 mm)

Single Clutch — 1200 Replacement unit

Clutch type	Borg and Beck 12AS
Plate type and diameter	Borglita, 12 in
Plate facing material	Mintex H19
Plate thickness (new)	0.52 in (13.21 mm)
Number of springs	16
Spring colour	lavender/black
Spring pressure (at checking length)	112-122 lb (50-55 kg)
Spring checking length	1.69 in (42.92 mm)
Pedal free-play	1 in (25.4 mm)
Release lever height, i.e.: Distance from tips of release levers to flywheel face when clutch is assembled with four 0.520 in (13.2 mm) spacers in place of driven plate	2.25 in (57.15 mm)

CLUTCH SERVICE TOOLS

Baseplate Kits

Basic Baseplate Kit (No. 1) can be used for all Selectamatic Tractor clutches and the various spacers and adaptors, etc., required for different clutches are available in kits so that tool requirements can be matched to the actual range of clutches being serviced.

The list of Baseplate Kits shows the full range, and contents, of kits and the tractor models, and clutches, for which they are required.

As it is essential to use the correct adaptors and spacers, etc., the List of Setting Equipment shows spacers and adaptors to use for each clutch.

Flywheel Kits

Clutches can be set on the flywheel by using the kits shown on pages 12 and 13.

These kits are not available now as a service tool.

The information has been included for kits already in use.

For best results, it is recommended that a baseplate kit is used for setting a clutch.

BASEPLATE KITS

Tractor	Clutch	Kit No. and Part No.	Contents of Kit			Remarks
			Part No.	Description	Qty	
All models	All types	Kit No. 1 961850	912917	baseplate	1	Basic baseplate Kit
			961845	centre pillar	1	
			961844	actuator	1	
			961846	setting finger, short	1	
			961086	stud, $\frac{3}{8}$ UNC x $3\frac{1}{2}$ in.	9	
			19472	washer, $\frac{3}{8}$ in.	9	
			607045	nut, $\frac{3}{8}$ UNC	9	
			602806	setscrew, $\frac{1}{8}$ UNC x $1\frac{1}{2}$ in.	6	
			961087	socket, $\frac{1}{4}$ AF (ED 562)	1	
			961697	code card	1	
			961847	operating instructions	1	
			961848	fibre box	1	
Livedrive models						
770, 780, 880	Borg and Beck 10/10 in.	Kit No. 2 961856	912723	adaptor — centre pillar	1	Used with Kit 1
			961853	spacer, Code 8 — centre pillar	1	
990	Borg and Beck 11/10 in.		908888	spacer, Code 16X — centre pillar	1	
			961855	spacer, Code 14 — pressure plate	3	
3800, 4600	Borg and Beck 10/10 in.		912724	spacer — cover to baseplate	9	
780, 880	Laycock 10/10 in.		962577	spacer — pillar adaptor	1	Used with Kits 1 and 2
1200	Borg and Beck 11/11 in.	Kit No. 7 962135	920203	setting finger, long	1	Used with Kits 1, 2 and 4
			920198	adaptor — centre pillar (PTO)	1	
			920199	adaptor — centre pillar (Trans.)	1	
			962139	spacer, Code 13 — pressure plate	3	
			920202	bolt, $\frac{3}{8}$ x $\frac{1}{2}$ UNC, special	9	
			920201	nut, $\frac{1}{2}$ UNC, special	9	
			920204	adaptor plate — actuator	1	
			962188	retaining staple	3	
			962147	socket (ED 500)	1	
			962220	code card	1	
			962138	operating instructions	1	
Non-Livedrive models — Single-plate clutch						
770	Borg and Beck 9 in.	Kit No. 4 961862	961857	spacer, Code 3 — pressure plate	4	Used with Kits 1 and 2
880	Borg and Beck 10 in.					
990	Borg and Beck 11 in.					
1200	Borg and Beck 12 in.					
Non-Livedrive models — Twin-plate clutch						
880	Borg and Beck 10/10 in.	Kit No. 3 961861	961843	spacer, Code 17X — pressure plate	3	Used with Kits 1 and 2
990	Borg and Beck 10/10 in.					
990	Borg and Beck 11/10 in.					

SETTING EQUIPMENT REQUIRED WHEN USING BASEPLATE

Tractor	Clutch type	Centre pillar spacer	Centre pillar adaptor	Pressure plate spacer	Cover spacer
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	Code 8 (961853)	912723	Code 14 (961855)	912724
780 880	Laycock 10/10 in.	Code 8 (961853)	912723 + 962577	Code 14 (961855)	912724
990	Borg and Beck 11/10 in.	Code 16X (908888)	912723	Code 14 (961855)	912724
1200	Borg and Beck 11/11 in.	Code 16X (908888)	920199 (Trans.) 920198 (PTO)	Code 13 (962139) Code 3 (961857)	none none
Non-Livedrive models — Single-plate clutch 770	Borg and Beck 9 in.	Code 8 (961853)	none	Code 3 (961857)	none
780 880 3800 4600	Borg and Beck 10 in.				
990	Borg and Beck 11 in.				
1200	Borg and Beck 12 in.	Code 16X (908888)	none	Code 3 (961857)	none
Non-Livedrive models — Twin-plate clutch 880	Borg and Beck 10/10 in.	Code 8 (961853)	912723	Code 17X (961843)	912724
880 990 990	Borg and Beck 10/10 in. Borg and Beck 10/10 in. Borg and Beck 11/10 in.	Code 16X (908888)	912723	Code 17X (961843)	912724

KITS FOR USE WITH FLYWHEELS

Tractor	Clutch	Kit No. and Part No.	Contents of Kit			Remarks
			Part No.	Description	Qty	
All models	All types	Kit No. 10 961866	961845	centre pillar	1	Basic flywheel kit
			961844	actuator	1	
			961846	setting finger, short	1	
			13179	bolt, $\frac{3}{8}$ BSF x $3\frac{1}{2}$ in.	2	
			961877	stud, $\frac{3}{8}$ BSF x $3\frac{3}{8}$ in.	8	
			19472	washer, $\frac{3}{8}$ in.	10	
			19403	nut, $\frac{3}{8}$ BSF	10	
			961864	socket, $\frac{3}{8}$ BSF (ED 600)	1	
			961865	operating instructions	1	
			961088	code card	1	
			961848	fibre box	1	
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	Kit No. 11 961870	961867	adaptor, No. 1 — flywheel	1	Used with Kit 10
			961868	adaptor, No. 9 — centre pillar	1	
			961853	spacer, Code 8 — centre pillar	1	
			961859	spacer, Code 10 — separator plate	3	
			961855	spacer, Code 14 — pressure plate	3	
			961869	setting finger, short	1	
770 780 880 3800 4600	Borg and Beck 10/10 in.	Kit No. 14 961873	961873	adaptor, No. 2 — flywheel	1	Used with Kits 10, 11 and 12
780 880	Laycock 10/10 in.		962577	spacer — pillar adaptor	1	Used with Kits 10 and 11
990	Borg and Beck 11/10 in.	Kit No. 12 961871	908888 961086 607045 961087	spacer, Code 16X — centre pillar stud, $\frac{3}{8}$ UNC x $3\frac{3}{8}$ in. nut, $\frac{3}{8}$ UNC socket, $\frac{3}{8}$ AF (ED 562)	1 9 9 1	Used with Kits 10 and 11
1200	Borg and Beck 11/11 in.	Kit No. 21 962137	920199 920198 962139 920203 920204 962188 920200 920201 962147 962138 962221	adaptor — centre pillar (Trans.) adaptor — centre pillar (PTO) spacer, Code 13 — pressure plate (Trans.) setting finger, long adaptor plate — actuator retaining staple stud, $\frac{7}{8}$ UNC x $5\frac{1}{2}$ in. nut, $\frac{7}{8}$ UNC socket (ED 500) operating instructions code card	1 1 3 1 1 3 9 9 1 1 1	Used with Kits 10, 11, 12, 14 and 19
Non-Livedrive models—Single-plate clutch 770	Borg and Beck 9 in.	Kit No. 18 961851	961858 602806	spacer, Code 11 — centre pillar setscrew, $\frac{5}{16}$ UNC x $1\frac{1}{8}$ in.	1 6	Used with Kits 10, 11, 15, 17
780 880 3800 4600	Borg and Beck 10 in.	Kit No. 17 961876	961876	adaptor, No. 4 — flywheel	1	Used with Kits 10 and 11
990	Borg and Beck 11 in.	Kit No. 19 908889	908889	spacer, Code 15X — centre pillar	1	Used with Kits 10 and 11
1200	Borg and Beck 12 in.	Kit No. 22 962448	962139 912724	spacer, Code 13 — pressure plate spacer — pressure plate	4 4	Used with Kits 10, 11, 14, 17
Non-Livedrive models — Twin-plate clutch 880 990 990	Borg and Beck 10/10 in. Borg and Beck 10/10 in. Borg and Beck 11/10 in.	Kit No. 13 961872	961855	spacer, Code 14 — separator plate	3	Used with Kits 10, 11 and 12

SETTING EQUIPMENT REQUIRED WHEN USING FLYWHEEL

Tractor	Clutch type	Flywheel adaptors	Centre pillar adaptor	Centre pillar spacer	Pressure plate spacers	
					Transmission	PTO
Livedrive models 770 780 880 3800 4600	Borg and Beck 10/10 in.	No. 1 (961867) and No. 2 (961873)	No. 9 (961868)	Code 8 (961853)	Code 14 (961855)	Code 10 (961859)
780 880	Laycock 10/10 in.	Nos. 1 and 2 (961867 and 961873)	No. 9 (961868) and 962577	Code 8 (961853)	Code 14 (961855)	Code 10 (961859)
990	Borg and Beck 11/10 in.	No. 1 (961867)	No. 9 (961868)	Code 16X (908888)	Code 14 (961855)	Code 10 (961859)
1200	Borg and Beck 11/11 in.	Nos. 1 and 2 (961867 and 961873)	920199 920198	Code 16X (908888) Code 16X (908888)	Code 13 (962139) —	Code 10 (961859)
Non-Livedrive models—Single-plate clutch 770	Borg and Beck 9 in.	Nos. 1 and 4 (961867 and 961876)	—	Code 11 (961858)	Code 3 (961857)	—
880 3800 4600	Borg and Beck 10 in.	Nos. 1, 2, 4 (961867, 961873 and 961876)	—	Code 8 (961853)	Code 3 (961857)	—
990	Borg and Beck 11 in.	Nos. 1 and 4 (961867 and 961876)	—	Code 15X (908889)	Code 3 (961857)	—
1200	Borg and Beck 12 in.	Nos. 1 and 2 (961867 and 961873)	No. 9 (961868)	Code 16X (908888)	Code 13 + 912724	—
Non-Livedrive models — Twin-plate clutch 880	Borg and Beck 10/10 in.	No. 1 (961867)	No. 9 (961868)	Code 8 (961853)	Code 14 (961855)	—
990 990	Borg and Beck 10/10 in. Borg and Beck 11/10 in.	No. 1 (961867)	No. 9 (961868)	Code 16X (908888)	Code 14 (961855)	—

CLUTCH FAULT DIAGNOSIS

The most common causes of faulty clutch operation are summarised below for easy reference and if unsatisfactory operation is experienced the appropriate section should be consulted. When a clutch is removed for examination all the points applicable should be checked, because if the fault is due to more than one cause these must all be

rectified in order to obtain satisfactory operation.

Operating conditions can also have an effect on clutch operation and these should not be overlooked when investigating clutch problems. The most common causes of clutch failure are due to the operator riding the clutch pedal or not maintaining sufficient pedal free-play.

Double Livedrive Clutch

Transmission Clutch Slip

1. Insufficient pedal free-play.
2. Insufficient clearance in hand clutch linkage.
3. Cross shaft tight in its bearings.
4. Plate facings worn.
5. Plate facings contaminated with oil.
If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals. The gearbox oil can also leak along the inside of the clutch driveshaft if the felt seal is misplaced or damaged.
6. Thrust springs weak.
7. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the flywheel.
8. Spring cups in cover damaged, causing the cups to foul the spring coils and preventing the springs from exerting their full pressure.
9. Excessive material ground from separator plate, or pressure plate, causing reduction of spring pressure.
10. Pressure plate surface has distortion, caused by high temperature.

Power Take-off Clutch Slip

1. Incorrect adjustment of the three inner adjusting screws.
2. Worn or distorted linings.
3. Separator plate tight in flywheel.
4. Thrust springs weak.
5. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the drive plates.
6. Excessive material ground from separator plate causing reduction of spring pressure.
7. Spring cups in cover damaged, causing cups to foul the spring coils and preventing the springs from exerting their full pressure.
8. Separator plate surface has distortion, caused by high temperature.

Transmission Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of hand clutch linkage.
3. Incorrect adjustment of inner cover adjusting screws and/or pedal roller eccentric.
4. Incorrectly adjusted clutch stop.
5. Plate facings dragging due to being contaminated with oil.
If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals. The gearbox oil can also leak along the inside of the clutch driveshaft if the felt seal is misplaced or damaged.
6. Incorrect release lever setting.
7. Wear in release mechanism: release lever ends, pivots or needle rollers.
8. Drive plate tight on clutch shaft splines.
9. Drive plate distorted: the plate should not be more than 0.015 in. (0.38 mm) out of true.
10. Driveshaft not revolving freely in cover bearing. This may be due to a seized or damaged bearing, but can also be caused by the bearing being distorted by the cover bore. The bearing must not be tight in the bore and if necessary the bore should be scraped out until the bearing can be pushed into place by hand. The bearing housing must also be concentric with the clutch cover and to check this it is necessary to remove and dismantle the clutch, then replace the cover assembly on the flywheel. Bearing bore run-out can then be checked with a dial gauge: if the total dial variation exceeds 0.004 in. (0.10 mm) correct by scraping the bore. A slight increase in bore diameter will not be detrimental.
11. Power take-off shaft fouling inside of clutch shaft. There should be no contact between the cardan shaft and driveshaft except by the felt sealing ring. Straighten the cardan shaft if it is more than 0.005 in. (0.13 mm) out of true when turned between the centres. Check the inner bore of the clutch driveshaft: if the bore is marked cardan shaft is out of true.

12. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be radial clearance between the shaft and bearing, 0.0015 in. (0.04 mm) on 6-speed and 0.006 in. (0.15 mm) on 12-speed — and check the gearbox mountings: the gearbox is not mounted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".
13. Separator plate tapered across diameter. The plate should be completely flat with a maximum of 0.002 in. (0.05 mm) surface ripple.

Power Take-off Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of cover adjusting screws.
3. Drive plate facings bonded to flywheel, due to infrequent use. It is important that the power take-off clutch is disengaged periodically, to prevent any possibility of the facings adhering to the flywheel face.
4. Incorrect release lever height setting.
5. Distorted drive plate: the plate should not be more than 0.015 in. (0.38 mm) out of true.
6. Seized flywheel spigot bearing.
7. Insufficient clearance between separator plate and flywheel. The plate teeth backlash can be checked with a feeler gauge and should be 0.007–0.011 in. (0.18–0.28 mm) on a 990 clutch, or 0.010–0.014 in. (0.25–0.35 mm) on other clutches.

Dual Independent Clutch

Transmission Clutch Slip

1. Insufficient pedal free-play.
2. Cross shaft tight in bearings
3. Release bearing housing tight on support snout.
4. Plate facings worn.
5. Plate facings contaminated with oil. If facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to over-filling or misplaced seals. Gearbox oil may also leak along inside of clutch drive shaft if heart-shaped seal is displaced or damaged.
6. Thrust springs weak.
7. Pressure plate lugs binding in cover slots and preventing pressure plate being held tightly against separator housing.
8. Spring cup in cover damaged and causing cups to foul coils and prevent springs exerting full pressure.
9. Excessive material ground from pressure plate, causing reduction of spring pressure.
10. Pressure plate surface has distortion, caused by high temperature.

Power Take-Off Clutch Slip

1. Insufficient free-play in linkage.
2. Cross shaft tight in bearings.
3. Hand lever pivot seized.

4. Pressure plate lugs binding in separator housing.
5. Release levers, or toggles, binding or fouling.
6. Worn plate facings.
7. Weak thrust springs.
8. Pressure plate surface has distortion, caused by high temperature.

Transmission Clutch Drag

1. Incorrect free-play adjustment.
2. Incorrectly adjusted clutch stop.
3. Plate facings dragging due to being contaminated with oil. If facings are renewed because of oil contamination, the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling or displaced front seals. Gearbox oil can also leak along inside of clutch driveshaft if heart-shaped seal is displaced or damaged.
4. Incorrect release lever setting.
5. Wear in release mechanism, release lever ends or pivots.
6. Driven plate tight on shaft splines.
7. Driven plate distorted: plate should not be more than 0.015 in. (0.38 mm) out of true.
8. Driveshaft not revolving freely in separator housing bearing. This may be caused by a seized or damaged bearing, but can also be caused by bearing being tight in housing bore. The bearing must not be tight in bore.

and bore must be concentric. If bore variation exceeds 0.004 in. (0.10 mm) when checked with dial gauge, correct by scraping bore. A slight increase in bore diameter will not be detrimental.

9. Power take-off cardan shaft fouling inside of clutch driveshaft. There should be no contact between shafts, except by the sealing ring. Straighten cardan shaft if it is more than 0.005 in. (0.13 mm) out of true when turned between centres.
10. Muff coupling end-float or alignment: coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise clutch and gearbox shafts are not in line. If shafts are not in line, check clutch support snout bearing — there should be 0.0015 in. (0.04 mm) radial clearance be-

tween shaft and bearing — and check gearbox mountings: gearbox is not mounted rigidly in frame but should have not less than 0.012 in. (0.30 mm) "float" when gearbox cover is bolted down.

Power Take-Off Clutch Spin

1. Incorrect free-play in hand lever.
2. Driven plate facings bonded to flywheel due to infrequent use. It is important that PTO clutch is disengaged periodically, to prevent any possibility of facings adhering to flywheel face.
3. Incorrect release lever height setting.
4. Distorted driven plate: plate should be not more than 0.015 in. (0.38 mm) out of true.
5. Seized flywheel spigot bearing.

Single Clutch

Clutch Slip

1. Incorrect pedal free-play.
2. Incorrect adjustment of hand clutch linkage.
3. Cross shaft tight in its bearings.
4. Drive plate facings worn.
5. Drive plate facings contaminated with oil. If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.
6. Thrust springs weak.
7. Pressure plate lugs binding in cover slots and preventing plate from being held tightly against the flywheel.
8. Excessive material ground from pressure plate, causing reduced pressure of thrust springs.
9. Pressure plate surface has distortion, caused by high temperature.

Clutch Spin

1. Incorrect pedal free-play.
2. Incorrect release lever height setting.
3. Clutch stop friction pad worn.

4. Plate facings dragging due to being contaminated with oil. If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.
5. Drive plate distorted: plate should be not more than 0.015 in. (0.38 mm) out of true.
6. Drive plate hub tight on clutch shaft splines.
7. Worn release mechanism: release lever ends, pivots or eyebolts.
8. Seized flywheel spigot bearing.
9. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be 0.0015 in. (0.04 mm) radial clearance between the shaft and bearing — and check the gearbox mountings: the gearbox is not bolted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".

Twin Plate Clutch

Clutch Slip

1. Insufficient pedal free-play.
2. Cross shaft tight in its bearings.
3. Plate facings worn.
4. Plate facings contaminated with oil.

If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling, or misplaced front seals.

5. Thrust springs weak.
6. Pressure plate lugs binding in cover slots and preventing pressure plate from being held tightly against the flywheel.
7. Spring cups in cover damaged, causing the cups to foul the spring coils and preventing the springs from exerting their full pressure.
8. Excessive material ground from separator plate, causing reduction of thrust spring pressure.
9. Separator plate surface has distortion caused by high temperature.
8. Drive plates distorted. Plates should be not more than 0.015 in. (0.38 mm) out of true.
9. Driveshaft not revolving freely in cover bearing. This may be due to a seized or damaged bearing, but can also be caused by the bearing being distorted by the cover bore. The bearing must not be tight in the bore and if necessary the bore should be scraped out until the bearing can be pushed into place by hand. The bearing housing must also be concentric with the clutch cover and to check this it is necessary to remove and dismantle the clutch, then replace the cover assembly on the flywheel. Bearing bore run-out can then be checked with a dial gauge: if the total dial variation exceeds 0.004 in. (0.10 mm) correct by scraping the bore. A slight increase in bore diameter will not be detrimental.

Clutch Drag

1. Incorrect pedal free-play adjustment.
2. Incorrect adjustment of inner cover adjusting screws.
3. Clutch stop friction pad worn.
4. Plate facings dragging due to being contaminated with oil.
If the facings are renewed because of oil contamination the oil leakage should be rectified to prevent a recurrence. Possible sources of oil leakage are: rear main bearing leakage; gearbox leakage due to overfilling or misplaced seals.
5. Incorrect release lever setting.
6. Wear in release mechanism: release lever ends, pivots or needle rollers.
7. Driven plates tight on shaft splines.
10. Muff coupling end-float or alignment: the coupling should have not less than 0.010 in. (0.25 mm) end-float and should be free to engage in all spline positions through 360°, otherwise the clutch shaft and gearbox input shafts are not in line. If the shafts are not in line check the clutch shaft support bearing — there should be 0.0015 in. (0.04 mm) radial clearance between the shaft end bearing — and check the gearbox mountings: the gearbox is not bolted rigidly to the main frame but should have not less than 0.012 in. (0.30 mm) "float".
11. If a rear-mounted hydraulic pump, driven directly from the flywheel, is fitted, examine the driveshaft bore to ensure that it is not contacting the pump driveshaft.

HOW TO REMOVE AND INSTALL 770, 780 AND 3800 TRACTORS

Removal

The clutch can be removed after the combined gearbox top and clutch housing has been removed. Procedure for Livedrive and Non-Livedrive differs on one point only — on Livedrive models the power take-off unit must be removed so that the PTO cardan shaft can be withdrawn clear of clutch.

1. Remove earth lead from battery terminal. Remove fuel tank with instrument panel attached to it. Disconnect throttle control from hand lever and drag link from drop arm. If tractor is fitted with power-assisted steering, tie steering ram to tractor frame to avoid straining pipes. Remove steering box, complete with column and wheel.
2. Disconnect wiring from starter and remove starter from clutch housing. Remove the two figure-of-eight spring clips which hold clutch fork to release bearing carrier: these are accessible through aperture on underside of main frame.
3. Remove gearbox cover — 17 bolts into main frame, five bolts into rear axle. Note that one of the main frame bolts is inside the steering box oil bath. See Figure 1.
4. On Livedrive models, drain transmission oil into a *clean* container, remove power take-off unit and withdraw cardan shaft until it is clear of clutch.

NOTE: Tractors with a hydraulic filter warning lamp have a switch for this lamp under the PTO unit and it is necessary to remove switch adaptor from PTO case before PTO unit can be withdrawn. See Figure 2.

5. Release circlip at front of muff coupling and slide coupling forward. Detach release bearing support snout from frame by removing the three fixing bolts. If tractor is fitted with a band type clutch stop, disconnect the band and remove stop assembly out of frame.
6. Remove bolts attaching clutch cover to flywheel, placing a $\frac{7}{8}$ in. nut under each release lever at the same time, to prevent the thrust springs expanding too far. Lift clutch and driveshaft assembly out of frame; raise cover first and follow with shaft.
7. Retain the three flywheel springs until required for assembly.




Figure 1.
GEARBOX COVER — 780/770/3800 TRACTORS
A. Steering box oil bath B. Main frame bolt hole




Figure 2.
REMOVING OIL FILTER SWITCH ADAPTOR
A. PTO case B. Adaptor C. 'O' ring — adaptor

Installation

After servicing the clutch unit (see appropriate page) and checking the components with reference to the fault-finding information on Page 15, replace the clutch in reverse order to removal, main points to note being listed below.

1. Fit PTO plate with hub towards flywheel and separator plate with assembly marks aligned.
2. Place the three springs in flywheel holes. Assemble release bearing and support snout on shaft, fitting new 'O' ring in snout groove.
3. Fit driveshaft assembly in clutch cover and fit transmission driven plate on shaft — hub towards flywheel — then fit assembly on to flywheel. Line up dowel holes and replace bolts, tightening evenly and by diametrical selection until fully tightened.
4. Check muff coupling end-float. This should be not less than 0.25 mm (0.010 in.) and may be increased by removing shims from behind rear end of coupling.
5. Before fitting gearbox cover, check that clutch cross shaft spring is correctly located against fork and casting and set clutch stop, if fitted. See Page 62.
6. Refit the figure-of-eight spring clips to clutch fork, working through the bottom of main frame.
7. When assembly is completed, adjust pedal free-play and if necessary reset pedal, or lever, on cross shaft splines. See Page 31. Adjust clutch stop, if fitted.

880 AND 990 TRACTORS

The most convenient method of removing the clutch depends on the tractor type. All Livedrive tractors are fitted with a band type clutch brake. On early tractors this prevented the muff coupling on six-speed tractors being slid far enough forward to clear the gearbox driveshaft. This means that the clutch must be removed by splitting the tractor — as on 12-speed models.

On later models a change was introduced reducing the width of the clutch-stop drum, allowing the clutch to be removed out of the top of main frame after the gearbox cover has been removed — as on Non-Livedrive models.

Clutch removal methods for different tractors are as below:

1. **Non-Livedrive 6-speed Tractors:** Remove gearbox and clutch cover and lift out the clutch — Method 'A'.
2. **Livedrive 6-speed Tractors:** Up to Serial Numbers 990/A/487806, 880/A/533604. Split the tractor and remove the clutch from the flywheel — Method 'B'.
3. **Livedrive 6-speed Tractors:** Serial Numbers 990/A/487807 onwards, 880/A/533604 onwards, 4600/900001 onwards. Remove the gearbox and clutch cover and lift out the clutch — Method 'A'.
4. **Livedrive 12-speed Tractors:** Split the tractor and remove the clutch from the flywheel — Method 'B'.




Figure 3. STEERING BOX REMOVAL

A. Bolts, box to gearbox cover B. Droparm nut

Removal — Method 'A'

1. Disconnect fuel pipes, wiring, and throttle and stop control linkages. On 990 tractors, remove throttle lever.
2. Remove fuel tank and instrument panel. Disconnect steering drop-arm.
3. On 990 Tractors only: Remove steering-box to obtain access to the bolt beneath it which passes through the spacer wedge and into the clutch housing.
4. Remove all gearbox cover fixing bolts (five through the rear axle) and lift cover off main frame. On 880 Tractors the gearbox cover and steering-box can be removed as a unit.
5. On 990 Tractors only: Disconnect the main lead and remove starter motor.
6. Slacken clutch free-play adjusting screw and remove clutch cover.
7. On Livedrive models only: Remove clutch stop brake band by disconnecting it at both ends. Release circlips locating the brake drum and slide the drum forwards to the support snout.




Figure 4. 990 GEARBOX COVER

A. Clutch cover
B. Bolts, cover to engine
C. Bolts, cover to frame
D. Setscrew, cover to engine
E. Wedge
F. Bolts gearbox cover to frame
G. Bolt, gearbox to clutch cover
H. Gearbox cover
J. Main frame

8. Release circlip retaining the muff coupling and slide coupling fully forwards. Do not disturb muff coupling end-float adjusting shims on gearbox drive shaft.
9. On Livedrive models remove PTO housing and withdraw PTO cardan shaft.

NOTE: Tractors with a hydraulic filter warning lamp have a switch for this lamp under the PTO unit and it is necessary to remove switch adaptor from PTO case before PTO unit can be withdrawn. See Figure 5.

10. Detach support housing from main frame by unscrewing the three fixing bolts and remove the two spring clips securing cross-shaft fork to release bearing carrier.
11. On Non-Livedrive models, slide the support snout and clutch shaft away from flywheel until the clutch shaft is clear of flywheel spigot bearing.
12. Remove the bolts fixing clutch cover to flywheel, wedging a $\frac{7}{16}$ in. nut under each release lever as this is done. These nuts prevent the clutch thrust spring expanding too far and so assist removal.
13. Ease clutch cover assembly off its dowels and remove the clutch and shaft assembly complete from the main frame.
On Non-Livedrive tractors this can be done by lifting the rear of the clutch shaft until it is clear of the gearbox and then lifting the whole unit rearwards and upwards. On Livedrive tractors the rear of the clutch shaft must first be lowered into the main frame and the unit then lifted out, cover assembly first.
14. Mark the clutch cover, separator plate and flywheel to ensure replacement in the same relative positions. Retain the three push-off springs for reassembly.

Installation — Method 'A'

The clutch should be replaced in the reverse order to removal, special attention being given to the following points.

1. Examine the flywheel spigot bearing and replace if necessary. Place a small quantity of high-melting-point grease in the cavity behind the bearing.
2. Check the fit of the drive plates on the clutch shaft. The plates should slide freely on the spline without excessive slackness. Fit the plates with the hub towards the flywheel. (Borglite plates — "Flywheel" mark to flywheel.)
3. Check that the separator teeth backlash is within the following limits:
10/10 in. double clutch—0.010 in. to 0.014 in.
11/10 in. double clutch—0.007 in. to 0.011 in.

If the tolerance is above that quoted, rattle may occur when the clutch is operated but if the tolerance is below that quoted then difficulty may be experienced in engaging the PTO gears, due to the PTO clutch dragging.




Figure 5. REMOVING OIL FILTER SWITCH ADAPTOR

A. PTO case B. Adaptor C. 'O' Ring

4. Refit clutch cover with dowel holes in alignment with dowels in flywheel. Tighten the bolts progressively and by diagonal selection to avoid distortion of cover.
5. Check that the clutch cross shaft is not binding in the main frame.
6. Check that PTO cardan shaft is straight. If bent more than 0.005 in. (0.127 mm) it may foul on the inside of the hollow transmission shaft.
7. Check that the support snout bearing is a clearance fit on the clutch shaft. The bearing should have a radial clearance of 0.0015 in. (0.4 mm), 6-speed or 0.006 in. (0.15 mm) 12-speed.
8. Check the muff coupling end-float, 0.010 in.—0.040 in. (0.25 mm–1.01 mm).
9. On 990 Tractors the clutch housing and gearbox cover are bolted together to increase the effective depth of the main frame. To obtain a rigid attachment a taper wedge is fitted between the housing and the cover faces. After firmly bolting the clutch housing and gearbox cover in position — tightening the gearbox cover against the rear axle before tightening the cover-to-main-frame bolts — place the wedge in the gap between the two faces and push the bolts through the holes in gearbox cover. If the wedge is not tight in the gap when the bolts are screwed in loosely, push the wedge upwards and add shims so that when the bolts are tightened the housing and cover are bolted solidly together without being distorted.
10. When the replacement is completed, readjust the clutch free-play and clutch stop, if fitted.

Removing the Clutch by Splitting the Tractor — Method 'B'



WARNING: The two halves of the tractor are very heavy. The job must be done on a hard level floor. Use equipment which can hold the weight of the tractor easily. Serious injury can result from not following these instructions.

As the engine and transmission units are heavy and require to be aligned carefully when being reassembled, this operation should be carried out with the tractor standing on firm, level ground.

Place a jack under the front end of rear main frame so that it can support the rear half of tractor when the front main frame is withdrawn. Place a block of wood between the jack and main frame and extend the jack so that it takes weight but does not lift the tractor. Drive two suitable wooden wedges between each side of the front extension and axle beam, so that the engine unit will remain upright. The wedges should be of hard wood and approximately 5 in. (12.5 cm) long so that they can be driven firmly into position without any possibility of

becoming dislodged. Place a trolley jack under the flywheel housing so that the engine unit can eventually be drawn forwards.

1. Disconnect throttle and stop control linkages.
2. On 990 Tractors remove the throttle lever.
3. Disconnect fuel pipes and wiring, and remove fuel tank and instrument panel.
4. Disconnect main lead and remove starter motor (990 only).
5. Disconnect steering drop-arm.
6. Remove the bolts attaching the clutch cover and rear main frame to front section of the tractor.
7. Draw the front half of tractor forwards until it is clear of clutch driveshaft. To avoid damaging the clutch plates or driveshafts adjust the two jacks so that the front and rear main frames are withdrawn squarely away from each other.
8. Fit a $\frac{7}{16}$ nut under each release lever and unbolt the clutch unit from the flywheel.
9. Mark the separator plate and withdraw it from flywheel. Retain the three push-off springs until required for assembly.




Figure 6. 880 TRACTOR "SPLIT" FOR CLUTCH REMOVAL

A. Supporting wedge

B. Clutch assembly

C. Flywheel housing

Installation — Method 'B'

1. Examine flywheel spigot bearing and replace if necessary. Place a small amount of high-melting-point grease in the cavity behind the bearing.
2. Place the three push-off springs into the holes in flywheel and fit driven plate in position (hub to flywheel).
3. Fit separator plate into flywheel with the markings aligned.
4. A mandrel, or pilot clutch shaft, Figure 7, will be required to centralise the driven plates as the clutch assembly is fitted to the flywheel. Insert this pilot shaft through the clutch cover bearing and fit transmission plate on to it (hub to flywheel side).
5. Bolt clutch assembly to flywheel, the end of the mandrel being located in the flywheel spigot bearing. Tighten bolts progressively and by diagonal selection to avoid distortion and then withdraw the mandrel.
6. Check that the adjusting screw clearances are 0.070 in. (1.8 mm) as these are more accessible when the tractor is split.
7. Check that clutch release mechanism is in order and that cross shaft is not binding in main frame. Fully release the pedal free-play adjustment.
8. Ensure that the PTO cardan shaft is engaged on the splines of the input shaft in the PTO housing and also that it is pushed fully to the rear.
9. Clean the faces of the two halves of the tractor and push together. (It is essential that the two faces should be parallel and in line and two guide studs temporarily screwed into the main frame will assist aligning the two halves.) When the clutch driveshaft enters the cover, turn the engine so that the splines on the driven plates can be lined up with those on the driveshaft and cardan shaft.
10. When the two sections are together and have entered into the dowels, fit the bolts and fully tighten.
11. Refit starter and throttle lever on the 990 Tractor.
12. Replace fuel tank, reconnect fuel pipes, throttle and stop controls, and steering drop-arm.
13. Adjust pedal linkage as described on page 31, and clutch stop, if fitted.




Figure 7. CLUTCH PLATE PILOT — LIVEDRIVE TRACTORS (EXCEPT 1200)

A. 0.874 in (22.20 mm)	B. 0.915 in (23.24 mm)	C. 1.420 in (36.07 mm)
D. 1.771 in (44.98 mm)	E. $\frac{5}{8}$ in (15.88 mm)	F. $1\frac{1}{2}$ in (38.10 mm)
G. $1\frac{1}{2}$ in (44.45 mm)	H. 5 in (127 mm)	J. $\frac{3}{8}$ in (9.5 mm) dia. hole
	K. $3\frac{1}{4}$ in (82.55 mm)	

1200 TRACTORS

Removal — Method 'A'

1. Remove bonnet top, grille and tool box. Disconnect battery and remove starter.
2. Disconnect drag link from drop arm. If tractor is fitted with power-assisted steering tie ram to tractor frame, to avoid straining pipes.
3. Unscrew engine speed indicator cable, disconnect fuel pipe and instrument panel wiring so that fuel tank and panel can be removed complete.
4. Drain steering box oil, disconnect hand throttle and remove steering box, complete with column and wheel.
5. Drain transmission oil into *clean containers*, capacity approximately 10 gallons (45.4 litres).
6. Remove seat and support from rear axle case. Remove drawbar and lower links.
7. After removing sensing unit, remove the twelve bolts attaching PTO case to axle case then remove PTO unit so that cardan shaft can be withdrawn clear of clutch. (Fig. 8.)
8. Remove gearbox cover — five bolts into rear axle case, four bolts into clutch housing and 14 bolts into main frame (two of these are inside steering cavity). (Fig. 9.)
9. Remove clutch housing — three bolts into starter support plate and six into main frame. Place PTO clutch lever in "disengaged" position and hook three retaining staples, Part No. 962188, between the PTO release levers and cover, then unlock hand lever and allow the staples to hold the levers towards the clutch cover. (Fig. 36.)
10. Release circlip at front of muff coupling from its groove in driveshaft and if coupling is fitted with wedge-shaped plungers, remove these by lifting retaining clip to one side so that plungers may be extracted. As the two plungers are fitted the opposite way round, note which way each plunger chamfer is fitted.
11. Fully unscrew adjusting nut on PTO clutch connecting rod and disconnect PTO release bearing carrier by removing the special bolt from one side and pivot pin from other side of cross shaft fork.
12. Unscrew adjusting nut on transmission connecting rod to end of thread and remove the three screws attaching support snout and clutch stop to main frame.
13. Remove the nine long bolts attaching clutch assembly to flywheel, but do not remove the short bolts attaching clutch cover to separator housing. Lift clutch unit, complete with driveshaft, release bearings and support snout, out of the tractor. Raise driveshaft first, then lift complete assembly upwards and rearwards.
14. Withdraw driveshaft from separator housing and remove release bearings, etc.




Figure 8.

PTO CARDAN SHAFT WITHDRAWN FROM CLUTCH

A. Rear axle case B. Cardan shaft




Figure 9. 1200 TRACTOR WITH CLUTCH HOUSING AND GEARBOX COVER REMOVED

- | | | |
|--------------------|------------------------------|-------------------------------|
| A. Clutch assembly | B. Transmission release fork | C. PTO release fork |
| D. Support snout | E. Muff coupling | F. Bolts — clutch to flywheel |




Figure 10. CLUTCH RELEASE MECHANISM — 1200 TRACTORS

- | | | | |
|----------------|-----------------------|--------------------|----------------------|
| A. Cross shaft | } Transmission clutch | D. Cross shaft | E. Fork |
| B. Fork | | F. Bearing carrier | G. Friction washer |
| C. Sleeve | | H. Special washer | J. Belleville washer |

Installation

Before refitting clutch unit, first check the following:

1. Examine PTO clutch linkage; lubricate hand lever catch and pivot. Check that cross shaft operates quite freely in main frame. Examine release bearing and renew if any signs of roughness are apparent. On later tractors the bearing housing is connected by a flexible tube to the cross shaft bearing grease passage so that the bearing is lubricated at the same time as the left-hand bearings. If the bearing does not have provision for being lubricated during service, ensure that it is packed with molybdenum disulphide, lithium based grease. If the pin on the right-hand side of the release bearing housing is only 2 in. (50.8 mm) long, replace this with a later type pin, Part No. 925323, which is 2½ in. (57.1 mm) long and the additional length of thread will allow six Belleville washers to be fitted in place of a single washer fitted on earlier, shorter, pin. (Fig. 10.) Fit tabwasher (626399) on left-hand pivot pin.
2. Examine transmission clutch linkage: lubricate pedal pivot and ensure that pedal does not foul starter switch wire conduit. Check that cross shaft operates freely. Lubricate pins in cross shaft fork with anti-scuffing paste. Renew release bearing if rough or dry: if bearing is renewed, fit latest type bearing, Part No. 620112. Clean inside of bearing carrier, smear it with anti-scuffing paste and check that carrier slides freely on support snout.

Refit clutch in reverse order of removal, taking note of the following:

Lower clutch stop into tractor frame and fit driveshaft, complete with release bearings, support snout, circlip and muff coupling into clutch unit. Fit PTO driven plate in flywheel and lower complete assembly into position, taking care to locate the two release bearing carriers in their forks. Slide cardan shaft into the clutch until it passes through PTO driven plate and enters flywheel spigot bearing, then bolt clutch assembly to flywheel.

Bolt support snout and clutch stop to main frame, slide muff coupling on to gearbox mainshaft and slide circlip into driveshaft groove. Muff couplings without plungers can be fitted on any spline but couplings with plungers must be fitted

with plunger holes opposite chamfered splines on shafts, the plunger tapers will then be against a chamfer and not against a spline corner. As the plunger tapers must be towards the non-driving side of spline ensure that front plunger is fitted with taper on its leading side and taper on rear plunger towards its trailing side.

No undue force should be required when sliding coupling on to gearbox shaft and, when retaining circlip is in position, coupling should have 0.008 to 0.040 in. (0.20 to 0.01 mm) end-float. If necessary this can be increased by removing shims from rear end of coupling.

Connect PTO release bearing carrier to its fork, fitting six Belleville washers, plain washer and two friction washers as shown in Fig. 10. Tighten the Nyloc nut to compress Belleville washers then unscrew a half-turn.

Set clutch stop (see Page 63) before replacing gearbox cover. Smear new cover gaskets with grease, to hold them in position, then fit cover and tighten bolts down into main frame only sufficient to hold cover against main frame face. Fully tighten bolts through rear axle case then fully tighten cover-to-main-frame bolts. Place spacing wedge in gap between gearbox cover and clutch housing. If wedge is not tight, add shims until wedge is so tight it has to be driven in with a copper hammer. When the bolts are fully tightened, housing and cover will then be bolted solidly together without distortion.

After replacing steering box, refill with oil to level-plug and refill transmission with oil after fitting PTO unit.

Ensure that both clutches have the correct amount of free-play. (See Page 54.)

Clutch Removal by Splitting the Tractor — Method 'B'



WARNING: The two halves of the tractor are very heavy. The job must be done on a hard level floor. Use equipment which can hold the weight of the tractor safely. Serious injury can result from not following these instructions.

As it is necessary to centralise the PTO release mechanism very carefully when joining the two halves of tractor together, this method of clutch removal should be carried out by experienced personnel only.

1. With tractor standing on firm, level ground and with ample space round it, firmly apply hand brake.
2. Remove silencer, bonnet top and grille. Disconnect battery leads and remove toolbox.
3. Drain transmission oil into *clean containers*, capacity approximately 10 gal (45 litres).
4. Remove starter motor. Disconnect main wiring harness connectors under fuel tank and wiring to oil warning lamp switch.
5. Release guide tube wiring after disconnecting engine speed indicator cable. Disconnect fuel and leak-off pipes from tank.

6. Disconnect throttle and stop cables from injection pump, then remove cable bracket from pump.
7. Disconnect steering drag link from drop arm. If tractor is fitted with hydrostatic steering, disconnect the two flexible ram pipes, also all four pipes from the servo valve and pipes from pump to reservoir. The two large pipes may then be extracted forwards from under fuel tank.

Important: It is essential that all pipes and connections are sealed against ingress of dirt, otherwise serious damage may occur when the system has been assembled.

8. Remove clutch pit cover. Place hand clutch lever in "disengaged" position and place a retaining staple, Part No. 962188, over each PTO release lever: it will be necessary to turn engine to bring release levers opposite cover aperture. Return hand lever to "engaged" position and check that staples are correctly positioned.
9. Remove adjusting nuts from PTO and transmission rods. Disconnect anchor from transmission cross shaft return spring. This anchor is hooked through a hole in the underside of the main frame, 6½ in. (16.5 cm) forward of main frame joint and 5 in. (12.7 cm) towards the left-hand side of the frame centre line.
10. Disconnect hydraulic pressure pipe at union underneath right-hand foot plate and disconnect pump inlet pipe from filter housing.




Figure 11. 1200 TRACTOR "SPLIT" FOR CLUTCH REMOVAL

- | | | |
|-----------------------------|------------------------------|--|
| A. Transmission cross shaft | B. PTO cross shaft | C. Transmission release bearing sleeve |
| D. Hydraulic pressure pipe | E. Hydraulic pump inlet pipe | |

Pipe is sealed by an 'O' ring inside housing and on early tractors, where pipe was fitted directly into housing, the pipe should be removed and 3 in. (76.2 mm) cut off the housing end of pipe. Thoroughly clean inside of pipe after cutting. Connecting pipe (921796), hose (917126) and clips (621960) can be fitted during assembly.

11. Remove two centre bolts from main frame joint so that trolley-jack can be located under front frame, behind oil sump. Place an adjustable stand under rear of main frame joint and extend jack and stand so that they take weight but do not lift main frame.
12. Disconnect check chains, remove bolts attaching drawbar frame to PTO and lower frame to ground. If more convenient, the drawbar can be completely removed.
13. Remove sensing unit from PTO case, then remove PTO unit from rear axle case. Withdraw cardan shaft: if coupling is not bolted to cardan shaft, insert a bolt through hole in shaft end so the shaft can be levered out until it is clear of clutch. (Fig. 8.)
14. Drive a wooden wedge between each side of main frame and front axle to hold front end of tractor vertical (A Fig. 6). Remove bolts attaching clutch cover to engine and main frame and, after ensuring that stand and jack are supporting weight of frame, remove remaining front-to-rear main frame bolts.
15. With the aid of an assistant, carefully push front of tractor forward until there is a 3 to 4 in. (8 to 10 cm) gap in frame. Remove bolt attaching return spring lever to transmission cross shaft (Fig. 12) so that shaft can turn as main frames are moved further away. If release bearing is fitted with a lubrication pipe, disconnect this from side of main frame.
16. Withdraw front of tractor until clutch is accessible then remove the nine long cover bolts and lift clutch assembly from flywheel.




Figure 12.

TRANSMISSION RELEASE FORK - 1200 TRACTORS
A. Release fork B. Cross shaft C. Return spring

Installing the Clutch

To ensure driven plates are centralised, and thus permit driveshafts to be engaged as the two halves of tractor are brought together, a pilot tool made to the dimensions shown in Fig. 12 is required.

Insert pilot through bearing in separator housing so that it centralises transmission plate then fit PTO driven plate on pilot and fit assembly on fly-wheel. Engage pilot in crankshaft spigot bearing and align cover and flywheel marks. Replace the nine long bolts and tighten evenly and by diametrical selection. Withdraw pilot when bolts have been firmly tightened.

Examination Before Assembling Tractor

Before commencing to assemble tractor, check the following:

1. Examine release bearings and renew if they show any signs of roughness or are dry. If transmission release bearing is renewed, fit the latest type bearing, Part No. 620112. Clean inside of bearing carrier and check that it slides freely on support snout.
2. If the PTO clutch fork pivot is the early type with only one Belleville washer, fit the latest type pin (925323) and six Belleville washers (626723) as shown in Fig. 10. Tighten the Nyloc nut until the Belleville washers are fully compressed then unscrew half-a-turn. Fit the latest type tabwasher (626399) on the left-hand pivot pin.
3. Check that both clutch cross shafts are quite free in their bearings. Lubricate pins on transmission fork with anti-scuffing paste.
4. Lubricate pedal pivot and check that pedal does not foul starter switch wire conduit. Lubricate hand lever catch and pivot. Check that lever pull-off spring has sufficient tension to hold lever fully forward; if necessary, replace the pull-off spring or fit an additional spring.

Assembling Tractor

1. Screw two $\frac{1}{2}$ UNC \times 6 in. (15 cm) guide studs into third hole down on each side of front main frame face. Bring the two halves of tractor together until guide studs enter appropriate holes in rear main frame. Ensure slots in transmission bearing carrier are vertical and fork inserts are positioned so that they can enter slots when cross shaft is turned, then continue bringing main frames together until cross shaft can be turned and pins engaged in carrier slots. When the frames are only 3 to 4 in. (7.5 to 10.0 cm) apart examine release fork to make sure that pins are correctly engaged in carrier slots then replace bolt in return spring lever and connect PTO bearing lubrication pipe into left-hand side of main frame.
2. Push two halves of tractor to close the gap and allow a bolt to be fitted in each side of frame but *do not tighten bolts to force frames together*. It will probably be necessary to turn engine before driven plate can be engaged on clutch shaft splines.
3. Push cardan shaft through clutch until it passes through driven plate and into fly-wheel spigot bearing. If cardan shaft cannot be pushed into spigot bearing, connect linkage and disengage PTO clutch then push shaft in whilst turning it. Refit all main frame and clutch cover bolts and firmly tighten. Connect linkage and adjust. (See Page 54.)
4. Continue assembly of tractor in reverse order of dismantling. Fit new hydraulic oil filter, or wash if earlier gauze type, before filling transmission with oil. If original oil is being replaced, pour through a funnel with a fine strainer and do not replace the last gallon, which will have accumulated any sediment. If tractor is fitted with hydrostatic steering reconnect all pipes, fill with new fluid and then bleed and check system.




Figure 13. CLUTCH PLATE PILOT — 1200 TRACTORS

A. 0.874 in (22.20 mm)	B. 0.915 in (23.24 mm)	C. 1.374 in (34.90 mm)
D. 1.420 in (36.07 mm)	E. $\frac{3}{4}$ in (19.05 mm)	F. $2\frac{1}{2}$ in (57.15 mm)
G. $1\frac{1}{2}$ in (38.10 mm)	H. 6 in (152.4 mm)	J. $\frac{3}{8}$ in (9.5 mm) dia. hole

MAINTENANCE AND REPAIR

SINGLE PLATE CLUTCH

Description

The clutch is of the dry plate type and consists of a driven plate, cover assembly and withdrawal mechanism.

The driven plate consists of a thin steel disc with a splined hub riveted to the centre and friction facings riveted to each side of the outer edge. The cover assembly is built up from a steel pressing and incorporates a cast iron pressure plate loaded with thrust springs. Mounted on the pressure plate are three release levers which pivot on floating pins retained in the eyebolts and transmit movement to the pressure plate through struts.

Operation — 880 and 990 Tractors

The withdrawal mechanism shown in Fig. 14 is that used on 880 and 990 Tractors. As the clutch pedal is depressed, the lever turns the cross shaft which moves the carbon block forward by means of the fork. As movement of the carbon block is transmitted to the release levers by the lever plate, the levers pivot on the pins and draw pressure plate away from flywheel by means of the struts, thus releasing the driven plate and disengaging the drive.

Adjustment—880 and 990 Tractors

The only adjustment required in service is the maintaining of clutch pedal "free play" from 1 to 1½ in. (2.5 to 3.8 cm). To adjust pedal free-play,




Figure 14. SINGLE PLATE CLUTCH — 990/880 TRACTORS

- | | | | |
|------------------|--------------------|------------------------|-------------------|
| A. Driven plate | B. Pressure plate | C. Thrust spring | D. Cover |
| E. Release lever | F. Eye bolt | G. Release lever plate | H. Spigot bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Operating lever | P. Pedal | Q. Roller |
| | R. Adjusting screw | | |

release locknut and turn adjusting screw until correct movement is obtained. Retighten locknut.

If hand clutch is fitted (see page 64) the rod adjusting nut should be slackened before adjusting pedal free-play and then reset afterwards to give a clearance of $\frac{1}{16}$ in. (1.5 mm).

Operation — 770 Tractors

The clutch pedal on the 770 Tractor is fitted directly on to the cross shaft, which is housed in the gearbox cover and not in the main frame as on the other models (see Fig. 15). Operation of the clutch withdrawal mechanism is, otherwise, the same as on the 880 and 990 Tractors.

Adjustment — 770 Tractors

The only adjustment required during service is the maintaining of $\frac{1}{2}$ to $\frac{3}{4}$ in. (1–2 cm) pedal free-play, to ensure that the withdrawal mechanism is disengaged when the pedal is released.

As the drive plate facings wear, pedal free-play will be reduced and when necessary should be reset by screwing the stop screw further into the main frame. When the pedal has insufficient free-play and the stop screw is screwed fully inwards, the pedal should be removed from its shaft, turned clockwise into the next serration, and refitted on shaft. The adjusting screw can then be screwed outwards until correct free-play is obtained.

As the cross shaft will turn, due to the action of the shaft return spring, when the pedal is removed, it is advisable to mark the original positions of the shaft and pedal so that the new position can be easily found.




Figure 15. SINGLE PLATE CLUTCH — 770 TRACTOR

- | | | | |
|------------------|------------------------|------------------------|-------------------|
| A. Driven plate | B. Pressure plate | C. Thrust spring | D. Cover |
| E. Release lever | F. Eye bolt | G. Release lever plate | H. Spigot bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Pedal return spring | P. Pedal | |

Servicing the Single-Plate Clutch Unit

1. Mark the position of the release levers, cover plate, pressure plate, and eyebolts so that these may be refitted in the same position should new parts be unnecessary.
2. Place the assembly on a press, with a block under the pressure plate positioned so that the cover is free to move down. Place a block or bar across top of the cover, resting on the spring bosses.
3. Compress the cover against pressure plate, unlock and remove eye nuts. Slowly release the pressure on cover until the thrust springs are fully extended.
4. Lift off cover, and remove thrust springs. Remove release levers (Fig. 16), clean and examine all parts.
5. To assemble clutch, place pressure plate on the block and replace release levers and struts (Fig. 17), taking note of the marks made during dismantling and applying a smear of grease to the pivot pins and struts.
6. Replace thrust springs on the pressure plate bosses and place cover in position on top of the springs, after ensuring that the three anti-rattle springs are in position on cover and the marks made during dismantling are in alignment.
7. With the second block placed across cover, as in dismantling, compress thrust springs until the eyebolt nuts can be replaced.
8. Remove clutch assembly from the press and depress release levers two or three times to settle the working parts.



Figure 16. REMOVING THE RELEASE LEVERS



Figure 17. REPLACING STRUT AND RELEASE LEVER

Operations 1–8 can alternatively be carried out using the Clutch Tool (see Service Tool Leaflet A3). The clutch should be bolted on to the base plate, Part No. 912917, using the long studs and nuts in the kit. The thrust springs are released by gradually unscrewing the nuts on the long studs so allowing clutch cover to lift away from pressure plate.

After reassembly the clutch should be set up as follows, using the clutch tool in Figure 18.

9. Fit No. 3 Code spacers in place of the driven plate. Position a spacer opposite each release lever, bolt clutch to base plate and fit the actuator assembly. Operate the actuator lever a few times to "bed in" the release lever mechanism.

10. Remove actuator and fit centre pillar with the correct spacer, recess downwards.

For 9 in. clutch (770 Tractor) use centre pillar spacer Code No. 8

For 10 in. clutch (880 Tractor) use centre pillar spacer Code No. 8

For 11 in. clutch (990 Tractor) use centre pillar spacer Code No. 16x.

Check release lever heights with setting finger and reset if incorrect.

11. Refit actuator and operate clutch a few times, finally rechecking the release lever heights before locking the adjusting nuts by peening the cylindrical portion of the nut into the eyebolt.

12. Fit release lever plate and secure by fitting the three retaining springs. Before moving clutch from flywheel or base plate, replace the three nuts used as packing pieces between the cover and release levers.




Figure 18. CHECKING RELEASE LEVER HEIGHT

- | | | | |
|---------------|------------------|-----------------------------|-------------------|
| A. Base plate | B. Studs | C. Spacers — pressure plate | D. Release lever |
| E. Actuator | F. Centre pillar | G. Spacer — centre pillar | H. Setting finger |

TWIN-PLATE CLUTCH

The twin-plate clutch is an optional fitting on 880 and 990 Non-Livedrive Tractors and is of similar construction to the Livedrive clutch but has both inner and outer driven plates mounted on the same driveshaft. The clutch therefore functions as a single clutch but the twin plates give it twice the facing area of a single plate unit.

Adjustment

Clutch pedal adjustment is by means of the adjusting screw on the cross shaft operating lever (Fig. 21) and this should be set to give 1 to 1½ in. (2.5 to 3.8 cm) free-play. As no intermediate stage is required, the pedal roller has no eccentric adjustment and the cross shaft lever is not equipped with two angled faces. The maintaining of sufficient free-play is the only adjustment normally required during service.

On early clutches there are three adjusting screws on the inner cover — the screws used for PTO clutch adjustment on the Livedrive clutch and shown in Fig. 21 — and if the driven plates fail to stop when the pedal is fully depressed, this may be caused by excessive clearance between the screws and pressure plate. To set the adjusting screws, remove vent cover from clutch housing and turn engine so that one of the screws is opposite cover aperture. Release locknut, insert a 0.050 in. (1.27 mm) feeler gauge through hole in clutch cover and between screw end and pressure plate. After adjusting screw so that it just holds feeler gauge, hold screw stationary and firmly tighten locknut. Turn engine and adjust the two remaining screws in the same manner. Ensure that the locknuts are fully tightened before replacing cover.




Figure 19. TWIN-PLATE CLUTCH

- | | | |
|------------------|----------------------------|----------------------|
| A. Flywheel | B. Separator plate | C. Pressure plate |
| D. Driven plates | E. Driveshaft | F. Thrust springs |
| G. Release lever | H. Release bearing | J. Spring — flywheel |
| | K. Spring — pressure plate | |

Servicing the Twin-Plate Clutch

Early twin plate clutches had an inner cover, with allen screw adjusters, similar to Livedrive clutches.

When replacing parts in these clutches, use the following parts, which are used in later clutches.

Remove the inner cover, the six light springs and cups, and discard.

Install a pressure plate K962573, three springs K625232 and two drive plates K928288.

This will give easier gear selection and a smooth engagement of the drive.

NOTE: If the original clutch has two 10 in driven plates, install a new cover assembly K924529 plus the springs and plates above.

1. To ensure re-assembly of parts in the same relative position, mark the pressure plate, release levers and covers.
2. Screw long studs into appropriate holes in clutch tool baseplate, using screwdriver slots in studs. Fit a cover spacer (912724) on each stud and place three spacers, Code 17X, on baseplate — equally spaced and positioned so that the pressure plate will rest on them. Slide clutch assembly on studs. Fit nuts on studs and tighten down evenly, and by diametrical selection, until the clutch is clamped firmly against baseplate.
3. Remove release lever thrust plate and if clutch is fitted with an inner cover, remove the three inner cover adjusting screws.
4. Remove split pins from release lever fulcrum pins. Withdraw pins and remove anti-rattle springs and release levers.
5. If required, extract pin securing roller bearing in each release lever, preparing to catch the 19 needle rollers as each pin is removed.
6. Evenly, and by diametrical selection, unscrew nuts from the long studs until thrust springs are released then remove cover and separate the various parts.

Checking the Clutch Parts

Examine all parts after cleaning, paying special attention to the following:

Release Levers: Renew if flats are worn on tips of fulcrum points. If necessary, fit new roller assemblies and lubricate with anti-scuffing paste.

Cover Bearing: Renew if bearing is tight or dry. When fitting a new bearing ensure that it is a sliding fit in housing. If necessary scrape out the housing until bearing can be pushed freely into position.

Thrust Springs: Renew any springs that are weak, damaged or rusty. As the free-length varies,

even on new springs a spring tester must be used.

Pressure Plate: If surface is cracked, blued or badly scored renew. If slightly scored the surface may be refaced provided that not more than 0.015 in. (0.38 mm) of metal is removed.

Separator Plate: If plate is cracked, blued or badly scored it should be renewed. If slightly scored the surfaces may be reground if thickness of plate is not reduced by more than 0.030 in. (0.75 mm). Also check that plate is a free sliding fit in the flywheel teeth: a tight plate will cause clutch drag and a very slack plate may rattle when the pedal is fully depressed, although separator plate rattle is not detrimental to clutch operation.

Covers: Fit pressure plate into cover and check that release lever lugs have sufficient clearance to allow 0.006 to 0.012 in. (0.15 to 0.30 mm) movement of cover; if not, file cover slots, where required, to increase clearance. On early clutches with an inner cover also check that the adjusting screw inserts are in good condition; renew these if necessary.

Separator Plate Springs: Clean out the three holes in flywheel and check springs. Clutches without inner cover also have three compression springs in pressure plate and it is important that these operate freely, otherwise clutch will spin when disengaged.

Driven Plates: Install new drive plates (see Page 63) and check that plates slide freely on shaft splines. Two special drive plates K942540 can be installed. These give a longer life, but the engagement of the drive is sudden.

Assembling and Setting a Twin-Plate Clutch

1. Place baseplate (Service Tool 961696) on bench and clean face. Screw long studs into appropriate holes in baseplate, using screwdriver slot in stud ends. Screw adaptor (912723) into centre of baseplate and place a cover spacer (912724) on each stud.
2. Position three spacers, Code 17X, on baseplate and fit pressure plate on top of spacers: ensure that spacers are equally spaced under pressure plate and plate is central with studs.
3. Lightly smear pressure plate lugs with anti-scuffing paste. Place thrust springs in position next to the release levers and the cups over the springs. Replace outer cover and fit a nut on each baseplate stud. Check that assembly marks are aligned then tighten nuts down, evenly and by diametrical selection, until cover is firmly clamped against spacers on stud.

4. Replace release levers, but not lever plates, and screw actuator into adaptor. Do not screw actuator too far into adaptor: screw it in so that when actuator lever is horizontal the release lever tips are depressed $\frac{1}{8}$ in. (3.2 mm). Operate actuator rapidly about a dozen times to settle working parts. This is essential otherwise release lever setting may change when clutch is put into operation.
5. Remove actuator and screw centre pillar into adaptor. Place the Code 16X on the centre pillar — recess in spacer downwards — then fit checking finger. Set release levers, by shimming adjuster pads, so that lever tips are within 0.002 in. (0.05 mm) of gauge finger. Hold levers down firmly by hand when checking height setting and use a feeler gauge to measure the clearance between lever and gauge finger: a 0.001 in. variation in shim thickness gives 0.0045 in. variation at lever tip. (Fig. 20.)
Shims for release lever roller pads:

0.002 in. thick	Part No. 900258
0.003 in. thick	Part No. 901723
0.010 in. thick	Part No. 904138
0.020 in. thick	Part No. 904193
6. Remove gauge, spacer and centre pillar. Screw actuator into adaptor, as in Operation 4, and operate actuator rapidly a dozen times. Remove actuator, refit centre pillar, spacer and gauge finger, then recheck that all release levers are correctly set. Re-adjust if necessary, ensuring that adjuster pad screws are firmly tightened.
7. Fit anti-rattle springs on release levers: these are quite strong and the easiest way of fitting them is to make a simple lever as shown in Fig. 29. If the pins attaching release levers to pressure plate lugs are removed and springs fitted in position, the lever can be rested against cover bearing housing and used to push release lever outward against spring until retaining pin can be fitted. (Fig. 30.)
8. Smear release lever tips with anti-scuffing paste then replace lever thrust plate and secure with spring clips. Fit a $\frac{7}{16}$ in. nut under outer end of each release lever, to prevent thrust springs expanding too far, then unscrew the stud nuts evenly and remove clutch from baseplate.




Figure 20. SETTING RELEASE LEVER HEIGHT

- | | | |
|----------------------------|----------------------------|---------------------------|
| A. Baseplate | B. Spacer — cover | C. Studs |
| D. Spacer — pressure plate | E. Adaptor — centre pillar | F. Spacer — centre pillar |
| G. Centre pillar | H. Setting finger | J. Release lever |
| | K. Adjuster pad | |

DOUBLE CLUTCH — LIVEDRIVE TRACTORS

Description

The double clutch is in effect two separate clutches mounted in tandem and controlled by a common pedal. The inner clutch (which is nearest the flywheel) transmits the drive to the hydraulic lift pump and power take-off and the outer clutch transmits the main drive to the gearbox. Disengagement of the main drive clutch does not, therefore, disengage the drive to the power take-off or hydraulic pump, which remain in operation until the second clutch is disengaged.

Operation — 880, 4600 and 990 Tractors

The operating mechanism shown in Fig. 21 is used on the 880, 4600 and 990 tractors. As the clutch pedal is depressed the pressure plate is drawn rearwards by the action of the release levers until the rear (transmission) drive plate is free and the adjusting screw clearance is reduced from 0.070 in. (1.78 mm) to 0.009-0.012 in. (0.23-31 mm). During this first stage the pedal roller will have moved along the cross shaft lever until it is in contact with both faces. Further movement of the clutch pedal will cause the roller to continue turning the




Figure 21. DOUBLE CLUTCH — 880/4600/990 LIVEDRIVE TRACTORS

- | | | | |
|--------------------------------|----------------------------|------------------------|-----------------------|
| A. Driven plate — transmission | B. Pressure plate | C. Thrust springs | D. Cover — outer |
| E. Cover — inner | F. Release lever | G. Release lever plate | H. Bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Operating lever | P. Pedal | Q. Roller |
| R. Adjusting screw — pedal | S. Adjusting screw — cover | T. Separator plate | U. Driven plate — PTO |
| | V. Driveshaft — PTO | | |

cross shaft and cause the pressure plate to move further to the rear until the adjusting screw clearance is reduced to zero: this is the second stage movement. Further movement of the pedal beyond this point (third stage) will also move the inner cover to the rear as the pressure plate is now in contact with the adjusting screws. As inner cover is withdrawn the pressure on separator plate is released so that the three flywheel springs move the separator plate rearwards, thus disengaging the PTO clutch plate.

Adjustment — 880, 4600 and 990 Tractors

As the clutch linings wear during service the separator plate and pressure plate will move closer to the flywheel and reduce the amount of pedal free-play. This should be adjusted by slackening the locknut and turning the adjusting screw until free-play is 1 to 1½ in. (2.5 to 3.8 cm). If a hand clutch is fitted (see page 26) the adjusting nut on the connecting rod should be slackened before adjusting free-play and then reset afterwards to give a clearance of ⅛ in. (1.5 mm). (Fig. 21.)

Note: The eccentric roller pin is set during manufacture and should not normally require resetting, unless new parts are fitted to the operating mechanism.

If difficulty is experienced in freeing PTO clutch, or if clutch unit has been removed, proceed as follows:

1. With the clutch housing fully tightened down, adjust the pedal free-play from 1 to 1½ in. (2.5 to 3.8 cm).
2. Set the three inner cover adjusting screws to give 0.070 in. (1.78 mm) clearance between the pressure plate and the end of the screws. The adjusting screw clearance can be checked by inserting a feeler gauge through the holes in the outer cover. If clutch housing is in position the adjusting screws are accessible when clutch pit cover (919568) is removed and engine turned to bring the screws opposite the cover aperture.
3. Depress clutch pedal until pedal roller is in contact with both faces on cross shaft lever then check the cover adjusting screw clearance. If the adjusting screw clearance is not 0.009–0.012 in. (0.23–0.31 mm) adjust by rotating the eccentric pin to the next position. (Move clockwise to increase the clearance and anti-clockwise to decrease it.) One hole movement gives approximately 0.005 in. (0.13 mm) adjustment.
4. If the correct clearance still cannot be obtained, reset the three adjusting screws to within the limits 0.065–0.072 in. (1.65–1.83 mm) to obtain correct clearance.
5. Reset pedal free-play to 1–1½ in. (2.5–3.8 cm) If new facings have been fitted set free-play to 1½ in. (3.8 cm.) to allow for bedding in.

Adjustment — Laycock Clutch: A number of 880 Tractors are fitted with a Laycock clutch, and pedal free-play adjustment on these tractors is exactly the same as the pedal adjustment previously described for tractors fitted with a Borg and Beck clutch. The internal adjustment is, however, different and if the power take-off clutch does not fully disengage when the pedal is fully depressed the adjusting screws on the three release levers should be adjusted as described on page 42 for 780 Tractors. See page 49 for repair information.

Operation — 780 and 3800 Tractors

The operating mechanism used on 780 and 3800 Tractors is shown in Fig. 22. As the clutch pedal is depressed the roller in the cross shaft fork rolls along the pedal cam and turns the cross shaft. When the pedal is depressed approximately halfway the cross shaft is only turned sufficiently to withdraw the pressure plate, far enough to release the main drive plate but not far enough to contact the three adjusting screws on the inner cover. The power take-off clutch therefore remains engaged and only the drive to the transmission is disconnected.

When the clutch pedal is fully depressed the cross shaft is turned so far that the pressure plate is drawn past the point where it contacts the three inner cover screws. The inner cover is thus also withdrawn and both transmission and power take-off clutches are disengaged.

Adjustment — 780 and 3800 Tractors

As the clutch linings wear during service the separator plate and pressure plate will move closer to the flywheel and reduce the amount of pedal free-play, thus pedal adjustment should be checked frequently and, when necessary, adjusted by means of the stop bolt in the main frame. This bolt determines position of pedal when clutch is engaged; screwing the bolt further into frame will increase pedal travel and also increase the amount of free-play. The screw should be set so that pedal free-play is $\frac{3}{4}$ to 1 in. (1.9 to 2.5 cm) and if this amount of free-play cannot be obtained because the screw head is screwed right down on to the locknut more adjustment can be obtained by repositioning the operating lever on cross shaft. First scribe a line across the




Figure 22. CLUTCH OPERATING MECHANISM — 780/3800 TRACTORS

- | | | | |
|----------------|--------------------|------------------------|--------------------|
| A. Pedal | B. Roller | C. Operating lever | D. Stop bolt |
| E. Cross shaft | F. Return spring | G. Fork | H. Connecting link |
| J. Lever | K. Adjusting screw | L. Shaft — clutch stop | |

lever and cross shaft end (this will enable the new position to be checked against the original position), then remove the two pedal springs and operating lever clamp bolt. Slide operating lever towards the end of shaft so that the splines are exposed behind the lever then firmly grip cross shaft with a pair of pliers and, whilst holding shaft clockwise against return spring inside the cover, remove lever and refit on the next clockwise spline. Check scribe marks to make sure the lever has been moved only one spline and in the correct (clockwise) direction, then refit the clamp bolt and springs and re-adjust the stop bolt.

If the amount of pedal free-play is correct, but the power take-off clutch does not fully disengage when the pedal is fully depressed, this is probably due to excessive clearance between pressure plate and inner cover adjusting screws.

To reset inner cover adjusting screws, remove cover plate from right-hand side of clutch housing and turn engine until a screw is opposite the cover aperture. Insert a feeler gauge through hole in outer cover and set adjusting screw so that it has 0.070 in. (1.78 mm) clearance then *firmly tighten the locknut*. Mark the screw with chalk so that if the engine is turned too far the same screw is not adjusted twice, then turn the engine and reset the other two screws. Finally, recheck pedal free-play and replace cover plate.

Adjustment — Laycock Clutch: A certain number of 780 Tractors are fitted with a Laycock clutch and pedal free-play adjustment on these tractors is exactly the same as the pedal adjustment previously described for tractors fitted with a Borg and Beck clutch. The internal adjustment is, however, different and if the power take-off clutch does not fully disengage when pedal is fully depressed the adjusting screws on the three clutch levers should be reset as follows:

1. Check that the clutch housing bolts are fully tightened and the pedal free-play is correct.
2. Make a feeler gauge to the dimensions shown in Fig. 23 and remove cover plate from right-hand side of the clutch housing.
3. Turn engine until a release lever is opposite cover aperture then insert cranked end of feeler gauge through open heel of lever. (Fig. 24.) Pass end of gauge over roller and pin until it goes under the adjusting screw, then release locknut and, *taking care to note the number of flats the screw is turned*, tighten screw until it just commences to hold the gauge. Firmly tighten locknut, whilst holding screw stationary, and mark lever with chalk, so that it is not adjusted again if engine is turned too far. Reset remaining screws, *not by using the gauge but by turning the screws exactly the same amount as it was necessary to turn the first screw*. This is important as it ensures the plates and facings remain parallel.




Figure 23. FEELER GAUGE — LAYCOCK CLUTCH

A.	4 in	(101.6 mm)	B.	$\frac{3}{8}$ in	(9.5 mm)
C.	$\frac{3}{32}$ in	(2.4 mm)	D.	$\frac{3}{8}$ in	(9.5 mm)
E.	0.048 in	(1.22 mm)			




Figure 24.

INTERNAL ADJUSTMENT — LAYCOCK CLUTCH

A.	Release lever	B.	Roller
C.	Adjusting screw	D.	Cover thrust button

Operation — 770 Tractors

As the clutch pedal is fitted directly on the cross shaft, and does not operate the cross shaft via a roller and double-faced lever as on 880 Tractors, the pedal has only two stages of movement. (Fig. 25.)

Depressing the pedal until the pressure plate is drawn rearwards and touches the three inner cover adjusting screws gives the first stage and disengages the transmission drive plate. Depressing pedal fully into the second stage withdraws the inner cover, due to the pressure plate pushing the three adjusting screws, and releases pressure on the separator plate. The three flywheel springs then push separator plate from flywheel and release the power take-off drive plate.

Adjustment — 770 Tractors

As the linings wear during service, pedal free-play will be reduced and this must be restored by adjusting the pedal-stop bolt. Screw the adjusting screw into main frame until pedal has $\frac{1}{2}$ to $\frac{3}{4}$ in. (1.3–2 cm) free-play. When the adjusting screw is fully screwed into main frame a further range of adjustment may be obtained by removing pedal from cross shaft and refitting on the next clockwise serration. This will give pedal a large amount of free-play and allow the adjusting screw to be screwed outwards until the correct amount of free-play is obtained. As the cross shaft will turn, due to action of the shaft return spring, when the pedal is removed, it is advisable to mark the original positions of the shaft and pedal so that the new position can be easily found.




Figure 25. DOUBLE CLUTCH — 770 TRACTOR

- | | | | |
|--------------------------------|-----------------------|------------------------|----------------------------|
| A. Driven plate — transmission | B. Pressure plate | C. Thrust springs | D. Cover — outer |
| E. Cover — inner | F. Release lever | G. Release lever plate | H. Bearing |
| J. Clutch shaft | K. Support snout | L. Release bearing | M. Release fork |
| N. Cross shaft | O. Return spring | P. Pedal | Q. Adjusting screw — cover |
| R. Separator plate | S. Driven plate — PTO | T. Cardan shaft — PTO | |

When pedal free-play is being adjusted, after the clutch unit has been serviced, it may be necessary to remove pedal from cross shaft and refit on the next clockwise serration, to allow for the change in pedal position, due to the new plate facings.

If difficulty is experienced in freeing PTO clutch, or if clutch unit has been removed from the flywheel, the three adjusting screws in the inner clutch cover should be adjusted to give 0.070 in. (1.78 mm) clearance between the pressure plate and the end of the screw.

The adjusting screw clearance can be checked by inserting a feeler gauge through the holes in the outer cover. If gearbox top is in position the adjusting screws are accessible when the cover plate is removed from right-hand side of clutch compartment and the engine turned to bring the screws opposite the cover aperture. Ensure that the locknuts are firmly tightened after setting the adjusting screws and finally set pedal free-play.

Servicing Borg and Beck Livedrive Clutch

The clutch can be dismantled by using the base plate, Service Tool 912917. (See Service Tool Leaflet A4.)

1. To ensure reassembly of the parts in the same relative position, thereby preserving the balance and adjustment of the clutch, mark the following parts:
 - a. pressure plate and inner and outer clutch covers.
 - b. release levers and pressure plate lugs.
 - c. separator plate and flywheel.
2. Remove three adjuster screws and nuts.
3. Screw the long studs into the appropriate holes in the base plate — the studs have a screwdriver slot in the end for this purpose — and fit a cover spacer (912724) on each stud. Place three Code 14 spacers on the base plate, equally spaced and positioned so that the pressure plate will rest on them. Place the clutch assembly on the studs, fit the stud nuts, and tighten down progressively and by diametrical selection.
4. Disengage release lever plate by removing the retaining springs from each release lever.
5. Remove split pins from the release lever fulcrum pins; withdraw the pins and remove release levers after removing the anti-rattle springs.
6. If required, extract the pin securing the roller bearing in each release lever, preparing to catch the 19 needle rollers as each pin is removed.
7. Slowly, and by diametrical selection, unscrew nuts on the long studs securing clutch cover to base plate so that the thrust springs are under control as the cover is released. Separate the various parts of clutch.

Checking the Clutch Parts

Before reassembling the clutch unit all parts should be thoroughly cleaned and then checked over as below.

1. Check release levers for wear. Renew if flats are worn on the tips or fulcrum points. If necessary fit new roller assemblies and lubricate with anti-scuffing paste.
2. Examine the outer cover bearing and renew if tight or dry. When fitting a new bearing ensure that it is a sliding fit in the housing otherwise the bearing will not run freely and may cause clutch spin. If necessary scrape out the housing until the bearing can be pushed freely into position.
3. Check all the clutch springs. Replace if discoloured, rusty or weak.
4. Examine pressure plate and replace if badly scored, cracked or blued. Slight scores or cracks may be removed by resurfacing. Maximum amount which can be removed — 0.015 in. (0.38 mm.)
5. Check the condition of the separator plate. If it is only worn on the transmission side, further life may be obtained by reversing it. If badly cracked or blued, it should be replaced as the maximum which can be removed by resurfacing is 0.030 in. (0.75 mm) (total both sides). Also check that the plate is a free sliding fit in the flywheel teeth: a tight plate will cause power take-off clutch spin and a very slack plate may rattle when the pedal is fully depressed. Separator plate rattle is not, however, detrimental to clutch operation.
6. Fit the pressure plate into each cover in turn and check that the clearance between the three lugs and their respective slots is sufficient to give the covers 0.006–0.012 in. (0.15–0.30 mm) total side play on the pressure plate. If not increase the clearance by filing the cover slots. If the cover slots are filed to increase the clearance, also open out the three adjusting screw-holes in the outer cover to $\frac{11}{16}$ in. (17.5 mm) to prevent any possibility of the locknuts fouling the cover and breaking the screws.
7. Examine threaded bushes in inner cover and fit new bushes if the threads are worn or if the bushes are loose. New bushes are available under Part No. 962449, and as these are threaded $\frac{1}{8}$ UNF a set of three must be

fitted, with new screws and nuts, if they are replacing $\frac{1}{4}$ UNF nuts used on earlier clutches, otherwise the clutch would be out of balance. It will also be necessary to enlarge the three outer cover holes to $\frac{11}{16}$ in. (17.5 mm) diameter, to allow sufficient clearance for the larger adjusting nuts.

To fit the bushes successfully it is necessary to make a swaging tool to the dimensions shown in Fig. 26. Make the tool from silver steel (good quality tool steel with approximately 1% carbon) and heat treat after machining. Heat to a bright red colour then quench in oil. Polish the spigot end, reheat it to a purple colour and allow to cool naturally in air.

To fit new bushes:

- Drill out the existing bushes with a $\frac{1}{2}$ in. (12.7 mm) diameter drill.
- Countersink the holes on outside of cover to $\frac{3}{8}$ in. (15.48 mm) diameter at 90° included angle.
- Press or drive the new bushes in from inside the cover until the bush shoulder is pressed firmly against inside of cover.

- Turn cover over and whilst supporting the bush on an anvil use the round end of the tool to flare the hollow end of the bush.
- Reverse the tool and use the spigot end to firmly swage the bush in position.
- With a smooth file "dress" the bush flush with the outside of the cover.

The cover and bush must be supported on an anvil during the flaring and swaging operation. A press must be used of at least 5 tons (5080 kg) capacity.

- Check the three "push-off" springs in fly-wheel.
- Examine the drive plates (see page 59) and check that the plates slide freely on the shaft splines.




Figure 26. INSERT SWAGING TOOL — BORG AND BECK

A. 0.438 in (11.11 mm)	B. 0.040 in (1.016 mm)	C. 0.025 in (0.635 mm)
D. 0.609 in (15.47 mm)	E. 0.75 in. (19.05 mm)	F. 0.312 in (7.93 mm)
	G. 0.065 in (1.65 mm)	

Assembling and Setting a Borg and Beck Double Clutch

1. Place the base plate Service Tool 912917 on the bench and clean the face.
2. Screw the long studs into the appropriate holes in the base plate; the screws have a screw-driver slot at one end for this purpose.
3. Screw the pillar adaptor (912723) into the centre of the base plate and place Code 14 spacers on the base plate, equally spaced and positioned so that they are under the release levers. Fit a cover spacer (912724) on each stud, so that when the stud nuts are tightened the spacers will be clamped between the cover flange and base plate.
4. Fit pressure plate on top of the spacers and, after lightly coating the lugs with anti-scuffing paste, fit the inner cover, springs, spring covers and outer cover. Tighten down the cover using the long studs and nuts. Check that all marks made when dismantling are re-aligned and tighten the nuts progressively and by diametrical selection to avoid distorting the cover.
5. Fit release levers.
6. Screw the actuator into the adaptor and depress the handle about twelve times to settle the release mechanism. This is essential, otherwise the release lever setting may change when

the clutch is put into operation. It is also important to bear in mind that the purpose of this is to operate the release levers in their normal working position, and the actuator must only be screwed into the adaptor far enough to bring the handle horizontal. If the actuator is screwed fully into the adaptor and the handle operated in an almost vertical position, damage to the actuator may occur.

7. Remove actuator and fit centre pillar in its place. Place the appropriate spacer, Code 8 on a 10/10 in. clutch and Code 16 on a 11/10 in. clutch, on the centre pillar, with the recess downwards, and then fit the single checking finger. (Fig. 28.)
8. Set release levers, by shimming the adjuster pads, to finger height, checking with a set of feeler gauges. A variation of 0.001 in. shim thickness will give a 0.0045 in. variation at the lever tip and the lever tips should be adjusted to within 0.002 in. (0.05 mm) of each other. Operate clutch after changing the shims to settle the parts, and hold the release levers down firmly by hand when checking the height.

Shims for release lever roller pads :

0.002 in. thick	Part No. 900258
0.003 in. thick	Part No. 901723
0.010 in. thick	Part No. 904138
0.020 in. thick	Part No. 904193




Figure 27. ASSEMBLING A DOUBLE CLUTCH — BORG AND BECK

A. Baseplate	B. Spacers — cover	C. Studs	D. Spacers — pressure plate
E. Adaptor — centre pillar	F. Pressure plate	G. Thrust spring	H. Inner cover
J. Outer cover	K. Release lever	L. Adjuster pad	M. Actuator




Figure 28. CHECKING RELEASE LEVER HEIGHT — BORG AND BECK

- | | | | |
|----------------------------|---------------------------|------------------|-----------------------------|
| A. Baseplate | B. Spacers — cover | C. Studs | D. Spacers — pressure plate |
| E. Adaptor — centre pillar | F. Spacer — centre pillar | G. Centre pillar | H. Setting finger |
| | J. Release lever | K. Adjuster pad | |




Figure 29. ANTI-RATTLE SPRING REPLACING TOOL — BORG AND BECK

- | | | |
|-------------------------------|--------------------------------|-------------------------------------|
| A. $\frac{3}{4}$ in (19.0 mm) | B. $\frac{3}{8}$ in (9.5 mm) | C. $\frac{3}{2}$ in (2.4 mm) radius |
| D. $\frac{1}{8}$ in (3.2 mm) | E. $11\frac{1}{2}$ in (292 mm) | F. $1\frac{1}{2}$ in (38.1 mm) |
| | G. $\frac{3}{2}$ in (2.4 mm) | |

9. Refit the release lever anti-rattle springs. These are of the double coil type and quite strong. The easiest way of fitting them is to make a simple tool as shown in Fig. 29. If the pins attaching the release levers to the pressure plate lugs are removed, and the springs fitted in position, the tool can be rested against the cover bearing housing and used as a lever to push the release lever outwards, against the spring, until the retaining pin can be refitted.
10. Fit the three adjusting screws and nuts into the inner cover and set them to a clearance of 0.070 in. (1.78 mm). (Note that this clearance will require resetting after the clutch is assembled on the tractor flywheel.) Refit release lever plate, securing with the spring clips.
11. Before removing the clutch from base plate, replace the $\frac{7}{16}$ in. nuts under the release levers, to prevent the thrust springs expanding too far.




Figure 30. FITTING ANTI-RATTLE SPRINGS

Laycock Double Clutch

The Laycock double clutch is fitted to a number of 880 and 780 Tractors and as this clutch does not use the same release bearing and carrier as the Borg and Beck clutch they are not directly interchangeable.

As the clutch pedal is depressed the release levers (Fig. 31) pivot first about the fulcrum rollers and then, when the adjusting screw contacts the cover thrust button, on the outer cover. When release lever is pivoting on fulcrum roller the pressure plate is drawn rearwards to release the transmission plate but the pressure of the thrust springs is transferred to the three plungers, which are pressed against the separator plate and therefore hold the power take-off driven plate firmly in engagement. Pressing the release levers so far that they pivot on the cover thrust button withdraws pressure plate and also releases the three plungers, so that the three springs in flywheel push the separator plate away from flywheel and release the power take-off plate. Both clutches are therefore disengaged when pedal is fully depressed but only the transmission clutch is disengaged if pedal is not depressed past the point where the adjusting screw contacts cover thrust button.

Servicing the Laycock Double Clutch Unit

The clutch unit can be dismantled by using clutch tool kits 961850 (Kit No. 1) and 961856 (Kit No. 2) which include base plate 912917 (see

Service Tool Leaflet A4 or C1). The parts of the tool are identical to those for Borg and Beck clutch except that a centre pillar adaptor 962577 will also be required.

1. To ensure assembly of parts in the same relative position, thereby preserving the balance of the clutch, mark the following parts.
 - a. pressure plate and outer cover
 - b. release levers and plungers
 - c. separator plate and flywheel
2. Screw long studs into appropriate holes in baseplate — the studs have a screwdriver slot for this purpose — and fit a cover spacer 912724 on each stud. Place three code 14 spacers on baseplate, equally spaced and positioned so that the pressure plate will rest on them. Place clutch assembly on studs with release levers opposite the spacers. Fit stud nuts and tighten down progressively by diametrical selection.
3. Slacken off the adjusting screws, remove release lever pivots and spring anchor pins, remove release levers and withdraw roller pins and rollers, and extract plungers.
4. Slowly, and by diametrical selection, unscrew nuts on long studs securing cover to base plate so that thrust springs are under control as cover is released. Separate the various parts of the clutch.




Figure 31. SETTING RELEASE LEVER HEIGHT — LAYCOCK

- | | | |
|-----------------------------------|-----------------------------|--------------------------------|
| A. Baseplate | B. Spacer — cover | C. Spacers — pressure plate |
| D. Adaptor — centre pillar | E. Spacer — 961853 | F. Spacer — 962577 |
| G. Setting finger | H. Release lever | J. Adjusting screw — PTO stage |
| K. Adjusting screw — lever height | L. Plunger — pressure plate | M. Roller — release lever |

Checking Clutch Parts: Before re-assembling clutch all parts should be thoroughly cleaned and then checked as below.

1. Check release levers for wear. Renew if main pivot pin holes are worn, replace adjusting screws if any flats are worn on fulcrum points. Where new adjusting screws are being fitted check that the spherical end is smooth. If there is a pip on end this should be polished away with emery cloth.
2. Examine release lever rollers and renew if any flats are apparent, fit new roller assemblies and lightly lubricate with anti-scuffing paste.
3. Examine thrust buttons (for the PTO stage). If these are excessively worn the cover should be replaced. It is not recommended that the buttons be changed in service.
4. Examine clutch cover bearing and renew if tight or dry. A new bearing should be a light push fit in cover otherwise clutch may spin because outer track will be deformed. If necessary, scrape the three housing locations until bearing can be pushed freely into position. *It is important that an equal amount is removed from each of the locating faces.* To change the bearing it will be necessary to carefully cut the three rivets, remove retaining plate and punch the rivets out of clutch cover. On re-assembly retaining plate may be secured with three round head $\frac{3}{16}$ in. diameter rivets or alternatively three round head $\frac{3}{16}$ BSF screws and nuts, the heads of the screws should be on outer face of clutch cover and the nuts should be treated with Loctite to ensure that they do not work loose.
5. Check clutch springs, replace if discoloured or rusty. It should be noted that the free length of springs may vary up to $\frac{1}{16}$ in. (1.5 mm) and this is no indication of weak springs. It is the loaded length of the spring that is important.
6. Examine spring seat insulating washers and replace if damaged or broken.
7. Examine pressure plate and replace if badly scored, cracked or blued. Slight scores or cracks may be removed by re-surfacing. Do not reduce the thickness by more than 0.015 in. (0.38 mm).
8. Fit pressure plate into cover and check that the clearance between the three lugs and their respective slots is sufficient to give cover 0.006 to 0.010 in. (0.15 to 0.25 mm) total side play on the pressure plate. If not, increase the clearance by filing cover slots.
9. Check the condition of separator plate. If it is only worn on the transmission side, further life may be obtained by reversing it. If badly cracked or blued it should be replaced as the maximum which can be removed by re-surfacing is 0.015 in. (0.38 mm) per side.

NOTE: It is inadvisable to re-use clutch springs if any re-surfacing of pressure or separator plate has been carried out. New springs and insulating washers should be fitted to ensure the clutch clamping load is maintained.

Check that separator plate is a sliding fit in flywheel; a tight plate will cause the PTO drive plate to spin and a slack plate may rattle when pedal is fully depressed. Separator plate rattle is not, however, detrimental to the operation of clutch.

10. Check the three push-off springs in flywheel and renew if necessary. These should be of equal length.
11. Examine driven plates (see Page 59) and check that the plates slide freely on shaft splines.

Assembling and Setting Clutch Unit

1. Place baseplate 912917 on bench and clean the face.
2. Screw long studs into appropriate holes in base plate; the screws have a screwdriver slot at one end for this purpose.
3. Screw pillar adaptor (912723) into centre of baseplate and place three Code 14 spacers on baseplate equally spaced and positioned so that pressure plate will rest on them. Fit a cover spacer (912724) on each stud so that when stud nuts are tightened the spacers will be clamped between cover flange and baseplate.
4. Fit pressure plate on top of spacers and lightly coat lugs with anti-scuffing paste. Fit plungers (also lightly coated with anti-scuffing paste), springs and spring insulating washers, spring covers and then the cover. Tighten down cover using long studs and nuts. Check that all identification marks made when dismantling are aligned and tighten nuts progressively and by diametrical selection to avoid distorting cover.
5. Fit release levers.
6. Screw actuator into adaptor and depress handle about twelve times to settle release mechanism. This is essential, otherwise the release lever setting may change when clutch is put into operation. It is also important to bear in mind that the purpose of this is to operate release levers in their normal working position, and actuator must only be screwed into adaptor far enough to bring the handle horizontal. If actuator is screwed fully into adaptor and handle operated in an almost vertical position, damage to actuator may occur.

7. Remove actuator and fit centre pillar in its place. Place the spacer (Code 8) and a Laycock adaptor spacer 962577, on centre pillar with the recess downwards, and then fit setting finger.
8. Set release levers with adjuster screws K, Figure 31, to finger height. The height of adjuster screws must be alike. Operate clutch again with actuator lever and recheck height. The release levers should be held down firmly by hand so that roller is in contact with plunger.
9. Refit release lever anti-rattle springs. These are of double coil type and can be easily fitted by hand. The tails of spring fit in the two anchor holes in cover, the hoop of spring fits over lever and the two eyes mount on release lever pivot pin.
10. Fit the three adjusting screws and nuts into release levers and set them as follows: If a Borg and Beck drive plate K923374 is to be installed, set to a 0.048 in. (1.22 mm) clearance. Set to 0.038 in. when a Laycock drive plate is to be installed.
11. Before removing clutch from baseplate, replace transit blocks — $\frac{3}{32}$ in. \times $\frac{1}{2}$ in. \times 2 in. (2.38 \times 12.7 \times 50.8 mm) — between cover and pressure plate at the heel of release levers to prevent thrust springs expanding too far as shown in Figure 32.

Driven Plates: When fitting the driven plates it is essential that the flanged side of plate hub faces towards flywheel. On new Borglite plate the appropriate facing will be stamped "Flywheel this Side" in red.

A complete Borg and Beck clutch assembly can be fitted if necessary without any modifications. You must use the Laycock release bearing K600085 with the Borg and Beck clutch.




Figure 32.

FITTING TRANSIT BLOCK TO LAYCOCK CLUTCH

A. Lever B. Transit block

DUAL INDEPENDENT CLUTCH — 1200 TRACTORS

Operation

The dual clutch fitted in 1200 Livedrive Tractors has two 11 in. (27.9 cm) diameter plates assembled into a single unit but each fitted with its own release mechanism. The transmission clutch is controlled by a foot pedal and the power take-off clutch controlled by a hand lever. Each clutch can therefore be disengaged, or engaged, independently of the other clutch. (Fig. 33.)

The power take-off hand lever is fitted with a catch so that the lever can be locked in the disengaged position for temporarily disengaging drive to power-driven implements. The lever should not, however, remain in the disengaged position for long periods as this would place unnecessary strain on the release mechanism. Always put the power take-off gear lever in neutral and engage the power take-off clutch when not using the power take-off.




Figure 33. SECTIONAL ARRANGEMENT OF DUAL CLUTCH

- | | | | |
|--------------------|-----------------------|--------------------|--------------|
| A. Driven plate | } Transmission clutch | F. Driven plate | } PTO clutch |
| B. Pressure plate | | G. Pressure plate | |
| C. Release lever | | H. Release lever | |
| D. Release bearing | | J. Release bearing | |
| E. Support snout | | K. Driveshaft | |

Adjustments

As the clutch facings wear during service the amount of free-play in the operating linkage will be reduced and the maintaining of sufficient free-play is the only adjustment required in the field.

Failure to maintain sufficient free-play in either the transmission or power take-off clutch linkage will cause premature wear of the release mechanism and ultimate clutch failure.

Transmission Clutch Adjustment

If the pedal free-play is less than $\frac{1}{2}$ in. (12 mm) release the locknut and unscrew the adjusting nut, to lengthen the rod, until the free-play is increased to $\frac{3}{4}$ –1 in. (1.9–2.5 cm) then tighten the locknut. (Fig. 34.)

Clutch Adjustment

The power take-off lever should have $1\frac{1}{4}$ in. (3.2 cm) free-play when in the forward – engaged – position, and to increase the amount of free-play release the locknut and unscrew the adjusting nut to lengthen the rod then tighten the locknut.

When adjusting the power take-off clutch always check that the hand lever return spring has sufficient tension to hold the rod fully forward when in the engaged position. If necessary renew the pull-off spring, or fit an additional spring, to hold the lever firmly against the front of the slot. *Failure to carry out this check may result in premature wear of the release mechanism.*




Figure 34. CLUTCH LINKAGE — 1200 TRACTORS

- | | |
|--------------------|-----------------------|
| A. Free play | } Transmission clutch |
| B. Connecting rod | |
| C. Adjusting nut | |
| D. Adjusting screw | — clutch stop |
| E. Free play | } PTO clutch |
| F. Connecting rod | |
| G. Adjusting nut | |

Servicing the Clutch Unit

To service the dual clutch unit it is necessary to use either a baseplate kit or a flywheel kit of Service Tools. (See Page 9.)

Several modifications have been made to this clutch. To make sure of a good repair with low cost, use the following recommendations when servicing the clutch.

1. Very early type clutch K919860. This has release levers stamped 49405. The eyebolts for the PTO pressure plate have a $\frac{5}{16}$ UNF thread.
This unit is best replaced with a complete new unit.
2. Early type clutch K919860. This has release levers stamped 49405 also, but the eyebolts for the PTO pressure plate have a $\frac{3}{8}$ UNF thread.
If the separator housing is good, assemble with a new transmission cover assembly K962809.
3. Later type clutches K929803 and K962949. These have release levers stamped 55118 or 55568.
Replace release levers, springs and adjuster screws in sets as needed. Make sure all release levers have the same number stamped on them.

Dismantling the Clutch:

1. Screw the nine special long bolts in the appropriate holes in baseplate, tighten firmly and lightly smear the long threaded portion with anti-scuffing paste.
2. Place three Code 3 spacers, evenly spaced, on the baseplate. Slide clutch assembly on the bolts and position the three spacers so that they are adjacent to the three PTO pressure-plate toggle lugs. (Fig. 35.) Fit a flat washer and nut on each bolt. Tighten the nuts evenly, and by diametrical selection, until clutch and baseplate are clamped firmly together.
3. To maintain balance when re-assembled mark the following components, PTO and main drive covers, pressure plate and release levers, PTO cover yokes and release levers, main drive cover and pressure plate.
4. Screw the long centre pillar adaptor into baseplate and screw actuator into adaptor. Using actuator to depress PTO release levers, remove the three retaining staples then unscrew actuator. (Fig. 36.)
5. Remove clevis pins from the ends of all release levers and remove transmission release levers from cover. Remove the six short bolts attaching cover to main housing.
6. Remove nuts from the nine long bolts. Unscrew nuts evenly, and by diametrical selection, until the thrust springs are fully expanded, then dismantle clutch from baseplate. (Fig. 37.)




Figure 35.

PUTTING THE CLUTCH ON THE BASEPLATE

A. Studs B. Baseplate C. Spacer




Figure 36. REMOVING RETAINING STAPLES

A. Actuator
B. Adaptor plate

Inspection of Parts

Examine all parts after cleaning, paying special attention to the following:

Transmission and PTO Pressure Plates and Separator Housing: The friction surfaces must be smooth and free from blueing or cracks and the pivot points not excessively worn. The friction surfaces may be reground provided that not more than 0.015 in. (0.38 mm) of metal is removed from any one face. Excessive removal of metal will reduce pressure and affect clutch operation.

Separator Housing Bearing: Renew bearing if it is tight, affected by dust, or if the lubricant has dried out.

Replace the thrust springs as a full set if the following specifications are not met.

Transmission Springs

<i>Standard</i>	<i>Heavy Duty</i>
Part No. K625262	K625211
Colour Violet/Black	Buff/Black
or	
Green/Black	
Strength 68 kg (150 lb)	84 kg (185 lb)
Length 42.9 mm (1.69 in)	42.9 (1.69 in)

P.T.O. Springs

Colour	Red
Strength	59-63 kg (131-140 lb)
Length	35.81 mm (1.41 in.)

Insulating Washers: Renew any broken, or damaged, insulating washers. Fix any loose washers in place on the housing with adhesive.

Transmission Cover: Renew if release lever pivots are distorted or loose. Place the pressure plate inside the cover, assembly marks aligned, to ensure plate lugs slide freely through cover holes. File plate lugs if there is insufficient clearance.

Release Levers: Damaged or worn levers should be renewed, together with any bent or worn pivot pins. Fit new springs to levers.

Release Levers Marked 49405: If hexagonal-headed adjusting screws are fitted in the transmission release levers, replace these with socket headed screws. Part No. 923990, which are lighter. If lighter screws are not available reduce the weight of the original screws, by sawing off the hexagon head and cutting a screwdriver slot in the screw end.

Release Lever Plates: Renew these if they are worn on the surface or lever tip register.

Release Lever Toggles: If the PTO lever toggles are being renewed ensure that the correct toggles are being used. A number of early clutches were fitted with $\frac{5}{16}$ UNF toggles and these must not be replaced by $\frac{3}{8}$ UNF toggles, which are thicker and would not operate freely. See Figure 38.




Figure 37. DISMANTLING CLUTCH

- A. Separator housing B. PTO toggles
C. Cover assembly




Figure 38. PTO CLUTCH TOGGLE LEVERS

- A. Early toggle, $\frac{5}{16}$ UNF threads
B. Later toggle, $\frac{3}{8}$ UNF threads

Assembly and Setting

1. Clean and dry all clutch components, baseplate and spacers. Check that adaptors screw freely into baseplate and lightly lubricate threads.
2. Place Code 3 spacers on baseplate and place PTO pressure plate on spacers; position plate so the spacers are adjacent to plate lugs. Figure 39. Fit red springs on pressure plate and, after smearing plate lugs with anti-scuffing paste, place separator housing in position. Align the assembly marks and ensure that no insulating washers fall out as the housing is inverted. Look through the holes of the separator plate to check spring location. Figure 40.

An alternative method of assembling PTO pressure plate is to lay separator housing on bench, fit thrust springs and pressure plate in housing then turn assembly over whilst holding housing and plate together and place on baseplate.

3. Place a new drive plate on friction surface of separator housing then fit transmission pressure plate on the spacers. Position pressure plate so that assembly marks are aligned. Install clutch spigot tool to hold plate in the centre.
4. Fit the transmission clutch thrust springs on pressure plate and, after lightly smearing the inside of cover apertures with anti-scuffing paste, align assembly marks and place cover over springs, taking care that the cover does not bind on the pressure plate lugs. Screw a nut, *with a flat washer underneath*, on each of the nine long bolts. Tighten nuts evenly and by diametrical selection, until the assembly is clamped firmly against baseplate. Replace and fully tighten the short bolts attaching cover to separator housing. Figure 41.
5. Fit transmission release levers and retaining springs. Smear pivot pins and contact points of release levers with anti-scuffing paste and take care not to overstretch the springs. Secure the pivot pins with split pins. Fit release lever plate and retain in position by fitting split pins: the small leaf spring in end of lever must be pressed in towards lever and the split pin fitted underneath it, so that the plate is held against the lever tips.
6. Fit PTO release levers, fit split pins in lever pivot pins. Fit the release lever plate on ends of lever.




Figure 39. ASSEMBLING PTO PRESSURE PLATE




Figure 40. FITTING SEPARATOR HOUSING




Figure 41. ASSEMBLING TRANSMISSION CLUTCH

7. Screw the short adaptor into baseplate and screw actuator into adaptor. Do not screw actuator too far into adaptor but screw it in so that when actuator lever is horizontal the release lever plate is depressed $\frac{1}{8}$ in. (3.2 mm). Operate actuator handle rapidly about a dozen times: this is essential to settle the moving parts, otherwise the lever settings will change when the clutch is used.
8. Remove actuator and screw centre pillar firmly into adaptor. Place a spacer, Code 16X (some early spacers were marked "Code 16" only), on centre pillar — recess in spacer towards adaptor. Fit short setting finger on centre pillar and set adjusting screws on transmission levers so that when finger is rotated, whilst being held firmly and squarely against spacer, it just touches lever plate all the way round. Figure 42. When the levers are correctly set, hold screws stationary and firmly tighten locknuts.
9. Remove gauge finger and centre pillar. Screw actuator into adaptor and repeat Operation 7, then refit spacer and gauge finger to recheck lever adjustment. Reset lever screws if necessary, but ensure that locknuts are fully tightened.
10. Remove short adaptor from baseplate and screw long adaptor in its place. Fit circular plate on actuator and screw actuator into adaptor until the release lever plate is pushed down $\frac{1}{8}$ in. (3.2 mm) when the lever is horizontal. Operate actuator rapidly about a dozen times: this is essential to settle the moving parts and ensure the lever setting does not alter when clutch is used.
11. Remove actuator, screw centre pillar into adaptor and fit spacer, Code 16X (some early spacers were marked "Code 16" only), on pillar — recess in spacer towards adaptor. Fit the long setting finger on centre pillar and set the three toggles so that when setting finger is rotated, whilst being held firmly and squarely against spacer, it just touches the lever plate all the way round. Figure 43. When the lever setting is correct, lock toggles by firmly tightening all six locknuts.
12. Remove gauge and centre pillar. Screw actuator, with plate, into adaptor and operate actuator a dozen times, as described in Operation 10, then replace spacer and gauge to recheck lever setting. Reset toggles if necessary, but ensure that all locknuts are fully tightened.
13. Install retaining staples on the PTO levers. Check that all split pins are locked. Remove the nuts from the long studs evenly and lift the clutch from baseplate.




Figure 42.
SETTING TRANSMISSION RELEASE LEVER HEIGHT




Figure 43. SETTING PTO RELEASE LEVER HEIGHT



WARNING: Do not make retaining staples from welding wire or soft wire. Use the correct parts or staples can come off and cause injury.

DRIVEN PLATES

An examination of the various driven plates will show that they are of either the rigid or the Borglite type. The Borglite type consists of a series of segments, set alternately concave and convex, riveted to a centre plate which is itself riveted to a splined hub. The facings are riveted to the segments, each rivet being attached to only one facing. The alternate hole in each facing is drilled to give access to the rivet securing the facing on the opposite side of the plate. It is important that the side of the plate marked "Flywheel" should always be fitted towards the flywheel.

NOTE: It is recommended that Borglite plates are replaced complete and not repaired. A very high standard of fitting and checking is needed to fit new linings to these plates.

The rigid type plate is a one-piece steel disc which is cut to form segments. The disc is riveted to a centre hub and the facings are connected to alternate segments, as described above for the Borglite plate.

As rigid plates have 24 facing rivets and Borglite plates have 40 facing rivets, facings are not interchangeable, but facings are available to suit either type of plate.

Refacing Driven Plates

To remove the old facings drill out the rivets using a $\frac{3}{8}$ in. (4 mm) diameter drill inserted through the clearance hole in the opposite side facing.

The open portion of the rivet readily centres the drill enabling a speedy and clear removal to be effected.

When the facings have been removed examine the plate carefully. If any signs of cracking are apparent, or if the hub is loose on the rivets or worn in the splines, a new plate complete with facings is required. Also check the plate for distortion and discard it if more than 0.015 in. (0.38 mm) out of true when spun on a mandrel between centres.

Place one of the new facings in position on the disc, noting that the convex side of the plate segments are against the rivet holes in the facing.

Insert hollow steel rivets with their heads against the metal disc segment and roll rivet shank securely against the facing counterbore; this is the opposite procedure to that used with brass rivets. Use a rivet press for this job. Rivets must be fitted correctly. Too much pressure will cause a crack around the rivet.

Insert brass rivets, with their heads in counter-bored holes in facing, and roll the shanks securely against plate disc. Use a rivet press for this job.

Secure the opposite side facing in a similar manner, when it will be noted that counter-bored holes in one facing coincide with clearance holes in the other facing.




Figure 44. BORGLITE DRIVEN PLATE

A. Hub

B. Disc

C. Segment

D. Facing

E. Rivet

Replacement Driven Plates


Sintered Plate K942540: This plate can be installed in any Livedrive or later type twin plate clutch. This type of plate has a longer life but gives a sudden engagement of the drive.

Transmission Borglite Plate K942507: This is a 11 in Borglite plate used for replacement in all 11 in Live-drive Double and Dual clutches. The plate has Thermoid linings.

Transmission Plate K962563: This is a rigid 11 in plate with Thermoid linings and can be used in place of the Borglite K942507 plate.

Transmission Plate K928288: This is a rigid 10 in plate with Thermoid linings and can be used in Live-drive 10 in clutches.

Transmission Plate K200383: This is a 10 in Borglite plate with Raybestos 1488-05 linings. This plate is recommended to replace plate K923374 when operating techniques cause linings to separate from plate. This is caused by the plate rotating at higher speeds than necessary during operation.



R 79:56

Figure 45 — SINGLE CLUTCH

A. Flywheel


B. Driven plate

Installation of Driven Plates

It is important that the driven plates are installed correctly, or damage will be caused.

Borglite plates have the stamped words FLYWHEEL SIDE on the one side of the metal plate.

The FLYWHEEL SIDE mark can be wrong for some clutches. To make sure the plates are installed correctly look at Figures 45, 46, 47 and 48. Make a note on which side of the plate the flange of the centre hub is on.




R 79:57

Figure 46 — TWIN PLATE CLUTCH

A. Front plate

B. Rear plate




R79-58

Figure 47. DOUBLE LIVE DRIVE CLUTCH

- A. Flywheel
B. PTO driven plate

- C. Transmission plate K942507 (Borglite)
D. Separator plate

- E. Transmission plate K919861



R79-59

Figure 48. DUAL INDEPENDENT CLUTCH

- A. Flywheel

- B. PTO plate

- C. Separator housing

- D. Transmission plate

CLUTCH STOP MECHANISM

With the exception of 770 Tractors, all Livedrive models are fitted with a small brake band which operates on a drum on clutch driveshaft. When clutch pedal is depressed to disengage transmission clutch the band is tightened round the drum and stops shaft revolving, thus allowing gears to be engaged without noise or damage.

All Non-Livedrive Tractors and 770 Livedrive models have a spring-loaded friction pad attached to inside of gearbox cover. The pad is in permanent contact with the muff coupling and when clutch is disengaged the slight drag of the pad brings clutch driveshaft to a standstill. There is no adjustment or setting required and the only maintenance necessary is examination of pad whenever gearbox top is removed.

Adjustment: The only external adjustment available is by means of the operating lever adjusting screw and this should be set so that when pedal is depressed sufficiently to take up all the free-play and operating lever is turned clockwise until brake-band touches drum — this only requires light hand pressure — head of adjusting screw is $\frac{1}{16}$ in. (1.6 mm) clear of operating lever or, on 1200 Tractors, pedal pin.

Examination: This should be carried out whenever gearbox cover is removed. Examine brake band lining and renew if more than half worn. New linings are $\frac{1}{8}$ in. (3.2 mm) thick and are bonded to the band. New linings should be soaked in oil before fitting.

Internal Setting (except 1200): Disconnect pedal linkage by removing clevis pin C, Figure 49 from connecting link and check that long stud K is nearly flush with internal face of large fork-end L.




Figure 49. CLUTCH STOP — 990/880/780 LIVEDRIVE TRACTORS

- | | | | |
|-----------------------|----------------------|---------------|---------------|
| A. Clutch pedal | B. Connecting link | C. Clevis pin | D. Lever |
| E. Adjusting screw | F. Operating lever | G. Coupling | H. Shaft |
| J. Compression spring | K. Stud | L. Fork | M. Anchor pin |
| N. Tension spring | O. Brake band | P. Locknuts | Q. Drum |
| | R. Clutch driveshaft | | |

Adjust nuts at lower end of stud K so that spring J is compressed to a length of $2\frac{3}{4}$ in. (67.4 mm). Push anchor pin down and insert a 0.070 in. (1.78 mm) feeler gauge between pin and stop. Release anchor so that it holds feeler gauge then set locknuts P so that band is only just clear of drum. Withdraw feeler gauge, refit clevis pin and set lever adjusting screw E so that it is $\frac{1}{16}$ in. (1.6 mm) clear of operating lever when pedal is depressed to take up the free-play, and lever F is turned lightly clockwise until brake-band touches drum.

Internal Setting (1200 Tractors): Check the length of the compression spring E, Figure 45. This should be compressed to a length of $2\frac{3}{8}$ in. (60.3 mm) and is set by means of the adjusting nuts on stud F. Screw adjusting screw C fully into the operating

lever B and release pedal so that it is in the fully engaged position. With clutch stop mechanism held in the "off" position by return spring G, tighten nuts J until clearance between band and drum is just eliminated — take care not to overtighten nuts — then unscrew nuts two full turns and lock firmly. This will give correct clearance between band and drum. Finally set adjusting screw C so that when pedal is depressed to take up free-play and operating lever B is pressed lightly down, so that band is touching drum, screw head is $\frac{1}{16}$ in. (1.6 mm) clear of pedal pin.

Before refitting gearbox cover, check that the lubricating oil pipe is positioned so that it directs oil on to clutch-stop drum; the brake lining will wear rapidly if not lubricated.




Figure 50. CLUTCH STOP — 1200 LIVEDRIVE TRACTORS

- | | | | |
|-----------------|--------------------|--------------------|-------------------|
| A. Clutch pedal | B. Operating lever | C. Adjusting screw | D. Fork |
| F. Stud | G. Return spring | H. Brake band | J. Adjusting nuts |
| | K. Muff coupling | | |

OVERLOAD RELEASE WITHDRAWAL MECHANISM

Some 880 and 990 Tractors were fitted with a clutch withdrawal mechanism which is operated by an overload release cable from the top link. The resetting lever (hand clutch lever) is mounted on the left-hand side of the rear axle casing and is normally retained in the rear (engaged) position by the catch engaging with the stud. See Figure 51.

When the catch lever is raised by the overload release cable, or tripped by hand, the catch releases the lever and allows the tension spring to draw the lever forward, thus disengaging the clutch.

On Livedrive tractors the hand clutch disengages the main drive clutch only, the power take-off and belt pulley remaining operative until disengaged by the clutch pedal.

Adjustment of the Hand Clutch

Resetting of the clutch pedal free-play by means of the adjustment bolt also resets the free-play in the hand clutch linkage. The setting of the hand clutch rod adjusting nut should, however, always be checked when the clutch is adjusted to ensure that the hand clutch linkage does not prevent the clutch pedal from returning to the fully engaged position. When the clutch pedal is against the stop on the clutch housing, and the hand clutch lever is locked in the engaged position, the adjusting nut should be $\frac{1}{16}$ in. (1.5 mm) clear of the pin.




Figure 51. HAND CLUTCH LINKAGE

- | | | | |
|-------------------|----------------------|--------------------|------------------|
| A. Hand lever | B. Guide bracket | C. Support bracket | D. Trigger |
| E. Torsion spring | F. Locking pin | G. Tension spring | H. Anchor stud |
| J. Pivot bracket | K. Clevis pin | L. Connecting rod | M. Adjusting nut |
| | N. Cross shaft lever | | |

SUMMARY OF DESIGN CHANGES

Details of Change

Power take-off clutch adjusting screws on inner cover increased from $\frac{1}{4}$ UNF to $\frac{5}{16}$ UNF. Parts, except screws and nuts, are interchangeable but if a new inner cover is used with an earlier outer cover the holes in the outer cover must be increased to $\frac{11}{16}$ in. (17.5 mm), to provide clearance for the larger adjusting screws.

Drain hole drilled through support snouts, Part Nos. 89334 and 911906 to prevent any possibility of oil seepage past the clutch shaft bearing reaching the clutch.

Clutch driven plate change from rigid type to Borglite. Part number of plate changed from 906854 to 915694. As the Borglite plate has 40 facing rivets and the rigid plate only 24 rivets, facings are not interchangeable.

Width of clutch stop drum reduced from $1\frac{5}{8}$ in. to 1 in. so that on 6-speed tractors the clutch can be removed without "splitting" the tractor. Part number of the drum changed from 915582 to 917780 and these are not interchangeable unless a new clutch driveshaft is also fitted.

Clutch driveshaft ball bearing (19201) changed to single seal type bearing. The new bearing, Part No. 620033 is interchangeable with the previous bearing and must be fitted with the sealed side towards the support snout.

Stop bolt, Part No. 912855, fitted on left-hand fender to give positive stop for resetting-lever and prevent damage to guide bracket (913860).

Clutch-housing locating-dowels case hardened and increased in length from $\frac{3}{4}$ to $1\frac{1}{8}$ in. (19.0 to 28.5 mm) to give more positive location of housing. Part No. of dowel changed from 35840 to 621838.

Hole in clutch pedal, for operating starter safety switch, tapped $\frac{3}{8}$ UNC so that threaded operating peg (K920281) can be used instead of plain peg (K918618).

Clutch-stop fork end, Part No. K916482, replaced by fork end K916481.

Tension of PTO thrust springs increased from 41 to 53 kg (91 to 117 lb). Part number and colour marking of springs changed from K900261 (buff) to K902514 (pink). Part number of cover assembly changed from K917998 to K921273. Springs are interchangeable if fitted in sets.

Tension of transmission thrust spring increased from 53 to 61 kg (117 to 135 lb). Part number and colour marking of springs changed from K625210 (lavender/black) to K962292 (dark blue/light green). Part number (K919860) of clutch assembly is unchanged and springs are interchangeable if fitted in sets.

Power take-off clutch operating toggles increased in diameter. As the new toggles, which may be identified by having $\frac{3}{8}$ UNF threads, have larger eyebolts than the $\frac{1}{2}$ UNF toggles, corresponding changes to the clutch cover, pressure plate and release levers do not allow the new toggles to be fitted to earlier clutches unless all the later parts are fitted.

Strength of clutch-pedal springs increased from 3 to 8 kg (7 to 18 lb) by increasing thickness of springs from 13 SWG to 10 SWG. Part number of springs (K921684 and K921685) and retaining pins (K921683 and K921686) unchanged.

Strength of cross shaft return spring increased by changing thickness of spring from 7 SWG to 6 SWG. Part number of spring (K921687) unchanged.

When introduced

AD4/47A/63792
AD3/55A/2847
AD3/49A/1929
(April 1966)

990/A/484285
880/A/531626
(April 1966)

AD4/47B/41329
(April 1966)

990/A/487807
880/A/533604
(June 1966)

990/A/487807
880/A/533604
(June 1966)

880/535820
990/491847
(September 1966)

AD3/49A/4988
AD3/55A/8773
AD4/47A/72497
(January 1967)

880/539423
990/496835
(January 1967)

880/539995
990/497389
(February 1967)

AD4/47A/78292
(June 1967)

AD4/55A/4665
(November 1967)

AD4/55A/2839
(June 1967)

780/600610
(December 1967)

780/600745
(January 1968)

Clutch dust cover U1174 introduced to prevent build up of dust in the flywheel housing. Required only in exceptionally dry and dusty conditions.

1200
(February 1968)

Tension of transmission lever anti-rattle springs increased by changing thickness of springs from 12 SWG to 10 SWG, and lever adjusting screws changed to lighter screws with socket head. Part number of spring changed from K919863 to K923989, and number adjusting screw changed from K919864 to K923990. Parts are interchangeable but must be fitted in sets to preserve clutch balance.

AD4/55/5611
(February 1968)

Pull-off spring (K624935), hook (K916478) and anchor plate (K924167) fitted on PTO hand lever to hold lever firmly in "engaged" position and prevent unnecessary wear of release mechanism.

1200/706056
(July 1968)

Length of trunnion pin in cross shaft fork increased and six Belleville washers (K626723) fitted on pin to increase tension and hold release bearing clear of release lever plate when clutch is engaged. Part number of pin changed from K915834 to K925323.

1200/707333
(December 1968)

Power take-off release-bearing housing connected to grease channel in main frame by a nylon tube, so that release bearing is lubricated at same time as left-hand cross-shaft bearings. Part number of housing (K915837) unchanged but tapped boss incorporated for tube connection.

1200/707536
(January 1969)

Transmission release bearing changed from Part No. K19169, which has 7.9 mm ($\frac{5}{16}$ in) ball bearings, to Part No. K620112 bearing, which has 9.5 mm ($\frac{3}{8}$ in) diameter balls. Bearings are interchangeable and the K620112 bearing should be used as a replacement.

1200/708319
(March 1969)

Twin-plate clutch redesigned so that both drive plates are engaged simultaneously. Inner cover (K918606 or K918613) deleted and three springs (K625232) fitted in pressure plate so that inner driven plate is released at same time as outer plate. Earlier 990 clutches can be changed by discarding the inner cover and fitting a new pressure plate (K962573) and three springs (K625232).

355001/22392
355005/1011
355105/1002
449005/1415
(June 1969)

Cored holes in front main frame (K915404) repositioned and clutch housing vent cover (K904246) changed to plain cover (K923650) to prevent dust entering clutch compartment.

1200/710355
(September 1969)

Slot in guide brackets (K919401 and K919402) reshaped to facilitate operation of hand-lever catch. Part numbers of brackets unchanged but care must be taken that new and old type brackets are not used on the same tractor.

1200/711248
(November 1969)

Tension of transmission thrust springs increased from 57 kg (125 lb) to 66 kg (145 lb). Part number and colour marking of springs changed from K902512 (brown) to K928922 (red). Springs are interchangeable if fitted in sets.

449001/19735
(April 1970)

Transmission lever pivot pin increased in length from 6.5 to 8 mm ($\frac{1}{4}$ to $\frac{5}{16}$ in). Release levers strengthened, part number changed from K919851 to K962808. Wider thrust pads on release lever plate drilled and fitted with spring steel pins. Rat trap springs replace leaf springs on release lever plate. Transmission spring changed from K625231 (dark blue/light green) to K625262 (violet/black) and strength increased from 61 to 68 kg (135 to 150 lb). Parts not interchangeable.

AD4/55A/15122
(September 1970)

Groove machined on the 12 speed gearbox driveshaft and at the support snout steady bearing position and 'O' ring K15535 fitted.

990/824197
880/560763
4600/900497
U1074/1099
(February 1971)

Clutch release lever adjusting screw repositioned centrally on the thrust button.

TRANSMISSION RELEASE LEVER IDENTIFICATION (1200)

Stamped	DB Part Number	Set of three	Description
49405	K919581	Use K962979	Release lever narrow → E15122
55118	K962808		Release lever wide E15122 →
55568	K962948	K962979	Release lever wide later models


455001/17909
455021/1205
455031/15037
(August 1971)

Length of PTO release lever adjusting screws increased by 5 mm ($\frac{3}{16}$ in) to provide more adjustment during bedding in of clutch. Part number of screws changed from K962536 to K962994.

355001/33058
(December 1971)

CLUTCH

B2



David Brown®

Service Repair Manual

**770, 880 & 990
TRANSMISSION**

Section C1 (Pub. 9-38115) March 1967



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

GEARBOX — 880 AND 990 TRACTORS

Six-Speed and Twelve-Speed Models

The gearbox is of open construction, being formed by two cast iron end-plates secured together by four steel spacer bars. The end-plates house the bearings, which in turn carry the shafts and gears. On *Livedrive* tractors the gearbox driveshaft is hollow, permitting the power take-off driveshaft to pass through the gearbox to the rear-mounted power take-off and hydraulic lift pump.

The gears are straight-toothed spur gears and are carried on splined shafts to permit movement for gear engagement. The crown-wheel pinion is integral with the gearbox output-shaft and allows the bevel-pinion-type differential to be supported on the gearbox rear end-plate, thus making a compact unit which can be fully assembled before being mounted in the tractor frame.

The six-speed gearbox is, in effect, two three-speed boxes: a high-range gearbox and a low-range gearbox. The selection of the range in use is determined by the position of the range gear-lever, which causes the layshaft to be driven at high or low speed as required.

Three forward speeds and one reverse are available in each range, the required speed being selected by means of the main gear-lever which slides the gears on the pinion shaft so that they mesh with the appropriate gear on the layshaft. Reverse gear is obtained by interposing an idler gear, positioned on the driveshaft between the pinion shaft and layshaft, thus reversing the direction of rotation of the pinion shaft. When either the main or range gear-lever is in




Figure 1. GEAR TRAIN: First Gear — High Ratio




Figure 2. GEAR TRAIN: Top Gear — Low Ratio




Figure 3. TRACTOR WITH REAR AXLE CASE AND-GEARBOX REMOVED

- | | |
|-----------------------|---------------------------|
| A. Tractor main frame | B. Gearbox mounting bolts |
| C. Clutch driveshaft | D. P.T.O cardan shaft |

the neutral position, the gears are not engaged and no drive is transmitted through the gearbox.

The twelve-speed gearbox is an alternative fitting to the six-speed unit and consists of a six-speed gearbox with an auxiliary reduction gear mounted on the front end-plate. The auxiliary gear may be engaged, or disengaged, by means of an additional gear-lever and when engaged reduces all gear ratios by approximately 40%, thus giving the very low travelling speeds required for certain operations. When the auxiliary gear is disengaged the gearbox becomes, in effect, a normal six-speed gearbox with the same gear ratios as a six-speed model.

Removing the Gearbox Unit

Before starting to strip the tractor for gearbox removal, thoroughly clean the gearbox cover, rear-axle case top and power take-off case to prevent any possibility of dirt entering the main frame and subsequently damaging the hydraulic system.

The gearbox unit and differential assembly may be removed as a complete unit and the most convenient method of doing this depends on the tractor type.

All Selectamatic Livedrive tractors are fitted with a band-type clutch-stop and on early models this prevented the muff coupling from being slid far

enough forward to clear the gearbox driveshaft. This means that the gearbox must, therefore, be removed by "splitting" the rear axle from the main frame. On later models the width of the clutch-stop drum was reduced to allow the gearbox to be removed forwards after taking off the gearbox cover.

As twelve-speed tractors are not fitted with a muff coupling, the input gear being mounted direct on the clutch driveshaft, the gearbox cannot be removed forwards and must, therefore, be withdrawn rearwards.

Gearbox removal methods for different tractor types are as follows:

1. Livedrive Six-Speed Tractors:

To Serial Numbers 990A/487806
880A/533604

Remove the gearbox rearwards after splitting the rear axle from the main frame (Method A).

2. Livedrive Six-Speed Tractors:

From Serial Numbers 990A/487807 onwards
880A/533605 onwards

Remove the gearbox forwards after taking off the gearbox cover (Method B).

3. Livedrive Twelve-Speed Tractors:

Remove gearbox rearwards after splitting the rear axle from the main frame (Method A).

4. **Non-Livedrive Six-Speed Tractors:**
Remove the gearbox forwards after taking off the gearbox cover (Method B).

Removing Gearbox Rearwards (Method A)

1. Disconnect steering drop-arm and throttle linkage.
2. On 990 tractors only: Remove hand-throttle lever and steering-box to obtain access to the bolt beneath steering-box which passes through the spacer wedge and into the clutch housing.
3. Remove all gearbox-cover fixing bolts (five through the rear axle) and lift cover off main frame. On 880 tractors the gearbox cover and steering-box can be removed as a unit.
4. Disconnect and remove gearbox lubrication pipes and drain transmission oil.
5. Remove drawbar frame and the lift linkage; jack up the tractor, supporting it firmly under rear main frame.
6. Remove both rear wheels and reduction units. A trolley-jack or portable crane is useful to support the weight of the reductions. As the brake drums may bind on the brake shoes it is advisable to slacken off the brake-rod adjusting nuts before removing the reduction units.
7. Remove oil-seal housing from right-hand side of axle case in order that a hand may be inserted into the case to extract the differential-lock sleeve and spring. As the spring may have expanded and trapped the sleeve in the case, it will probably be necessary to manipulate the differential-lock pedal whilst positioning the sleeve for extraction. It is not necessary to completely remove the sleeve and spring from axle case; all that is required is for the sleeve and spring to be clear of the differential.
8. Remove transmission sump cover-plate and withdraw filter unit. Disconnect sensing unit cable and remove power take-off unit. Remove the four bolts attaching the oil inlet pipe to the base of hydraulic pump.
9. Disconnect brake linkage.
10. Withdraw PTO cardan shaft and remove the mudguards from the footplates.
11. Place a trolley-jack under axle case and, whilst holding axle case vertical, remove the cap screws attaching axle to main frame. Ease the casing off the dowels and carefully withdraw it from main frame.
12. Remove the four gearbox mounting bolts and remove gearbox by sliding rearwards out of main frame.
13. On twelve-speed models the drive-gear thrust washer will be released as gearbox is withdrawn from clutch shaft. Remove this washer from main frame and retain until required for re-assembly. On the six-speed models retain the muff-coupling end-float adjusting shims until required for replacement.

Replacing the Gearbox (Method A)

1. Ensure that the inside of main frame is clean, then slide gearbox into position. On twelve-speed gearboxes a thrust washer is fitted between the drive gear and end-cap and, as this washer is not retained in position until the clutch shaft is inserted into the gear, the washer should be smeared with grease before fitting and care taken to ensure that it is not displaced as the clutch shaft enters the gear. On six-speed gearboxes fit the muff-coupling end-float adjusting shims in place before positioning the gearbox.
2. Temporarily fit the four mounting bolts without bushes and tighten so that the end-plates are clamped to the main frame. Release the four Nyloc nuts on the front ends of spacer bars and, after giving the end of each spacer bar a few taps with a soft-faced hammer to allow the bars to align themselves in the clearance holes in the end-plate, retighten the nuts to 70 lb ft (9.67 kg metres). Remove the mounting bolts, fit the bushes into end-plates and replace the bolts, tightening to 100 lb ft (13.83 kg metres). The mounting bushes are a clearance fit in the end-plates so that when the bolts are fully tightened the gearbox is not clamped rigidly to the frame but has a limited amount of vertical and horizontal "float". On six-speed models check the muff-coupling end-float: 0.010–0.040 in. (0.25–1.0 mm). Adjust, if necessary, by changing the thickness of the shims on the end of the gearbox input shaft.
3. Wipe the axle and main frame faces clean and lift the axle assembly on a trolley-jack. Slide the axle into position on the dowels, guiding the oil inlet pipe into position at the same time. Refit the cap screws and nuts, tightening to 55 lb ft (7.60 kg metres).
4. Slide PTO cardan shaft through gearbox and into clutch. Insert the shaft carefully so as not to damage the oil seal. On six-speed gearboxes this seal is a felt ring inside the end of the clutch shaft, and if the cardan shaft is turned whilst the splines are in contact with the ring, the ring may be damaged or displaced. If difficulty is experienced entering the shaft into clutch, fully depress clutch pedal to free the driven plate, and turn the shaft as it is pushed home.
5. After ensuring that the 'O' ring is in position on the pipe flange, replace the bolts attaching the pipe to the base of the hydraulic pump. Refit the power take-off unit and reconnect the brake linkage.
6. Push differential-lock spring into differential gear and push sleeve against the spring. Insert the special tool (Fig. 4) into axle case and against the sleeve. Push sleeve against spring until the splines on the sleeve start to enter the differential gear, then turn the tool to engage




Figure 4. TOOL FOR REPLACING DIFFERENTIAL LOCK SLEEVE

A. 4½ in. (10.79 cm)	B. ½ in. (1.27 cm)
C. 6½ in. (16.51 cm)	D. 4 in. (10.16 cm)
E. 19½ in. (48.89 cm)	F. 1½ in. (3.81 cm)
G. 4 in. (10.16 cm)	H. 9 in. (22.86 cm)
I. ½ in. (1.27 cm)	J. 1½ in. (3.81 cm)
K. ½ in. (1.27 cm)	L. 2½ in. (5.71 cm)
M. 1 in. (2.54 cm)	

the pedal fork into sleeve groove. If the pedal is then held in the "engaged" position the spring will be retained in the compressed position and permit the reduction unit to be refitted.

- Examine axle case oil seals; if they are not in good condition they should be renewed. New seals should be fitted with the seal lips towards the centre of the tractor and the space between the seals packed with high-melting-point grease. Replace right-hand oil-seal housing, smearing the outside of housing with jointing compound before pressing it into axle case.
- Ensure that axle-case faces are clean and the brake shoes in good condition. Smear the inside of axle oil seals with grease and refit reduction units, taking care not to damage the seals. Degrease the bolt and stud threads and smear with Loctite before replacing and tightening to 75 lb ft (10.5 kg metres).
- Fit rear wheels and adjust brakes. Jack up the tractor and remove supports from under main frame.
- Replace gearbox lubrication pipes and refit gearbox cover, using new gaskets. Check that gear levers are correctly located in their selectors before fitting the cover bolts. When the cover is in position tighten the cover-to-main-frame bolts only sufficient to hold the cover down on to the main frame, then fully tighten the bolts through the axle case. Finally tighten the cover down on to main frame.
- On 990 tractors only: Place the spacing wedge in the gap between gearbox cover and clutch cover. If wedge is not tight in the gap add shims until the wedge is so tight it has to be driven in with a copper hammer. When the

bolts are tightened the housing and cover will then be bolted solidly together without being distorted. Fill steering-box oil bath to within half-an-inch (12 mm) of cover face and fit steering-box and column. Note that the long bolts through the front of box will have to be inserted in the box holes before box is placed in position. Replace hand throttle lever.

- Replace steering-box drop arm, noting that the dot on arm is opposite chisel mark across end of shaft. Reconnect throttle control linkage.
- Replace drawbar frame and refill transmission with correct grade of lubricant. Adjust sensing unit cable (see Page 20, Hydraulic Section).

Removing the Gearbox Forwards (Method B)

- Carry out operations 1 to 7 as listed in Method A.
- Release circlip locating muff-coupling and slide coupling forwards. On Livedrive models also release the circlips locating clutch-stop brake drum. The brake drum can now be pushed fully forward on the clutch shaft, so allowing the muff coupling to be moved forward until it is clear of gearbox driveshaft. Retain the end-float adjusting shims until required for replacement.
- On Livedrive models remove PTO housing and withdraw cardan shaft. Remove the bolts attaching support snout to main frame and remove the two figure-of-eight clips from clutch fork. After removing the bolts attaching clutch cover to flywheel, remove clutch assembly complete with driveshaft, support snout and muff coupling.
- Remove the four gearbox mounting bolts then remove the gearbox by lifting forwards and upwards.

Replacing Gearbox (Method B)

- Clean inside of main frame and lower gearbox into position, sliding rearwards. Temporarily fit the four mounting bolts without bushes and tighten so that end-plates are clamped to main frame. Release the four Nyloc nuts on front ends of spacer bars and after giving the end of each spacer bar a few taps with a copper hammer, to allow the bars to align themselves in the clearance holes in end-plate, retighten the nuts to 70 lb ft (9.67 kg metres). Remove the mounting bolts, fit bushes and replace the bolts, tightening to 100 lb ft (13.83 kg metres). The mounting bushes are a clearance fit in the end-plates so that when the bolts are fully tightened the gearbox is not held rigidly to the main frame but has a limited amount of vertical and horizontal "float".
- Replace the clutch assembly in the reverse order of removal (see Page 18 of Clutch Section).
- Replace muff-coupling end-float adjusting




Figure 5. TRACTOR STRIPPED FOR GEARBOX REMOVAL

A. Gearbox mounting bolts B. Lubrication pipe C. Muff coupling

shims on gearbox driveshaft and slide muff coupling into position. Fit retaining circlip and check that end-float is 0.010–0.040 in. (0.25–1.0 mm). If not, adjust as necessary by changing the thickness of shims on gearbox input shaft. On Livedrive models, also slide clutch-stop drum back into position, fit the locating circlips then adjust the clearance of clutch-stop brake band and set the length of the compression spring (see Page 15 of the Clutch Section).

4. On Livedrive models slide the PTO cardan shaft through gearbox, taking care not to damage the felt ring in clutch shaft. Replace PTO unit.
5. Continue the replacement by carrying out operations 6 to 13 as given in Method A.

Dismantling the Gearbox

As the gearbox and differential is a rather cumbersome and heavy assembly, a support stand will assist dismantling and assembly operations. A suitable stand can often be fabricated from scrap materials, a typical example being shown in Fig. 6. Only the dimensions that are shown are important and it should be noted that the two support points for the front end-plate must be in line with the two rear supports, in order to maintain the end-plates in alignment during assembly.

On twelve-speed gearboxes commence dismantling by removing the gear housing from the

front end-plate; this is secured by three of the spacer-bar nuts and may be drawn off the dowels, complete with gears and selector, after the nuts have been removed. When the gear housing has been removed place it in a vice and remove the selector shaft by pushing it out towards the rear, then withdraw the selector and clutch member; note that when the selector rod is withdrawn out of the selector the detent spring and ball inside the selector will be released. Remove layshaft nut then place the housing on bed of a press and press layshaft out of gear and bearing. Remove the three cover screws and withdraw drive gear; if spacer washers were fitted between end-cover and gear housing retain these for refitting during assembly.

Remove nut from end of pinion shaft (this is left-hand thread) and remove the bolts attaching bearing housing to end-plate. Draw the pinion-bearing housing from the end-plate by screwing two $\frac{3}{8}$ UNC bolts into the tapped holes in the housing flange and tapping the end of pinion, to prevent it being drawn out with the housing. When the housing has been removed, replace inner track of the thrust race on the pinion, ensuring that the distance piece and shims have not been disturbed; refit the pinion nut. The shims fitted between housing and end-plate should be retained for use during assembly as these control the meshing of the crown-wheel and pinion.

With the four spacer-bar nuts removed, engage reverse gear by levering the selector rearwards, then gently tap the end-plate forward with a soft-faced hammer. Allow the 2nd/3rd selector rod to move with the end-plate but do not allow the 1st/reverse rod to




Figure 6. GEARBOX SUPPORT STAND

A. 12½ in. (32.06 cm)

B. 13½ in. (35.08 cm)

C. 11½ in. (29.52 cm)

D. ½ BSF tapped holes

E. 12 in. (30.48 cm)

Note: In order to support the end-plates in correct alignment it is essential that the two side supports are correctly aligned

move out of gear. Withdraw end-plate until reverse selector rod is clear of its detent ball; it will then also be clear of the interlocking plunger and allow the end-plate to be withdrawn and the selector rods and gears to remain. As the end-plate is withdrawn the layshaft can be removed.

When the end-plate has been removed turn it upside down and tap it on the bench to remove the three detent springs; remove the interlocking plunger from side of plate in a similar manner.

Remove pinion shaft, complete with gears and thrust-bearing tracks, withdrawing the selector forks and rods at the same time. Remove driveshaft by tapping forwards with a soft-faced hammer, taking care of the shims fitted behind the rear bearing if a twelve-speed box; on six-speed boxes these shims are fitted behind the front bearing.

Make suitable marks on the differential-bearing caps, so that the caps can be replaced in their original position, then remove the four cap bolts and lift the differential assembly from end-plate. If an oil scraper is mounted on the end-plate, remove this to avoid possible damage.

The main driveshaft also carries the reverse idler gear and this may be removed by supporting the gear

on the bed of a press and pressing the shaft out of the gear and rear bearing; the gear carrier bush can be left on the shaft if it is kept clear of the press support. Note that the thrust washer at rear of bearing is locked to the carrier by means of a small dowel pin.

The pinion-shaft gears will be prevented from sliding off the splines by the thrust-bearing inner races and may be removed by placing the gears on a press and pressing the pinion out of the bearing tracks. When the bearing tracks are removed from the pinion, place these with the distance piece and shims and retain until required for assembly.

To strip the differential, unlock the tabwashers and remove the differential-casing cover bolts, mark the position of the cover and case, then lift the cover off the dowels. Remove one of the split pins, or circlips, from the end of the differential pin then tap the pin out of the casing to release the pinions.

Assembling the Gearbox

After cleaning all components examine the gears for chipped or worn teeth and check the bearings for any signs of roughness. If the pinion-roller bearings are to be renewed, fit the new outer tracks supplied with the new bearings. The outer track of the pinion




Figure 7. TWELVE-SPEED GEARBOX — 880/990 TRACTORS

- | | | | |
|----------------------|-----------------------|---------------------------|------------------------------|
| A. Rear end-plate | B. Front end-plate | C. Spacer bar | D. Housing — creeper gear |
| E. Clutch driveshaft | F. Driving gear | G. Thrust washer | H. Sliding dog-clutch |
| I. Driven gear | J. Thrust washer | K. Needle roller bearings | L. Driveshaft |
| M. Range pinion | N. Reverse idler gear | O. PTO cardan shaft | P. Creeper layshaft |
| Q. Distance piece | R. Main layshaft | S. Pinion shaft | T. Housing — pinion bearings |

rear race is secured in rear end-plate by means of a bolt and two special washers; if this bolt is removed ensure that it is replaced with the bolt head on rear (differential side) of end-plate, otherwise the bolt may foul the crown-wheel. Tighten the nut to 9 lb ft (1.3 kg metres).

The two lower spacer bars are screwed (right-hand thread) into the rear end-plate and do not normally require removing; if, however, the bars are removed the threads should be smeared with Loctite sealant (Part No. 960998) after degreasing and treating with Locquic primer (Part No. 961673), then screwed into the end-plate and firmly tightened.

Torrington needle-roller bearings are employed in a number of places in the twelve-speed gearbox.




Figure 8. NEEDLE ROLLER BEARING

- | | |
|-------------------|------------------|
| A. Steel shell | B. Needle roller |
| C. Roller chamfer | D. Shell lip |

These bearings consist of a number of small diameter needle rollers housed inside a thin steel shell. The ends of the rollers are chamfered and the ends of the shell lipped inwards so that they pass round the roller chamfers and retain the rollers in position. It is, therefore, important that no undue force is applied to the bearings as this may distort the shell lip and jam the rollers.

Once fitted, needle-roller bearings should not be removed unless they are to be renewed, and when fitting new bearings these must be pressed in, using a special tool to protect the shell lip from damage. The stamped end of bearing should be placed against the tool, the bearing placed squarely in position and then pressed in. Under no circumstances should the bearing be driven or hammered in, even when using the special tool. Use of the special tool will also ensure that the bearings are pressed in to the correct depth.

Place the pinion shaft in a vice, fitted with soft-jaw grips, and temporarily assemble the thrust bearings and housing. Tighten the Nyloc nut on end of pinion to 200 lb ft (27.6 kg metres) then check the bearing clearance; this should be 0.002–0.004 in. (0.051–0.102 mm) and shims should be added, or




Figure 9. TOOL FOR FITTING 620053 NEEDLE ROLLER BEARING

- | | |
|----|---------------------------------------|
| A. | Diameter 1.749 in. (44.427 mm) |
| B. | Diameter $2\frac{1}{8}$ in. (52.4 mm) |
| C. | Diameter $2\frac{1}{2}$ in. (66.7 mm) |
| D. | Recess $\frac{1}{8}$ in. (15.87 mm) |
| E. | Chamfer 15° |

removed, until this clearance is obtained. When sufficient shims have been fitted so that the required bearing clearance is obtained, remove the nut and draw the complete bearing assembly off the pinion and retain in a safe place until required for assembly.

Fit the 1st/reverse gear on to pinion shaft, positioned with the selector groove towards thrust bearing (front) end, followed by 2nd/3rd gear with its selector groove towards the teeth (rear) end. Insert pinion into roller-bearing track in rear end-plate.

On twelve-speed gearboxes a bush is fitted inside the front end of driveshaft. This bush is a steady bearing for the power take-off cardan shaft and the recess in the bush should be packed with high-melting-point grease before assembly.

Press reverse-gear carrier bush on to driveshaft until it contacts the circlip. Smear the inside of gear




Figure 10. TOOL FOR FITTING 620052 NEEDLE ROLLER BEARING

- | | |
|----|---------------------------------------|
| A. | Diameter 2.623 in. (66.62 mm) |
| B. | Diameter $2\frac{1}{8}$ in. (74.6 mm) |
| C. | Location $\frac{1}{8}$ in. (3.97 mm) |
| D. | Location $1\frac{1}{8}$ in. (33.3 mm) |
| E. | Chamfer 15° |

bush with anti-scuffing paste and slide the gear on to carrier, chamfered edge of teeth towards front of shaft. Fit the thrust washer, locking this to carrier bush by fitting the pin through the holes in thrust washer and carrier, followed by the rear bearing. Press rear bearing on to shaft until the thrust washer and carrier bush are pushed against the circlip, then check that the gear can be turned quite freely. Slide range pinion on to driveshaft, selector groove towards the rear, and, if a six-speed box, replace the front bearing and circlip, fitting circlip first and then pressing the bearing on the shaft until it contacts circlip. Replace shaft in position in the rear end-plate, noting that on twelve-speed boxes shims are fitted between rear bearing and end-plate.

Replace layshaft shims in the bearing location in front end-plate. On the twelve-speed gearbox check that distance piece which is fitted between the outer races of main and creeper-gear layshaft is held in position by the locating screw in the side of end plate. On six-speed gearboxes also replace drive-shaft-bearing shims before sliding end-plates on to spacer bars. Guide the bearings into position when fitting the end-plate, taking care that the races do




Figure 11. TOOL FOR FITTING DRIVESHAFT BUSH (TWELVE-SPEED)

- A. Diameter 1.129 in. (28.676 mm)
- B. Diameter 1½ in. (31.7 mm)
- C. Diameter 1⅝ in. (41.3 mm)
- D. Recess ⅞ in. (22.2 mm)
- E. Recess ⅜ in. (11.6 mm)

not bind in the housing; when end-plate is in position fit spacer-bar nuts to hold end-plate firmly in position.

On twelve-speed boxes three of the spacer bars are extended for attaching the gear housing and in order to clamp end-plate firmly in position three distance pieces, 1⅝ in. (41 mm) long, should be fitted so that the nuts can be tightened and the end-plate clamped firmly in position.

With the spacer-bar nuts tightened to hold end-plate firmly in position, check the layshaft end-float. This should be 0.002–0.004 in. (0.051–0.0102 mm), and is controlled by the thickness of the front bearing shims. If only two 0.010 in. (0.254 mm) shims are fitted initially the thickness of the additional shims required may be found by measuring the end-float with a dial gauge and subtracting 0.003 in. (0.076 mm) from the gauge reading.

On six-speed gearboxes the driveshaft end-float should be 0.006–0.010 in. (0.152–0.254 mm), and this is determined by the thickness of shims fitted between the front bearing and end-plate.

On twelve-speed gearboxes the driveshaft shims are fitted between the rear bearings and end-plate. To check if sufficient shims have been used, fit driven pinion on to driveshaft, noting that the needle-roller bearing inside the gear is in good condition and placing the thrust washer on the gear so that the oil groove is against end-plate. The thrust washer faces should be smeared with anti-scuffing paste. When the gear is in position fit the circlip on to driveshaft and temporarily fit inner clutch member. With front end-plate clamped in position, push the inner clutch member against drive gear whilst inserting a feeler gauge between thrust washer and end-plate. With clutch member pressed against circlip, as described, the thrust washer should have 0.015 in. (0.381 mm) clearance and may be adjusted by adding, or removing, shims between the rear bearing and end-plate.

When the shaft end-floats have been correctly adjusted, continue the assembly by assembling the pinion thrust bearing. Place an inner track on the pinion, noting that on twelve-speed gearboxes a distance washer is fitted between the inner race and pinion; replace the bearing housing, distance piece, shims and the second inner race. Ensure that the shims selected when the pinion-bearing clearance was set previously are refitted as removed, and that the pinion-meshing shims fitted between the housing and end-plate are refitted as originally installed. Replace the bearing-housing bolts, tightening to 30 lb ft (4.1 kg metres). Fit the flat washer on to the pinion, replace the Nyloc nut and tighten to 200 lb ft (27.6 kg metres). Sliding two gears into engagement simultaneously will lock the pinion shaft and facilitate tightening the nut.




Figure 12. TOOL FOR COMPRESSING DETENT SPRINGS

- A. ⅜ in. (9.5 mm)
- B. ⅝ in. (15.9 mm)
- C. ⅜ in. (4.8 mm)
- D. 6 in. (150 mm)
- E. Gear lever knob

Remove the Mills pin securing High/Low range selector on to its rod; slide selector off its rod and enter rear end of selector rod into the front end-plate. Insert detent spring into the hole in front end-plate followed by the plunger, domed end upwards. Compress the detent spring by pushing the plunger down with a suitable tool (Fig. 12) until the end of the selector rod rides on to the plunger and enables the tool to be withdrawn. Position the selector fork in the gear groove and push the selector rod through

the selector until the pin-holes are in line and a new Mills pin fitted.

Remove the 1st/reverse selector from its selector rod and fit rod into end-plate, holding the detent ball down in the same manner as the plunger on high/low range rod. When the new Mills pin has been fitted, place selector rod in the neutral position and place gear interlocking plunger in the horizontal hole in end-plate. The 2nd/3rd selector rod can then be fitted in the same manner as the other rods.




Figure 13. GEARBOX FRONT END-PLATE

- A. Detent springs B. Detent ball (1st/reverse gear)
C. Detent ball (2nd/3rd gear) D. Interlocking plunger

Press the outer tracks of creeper-gear layshaft bearings into the housing and front end-plate, replacing the shims fitted between end-plate and bearing track. Press the inner tracks of thrust races on to ends of creeper-gear layshaft. Fit selector in position and fit selector rod through from the rear of housing, holding the detent ball down against spring until selector rod passes over the ball.

Place outer clutch member into selector fork then place inner clutch member inside outer clutch member. Refit creeper-gear housing on to spacer bars, entering the creeper-gear layshaft bearings into

the outer bearing tracks and sliding inner clutch member on to the driveshaft splines at the same time. When the housing is located on the dowels, fit the four spacer-bar nuts and tighten to 70 lb ft (9.67 kg metres). Check creeper-gear layshaft end-float. This should be 0.001–0.003 in (0.025–0.076 mm) and is controlled by the thickness of shims fitted between end-plate and bearing track.

Ensure that the oil seal and 'O' ring inside the driving gear are in good condition before fitting gear into housing. If oil seal is replaced note that seal should be fitted with lip towards front and is pressed into the gear until seal face is 0.050–0.060 in.




Figure 14. TOOL FOR FITTING DRIVING GEAR OIL SEAL (TWELVE-SPEED)

- A. Diameter $1\frac{1}{8}$ in. (28.6 mm)
B. Diameter $1\frac{1}{2}$ in. (47.6 mm)
C. Diameter $2\frac{1}{2}$ in. (57.1 mm)
D. Recess $\frac{1}{8}$ in. (1.6 mm)
E. Recess $\frac{1}{2}$ in. (12.7 mm)

(1.3–1.5 mm) below the gear end-face (Fig. 14). After fitting drive gear replace front cover, replacing any distance washers originally fitted between end-cover and gear housing. Check thrust washer clearance by placing the thrust washer in position and inserting a feeler gauge. After checking that thrust washer has not less than 0.015 in. (0.381 mm) clearance, remove the thrust washer and wire it to front cover.

Fit driving gear on to creeper-gear layshaft, replace the large, flat washer and tighten the nut to 150 lb ft (20.7 kg metres).

GEARBOX — 770 TRACTORS

The gearbox is of open construction being formed by two cast iron end-plates attached together by four steel spacer bars. The end-plates house the bearings, which in turn carry the shafts and gears. The gears are straight-toothed spur gears and are carried on splined shafts to permit movement for gear engagement.

The crown-wheel pinion is integral with the gearbox output shaft and allows the bevel-pinion-type differential to be supported on gearbox rear end-plate, thus making a compact unit which can be fully assembled before being mounted in the tractor.

The gearbox has four ranges, each range having

three forward speeds and one reverse speed, giving a choice of twelve forward speeds and four reverse speeds. The speeds are selected by the main gear lever, which slides the gears on the pinion shaft so that they mesh with the appropriate gear on layshaft. Reverse gear is obtained by interposing an idler gear, positioned on the driveshaft between the layshaft and pinion shaft, thus reversing the direction of rotation of the pinion shaft. When the gear lever is in the neutral position the gears are not engaged and no drive is transmitted through the gearbox.

The high and low-range gears are incorporated in the main gearbox between the two end-plates, but the slow and normal gears form an auxiliary




Figure 15. GEAR TRAIN
Second gear — low ratio (creeper gear in low)




Figure 16. GEAR TRAIN
Third gear — low ratio (creeper gear in normal)

reduction unit which is mounted inside the front end-plate. The range gear lever selects the range in use and has four position — low-slow, low-normal, high-low, and high-normal ranges.

Gearbox Removal

Before starting to strip tractor for gearbox removal thoroughly clean gearbox cover, rear-axle case and power take-off case, to prevent any possibility of dirt entering main frame and subsequently damaging the hydraulic system.

On 770 tractors the gearbox cover is integral with the clutch housing, and the fuel tank, instrument panel and wiring must therefore be removed in order to remove gearbox cover. Also note that the steering-box must be removed first as one of the gearbox cover holding-down bolts is inside the steering-box oil bath (Fig. 17).

On tractors from Serial No. 580651 the gearbox can be removed forwards after the reduction units have been removed, but tractors prior to this number have a larger web in rear main frame which prevents gearbox being slid forward, and on these tractors the gearbox must therefore be removed rearwards after first removing rear axle case.




Figure 17. GEARBOX COVER

A. Steering-box oil bath

B. Main frame bolt-hole

Removing Gearbox: Tractors from Serial No. 580651 onwards —

1. Disconnect throttle and stop control linkage and steering drop-arm.
2. Remove steering-box, fuel tank, instrument panel and wiring.
3. Remove the figure-of-eight spring clips from clutch shaft fork; these are accessible after removing the cover from underside of main frame clutch compartment and right-hand side inspection cover.
4. Disconnect main lead and remove starter motor from clutch housing.
5. Remove gearbox cover, noting that one of the bolts is in the steering-box oil bath. Drain transmission oil, remove sump cover and filter.

6. Support tractor under the main frame and remove both rear wheels and reduction units. It is advisable to slacken off the brake rod adjustment to ensure that the shoes do not bind in the drums as the reductions are removed.
7. Remove right-hand side oil-seal housing from axle case and extract the differential lock sleeve and spring from differential case. As the spring may have expanded and trapped the sleeve in the case, it may be necessary to manipulate the differential-lock pedal whilst positioning the sleeve for extraction.
8. Disconnect and remove gearbox lubrication pipes.
9. Release circlip locating muff-coupling and slide the coupling forwards. Retain the spacing shims from driving-gear shaft.
10. Disconnect sensing unit cable and remove power take-off unit. Withdraw PTO cardan shaft.
11. Remove two gearbox mounting bolts and dowel screws. The gearbox can now be removed by sliding it forward and lifting it out of main frame.

Removing Gearbox: Tractors to Serial No. 580650 — The gearbox in these tractors must be removed rearwards after rear axle has been "split" from main frame. The procedure is as follows:

1. Carry out operations 1 to 10 as given above for later models.
2. Disconnect brake linkage.
3. Remove the four bolts attaching the oil inlet pipe to the base of the hydraulic pump.
4. Withdraw PTO cardan shaft and remove mudguards from footplates.
5. Support rear axle case on a trolley-jack and remove the nuts and bolts attaching axle to main frame. Ease case off the dowels and gently withdraw from main frame; ensure that PTO cardan shaft remains in gearbox.
6. Remove the two gearbox mounting bolts and dowel screws then slide gearbox rearwards out of main frame.

Replacing Gearbox

The following operations apply to all models except where stated:

1. Ensure that inside of main frame is clean, then lower gearbox and slide it into position. Fit the dowel screws and clamp down rear end-plate using the mounting bolts without the bushes. Check that both front end-plate lugs are seated on main frame — if not, release the four Nyloc nuts on front ends of spacer bars and tap the end of each bar with a copper hammer to allow the bars to align themselves in the end-plate. Retighten the spacer bar nuts to 70 lb ft (9.67 kg metres) and remove the mounting bolts. Refit the bolts with their bushes and tighten to 100 lb ft (13.83 kg metres). The gearbox is not bolted rigidly to the frame but should have a small amount




Figure 18. '770' TRACTOR WITH GEARBOX COVER REMOVED

A. Gearbox mounting bolts B. Lubrication pipe C. Muff coupling D. Clutch driveshaft

- of vertical and horizontal "float" when the bolts are fully tightened.
2. Tractors to Serial No. 580650 only: Slide PTO cardan shaft into gearbox, noting that the shaft end with the tapped hole must be towards the PTO unit. Fit rear axle into position on the dowels, guiding the oil inlet pipe and PTO shaft into position at the same time. Refit cap screws and nuts and tighten to 45 lb ft (6.22 kg metres). Refit the bolt attaching oil inlet pipe to main frame and replace filter and sump plate. Reconnect brake linkage.
3. Push differential lock spring into differential gear and push sleeve against the spring. Insert the special tool (Fig. 19) into axle case and against the sleeve. Push sleeve against spring until the splines on sleeve start to enter differential gear, then move the tool to engage pedal fork in the sleeve groove. The pedal should then be fastened in the "engaged" position to hold the sleeve in place so that the reduction unit can be refitted.
4. Examine axle case oil seals and replace if they are in poor condition. If new seals are fitted ensure that they are positioned so that the seal lips will point towards the centre of the tractor when installed and pack the cavity between the seals with high-melting-point grease. Replace right-hand oil seal housing, smearing the outside of housing with jointing compound before pressing it into axle case. Smear the inside of oil seals with grease, fit the reduction units and rear wheels then adjust brakes.
5. Refit muff coupling and check the end-float. If coupling end-float is not 0.010–0.040 in. (0.25–1.0 mm) remove or add shims as required. Replace gearbox lubrication pipes.

6. Tractors from Serial No. 580651 only: Fit PTO cardan shaft into gearbox and replace PTO housing.




Figure 19. TOOL FOR REPLACING DIFFERENTIAL LOCK SLEEVE

- | | |
|---------------------------|----------------------------------|
| A. 1½ in. (31.7 mm) | B. 1 in. (25.4 mm) |
| C. ⅝ in. (15.9 mm) | D. 1⅜ in. (34.9 mm) |
| E. ½ in. (12.7 mm) | F. ⅜ in. (22.2 mm) |
| G. 2 in. (50.8 mm) | H. ⅝ in. UNC thread |
| I. ½ in. Whitworth thread | J. 1½ in. washer welded as shown |

This tool is used with slide hammer 4235A and the thread at H is to enable the tool to be also used for extracting the front axle trunnion pin

7. Refit gearbox cover and replace the figure-of-eight spring clips on to clutch-shaft fork. Adjust clutch pedal free-play to ½–¾ in. (See Page 8, Clutch Section).
8. Refit the starter motor and steering column box.
9. Replace fuel tank and instrument panel, reconnect the wiring and controls.




Figure 20. TWELVE-SPEED GEARBOX — 770 TRACTORS

- | | | | | |
|------------------------|--------------------|-----------------------|-------------------|---------------------------|
| A. Bear end-plate | B. Front end-plate | C. Spacer bar | D. Driving gear | E. Slow-normal gear |
| F. High-low range gear | G. Driveshaft | H. Reverse idler gear | I. Creep layshaft | J. Needle roller bearings |
| K. Thrust washers | L. Main layshaft | M. Ball bearing | N. Pinion shaft | O. Pinion housing |
| | P. 2nd/3rd gear | Q. 1st/Reverse gear | | |

Dismantling the Gearbox

If gearbox is to be completely dismantled, the Nyloc nut on the pinion shaft (left-hand thread) should be removed first as the shaft is difficult to hold when the gearbox has been partly dismantled.

Continue by removing the four Nyloc nuts from the ends of spacer bars. Withdraw front end-plate complete with all the selector forks and rods, pinion shaft, driveshaft and layshaft. The layshaft can now be withdrawn from front end-plate and the roller bearings removed as required. The shims controlling the layshaft end-float should be removed from rear end-plate and kept with the layshaft until reassembly. Also remove the shims controlling driveshaft end-float.

Drive out the Mills pin fixing the High/Low ratio selector fork to the selector rod and withdraw driveshaft rearwards complete with gear, selector fork and bearings.

Rotate the High/Low selector rod until the Mills pin holding the selector can be driven out and then withdraw the rod rearwards, taking care to retain the detent ball, spring and interlocking plunger until required for assembly.

The driveshaft also carries the reverse idler gear and this may be removed by supporting the gear on the bed of a press and pressing the shaft out of the gear and rear bearing; the gear carrier bush can be left on the shaft if it is kept clear of the press support. Note that the thrust washer at rear of bearing is locked to carrier by means of a small dowel pin.

Remove the bolts attaching pinion-bearing housing to front end-plate and withdraw housing by screwing two $\frac{3}{8}$ UNC bolts into the threaded holes in housing flange. The end of pinion shaft should be tapped with a copper hammer to prevent it from being drawn out with the housing. When housing has been removed the pinion shaft can be lowered to clear the selector forks and then withdrawn rearwards.

The shims fitted between pinion housing and end-plate should be retained for use during assembly as these control the meshing of the crown-wheel and pinion.

If pinion-shaft gears are to be removed they should be supported on the bed of a press and the shaft then pressed out of inner bearing track and gears. The inner-bearing tracks should be placed with the distance piece and shims and kept until required for assembly.

The 1st/Rev. and 2nd/3rd gear selectors, rod and forks need not be removed unless required, removal procedure being the same as for the other selectors.

Drive the Mills pin out of creeper-gear selector fork and remove the rod, detent ball and spring. The driven gear can now be lifted out of its housing. Remove the circlip from driving-gear shaft and press the gear out rearwards. Remove circlip retaining the front ball-race and press the bearing out. The rear bearing will probably have been removed with the driveshaft, but if not it can now be easily pressed out of the housing.

Drive out the spring pin locating creeper-gear layshaft spindle and remove the spindle forwards. Lift out layshaft together with the thrust washers.

Make suitable marks on the differential-bearing caps so that the caps can be replaced in their original position, then remove the four cap bolts and lift differential assembly from end-plate.

To strip the differential, unlock the tabwashers and remove differential-casing cover bolts, mark the position of cover and case then lift cover off the dowels. Remove one of the split pins, or circlips, from end of differential pin and tap pin out of casing to release the bevel pinions.

Assembling the Gearbox

After cleaning all components, examine the gears for chipped or worn teeth and check the bearings for any sign of roughness. If the pinion-roller bearings are to be renewed, remove outer tracks from housing and rear end-plate and fit the tracks supplied with the new bearings. The outer track of pinion rear race is secured in rear end-plate by means of a bolt and two special washers. If this bolt is removed ensure that it is replaced with the bolt head on the rear (crown-wheel side) of end-plate — otherwise the bolt may foul the crown-wheel — and the nut tightened to 9 lb ft (1.33 kg metres).

The two lower spacer bars are screwed (right-hand thread) into rear end-plate and do not normally require removing. If, however, the bars are removed the threads should be degreased, smeared with Loctite sealant (960998) and then screwed into end-plate and firmly tightened.




Figure 21. NEEDLE ROLLER BEARING

- | | |
|-------------------|------------------|
| A. Steel shell | B. Needle roller |
| C. Roller chamfer | D. Shell lip |

Examine the condition of needle-roller bearings inside creeper layshaft and renew if worn or damaged. These bearings consist of a number of small diameter rollers housed inside a thin steel shell. The ends of the rollers are chamfered and the ends of the shell lipped inwards so that they pass round the roller chamfers and retain the rollers in position. It is, therefore, very important that no undue force is applied to the bearings as this may distort the shell lip and jam the rollers.

Once fitted, needle-roller bearings should not be removed unless they are to be renewed, and when fitting new bearings these must be pressed in using a special tool to protect the shell lip from damage (Fig. 22). The stamped end of the bearing should be placed against the tool, the bearing placed squarely in position and then pressed in. Under no circumstances should the bearing be driven or hammered in, even when using the special tool.

Smear needle-roller bearings with grease and the thrust washers with anti-scuffing paste. Lower layshaft into position in end-plate and fit the two thrust washers at the same time. Align layshaft and thrust washers with spindle holes then refit the spindle and secure with the spring pin.




Figure 22. TOOL FOR FITTING 620070 NEEDLE ROLLER BEARING

- A. Diameter 0.992 in. (25.19 mm)
- B. Diameter 1.244 in. (31.59 mm)
- C. Diameter $1\frac{1}{2}$ in. (38.1 mm)
- D. Recess $\frac{1}{8}$ in. (1.6 mm)
- E. Chamfer 15°

The front ball bearing supporting the driving gear is located in the front end-plate by two circlips. Fit the inner circlip, press the front bearing into position against the circlip then fit the second circlip. Check the condition of the seal in drive gear and replace if damaged. Press rear bearing on to driving gear and after fitting the distance piece press gear and bearing into housing until the distance piece comes up against front bearing and enables the circlip to be fitted on front of gear shaft. Lower the driven gear into housing and slide the dog on to driving gear.

Insert detent spring and ball into hole in front end-plate and, using a suitable tool (Fig. 23) to hold the ball down against the spring, push the selector rod into the end-plate until the end of the rod rides over the ball and enables the tool to be withdrawn. Push the rod through selector and fit Mills pin. Drop in the interlocking plunger and fit creeper-gear selector rod in the same manner after having placed selector fork in groove of driven gear. Fit a new Mills pin into creeper gear selector fork.

Place pinion shaft in a vice, fitted with soft-jaw grips, and temporarily assemble the thrust bearings




Figure 23. TOOL FOR COMPRESSING DETENT SPRINGS

- A. $\frac{7}{8}$ in. (9.5 mm)
- B. $\frac{3}{4}$ in. (15.9 mm)
- C. $\frac{3}{4}$ in. (4.8 mm)
- D. 6 in. (150 mm)
- E. Gear lever knob

and housing. Tighten the Nyloc nut on end of pinion to 200 lb ft (2.76 kg metres) and check bearing clearance. This must be 0.001–0.003 in. (0.025–0.076 mm) and shims should be added or removed until this clearance is obtained. When this clearance is correct, remove the nut and draw complete bearing assembly off the pinion and retain for assembly.

Fit the 1st/Rev. gear on to pinion shaft, with selector groove towards the thrust bearings (front end), followed by the 2nd/3rd gear with selector groove towards the teeth (rear end).

Guide pinion into position in front end-plate, ensuring that selector forks are located in the grooves in the gears, and fit bearing housing complete with thrust races. The original shims should be fitted between housing and front end-plate.




Figure 24. TOOL FOR FITTING DRIVESHAFT BUSH

- A. Diameter 0.870 in. (22.09 mm)
- B. Diameter 0.935 in. (23.749 mm)
- C. Diameter $1\frac{1}{2}$ in. (31.7 mm)
- D. Recess $\frac{3}{8}$ in. (15.9 mm)
- E. Recess $\frac{1}{8}$ in. (1.6 mm)

The inside of the hollow driveshaft has a recess at the front end and on Livedrive tractors a bush is fitted in the recess to act as a steady bearing for the power take-off cardan shaft. The same driveshaft is used in Non-Livedrive gearboxes but as the shorter cardan shaft does not require a steady bearing the bush is omitted.

Press reverse gear carrier bush on to driveshaft until it contacts the circlip. Smear the inside of gear bush with anti-scuffing paste and slide gear on to

carrier, chamfered edge of teeth towards front of shaft. Fit thrust washer, locking this to carrier bush by fitting the pin through the holes in thrust washer and carrier, followed by the rear bearing. Press rear bearing on to shaft until thrust washer and carrier bush are pushed against circlip, then check that the gear can be turned quite freely. Slide range pinion on to driveshaft, selector groove towards the rear. Fit circlip on to shaft and press the front ball race on to shaft until it contacts circlip. Fit High/Low range selector fork into the groove in the gear and, whilst sliding fork on to rod, replace driveshaft in front end-plate.

Fit the two bearings on to main layshaft and replace layshaft in front end-plate.

The front end-plate is now complete with all the gears, shafts, selectors and rods. Place the original shims in the layshaft and driveshaft bores in the rear end-plate and assemble the two end-plates together. Tighten the spacer bar nuts to 70 lb ft (9.67 kg metres) and check the shaft end-floats. These should be: layshaft 0.010–0.015 in. (0.25–0.38mm), driveshaft 0.006–0.010 in. (0.15–0.25 mm). If the end-floats are incorrect remove front end-plate and adjust the shims.

DIFFERENTIAL




Figure 25. DIFFERENTIAL LOCK

A. Foot pedal
E. Spur pinion shaft

B. Lever and shaft
F. Compression spring

C. Fork
G. Side-plate — differential cage

D. Splined sleeve
H. Differential gear

The differential is mounted on the gearbox rear end-plate and permits the two rear wheels to rotate at different speeds whilst transmitting equal driving torque to both wheels.

As the differential action is essential to allow the tractor to turn from a straight course but limits the wheel grip, by allowing one wheel to remain station-

ary when the other is spinning, a differential lock is fitted so that when the lock is applied the rear wheels cannot revolve at different speeds.

The differential lock is controlled by a foot pedal on right-hand side of tractor and when the pedal is depressed the sleeve on spur pinion shaft slides into engagement with differential cage and gives, in




Figure 26. DIFFERENTIAL

- | | | | |
|---------------------------|----------------------|------------------------|----------------------------|
| A. Gearbox rear end-plate | B. Bearing cap | C. Bearing adjuster | D. Angular contact bearing |
| E. Differential cage | F. Differential gear | G. Differential pinion | H. Pin |
| I. Crown wheel | J. Bevel pinion | K. Roller bearing | L. Bearing housing |
| M. Shims | N. Thrust bearings | O. Distance piece | P. Shims |

effect, a solid drive to both wheels. Maximum wheel grip is therefore obtained, but as both wheels are being driven at the same speed the tractor will tend to travel in a straight line and make it impossible to turn sharply. For this reason the differential lock should not be used on the highway or when travelling at high speed as the unexpected failure of the tractor to turn could have serious consequences. The differential-lock pedal is spring loaded so that it returns to the disengaged position when released, but as the sleeve is most likely to be under torque — and the pressure against shaft splines will prevent the spring from sliding the sleeve along shaft — the lock will not always disengage when the pedal is released. If pedal therefore remains down when released, the differential lock is engaged and no attempt should be made to turn tractor sharply until the pedal has sprung upwards; if necessary, momentarily depress the two brake pedals in turn to release the torque and allow lock to disengage.

Dismantling the Differential Assembly

The differential assembly is attached to the gearbox rear end-plate by means of two bearing caps and before the caps are removed they should be marked so that they can be refitted in their original position; the caps are bolted to the end-plate before final machining and are not, therefore, interchangeable.

After removing differential assembly, unlock tabwashers and remove end-plate nuts. Mark the position of end-plate and cage then carefully tap the plate off dowels. Remove pinion pin; this is secured by a split pin, or on later models a circlip, at each end, and extract the pinions and side gear.

The crown-wheel is bolted to differential case and need not be removed unless it is to be renewed. Crown-wheels and pinions are matched during manufacture and must not be interchanged. Replacement crown-wheels and pinions obtained from Parts Department are wired together and care must be taken to ensure that they do not become detached during storage. If a crown-wheel or pinion becomes worn it must not be replaced singly but should be replaced with a matched pair of gears.

Examine differential side bearings and renew if they show any signs of roughness. As the bearings are angular contact type, they cannot be removed by holding the outer track but must be removed by using an extractor, such as Service Tool 960605, which pulls against the bearing inner track.

Assembling the Differential

Fit crown-wheel on to differential cage. Ensure that wheel face fits flat against the cage flange and tighten the bolts, by diagonal selection, to 50 lb ft (6.91 kg metres) before locking with the tabwashers.

Press the side bearings on to the cage and side-plate. As these are angular contact bearings they must be fitted so that the word "Thrust" stamped on the outer track is facing away from differential and will be against the bearing adjuster when fully assembled.

Smear bearing faces of the two bevel gears with anti-scuffing paste and place one of the gears inside differential cage. Smear the bores and faces of the two bevel pinions with anti-scuffing paste and place them both in position inside cage. Push the pin through holes in the case and gears before securing the pin in position with split pins. On later models the pin is free to rotate and is retained in position by circlips, but on earlier models the cage is grooved so that the retaining split pins also prevent the pin from rotating. Place remaining bevel gear on the two pinions and fit end-plate on to cage. Ensure the marks made before dismantling are aligned and the plate fits flat against cage face. Cages with nine bolt holes are fitted with $1\frac{1}{8}$ in. (28.57 mm) long dowels, but cages with six bolt holes are only drilled deep enough for $\frac{3}{4}$ in. (19.05 mm) long dowels. Replace the bolts after degreasing the threads and treating with Loctite. Position the tabwashers so that they cover the dowels and tighten the bolts by diagonal selection to 30 lb ft (4.15 kg metres) before locking with the tabwashers.

When fitting end-plates with nine bolt holes ensure that the plate is fitted with the dowels located in the three special holes. As the dowel holes are only slightly smaller than the bolt holes, to assist identification a small indentation is made adjacent to one of the dowel holes.

Remove bearing caps from gearbox rear end-plate and place the differential in position: crown-wheel on right-hand side of pinion. Replace bearing adjusters and caps, ensuring that the marks made on caps and end-plate are aligned.

Crown-Wheel and Pinion Adjustment

To obtain long life and quiet running of the crown-wheel and pinion it is essential that they are correctly meshed and adjustment is therefore provided so that both crown-wheel and pinion can be moved to bring the teeth into correct mesh.

Adjustment of crown-wheel is by means of two ring nuts on differential side bearings, which can be screwed in or out to move differential cage sideways, and pinion adjustment is by means of shims fitted between the thrust-bearing housing and gearbox front end-plate, which can be changed in thickness to move the pinion in or out of mesh.

After mounting differential assembly on gearbox rear end-plate, screw right-hand bearing adjuster inwards until the gear teeth backlash is reduced to 0.007–0.009 in. (0.18–0.23 mm) and screw left-hand adjuster inwards until differential cage end-float is reduced to 0.000–0.002 in. (0.00–0.05 mm).

To check the differential cage end-float, mount dial gauge with its finger resting on the differential cage and, with a suitable lever at each side of the differential cage, lever the cage first to one side and then the other. The amount of clearance will then be shown on the dial gauge.

The teeth backlash can be checked by mounting a dial gauge at right-angles to the crown-wheel teeth and holding the pinion — by levering against one of




Figure 27. CROWN WHEEL TEETH MARKING

the gears with a hammer shaft — whilst rocking the crown wheel against the stationary pinion. The amount of crown-wheel movement, which will also be the amount of tooth backlash, will then be shown on the gauge.

When gear backlash and bearing clearance are correct; smear the crown-wheel teeth with marking compound and whilst applying a slight load to the pinion shaft rotate the crown-wheel in alternate directions. The resulting mark on the crown-wheel teeth should be slightly towards the outer edge of the teeth and extend approximately two-thirds of the length of the teeth. After examining the teeth marking, correct as required (see Fig. 27) by removing the thrust-bearing housing bolts, withdrawing the housing and adding, or removing, shims. Shims may be cut adjacent to one of the semi-circular cut-outs to enable the shims to be fitted without removing housing from pinion.

As any adjustment made to the position of pinion will also affect gear backlash it may be necessary to readjust the position of the crown wheel after each

A. CORRECT MARKING

Contact area extending approximately two-thirds of the length of the tooth and positioned slightly towards the outer edge.

B. HEEL CONTACT

Pinion requires moving nearer to crown wheel by reducing the thickness of the bearing housing shims.

C. PEAK CONTACT

Gears too far out of mesh. If backlash is not excessive move pinion nearer to crown wheel.

D. TOE CONTACT

Gears too deep in mesh. Increase thickness of bearing housing shims to move pinion away from the crown wheel.

E. ROOT CONTACT

Gears too deep in mesh. If backlash is sufficient, move pinion away from the crown wheel by increasing the thickness of the bearing housing shims.

pinion adjustment. Since turning the bearing adjusters to re-set the tooth backlash will disturb the end-float setting, note how far the adjuster is turned and then turn the other side adjuster exactly the same amount but in the opposite direction, e.g., if the right-hand adjuster is screwed outwards two castellations and the left-hand adjuster screwed inwards two castellations the differential cage end-float will be unchanged but the tooth backlash will be increased.

When checking the gear marking ensure that pinion-housing bolts are fully tightened and the side bearings are against the adjusters. Tapping differential cage from side to side with a soft-faced hammer will push side bearings against adjusters and prevent any possibility of obtaining a false amount of end-float.

When a satisfactory tooth mark has been obtained and the gear backlash and bearing end-float are correct, tighten the cap nuts to 120 lb ft (16.6 kg metres) before locking with the tabwashers. Fit the plates to lock the bearing adjusters and check that pinion-housing bolts are tightened to 30 lb ft (4.14 kg metres).

REDUCTION UNITS




Figure 28. FINAL DRIVESHAFT OIL SEAL — 990 TRACTOR

- | | | | | |
|---------------------|---------------------|-------------|------------------|-------------------------|
| A. Final driveshaft | B. Oil seal housing | C. Oil seal | D. Grease baffle | E. Taper roller bearing |
| F. Shims | G. Dirt shield | H. Collar | I. 'O' ring | |

The reduction units are bolted to the ends of rear axle case and consist of a one-piece casting which houses the spur reduction final drive gears. The spur pinion shafts are splined into differential at their inner ends and are supported by two taper roller bearings in the reduction housing at their outer ends. The final drive shafts are supported on taper roller bearings and are fitted with special seals to retain lubricant and prevent dirt entering the reduction unit.

Final Driveshaft Oil Seals

The oil seal on the final driveshafts prevent dirt entering shaft bearings and the purpose of the grease nipple is to maintain the seal cavity full of clean grease. When grease is pumped through the nipple, excess grease in the cavity is forced outwards between shaft and housing and pushes out dirt which would otherwise damage the seal. A discharge of grease out of the seal housing is not, therefore, detrimental but desirable, as this ensures that the

seal is being kept free of abrasive matter which would quickly damage the seal.

If, through lack of regular greasing, the seal is damaged by dirt, oil from the reduction unit will leak past the seal and indicate that the seal requires renewing.

To remove a final driveshaft oil seal it is not necessary to remove the reduction unit. Drain the oil and remove cover. Jack up the rear of tractor and remove wheel. Unlock tabwasher on final driveshaft and release ring nut. The nut is right-hand thread and may be released using Service Tool 909482 and a heavy copper hammer.

Insert a socket wrench through the holes in final driveshaft flange and remove two opposite seal-housing-to-reduction-case bolts.

Clean the threads in final driveshaft extraction holes by screwing a $\frac{1}{2}$ BSF tap into each hole: this is essential to prevent damage to the shaft and extraction bolt threads. Screw the two extraction bolts (Service Tool 900207) into shaft flange and place two thrust blocks between the housing flange




Figure 29. DIMENSIONS OF THRUST BLOCK

- | | |
|---------------------------------|--------------------------------|
| A. $2\frac{1}{8}$ in. (65.1 mm) | B. 3 in. (76.2 mm) |
| C. $1\frac{1}{8}$ in. (33.4 mm) | D. $\frac{1}{8}$ in. (14.3 mm) |
- Drill $\frac{1}{2}$ in. (6 mm) diameter indentation $\frac{1}{8}$ in. (1.6 mm) deep at position shown

and bolt ends. These thrust blocks are necessary to prevent the extraction bolts damaging the housing, and dimensions of a suitable block are shown in Fig. 29. Tighten the bolts evenly to draw the shaft out of the housing and bearing, noting that the ring nut must be unscrewed at the same time. Shims fitted between the seal housing and case should be retained and refitted when reassembling so that the original bearing setting is maintained. Extract the gear, tabwasher, ring nut and inner bearing from inside case.

Do not attempt to remove bearing by pressing shaft out of seal housing or by using the extraction bolts with the shaft assembly clamped in a vice. If seal housing is not bolted to reduction case it will distort under pressure and cause the taper roller bearing to grip the shaft very tightly.

After extracting shaft remove the housing and bearing. Clean the housing and fit a new seal. Carefully press the seal into housing using Service Tools 960904 and 900211, to avoid distorting seal, and positioning the seal so that its inner lip is pointing towards the outside of the housing (Fig. 28).

Pack the inside of seal cavity with high-melting-point grease and clean the driveshaft before placing housing in position on shaft.

On 880 tractors the seal housing incorporates an 'O' ring which should be renewed before the housing is fitted on shaft. On 990 and 770 tractors a metal grease baffle is clamped between the housing and bearing and this should be fitted before the bearing is pressed on to shaft. The purpose of the baffle and 'O' ring is to prevent grease passing into the reduction unit, so that when grease is pumped through nipple it forces the dirty grease outwards through the gap between shaft and housing.

Ensure that inner bearing is in position inside the case — if necessary smear the bearing with grease so




Figure 30. DIFFERENTIAL LOCK PEDAL WIRED IN ENGAGED POSITION

- A. Pedal B. Operating lever

that it will remain in position — and replace the gear inside the case. Remove all traces of oil from shaft splines then smear splines with Loctite. Refit shaft assembly into case, fitting the tabwasher and ring nut at the same time, and also replacing the shims between the housing and case. On 990 tractors the housing should be fitted so that the grease nipple is at the seven o'clock position.

Firmly tighten shaft ring nut. As it is essential that the nut is tightened until the gear, distance piece and bearing are clamped solidly together, ensure that the nut is fully tightened before locking with the tabwasher. Do not tighten the nut with a hammer and punch but use a 'C' spanner of the correct size (Service Tool 909842) and a hammer, otherwise the gear may chatter on the splines and cause the driveshaft to develop end-float. When the ring nut has been fully tightened, strike the centre of the shaft flange with a hide-faced hammer then check the tightness of nut.

After tightening the ring nut and oil seal housing bolts check that there is no free play in the shaft bearings. The shaft bearings should have 0.005–0.007 in. (0.127–0.178 mm) pre-load and if the original thickness of shims has been refitted the setting will be unchanged. If the bearing pre-load is incorrect shims must be added or removed (see Page 27).

Refit reduction case cover plate and fill to the correct level with the recommended grade of oil. Pump grease through the nipple until the housing cavity is filled and surplus grease is discharged through the gap between housing and driveshaft, then refit the wheel.




Figure 31. REMOVING OIL SEAL HOUSING FROM AXLE CASE

- | | |
|----------------------------|---------------------|
| A. Oil seal housing | B. Bridge piece |
| C. Bolts into seal housing | D. Extraction bolts |

Removal of the Reduction Units

Before attempting to remove a reduction unit first ensure that the tractor is standing on firm and reasonably level ground and that suitable packing material is available to support the weight of tractor.

Caution: The differential lock must be retained in the engaged position, by holding the pedal depressed whilst the operating lever is wired to the hand brake lever (Fig. 30), otherwise the differential-lock sleeve will become displaced when the reduction unit is withdrawn and prevent the unit from being refitted.

Raise the rear end of tractor until the rear wheels are clear of the ground, then place packings under rear axle case. Remove the rear wheels and release the brake adjustment, to prevent the brake drum from binding on the brake shoes. Remove the drain plugs and allow the oil to drain into a suitable container. Remove the bolts attaching the reduction unit to axle case and withdraw the complete unit, taking care not to damage the oil seals in axle case. A trolley-jack, or small packing case, placed under the reductions will assist in supporting the weight and allow the unit to be withdrawn horizontally until spur pinion shafts are clear of axle case.

Replacement of the reduction units should be carried out in reverse order of removal, paying special attention to the following:

1. Examine the condition of the brake linings and renew if excessively worn or contaminated with oil (see Page 29).
2. Examine the axle case oil seals and renew if damaged or if any signs of oil leakage is apparent.
3. Ensure that spur pinion shaft splines are clean and the inside of brake drum is free from oil.




Figure 32. REAR AXLE CASE OIL SEALS

- | | |
|--------------|-----------------|
| A. Oil seals | B. Seal housing |
|--------------|-----------------|

Axle Case Oil Seals

The oil seals in the axle case prevent transmission oil from reaching the brake shoes and are accessible when the reduction units are removed. To remove the seal, first draw housing out of axle case, using Service Tools 900207 and 900208. These tools consist of a bridge piece and four extractor bolts: the two $\frac{1}{2}$ BSF bolts fit through the inner holes in the bridge piece and into the two tapped holes in seal housing; the two $\frac{1}{2}$ BSF bolts screw through the tapped holes in bridge piece and against axle case (Fig. 31). Tightening the two outer bolts will then draw the housing out of the axle case and allow the oil seal to be pushed out of housing by tightening the two inner bolts.

When fitting new seals, position the seals so that when installed all the seal lips point towards the centre of tractor. Before fitting the seal housing into axle case, pack the cavity between the seals with high-melting-point grease and smear the inside of seals with grease and the outside of the housing with jointing compound.

Dismantling the Reduction Units

Remove brake drum from spur pinion shaft, using Service Tool 960618 or two $\frac{1}{2}$ UNC extractor bolts screwed through the tapped holes in the drum and remove the reduction case cover.

Unlock the tabwasher on final driveshaft and release ring nut until it touches the inner bearing. The nut is right-hand thread and may be released using Service Tool 909802 and a hammer.

Insert a socket wrench through the holes in final driveshaft flange and remove two of the bolts attaching seal housing to reduction case. Clean the threads in the final driveshaft extraction holes with a $\frac{1}{2}$ BSF tap: this is essential to prevent damage to the shaft and extraction bolt threads. Screw two extraction bolts (Service Tool 900207) into shaft flange and place two thrust blocks between the housing flange and bolt ends. These thrust blocks are necessary to prevent the extraction bolts damaging the housing, and dimensions of a suitable block are

Figure 33. REDUCTION UNIT -- 990 TRACTOR

- S R Q M N M O P Q
- Figure 33. REDUCTION UNIT -- 990 TRACTOR
- | | | | | | |
|----|----------------------|----|----------------------|----|---------------|
| A. | Final driveshaft | C. | Oil seal | D. | Grease baffle |
| E. | Taper roller bearing | G. | Distance piece | H. | Spur gear |
| I. | Washer | K. | Taper roller bearing | L. | Case |
| M. | Taper roller bearing | O. | Shims | P. | End cover |
| Q. | Circlep | S. | Brake drum | | |
| B. | Oil seal housing | | | | |
| F. | Shims | | | | |
| J. | Ring nut | | | | |
| N. | Spur pinion shaft | | | | |
| R. | Oil seal | | | | |

shown in Fig. 29. Tighten the bolts evenly to draw the shaft out of the housing and bearing, noting that the ring nut must be unscrewed at the same time.

Do not attempt to remove bearing by pressing shaft out of seal housing or using extractor bolts with the shaft assembly held in a vice. If the seal housing is not bolted to reduction case it will distort under pressure and cause the taper roller bearing to grip the shaft very tightly.

After withdrawing shaft remove seal housing and bearing then press oil seal out of the housing. Shims are fitted between the housing flange and reduction case and these should be retained for use during assembly.

Spur Pinion Shaft Removal — 880 and 990 Tractors

Remove the circlip from outside the outer bearing end-cover then remove the shaft by tapping the splined end with a soft-faced hammer. The shaft will push the end-cover shims and outer bearing out of the case, but the oil seal and outer track of the inner bearing will remain in position. Remove the oil seal by passing a long drift through the end-cover aperture, then remove the bearing outer track by tapping inwards into case.

Spur Pinion Shaft Removal — 770 Tractors

Removing the brake drum will expose the shaft collar and this must be removed from shaft. The collar should not be very tight and is provided with a groove so that it can be levered out of position. After removing collar, lever oil seal out of case to expose inner bearing circlip. Remove the circlip then pierce the welch plug with a sharp punch and lever the plug out. Insert a $\frac{3}{8}$ in. (20 mm) diameter soft drift through the welch plug aperture and, whilst holding the shaft square with case, drive the shaft out. The inner bearing, shims and distance piece will be removed with shaft but the outer track of outer bearing will remain in the case and may be removed using Service Tool 960608 with an adaptor made to the dimensions shown in Fig. 34.

Replacing the Spur Pinion Shafts

After cleaning all components, examine bearings for any signs of roughness and the gear teeth for wear. If the bearings are not being renewed, the bearing track in case need not be removed, but if new bearings are being fitted the bearing track should be removed from the case and replaced with the track supplied with new bearing.

Refit spur pinion shaft in the opposite order of removal. On 770 tractors replace the shims between distance piece and inner bearing before replacing the circlip. The bearings should have 0.001–0.003 in. (0.025–0.076 mm) pre-load and if any free play is present rotate the shaft then push the distance piece inwards and measure the gap between the distance piece and circlip with a feeler gauge. The correct




Figure 34. TOOL FOR REMOVING OUTER SPUR PINION BEARING — 770 TRACTOR

- A. $1\frac{1}{2}$ in. (44.4 mm) B. 0.980 in. (24.89 mm)
- C. 2.415 in. (61.34 mm)
- D. 0.393 in. (9.98 mm) diameter
- E. 31797 bolt with thickness of head reduced to $\frac{1}{8}$ in. (3.2 mm)
- F. Extractor bolt 960608 ($\frac{1}{2}$ in. BSF)

bearing preload can then be obtained by fitting additional shims which are 0.003 in. (0.076 mm) thicker than the gap. When the bearing setting is correct, fit a new oil seal, ensuring that the seal lip is pointing inwards towards the gear. Before fitting a new welch plug place unit on the floor, so that spur pinion shaft is vertical, and place a short piece of $\frac{7}{8}$ in. (20 mm) diameter bar through the welch plug hole. Fit a new 'O' ring inside the shaft collar then slide collar on to shaft: recessed edge of collar towards the bearing. Place brake drum key in position and slide brake drum on to shaft. With the end of spur pinion shaft resting on the piece of bar, drive brake drum on to shaft until it comes firmly against the collar. Do not strike the rim of brake drum but use a long piece of tube over the shaft. Fit a new welch plug when the brake drum has been driven "fully home".

On 990 and 880 tractors replace spur pinion shaft in the case then fit the outer bearing track and temporarily replace the end-cover without an 'O' ring. Fit the circlip, then rotate the shaft whilst pushing cover fully inwards and measure the gap between cover and circlip. Remove circlip and cover, fit shims 0.003 in. (0.076 mm) thicker than the width of the gap and replace the cover, with 'O' ring and circlip. The bearings will then have 0.003 in. (0.076 mm) preload.

Fit a new oil seal into the case, inner lip of the seal towards the gear. Clean the shaft and smear with Loctite before placing the collar in position on the shaft. Ensure that the collar is free from burrs or damage, which would reduce oil seal life, and is fitted so that the chamfered edge is towards the the bearing.




Figure 35. REDUCTION UNIT - 770 TRACTOR

A. Final driveshaft	B. Oil seal housing	C. Oil seal	D. Grease bottle	E. Taper roller bearing
F. Shims	G. Distance piece	H. Spur gear	I. Tabwasher	J. Ring nut
K. Taper roller bearing	L. Case	M. Taper roller bearing	N. Spur pinion shaft	O. Shims
P. Distance piece	Q. Circlip	R. Oil seal	S. Brake drum	

Fit the brake drum key into the shaft keyway and place the drum on the shaft. Using Service Tool 960618, or a long piece of tube over the shaft, drive the drum on to the shaft until it is firmly against the collar.

Replacing the Final Driveshaft

Clean the housing and fit a new seal. Carefully press the seal into position to avoid distorting seal case and position the seal so that the inner lip is pointing towards the outside of housing (Fig. 28). Pack the inside of seal with high-melting-point grease and clean the driveshaft before placing housing in position on shaft.

On 880 tractors the seal housing incorporates an 'O' ring which should be renewed before the housing is fitted on shaft. On 990 and 770 tractors a metal grease baffle is clamped between the housing and bearing and this should be fitted before the bearing is pressed on to shaft and positioned so that the inner lip of the baffle is towards the seal. The purpose of the baffle and 'O' ring is to prevent grease passing into the reduction unit, so that when grease is pumped through nipple it forces the dirty grease outwards through the gap between shaft and housing.

Place shaft inner bearing in position inside the case — if necessary smear the bearing with grease so that it will remain in position — and place gear in case. If a new inner bearing is being fitted it would be necessary to remove the bearing track from the case, using Service Tool 960608 with a 960986 adaptor, and fit the track supplied with the new bearing. Remove all traces of oil from shaft splines then apply Locquic primer and smear splines with Loctite. Fit shaft assembly into case, fitting the tabwasher and ring nut at the same time. Temporarily fit only three housing bolts, equally spaced and only screwed in finger-tight.

Firmly tighten the shaft ring nut. As it is essential that the nut is tightened until the gear, distance piece and bearing are clamped solidly together, ensure that it is fully tightened before locking with the tabwasher. Do not tighten ring nut with a hammer and punch but use a 'C' spanner of the correct size (Service Tool 909842) and a hammer, otherwise the gear may chatter in the splines and cause driveshaft to develop end-float.

When the ring nut has been fully tightened, rotate the shaft and tighten the three housing bolts until bearings become tight and prevent shaft being rocked against the gear backlash. Do not over-tighten the

bolts so that the housing flange is distorted, but tighten them evenly so that when a feeler gauge is inserted between housing and case flange the gap is equal all the way round. As a false setting will be obtained if the inner bearing is not against the shaft shoulder, strike the centre of shaft flange with a soft-faced hammer to ensure the bearing is pushed "fully home". When the three bolts have been tightened as described, measure the gap between housing and case faces with a feeler gauge. This gap, if equal all the way round, will be the thickness of shims required to give the bearings no pre-load, and as the bearings require 0.005–0.007 in. (0.127–0.178 mm) pre-load shims should be selected which are 0.005 in. (0.127 mm) less than the width of the gap.

Thickness of seal housing shims:

Part No.	Shim
902772	0.003 in. (0.076 mm)
902773	0.006 in. (0.152 mm)
902774	0.009 in. (0.229 mm)
902775	0.015 in. (0.381 mm)

Having measured the gap and selected the appropriate shims, remove the three housing bolts and fit the shims. The shims are split to enable them to be fitted without removing the shaft and should be positioned so that the split will be horizontal when the unit is installed on the tractor.

On 990 tractors the seal housing should be positioned so that the grease nipple is at the seven o'clock position.

Tighten the housing bolts evenly to 50 lb ft (6.91 kg metres) and fit a new 'O' ring in the seal housing groove. Pump grease through the nipple until the seal cavity is filled and grease is forced out between housing and driveshaft flange.

Refit cover plate, using a new gasket, and tighten the bolts to 30 lb ft (4.15 kg metres) on 990 and 880 tractors and 20 lb ft (2.76 kg metres) on 770 tractors.

As it is essential that no build up of pressure takes place inside the reduction case a breather is fitted in the cover plate. On 990 and 880 tractors one of the cover bolts is drilled to act as a breather and it is therefore important that this bolt is not replaced by an undrilled bolt and is fitted at the top of cover plate. On 770 tractors a breather plug is fitted in the cover. When assembling a reduction or replacing a leaking oil seal always check that the breather is clear as a blocked breather can cause oil to be forced past the seals.

Refill the unit to the level of the filler plug with the recommended grade of oil.

BRAKES




Figure 36. BRAKE MECHANISM

- | | | | | |
|--------------------|----------------|--------------------|---------------------|--------------------|
| A. Hand lever | B. Fork | C. Operating lever | D. Right-hand pedal | E. Left-hand pedal |
| F. Adjusting screw | G. Cross shaft | H. Brake rod | J. Adjusting nut | K. Camshaft lever |
| L. Camshaft | M. Brake shoe | N. Anchor pin | O. Brake drum | |

Operation of Brakes

The brake shoes are mounted on the ends of axle case and operate inside brake drums mounted on the spur pinion shafts. Each brake is operated by its own pedal, permitting the brake to be applied on one side only to assist steering when making very short turns in the field. For normal operations, when both brakes are required to be operated simultaneously the two pedals should be locked together.

The hand lever mounted on the side of tractor is a parking brake and applies the brakes on both sides. A spring-loaded pawl inside the lever housing engages in the teeth on hand lever to retain the lever in the "on" position. The hand lever is free to rotate, and when turned so that the lever teeth are not in line with the pawl the lever will return to the "off" position when released.

Brake Adjustment

Adjustments to compensate for lining wear should be made by reducing the lengths of the two rods connecting the camshaft levers to the cross shaft. As the linkage is not compensated, the adjustments will have to be balanced so that both brakes are applied evenly when the pedals are locked together.

To adjust the brakes, chock the front wheels to prevent the tractor from moving, then raise the rear wheels clear of the ground. With the two pedals locked together and the gear lever in neutral, release the locknut and tighten the adjusting nut on one rod until the brake starts to bind, then release until the wheel is free. Apply the hand brake until the wheel can just be turned then tighten the adjusting nut on the other side rod until both wheels bind equally. Release the hand brake and check that the wheels are free, then hold the adjusting nuts stationary and tighten the locknuts.

Adjusting the length of the brake rods also adjusts the hand brake and no further adjustment is required. When the adjustment is completed road-test the tractor and check for satisfactory brake operation.

Brake Linkage

The brake linkage is shown in Fig. 36. The two foot pedals are mounted on a common cross shaft which is supported by self-aligning bushes incorporated in the footplates. The left-hand brake pedal is secured to the shaft by a Mills pin but the right-hand pedal is loose on the shaft and is retained in position by a collar pinned on the end of the shaft.

For independent operation of the two brakes it is essential that the right-hand pedal is free to pivot on the cross shaft; the pedal boss should therefore be periodically lubricated through the grease nipple.

The hand brake is connected directly to the cross shaft by means of an operating lever between the pedal bosses. The operating lever has two lugs which contact the pedal bosses and to enable the two pedals to be aligned the right-hand pedal has an adjusting screw which should be set so that when the hand brake is applied the pedal locking catch remains in line with the slot in the opposite pedal.

The brake-shoe camshafts are supported in two bushes in the axle case. These bushes are self-lubricating and may be driven out with a suitable drift when the camshaft has been removed.

The shoe fulcrum pins are screwed into the axle case and if removed the threads should be cleaned and smeared with Loctite before the pins are replaced to prevent any possibility of transmission oil leaking along the threads and to prevent the pins becoming loose during service.




Figure 37. REMOVING THE BRAKE SHOES

Relining the Brake Shoes

After removing the reduction units (see Page 23) to expose the brake mechanism remove the brake shoes, taking care not to over-stretch the springs (Fig. 37).

Remove the rivets from the brake shoes by drilling out the open portion of the shank, then punching out. Clean the shoes and fit new linings, ensuring that these fit close to the shoes and are not contaminated with oil or grease.

If the brake shoes are re-lined because of oil contamination the cause of the oil leakage must be rectified to prevent a recurrence. If thick oil leaks on to the brake shoes this will be from the reduction unit

and the brake drum should be removed from spur pinion shaft and the shaft oil seal renewed (see Page 25). As it is possible for oil to by-pass the seal by leaking along the shaft inside the collar, remove the collar, degrease the shaft and collar, then smear the shaft with Loctite and press the collar into position. Do not use Loctite on 770 tractors as this will make the collar difficult to remove, but fit a new 'O' ring in the groove inside the collar.

If transmission oil leaks on to the brakes, the oil seal housing should be withdrawn from axle case and the seals renewed (see Page 23).

Examine brake drums before refitting the reduction units. If the drums are excessively scored or worn they should be renewed or reground, otherwise excessive lining wear may take place.

Four-Wheel Braking System

This is an optional fitting on 880 tractors and on 990 tractors with heavy duty front axles. The rear brakes are as on standard tractors but are both operated by a single pedal and cannot, therefore, be applied independently to assist steering. The front-wheel brakes are hydraulically operated by a master cylinder mounted beneath the right-hand footplate.

The foot-pedal pivots freely on the brake cross-shaft and operates the brakes through a compensating lever. One end of the compensating lever contacts the brake cross-shaft lever, so operating the rear brakes, and the other end is connected to the front brake master cylinder by a push-rod. As the compensating lever is free to pivot on the pedal, this mechanism ensures that the front and rear brakes are applied evenly.

The compensating lever passes through a slot in the pedal and this slot limits the angle through which the compensating lever can pivot, thus ensuring that the rear brakes will operate in the event of hydraulic failure in the front brakes. The hand-brake operating lever contacts the brake cross-shaft lever and operates the rear brakes only.

The hydraulic pipe-line from the master cylinder passes down right-hand side of tractor and then along the front axle to each wheel. Flexible pipes are used from main frame to front axle and from front axle to each wheel. A pressure switch is fitted in the pipe-line between front axle and master cylinder to enable brake lights to be operated.

Brake Adjustment

As the brake linings wear during service the brake pedal travel will increase. When pedal travel becomes excessive adjust the brakes as follows:

1. Jack the rear wheels clear of ground and, with hand-brake in the "off" position, tighten brake rod adjuster nut until brake starts to bind then unscrew until the wheel revolves freely.
2. Apply hand-brake until wheel can just be turned then tighten adjusting nut on the other side until resistance to turning is equal on both wheels. Release hand-brake and check that




Figure 38. FRONT WHEEL BRAKE ADJUSTMENT
A. Brake adjuster B. Brake shoe steady post

wheels revolve freely then hold the adjusting nuts stationary and tighten locknuts.

3. Lower rear wheels on to ground and jack front wheels clear of ground.
4. Turn the square-headed adjuster on inside of back-plate (Fig. 38) clockwise until brake starts to bind, then unscrew two "clicks". Check that wheel rotates freely then adjust the opposite side brake in the same manner. As the front brakes are hydraulic, and therefore fully compensating, it is not necessary to balance the adjustment. Do not attempt to adjust brakes by means of the two slotted studs on the back-plate. These are the brake shoe steady posts and must not be disturbed.
5. Check level in fluid reservoir and top up if necessary. Lubricate pedal pivot and compensator lever through the three grease nipples.
6. Road test and check the brakes for satisfactory operation.

Setting the Brake Linkage

Once set, the linkage should not normally require any adjustment, the adjustment for lining wear being all that is required, but if the linkage has been disturbed re-set as follows:

1. Place hand-brake in the "off" position. The spring on brake pedal should then hold the pedal in its rearmost position, i.e., up against the footplate. Release locknut on hand-brake operating-lever adjusting screw and tighten adjusting screw as far as possible.
2. Adjust the length of master cylinder push-rod so that when the right-hand end of the compensator lever is held rearwards to take up




Figure 39. FRONT BRAKE MASTER CYLINDER
A. Filler cap B. Outlet pipe

the play in push rod ends, the compensator lever is at right-angles to centre line of brake pedal.

3. Unscrew adjusting screw in hand-brake operating lever until the clearance between cross-shaft lever and end of the compensator lever is reduced to 0.30 in. (0.76 mm), then tighten the locknut.
4. Adjust front and rear brakes as described previously.

Venting the Hydraulic Braking System

If the level of fluid in master cylinder reservoir is allowed to fall too low, or if any part of the system has been disconnected, the brake pedal will be "spongy" due to air being present in system. It will be necessary to remove this air-lock by venting the system at wheel cylinders (left-hand first and then right-hand). The sequence is as follows:

1. Remove rubber dust cover and attach a length of rubber tubing to wheel-cylinder vent screw. Place lower end of tube in glass jar containing a small amount of brake fluid. The end of the tube must be kept submerged in the fluid.
2. Slacken vent screw and slowly pump the brake pedal, pausing at end of each stroke, until the fluid issuing from tube shows no sign of air bubbles.
3. Tighten vent screw, taking care to hold tube under surface of the fluid.
4. The fluid in the reservoir must be replenished throughout venting to prevent another air-lock being formed. Carry out the above procedure on both wheels. Finally, check the vent screws for tightness, replace dust covers and top up the reservoir to the correct level. Only Girling crimson brake fluid should be used.




Figure 40. FOUR-WHEEL BRAKE MECHANISM

- | | | | |
|--------------------|------------------------------|----------------------|-------------------|
| A. Brake pedal | B. Compensator lever | C. Cross shaft lever | D. Cross shaft |
| E. Master cylinder | F. Brake rod | G. Camshaft lever | H. Brake camshaft |
| I. Handbrake lever | J. Handbrake operating lever | K. Adjusting screw | |




Figure 41. FRONT BRAKE MASTER CYLINDER

A. Filler cap	B. Washer	C. Cylinder body	D. Push rod	E. Retaining washer
F. Circlip	G. Dust cover	H. Plunger	I. Plunger seal	J. Thimble
K. Spring	L. Spacer	M. Spring washer	N. Valve stem	O. Valve seal

Dismantling Front Brake Assembly

1. Jack up front axle and remove wheel.
2. Slacken shoe adjuster (anti-clockwise), remove the two drum locating screws and withdraw brake drum from hub.
3. Remove the two brake shoes and springs. If wheel cylinder is not to be dismantled, e.g., when re-lining brake shoes, retain pistons in cylinder by wiring round the cylinder.
4. Remove adjuster plungers, clean them, and retain for fitting in the same position.
5. If cylinder is to be dismantled, disconnect flexible hose from wheel cylinder and secure the loose end above the level of master cylinder to prevent undue loss of fluid. Remove cylinder from back-plate.
6. Remove dust covers, pistons and vent screw.

Reassembling

1. Clean all wheel cylinder components by washing in brake fluid and examine for damage. Renew where necessary. Do not wash brake components in diesel fuel, petrol or paraffin as this will contaminate the rubber seals and shorten their life.
2. Refit vent screw.
3. Refit pistons, etc., with new seals. Renew dust covers as required. Care must be taken not to

contaminate seals, pistons, etc., with oil. The only lubricants used should be the special rubber lubricant supplied in the seal kit or brake fluid.

4. Fit wheel cylinder to back-plate. Reconnect flexible pipe. On 880 tractors the single-piston wheel cylinder must slide freely on the back-plate. On 990 tractors the bolts holding the double-piston cylinder should be left slack until the brake drum is fitted.
5. Replace adjuster plungers. If these are replaced correctly the slots in plungers will line up with brake shoes when the plungers are pressed down firmly on to the adjusting wedge.
6. If necessary, re-line the brake shoes and then replace together with the springs.
7. Examine brake drum for scoring and ovality and re-grind if required. Maximum amount which can be removed is 0.030 in. (0.75 mm). Replace brake drum and fit the two locating screws. On 990 tractors screw in the adjuster until the drum is locked. This will centralise the wheel cylinder so that the bolts holding wheel cylinder to back-plate can be tightened.
8. Top up reservoir and vent the system.
9. Replace the wheel and adjust brake shoes as described above.

Servicing the Master Cylinder

1. Disconnect master cylinder push-rod by unscrewing adjusting sleeve.

2. Disconnect hydraulic pipe-line from master cylinder.
3. Unscrew the two mounting bolts and remove master cylinder.
4. Remove dust cover and release circlip retaining the push-rod and piston assembly. Withdraw piston, spring and valve stem, etc.
5. Clean piston and cylinder by washing in brake fluid. **Do not wash components in diesel fuel, petrol or paraffin as this will contaminate the rubber seals and shorten their life.**
6. Fit new seals to piston and reassemble the piston and push-rod in cylinder; replace the retaining circlip and dust cover.
7. Fit master cylinder to tractor and reconnect pipe and push-rod.
8. Readjust the push-rod length as described under "Adjustment" and then top up the reservoir and vent the system.

DIMENSIONAL DATA

990 and 880 Gearbox

Pinion shaft bearing clearance (six- and twelve-speed)	0.002—0.004 in (0.05 —0.10 mm)
Layshaft bearing clearance (six- and twelve-speed)	0.002—0.004 in (0.05 —0.10 mm)
Main driveshaft end-float	0.006—0.010 in (0.15 —0.25 mm)
Creeper layshaft bearing clearance (twelve-speed)	0.001—0.003 in (0.025—0.076 mm)
Thrust washer clearance (twelve-speed):	
Creeper drive gear, minimum 0.015 in (0.38 mm)
Creeper driven gear, minimum 0.015 in (0.38 mm)
Differential cage end-float	0.000—0.002 in (0.00 —0.05 mm)
Crown wheel backlash	0.007—0.009 in (0.178—0.229 mm)
Muff coupling end-float (six-speed)	0.010—0.04 in (0.25 —1.0 mm)
Gearbox mounting clearance: vertical	0.016—0.021 in (0.40 —0.53 mm)
lateral	0.008—0.012 in (0.20 —0.30 mm)

770 Gearbox

Pinion shaft bearing clearance	0.001—0.003 in (0.025—0.076 mm)
Main layshaft bearing clearance	0.010—0.015 in (0.25—0.38 mm)
Creeper layshaft end-float	0.005—0.012 in (0.13—0.30 mm)
Driveshaft end-float	0.006—0.010 in (0.15—0.25 mm)
Differential cage end-float	0.000—0.002 in (0.00—0.05 mm)
Crown wheel backlash	0.007—0.009 in (0.178—0.229 mm)
Muff coupling end-float	0.010—0.040 in (0.25—1.0 mm)
Gearbox mounting clearance: vertical	0.016—0.021 in (0.40—0.53 mm)
lateral	0.008—0.012 in (0.20—0.30 mm)

Reduction Units — 990, 880 and 770 Tractors

Spur pinion shaft bearing pre-load	0.001—0.003 in (0.025—0.076 mm)
Final driveshaft bearing pre-load	0.005—0.007 in (0.127—0.178 mm)
Final drive gear backlash	0.006—0.010 in (0.15—0.25 mm)

Brakes

Drum diameter (new)	} rear	8.505 in (216.03 mm)
Drum diameter (maximum re-grind)		8.565 in (217.55 mm)
Drum diameter (new)	} front (12-inch brakes)	12.005 in (304.93 mm)
Drum diameter (maximum re-grind)		12.065 in (306.45 mm)
Drum diameter (new)	} front (10-inch brakes)	10.005 in (254.13 mm)
Drum diameter (maximum re-grind)		10.065 in (255.65 mm)

Tightening Torques

Gearbox mounting bolts	100 lb ft (13.83 kg metres)
Spacer bar nuts	70 lb ft (9.67 kg metres)
Pinion thrust bearing housing bolts	30 lb ft (4.15 kg metres)
Crown wheel attachment bolts	50 lb ft (6.92 kg metres)
Differential cover bolts	30 lb ft (4.15 kg metres)
Differential bearing cap bolts	120 lb ft (16.6 kg metres)
Gearbox pinion nut — 990 and 880 tractors	200 lb ft (27.6 kg metres)
Gearbox pinion nut — 770 tractor	150 lb ft (20.7 kg metres)
Creeper layshaft nut	150 lb ft (20.7 kg metres)
Rear axle to main frame bolts — 990 and 880 tractors	55 lb ft (7.6 kg metres)
Rear axle to main frame bolts — 770 tractor	45 lb ft (6.2 kg metres)
Reduction units to rear axle case bolts — 990 and 880 tractors	75 lb ft (10.5 kg metres)
Reduction units to rear axle case bolts — 770 tractor	45 lb ft (6.2 kg metres)
Transmission sump bolts	15 lb ft (2.1 kg metres)
Reduction case cover bolts — 990 and 880 tractors	30 lb ft (4.15 kg metres)
Reduction case cover bolts — 770 tractor	25 lb ft (3.46 kg metres)
Reduction case seal housing bolts	50 lb ft (6.92 kg metres)
Rear wheel nuts	110 lb ft (15.21 kg metres)

SUMMARY OF DESIGN CHANGES

Details of change

When introduced

Rear wheel fixing changed from six-bolt to eight-bolt. Part No. of final driveshaft changed from 910603 to 916494. Final driveshafts and wheel centres are not interchangeable.

990/482936
(March 1966)

Pre-load of spur pinion shaft bearings increased to 0.001—0.003 in. (0.025—0.076 mm) and pre-load of final driveshaft bearings increased to 0.005—0.007 in. (0.127—0.178 mm) pre-load.

990/491127
880/535724
770/584761
(September 1966)

Number of bolts attaching end-plate (903184) to differential cage (908780) increased from six to nine and length of dowels (14542) increased from $\frac{3}{4}$ in. (19.0 mm) to $1\frac{1}{8}$ in. (28.5 mm). Part Nos. of end-plate and cage are unchanged but the new dowels (621801) can only be used with a cage to the latest change.

990/491369
880/535881
770/584947
(September 1966)

Location of differential pin (30233) changed from split pins to circlips and differential pinions (15020) fitted with bushes. The new pin (916863), which is free to revolve in the differential cage, is interchangeable with the previous pin and the new pinion and bush assembly (910465) is interchangeable with the previous pinion.

990/491369
(September 1966)

Material of gear lever dirt excluder changed from rubber to neoprene. The new dirt excluder (917375), which is also a slightly different shape, is interchangeable with the previous excluder (903932).

All models
(October 1966)

Differential-lock pedal pivot pin increased in length so that pedal can be retained with spring pin instead of circlip used previously. Part No. of pivot pin (907643) changed to 919577 and this is interchangeable with previous pin if spring pin (690976) is also fitted.

990/492888
880/536714
770/585295
(October 1966)

Differential bearing cap studs, Part No. 608604, replaced by bolts 601240. Tabwasher, 11590 replaced by tabwasher, 626389. Studs and bolts are interchangeable but tabwasher 11590 should be used with studs and tabwasher 626389 used with bolts.

990/498101
880/540745
770/587310
(March 1967)

David Brown®

Service Repair Manual

990, 1200 & 1210 TRACTORS
with Selene 4WD Front Axle

Section C2 (Pub. 9-38116) February 1975



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



CONTENTS	Page
DESCRIPTION	3
FRONT WHEEL ALIGNMENT	3
FRONT HUBS AND EPICYCLIC REDUCTIONS GEARS	4
HALF SHAFTS AND UNIVERSAL JOINTS	4
DISMANTLING AND ASSEMBLY OF DIFFERENTIAL	9
INSTALLATION OF BEVEL PINION AND BEARING	15
FRONT AXLE CASE	18
PROPELLER SHAFT	18
TRANSFER GEARBOX	18
TYRE PRESSURES	22
TYRE SIZES	22
TRACK WIDTH	22
FINAL DRIVE REDUCTION	22
FRONT AXLE WEIGHT	22
FAULT FINDING	22
SPECIAL SERVICE TOOLS	23
BOLT TIGHTENING TORQUES	23
SPECIFICATION AND DATA	25
APPROVED LUBRICANTS	26
SERVICING INFORMATION	26

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

Reprinted in England by Waddington & Ledger Ltd., Dewsbury January 1978

© David Brown Tractors Ltd., Meltham, HUDDERSFIELD HD73AR

GENERAL DESCRIPTION

Four-wheel drive tractors are basically standard tractors with the addition of a 'live' front axle, connected by propeller shaft to a special transfer gearbox mounted on the underside of the tractor main frame. On 1200, 1210 tractors the transfer gearbox is driven by a muff coupling connected to the extended bevel pinion shaft, but on 990 tractors the transfer box is directly below the main gearbox and is driven by the second/third gear on the pinion shaft.

As front-wheel drive should not normally be engaged when travelling on the highway, or operating on very hard ground, a control lever under the tractor instrument panel operates a dog clutch in the transfer box to disengage the drive to the front axle.

FRONT WHEEL ALIGNMENT

Checking Alignment: With front wheels in straight-ahead position, move the tractor a short distance forward, so that the tyres settle in a free-rolling condition, then place an alignment gauge between the tyres. Place gauge pointer to zero. Remove gauge, replace in a similar position behind axle and check scale reading: this should read $\frac{1}{8}$ to $\frac{1}{4}$ in (1.6 to 6.3mm) toe-in.

Adjusting alignment: Remove split pin, nut and pivot pin from one end of track rod. Release the two clamp bolts then turn back rod end, clockwise to decrease toe-in, or anti-clockwise to increase toe-in. Replace track rod on steering lever and replace pivot pin, then recheck alignment.




FIGURE 1. FRONT HUB AND SWIVEL HOUSING

- | | | |
|------------------|---------------|-------------------|
| A. Front hub | F. Half-shaft | K. Thrust washers |
| B. End cover | G. Ring nuts | L. Swivel housing |
| C. Planet pinion | H. Bearings | M. Pivot plate |
| D. Annulus gear | J. Oil seal | N. Seal housing |
| E. Sun gear | | |

After adjusting the track rod length it is advisable to move the tractor at least 10ft (3 metre) before rechecking alignment, so that the wheels have settled in their new position.

When the alignment is correct, replace the pivot-pin nut. Tighten the nut as tight as possible by hand then use a spanner to tighten it to the next pin-hole and fit a split pin. This will give the track-rod end 0.004 to 0.008in (0.10 to 0.20mm) clearance on the steering lever.

FRONT HUBS AND EPICYCLIC REDUCTION GEARS

Refer to figure 1.

Hub removal: Raise front wheels from ground and place suitable supports under front axle case. Remove front wheel, turn hub so that the drain plug in hub casing is towards the bottom then remove plug and allow oil to drain.

Remove hub end-cover B; planet gears will be withdrawn with cover and leaves the sun gear on exposed half-shaft. Remove circlip from end of half-shaft and slide sun gear E off shaft splines.

After unlocking tabwasher, remove both ring nuts G from end of axle case, using a correctly fitting tubular socket so that the nuts are not damaged.

Remove thrust washer and annulus gear D, then withdraw hub A.

Hub oil seals: The hub seals J are accessible when the hubs are removed and a new seal should be fitted if there are any signs of oil leakage, or if the seal is damaged.

Lever out the old seal and after ensuring that the inside of the hub is clean, carefully press the new seal into position using a flat plate to prevent the seal being distorted and positioning the seal lip towards inside of hub.

Hub bearings: Clean and examine the bearings H whilst the hub is removed and renew if worn or chipped. Hub bearing adjustment is by means of shims fitted between the inner bearing and distance piece, and sufficient shims should be fitted so that when the retaining ring nuts are fully tightened the hub requires a torque of 5 to 8½ lb ft (0.7 to 1.2 kg metre) to turn it against drag of bearings and oil seal.

Epicyclic reduction gears: The planet gears C are carried inside the hub cover and run on needle roller bearings. Early gears have two sets of 25 loose rollers with a distance piece between but later models have a pair of composite roller bearings and no distance piece. The pinions should have 0.006 to 0.008in (0.15 to 0.20mm) end-float and 0.002 to 0.004in (0.06 to 0.12mm) clearance on shaft.

When replacing the pinions, smear the needle rollers with good quality grease and, if loose rollers, *ensure that distance piece is fitted between each set*—otherwise bearings will fail after a short period of service. Fit a thrust washer at each side of gears C and position flat on bearing pins towards centre. Refit retaining ring and secure with setscrews.

The annulus gear D may be pressed off its carrier after removing the setscrews. Align setscrew holes in gear and carrier when pressing new gear into position. Tighten setscrews evenly, and by diametrical selection, then fully tighten and lock with tab-washer.

Refitting hub: Wipe seal band clean and smear oil seal with clean grease. Replace hub with inner bearing inside, refit shims and distance piece. Fit annulus gear and carrier D with outer bearing attached, replace special washer and ring nut. Ensure that carrier is pushed against distance piece then fully tighten ring nut G with a correctly-fitting spanner. Check bearing pre-load, by measuring torque required to turn hub. This should be 5 to 8½ lb ft (0.7 to 1.2 kg metre) and if incorrect can be adjusted by changing thickness of shims between distance piece and inner bearing.

When bearing pre-load is correct, replace tabwasher and outer ring nut. Fully tighten ring nut then securely lock with tabwasher. Replace sun gear E on shaft end. Push gear against inner circlip then replace outer circlip. Fit new gasket on cover face then replace cover B, complete with planetary gears. Turn cover until all gears are in mesh then turn hub to align bolt holes and push cover into position. Replace bolts and tighten evenly and by diametrical selection.

Refill hub with 2½ pints (1½ litre) of SAE 90 EP gear oil through plug hole. Turn hub so that plug hole is mid-way between three and four o'clock position, then check that oil reaches level of plug hole before replacing and fully tightening plug.

Replace wheels and lower tractor to ground.

HALF-SHAFTS AND UNIVERSAL JOINTS

Half-shaft end float: When hub is removed the half-shaft end float can be checked—see figure 2. This should be 0.06 to 0.08in (1.5 to 2.0mm) and if excessive can be reduced by removing the half-shaft and fitting new thrust washers.

Half-shaft removal: Remove the inner circlip on the shaft then, with the hub removed, the bolts inside the dirt shield will be exposed and removing these bolts will allow the dirt shield and hub carrier to be withdrawn.

When removing the hub carrier, support the drive-shaft so that it does not form an acute angle, otherwise the universal joint may fall apart.


Pull complete half-shaft assembly out of axle case, lay it on a *clean* surface and cover with paper to prevent dirt adhering to the universal joint.

Half-shaft thrust washers and seals: Thrust washers and seals are positioned in the axle case and hub carrier. If the washers are worn, or the seals damaged, they should be renewed.

Clean surplus grease from seal locations and note that both seals should be fitted with the seal lips inwards, away from the universal joint.

FIGURE 2.
CHECKING HALF SHAFT END FLOAT

- A. Ring nuts
- B. Shaft
- C. Dial gauge



Hub carrier bush should have 0.008 to 0.012in (0.20 to 0.30mm) clearance on shaft. Bush is an interference fit in carrier and a suitable tool for replacing the bush is shown in Figure 3.

over spherical end of axle case and liberally coat the composite felt seal with oil before placing this on axle.




FIGURE 3. TOOL FOR REPLACING HALF-SHAFT BUSH

- | | |
|--------------------|----------------|
| A. 7½in (200mm) | D. 1½in (32mm) |
| B. 1.95in (49.3mm) | E. ¾in (9.5mm) |
| C. 1.50in (38.1mm) | |

Swivel housings: These pivot on tapered roller bearings and may be removed after disconnecting drag link and seal housing—N Figure 1, then removing the pivot plates—M so that the bearing cones can be withdrawn.

New seals should be fitted before the swivel housing is replaced. Gently stretch the smaller neoprene seal




FIGURE 4. TIGHTENING SWIVEL HOUSING BEARING PLATE
A. Shims

Replace swivel housing, bearing cones and pivot plates. Fully tighten plate bolts (figure 4) then check bearing setting. Add, or subtract, shims A under upper pivot plate until bearing end-float is almost eliminated, then remove 0.004in (0.010mm) of shims and replace pivot plate. When the bolts are finally tightened the bearings will then have the correct pre-load of 0.003 to 0.005in (0.08 to 0.13mm). When pre-load is correct, attach seals—N Figure 1, to swivel housing and replace track rod. Tighten track-rod nut as tight as possible by hand then use a spanner to tighten nut to next pin-hole: This will give rod end 0.004 to 0.008in (0.10 to 0.20mm) clearance on housing lever.

Universal Joints: To check joints for wear, hold half-shaft assembly vertically in a vice, long end of shaft downwards. Whilst pushing short end of shaft firmly downwards try to turn it backwards and forwards and if no play exists, the shaft is serviceable. If play is present, fit a new half-shaft assembly.




FIGURE 5.
CHECKING UNIVERSAL JOINT PRE-LOAD
A. Torque gauge B. Adaptor

Shaft joints are assembled with a pre-load of 20 to 24 lb ft (2.75 to 3.3 kg metre)—see Figure 5. The pre-load will, however, be reduced, due to normal wear when the shaft has been in service for a long time and a shaft without pre-load may be used again if no play exists in the joint.

NOTE: Parts are not available for the universal joint and should there be excessive wear a new complete universal joint assembly should be fitted.

When partly worn the assembly can come apart accidentally when removed from its housing. The following assembly instructions are offered only for such occasions—see Figure 6.

1. Drive the thrust ball pin lock out of the drive assembly—A Figure 6. This is necessary to allow the pin to be inserted fully during the assembly procedure.
2. Wash all parts of the universal drive with dry cleaning solvent and dry with compressed air.
3. Inspect all parts for chips or cracks. If there are any signs of cracking or chipping of the metal of the cusps or yoke or any other parts of the shaft, replace the complete shaft assembly.
4. Measure the balls with a micrometer, B Figure 6—for size, smoothness and roundness. If any one of the four driving balls or the centre ball shows evidence of excessive wear, cracks or flat spots, replace the assembly. Pair the two smallest and the two largest balls.
5. As the joint is being assembled, place the two largest balls diagonally across from each other as shown at 1 and 2, or 3 and 4, in C Figure 6. Clamp the short shaft in a vice with the universal joint section at the top. Install the centre ball pin D Figure 6. Fit the centre ball in the socket on the end of the shaft and then place the long shaft in position on the ball. Install three of the drive balls. To fit the fourth ball, turn the centre ball to bring the groove towards the drive ball about to be installed, E Figure 6. Push the driving ball into place. Straighten up the long shaft and remove the assembly from the vice. Insert the assembly and clamp the long shaft in the vice. Swing the short shaft sideways and lift it slightly to loosen the centre ball. Turn the centre ball to align the hole in it with the centre ball pin in the end of the short shaft, allowing the pin to drop into position in the ball. Push the two sections together firmly and drive a new ball pin lock into the joint end of the short shaft A Figure 6 and centre-punch both ends of the lock to hold it in position.
6. Lubricate the joint with general purpose grease. Move the joint while lubricating to ensure all working surfaces are covered.








FIGURE 6. ASSEMBLING UNIVERSAL JOINT

- A. Ball pin lock
- B. Micrometer
- C. Positions of drive balls
- D. Centre ball pin
- E. Centre ball




FIGURE 7. DIFFERENTIAL UNIT

- | | |
|---------------------------|-------------------------|
| A. Pinion thrust bearings | D. Differential pinions |
| B. Spiral gear | E. Differential gear |
| C. Spiral gear thrust pad | F. Bevel pinion |

DISMANTLING AND ASSEMBLY OF DIFFERENTIAL

Refer to Figure 7.

Differential Unit: The axle case is equipped with a four-pinion differential. The unit is carried on two taper roller bearings which are adjustable by adjuster wheels located at either side of the differential housing. The lubricant is confined to the differential unit.

Bevel Pinion: The bevel pinion is mounted on a single taper roller inner bearing and a double taper roller outer bearing. The adjustment of these bearings is controlled by a spacer and shims on the bevel pinion shaft.

Thrust Pad: The thrust pad is mounted in the differential housing at the rear of the spiral gear (crown wheel). The thrust pad prevents distortion of the spiral gear when either a driving force or extreme torque is suddenly applied to the axle.

Removing Differential Housing: Drain the oil from the hubs and differential and then remove the half-shafts. The differential housing may then be removed, by taking out the setscrews which hold it into the axle case.




FIGURE 8.
SLACKENING DIFFERENTIAL ADJUSTER WHEELS

Removing Differential Unit: Slacken the nut on the end of the bevel pinion before removing the differential unit. The bearing adjuster lock plates (2 off) should be removed and the two remaining bearing cap nuts should be slackened. Unscrew the bearing adjuster wheels to relieve bearing load (see Figure 8) with a tool to the dimensions shown in Figure 9. The bearing caps may now be removed followed by the differential unit from the carrier.

Note the bearing caps should be marked to facilitate assembly.

Removing Thrust Pad: The thrust pad is located in the side of the differential housing. Early 4-wheel drive units had the locknut welded in place after setting and therefore the weld must be broken. When

assembling use loctite in place of the weld. The later units use loctite. After the locknut has been removed the adjusting screw and thrust pad may be removed.




FIGURE 9.
WRENCH FOR TIGHTENING OR SLACKENING
THE DIFFERENTIAL ADJUSTER WHEELS




FIGURE 10.
REMOVING THE DIFFERENTIAL BEARINGS
A. Special puller

Removing Differential bearings and spiral gear (crown wheel): The bearings must be removed with a puller—see Figure 10. If the bearings are to be used again they should be wired to their appropriate race. Remove the bolts securing the spiral gear to the differential cage and then either press or pull the spiral gear off.




FIGURE 11. DRILLING OUT DIFFERENTIAL CAGE CAP LOCK PINS

A. Drill

Removing Differential cage cap: To do this the cap locking pins (3 off) must be removed. This is done by driving the pins below the surface, accurately centre punching the lock pins. Then drill them out with a number one (0.288in) drill—see Figure 11. Punch the remaining sleeve out. Clamp the remaining assembly by the cage flange between copper jaws of a heavy vice. Heat the case immediately below the cage cap with an acetylene torch flame. The torch should be moved around the area below the cap until solder will flow when rubbed over the heated surface. When the cage is thoroughly heated loosen the cap with a blunt drift or by using a wrench—see Figure 12, to the dimensions shown in Figure 13.




FIGURE 12.
REMOVING DIFFERENTIAL CAGE CAP





FIGURE 13.
WRENCH FOR REMOVING DIFFERENTIAL
CAGE CAP





FIGURE 14.
REMOVING DIFFERENTIAL PINION LOCKING PIN

Removing Differential pinions and pins: Remove the locking pins (3 off) which hold the differential pins in place by drifting them out with a small punch—see Figure 14. The long differential pin should be removed with its appropriate pinions (2 off) and thrust washers (2 off). The two small differential pins should then be removed in turn along with their appropriate pinions and thrust washers. The remaining differential wheel and block may then be lifted out of the cage. Note—the differential pins may require drifting out of the cage.

Removing Bevel Pinion and pinion bearings: Referring to Figure 18, remove the bevel pinion nut A, drive flange B and oil seal C. The bevel pinion can now be pushed out of the front of the differential housing. Loosen the setscrew E which locks the bearing retainer nut in position. Remove bearing retainer nut—B Figure 15 from its position in the rear tail of the differential housing. Remove the rear inner bearing race—K Figure 18 and then drift the outer bearing races F and G from the differential housing.

FIGURE 15.
REMOVING DRIVE PINION BEARING RETAINING NUT
A. Locking screw removed
B. Wrench—see fig. 9



bearing race—K Figure 18 and then drift the outer bearing races F and G from the differential housing.

Remove the two inner bearing races J and H and spacer L from the bevel pinion. A bearing puller will be required to remove the bearings from the bevel pinion—Figure 16.

Inspection of Components: Clean all parts thoroughly in diesel, paraffin etc. Check the spiral gear and bevel pinion for chipped, scored or broken teeth. The oil seal contact point should not be scored or worn. If it is found that either one of these components is damaged they should both be renewed because they are matched together. Bearings and bearing races should be checked for damage, wear or pitting of the surface and replaced if necessary.

Differential wheels and pinions should also be inspected for signs of wear, pitting or chipped teeth. Thrust washers and thrust pad should be checked for being scored and replace if necessary.

Installing Differential Pinions, Wheels and Pins: Place a thrust washer over the hub of the differential wheel and then place the wheel in the bottom of the cage. Line up the locking pin hole in the long differential pin with the hole in the cage and then drive in the locking pin until it protrudes approximately $\frac{1}{8}$ in (2.5mm) inside the cage. Insert a thrust washer (side with indents towards the pinion) and pinion into the cage. Insert pinion shaft block with punch marked sides facing the short shaft holes. Drive the differential pin through the thrust washer, pinion and pinion block. Replace the other pinion and thrust washer. Drive the differential

pin fully home and insert the locking pin and peen over. The two smaller differential pins, pinions, thrust washers and locking pins should be fitted in the same way. Note the smaller differential pins only support one pinion each and do not go through the block but have one end supported in the block. Peen both locking pins over.

Installing cage cap: The cage should be clamped between copper jaws of a heavy vice. The threaded area of the cage where the cap fits should be heated as previously outlined in the dismantling section. The threaded portion of the cap should be immersed in oil and the remaining thrust washer and differential wheel should be assembled into the cage cap then screwed into the cage. A blunt punch may be used to tighten securely, or use a wrench as shown in Figure 12. Three holes 0.025in (0.6mm) diameter, equally spaced, should be drilled through the cage into the heavy sections of the cap. The new locking pins should be driven into the holes until they are $\frac{1}{8}$ in (1.5mm) below the surface of the cap. The edges around the hole should be peened over as at D Figure 17. The cage assembly should then be blown through with compressed air to remove any drilling swarf which will be in the assembly.

Installing Differential bearings and spiral gear: The bearings should be pressed onto the cage, check that there are no burrs on the cage cap. The spiral gear, (crown wheel) should also be pressed on, taking special care to line up the holes in the gear and cage flange. Replace the bolts but do not completely tighten until the differential is installed in the housing then lock with tabwashers.




FIGURE 16. REMOVING INNER BEARING AND SPACER FROM BEVEL PINION

A. Plate with hole for bevel pinion head to pass through
B. Puller




FIGURE 17. PEENING OVER DIFFERENTIAL CAGE CAP LOCKING PINS

- A. Cage
- B. Cage cap locking pins
- C. Cage cap
- D. Punch





FIGURE 18. ASSEMBLY OF PINION SHAFT

- A. Flange nut
- B. Drive flange
- C. Oil seal
- D. Bearing retaining nut
- E. Locking screw
- N. Shims for adjusting engagement with spiral gear
- P. Shims for controlling bearing pre-load
- F, G. Outer tracks
- H, J, & K. Inner tracks
- L. Spacer
- M. Splined washer



- | | |
|--------------------------|---------------------------------|
| A. Flange nut | H. Bearing inner track and race |
| D. Bearing retaining nut | K. Bearing |
| E. Locking screw | Q. Thickness of shims required |
| F. Bearing outer track | R. Distance collar |
| G. Bearing outer track | X & Y. Dial Gauge positions |

INSTALLATION OF BEVEL PINION AND BEARINGS

Refer to Figure 18A.

Press the outer tracks F and G of the bearings into the differential housing. Track G has a letter 'Y' etched on its edge, this should face the drive flange. Insert the race and its track K and secure with the retaining nut D. Tighten the locking screw E.

Finding the correct shims (N Figure 18) to position the pinion relative to the spiral gear: Take the dummy master pinion SK/DB 7917 (see special tool list on page 23) and fit the bearing track and its race H. Fit the assembly in the housing, entering it through the bearing K. Add the special distance piece R and nut A. (If R is not available, fit splined washer M and drive flange B Figure 18, instead). Tighten nut A a bit at a time, meanwhile rotating the pinion to ensure the bearings roll smoothly. Continue tightening the nut until the pre-load produces a resistance to turning in the pinion of 40-50 lb in (0.46-0.57 kg metre) measured as in Figure 19.

Using a dial indicator, alternately in position X and Y, measure the distance between the end of the dummy pinion and the bottom half of the differential bearing housing. Repeat on the other side of the housing (without turning the pinion) and take the mean of the two measurements. This is the equivalent of the thickness of shims required at N Figure 18, to give the correct meshing of the pinion and bevel gear. Remove the dummy pinion.




FIGURE 19.
CHECKING DRIVE PINION BEARING PRE-LOAD

Finding the correct shims for pre-loading the bearing: Temporarily assemble the selected pinion using the correct thickness of shims at N, and the bearing and inner track H transferred from the dummy pinion. Fit the bearing and inner track J to the pinion followed by the spacer L. This is the reverse order to the proper position and is necessary to permit adjustment of the pre-load between front and rear bearings. As a starting point, add the same thickness

of shims next to the spacer L as was found necessary at N.

Enter the pinion into the differential housing, add the splined washer M and the drive flange B. Do not add the oil seal at this stage. Tighten the flange nut to 180 - 200 lb ft (24.9 - 27.6 kg metre) making sure that the bearings roll smoothly by turning the pinion from time to time as the nut is tightened. Check the turning torque as shown in Figure 19. The correct amount of pre-load is achieved when the turning torque is 40 - 50 lb in (0.46 - 0.57 kg metre). Add shims, a small amount at a time, until the correct turning torque is obtained. Finally re-assemble the pinion with the spacer L transferred to the position against the shoulder on the pinion as shown in Figure 18, followed by the correct thickness of shims at P.

Retighten the drive flange nut to 180 - 200 lb ft (24.9 - 27.6 kg metre). If the castellation of the nut and split pin hole do not coincide, the nut should be removed and the back face machined off by either grinding or filing. Only a small amount of material will require removing. The split pin and oil seal should not be fitted at this stage.

IMPORTANT: *The importance of correct bevel pinion bearing preloads cannot be over-emphasised. The whole differential assembly operates at a higher temperature than it is possible to obtain when adjusting the bearings. The ideal setting allows the bearings, under operating conditions of load and temperature, to run free but without end play. When adjusting the differential the correct preload will appear too tight, but the unit will run free at operating temperatures.*

Assembly of differential unit into differential housing: Fit the steel thrust pad with its accompanying screw and locknut, noting that the locknut will only fit one way onto the screw. The thrust pad should be positioned well clear of the spiral gear until backlash has been set. The outer bearing races should be fitted over the differential inner bearing races and then place all the unit in the housing. Screw in the adjuster wheels until they contact the differential bearings races and then place all the unit in the housing. Screw in the adjuster wheels until they contact the differential bearings races and then place all the unit in the housing. Screw in the adjuster wheels until they contact the differential bearings. The two bearing caps can now be fitted taking special care that the caps are fitted to the side they were removed from.

Setting spiral gear backlash: Turn the bearing adjuster wheels to give excessive backlash and then tighten the two lower bearing cap bolts to 85 - 90 lb ft (11.8 - 12.4 kg metre). Fully tighten the spiral gear (crown wheel) bolts to the correct torque figure and then bend the tab washers over. Attach a dial indicator with its anvil resting against the back face of the spiral gear (crown wheel) and then eliminate all end float by turning the adjuster wheel opposite the crown wheel clockwise. The run out should be checked and should not exceed 0.003in




FIGURE 20.
CHECKING SPIRAL GEAR BACKLASH

(0.075mm). Position the dial indicator on the differential housing with the anvil resting on a gear tooth (right angles to its face—Figure 20) and then check the amount of backlash at 90 degree intervals around the spiral gear. At the point of least backlash stop and then turn the bearing adjuster wheels until only 0.001in (0.025mm) of backlash exists.

Note: Always move both the bearing adjusters an equal amount to maintain zero end play.

The bearing cap nut behind the spiral gear should now be tightened to 85 - 90 lb ft (11.8 - 12.4 kg metre), after fitting adjuster wheel locking tab. The remaining bearing adjuster wheel (opposite spiral gear) should be turned clockwise until the backlash reading is 0.006 to 0.008in (0.15 to 0.20mm) thus pre-loading the differential bearings. The remaining bearing cap nut should be torqued to 85 - 90 lb ft (11.8 - 12.4 kg metre), after fitting adjuster wheel locking tab.

If all adjustments have been made properly, the gears will be correctly meshed and quiet in operation. However, correct tooth mesh contact is essential for quiet operation and long life, therefore it is recommended that tooth contact be checked with engineers blue before fitting the bevel pinion shaft oil seal.

Checking the Tooth Marking: Lightly coat about a dozen crown-wheel teeth with marking blue, or red lead mixed with a little oil, and rotate the crown wheel backwards and forwards so that the coated teeth are rolled to and fro against the pinion; a slight pressure against the pinion will load the gears and give a clearer mark.

When sufficient rotation has been made to squeeze the marking out of the teeth and leave a bare area the exact size, shape and location of the tooth;




FIGURE 21.
SATISFACTORY TOOTH CONTACT - GEARS UNLOADED

examine the contact mark on drive side of the crown wheel teeth; mark on overrun side of teeth will be correct when drive side mark is correct.

Correct tooth marking is shown when the contact marking evenly covers the depth of the tooth flank. The marking should be an elongated oval shape nearer to the toe than the heel of the tooth. When running under operational loads the markings will spread to almost the full length of the tooth, see Figures 21 and 22.




FIGURE 22.
SATISFACTORY TOOTH CONTACT - GEARS UNDER
OPERATING LOAD




FIGURE 23.
HIGH TOOTH CONTACT

If the bevel pinion is too far out of mesh the contact area will be at the top edge of tooth flank, see Figure 23. Shims must be inserted between the bevel pinion and bearing. Then adjust the spiral gear (crown wheel) away from the bevel pinion to obtain correct backlash. Note an equal thickness of shims must be added between the two sets of bevel pinion bearings to maintain the correct pre-load.




FIGURE 24.
LOW TOOTH CONTACT

If the contact area is low down on the tooth flank the bevel pinion will be too tight in mesh, see Figure 24. This is rectified by removing shims from between the bevel pinion and bearing. The spiral gear (crown wheel) may require adjusting then to obtain the correct backlash. Note the same thickness of shims will require removing from between the two sets of bevel pinion bearings to maintain the correct pre-load.

Toe contact is shown by the contact area at the toe end of the tooth (inner edge of teeth), see Figure 25. To rectify this condition the spiral gear (crown wheel) requires moving out of mesh. Shims may be necessary to obtain satisfactory marking and backlash.




FIGURE 25.
SHORT TOE CONTACT

Heel contact is shown by the contact area at the large end of the tooth (outside edge), see Figure 26. This is rectified by moving the spiral gear (crown wheel) deeper into mesh. It will be necessary to remove shims from under the bevel pinion to obtain satisfactory markings and backlash.




FIGURE 26.
SHORT HEEL CONTACT

Screw the thrust pad adjuster screw in until the pad just touches the back of the spiral gear and then back it off $\frac{1}{16}$ to $\frac{1}{8}$ of a turn to give 0.006 to 0.008in (0.15 to 0.20mm) clearance. The nut should be treated with loctite and tightened securely—see Figure 27. Remove the bevel pinion nut and drive flange, fit the oil seal after coating the inner periphery with a non-hardening plastic gasket cement. Refit the drive flange and tighten the nut to 180 - 200 lb ft (24.9 - 27.6 kg metre).




FIGURE 27.

SPIRAL GEAR THRUST PAD ADJUSTER

- | | |
|------------------------------|----------------|
| A. Adjuster screw | D. Thrust Pad |
| B. Locknut | E. Spiral gear |
| C. Clearance (0.006-0.008in) | |

Pinion oil seal: This can be replaced without disturbing the pinion bearings. Remove front end of propeller shaft. Unscrew nut and withdraw driving flange from pinion. Remove seal with a suitable lever, wipe inside of casting and coat outer periphery of new seal and flange nose with a non-hardening plastic gasket cement. Carefully fit seal in position then smear inside of seal with grease. Replace driving flange, washer and nut. Fully tighten nut to 180 - 200 lb ft (24.9 - 27.6 kg metre), lock with split pin and replace propeller shaft.

FRONT AXLE CASE

The front axle case is attached to the front extension by a trunnion pin and to remove the axle it is necessary to remove the front extension from the tractor and then withdraw the trunnion pin, which is locked to the axle by a bolt through the axle tube.

Steering lock stops: Minimum turning radius is governed by stop screws which on early tractors were spot-welded to the axle case but on later tractors the screws are secured by locknuts.

NOTE: No adjustment of the stops must be made to reduce the tractor turning circle otherwise the half-shaft universal joints may be damaged and the front wheels foul the steering ram or tractor frame.

PROPELLER SHAFT

The propeller shaft has a standard automotive type universal joint at each end, the rear joint incorporating a sliding joint to allow for variations in shaft length as the axle pivots. When a shaft is separated at the sliding joint always ensure that when the joint is refitted both front and rear joints are on the same plane, see Figure 28.

TRANSFER GEARBOX

Selector mechanism: The selector ball and spring can be removed without draining the transmission oil. Remove plug in left-hand cover and extract ball and spring. Free-length of spring should be 0.949in (24mm).

After replacing the ball and spring, coat plug with a plastic non-hardening jointing compound before screwing plug into position: on early units this is a grubscrew with screwdriver slot. When replacing later type plugs, fully tighten plug then unscrew just sufficiently to permit the selector rod to be moved. Selector housing can be moved complete by draining oil and then removing the four setscrews which attach housing to left-hand side of gearbox. On 1200, 1210 tractors it is necessary to remove the hydraulic pump inlet pipe.

Selector fork is located on a rod by a socket head grubscrew, which must be removed to enable rod to be withdrawn from housing. The oil seal may then be replaced and the selector rod examined for wear. When assembling housing, check that selector rod is free from burrs and sharp edges, which could damage the oil seal, then smear rod and seal with grease.

Replace locking screw in selector fork. Refit detent ball, spring and plug as described previously.

Driving flange oil seal: After draining oil into clean containers, remove rear end of propeller shaft. Remove split pin and nut from end of driveshaft then lever flange off shaft. Remove seal housing from case, lever seal from housing then carefully press new seal into position.

Replace housing, using a new gasket, and smear inside of seal with grease. Examine driving flange for wear or sharp edges and clean if necessary. Replace flange and nut. Fully tighten nut before locking with split pin, replace propeller shaft and refill with oil.

TRANSFER GEARBOX REMOVAL 990 Selectamatic tractors

Refer to Figure 29.

The transfer box is attached to the tractor frame by eight nuts or bolts and two large bolts through the case lugs. Two of the smaller bolts are located above the full-flow filter housing; on later tractors two longer bolts are used in this position and access to them is inside the filter chamber. Also in the filter chamber are two smaller bolts which secure the hydraulic pump suction pipe to the transfer gear case and these must also be removed.




FIGURE 28. PROPELLER SHAFT




FIGURE 29. TRANSFER GEARBOX - 990 TRACTORS

- | | | |
|-----------------|-------------------|-------------------|
| A. Driving gear | E. Rear bearing | J. Oil seal |
| B. Top shaft | F. Circlip | K. Distance piece |
| C. Oil filter | G. Front bearing | L. Dog clutch |
| D. Output shaft | H. Driving flange | |




FIGURE 30.
REMOVING OUTPUT SHAFT

- A. Output shaft
- B. Extractor bolts
- C. $3\frac{1}{2}$ in centres
- D. Output bearing
- E. Selector dog
- F. Distance piece

When removing the transfer case from the tractor carefully note the thickness of the gasket used and the number of shims fitted between the front lugs. To maintain the correct gear backlash the original thickness of gasket and shims must be used when re-fitting the box. The gasket is laminated aluminium and a new one should be pared down to the correct thickness.

When the box has been removed the top shaft B may be driven out with a hammer and brass drift after removing locating screw from top of front lug. Lift gear A out, noting that distance pieces are fitted at each side of gear. The twin double-row ball bearings are retained in the gear by a circlip at each side; remove both circlips then press both races out at the same time.

To remove the lower shaft D, first remove flange nut followed by flange H and seal housing. Remove case sump cover and remove circlip F from inner shaft end: this is accessible from inside the filter housing. The shaft may then be driven forward with a brass drift or preferably extracted with a simple puller as shown in Figure 30. As the gear must be held square with the shaft a suitable distance piece F should be inserted between the gear and case, otherwise the gear will contact inside of casting and be tilted on shaft.

Extract gear from case when shaft has been withdrawn. Ball race on gear may be pressed out after removing circlip.

To remove hydraulic pump suction pipe it is necessary to remove the PTO unit and lift the gearbox.

Commence re-assembly by fitting gear complete with ball race, inside housing. Fit distance piece K behind the gear and fit the dog clutch L in front of the gear, then tap rear bearing E forward until circlip F can be replaced on end of shaft D. NOTE: If oil leakage is to be completely eliminated it is essential that all gaskets and bolts that are screwed into holes through case, are treated with a plastic non-hardening jointing compound.

Smear inside of oil seal with grease, replace driving flange H and nut. Fully tighten nut then lock with split pin.

Place upper gear, with distance piece at each end, between case lugs. Push shaft into position and replace locating screw.

Replacing 990 transfer gearbox: Temporarily fit a bolt in the drive flange and, whilst holding the upper gear stationary, check the gear backlash by measuring the bolt movement. Place unit in position without gasket and tighten bolts evenly until backlash at the driving flange is 0.002 to 0.005 in (0.076 to 0.127 mm) greater than the backlash between the two transfer gears, then measure the gap between main frame and transfer box faces with a feeler gauge. Ensure that the faces are parallel by checking the gap at four equidistant points then remove the transfer box. Refit the transfer box using a gasket of the measured thickness: if an aluminium gasket is used, laminations can be removed to give the required thickness.

After bolting the transfer case in position and before fitting the two large bolts through the forward lugs, check the clearance between lugs and frame—this should be approximately the same thickness as the gasket—then fit shims of this thickness and replace bolts.

Fit new element in hydraulic filter, reconnect propeller shaft and refill transmission with oil.

TRANSFER GEARBOX REMOVAL 1200 Selectamatic and 1210 tractors

Refer to Figure 31.

To gain access to the muff coupling it is necessary to drain the transmission oil, ensuring that this is kept clean if it is to be re-used, remove gearbox cover, brake cross shaft and tube. It is also necessary to remove the clutch stop on 1200 tractors. Remove bolt from muff coupling A and slide coupling on gearbox pinion so that it is clear of transfer box shaft. Disconnect rear end of propeller shaft and, whilst supporting weight of unit, remove the four large nuts attaching transfer case to main frame then lower case to ground.

Note thickness of main frame gasket so that a new gasket of the same thickness can be used when re-assembling.




FIGURE 31. TRANSFER GEARBOX - 1200, 1210 TRACTORS

- | | | |
|-----------------------|-----------------|-------------------|
| A. Muff coupling | E. Rear cover | J. Front bearing |
| B. Top shaft | F. Rear bearing | K. Driving flange |
| C. Intermediate shaft | G. Circlip | L. Oil seal |
| D. Output shaft | H. Selector dog | |

To remove upper gear, remove shaft circlip and the four setscrews attaching bearing housing to case, then push shaft B forward out of rear bearing and gear.

Remove centre shaft C in the same manner as upper shaft.

To remove lower shaft D, first remove flange nut followed by flange K and seal housing. Remove cover E from rear of case and extract circlip G from shaft end. Remove case sump cover then tap shaft forward with hammer and brass drift, leaving the rear bearing F, distance piece and gear in case.

Commence re-assembly by fitting lower gear, complete with ball race, inside case. Fit distance piece behind the gear and fit the dog clutch in front, then push shaft into position. Replace front bearing J and oil seal housing; tap rear bearing F forward and replace circlip G on shaft end.

NOTE: If oil leakage is to be completely eliminated it is essential that all gaskets, and bolts that are screwed into holes through case, are treated with a plastic non-hardening jointing compound.

Replace rear cover and sump cover. Smear inside of seal with grease, replace driving flange and nut. Fully tighten nut then lock with split pin.

Replace centre gear in case, push shaft C, with distance piece on splines, into position. Bolt housing on front of case and replace circlip on rear end of shaft.

Replace upper gear and shaft B in same manner as centre shaft.

Replacing 1200, 1210 transfer box: Ensure that *muff coupling is on tractor pinion shaft then bolt transfer box in position, using a new gasket of same thickness as original gasket or pare down a laminated aluminium gasket to correct thickness. Tighten bolts into main frame evenly and when fully tight check that transfer box is in line with gearbox by sliding muff coupling on to transfer box splines: coupling should engage freely in any position through full 360°. If the coupling does not line up correctly or the old gasket has been discarded, place transfer box in position and tighten bolts evenly until coupling aligns correctly. Ensure that the faces are parallel by checking the gap at four equidistant points with feeler gauges. Remove transfer box and fit gasket of same thickness as gap.*

Replace bolt through muff coupling, refit brake cross shaft and tube. Fit gearbox cover and oil pump suction pipe. Connect propeller shaft and refill transmission with *clean oil*.

Oil Levels

Level/filler plug in hub should be positioned just below wheel centre. Differential level plug is on left-hand side of differential unit.

To add grease to swivel housings, remove square-headed plug from front of housings and pump grease into housing until it shows at plug-hole.

The exposed part of the spherical face should be treated with thick oil or grease if the tractor is to stand for any length of time between periods of use.

TYRE PRESSURES

<i>990 tractor</i>		<i>lb/in² kg/cm²</i>
Road work	front 18	1.3
	rear 14	1.0
Field work	front 12	0.8
	rear 12	0.8
Front loader work	front 18	1.3
	rear 12	0.8

<i>1210, 1200 tractor</i>		
Road work	front 26	1.8 (10-24 6-ply)
	14	1.0 (11-24 4-ply)
	rear 17	1.2
Field work	front 12	0.8
	rear 12	0.8
Front loader work	front 26	1.8 (10-24 6-ply)
	14	1.0 (11-24 4-ply)
	rear 12	0.8

TYRE SIZES

To prevent undue 'wind-up' between the front and rear axles the original front and rear tyre sizes should be maintained. As the rolling radius differs for different makes of nominally the same size of tyres, it is preferable to replace with the same make of tyres. New tyres on one axle should not be mixed with worn tyres on the other axle.

TRACK WIDTH

Front wheel track is fixed at 54in (137cm) on 990 tractors and 60in (152cm) on 1200, 1210 tractors. Do not attempt to alter the wheel track by reversing the front wheels: the wheels *have a cone seat for the wheel nuts on one side only* and will work loose if fitted the wrong way.

FINAL DRIVE REDUCTION

Only 9/50 ratio final drive reductions are fitted to four-wheel drive tractors and this ratio must not be altered, otherwise the front-to-rear axle ratio will be incorrect.

FRONT AXLE WEIGHT

Maximum load on front axle should not exceed 6 600 lb (3000 kg) on 990 tractors and 8 250 lb (3750 kg) on 1210, 1200 tractors.

FAULT FINDING

NOTE: It is inherent in the design of the gear transfer train that a high-pitched whine will occur when travelling at high speed on a hard surface; this is normal. The whine will be reduced when working at normal cultivation speeds in the field.

Certain road surfaces also cause tyre noise that may seem to come from the axle case. Before attempting to eliminate axle noise, be sure the noise is not caused by the tyres. **DO NOT ATTEMPT TO LOCATE AXLE NOISE BY OPERATING THE TRACTOR WITH THE WHEELS OFF THE GROUND.**

The normal operating temperature of the transfer case is high, therefore, the assembly should not be considered overheated unless abnormal gear noise or lubricant leaks past the oil seals.

Difficulty in changing the main gears may be due to the tractor operating in 4WD on a hard surface and wind-up occurring in the transmission gears between the front and rear wheels. Disengagement of the drive to the front axle will eliminate this problem. It is also most important that the correct tyre size combinations and pressures are used.

SPECIAL SERVICE TOOLS

The following special tools are available from V. L. Churchill & Co. Ltd., P.O. Box 3, London Road, Daventry, Northants, NN11 4NF and are specifically designed for dismantling and re-building the differential assembly.

SK/DB 7912	Differential and Differential Retainer Adjuster
SK/DB 7913	Differential cage spanner
SK/DB 7915	Differential side bearing remover
SK/DB 7916	Differential pinion bearing remover
SK/DB 7917	Dummy master pinion
SK/DB 7918	Hub locknut spanner
R.G. 421	Pinion drive flange wrench
	$\frac{3}{8}$ - $\frac{1}{2}$ Convertors
R.G. 422	Torque meter 5 - 120 lb in
18G 191	Special Magnetic base dial indicator
4221	Main tool for bearing adaptors

BOLT TIGHTENING TORQUES

This is dependent on bolt material, which is indicated by code number stamped on bolt head.

Tightening Torques—Inch Size Bolts

Thread size	Number of threads	Bolt 5S		Bolt 8G		Bolt 10K	
		kg m	lb ft	kg m	lb ft	kg m	lb ft
$\frac{1}{4}$	20 UNC	0.90	6.5	1.36	9.75	1.86	13.5
$\frac{1}{4}$	28 UNF	0.95	7.0	1.42	10.25	1.93	14.0
$\frac{5}{16}$	18 UNC	1.89	13.75	3.02	22.0	4.25	31.0
$\frac{5}{16}$	24 UNF	2.00	14.5	3.21	23.5	4.52	32.75
$\frac{3}{8}$	16 UNC	3.11	22.5	5.12	37.0	7.30	53.0
$\frac{3}{8}$	24 UNF	3.35	24.5	5.39	39.0	7.60	55.0
$\frac{7}{16}$	14 UNC	4.50	32.75	7.20	52.0	10.10	73.0
$\frac{7}{16}$	20 UNF	4.83	35.0	7.72	56.0	10.52	76.0
$\frac{1}{2}$	13 UNC	5.91	43.0	9.45	68.5	11.30	82.0
$\frac{1}{2}$	20 UNF	6.14	44.5	9.68	70.0	13.53	98.0
$\frac{9}{16}$	12 UNC	8.70	63.0	13.96	101.0	17.55	127.0
$\frac{9}{16}$	18 UNF	9.27	67.0	14.58	106.0	20.48	148.0
$\frac{5}{8}$	11 UNC	12.90	93.5	20.80	150.0	29.40	213.0
$\frac{5}{8}$	18 UNF	13.50	98.0	21.80	158.0	30.80	223.0
$\frac{3}{4}$	10 UNC	19.65	142.0	31.45	227.5	42.58	308.0
$\frac{3}{4}$	16 UNF	21.30	154.0	34.30	250.0	48.0	348.0
$\frac{7}{8}$	9 UNC	27.70	200.0	44.40	320.0	62.90	455.0
$\frac{7}{8}$	14 UNF	29.40	212.5	47.0	340.0	66.36	480.0
1	8 UNC	37.90	274.0	60.80	440.0	84.90	615.0
1	12 UNF	39.26	284.0	64.70	468.0	89.80	650.0

Tightening Torques—Millimetre Size Bolts

Thread size	Thread pitch	Bolt 5S		Bolt 8G		Bolt 10K	
		kg m	lb ft	kg m	lb ft	kg m	lb ft
4	0.70 MA	0.23	1.7	0.37	2.7	0.52	3.75
5	0.80 MA	0.45	3.25	0.72	5.2	1.01	7.25
6	1.0 MA	0.77	5.6	1.23	8.9	1.73	12.5
7	1.0 MA	1.26	9.25	2.02	14.6	2.84	20.6
8	1.25 MA	1.89	13.7	3.02	21.8	4.25	30.8
8	1.0 MB	2.0	14.5	3.21	23.25	4.52	32.75
10	1.5 MA	3.35	24.25	5.36	39.0	7.54	54.5
10	1.0 MB	3.64	26.25	5.82	42.0	8.18	59.2
12	1.75 MA	5.68	41.1	9.09	65.8	12.80	93.0
12	1.5 MB	5.91	43.0	9.45	68.5	13.30	96.0
14	2.0 MA	8.62	62.3	13.8	100.0	19.40	140.0
14	1.5 MB	9.09	66.0	14.50	105.0	20.40	148.0
16	2.0 MA	13.10	95.0	21.0	152.0	29.50	214.0
16	1.5 MB	13.70	99.0	22.0	160.0	30.90	224.0
18	2.5 MA	16.40	118.6	26.30	191.0	37.0	268.0
18	1.5 MB	17.90	130.0	28.70	210.0	40.40	292.5
20	2.5 MA	22.90	165.0	36.60	260.0	51.50	372.5
20	1.5 MB	24.70	180.0	39.50	285.0	55.60	402.0
22	2.5 MA	27.70	200.0	44.40	322.0	62.40	452.5
22	1.5 MB	29.40	212.5	47.0	340.0	66.10	480.0
24	3.0 MA	35.60	258.0	56.90	412.0	80.0	580.0
24	2.0 MB	37.70	272.5	60.40	437.0	84.90	615.0

MA denotes metric coarse thread
MB denotes metric fine thread

SPECIFICATION AND DATA

Capacities

Front hubs	2½ pints (1.25 litres)
Front differential	4½ pints (2.5 litres)
Front swivel housings (minimum)	1 lb (0.45 kg)

Front axle

Front wheel toe-in (mean setting)	½ in (4mm)
Turning angle (inside wheel)	25° - 26°
Half-shaft end-float	0.06 - 0.08 in (1.5 - 2.0mm)
Half-shaft joint pre-load	20 - 24 lb ft (2.7 - 3.3 kg metre)
Steering swivel housing pre-load	0.003 - 0.005 in (0.08 - 0.13mm)
Front axle ground clearance (nominal)	14 in (35.6cm)

Front Hubs

Hub bearing pre-load	5 - 8½ lb ft (0.7 - 1.2 kg metre)
Planet gear and bearing clearance on shaft	0.002 - 0.004 in (0.05 - 0.10mm)
Planet gear end-float	0.006 - 0.008 in (0.15 - 0.20mm)
Planet gear shaft clearance in end cover	0.001 - 0.004 in (0.02 - 0.10mm)

Differential

Crown wheel and pinion backlash	0.006 - 0.008 in (0.15 - 0.20mm)
Crown wheel thrust pad clearance	0.006 - 0.008 in (0.15 - 0.20mm)
Pinion bearing pre-load (oil seal removed)	40 - 50 lb in (0.46 - 0.57 kg metre)
Differential side bearing pre-load	0.005 - 0.007 in (0.13 - 0.18mm)

Transfer Gearbox

Transfer gearbox to tractor gearbox-backlash (990)	0.003 - 0.006 in (0.08 - 0.15mm)
Method of transfer/tractor gearbox adjustment	Selective paper gaskets or laminated aluminium gaskets.
Backlash between any two transfer gears	0.006 - 0.008 in (0.15 - 0.20mm)
Selector dog backlash in gear	0.004 - 0.008 in (0.10 - 0.20mm)
Selector dog clearance on shaft	0.0015 - 0.004 in (0.03 - 0.10mm)
Selector spring free-length	0.949 in (24mm)

APPROVED LUBRICANTS

<i>Application</i>	<i>Grade</i>	<i>Brand Name</i>
Front differential	SAE 90EP	Amoco-MP Gear Lubricant SAE 90
Front hubs		BP - Gear Oil EP 90 Agricastrol Gear Oil EP 90/140 Esso Gear Oil EP 90/140 Mobil - Mobilube GX 90 Gear Oil Shell Spirax 90 EP
Front swivel housings	Multi-purpose Grease	Amoco-Arnoloth Grease 2 BP - Energreaße L2 Castrol - LM Grease Esso - Beacon 2 Mobil - Mobilgrease MP Shell - Retinax A

SERVICING INFORMATION

Servicing Periods

Front Swivel Housings	every 300 hours
Front Hubs	every 500 hours
Front Differential	every 500 hours
Transfer Gearbox (tractor transmission oil)	every 1000 hours
Propeller shaft	every week
Track rod joints	daily or more often in difficult or arduous conditions
Pivot points on transfer gearbox control linkage	lubricate with oil daily

David Brown®

Service Repair Manual

SYNCHROMESH TRANSMISSION

885, 990, 995 and 996 Tractors

Section C3 (Pub. 9-37142) January 1978



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



Written In *Clear
And
Simple
English*

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

© Published by David Brown Tractors Ltd.

Printed in England by The Cloister Press, Heston Mersey, Stockport.

CONTENTS

SECTION	DETAILS	PAGE
Introduction		C3/1
Methods of Removing the Gearbox		C3/2
Special Tools		C3/3
Removing the Gearbox: Method A		C3/9
Removing the Gearbox: Method B		C3/12
Installing the Gearbox: Method B		C3/12
Replacing the Oil Filter		C3/14
Installing the Gearbox: Method A		C3/14
Disassembly of the Gearbox:		
Introduction		C3/18
Disassembly		C3/18
Inspection of Parts		C3/21
Adjustments before Assembling the Gearbox:		
Auxiliary Layshaft		C3/23
Layshaft Bearings		C3/23
Gear and Range Levers:		
Removing		C3/24
Installing		C3/24
Dirt Excluders		C3/24
Assembling the Gearbox		C3/25
Differential:		
Disassembly		C3/28
Assembly		C3/28
Bevel Pinion Adjustments		C3/30
Spiral Gear Adjustments		C3/32
Reduction Units:		
Removing and Installing		C3/33
Disassembly		C3/35
Spur Pinion Shaft		C3/36
Final Drive Shaft		C3/37
Rear Axle Case Oil Seals		C3/39
Reduction Case Breather		C3/39
Data		C3/40

SYNCHROMESH GEARBOX, 8 AND 9 SERIES TRACTORS

Introduction

The gearbox is made from two end plates fastened together by four spacer bars. The gear shafts are kept in position by taper roller bearings. The taper roller bearings are installed in the end plates and can be adjusted by shims. On Livedrive tractors the gearbox drive shaft is hollow. This permits the installation of the cardan shaft which turns the power take-off unit. The bevel pinion and the gearbox output shaft are made in one piece. The differential and bevel wheel are installed on the rear end plate. Using this arrangement, the gearbox and differential can be assembled as a unit. The unit can then be installed in the tractor.

The six speed gearbox is a high range gearbox and a low range gearbox. The range needed can be selected by the range lever to change the gear ratio of the layshaft. There are three forward and one reverse gear in each range. The gear needed can be selected by the main gear lever. The twelve speed gearbox is a six speed gearbox with an auxiliary reduction gear installed on the front end plate. This reduction gear can be engaged by the range lever. When the auxiliary reduction gear is disengaged, the gearbox becomes a normal six speed gearbox.

MAINTENANCE AND REPAIR

Methods of Removing the Gearbox:

There are two ways of removing the gearbox.

Method A

This procedure must only be used for six speed gearboxes. It is done by removing the reduction units and lifting the gearbox up out of the main frame.

Method B

This procedure must be used for twelve speed gearboxes and can also be used for six speed gearboxes. It is done by separating the rear axle case and the main frame and removing the gearbox toward the rear of the tractor.

SPECIAL TOOLS

Tool	Illustration	Page
Gearbox support	1	C3/4
Tool for Compression of Detent Springs.....	2	C3/4
Tool for checking the Depth of Spring holes	3	C3/4
Differential Bearing Remover	4	C3/5
Tool for Removing Oil Seal Housing	5	C3/5
Tool for Removing the Brake Drum.....	6	C3/6
Modification to Brake Drum Removing Tool.....	7	C3/6
Pinion Setting Gauge.....	8	C3/7
Tool for Replacing Differential Lock	9	C3/7
Tool for Removing Final Drive Shaft	10	C3/8




Figure 1 GEARBOX SUPPORT

- A. 321 mm (12½ in)
D. ½ BSF tapped holes

- B. 351 mm (13½ in)
E. 304 mm (12 in)

- C. 295 mm (11½ in)

Note: It is essential that the two side supports are correctly aligned.




Figure 2

TOOL FOR COMPRESSING DETENT SPRINGS

- A. 9.5 mm (¾ in)
B. 15.9 mm (⅝ in)
C. 4.8 mm (⅜ in)
D. 150 mm (6 in)
E. Gear lever knob





Figure 3

TOOL FOR CHECKING DEPTH OF DETENT SPRING HOLES

- A. Round bar 10 mm (⅜ in) diameter
B. 27.94 mm (1.10 in)

Part No. K960605 DIFFERENTIAL BEARING REMOVER



N.B.—This tool is used in conjunction with Churchill No. 55 puller.

This tool consists of:—

- A. Two special claw legs
- B. A thrust pad
- C. Two adjustable arms

Figure 4

Part No. K900208 REAR AXLE OIL SEAL AND OIL SEAL HOUSING EXTRACTOR

Note: Use with K900207.




Figure 5

Part. No. K960618 BRAKE DRUM REMOVER AND REPLACER




Figure 6

- A. Main tool
B. Large tommy bar (not shown)
C. & D. Two distance pieces

- E. Annular spacer
F. Two $\frac{1}{2}$ in BSF bolts
G. Two $\frac{3}{4}$ in BSF bolts




Figure 7
MODIFICATIONS TO
BRAKE DRUM REMOVER

- A. Service tool 960618
B. Additional pair of 13.5 mm ($\frac{1}{2}$ in) dia. holes at 104.8 mm ($4\frac{1}{4}$ in) centres
C. Holes in distance piece converted into 13.5 mm ($\frac{1}{2}$ in) wide by 7.9 mm ($\frac{5}{16}$ in) deep slots
D. 47.6 mm ($1\frac{7}{8}$ in) } Collar
E. 82.5 mm ($3\frac{1}{4}$ in) }
F. 44.5 mm ($1\frac{3}{4}$ in) }
G. 88.9 mm ($3\frac{1}{2}$ in) } Distance tube
H. 22.2 mm ($\frac{7}{8}$ in) } (two required)
J. 14.3 mm ($\frac{9}{16}$ in) }




Figure 8
PINION SETTING GAUGE
(Service Tool DB 8208)

- | | |
|-------------------|------------|
| A. Dummy bearings | B. Mandrel |
| C. Spacer | D. Probe |




Figure 9 TOOL FOR REPLACING DIFFERENTIAL LOCK SLEEVE

- | | | |
|---------------------|---------------------|--------------------|
| A. 609.6 mm (24 in) | B. 228.6 mm (9 in) | C. 101.6 mm (4 in) |
| D. 304.8 mm (12 in) | E. 38.1 mm (1½ in) | F. 25.4 mm (1 in) |
| G. Hose clip | H. 103.2 mm (4¼ in) | |




Figure 10 TOOL FOR REMOVING FINAL DRIVE SHAFT




Figure 11 DIMENSIONS OF JACKING PLATE

Material — Steel plate 12 mm ($\frac{1}{2}$ in) thick.

Dimensions

- A. 114.3 mm ($4\frac{1}{2}$ in)
- B. 57.1 mm ($2\frac{1}{4}$ in)
- C. 93.7 mm ($3\frac{3}{4}$ in)
- D. 38.9 mm ($1\frac{1}{2}$ in)
- E. 85.7 mm ($3\frac{3}{4}$ in)
- F. 76.2 mm (3 in)
- G. 70.6 mm ($2\frac{3}{4}$ in)
- H. 29.4 mm ($1\frac{1}{4}$ in)

- J. Drill 4 holes
20.5 mm ($\frac{3}{4}$ in) dia.
- K. Drill 4 holes
17.5 mm ($\frac{1}{2}$ in) dia.
- *L. Drill 2 holes
11.1 mm ($\frac{7}{16}$ in) dia.
and tap $\frac{1}{2}$ - 16 BSF.

*Alternatively if BSF taps are not available, thread to suit jacking bolts, minimum 12 mm ($\frac{1}{2}$ in) dia.

Removing the Gearbox (Method A)

1. Clean the outside of the tractor.
NOTE: To do the next jobs you will need clean containers with covers. Make sure that the containers will hold all the fuel from the fuel tank. Use a separate container which will hold a minimum of 40 litres (5 gal) for the transmission oil.
2. Remove the fuel from the fuel tank.
3. Remove the oil from the transmission casing.
4. Disconnect:
The battery cables.
The drive for the engine speed indicator.
The throttle linkage.
The fuel pipes from the fuel tank.
5. Remove:
The bracket for the engine stop control from the steering box.
The fuel tank with the instrument panel.




Figure 12

Tractors with Manual Steering

6. Remove the bolts which fasten the steering box to the main frame.
Disconnect the drag link from the steering drop arm.
Remove the steering assembly.
NOTE: Do not turn the steering wheel after the steering assembly has been removed.

Tractors with Hydrostatic Steering

7. Remove the oil from the steering reservoir.
8. Disconnect the inlet pipe from the steering pump.
9. Disconnect the four pipes which are fastened to the steering valve.
Make sure that you can connect the pipes correctly by putting a mark on each pipe.




Figure 13

MAINTENANCE AND REPAIR

10. Remove the support bracket with the steering column and the steering valve.
NOTE: Do not turn the steering wheel after the steering column has been removed.
11. Remove:
The tractor seat and support bracket. The bolts which fasten the gearbox cover to the clutch housing.
The wedge fitted between the gearbox cover and the clutch housing.
The bolts which fasten the gearbox cover to the main frame and the rear axle casing.
The gearbox cover.
12. Put a support below the drawbar frame.
Remove the bolts which fasten the drawbar frame to the hitch.
Remove the support and lower the drawbar frame to the ground.
13. Disconnect the sensing unit cable.
Remove the sensing unit.
14. Use a hoist to hold the PTO in position.
Remove the vacuum switch adaptor.
Remove the bolts which fasten the PTO to the rear axle casing.
Install two guide studs into horizontally opposite holes in the rear axle casing.
Pull the PTO away from the rear axle casing.
Lower the PTO to the ground.
Pull the cardan shaft out of the gearbox.
15. Use a 5 ton jack to raise the back of the tractor.
Put a support below each side of the rear axle casing.
16. Loosen the adjusting nuts on both brake rods.
Remove both reduction units. See Section: Removing the Reduction Units.




Figure 14

- A. Hitch Plate
B. Setscrews (Hitch plate to PTO casing)




Figure 15

- A. PTO case B. Adaptor C. 'O' ring — adaptor

17. Remove the oil seal housing from the right hand side of the axle casing.
Put your hand into the axle casing and pull the differential locking sleeve and spring away from the differential.
NOTE: If the differential locking sleeve and spring do not move easily, get assistance to move the differential lock pedal up and down.
Continue pulling until the locking sleeve and spring are away from the differential. It is not necessary to remove the locking sleeve and spring from the axle casing.
18. Use external circlip pliers to remove the circlip from the groove in the clutch shaft. Move the circlip and the muff coupling toward the clutch until the muff coupling is away from the gearbox main shaft.
Keep the shims which are installed between the muff coupling and the gearbox mainshaft for use when you install the gearbox.
19. Remove the lubrication pipes for the gearbox.
20. Remove the bolts and bushes which fasten the gearbox to the main frame.
21. Use a hoist to remove the gearbox from the main frame.




Figure 16

- | | |
|----------------------------|---------------------|
| A. Oil seal housing | B. Bridge piece |
| C. Bolts into seal housing | D. Extraction bolts |




Figure 17 DIFFERENTIAL LOCK

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | B. Sleeve |
| C. Operating fork | D. Pedal |
| E. Return spring | F. End plate — differential cage |

17. Remove the oil seal housing from the right hand side of the axle casing.

Put your hand into the axle casing and pull the differential locking sleeve and spring away from the differential.

NOTE: If the differential locking sleeve and spring do not move easily, get assistance to move the differential lock pedal up and down.

Continue pulling until the locking sleeve and spring are away from the differential. It is not necessary to remove the locking sleeve and spring from the axle casing.

18. Use external circlip pliers to remove the circlip from the groove in the clutch shaft. Move the circlip and the muff coupling toward the clutch until the muff coupling is away from the gearbox main shaft.

Keep the shims which are installed between the muff coupling and the gearbox mainshaft for use when you install the gearbox.

19. Remove the lubrication pipes for the gearbox.

20. Remove the bolts and bushes which fasten the gearbox to the main frame.

21. Use a hoist to remove the gearbox from the main frame.




Figure 16

- | | |
|----------------------------|---------------------|
| A. Oil seal housing | B. Bridge piece |
| C. Bolts into seal housing | D. Extraction bolts |




Figure 17 DIFFERENTIAL LOCK

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | B. Sleeve |
| C. Operating fork | D. Pedal |
| E. Return spring | F. End plate — differential cage |

5. Tighten the bolts and check that both lugs of the front end plate are against the main frame. Do this job to make sure that the gearbox is aligned correctly.
If the lugs are not against the main frame:
Loosen the four $\frac{3}{8}$ in Nyloc nuts at the front of the gearbox.
Hit the spacer bars with a soft faced hammer until the lugs are against the main frame.
Tighten the Nyloc nuts to 9.7 kg m (70 lb ft).
6. Remove the mounting bolts and install the bushes.
Install the mounting bolts and tighten to 13.8 kg m (100 lb ft).
7. Clean the faces of the main frame and the axle case.
Put grease on to a new gasket and install the gasket on the main frame.
8. Use a trolley jack to raise the axle case and push the axle case in position on the dowels.
9. Install the screws and tighten to 7.6 kg m (55 lb ft).
10. See the procedure for Installing the Gearbox (Method A).
Do jobs 8 to 27.




Figure 19

R 77-190

MAINTENANCE AND REPAIR

Replacing the Oil Filter

Before you install the gearbox you must:

Remove the oil filter cover, the filter screen and the filter element.

Clean inside the main frame.

Remove the old gasket from the main frame and axle casing faces.

Wash the filter gauze in new fuel oil.

Destroy the filter element and the 'O' rings.

Assemble a new filter element to the filter screen.

Using new 'O' rings, install the filter element and gauze on the oil suction pipe.

Using a new gasket, install the oil filter cover.

NOTE: Make sure that you do not cause damage to the new filter element before or during installation.

Installing the Gearbox (Method A)

1. Install the shims on the gearbox mainshaft.
2. Use a hoist to lower the gearbox into the main frame.
3. Install the mounting bolts at the back of the gearbox without the bushes.
4. Tighten the mounting bolts and check that both lugs of the front end plate are against the main frame. Do this job to make sure that the gearbox is aligned correctly.

If the lugs are not against the main frame:

Loosen the four $\frac{3}{8}$ in Nyloc nuts at the front of the gearbox.

Hit the spacer bars with a soft faced hammer until the lugs are against the main frame.

Tighten the Nyloc nuts to 9.7 kg m (70 lb ft).

5. Remove the mounting bolts and install the two bushes.

Install the mounting bolts and tighten to 13.8 kg m (100 lb ft).




Figure 20 OIL FILTER

A. 'O' ring	B. Filter Element
C. 'O' ring	D. Magnet
E. Screw	F. Valve and Gauze
G. Gasket	H. Filter Cover
J. Setscrew	K. Drain Plug

R 77 131

6. Move the muff coupling toward the gearbox until the splines are engaged to the maximum. Do not use force to do this job. The splines must engage easily in any position.
7. Install the circlip in the groove in the clutch shaft and check the free movement of the muff coupling.
The free movement must be 0.20 to 1.0 mm (0.008 to 0.040 in).
If necessary, move the muff coupling until it is disengaged from the gearbox mainshaft and add or remove shims until the free movement is correct.
8. Remove the sharp edges from the splines of the cardan shaft.
Push the cardan shaft through the gearbox into the clutch.
NOTE: If this job is difficult, disengage the PTO clutch. Then push and turn the cardan shaft until it is in the correct position.
9. Install the differential locking sleeve. To do this job using the tool shown in Figure 9.
Install the spring in the end plate.
Put the locking sleeve on the tool with the splines away from the handle of the tool.
Using the tool put the locking sleeve into the axle casing.
Push the tool toward the differential until the groove of the locking sleeve is behind the inner gusset of the casing.
NOTE: Do not permit the tool to go into the spring or it will be difficult to engage the selector fork into the groove of the locking sleeve.
Move the selector fork until it is in alignment with the groove of the locking sleeve.
Then turn the tool clockwise to engage the locking sleeve with the selector fork.
Push the tool a small amount toward the differential until the end of the tool is in the spring.
Push the tool toward the differential until the splines on the locking sleeve engage into the splines on the end plate.
Push the pedal to engage the differential lock.
Use wire to hold the lock in position.
Remove the tool.

MAINTENANCE AND REPAIR

10. Before you install new oil seals in the rear axle case, check that the seal lips are toward the differential. After you have installed the oil seals put grease into the space between the oil seals.
See Section: Rear Axle Case Oil Seals.
11. Use a brush to put jointing compound on to the face of the right-hand seal housing.
Install the seal housing to the axle casing using a soft faced hammer.
12. Check the condition of the brake shoes and install new linings if necessary.
Clean the faces of the axle casing and inside the brake drums.
Install both reduction units. See the Section Installing the Reduction Units.
Tighten the bolts to 10·4 kg m (75 lb ft).
13. Install both rear wheels.
14. Adjust both brakes.
15. Use a 5 ton jack to raise the back of the tractor.
Remove the supports.
Lower the tractor to the ground.
16. Use a hoist to install the PTO.
Tighten the bolts to 10·4 kg m (75 lb ft).
17. Install the lubrication pipes.
18. Use a new gasket and install the gearbox cover.
Check that the gear levers are engaged in the selectors.
Install the bolts and tighten all the bolts to 1·4 kg m (10 lb ft).
Tighten the bolts which fasten the cover to the axle case to 6·9 kg m (50 lb ft).
Tighten the bolts which fasten the cover to the main frame to 6·9 kg m (50 lb ft).
Install the wedge between the cover and the clutch housing.
Install the bolts and tighten to 6·9 kg m (50 lb ft).

Tractors with Manual Steering

19. Install the steering assembly.
Install and tighten the bolts which fasten the steering box to the main frame.
Connect the drag link to the drop arm.
Check the oil level of the steering box and add oil if necessary.

Tractors with Hydrostatic Steering

20. Install the steering column and mounting bracket.
Connect the four pipes to the steering valves. Use the marks to put the pipes in the correct position.
Connect the inlet pipe from the steering pump.
Fill the steering reservoir with new oil to the correct level.
21. Fill the transmission with oil to the correct level.
NOTE: If you use the old oil, put the oil in the transmission using a funnel with a fine filter.
Destroy the last 5 litres (one gallon). Add new oil to the correct level.
22. Install:
The fuel tank with the instrument panel.
The bracket for the engine stop control.
23. Connect:
The fuel pipes to the fuel tank.
The throttle linkage.
The drive for the engine speed indicator.
The battery cables.
24. Install the tractor seat.
25. Fill the fuel tank with new fuel oil.
26. Start the engine.

Tractors with Hydrostatic Steering

27. Use a 5 ton jack to raise the front wheels.
Turn the steering wheel from left to right four times to remove air from the hydraulic system.
Check the oil level and add new oil if necessary.




Figure 21

R77132




Figure 22

R77133

Introduction

The construction of the twelve speed and six speed gearbox is similar and the basic parts are the same.

The difference is that the twelve speed gearbox has an extra layshaft, drive gear and selector linkage.

The procedure for disassembly and assembly of both gearboxes is the same except for Operation 11, Disassembly, and Operation 18, Assembly.

The procedure for disassembly and assembly of the extra layshaft is in the section: Auxiliary Layshaft.

Disassembly of the Gearbox

1. Put the gearbox on an acceptable stand. See the section Special Tools.
2. Put a support under the slow/normal selector rod and remove the Mills pins from the selector fork and the selector jaw. Use a 500 g (1 lb) hammer and a 3 mm ($\frac{1}{8}$ in) punch to do this job.
3. Move the slow/normal selector rod toward the front of the gearbox. At the same time push the selector jaw and fork toward the rear end plate. Remove the selector jaw and fork. Pull the selector rod out of the front end plate. Remove the ball and spring.
4. Engage low gear and put a soft metal punch between two gears to stop the pinion shaft turning.
Use a socket spanner $1\frac{1}{8}$ in A/F, to remove the Nyloc nut from the pinion shaft.
NOTE: Turn the nut **CLOCKWISE**.
Remove the washer and the bearing cone.
Remove the soft metal punch.
Put the selector jaws in the neutral position.
5. Remove the four Nyloc nuts which fasten the front end plate to the spacer bars.




Figure 23




Figure 24

6. Engage medium gear by pushing the shortest selector rod toward the rear end plate. Keep the selector rod in this position. At the same time use a soft faced hammer to hit the front end plate toward the front of the gearbox until the end plate is away from the ball and gear lock grooves in the selector rod.
Remove the ball from the hole in the end plate.
7. Push the selector rod for the high/low range toward the rear end plate. Remove the selector lock, ball and spring from the front end plate.
NOTE: Selector locks are not installed on 'Q' cab tractors.
8. Push the selector rod for the low/reverse range toward the rear end plate.
Remove the lock, ball and spring from the front end plate.
9. Remove the driving gear from the driveshaft.
10. Hold the driveshaft in position and remove the front end plate.
When the end plate has been removed, hit it on a soft surface to remove the locks and springs.
11. Put the selector jaws in the neutral position.
12. Remove the driveshaft with the selector rod and fork.
13. Remove the layshaft.
14. Put a soft metal or wood wedge between the end of the pinion shaft and the rear end plate.




Figure 25

R77136




Figure 26

R77137




Figure 27

R77138




Figure 28

R77139




Figure 29

R77140

MAINTENANCE AND REPAIR

15. Remove the distance pieces, shims and special washer. Remove the high gear. Be ready to keep the bearing pads which will fall when the gear is moved.
16. Remove the sliding gear with the selector rod and fork.
17. Remove the front dog gear.
Use external circlip pliers to remove the circlip.
Remove the back dog gear.
18. Remove the medium gear. Be ready to keep the bearing pads which will fall when the gear is moved.
19. Remove the special washer.
Use external circlip pliers to remove the circlip.
NOTE: A split ring is used instead of a circlip on later models.
20. Remove the low gear with the selector rod and fork.
21. Put a mark on both the differential bearing caps and the rear end plate so that you can assemble the bearing caps in the correct position.
22. Put a support under the differential.
Remove the bearing caps.
Remove the differential assembly.
23. Remove the wedge and carefully pull the pinion out of the rear end plate.




Figure 30

Auxiliary Layshaft (12 speed gearboxes)

Disassembly

1. Remove the setscrew, tabwasher and locking plate from the front end plate.
2. Push the layshaft spindle out of the end plate.
3. Remove the layshaft and the two thrust washers.
4. Push the needle roller bearings and the distance piece out of the layshaft.




Figure 31

INSPECTION OF PARTS

Selector Parts

1. Check the position of a detent ball in the grooves of the selector rods.
There must be a small clearance between the detent ball and the bottom of the groove.
If there is no clearance, remove material from the bottom of the groove.
2. Measure the length of the springs.
If the length is less than 31.7 mm (1½ in) replace the spring.
3. Measure the depth of the spring hole.
To do this use a metal rod 100 mm (4 in) long and 10 mm (¾ in) diameter.
Use a hacksaw to put a mark 27.9 mm (1.100 in) from one end.
Put the bar in the spring hole with the measured end toward the bottom of the hole.
Look through the hole for the selector rod.
The mark must be at the same level as the edge of the hole for the selector rod.
If the mark is below the edge of the hole, remove the rod, install shims in the bottom of the spring hole.
Do this until the mark and the hole are aligned.

Gear Teeth

1. Check the gear teeth for wear and damage.
If it is known that a gear will not hold in the engaged position, replace the gear wheels in that ratio.
2. Check that the centralizer springs can be easily moved in the grooves in the sliding gear.
NOTE: Do not try to disassemble the sliding gear.
Be careful not to damage the cones in the sliding gear.

Bearings

1. Check the bearings for wear or damage. If you can see any wear or damage to the layshaft bearings, they must be replaced.
2. Check the bearing cups in the end plates for wear and damage.
NOTE: If it is necessary to replace a taper roller bearing, the bearing cup must also be replaced.




Figure 32
SELECTOR ROD AND DETENT BALL

A. Correct

B. Wrong

R77/M3




Figure 33
CHECKING DEPTH OF
DETENT SPRING HOLES

- A. Test rod
B. 27.94 mm (1.10 in)
C. End plate

R77/M3

MAINTENANCE AND REPAIR

Auxiliary Layshaft Bearings

1. Check the needle roller bearings, the layshaft spindle and the layshaft bore for wear and damage.

NOTE: If any one of these parts needs replacing, all the parts must be replaced. If this is not done, the result will be rapid wear of all the parts and possible gearbox failure.

Driveshaft Bush

1. Check the bush inside the front of the driveshaft for wear.
Replace if necessary.

Driven Gear

1. Replace the oil seal and 'O' ring inside the driven gear.

Use 'O' ring Part Number K623555.

Install the oil seal with the seal lip towards the differential.

To prevent damage to the oil seal when you install the PTO cardan shaft, remove the sharp edges from the splines of the cardan shaft.

Layshaft Bearing Failure

This can be caused by a failure of the lubrication system. Check:

1. That the oil pipes are correctly positioned.
2. That there is a supply of oil from the pump.




Figure 34

- A. Driveshaft Bush
- B. Driven Gear
- C. Oil Seal
- D. 'O' Ring

R77/45

ADJUSTMENTS BEFORE ASSEMBLING THE GEARBOX

Auxiliary Layshaft: Twelve Speed Gearbox

If a new layshaft, spindle and needle bearings are being installed, do these jobs:

1. Put the layshaft with the bore vertical on a flat surface.
2. Put one needle bearing, the distance piece and the other needle bearing inside the bore of the layshaft.
3. Use a straight edge and a feeler gauge to measure the clearance between the face of the layshaft gear and the case of the needle bearing.
4. The correct clearance must be 0.25 mm (0.010 in) to 1.3 mm (0.050 in).
5. If the clearance is not correct check:
The needle bearings are Part Number K620273.
The length of the distance piece is 42.54 to 42.67 mm (1.675 to 1.680 in).




Figure 35

Layshaft Bearing Clearance

1. Remove the cup for the layshaft bearing from the front end plate.
Remove shims approximately 0.20 mm (0.008 in) in thickness.
Install the cup in the front end plate.
2. Put the layshaft in position in the rear end plate.
Install the front end plate.
Install the Nyloc nuts on the spacer bars and tighten to 9.7 kg m (70 lb ft).
3. Turn the layshaft to align the bearings.
4. Put a dial gauge against the end of the layshaft and move the layshaft backwards and forwards.
Measure the amount of movement.
5. To find the correct amount of shims needed:
Example: Amount of movement 0.016 in
Minus (—) Movement needed 0.003 in
Shims needed 0.013 in
6. Remove the front end plate and the layshaft.
Remove the bearing cup from the front end plate.
Install the correct amount of shims and the bearing cup.
7. Do jobs 2, 3 and 4 again to check that the clearance is correct.
This is important.




Figure 36 POSITION OF SHIMS

A. = 1.5 to 1.73 mm (0.058 to 0.068 in)
Install shims in the front end plate.

A. = 3.33 to 3.58 mm (0.131 to 0.141 in)
Install shims in the rear end plate.

GEAR LEVERS

Removing

1. Clean the gearbox cover and the ball housings.
2. Remove the setscrews which fasten the ball housings to the gearbox cover.
3. Remove the ball housings with the gear levers.
4. Put a cover over the holes in the gearbox cover to prevent dirt falling into the gearbox.
5. Remove the gear lever knobs by turning the knobs counterclockwise.
6. Bend the tabwashers away from the support plate setscrews.
Remove the support plate setscrews and the support plate.
7. Hold the ball end of the gear lever.
Carefully pull the gear lever through the dirt excluder.

Installing

1. Put grease in the ball housing.
2. Hold the ball end of the gear lever. Push the lever in position through the dirt excluder.
3. Install the support plate, setscrews and new tabwashers.
4. Tighten the support plate setscrews to 0.55 kg m (4 lb ft).
Bend the tabwashers to keep the setscrews in position.
5. Install the gear lever knob.
6. Use a new gasket. Install the ball housing on the gearbox cover.
Check that the lever is engaged in the selector jaws.
7. Install the setscrews. Tighten to 0.97 kg m (7 lb ft).

Dirt Excluders

1. Check the dirt excluders for wear and damage.
Replace if not correct.
2. Make sure that when the clip is in position the dirt excluder is tight against the ball housing.
NOTE: A hose clip can be used to hold the dirt excluder in position.




Figure 37 GEAR SELECTOR LEVERS

A. Range lever
C. Support plate
E. Gear lever

B. Housing
D. Dirt excluder
F. Housing

R77148

AUXILIARY LAYSHAFT

Twelve Speed Gearbox: See Figure 31

1. Install the needle bearings and distance piece in the layshaft bore.
Put the layshaft in position in the front end plate.
2. Install a thrust washer at each end of the layshaft.
3. Align the holes and install the spindle.
4. Turn the spindle until the slot in the spindle is aligned with the screw hole in the end plate.
5. Install the locking plate, screw and tabwasher.
6. Tighten the screw to 2 kg m (15 lb ft).
Bend the tabwasher to hold the screw in position.

Temporary Installation of the Differential:

1. Put the differential assembly in position on the rear end plate.
2. Install the bearing caps with the marks correctly aligned.
3. Install the bolts and tabwashers and tighten the bolts to 16.6 kg m (120 lb ft).

Assembling the Gearbox:

1. Install the pinion into the rear end plate.
Put a soft metal or wood wedge between the end of the pinion shaft and the rear end plate.
2. Install the low gear complete with the selector rod and fork.
3. Install the circlip or the split ring.
Install the special washer.
NOTE: A split ring is now used instead of a circlip. See Technical Bulletin No. 63 of Aug. 1975.
4. Install the medium gear and the bearing pads.
5. Install the back dog gear with the smaller tooth sections toward the centre of the gearbox.
Look for the mark on the face of the dog gear.
Use external circlip pliers to install the circlip.
6. Look for the mark on the face of the front dog gear.
Install the front dog gear so that the smaller tooth sections are toward the back dog gear and the marks are aligned.
7. Install the sliding gear with the selector rod and fork.
8. Install the high gear and the bearing pads.
9. Install the special washer and the distance piece.
Use thick grease to hold the washer in position.
Add one shim, 0.008 in, to the shims that were removed.
Install the shims and distance piece.
NOTE: The small shoulder of the distance piece must be installed toward the front of the gearbox.
10. Install the layshaft.
11. Install the range pinion, also the selector rod and fork.
12. Put the selector jaws in the neutral position.
13. Install the springs and low/reverse and medium/high gear locks in the front end plate.
14. Put the front end plate in position on the end of the spacer bars.





Figure 38




Figure 39

MAINTENANCE AND REPAIR

15. Install the ball for the low/reverse selector rod using the special tool.
Do the procedure as follows:
Put the spring and the ball in the hole in the front end plate.
Hold the tool with the flat part toward the end of the selector rod.
Push the ball down with the tool.
Push the front end plate until the selector rod is in the hole and against the flat part of the tool.
Remove the tool.
16. Move the low/reverse selector rod forward until the groove in the rod aligns with the gear lock.
17. Install the four Nyloc nuts on the spacer bars for two turns.
18. Twelve Speed Gearbox.
Install the driving gear on the driveshaft.
19. Install the ball for the high/low selector rod, using the special tool to push the ball down as in Operation 15.
At the same time pull the selector rod toward the front end plate until the rod is against the flat part of the tool.
Remove the tool and pull the selector rod toward the front end plate.
20. Install the ball for the medium/high selector rod using the special tool as in Operation 19.
21. Align the layshaft bearings and push the front end plate into position.
22. Check that the lugs on the front end plate are against the face of the stand.
Tighten the nuts to 7.9 kg m (70 lb ft).
23. Install the bearing, special washer and Nyloc nut on the pinion shaft. See Figure 41.
24. Remove the wedge from between the pinion and the rear end plate.
25. Engage low gear and put a soft metal punch between two gears to stop the pinion shaft turning.
Use a socket spanner, 1 $\frac{1}{4}$ in A/F, to tighten the Nyloc nut to 27.6 kg m (200 lb ft).
26. Turn the pinion shaft to align the bearings.
27. Put a dial gauge against the end of the pinion shaft and move the pinion shaft backwards and forwards.
Measure the amount of movement.
28. To find the correct amount of shims to remove:
Example: Amount of Movement 0.010 in
Movement needed 0.000 in
Shims to be removed 0.010 in
NOTE: The tolerance is +0.002 to -0.002 in.
29. Remove the Nyloc nut, special washer, bearing and distance piece from the pinion shaft.
Remove shims of the correct size.
Install the distance piece, bearing, special washer and Nyloc nut.
Tighten the Nyloc nut to 27.6 kg m (200 lb ft).




Figure 40 GEARBOX FRONT END-PLATE

- A. Detent springs
- B. Detent ball (Low/Reverse Gear)
- C. Detent ball (Medium/High Gear)
- D. Interlocking plunger




Figure 41

- A. Nyloc Nut
- B. Special Washer
- C. Bearing Cone
- D. Distance Piece
- E. Shims

30. Remove the punch from between the gear teeth.
31. Engage either high or low gear.
32. Install the lock, spring and ball for the slow/normal selector rod.
Push the ball down using the special tool and install the slow/normal selector rod in the front end plate.
33. Push the selector rod through the selector fork and the selector jaw.
34. Put a support under the selector rod and install the Mills pin.
35. Make the adjustment to the spiral gear free movement.
See the Section: Spiral Gear for the procedure.

DIFFERENTIAL

Disassembly

1. Bend the tabwashers and remove the nine setscrews which fasten the cage to the end plate.
2. Put a mark on the cage and the end plate so that you can assemble the parts in the correct position. This job is important.
3. Use a soft faced hammer to remove the end plate.
4. Use external circlip pliers to remove the two circlips from the pin.
5. Use a mild steel punch and a hammer to remove the pin.
6. Remove the bevel wheels and bevel pinions.
NOTE: It is not necessary to remove the spiral gear from the cage unless it is to be replaced. If a new spiral gear is being installed, do jobs 7 and 8.
7. Bend the tabwashers and remove the nuts and bolts which fasten the spiral gear to the cage.
8. Use a soft faced hammer to remove the spiral gear.
9. Check the two ball bearings for wear and damage.
10. If there is wear or damage, use Service Tool K960605 to remove the bearings. **DO NOT** use a tool which pulls against the outer track of the bearings.




Figure 42 DIFFERENTIAL ASSEMBLY

- | | | | | | |
|----|---------------------|----|-------------|----|---------------|
| A. | Crown wheel | B. | Cage | C. | End plate |
| D. | Ball thrust bearing | E. | Pin | F. | Bevel pinions |
| | | G. | Bevel gears | | |

Assembly

1. Before you install new bearings, look for the word THRUST on the outer track of each bearing.
2. Install the bearings with the word THRUST toward the adjuster wheels. Use a press to push the bearings into position.
3. Before you install a new spiral gear, make sure that the faces of the cage and the spiral gear are clean.
NOTE: Spiral gears and bevel pinions are made as a set.
Do not replace one part unless the other part is also replaced.
4. Put the spiral gear in position on the cage and install the bolts. Replace the tabwashers and install the nuts. Tighten the nuts evenly to 6-92 kg m (50 lb ft). Bend the tabwashers to keep the nuts in position.




Figure 43 REMOVING DIFFERENTIAL BEARINGS

5. Put a small amount of molybdenum grease on the faces of the bevel wheels and bevel pinions.
6. Install a bevel wheel in the cage.
Install the bevel pinions in the cage.
7. Align the holes in the bevel pinions with the holes in the cage and install the pin.
8. Use external circlip pliers to install a circlip at each end of the pin.
9. Install the other bevel pinion.
10. Align the marks on the end plate and the cage and use a soft faced hammer to hit the end plate in position.
11. Use new tabwashers and install the setscrews.
Make sure that the tabwashers are over the dowels.
12. Tighten the setscrews to 4.2 kg m (30 lb ft).
13. Bend the tabwashers to keep the setscrews in position.

BEVEL PINION ADJUSTMENTS

NOTES:

When you install a new spiral gear you must install a new bevel pinion.

You must then adjust the position of the bevel pinion so that it engages correctly with the spiral gear.


You must also make this adjustment when you replace the taper roller bearings on the pinion shaft. To make this adjustment the gearbox must be disassembled.

To Make the Adjustment

1. Use a mild steel punch and a hammer to remove the pinion bearing cup from the rear end plate. Remove the shims from the rear end plate. Install the pinion bearing cup. Make sure it is correctly in position.
2. Install the bearing cone on the pinion shaft.
3. Install the front end plate. Tighten the Nyloc nuts to 9.67 kg m (70 lb ft).
4. Put the bevel pinion in position. Install the front bearing cone, washer and nut.
5. Tighten the nut while turning the pinion shaft until there is no free movement. The shaft will now be difficult to turn.
6. Assemble the Setting Gauge No. DB 8208 by installing the B spacer (5.9375 in) on the probe. Install the probe in the mandrel. Install the nut.
7. Put the setting gauge in position on the rear end plate. Install the bearing caps and the bolts. Tighten the bolts to 16.6 kg m (120 lb ft). Make sure that the mandrel is easy to move.
8. Move the mandrel until the probe is toward the back face of the pinion bearing. Turn the probe until it is against the face of the bearing. Tighten the nut. Check again the position of the probe. Make an adjustment if necessary.
9. Use a feeler gauge to measure the gap between the spacer and the mandrel. Make a record of this measurement.
10. Look for the number on the pinion face. Make a record of this number.
11. To find the correct amount of shims needed:
Example: Negative (—) number on the pinion face: — 0.007 in

Constant dimension	0.030 in
minus (—)	0.007 in
	<u>0.023 in</u>


Gap measurement	0.057 in
minus (—)	0.023 in
Total shims needed	<u>0.034 in</u>



R77155

Figure 44
PINION SETTING GAUGE
(Service Tool DB 8208)

- | | |
|-------------------|------------|
| A. Dummy bearings | B. Mandrel |
| C. Spacer | D. Probe |



R77156

Figure 45
CHECKING PINION SETTING
DISTANCE

- | |
|-------------------|
| A. Rear end-plate |
| B. Pinion bearing |
| C. Probe |
| D. Measured gap |

Example: Positive (+) number on the pinion face:

+0.007 in

Constant dimension	0.030 in
plus (+)	<u>0.007 in</u>
	0.037 in

Gap measurement	0.057 in
minus (—)	<u>0.037 in</u>

Total shims need	<u>0.020 in</u>
------------------	-----------------

12. Remove the Setting Gauge from the end plate.
13. Remove the nut, washer and cone from the pinion shaft.
Remove the pinion shaft.
14. Remove the pinion bearing cup.
Install the correct amount of shims.
Install the pinion bearing cup.
15. See page 25 for assembly of the gearbox.

SPIRAL GEAR ADJUSTMENTS

To Make the Adjustment

1. Remove the screws and lockplates from both adjuster wheels.
2. Use a screwdriver or flat bar to turn the left adjuster wheel clockwise until the spiral gear is pushed away from the pinion.
3. Turn the right adjuster wheel clockwise. At the same time hit the bearing caps and the differential cage with a soft faced hammer.
4. Do this until the spiral gear is difficult to turn.
5. Use a 150 mm (6 in) screwdriver as a weight. Put the point of the screwdriver in a horizontal hole in the differential cage.
6. Turn the right adjuster counterclockwise until the weight of the screwdriver moves the spiral gear between the pinion teeth.
7. Put a mark on both the adjusting wheels.
8. Put the probe of a dial gauge against the driving face of one of the teeth of the spiral gear to measure the free movement between the teeth.
9. Turn the left adjuster wheel counterclockwise and the right adjuster wheel clockwise. Use the marks to make sure that you turn each adjusting wheel the same amount.
10. When the gauge shows a free movement of 0.18 to 0.23 mm (0.007 to 0.009 in), tighten the bearing cap bolts to 16.6 kg m (120 lb ft). Bend the tabwashers to keep the bolts in position.
11. Check the free movement again and if correct install the lockplates and setscrews. Tighten the setscrews to 2.0 kg m (15 lb ft). Bend the lockplates to keep the setscrews in position.




Figure 46




Figure 47

REDUCTION UNITS

Removing the Reduction Units

1. Put the tractor on hard and level ground.
2. Use a 5 ton jack to raise the back of the tractor. Put a support below each side of the rear axle case.
3. Remove the back wheels.
4. Loosen the adjusting nuts on both brake rods.
5. Engage the differential lock. Use wire to hold the lock in position. Do not do this if the gearbox is to be removed.
6. Remove the oil from each unit into a clean container. The total capacity is 5 litres (8 pints).
7. Remove the nuts which fasten the right-hand side reduction unit to the rear axle case.
8. Carefully pull the reduction unit away from the axle case until the dowels are disengaged.
9. Permit the unit to turn until it is in the vertical position.
10. Put a trolley jack in position under the reduction unit. Raise the jack until it is against the reduction unit. Use the jack as a support. Pull the reduction unit away from the axle case.
11. Do the jobs 7 to 10 to remove the left-hand side reduction unit.

Before you install the reduction units.

1. Check the brake linings for wear and damage. Replace if necessary. Look in the book for the procedure.
2. Replace the oil seals in the axle case. See the procedure on Page C3/39.
3. Check that the differential lock is in the engaged position. If the lock is not in the correct position, see Page C3/15 and do job 9.

Installing the Reduction Units

1. Clean the brake shoes, the brake drum and the faces of the axle case and the reduction case.
2. Put the reduction unit in position on a trolley jack. Raise the jack until the reduction unit is in alignment with the axle case.
3. Push the reduction unit toward the axle case until the shaft is engaged in the differential splines.




Figure 48 DIFFERENTIAL LOCK PEDAL HELD IN ENGAGED POSITION

A. Pedal

B. Operating lever




Figure 49


MAINTENANCE AND REPAIR

4. Remove the jack.
Turn the reduction unit to align the dowel holes.
Push the reduction unit in position on the dowels.
5. Install the spring washers and nuts.
Tighten the nuts to 10.5 kg m (75 lb ft).
6. Adjust the brakes.
7. Install the back wheels.
8. Remove the supports from under the axle case.
9. Remove the wire from the differential lock lever.
10. Fill with new oil to the correct level.


REDUCTION UNIT

Disassembly:

1. Make sure that you have removed all the oil from the reduction case.
2. Remove the cover.
3. Bend the tabwasher away from the ring nut.
4. Use a spanner (Service Tool K909842) and a hammer to loosen the ring nut.
5. Turn the ring nut until it is against the inner bearing.
6. Clean the two holes, ($\frac{1}{2}$ in BSF thread) in the final driveshaft flange. Early types only.
7. Install two bolts (Service Tool K900207) in the holes.
8. Tighten the bolts against the heads of two bolts which fasten the oil seal housing to the reduction case.
9. Continue tightening the bolts evenly until the shaft is pulled out of the housing.
10. Remove the ring nut, tabwasher and the shaft from the reduction case.
11. Remove the six setscrews which fasten the oil seal housing to the reduction case. Remove the oil seal housing and the sleeve. Remove the spur gear.
12. Use Service Tool K960618 to remove the brake drum. Do the procedure as follows:
Put the two $\frac{1}{2}$ in UNC \times $3\frac{1}{2}$ in bolts in the holes in the flange of the tool.
Put the annular spacer in position on the bolts.
Fasten the tool flange to the drum with the bolts.
Use a bar through the tool lug to prevent the tool from turning.
Tighten the extractor screw to remove the drum.
NOTE: If the brake drum is difficult to remove, hit the end of the extractor screw with a heavy soft-faced hammer. Then continue to tighten the extractor screw until the drum can be removed.
13. Use internal circlip pliers to remove the circlip which holds the end cover in the reduction case.
14. Hit the splined end of the shaft with a soft-faced hammer until the end cover, shims and outer bearing cup are pushed out of the case.
15. Remove the spur pinion shaft from the case.
16. Remove the bearing cones.
17. Use a long punch through the case to remove the oil seal.
18. Use internal circlip pliers to remove the circlip. Remove the distance piece.
19. Use a mild steel punch to remove the inner bearing cup.
Hit the bearing cup from the outside toward the centre of the case.




R77181



R77163

- A. Service Tool
C. Distance Piece
B. Brake drum $2\frac{1}{2}$ in
D. Bolts $\frac{1}{2}$ UNC \times $3\frac{1}{2}$ in



R77184

- A. Service Tool
F. Collar
H. Bolts $\frac{1}{2}$ UNC \times 5 in
E. Brake drum $3\frac{1}{2}$ in
G. Distance Tube

MAINTENANCE AND REPAIR

20. Remove the collar from the spur pinion shaft.
Remove the 'O' ring from inside the collar.

Inspection:

1. Check all the bearing cups and cones for wear or damage.
2. Check the gear teeth for wear or damage.
3. Check the outside face of the collar for wear.
4. Replace any parts that show wear or damage.
5. Replace all the oil seals and 'O' rings.
Destroy the old seals and 'O' rings.
6. Check the brake drums for wear. See the Data Section for the permissible size before replacement is necessary.




Figure 53

THE FINAL DRIVE SHAFT OF LATE TYPE TRACTORS

R77/82

SPUR PINION SHAFT

Installing and Adjusting

1. Install the inner oil seal, circlip and distance piece in the reduction case.
2. Install the inner bearing cup.
3. Install the bearing cones on the spur pinion shaft.
4. Put the spur pinion shaft into the reduction case with the splined end through the oil seal.
5. Install the outer bearing cup.
6. Install a new 'O' ring in the collar.
7. Install the collar on the spur pinion shaft with the shoulder toward the bearing.
8. Install the key in the groove in the spur pinion shaft.

NOTE: Two keys must be installed when the brake drum is $2\frac{1}{2}$ inches wide.

9. Put the brake drum on the spur pinion shaft.
Align the grooves in the brake drum with the key.
10. Put a support against the outer end of the spur pinion shaft.
Use a steel tube 50 mm (2 in) bore and a heavy hammer to put the brake drum in position against the collar.
11. Turn the spur pinion shaft to align the bearings.
12. Install the end cover without the 'O' ring.
Install the circlip.
13. Push the end cover toward the bearing.
Use a feeler gauge to measure the gap between the end cover and the circlip.
Make a record of the measurement.
14. To find the correct amount of shims needed:
Example: Measurement of the gap 0.012 in
Plus (+) Bearing preload 0.003 in
Shims needed 0.015 in
15. Remove the circlip and end cover.
Install the correct amount of shims against the bearing cup.
Put a new 'O' ring in position on the end cover.
Install the end cover.
Install the circlip.




Figure 54

R77/85




Figure 55

R77/86




Figure 56

R77/87

FINAL DRIVESHAFT

Installing and Adjusting

NOTE: When you install new oil seals, use a piece of plate or round bar to prevent damage to the seal.

1. Put the inner oil seal (single lip type) in the bore of the reduction case.
Make sure that the lip of the seal is toward the inside of the reduction case.
2. Use the plate or round bar to push the oil seal in position.
The correct position for the oil seal is when the distance from the outer face of the seal to the face of the reduction case is 25 mm (1 in).
3. Put the outer oil seal (double lip type) in the bore of the oil seal housing.
Make sure that the seal lips are toward the outside of the seal housing.
4. Use the plate or round bar to push the oil seal in position.
The correct position is when the seal is against the inner shoulder of the seal housing.
5. Install the dirt shield, new 'O' ring and collar on the final drive shaft.
Make sure that the inside chamfer of the collar is toward the flange end of the shaft.
6. Install the oil seal housing on the final drive shaft.
7. Install the bearing cup in the oil seal housing.
8. Install the bearing cone and the sleeve on the final drive shaft.
Make sure that the chamfered end of the sleeve is toward the bearing.
9. Use an acceptable piece of pipe to push the sleeve until the bearing cone is against the collar.
10. Clean the splines on the final drive shaft.
Put the correct grade of Loctite on the splines.
11. Put the spur gear in the reduction case.
Carefully put the drive shaft in the reduction case to engage in the splines of the spur gear.
When the drive shaft is through the spur gear, install the tabwasher, ring nut and bearing cone.
Tighten the ring nut with your fingers.
12. Turn the oil seal housing so that when you look toward the spur gear:
 - (i) The grease nipple on the right-hand side is in the 0700 hours position.
 - (ii) The grease nipple on the left-hand side is in the 0500 hours position.
13. Install three bolts which fasten the seal housing to the reduction case. Put the bolts in position at even distances.
Tighten the bolts with your fingers.




Figure 57




Figure 58

UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Synchromesh Transmission, Section C3, Pub 9-37142

MAINTENANCE AND REPAIR

Pub 9-38198

14. Use a spanner (Service Tool K909842) and a hammer to tighten the ring nut.
When the ring nut is tight, bend the tabwasher to keep the ring nut in position.

IMPORTANT: The bearings must be set to the correct amount of pre-load. Before this can be done the position must be found where there is no free movement or pre-load on the bearings. Use the following method:

15. With no shims fitted, install the three bolts (at 120 degrees) which hold the seal housing to the reduction unit. Hold the pinion shaft to stop it turning. Then turn the final drive gear clockwise and counterclockwise against the pinion teeth. You will hear a loud noise as the gear teeth contact each other.

Use a feeler gauge to measure the gap between the seal housing and the reduction case. Use a spanner to tighten the bolts until the gap is the same at all positions around the seal housing. Check that the loud noise is still there. If the noise is not there, loosen the three bolts an exactly equal amount. Check that the noise has returned. If not, repeat the above procedure until the noise returns.

16. Tighten the three bolts one flat each and hit the end of the shaft with a copper or lead hammer to align the bearings. Repeat this procedure until the noise starts to reduce. At this point there is no pre-load or end clearance in the bearings.

Measure the gap and make a note of this measurement.

To find the correct amount of shims that are needed, use the example below as a guide.

Measurement of the gap	0.015 in
Minus (—) bearing pre-load	0.005 in
Shims needed	<u>0.010 in</u>

17. Remove the three bolts.

Install the correct amount of shims.

NOTE: Put the shims in position so that the ends of the shims are horizontal when the reduction unit is installed on the axle case.

18. Install all the bolts. Tighten the bolts to 6.9 kg m (50 lb ft).

19. Use a grease gun on the grease nipple to put grease in the space between the inner and outer oil seals.

When you do this job, look inside the reduction case at the inner oil seal.

Add grease until you can see grease at the lip of the inner oil seal.

20. Install a new gasket on the cover.

Install the cover with the filler plug at the bottom. Install the setscrews. Make sure that the hollow bolt is installed at the top.

Tighten the setscrews to 3.5 kg m (25 lb ft).

NOTE: A hollow bolt is not installed to tractors that have been changed to High Clearance.

REAR AXLE CASE OIL SEALS

There are two oil seals installed at each end of the axle case.

Removing the Oil Seals

1. You will need Service Tool K900208. Do the procedure as follows:
2. Use two $\frac{1}{4}$ BSF \times 2 in bolts to fasten the tool to the housing.
3. Install the two special bolts (900207) in the tool.
4. Tighten the bolts evenly to pull the housing out of the axle case.
5. Remove the oil seals from the housing.

Installing the Oil Seals

1. Clean the oil seal housing and the inside of the axle case.
2. Put a new seal in position in the bore of the housing.
Make sure that the seal lip is away from the housing shoulder.
Use an acceptable piece of metal or wood, 3 in diameter, to push the seal to the end of the housing bore.
3. Put the second new seal in position in the bore of the housing.
Make sure that the seal lip is away from the housing shoulder.
Use the same piece of wood or metal to push the seal in the housing until it is level with the housing edge.
4. Put grease in the space between the oil seals.
5. Put jointing compound on the outside of the housing.
6. Use a soft faced hammer to hit the housing in position in the axle case.

Reduction Case Breather

To give release to any pressure that may be inside the reduction case, one of the cover bolts is hollow. When you install the cover on the reduction case, check:

1. The hole in the bolt is clear of dirt.
2. You install the hollow bolt at the top of the cover.
NOTE: Do not replace the hollow bolt with a bolt of the normal type unless the tractor has been changed to High Clearance.




Figure 59 REMOVING OIL SEAL HOUSING FROM AXLE CASE

- | | |
|----------------------------|---------------------|
| A. Oil seal housing | B. Bridge piece |
| C. Bolts into seal housing | D. Extraction bolts |




Figure 60 REAR AXLE CASE OIL SEALS

- | | |
|--------------|-----------------|
| A. Oil seals | B. Seal housing |
|--------------|-----------------|

MAINTENANCE AND REPAIR

DATA

Driveshaft end clearance	0.4 mm	0.015 in
Auxiliary layshaft end clearance	0.25 to 1.3 mm	0.010 to 0.050 in
Layshaft end clearance	0.05 to 0.10 mm	0.002 to 0.004 in
Pinion end clearance	0.000 mm	0.000 in
Spiral gear free movement	0.18 to 0.23 mm	0.007 to 0.009 in
Differential bearing end clearance	0.05 mm	0.002 in
Gearbox mounting bushes: vertical	0.40 to 0.53 mm	0.016 to 0.021 in
	horizontal	0.008 to 0.012 in
Muff coupling end clearance	0.20 to 1.00 mm	0.008 to 0.040 in
Spur pinion shaft clearance (minus)	0.07 mm	0.003 in
Final driveshaft clearance (minus)	0.12 mm	0.005 in
Brake drum diameter (new)	216.41 mm	8.52 in

TORQUE

Gearbox mounting bolts	13.8 kg m	100 lb ft
Spacer bar nuts	9.7 kg m	70 lb ft
Housing bolts (pinion thrust bearing)	4.15 kg m	30 lb ft
Spiral gear fastening bolts	6.9 kg m	50 lb ft
Differential end plate bolts	4.2 kg m	30 lb ft
Differential bearing cap bolts	16.6 kg m	120 lb ft
Bevel pinion nut	27.6 kg m	200 lb ft
Axle case to main frame bolts	7.6 kg m	55 lb ft
Axle case to reduction unit bolts	10.4 kg m	75 lb ft
Reduction case to seal housing bolts	6.9 kg m	50 lb ft
Gearbox cover bolts	6.9 kg m	50 lb ft
PTO to axle case bolts	10.4 kg m	75 lb ft
Reduction unit cover bolts	3.5 kg m	25 lb ft



David Brown®

**Service Repair Manual
1200 & 1210 TRACTOR
TRANSMISSION**

Section C4 (Pub. 9-37152) December 1973



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



CONTENTS

REPAIR OPERATIONS

(In same order as Schedule of Repair Times, TP 670)

Operation	Description	Page
K1.	Removing and replacing gearbox	1
K1a.	Dismantling and assembling gearbox	4
	Repairs with 12-speed gearbox <i>in situ</i>	13
K1b.	Dismantling and assembling differential	16
K1c.	Adjusting differential bearing end-float	17
K2.	Removing and replacing gear levers	19
K4.	Removing and replacing reduction units	20
K4b.	Dismantling and assembling reduction unit	21
K4c.	Removing and replacing rear axle case oil seal	23
K5.	Removing and replacing final drive shaft oil seal	24
K7.	Removing and replacing differential lock pedal	25
	DIMENSIONAL DATA	25
	SUMMARY OF DESIGN CHANGES	26

OPERATION K1

Removing and Replacing Gearbox

The gearbox can be removed upwards after removing both reduction units and gearbox cover, without disturbing the clutch.

1. Clean the exterior of the tractor, paying particular attention to the gearbox cover and rear axle case.
2. Disconnect main battery lead, instrument panel wiring and engine speed indicator drive.
3. Disconnect throttle linkage from lower end of hand lever then remove hand lever. Remove engine stop control bracket from steering box.
4. Disconnect fuel pipes (drain fuel tank, to reduce its weight, if full) and remove fuel tank complete with instrument panel.
5. Disconnect drag link from drop arm and drain steering box oil. Remove steering box complete with column and wheel.

CAUTION: Do not turn steering wheel into full left-hand lock when drag link is disconnected as the steering nut can be turned past end of screw and allow the steel balls to fall out.

If tractor is fitted with hydrostatic steering, drain reservoir, to prevent oil leakage, by disconnecting pump inlet then disconnect four pipes from servo valve. Alternatively supply and return pipes can be blanked off to prevent leakage.

Remove mounting bracket, complete with servo valve and steering column. Do not turn steering wheel after removal or oil will be discharged from servo valve.

6. Drain transmission oil, (capacity approximately 9 gal., 40 litres), through plugs in main frame and rear axle case. If oil is to be re-used ensure that containers are very clean and are removed from under tractor as soon as oil is drained.
7. Remove tractor seat and support bracket. Remove gearbox cover to clutch housing bolts, lift out wedge and shims. Remove all gearbox cover bolts, including five through rear axle case, then lift off gearbox cover. (Fig. 1).
8. Remove the two bolts attaching drawbar frame to hitch brackets and lower drawbar to ground. Disconnect sensing unit cable and remove sensing unit. Remove bolts attaching PTO unit to rear axle case and withdraw PTO unit complete. Slide cardan shaft out of gearbox. (Fig. 2).
9. Raise rear of tractor and place suitable support stands under each side of rear axle. Fully unscrew adjusting nuts on both brake rods, to prevent shoes binding on brake drums, then remove both reduction units (see Page 20).
10. Remove oil seal housing from right-hand side of axle case (see Page 23), so that a hand can be inserted into axle case to withdraw diff lock sleeve and spring. As spring may have expanded and trapped sleeve in case it may be necessary to manipulate diff lock pedal to release sleeve. It is not necessary to remove spring or sleeve from axle: all that is required is for spring and sleeve to be clear of differential.




Figure 1. TRACTOR WITH GEARBOX COVER REMOVED

- | | |
|---------------------|-------------------------------|
| A. Clutch assembly | B. Transmission release fork |
| C. PTO release fork | D. Support snout |
| E. Muff coupling | F. Bolts — clutch to flywheel |




Figure 2.
TRACTOR WITH PTO UNIT REMOVED

- A. PTO cardan shaft
- B. Lubrication pipe
- C. Guide studs
- D. Differential
- E. Differential lock sleeve

11. Disconnect drive between clutch and gearbox by moving the muff coupling. On six-speed gearboxes release circlip on gearbox driveshaft then slide muff coupling fully rearwards until it is clear of clutch shaft. On twelve-speed gearboxes release circlip on clutch driveshaft then slide muff coupling fully forward until it is clear of gearbox shaft. Remove shims from gearbox shaft and retain these until required for re-assembly
12. Remove gearbox lubricating pipes and bolts attaching rear of gearbox to main frame. Screw a ½ UNC eyebolt into tapped hole in rear end plate, attach suitable lifting tackle to eyebolt and lift complete gearbox, front end first, out of frame.

Replace gearbox in reverse order of removal, paying particular attention to the following.

1. Remove hydraulic filter assembly from underside of main frame. Wash the screen filter in clean fuel oil and if filter incorporates a paper element, discard this and fit a new element.
CAUTION: Handle new filter elements with care. A dry element is fragile and if split will allow unfiltered oil to pass into the hydraulic system. Before replacing the hydraulic filter, clean inside of main frame and remove all traces of gasket from frame and axle faces.
2. Fit muff coupling onto clutch shaft if 12-speed, or gearbox shaft if 6-speed, ensuring that any shims originally fitted at rear of coupling are replaced on gearbox shaft. Lower gearbox assembly, rear end first, into main frame. Replace the two rear mounting bolts, *without bushes*, and fully tighten so that end plate is held firmly down on frame then check that both front-end plate lugs are touching main frame face. If both lugs are not touching main frame, release the four Nyloc nuts on front end of gearbox studs then tap end of each stud with a soft-faced hammer to allow end-plate to align itself. Fully tighten stud nuts then remove mounting bolts, fit bushes and replace and fully tighten bolts.

3. Slide muff coupling into position — forward on 6-speed, rearward on 12-speed — and check that gearbox alignment is correct by ensuring that coupling can be easily engaged in any position through a full 360 degrees. Slide shaft circlip into its groove then check muff coupling end float, this should be 0.008 to 0.040 in. (0.20 to 1.02 mm) and, if necessary, should be adjusted by changing thickness of shaft shims.
4. Examine clutch stop, if fitted, whilst gearbox cover is removed. Check condition of brake band and reset internal adjustment (see Clutch Section).
5. Slide PTO cardan shaft through gearbox and into clutch, taking care not to damage or displace seal in clutch shaft, or on 12-speed gearbox, driving gear. If difficulty is experienced entering shaft into clutch, place PTO clutch hand lever in disengaged position, so that clutch plate is released, then turn shaft whilst pushing it into place. Ensure that shaft is pushed fully into flywheel spigot bearing.
6. Replace diff-lock spring in differential end plate. Place sleeve on tool, shouldered end of sleeve towards handle end of tool, and insert tool into axle case. Push tool inwards until sleeve shoulder is behind inner web of casting. When placing sleeve in this position ensure that protruding end of tool is not entered in the spring or the sleeve will be tilted and make subsequent engagement of pedal fork difficult. Manipulate the pedal fork until it is in line with sleeve groove then turn tool to move sleeve sideways and engage fork in sleeve groove. At the same time the protruding end of tool will automatically locate in the spring and act as a guide to align sleeve end plate with end plate splines. Push tool towards differential and manipulate it until splines on sleeve engage in end plate splines then wire diff-lock down to hold the sleeve in the engaged position and allow tool to be withdrawn without the sleeve becoming displaced. (Fig. 3).
7. Examine rear axle case oil seals and renew if not in good condition. New seals should be fitted with the seal lips towards centre of tractor and cavity between seals packed with high-melting point grease. Replace seal housing in right-hand side of axle, smearing outside of housing with jointing compound before pressing it into axle case.




Figure 3. TOOL FOR REPLACING DIFFERENTIAL LOCK SLEEVE

- | | | |
|----------------------|----------------------|---------------------|
| A. 24 in. (609.6 mm) | B. 9 in. (228.6 mm) | C. 4 in. (101.6 mm) |
| D. 12 in. (304.8 mm) | E. 1½ in. (38.1 mm) | F. 1 in. (25.4 mm) |
| G. Hose clip | H. 4⅞ in. (103.2 mm) | |

8. Ensure that axle case faces are clean and brake shoes in good condition. Smear outside of axle case oil seals with grease and wipe the inside of brake drums then refit reduction units, taking care not to damage oil seals. Degrease bolt or stud threads then smear with Loctite before replacing. (Grade AV)
9. Replace rear wheels and re-adjust brakes. Remove supports and lower tractor on its wheels. Replace PTO unit.
10. Replace gearbox lubrication pipes, ensuring that the front pipe is correctly positioned: on 6-speed models the front pipe must be positioned to direct oil on the clutch stop drum but on 12-speed models the front pipe must be fully inserted into front end-plate hole so that auxiliary reduction lay shaft is pressure lubricated (there is no direct feed to the 12-speed clutch stop as the auxiliary reduction unit provides adequate oil splash). (Fig. 4).




Figure 4. OIL FEED PIPE — 12-SPEED GEARBOX

- | | | |
|-----------------------|--------------------|------------------|
| A. Auxiliary layshaft | B. Front end-plate | C. Oil feed pipe |
|-----------------------|--------------------|------------------|

11. Replace gearbox cover, using new gaskets and ensuring that gear levers are correctly engaged in their selectors before cover bolts are fitted. Tighten cover-to-main-frame bolts only sufficient to hold cover down on frame then fully tighten bolts through axle case before finally fully tightening bolts into main frame.
12. Place spacing wedge in gap between gearbox and clutch cover. If wedge is not tight in gap add shims until wedge is so tight that it has to be driven in with a copper hammer, then replace and fully tighten bolts.
13. Replace steering box and column. Re-connect drag link and refill steering box with oil
If hydrostatic steering is fitted, replace steering column complete with servo valve. Re-connect pipes to valve and pump, refill reservoir with new oil.
14. Refill transmission with oil: a quick way of doing this is to pour the oil into top of PTO case. If original oil is being re-used pour it through a funnel with a fine screen filter and discard the last gallon, which will have accumulated any sediment. Top up to level mark on dipstick with new oil then replace sensing unit.
15. Replace fuel tank and re-connect fuel pipes. Refit hand throttle and attach stop control bracket. Connect engine speed indicator cable and instrument panel wiring. Re-connect battery cable.
16. Replace seat, start engine and if hydrostatic steering is fitted raise front wheels off ground, turn steering wheel from lock-to-lock several times to vent system then top-up reservoir.




Figure 6.
GEARBOX SUPPORT STAND
Made to Service drawing Misc. 1747




Figure 5.
GEARBOX SUPPORT FRAME

- A. 30 in. (762.0 mm)
- B. 15 in. (381.0 mm)
- C. 11 in. (279.4 mm)
- D. 2 in. (50.8 mm)

OPERATION K1a

Dismantling and Assembling Gearbox

The gearbox assembly is a very heavy unit and repairs will be easier if a support stand is used.

Figure 5 shows an easily-made simple frame which is adequate if gearbox repairs are not carried out very often. If a greater number of gearbox repairs are undertaken the stand shown in Figure 6, which swivels to allow the gearbox to be positioned either horizontally or vertically, will be found very useful.

1200 Gearbox (non-synchromesh)

Place gearbox on stand and fasten down with rear mounting bolts. Mark rear end-plate then remove caps and differential assembly.

Depending on the reason for dismantling gearbox, it may be useful to check layshaft and pinion shaft end-floats before dismantling further. This could possibly save time during assembly as any correction required can be made whilst gearbox is dismantled. (see page 25).

Prevent pinion shaft from turning by engaging low/slow reverse gear and placing a brass drift between the teeth of pinion and layshaft gears, then remove pinion nut — this is left-hand thread. Remove washer, bearing, distance piece and shims from pinion then withdraw pinion rearwards, leaving the two gears inside the case. On 12-speed gearboxes place slow/normal selector in 'normal' range, to minimise risk of bending selector rod, then drive locating pin out of selector fork. Push selector rod out of end-plate, taking care of detent ball and spring. Extract gear lock from end-plate hole, using a punch with a spot of thick grease on the end, or a suitable magnet.

Push range selector rod rearwards, to reduce risk of rod bending, then drive locating pin from high/low range selector jaw.




Figure 7. SIX-SPEED GEARBOX — 1200 TRACTORS

A. Top shaft
E. Front bearing
J. 1st/reverse gear

B. Range pinion
F. Rear bearing
K. 2nd/3rd gear

C. Reverse idler
G. Cover plate
L. Crown wheel

D. Pinion shaft
H. Shims
M. Differential




Figure 8. TWELVE-SPEED SYNCHROMESH GEARBOX — 1210 TRACTORS

- | | | | |
|------------------|-----------------|---------------------|-----------------|
| A. Top shaft | B. Range pinion | C. Reverse idler | D. Pinion shaft |
| E. Front bearing | F. Rear bearing | G. 1st/reverse gear | H. Second gear |
| J. Third gear | K. Synchro hub | L. Crown wheel | M. Differential |

Lever main gearbox selector into reverse and range selector into low range. Remove the four end-plate nuts and withdraw the two upper bolts. Remove bolt attaching special retaining washer on inside of top shaft rear bearing and separate the two end-plates slightly, by tapping the front end-plate a short distance forward. Remove bolts attaching rear end-plate to stand, then slide end-plate rearwards away from spacer. (Fig. 7). Clamp front end-plate to stand then turn stand so that gearbox is held in vertical position, with front end-plate downwards.

Lift spacer off end-plate, tilting it at the same time so that it clears range selector, then remove layshaft and driven gears. Push range selector rod rearwards so that top shaft can be withdrawn: front bearing will be removed with shaft. Do not remove range selector rod from end-plate unless it is to be renewed, or the detent ball and spring require inspection.

1210 Synchromesh Gearbox

Place gearbox on stand and fasten down with rear mounting bolts. Engage low/slow first gear, so that gearbox can be locked with a brass drift between teeth of auxiliary reduction unit gears, then slacken pinion shaft nut — this is left-hand thread.

Remove Mills pins from 2nd/3rd selector fork, 1st/reverse and 2nd/3rd selector jaws and high/low selector fork. Place 1st/reverse selector rod in central position then remove pins from slow/normal selector fork and high/low selector jaw.

Remove 2nd/3rd selector rod by pushing it forwards; take care of detent ball and spring, which will be released when rod uncovers end-plate hole, and place selector jaw with rod.

Remove pinion shaft nut, washer, inner race, outer stepped distance piece and shims. Unscrew spacer bar, nuts and tap the two upper bolts rearwards until they are clear of front end-plate. With high/low selector rod in neutral, push slow/normal selector rod forwards out of end-plate — taking care of detent ball, spring and gear lock — then push high/low selector rod rearwards until it is clear of its detent ball.

Hold 1st/reverse selector rod rearwards whilst carefully tapping front end-plate forward. Take care of detent ball and spring, which will be released as end-plate passes end of 1st/reverse selector rod, and remove 1st/reverse selector jaw and slow/normal selector fork when removing end-plate.

Remove retaining bolt from topshaft rear bearing: this is located on rear face of rear end-plate and when removed will allow retaining washer to drop inside gearbox. Push topshaft, complete with high/low range selector, forward and if fork fouls on case push range selector rod rearwards.

Move spacer forward until it is approximately 1 in. (25 mm) clear of rear end-plate, then pull 1st/reverse selector rod forward until layshaft can be removed. Remove the two upper spacer bolts and push spacer as far forwards as possible then slide 3rd gear off pinion and remove the six bearing pads.

Remove front dog clutch from pinion and slide synchro hub and selector fork as far forward as possible so that circlip at front of rear dog clutch can be removed. The rear dog clutch and 2nd speed gear can then be moved forward to gain access to a second circlip at rear of 2nd gear; remove this circlip from its groove then slide 1st gear forward until 1st/reverse selector rod can be removed. (Fig. 8).

Slide spacer carefully forward on its two lower studs, but before removing spacer remove the following.

- Synchro hub with selector fork.
- Rear dog clutch.
- 2nd speed gear, bearing pads and splined washer.
- Rear circlip and 1st/reverse gear.

To remove the pinion shaft, mark and remove differential bearing caps. Lift off the differential assembly then withdraw pinion shaft rearwards out of end-plate.

Dismantling Auxiliary Reduction — 12-Speed Gearboxes Only:

Return end-plate to horizontal position. Lift out range selector jaw and remove slow/normal selector fork and gear from end-plate. Remove locating pin from end-plate so that auxiliary layshaft spindle can be driven out.

After removing circlip from front end of driving gear, push the shaft rearwards — taking care that rear bearing does not foul on layshaft gear — then lift gear out of end-plate. Lift out layshaft gear and thrust washers.

Gearbox Selector Rods: These need not be removed unless they are to be renewed, or if the detent balls and springs are to be examined. To remove the rods, place one in neutral position then push other rearwards until detent ball is released. The remaining rod may then also be pushed rearwards and the gear lock and detent springs removed.

Assembling the Gearbox: This can be divided into three sections:

- Inspection of parts to determine which parts require renewing or rectification.
- Adjustment of pinion shaft position and layshaft end-float prior to assembling gearbox.
- Assembling gearbox including final adjustment of crown wheel and pinion.

(a) Inspection and Rectification

After thoroughly cleaning all parts examine the gears for chipped or worn teeth and the bearings for any signs of wear or roughness.

Renew any defective parts paying particular attention to the following:

Roller Bearings: If new tapered roller bearings are fitted it is important that the outer track supplied with the new bearing is also fitted as tracks are not interchangeable. Ensure that the new track is fully seated in the end-plate bore, otherwise it will move during service and cause excessive end-float.

Gear Teeth: These should be marked evenly along the length of the tooth. Jumping out of gear will quickly produce uneven tooth marking, due to the progressively higher loading as the teeth slide out of mesh. In some cases the very high pressure can shave metal from the tooth and cause slightly tapered teeth. It is therefore important to carefully examine the gears if jumping-out-of-gear has been experienced and if any irregular teeth markings are apparent on any gear this gear, and also its mating gear, should be renewed.



Figure 9.
SELECTOR ROD AND DETENT BALL
A. Correct B. Incorrect

Selectors: If jumping out of gear has been experienced the selector rods, detent balls, springs and spring holes should be checked.

All the selector rods have grooves with straight sides at 60° and use 3/8 in (9.5 mm) diameter detent balls and springs. Check that the balls contact the side of the groove and do not touch the bottom of the groove. If necessary, grind the groove bottom, taking care not to touch the sides, until the ball has sufficient clearance. (Fig. 9).

Check the springs and spring holes: the springs should be renewed if their free-length is less than 1 1/4 in. (31.75 mm) and the spring holes should not be deeper than 1.10 in. (27.94 mm). To measure depth of spring hole, select a short piece of rod same diameter as spring and make a sawcut 1.10 in (27.94 mm) from the end. Place rod in end-plate hole then look through selector-rod hole: if sawcut is below level of selector-rod hole the spring hole is too deep and a suitable shim should be fitted under the spring. (Fig. 10).




Figure 10.
CHECKING DEPTH OF
DETENT SPRING HOLES

- A. Test rod
- B. 1.10 in. (27.94 mm)
- C. End plate

Auxiliary Layshaft Bearings — 12 Speed Gearboxes Only: Layshaft on early gearboxes was mounted on two Torrington needle roller bearings. These were a press fit in the gear bore and a distance piece was fitted to ensure the bearings did not move out of position. Current gearboxes have two cage and roller type needle bearings which run in direct contact with both gear bore and spindle. It is advisable to fit the latest type bearings and distance piece when early type gearboxes are dismantled. (Fig. 11).

Before assembling fit both bearings and distance piece inside gear and check that overall length of bearings and distance piece is 0.010 to 0.050 in. (0.25 to 1.27 mm) less than length of gear, to ensure that bearings are not end loaded when gear is fitted in case.




Figure 11.
AUXILIARY REDUCTION UNIT
— 12-SPEED GEARBOX

- A. Front end-plate
- B. Drive gear
- C. Driven gear
- D. Gearbox mainshaft
- E. Layshaft gears
- F. Layshaft spindle




Figure 12.
TOOL FOR REPLACING TOP SHAFT BUSH

- A. 1.125 in. (28.57 mm)
- B. 1.245 in. (31.62 mm)
- C. 1 1/2 in. (38.10 mm)
- D. 3/8 in. (19.05 mm)
- E. 1/8 in. (3.17 mm)
- F. 3 in. (76.2 mm)

Input Gear Oil Seal – 12 Speed Gearboxes Only: Check condition of the heart-shaped seal inside the gear bore and renew if damaged. Oil leakage past this seal will contaminate the clutch plates.

Gearbox Tie Bars: The two lower bars are screwed (right-hand thread) into the rear end-plate and do not normally require removing. If the bars are removed, degrease threads and smear with Loctite (960998) before screwing bars into end-plate and fully tightening.

Operation of Synchromesh Mechanism: The dog clutch between second and third gears consists of two inner, fixed, members and an outer, sliding, member. The sliding member incorporates two synchronising rings – one at each side – which are attached together by three waisted pins passing through clearance holes in sliding member. (Fig. 13).

When outer member is in its central (neutral) position both second and third gears are disengaged and free to revolve independently of the pinion shaft.




Figure 13.
SYNCHROMESH MECHANISM IN NEUTRAL

- | | |
|-----------------------|------------------------------|
| A. Second gear pinion | B. Second gear clutch member |
| C. Third gear pinion | D. Third gear clutch member |
| E. Fixed members | F. Sliding member |
| G. Synchronising ring | |
| H. Waisted pin | |

When gear lever is moved to engage second gear, the outer member is moved rearwards by its selector fork, and coned faces of synchronising ring and gear member are brought into contact. As synchronising ring contacts face of gear member the ring attempts to revolve at same speed as gear and in doing so overcomes tension of centring springs and moves the three waisted pins away from centre of clearance holes in sliding member. When the pins are not in the centre of their clearance holes the sliding member cannot pass freely over the pin shoulders and further pressure applied to the gear lever results in the sliding member pressing against the shoulder corners and pushing synchronising ring harder against gear member face. (Fig. 14).




Figure 14.
SYNCHROMESH MECHANISM CHANGING
INTO SECOND GEAR
(References as in Figure 13)

When synchronising ring and gear member are pressed together hard enough for the speed of the sliding member to be synchronised with speed of gear the six springs will centralise the pins in their holes and allow member to pass over the pin shoulders. The teeth on member and gear – which are now both rotating at same speed – will then be engaged and the gear locked to the pinion shaft. (Fig. 15).

Inspection of Synchromesh Mechanism: The sliding dog clutch is rivetted together and no attempt should be made to dismantle it. The only parts that can be removed are the six centralising springs, and if any of the springs are broken or worn renew the complete set.

The synchronising rings are faced with molybdenum deposit. This has a sprayed, not smooth, finish and must be handled carefully so that it is not chipped or scratched.




Figure 15.
SYNCHROMESH MECHANISM IN SECOND GEAR
(References as in Figure 13)

(b) Adjustments Prior to Final Assembly

The pinion shaft position is adjusted by shims in front of the rear bearing and these shims can only be changed when the gearbox has been dismantled. Similarly, the layshaft end-float can only be adjusted by adding, or removing, shims after the layshaft has been completely removed. Therefore, if a new crown wheel and pinion, pinion bearings, layshaft or layshaft bearings are being fitted it is necessary to temporarily assemble part of the gearbox to make these adjustments.

Assemble end-plates and spacer; if layshaft requires adjustment remove approximately 0.008 in. (0.20 mm) of shims from behind front layshaft bearing track. Tap bearing track firmly against remaining shims then fit layshaft in position before bolting end-plates together. Tighten the four spacer stud nuts to 70 lb ft (9.7 kg metres) and ensure that all four end-plate lugs are seated on the support stand.




Figure 16.
PINION SETTING GAUGE
(Service Tool DB 8208)

- | | |
|-------------------|------------|
| A. Dummy bearings | B. Mandrel |
| C. Spacer | D. Probe |

Measure the layshaft end-float. To obtain a correct reading first spin shaft, to centralise the tapered rollers, then apply an axial load with a forward and backward rotational movement, to fully seat the bearing rollers and eliminate residual clearance.




Figure 17.
CHECKING PINION SETTING
DISTANCE

- | |
|-------------------|
| A. Rear end-plate |
| B. Pinion bearing |
| C. Probe |
| D. Measured gap |

Repeat this in the opposite direction so that an accurate reading of shaft movement is shown on a dial gauge in contact with the shaft end, then make a note of the shim thickness required to obtain an end-float of 0.002 to 0.004 in. (0.05 to 0.10 mm).

Pinion Setting: Fit pinion shaft without gears, distance piece and shims but with front bearing washer and nut. Tighten nut, whilst periodically rotating pinion, until pinion cannot be turned by hand — this will ensure that the bearings are fully seated — then unscrew nut until pinion can be turned with only a slight drag.

1. Assemble setting gauge (Service Tool DB8208) by fitting thickest (6.3125 in.) spacer on tool probe and screwing probe as far as possible into tool mandrel. (Fig. 16). Mount tool on end-plate, fitting dummy bearings in end-plate bores and bolting bearing caps in position to hold tool in place.
2. Slide mandrel to bring probe into position and unscrew probe until probe tip makes light contact with rear face of pinion bearing or, if pinion is fitted with a circular trough, the rear face of trough. Tighten locknut to prevent probe turning then recheck that it is making light contact with bearing or trough. (Fig. 17).
3. Check the correction figure etched on pinion face. If this figure is negative (—) subtract it from 0.030 in. and if it is positive (+) add it to 0.030 in. Subtract the resulting figure from the gap between spacer and mandrel — which should be measured with a feeler gauge — to obtain the thickness of shims required to set the pinion in its correct position, e.g., if pinion is marked —.007 and gap measures 0.057 in. then

$$0.030 - 0.007 = 0.023 \text{ in. and shims required are}$$

$$0.057 - 0.023 = 0.034 \text{ in.}$$
 If pinion had been marked + 0.007 then

$$0.030 + 0.007 = 0.037 \text{ in. and shims required are}$$

$$0.057 - 0.037 = 0.020 \text{ in.}$$

After rechecking the figures, make a note of the shim thickness required and remove tool from end-plate. Remove pinion and separate the two end-plates. Tap rear bearing track out of end-plate bore, fit shims of required thickness in bore, and refit track, tapping it firmly against shims and bearing plate.

If layshaft end-float requires correction, remove bearing track and fit shims previously noted, then refit bearing track. On 1200 gearboxes, the shims were first fitted inside front bearing track, but changed to behind rear bearing on later gearboxes. On 1210 gearboxes, shims should be fitted at front or rear according to dimension of shoulder at front of layshaft. (Fig. 18).




Figure 18.
LAYSHAFT — 1210 GEARBOX

When 'A' is 0.130–0.120 in. (3.30–3.05 mm) shim front bearing
When 'A' is 0.160–0.150 in. (4.05–3.80 mm) shim rear bearing

(c) Assembling Gearbox

1200 Non-Synchromesh Gearbox

Clamp front end-plate to stand, horizontally as when in tractor:

Replace first/reverse detent spring and ball in end-plate hole then hold ball against spring with a suitable tool (Fig. 19) and push selector rod into position. Hold rod against tool, so that it is partially over ball, then withdraw tool and push rod completely over ball. Place rod in neutral position then replace gear lock plunger. Push plunger against selector rod then replace second/third selector rod in same manner as previous rod.




Figure 19.
TOOL FOR COMPRESSING DETENT SPRINGS

- A. $\frac{3}{8}$ in. (9.5 mm)
- B. $\frac{5}{8}$ in. (15.9 mm)
- C. $\frac{7}{8}$ in. (4.8 mm)
- D. 6 in. (150 mm)
- E. Gear lever knob

On 12-Speed Gearboxes: Fit needle roller bearings and distance piece in auxiliary layshaft gear then place gear loosely in end-plate. Fit driving gear in position — front bearing and outer track of rear bearing should already be in end-plate — then carefully tap gear into position. Ensure that roller bearing does not foul layshaft and fit circlip in groove at front of gear. Fit thrust washers at each end of auxiliary layshaft then align gear and washers with end-plate hole and fit spindle. Align spindle with hole in case then fit locating pin.

Locate driven gear on driving gear and position selector rod, using same tool as for other selector rods. Slide range selector jaw on rod but do not fit locating pin through jaw.

Replace gear locking plunger. Push plunger down until it is against range selector rod then fit slow/normal detent ball and spring. Insert slow/normal selector rod into end-plate, using same tool to compress detent spring, and sliding rod through selector fork. Do not fit locating pin through selector fork and rod.




Figure 20.
ASSEMBLING GEARBOX

- A. Front end-plate
- B. Mainshaft
- C. Reverse idler
- D. Range pinion

Fit reverse idler gear on mainshaft and fit thrust washer, with flat face of washer towards gear. If new bearings are being fitted, press these into position on shaft.

Turn end-plate so that remainder of gearbox can be assembled vertically on top of it. Lift range selector, so that range gear on mainshaft can be engaged in fork as shaft is placed in position, then push shaft down into end-plate.

Stand layshaft in its front bearing and fit the two pinion shaft driven gears in position in their respective selector forks, positioning the gears so that shaft splines are in line. (Fig. 20). With range selector in low and main selector in reverse gear, fit spacer on front end-plate. Tilt and rotate spacer slightly and lower slowly into position so that it does not disturb the pinion shaft gears.

Lower rear end-plate on to spacer, guiding the three selector rods into end-plate holes at the same time. When main shaft rear bearing is seated in end-plate, fit special retaining washer and bolt: obtain access to washer through pinion aperture and lock bolt with tab washer after tightening to 8 lb ft (1.1 kg metres).

Lower pinion shaft into position so that it holds the two gears in their selector forks, then turn gearbox into horizontal position and clamp down with the rear mounting bolts.

Fit upper tie bars through end-plates and replace all four tie-bar nuts. Tighten nuts to 70 lb ft (9.7 kg metres) then check that both front end-plate lugs are firmly seated on the support stand: if not, slacken tie-bar nuts and tap end of bars to allow end-plate to align itself before retightening nuts.

Place the two spacers with the existing shims and an additional 0.008 in. (0.20 mm) shim between on pinion shaft, so that pinion will have a measurable amount of end-float, then replace bearing, washer and nut. Move selectors to engage LS first gear, lock gearbox by placing a brass drift between teeth of drive gear and auxiliary layshaft gear then tighten pinion nut to 200 lb ft (27.7 kg metres). (Fig. 16).

With pinion nut fully tightened measure end-float of pinion. Rotate pinion whilst applying an axial load, first in one direction and then the other, so that an accurate end-float reading is shown on a dial gauge mounted against the shaft end.

When a correct reading has been obtained remove the pinion nut, washer and bearing. Remove first spacer and remove shims equal in thickness to the total end-float reading from behind spacer, then replace spacer, bearing, washer and nut. When the pinion nut is fully tightened the pinion bearings should then have the correct setting of 0.002 in. (0.05 mm) end-float to 0.002 in. (0.05 mm) preload.

If a 12-speed gearbox, partially withdraw the slow/normal selector rod so that the locating pin can be fitted through range selector jaw and rod, taking care not to disturb the gear lock plunger. Push selector rod back into position then fit locating pin through selector fork and rod.

Lift differential assembly into position on rear end-plate; crown wheel on right-hand side. Replace bearing adjusters and caps, ensuring that marks on caps and end-plate are aligned, then adjust bearing end-float. (see page 17).




Figure 21.
FITTING LAYSHAFT

- | | |
|--------------------|--------------|
| A. Front end-plate | B. Layshaft |
| C. Selector rods | D. Mainshaft |

1210 Synchromesh Gearbox

Place the two needle roller bearings, with distance piece between them, inside auxiliary layshaft. Push layshaft spindle — plugged end rearwards — far enough into front end-plate to allow a thrust washer to locate on its end then place layshaft — largest gear at front — inside end-plate. Press spindle into gear and replace rear thrust washer before aligning holes in spindle and plate so that locating pin can be fitted.

Fit inner circlip in input gearbox and press ball bearing into bore — from front — until it is against circlip then fit outer circlip. Replace outer spacer followed by outer track of roller race — flanged side of track to front. Press inner section of roller race on to driving gear. Fit inner spacer on gear, smear seal inside gear with high-melting-point grease then pass gear through back of end-plate and into ball race. Push gear "fully home" and fit circlip at front of gear.

Fit outer track of main shaft roller bearing — flanged side of track to front — into end-plate bore until it is pressed against circlip.

Replace distance piece and pinion outer bearing track — thickest edge of track towards distance piece — and press track against distance piece and circlip. Replace main shaft rear bearing in end-plate; fit shims behind bearing and replace locating bolt and special washer when bearing is "fully home". Tighten bolt to 8 lb ft (1.1 kg metres) then lock with tabwasher.

Having previously fitted the correct thickness of shims behind outer track of pinion bearing, place pinion in end-plate and replace differential assembly. Align marks on bearing caps and fit bearing adjusters but do not lock tabwashers on cap bolts. Tap a suitable hard wood wedge between differential cage and pinion end, so that pinion is held firmly in its rear bearing.

Slide spacer on to lower studs then fit low/reverse gear on pinion — selector groove towards rear — followed by circlip and splined washer. Fit second gear — synchro face at front — on pinion. Smear six bearing pads with grease and slide these in position inside gear then replace first fixed dog clutch, ensuring that face with centre-punch mark is towards front. Slide second circlip on shaft, but not far enough to locate in its groove.

Replace sliding dog clutch assembly together with its selector fork. Observe position of centre-punch mark on first dog clutch then replace second dog clutch with its centre-punch mark at rear and opposite the mark on first clutch. Locate 1st/reverse selector fork in gear groove and selector rod in end-plate then push spacer fully rearwards, locating both circlips in pinion grooves at the same time.

Fit third gear on pinion — synchro face towards rear — smear remaining six pads with grease and slide these inside gear. Smear splined washer with grease, to hold it in position until front end-plate is fitted, then fit washer and plain distance piece.

Place layshaft, with a bearing at each end, inside spacer and enter rear bearing into its track in end-plate.

With main shaft fully assembled — reverse gear and thrust washer at rear, range pinion in centre and circlip spacer washer and roller bearing at front — fit high/low selector fork into pinion groove. Ensure that Mills pin boss is at rear of selector fork and push shaft through rear bearing then fit circlip on shaft end.

Place 1st/reverse detent spring and ball in assembled front end-plate, fit slow/normal gear — with selector fork — on top shaft then slide end-plate up to spacer. Allow selector rods to enter end-plate holes and hold 1st/reverse ball down against spring with tool shown in Figure 19 until selector rod is entered over ball. Push end-plate against spacer, guiding layshaft into its bearings at same time.

Move 1st/reverse gear selector rod into its neutral position then fit gear locking plunger in place. Fit 2nd/3rd gear detent ball and spring in end-plate hole then push rear end of selector rod into end-plate, threading selector jaw on to rod at same time and pressing detent ball against spring as previously. Hold 2nd/3rd selector fork stationary whilst pushing rod through fork and into rear end-plate. Push the two long bolts through rear end-plate, spacer and front end-plate then fit the four nuts and tighten evenly to 70 lb ft (9.7 kg metres).

Refit original shims plus an additional 0.008 in. (0.20 mm), to give pinion a measurable amount of end-float, then replace stepped spacer — step towards front — bearing, special washer and nut. Tighten nut to 200 lb ft (27.7 kg metres) then measure pinion end-float. Rotate pinion whilst applying an axial load, first in one direction and then in another, so that an accurate end-float reading is shown on a dial gauge mounted on end-plate and in contact with shaft end.

When an accurate end-float reading has been obtained, remove pinion nut, washer and bearing. Withdraw stepped spacer and remove shims equal in thickness to the end-float reading, then replace spacer — step towards front — bearing, washer and nut. Tightening the nut to 200 lb ft (27.7 kg metres) will then give the correct bearing setting of 0.002 in. (0.05 mm) end-float to 0.002 in. (0.05 mm) preload.

Push range selector rod forward through rear end-plate and into selector fork. Fit detent ball and spring in front end-plate hole, taking care they do not drop into gearbox, then push rod over ball. Ensure that slow/normal selector fork is fitted in its gear then push range selector rod through its selector jaw.

With range selector rod in its neutral position, fit range gear locking plunger and slow/normal detent spring and ball then push slow/normal selector rod through its fork and end-plate until it reaches its neutral position.

Align all selector rod holes with forks and jaws then fit new Mills pins — old pins tend to be reduced in diameter when they are driven out.

Repairs with 12-Speed Gearbox in Situ: When the clutch is removed it is possible to work on the auxiliary reduction unit and using this method can save time in the following circumstances:

- When a clutch repair is being carried out and it is found necessary to renew the drive gear, due to early type splines on clutch shaft and muff coupling being excessively worn. Later type, 16-spline, parts can then be fitted without removing gearbox.
- When a failure is found to be only associated with the auxiliary reduction section; this could occur if lubrication to gearbox had, for any reason, been interrupted. If the gearbox end-plate is not damaged, this repair can be carried out without removing the gearbox.

Dismantling Auxiliary Reduction Unit: With clutch assembly removed, slide external circlip from driving gear and internal circlip from end-plate — a pair of substantial circlip pliers will be required for this. Using a soft-faced hammer, carefully tap driving gear towards rear until it touches main driveshaft. Insert a suitable flat-ended tool, such as a small chisel or screwdriver into one of the driving gear splines so that it can be wedged tightly between ball bearing and gear. Tap gear gently forward, ensuring that ball bearing is also pushed forward at same time, and when gear is fully forward release wedge then tap gear rearward without moving ball race. Repeat this procedure until ball bearing has been pushed clear of end-plate and can be removed. (Fig. 22). Remove circlip from inside bearing bore in end-plate and remove spacer. The driving gear, complete with roller bearing, can now be pushed forward out of end-plate. If only the driving gear is being replaced no further dismantling is necessary.




Figure 22. DRIVE GEAR — 12-SPEED GEARBOX

- | | | |
|-----------------|-------------------|-------------------|
| A. Driving gear | B. Circlip (gear) | C. Outer circlip |
| D. Ball bearing | E. Inner circlip | F. Distance piece |
| | G. Roller bearing | |




Figure 23. CREEPER AND RANGE SELECTOR RODS

- | | |
|-----------------------------|-------------------------|
| A. Range selector rod | B. Range selector fork |
| C. Range selector jaw | D. Gear locking plunger |
| E. Creeper selector rod | F. Creeper selector jaw |
| G. Detent balls and springs | |

Auxiliary Reduction Unit Removal: Release pinion shaft nut: this is left-hand thread. Slide range selector into rear position and slow/normal selector rod into forward position, to reduce risk of bending rods when driving locating pins out. Remove locating pin from slow/normal selector and push selector rod forward, *taking care not to lose the detent ball and spring*. Remove ball and spring but do not attempt to remove gear locking plunger: this can be done later without danger of it falling into main section of gearbox. Place a cloth under the range selector fork: access to this can be obtained through lubrication slot in gearbox spacer. Drive locating pin out of range selector fork then retrieve pin from cloth with a small magnet. (Fig. 24).

Remove lubrication pipe from front end-plate and remove pin locating auxiliary layshaft spindle in the end-plate. Remove pinion-shaft nut, washer and bearing then replace nut, to prevent distance pieces and shims being displaced.

After removing tie-bar nuts, tap end-plate forward approximately 1 in. (2.5 mm) then very carefully remove gear-locking plunger. Place a hand between end-plate and spacer to catch plunger and prevent it falling into main section of gearbox. Remove range detent ball from spring in a similar manner.

Lift out slow/normal driven gear and selector fork.

Push auxiliary layshaft spindle forward, using a suitable bent rod inserted between end-plate and spacer, until layshaft gear can be lifted out of end-plate.

Assembling Auxiliary Reduction: Re-assemble in reverse order of dismantling, paying particular attention to the following:

- (1) Always use latest type layshaft, bearings, distance piece and thrust washers. Lubricate all parts with transmission oil during assembly.
- (2) When sliding end-plate back into position ensure that the layshaft in main section of gearbox is not trapped but rotates freely.
- (3) After tightening tie-bar nuts to 70 lb ft (9.7 kg metres) check that both end-plate lugs are seated on main frame. If not, release nuts then gently tap end of tie bars so that end-plate can align itself then retighten nuts.

- (4) Before fitting slow/normal selector rod, push range selector into rear detent position, otherwise gear-locking plunger will prevent selector rods being refitted.
- (5) After replacing driving gear engage slow, low range first gear and place a brass drift between driving gear and layshaft to lock transmission tighten pinion-shaft nut to 200lb ft (27.7 kg metres).
- (6) Ensure that lubrication pipe is correctly located in front end-plate. When re-assembly is complete, remove range gear-lever ball-housing so that lubrication supply can be observed when engine is started. (Fig. 4).

Differential assembly

The differential is mounted on the gearbox rear end-plate and permits the two rear wheels to rotate at different speeds whilst equal driving torque is being transmitted to both wheels. As differential action is essential to allow the tractor to turn from a straight course — but limits wheel grip by allowing one wheel to remain stationary when other is spinning — a lock is fitted so that the differential can be put out of action (Fig. 25).

The differential lock is controlled by a foot pedal on right-hand side of tractor and when the pedal is depressed a sleeve on spur-pinion shaft slides into engagement with differential cage and gives a solid drive to both wheels. Maximum wheel grip is thus obtained, but as both wheels can only rotate at the same speed the tractor will tend to travel in a straight line and make it impossible to turn sharply. For this reason *the differential lock must not be engaged when travelling at high speed or on the highway* as the unexpected failure of the tractor to respond to the steering could have serious consequences.

The differential-lock sleeve is spring loaded so that it returns to the disengaged position when released, but as the sleeve is most likely to be under torque — and pressure against shaft splines will prevent spring from sliding sleeve along shaft — the lock will not always disengage immediately pedal is released. If pedal therefore remains down when it is released, the lock is engaged and no attempt should be made to turn tractor sharply until pedal has sprung upwards: if necessary, momentarily depress each brake pedal in turn to release the torque and allow lock to disengage.




Figure 24. DIFFERENTIAL LOCK

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | B. Sleeve |
| C. Operating fork | D. Pedal |
| E. Return spring | F. End plate — differential cage |




Figure 25. DIFFERENTIAL ASSEMBLY

- | | | |
|------------------------|----------------|------------------|
| A. Crown wheel | B. Cage | C. End plate |
| D. Ball thrust bearing | E. Pin | F. Bevel pinions |
| | G. Bevel gears | |

OPERATION K1b

Dismantling and Assembling Differential: Mark end-plate caps so they can be refitted in same position: caps are bolted to end-plate before final machining and are not, therefore, interchangeable. Support differential whilst removing cap bolts then lift assembly from gearbox end-plate.

Lay assembly on bench, unlock tabwashers and remove bolts from cage end-plate. Mark position of cage and end-plate then tap end-plate off dowel. Remove circlips from differential pin then tap pin out of cage and remove pinions. (Fig. 26).

Crown wheel is bolted to differential cage and need not be removed unless it is to be renewed. Crown wheels and pinions are matched during manufacture and must not be interchanged. Replacement crown wheels and pinions obtained from Parts Department are wired together and care must be taken to ensure that they do not become detached during storage. If a crown wheel or pinion becomes worn it must not be renewed singly but should be replaced with a matched pair of gears.

Examine differential side bearings and renew if they show any signs of roughness. As the bearings are angular contact type they cannot be removed by holding the outer track but must be removed with an extractor, such as Service Tool 960605, which pulls against the bearing inner track. When pressing new bearings on to cage and end-plate ensure that bearings are fitted so that word 'THRUST' stamped on bearing outer track is facing away from differential and will be against bearing adjusters when fully assembled.

If a new crown wheel is being fitted first bolt this on differential cage. Ensure that wheel fits flat against cage face and tighten bolts evenly to 50 lb ft (6.90 kg metres) before locking with tabwashers.

Smear faces of bevel gears and pinions with anti-scuffing paste. Place a bevel gear inside cage and place the two pinions in position on gear. Align pinions with hole in cage and fit differential pin through cage and pinions. Locate pin in cage by fitting a circlip at each end.

Place remaining bevel gear on pinions and fit end-plate on cage. Ensure the marks made during dismantling are aligned and end-plate fits flat against cage face. Fit tabwashers so that they cover ends of dowels then replace bolts. Tighten bolts evenly to 30 lb ft (4.2 kg metres) then lock with tabwashers.

When fitting a new end-plate on cage ensure that plate is fitted so that dowels are located in the three special dowel holes. As the dowel holes are only slightly smaller than the bolt holes, to assist identification a small indentation is made adjacent to one of the dowel holes.

Lift differential assembly into position on end-plate, crown wheel on right-hand side of pinion, and replace bearing caps. Use location marks to ensure caps are fitted in their original positions and screw bearing adjusters into position before tightening cap bolts.




Figure 26
ADJUSTING DIFFERENTIAL
BEARINGS

- A. Crown wheel
- B. Bearing adjuster
- C. Screwdriver

OPERATION K1c

Adjusting Bearing End-Float: Turn left-hand adjuster fully inwards so that maximum amount of backlash is obtained between crown wheel and pinion. Tighten right-hand adjuster whilst tapping bearing caps and differential cage with a copper hammer, to ensure bearings are fully seated against adjusters, until the bearings have a slight drag. Insert a 12 in. (30 cm) plastic handled screwdriver into hole in differential cage and set crown wheel so that screwdriver is just above horizontal position. This will result in a small off-centre weight and if the left-hand adjuster is now slowly unscrewed until the off-centre weight is sufficient to move the differential assembly within the limits of the teeth backlash this will give the correct bearing setting of no preload to 0.002 in. (0.05 mm) end-float. It is very difficult to make this setting using a dial gauge, due to possible flexing of the bearing caps. (Fig. 26).

Having obtained the correct bearing settings, *clearly mark the bearing adjusters* then turn both adjusters an *equal amount* (left hand outwards and right-hand inwards) until backlash between crown wheel and pinion is 0.007 to 0.009 in. (0.18 to 0.23 mm). Check backlash at three equally spaced teeth and if readings vary slightly use the smallest reading. Mark tooth with smallest reading and take all subsequent readings from this tooth. Measure the backlash with a dial gauge mounted at right-angles to a crown-wheel tooth and when correct, tighten bearing cap bolts to 120 lb ft (16.6 kg metres). Recheck tooth backlash after tightening cap bolts, re-adjust if necessary then lock clamp bolts with tabwashers and fit bearing adjuster locking plates.

Crown Wheel and Pinion Adjustment: To obtain long life and quiet running of crown wheel and pinion it is essential that they are correctly meshed. Adjustment is therefore provided so that both crown wheel and pinion can be moved to bring the teeth into correct mesh. Pinion location is by means of shims fitted at the front of the rear bearing and any change in thickness of these shims will move the pinion nearer, or further, from the crown wheel. As it is necessary to completely strip the gearbox to change the thickness of the pinion shims the easiest method of setting the gear mesh is to set the pinion in the correct position when assembling the gearbox so that when the crown wheel backlash is set the gear mesh is correct and no further pinion adjustment is required. The method of setting the pinion in its correct position is given on Page 10, as this must be done before final assembly of gearbox. Crown wheel adjustment is by means of a ring nut against each side bearing. Screwing the ring nuts in, or out, then moves the differential cage to take the teeth in, or out, of mesh as required.

Crown Wheel Tooth Marking: If the pinion is set to its correct setting distance and the crown wheel backlash is correct it is not normally necessary to check the crown wheel marking. The only exception to this is if the new bearings are fitted to a pinion which has been in operation for a large number of hours. In this case the pinion may require a small correction to compensate for slight tooth face wear.

Checking the Tooth Marking: Lightly coat about a dozen crown-wheel teeth with marking blue, or red lead mixed with a little oil, and rotate the crown wheel backwards and forwards so that the coated teeth are rolled to and fro against the pinion: a slight pressure against the pinion will load the gears and give a clearer mark.

When sufficient rotation has been made to squeeze the marking out of the teeth and leave a bare area the exact size, shape and location of the contact, examine the contact mark on drive side of the crown wheel teeth: mark on overrun side of teeth will be correct when drive side mark is correct.




Figure 27.
HIGH TOOTH CONTACT

A. Contact adjustment
B. Backlash correction

High tooth contact (Fig. 27) indicates that pinion is too far out. Add shim behind pinion rear bearing, to move pinion inward, then adjust crown wheel away from pinion to restore correct gear backlash.




Figure 28.
LOW TOOTH CONTACT

A. Contact adjustment
B. Backlash correction

Low tooth contact (Fig. 28) indicates that pinion is set too deep. Remove shim from behind pinion rear bearing, to move pinion outward, then adjust crown wheel towards pinion to restore correct gear backlash.




Figure 29.
SHORT TOE CONTACT
A. Contact adjustment
B. Backlash correction

Short toe contact on tooth (Fig. 29) indicates that crown wheel away from pinion will increase the length of contact area and also move area towards heel of tooth. To restore correct gear backlash it is also necessary to remove shims from behind pinion rear bearing.




Figure 30.
SHORT HEEL CONTACT
A. Contact adjustment
B. Backlash correction

Short heel contact on tooth (Fig. 30) indicates that crown wheel is too far away from pinion. Adjusting crown wheel closer to pinion will increase length of contact area and move area towards toe of teeth. To maintain correct gear backlash it will also be necessary to add shims behind pinion rear bearing.




Figure 31.
SATISFACTORY TOOTH CONTACT
A. Gears unloaded
B. Gears under operating load

Satisfactory tooth contact (Fig. 31) is roughly an elongated oval shape, nearer to the toe than the heel and covering the depth of the tooth flank. When under operating load the tooth contact will then spread to almost the full length of the tooth. More than one adjustment of crown wheel and pinions may be necessary to obtain correct tooth marking, and as it is necessary to strip the gearbox to adjust the pinion bearing shims, adjusting the gears by means of the tooth marking should only be carried out if the correct pinion setting distance does not give a satisfactory tooth mark.

OPERATION K2

Removing and Replacing Gear Selector Levers: Remove bolts attaching housing to gearbox cover — three on gear lever and four on range lever — then remove housing and lever.

To remove lever from housing, unscrew lever knob and slide dirt excluder off lever then remove support plate from underside of housing (Fig. 32).

Pack inside of housing with grease before replacing gear lever and support plate. After tightening support plate bolts, securely lock with tabwasher. Fit a new gasket on housing and replace housing on gearbox cover, ensuring that lever is correctly positioned in selector jaws.

On 12-speed tractors a baulk spring is attached under the gearbox cover to hold the range lever towards the high/low range selector Jaw..

Dirt Excluders: The rubber dirt excluder fitted on each gear lever prevents dirt and water entering main frame and contaminating the transmission oil. It is, therefore, essential that excluders are maintained in good condition to prevent dirty transmission oil affecting the hydraulic system. Always examine excluders when changing transmission oil and replace excluders that are torn or do not grip the lever tight enough to make a seal.

To replace an excluder, unscrew lever knob and push spring clip upwards with a large screwdriver until it is clear of housing. Wipe lever clean and smear inside of housing with grease before fitting new excluder. As retaining clips cannot be replaced satisfactorily without a special tool, secure excluder with a suitable hose clip.




Figure 32. GEAR SELECTOR LEVERS

A. Range lever
C. Support plate
E. Gear lever

B. Housing
D. Dirt excluder
F. Housing

OPERATION K4

Removing and Replacing Reduction Unit: With tractor standing on firm and reasonably level ground, raise rear of tractor and place substantial supports under rear axle. Remove rear wheels and unscrew brake adjusting nut to end of rod, otherwise shoes may bind in drum and prevent reduction unit being removed.




Figure 33.
DIFFERENTIAL-LOCK PEDAL
LOCKED IN ENGAGED POSITION

If the right-hand reduction unit is being removed, depress differential lock pedal and wire the operating lever upwards so that differential lock sleeve is held in the engaged position. *If this is not done the sleeve will be displaced when reduction unit is withdrawn and will have to be refitted before the reduction unit can be replaced.* (Fig. 33).

Remove nuts from studs through end of axle case and disconnect stabiliser bars, if fitted. Drain oil from unit.

As the reductions are quite heavy and require to be withdrawn horizontally until spur pinion shaft is clear of oil seal in end of axle case, some method of supporting the weight is advisable. Withdraw unit until studs are clear of their holes then allow unit to turn and place a trolley jack under the case cover. Raise the jack until it just takes the weight and permits the complete assembly to be withdrawn. Hold the unit vertical whilst pulling the jack squarely away from tractor, so that pinion shaft does not jam in axle case oil seal. (Fig. 34). Before replacing a reduction unit first examine the brake shoes and axle case oil seals. Reline brake shoes if linings are excessively worn and fit new oil seals if they are damaged or leaking (see Page 23).

If the differential lock sleeve has become displaced, due to the lock not being held firmly in engaged position whilst reduction unit is removed, it will be necessary to remove the right-hand oil seal housing and replace sleeve in its correct position before reduction unit can be refitted (See Page 2).

Clean brake shoes and end of axle case. Smear inside of oil seals with grease and wipe inside of brake drum. Whilst supporting weight of unit in same manner as during removal, enter spur pinion shaft into oil seal and move unit until shaft end enters differential. It will probably be necessary to turn the wheel flange to align shaft splines with splines in differential gear: note that right-hand shaft must enter two separate sets of splines — one in sleeve and another in gear. When reduction case is entered on dowels, replace and fully tighten stud nuts. Adjust brakes and replace wheels.




Figure 34.
REMOVING A REDUCTION UNIT

OPERATION K4b

Dismantling and Assembling Reduction Unit: After draining oil from case, remove cover plate and unlock tabwasher on final driveshaft. Using a suitable 'C' spanner (Service Tool 909842) and hammer, unscrew ring nut: this is right-hand thread.

Insert a socket wrench through holes in final driveshaft flange and remove two opposite seal—housing—to—reduction case bolts.

Clean threads in final driveshaft extraction holes by screwing a 1/2 BSF tap through each hole: this is essential to prevent damage to extraction bolt threads. Fit two extraction bolts (Service Tool 900207) through holes in shaft flange and place two thrust blocks between housing and bolt ends. These blocks are necessary to prevent damage to extraction bolts or housing and dimensions of suitable blocks are shown in Figure 36.

Tighten both extractor bolts evenly — spur gear splines are smeared with Loctite on assembly and will, therefore, be initially tight — to draw shaft out of housing and bearing. Do not attempt to withdraw shaft unless the seal housing is bolted to reduction case, otherwise the housing will be distorted and cause the taper roller bearing to grip the shaft very tightly.

After withdrawing shaft, remove spur gear, tabwasher, ring nut and inner bearings from case then remove seal housing and outer bearing.




Figure 36.
DIMENSIONS OF THRUST BLOCK

- | | |
|---------------------------------|--------------------------------|
| A. $2\frac{3}{8}$ in. (65.1 mm) | B. 3 in. (76.2 mm) |
| C. $1\frac{1}{8}$ in. (33.4 mm) | D. $\frac{3}{8}$ in. (14.3 mm) |
- Drill $\frac{1}{2}$ in. (6 mm) diameter indentation $\frac{1}{8}$ in. (1.6 mm) deep at position shown




Figure 35. FINAL DRIVE REDUCTION UNIT

- | | | |
|--------------|----------------------|--------------------|
| A. Case | B. Spur pinion shaft | C. Roller bearings |
| D. Cover | E. Circlip | F. Oil seal |
| G. Spur gear | H. Final driveshaft | J. Oil seal |
| | K. Seal housing | |

Brake Drum Removal: The brake drum is a tight fit on spur pinion shaft and is provided with two 1/2 UNC extraction holes. Do not attempt to remove drum by screwing two extractor bolts through drum and tightening them against reduction case, but use Service Tool 960618, which bolts to drum and has an extraction screw bearing against end of pinion shaft.

To use Service Tool 960618 for withdrawing 1200 brake drums it is necessary to drill two 17/32 in. (13.5 mm) diameter holes at 4 1/8 in. (104.8 mm) centres through the tool flange — holes in other brake drums are at 5 1/4 in. (133.35 mm) centres — and to convert holes in annular spacer into 17/32 in. (13.5 mm) wide by 5/16 in. (7.8 mm) deep slots (Fig. 37). Tool can then

be bolted rigidly to drum with two 1/2 UNC x 2 1/2 in. bolts (600816) and extractor screw tightened to pull drum off shaft. (Fig. 38).

When removing the 3 1/2 in. (88.9 mm) wide brake drums fitted on later tractors the annular spacer cannot be used and two distance tubes and a collar to the dimensions shown in Figure 37 will be required. Fit collar on shaft then slide extractor on shaft. Bolt extractor flange to drum with two 1/2 UNC x 5 in. bolts (600822), fitting a distance tube on each bolt. Hold extractor, with bar through end, whilst tightening extractor screw and if necessary strike end of screw with a heavy hammer to start drum moving. (Fig. 38).




Figure 37.
MODIFICATIONS TO
BRAKE DRUM REMOVER

- | | |
|--|--------------------------------|
| A. Service tool 960618 | |
| B. Additional pair of 1 1/2 in. (13.5 mm) dia. holes at 4 1/8 in. (104.8 mm) centres | |
| C. Holes in distance piece converted into 1 1/2 in. (13.5 mm) wide by 5/16 in. (7.9 mm) deep slots | |
| D. 1 7/8 in. (47.6 mm) | } Collar |
| E. 3 1/2 in. (82.5 mm) | |
| F. 1 3/4 in. (44.5 mm) | } Distance tube (two required) |
| G. 3 1/2 in. (88.9 mm) | |
| H. 7/8 in. (22.2 mm) | |
| J. 9/16 in. (14.3 mm) | |




Figure 38. REMOVING BRAKE DRUM

- | | |
|-----------------------------------|---------------------------------------|
| A. Service tool 960618 | B. Brake drum 2 1/2 in. (63.5 mm) |
| C. Distance piece | D. Bolts 1/2 UNC x 3 1/2 in. (600816) |
| E. Brake drum 3 1/2 in. (88.9 mm) | F. Collar |
| G. Distance tube | H. Bolt 1/2 UNC x 5 in. (600822) |

Spur Pinion Shaft Removal: After removing brake drum, remove end cover circlip then turn case so that pinion shaft is uppermost and place suitable wooden blocks under case. Ensure blocks will not foul pinion as it is pushed from case then strike end of pinion shaft with a soft-faced hammer or wooden block. When pinion shaft has pushed cover and outer bearing from case, turn case on its side and withdraw pinion shaft.

Spur Pinion Shaft Oil Seal: This should be examined whilst pinion shaft is removed and renewed if leaking or damaged. Lever out old seal then wipe bore clean before pressing new seal into position. Use a flat plate, or large mandrel, so that seal is not distorted, and position seal so that lip is towards circlip.

Oil Seal Collar: The seal collar on pinion shaft must not be worn or damaged, otherwise seal will be unable to prevent oil leakage. To prevent oil leakage between shaft and collar an 'O' ring is fitted inside collar and before fitting a new collar ensure that a new 'O' ring is fitted in collar groove.

Replacing Spur Pinion Shaft: Smear inside of case oil seal with grease then fit pinion shaft, with roller races on shaft, through oil seal. Lay case on bench so that pinion shaft hangs vertically over bench edge then replace outer bearing track in case bore and tap track down until it is pressed firmly against rollers.

Replace original shims on bearing track then replace cover, with 'O' ring in cover groove, and circlip. Rotate shaft, to settle bearings, then press cover firmly down and measure the gap between cover and circlip with a feeler gauge. Remove circlip and fit shims of sufficient thickness to completely fill the gap on outside of cover — this is much easier than removing cover — and replace circlip. As the bearings must have no clearance but up to 0.003 in. (0.08 mm) preload there must be no gap under the circlip.

Replacing Final Driveshaft: Ensure that thrust plate and bearing track are positioned in case bore and adjusting screw is screwed outwards clear of thrust plate.

Clean inside of shaft dirt shield, pack inside of oil seal with grease then fit housing on shaft. Fit grease baffle in housing and push outer track of roller race against baffle. Replace roller race and distance piece on shaft, smear both sides of a new gasket with jointing compound then fit this on housing face. Ensure that both shaft and gear splines are clean and free from oil then apply Locquic primer before smearing splines with Loctite. Place spur gear inside case then fit shaft through case and gear, replacing tabwasher, ring nut and inner bearing on shaft at the same time. Bolt seal housing to case, ensuring that drain slot adjacent to grease nipple will be towards the bottom when unit is refitted on tractor, i.e., grease nipple will be at 7 o'clock position. After screwing ring nut onto shaft, so that it will not prevent shaft fully entering inner bearing, tighten housing bolts evenly to 50 lb ft (6.9 kg metres).

Tighten shaft ring nut: do not use a hammer and punch but use a 'C' spanner (Service Tool 909842) and heavy hammer as the nut must be very tight, otherwise gear may work loose on splines. When ring nut has been fully tightened lock it securely with tabwasher.

Driveshaft Bearing Setting: With shaft ring nut and oil seal housing bolts fully tightened, remove bearing adjuster screw and strike centre of driveshaft flange with a hammer: this will push inner bearing back and give shaft some end-float. Replace adjuster screw without shims and screw this in whilst checking shaft end-float. Continue tightening adjusting screw until shaft end-float disappears and bearings start being preloaded then measure thickness of gap under adjusting screw head with a feeler gauge. Select shims 0.006 in less than the measured thickness of gap then remove bolt and fit shims under bolt head. Fully tighten bolt before locking with wire: shaft bearings should then have 0.005 to 0.007 in (0.13 to 0.18 mm) preload.

Reduction Case Breather: As it is essential that no build up of pressure takes place inside the reduction case one of the cover bolts is drilled to act as a breather. It is therefore important that the breather bolt is not replaced by an undrilled bolt and is not allowed to become blocked. When refitting a cover plate always check that the breather bolt is clear and fitted at the top of the cover

OPERATION K4c

Rear Axle Case Oil Seals: These are fitted in the housings at each end of the axle case and to remove seals it is first necessary to withdraw housing and then remove seals from housing. (Fig. 39).




Figure 39.
REAR AXLE CASE OIL SEALS

- A. Rear axle case
- B. Oil seal housing
- C. Drain hole
- D. Oil seals

To remove housing from axle case use Service Tool 900208. This consists of a bridge piece and two 1/4 BSF x 2 in. bolts. Attach bridge piece to housing, by screwing the two bolts into housing extraction holes, and fit two extractor screws (900207) through bridge piece. Tighten extractor screws evenly to draw housing out of axle case then remove bridge piece and drive seals out of housing with a hammer and drift. When fitting new seals, first clean inside of housing then press first seal, lip towards centre of axle case, to end of housing bore. Press second seal, also with lip towards centre of axle case, into housing until seal face is level with end of housing.

Before replacing seal housing, pack cavity between seals with high-melting-point grease and smear outside of housing with jointing compound. Wipe axle case. If housing incorporates a drain hole position this towards bottom then tap housing squarely into axle case.

Final Driveshaft Oil Seal: This consists of an external dirt excluder, oil seal and internal baffle. When grease is pumped through the housing grease nipple the baffle prevents grease passing into the reduction case and causes sufficient pressure to be built up to force the grease outwards past the seal and through the dirt excluder. The appearance of grease round the shaft dirt excluder does not therefore indicate that the shaft seal is leaking but shows that the grease is performing its correct function, which is to protect the seal by periodically flushing out dirt which would otherwise eventually damage the seal and bearing. (Fig. 40).

OPERATION K5

Removing and Replacing Final Driveshaft Oil Seal: It is not necessary to remove a reduction unit to replace the oil seal. Remove wheel, drain oil from reduction and remove the case cover.

Unlock the tabwasher on final driveshaft and unscrew ring nut, using a hammer and a suitable 'C' spanner such as Service Tool 909842: nut is right-hand thread. Insert a socket wrench through holes in driveshaft flange and remove two opposite seal-housing bolts. Screw a 1/2 BSF tap through both extraction holes in driveshaft flange: this is essential to prevent damage to extraction bolt threads. Screw two extraction bolts (Service Tool 900207) through holes in shaft flange and place two thrust blocks between housing and bolt ends.

These blocks are necessary to prevent damage to extraction bolts or housing, and dimensions of suitable blocks are shown in Figure 36).

Tighten both extractor bolts evenly — spur gear splines are smeared with Loctite on assembly and will therefore be initially tight — to draw shaft out of housing. Do not attempt to withdraw shaft unless seal housing is bolted to reduction case, otherwise housing will distort under pressure and cause the tapered roller bearing to grip the shaft very tightly.

After removing shaft, remove spur gear, tabwasher, ring nut and inner bearing from case then remove seal housing. Remove oil seal from housing and, after cleaning housing, carefully press new seal into position. Do not distort seal when pressing it into housing, and position seal so that lip is towards outside of housing. (Fig. 40).

Oil Seal Collar: The seal collar on shaft must be smooth and undamaged, otherwise the seal will be unable to prevent oil leakage. To remove a worn collar, drive a thin chisel, or screwdriver, down the back of the dirt shield to move collar far enough to get a lever behind it.

Fit a new dirt shield, positioning this in collar recess and fit a new 'O' ring on shaft: this prevents oil by-passing seal and leaking along inside of collar. Press collar firmly against shaft flange so that dirt shield is gripped tight.

Clean inside of dirt shield, pack seal with grease then fit housing on shaft. Replace grease baffle in housing and push outer track of roller bearing against baffle. Replace roller race and distance piece on shaft, smear both sides of a new gasket with jointing compound then fit this on housing face.




Figure 40. FINAL DRIVESHAFT OIL SEAL

- | | | |
|----------------|---------------------------|------------------|
| A. Drive shaft | B. Dirt shield | C. Shaft collar |
| D. Oil seal | E. Housing | F. Grease baffle |
| | G. Tapered roller bearing | |

Ensure that both shaft and gear splines are clean and free from oil then apply Locquic primer before smearing splines with Loctite (Grade AV). Place spur gear inside case then fit shaft through case and gear, replacing tabwasher, ring nut and inner bearing on shaft at same time. Bolt seal-housing to case, ensuring that drain slot adjacent to grease nipple is at the bottom, *i.e.*, grease nipple at 7 o'clock position. After screwing ring nut on to shaft, so that it will not prevent shaft fully entering inner bearing, tighten housing bolts to 50 lb ft (6.9 kg metres).

Tighten shaft ring nut. Do not use a hammer and punch, but use a 'C' spanner (Service Tool 909842) and heavy hammer as the nut must be very tight, otherwise gear may work loose on splines.

Driveshaft Bearing Setting: With shaft ring nut and seal housing bolts fully tightened, remove bearing adjuster screw and strike end of driveshaft with a hammer: this will push inner bearing back so that shaft will have end-float. Replace adjuster screw without shims and screw this in whilst checking shaft end-float. Continue tightening adjuster screw until shaft end-float disappears then check thickness of gap under bolt head with a feeler gauge. Select shims 0.006 in. (0.15 mm) less than the measured gap, then remove bolt and fit the shims under bolt head. Replace and fully tighten

bolt before locking with wire: shaft bearings will then have 0.005 to 0.007 in. (0.13 to 0.18 mm) preload.

Reduction Case Breather: As it is essential that no build up of pressure takes place inside the reduction unit one of the cover bolts is drilled so that it acts as a breather. It is therefore important that the breather bolt is not replaced by an undrilled bolt and is not allowed to become blocked. When refitting a cover plate, always check that breather bolt is clear and fitted at the top of the cover.

OPERATION K7

Removing and Replacing Differential Lock Pedal: Remove bolts attaching right-hand footplate to main frame and fender, then push footplate down so that it pivots on brake cross shaft and allows rear of plate to clear pedal pivot.

Remove spring pin from pedal pivot then slide pedal sideways. Pivot pin is screwed into main frame and can be removed if required.

Ensure that pivot pin is screwed tightly into frame then smear pin with grease before replacing pedal. Replace spring pin then lift footplate into position and replace bolts.

DIMENSIONAL DATA

Muff coupling end-float	0.008 – 0.040 in (0.20 – 1.02 mm)
Pinion shaft bearing setting	0.002 in (0.05 mm) end-float to
	0.002 in (0.05 mm) preload
Layshaft end-float	0.002 – 0.004 in (0.05 – 0.10 mm)
Auxiliary layshaft bearing distance piece	0.010 – 0.050 in (0.25 – 1.27 mm)
end-float between roller bearings	0.000 – 0.002 in (0.00 – 0.05 mm)
Differential side bearing end-float	0.007 – 0.009 in (0.18 – 0.23 mm)
Crown wheel and pinion tooth backlash	0.016 – 0.021 in (0.41 – 0.53 mm)
Gearbox mounting clearance: vertical	0.008 – 0.012 in (0.20 – 0.30 mm)
Gearbox mounting clearance: horizontal	0.001 – 0.003 in (0.02 – 0.08 mm)
Spur pinion shaft bearing pre-load	0.005 – 0.007 in (0.13 – 0.18 mm)
Final driveshaft bearing pre-load	

TIGHTENING TORQUES

	lb ft	kg m
Reduction case cover bolts	25	3.5
Reduction oil seal housing bolts	50	6.9
Reduction units to rear axle case bolts		
tractor 700001 to 700346	75	10.5
tractor 700347 to 703004	100	13
tractor 703005 onward	75	10.5
Final driveshaft ring nut	150	21
Gear lever housing bolts	9	1.3
Pinion shaft nut	200	28
Differential bearing cap bolts	120	16.5
Spacer stud nuts	70	9.7
Crown wheel bolt nuts	50	6.9
Adjusting nut lock plate bolts	20	2.8
Top shaft bearing retaining bolt	8	1.1
Differential cage cover bolts	30	4.2
Rear wheel hub nuts		
$\frac{5}{8}$ in (15.9mm) diameter	114	15.7
$\frac{3}{4}$ in (19mm) diameter	140	19.2

SUMMARY OF DESIGN CHANGES

Details of Change	When introduced
Material of reduction units to rear axle case bolts changed so that tightening torque of bolts can be increased from 75 to 100 lb ft (10.5 to 13.8 metres). Part number of bolts changed from 600803 to 600881	1200/700347-703004 (October 1967)
Wheel bolts in final driveshafts increased in length to 2½ in. to allow fitting of power-adjusted rear wheels. Part number of bolts changed from 611266/7 to 611271.	1200/700807 (April 1967)
Profile of detent ball groove in range selector rod (917733) changed from 90° to 60° included angle.	1200/700945 (April 1967)
Width of brake shoes increased from 2½ to 3½ in. (63.5 to 88.9 mm). Adaptor plate fitted between axle case and reduction unit and spur-pinion shafts increased in length.	1200/703005 (October 1967)
Oil capacity of transmission increased from 8 to 9 gallons (36.4 to 41.0 litres) by changing dipstick sleeve from 83884 (¾ in.) to 923725 (1¼ in.).	1200/705026 (February 1968)
Oil seal collar (910390) sealed to spur pinion shaft by fitting 'O' ring (15533) in groove on inside of collar.	1200/705386 (February 1968)
Bearings in auxiliary layshaft of 12-speed gearbox changed so that needle rollers run directly against gear and spindle. Part number of layshaft gear changed from 923796 to 924493. The later parts K924493, K620273, K924495 and K626714 should be used.	1200/706767 (October 1968)
Splines in muff coupling changed from six splines with straight sides to 16 splines with involute sides, with corresponding change to splines on clutch and gearbox driveshafts.	1200/708742 (May 1969)
Sealing washers (14582) fitted on gearbox cover to main frame bolts, in place of plain steel washers (15735), used previously.	1200/711300 (December 1969)
Plain bush (621244) in differential pinion changed to shouldered bush (928899). Part number of pinion changed from 910465 to 928900.	1200/15045 (November 1970)
Diameter of differential pin (942038) increased from 1 in. (25.4 mm) to 1½ in. (28.57 mm). Part number of differential cage changed from 908780 to 942316. New bevel pinions (942317) and circlips (12207) must also be used with the larger diameter pin.	1200/717761 (November 1971)
Auxiliary layshaft bearings of a different length fitted to a number of 1210 tractors. These bearings, which are 1¼ in. (31.75 mm) long and require a 1.425 in. (36.19 mm) spacer, will not be supplied as replacements and must, therefore, be replaced with 620273 bearings and 924495 spacer.	1210/721179 to 721263 (September 1972)
Shimming of gearbox layshaft moved from front end plate to rear end plate and shim qty reduced. When layshaft front shoulder is 3.20 mm (0.125 in.) shim at front. When front shoulder is 3.90 mm (0.153 in.) shim at rear.	1210 (April 1973)
Oil seal added to final drive shaft between outer bearing and spur gear. Seal lip faces spur gear to retain oil in reservoir. Outer bearing now lubricated with grease. Grease nipple in flange now accessible from rear. Pack bearing with grease on assembly and apply 2 shots from grease gun every 60 hours.	1210-721832 (July 1973)
Five internal serrations added to gear lever dirt excluder K929631 to improve retention and seal.	1210-724406 (February 1974)
A circular trough K945133 was used between pinion and rear pinion bearing on some tractors. This should be discarded at overhaul and shims K910454/5/6/7 added behind bearing cup to an approx. additional thickness of 0.90 mm (0.035 in.). Finally set pinion depth with tool DB 8208.	1210 (1973/4)
Diameter of special bolts attaching final drive hub to wheel centre increased in diameter from ⅝ in. to ¾ in. and holes in wheel centre increased from 19 to 25.4 mm (0.75 to 1.0 in.). Special wheel nuts K617210 available to fit latest wheel centres to earlier ⅝ in. bolts. Wheel nut brace K946622 and tommy bar K948095 fits ⅝ in. and ¾ in. nuts. Final drive ratios standardised at 10/49.	1210-725180 (April 1974)

Method of retention at rear of synchromesh unit changed from circlip to split rings and special recessed washer to provide more positive location.
Prior to this the first gear front hub was temporarily recessed and a wider circlip (and groove) K12300 used in place of K621865.

Split rings 1210-729430
(August 1975)

If the later specification is required in service proceed as follows:

Grind front face of 1st gear hub K942461 across full width to reduce overall length of hub to 40.5 mm (1.59 in.).

Extend the circlip groove (at rear of synchromesh unit) to the following dimensions:

Distance of front face of groove to front shoulder of shaft (threaded end) = 140.77 mm (5.542 in.).

Distance of rear face of groove to front shoulder of shaft (threaded end) = 145.57 mm (5.732 in.).

i.e. width of groove = 4.80 mm (0.189 in.).

Shaft dia at bottom of groove = 45.90 mm (1.807 in.).

Use two split rings K945962 and one recessed washer K948670 to replace circlip K12300 or K621865 and washer K940975.

Wider circlip
1210-723883

Recessed gear
1210-722949

Other David Brown publications on transmissions are available through your DB Dealer or from Publications section, David Brown Tractors Ltd., Meltham, Huddersfield, England HD7 3AR.

Service Repair Manual Section C1 Transmission, Non-synchromesh, not 1200	9-38115
Service Repair Manual, section C2, 4 WD Transmission and Front axle Mk I (Selene)	9-38116
Service Repair Manual, section C3, Transmission Non-synchromesh, not 1210 or 1410	9-37141
● Up-dated pages 19/20	9-38159
Service Repair Manual, section C5, Transmission Hydra-shift	9-37161
● Up-dated pages 25/28a	9-38156
● Up-dated pages 33/34	9-38161
Service Repair Manual, section C6, 4WD Transmission and Front Axle Mk I (Kramer)	9-37171
Service Repair Manual, section C7, 4WD Transmission and Front Axle Mk II	9-37172
1412 tractors—included in the Preliminary Service Information section	9-38121
Instructional drawings, Synchromesh Transmission (with booklet)	9-38501
● Instructional drawing, Synchromesh gearbox	9-38601

David Brown policy is one of continuous development and improvement, and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

TRANSMISSION - 1200 & 1210 TRACTOR



David Brown®

Service Repair Manual

HYDRA-SHIFT TRANSMISSION

1212 and 1412 Tractors

Section C5 (Pub. 9-37162) MAY 1979

Written In *Clear
And
Simple
English*

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



"David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.


Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual can give details of items which are not part of any specific tractor."

©Published by David Brown Tractors Ltd.

Printed in England by Waddington & Ledger Ltd., Dewsbury

SECTION	DETAILS	PAGE
Special Tools		2
Description		
Four-speed section		4
Operation		4
Range section		4
Regular Maintenance		
Cleaning the transmission filter		9
Maintenance and Repair		
Assembly of the gearbox		23
Disassembly of the four-speed units		19
Disassembly of the gearbox		16
Disassembly of the transmission oil pump		21
Removing the gearbox—method A		10
Removing the gearbox—method B		14
Removing the transmission oil pump		19
Sequence valve adjustment		22
Spool valve		20
Support sleeve seating rings		22
Fault Finding		
Brake band adjustment		33
Fault finding charts		35
Gear selection defects		31
Normal gear changes—down		31
Normal gear changes—up		31
Overlap		31
Procedure for checking the gear changes		31
Procedure for checking the transmission oil pressure		32
Underlap		31
Sequence valve adjustment—in tractor		31
Specification and Data		
Data		39
Specifications		38


SPECIAL TOOLS



R78-192

FIGURE 1 GEARBOX SUPPORT STAND


Make this stand from the measurements given on drawing No. MISC 1747. You can get this drawing from David Brown Tractors Service Department.



R77-120

FIGURE 2 TOOL FOR INSTALLING DIFFERENTIAL LOCK SLEEVE


- | | |
|---------------------|---------------------|
| A. 609.6 mm (24 in) | E. 38 mm (1½ in) |
| B. 228.6 mm (9 in) | F. 25.4 mm (1 in) |
| C. 101.6 mm (4 in) | G. Hose clip |
| D. 304.8 mm (12 in) | H. 103.2 mm (4¼ in) |



R78-193

FIGURE 3 TOOL FOR LIFTING THE GEARBOX


- | | |
|-------------------|------------------------|
| A. 203 mm (8 in) | D. 622 mm (24½ in) |
| B. ½ UNC × 7½ in | E. 229 mm (9 in) |
| C. 165 mm (6½ in) | F. 14.5 mm (⅝ in) dia. |
| | G. 83 mm (3½ in) |



R77-119

FIGURE 4 PINION SETTING GAUGE (SERVICE TOOL DB8208)

- | | |
|-------------------|-----------|
| A. Dummy bearings | C. Spacer |
| B. Mandrel | D. Probe |



R79 104

FIGURE 5 TOOL FOR LOCATING THE GEARBOX TO THE REAR AXLE

- A. 75 mm (3 in)
- B. 50 mm (2 in)
- C. 10 mm ($\frac{3}{8}$ in)
- D. 400 mm ± 1 mm ($15\frac{1}{2}$ in ± 0.040 in)
- E. 25 mm (1 in)
- F. 25 mm (1 in)
- G. 324 mm ($12\frac{3}{4}$ in)
- H. 25 mm (1 in)
- J. 105 mm ($4\frac{1}{8}$ in)
- K. 190.5 mm ± 0.25 mm ($7\frac{1}{2}$ in ± 0.010 in)
- L. 16.5 mm dia. ($\frac{5}{8}$ in dia.)
- M. 41 mm ($1\frac{5}{8}$ in)
- N. 19 mm radius ($\frac{3}{4}$ in radius)
- P. 127 mm (5 in)
- R. 146 mm ($5\frac{3}{4}$ in)
- S. 22 mm ($\frac{7}{8}$ in)
- T. Nut, $\frac{5}{8}$ -11 UNC (Qty. 2)
- U. Bolt, $\frac{5}{8}$ -11 UNC $\times 2\frac{1}{2}$ (Qty. 2)

Make from 30 ton grade weldable structural steel, 75 mm \times 50 mm \times 10 mm or equivalent. Dimensions 'S' and 'N' can be flame cut.



FIGURE 7 TOOL FOR LIFTING THE GEARBOX REAR UNIT

Material. 260 mm (18 in) long (minimum),
19 mm ($\frac{3}{4}$ in) wide
4.8 mm ($\frac{3}{16}$ in) thick

- A. 178 mm (7 in)
- B. 50 mm (2 in)
- C. 178 mm (7 in)
- X. 12.7 mm ($\frac{1}{2}$ in)

FIGURE 6 TOOL FOR COMPRESSING DETENT SPRINGS

- A. 9.5 mm ($\frac{3}{8}$ in)
- B. 15.8 mm ($\frac{5}{8}$ in)
- C. 4.8 mm ($\frac{3}{16}$ in)
- D. 150 mm (6 in)
- E. Gear lever knob



R78 196

The gearbox has two sections, a four speed section and a range section.

Four Speed Section

This is a semi-automatic planetary section at the input end of the gearbox. It is hydraulically controlled. Speeds are selected by moving the Hydra-Shift lever, 'A' Figure 9, without using the transmission clutch. This does not stop power to the drive wheels.

Range Section

This is a constant mesh range gear section. It has three forward ranges and one reverse range:

1. Creep range
2. Field range
3. Road range

The range gears are selected by moving the range lever, 'B' figure 9. The clutch pedal must be used.

Operation

NOTE: The direction of rotation used in this manual is that seen when looking at the rear of the gearbox.

The four speed section includes two planetary gear units (each one having two speeds), a hydraulic pump and control valves. Each planetary gear unit has a hydraulically operated multi-plate lock-up clutch, a free wheel mechanism and a hand brake.

The planetary gear units are of similar construction but have different ratios. When oil pressure is released from the unit, the carrier is held stationary by the free wheel mechanism and the brake band, see figure 10. When load is applied to the unit the carrier tries to turn in a counter clockwise direction. This is prevented by the free wheel mechanism. When the tractor is in the engine braking (overrun) condition, the carrier tries to




FIGURE 9 TRANSMISSION CONTROLS

- | | |
|----------------------|----------------------------|
| A. Hydra-Shift lever | B. Range lever |
| C. Clutch pedal | D. Differential lock pedal |




FIGURE 8 TRANSMISSION UNIT

- | | |
|-----------------------|-------------------------|
| A. Four speed section | B. Planetary gear units |
| C. Spool valve | D. Sequence valve |
| E. Oil pump | F. Range gear section |
| | G. Differential unit |




FIGURE 10. PLANETARY UNIT IN REDUCTION

- | | |
|------------------------------|--------------------------------|
| A. Lock up clutch disengaged | B. Brake band on |
| C. Carrier stationary | D. Free wheel mechanism—locked |
| E. Input shaft | |
| F. Output shaft | |

turn in a clockwise direction. This is prevented by the brake band. When the input shaft is turning, the planet pinions turn on their own spindles and the gears operate as a reduction unit, turning the output shaft at a decreased speed.

When oil pressure is applied, the brake band is released. Then the multi-plate clutch is engaged and holds the carrier to the input shaft, see figure 11. The input shaft, carrier and output shaft turn together, the input speed is not decreased.

The planetary gear unit gives a low ratio when oil pressure is released. It gives direct drive when oil pressure is applied. Because the change in output speed is made by engaging or disengaging the friction clutch, it can be done when the tractor is moving and when load is applied to the gearbox.

A single unit will only give two speeds. To get four speeds, two units of different ratios are installed in series. The front unit has a reduction ratio of 1.37:1. The rear unit has a reduction ratio of 1.82:1. In first gear, see figure 12, oil pressure is released from both units. The carriers are held stationary and the units work in reduction. The output shaft of the rear unit is driven through a reduction ratio of $1.37 \times 1.82 = 2.49:1$.

In second gear, see figure 13, oil pressure is applied to the front unit only. The front unit works in direct drive, the rear unit works in reduction. The output shaft of the rear unit is driven through a reduction ratio of $1 \times 1.82 = 1.82:1$.




FIGURE 11 PLANETARY UNIT IN DIRECT DRIVE

- | | |
|----------------------------|-------------------------------------|
| A. Lock-up clutch: engaged | D. Free-wheel mechanism: disengaged |
| B. Band brake: released | E. Input shaft |
| C. Carrier: revolving | F. Output shaft |




FIGURE 12. PLANETARY UNITS IN FIRST GEAR

Front unit in reduction – Rear unit in reduction

- | | |
|----------------------------------|----------------------------------|
| A. Lock-up clutch: disengaged | E. Lock-up clutch: disengaged |
| B. Band brake: applied by spring | F. Band brake: applied by spring |
| C. Carrier: stationary | G. Carrier: stationary |
| D. Free-wheel mechanism: locked | H. Free-wheel mechanism: locked |
| J. Input shaft | K. Output shaft |




FIGURE 13 PLANETARY UNITS IN SECOND GEAR

Front unit in direct drive – Rear unit in reduction

- | | |
|-----------------------------------|----------------------------------|
| A. Lock-up clutch: engaged | E. Lock-up clutch: disengaged |
| B. Band brake: released | F. Band brake: applied by spring |
| C. Carrier: revolving | G. Carrier: stationary |
| D. Free-wheel mechanism: released | H. Free-wheel mechanism: locked |
| J. Input shaft | K. Output shaft |

In third gear, see figure 14, oil pressure is applied to the rear unit only. The front unit works in reduction, the rear unit works in direct drive. The output shaft of the rear unit is driven through a reduction ratio of $1 \times 1.37 = 1.37:1$.

In fourth gear, see figure 15, oil pressure is applied to both units. Both units work in direct drive. The output shaft of the rear unit is driven at engine speed.

Gear selection in the four speed section is made by controlling the flow of oil to the planetary gear units. This is done by the hydraulic system, see figure 16.

The oil pump takes oil from the transmission case to the spool valve at the top of the gearbox. The valve spool is connected to the Hydra-Shift lever. When the lever is moved the spool controls the flow of oil to the correct clutch and brake cylinders.

When oil pressure is applied the clutch cylinder rotates with the carrier. The oil flows through a rotating joint in each planetary unit. Oil is prevented from leaking at the rotating joint by piston ring type seals, see figure 17.




FIGURE 14 PLANETARY UNITS IN THIRD GEAR

Front unit in reduction - Rear unit in direct drive
 A. Lock-up clutch: disengaged E. Lock-up clutch: engaged
 B. Band brake: applied by spring F. Band brake: released
 C. Carrier: stationary G. Carrier: revolving
 D. Free-wheel mechanism: locked H. Free-wheel mechanism: disengaged
 J. Input shaft
 K. Output shaft




FIGURE 15 PLANETARY UNITS IN FOURTH GEAR

Front unit in direct drive - Rear unit in direct drive
 A. Lock-up clutch: engaged E. Lock-up clutch: engaged
 B. Band brake: released F. Band brake: released
 C. Carrier: revolving G. Carrier: revolving
 D. Free-wheel mechanism: disengaged H. Free-wheel mechanism: disengaged
 J. Input shaft
 K. Output shaft




FIGURE 16 COMPONENTS OF THE HYDRAULIC SYSTEM

A. Low pressure oil pump D. Clutch cylinder (the rear clutch cylinder is not shown)
 B. Four-position spool valve with integral relief valve E. Brake cylinders
 C. Sequence timing valves




FIGURE 17 CLUTCH CYLINDER OIL SEALS

A. Planet carrier
 B. Clutch piston
 C. Sealing rings
 D. Oil connection
 E. Casing web

A sequence timing valve is installed in each clutch oil feed pipe. This makes sure that:

- When a higher gear is selected the brake band is released before the clutch is engaged.
- When a lower gear is selected the clutch is released before the brake band is engaged.
- When working together, the clutch which is being engaged, is engaged before the other clutch is released.

The sequence timing valve is a spring loaded piston valve with a control orifice in the piston head. See figures 18 to 21.

The spool valve directs oil to a planetary unit. Oil pressure is held back from the clutch cylinder by the sequence valve. This permits oil pressure to generate at the brake cylinder and releases the brake band. The oil pressure is then strong enough to open the sequence valve. Oil then moves through the rotating joint and moves the clutch piston. This happens in a very short time. When the clutch piston has moved approximately half the length of its stroke, buffer springs (see 'J' figure 37) on the piston face start to engage the clutch. Extra pressure is needed to push the clutch piston against the springs. This pushes the brake piston fully against the brake spring. See figures 18 to 21.

When a planetary unit moves from direct drive into reduction, the spool valve stops the flow of oil to the clutch and brake cylinders. The oil in the brake cylinder starts to flow through the control orifice in the sequence valve piston. Restrictors at the spool valve end of the




FIGURE 18 HYDRAULIC SYSTEM IN FIRST GEAR

- | | | | |
|--------------------------------|-----------------------------|--------------------------------|----------------------------|
| A. Clutch: <i>disengaged</i> | } Front Plan-
etary Unit | D. Clutch: <i>disengaged</i> | } Rear Plane-
tary Unit |
| B. Sequence valve: <i>open</i> | | E. Sequence valve: <i>open</i> | |
| C. Band brake: <i>applied</i> | | F. Band brake: <i>applied</i> | |
| G. Spool valve | | | |
| H. Relief valve | | | |
| J. Oil pump | | | |




FIGURE 19 HYDRAULIC SYSTEM IN SECOND GEAR

- | | | | |
|----------------------------------|--------------------------------|--------------------------------|-------------------------------|
| A. <i>Clutch: engaged</i> | } <i>Front Plan-etary Unit</i> | D. <i>Clutch: disengaged</i> | } <i>Rear Plan-etary Unit</i> |
| B. <i>Sequence valve: closed</i> | | E. <i>Sequence valve: open</i> | |
| C. <i>Band brake: released</i> | | F. <i>Band brake: applied</i> | |
| G. <i>Spool valve</i> | | | |
| H. <i>Relief valve</i> | | | |
| J. <i>Oil pump</i> | | | |

brake cylinder pipes control the oil flow from the brake cylinders. As the oil in the brake cylinders is decreased, the decreasing pressure of the brake spring causes a lower pressure at the sequence valve. During this sequence the oil pressure in the clutch cylinder is decreased, but not enough to stop the drive from the gearbox.

When the brake piston has reached approximately half the length of its stroke (as the clutch in the other unit starts to engage) oil pressure is decreased at the sequence valve. This permits the valve to move and release the clutch cylinder oil through the sequence valve piston and disengages the clutch. The brake cylinder continues to empty through the sequence valve piston control orifice. When the brake piston has reached its full stroke all the brake spring pressure is applied to the brake band, see figure 18.

When a load is applied to the gearbox and the clutch is disengaged, the carrier will try to turn in a counter-clockwise direction. This is prevented by the free wheel mechanism. When a lower gear is selected with load applied to the gearbox, the unit will automatically move into the reduction ratio before the brake band is applied. In the engine braking (overrun) condition, the output torque is reversed and the brake band will prevent the tractor from free wheeling.

The relief pressure valve is installed in the control valve body. This keeps a pressure of 4.99 to 5.2 Kg/cm² (71 to 75 lbs/in²) in the system. Oil released by the relief valve flows through pipes to the centre of each planetary unit to give lubrication to the units and to keep the clutch plates cool.




FIGURE 20 HYDRAULIC SYSTEM IN THIRD GEAR

- | | | | |
|-------------------------|----------------------|---------------------------|---------------------|
| A. Clutch: released | Front Planetary Unit | D. Clutch: engaged | Rear Planetary Unit |
| B. Sequence valve: open | | E. Sequence valve: closed | |
| C. Band brake: applied | | F. Band brake: released | |
| G. Spool valve | | | |
| H. Relief valve | | | |
| J. Oil pump | | | |




FIGURE 21 HYDRAULIC SYSTEM IN FOURTH GEAR

- | | | | |
|---------------------------|----------------------|---------------------------|---------------------|
| A. Clutch: engaged | Front Planetary Unit | D. Clutch: engaged | Rear Planetary Unit |
| B. Sequence valve: closed | | E. Sequence valve: closed | |
| C. Band brake: released | | F. Band brake: released | |
| G. Spool valve | | | |
| H. Relief valve | | | |
| J. Oil pump | | | |

Clean the transmission filter after the first 50 hours and then every 500 hours. You must also clean it when the Selectamatic hydraulic filter is replaced. Change the oil every 1000 hours.

Cleaning the Transmission Filter

Figure 22

1. Remove the plug 'C' from the filter housing and remove the oil. Destroy the last 4.5 litres (1 gallon).
2. Remove the plug 'B'. This is connected to the transmission pump inlet pipe and filter.
3. Wash the filter in clean fuel.
4. Remove the fuel with air pressure.
5. Install the plugs 'B' and 'C'.
6. Use the old oil to fill the system.
7. Add new oil of the correct grade until it is at the correct level.
8. Run the engine at the minimum idle speed for 30 seconds with the hydraulic control lever in the 'lower' position. Air will then be removed from the system.

At 500 hours and then every 1000 hours, make sure that the relief valve is working at the correct pressure. See page 33.




FIGURE 22 OIL PUMP FILTER

- | | |
|--|------------------------|
| A. Selectamatic system
full-flow filter housing | B. Transmission filter |
| | C. Drainplug |




FIGURE 23 GEARBOX WITH COVER REMOVED

- | | |
|---------------------------------|------------------------------|
| A. Spool valve | D. Pipes to brake cylinders |
| B. Front clutch pipe connection | E. Front brake band adjuster |
| C. Rear clutch pipe connection | F. Rear brake band adjuster |

REMOVING AND INSTALLING THE GEARBOX

You must split the tractor to remove the gearbox.

To remove the range section of the gearbox and to repair the crown wheel and pinion, use method A.

To remove and repair the four-speed section of the gearbox and to repair the range section (except the crown wheel and pinion), use method B.

Method A—Removing the Gearbox

1. On Q-cab tractors, remove the cab.
2. Clean the outside of the clutch housing, gearbox top, main frame and rear axle.
3. Put the tractor on hard, level ground.
4. Remove the oil from the transmission casing and the reduction units. Keep the oil in a clean, covered container. The container must have a minimum capacity of 40 litres (9 gallons).
5. Remove the transmission oil filter.
6. Disconnect the battery cable and remove the starter motor.
7. Put wooden wedges between the front axle and front frame to prevent movement.
8. Use a 5-ton jack to raise the back of the tractor. Put supports below the rear end of the main frame.
9. Remove the rear wheels.
10. Lower the tractor on to the supports.
11. Remove both reduction units.
12. Remove the oil seal housing from the right hand side of the axle casing using the extractor K900208. See figure 24.

Put your hand into the axle casing and pull the differential locking sleeve and spring away from the differential. See figure 25.

NOTE: If the differential locking sleeve and spring do not move easily, get assistance to move the differential lock pedal up and down. Continue




FIGURE 24 REMOVING THE OIL SEAL HOUSING

- | | |
|---------------------|----------------------------|
| A. Oil seal housing | C. Bolts into seal housing |
| B. Bridge piece | D. Extraction bolts |




FIGURE 25 DIFFERENTIAL LOCK

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | D. Pedal |
| B. Sleeve | E. Return spring |
| C. Operating fork | F. End plate – differential cage |

- pulling until locking sleeve and spring are away from the differential. It is not necessary to remove the locking sleeve and spring from the axle casing.
13. Remove the silencer and the bonnet.
 14. On models without 'Q'-cab:
Disconnect the Hydra-Shift lever linkage at the spool valve.
Remove the fuel tank and the instrument panel.
Disconnect the steering pipes from the Orbitrol valve, install plugs or caps on open pipe ends. See figure 26.
Remove the steering column together with the steering wheel and Orbitrol valve.
 15. Push the spool valve down fully.
 16. Remove the clutch housing and the gearbox cover.
 17. Remove the PTO unit, then pull out the cardan shaft from the gearbox.
 18. Remove the high pressure hydraulic pipe.
 19. Use a crane or a jack to support the weight of the rear axle case, then remove the bolts which fasten the axle case to the main frame.
 20. Pull the axle case from the dowels on the main frame, then move it clear of the tractor.
 21. Remove the two gearbox mounting bolts then install the lifting bracket. See figure 3, page 2.
 22. Use a crane to hold the gearbox. Pull the gearbox backwards until it is clear of the clutch, then lift it from the tractor.




FIGURE 26 REMOVING THE STEERING COLUMN

- | | |
|-------------------------|---------------------|
| A. Steering pipes | C. Throttle linkage |
| B. Orbitrol valve bolts | D. Steering column |

Method A—Installing the Gearbox

1. Clean the inside of the main frame.
2. Make sure that the transmission clutch release bearing sleeve is correctly engaged in the fork. See figure 27.
3. Slide the gearbox into position. Make sure that the clutch bearing sleeve slides on the support snout. Make sure that the 'O'-rings at the front end of the gearbox are not damaged.




FIGURE 27 CLUTCH RELEASE MECHANISM

- | | |
|---------------------|--------------------|
| Transmission Clutch | PTO Clutch |
| A. Cross shaft | D. Cross shaft |
| B. Fork | E. Fork |
| C. Sleeve | F. Bearing carrier |

NOTE: It is easier to push the gearbox into position if you engage high range and turn the crown wheel while pushing the gearbox, or if you turn any of the planetary pinions.

4. Install the two bushes (part number K920656) into the mounting bolt holes at the rear of the range gearbox. See figure 28.
5. Move the gearbox until the bushes fall into the main frame bolt holes.
6. Install the two mounting bolts and tighten them to 136 Nm.
7. Use a feeler gauge to check the clearance between the bolt heads and the top face of the gearbox lug. This must be between 0.40 and 0.53 mm.
8. Install a new full-flow filter element in the Selectamatic system. Wash the two filter screens in clean fuel. Assemble the filter and install the cover plate.
9. Clean the main frame and the rear axle frame faces. Put jointing compound on the face of the axle frame.
10. Install a new gasket then install the axle case onto the dowels.
11. Install the bolts and tighten them to 100 Nm.
12. Install the cardan shaft. Make sure that the oil seal inside the gearbox is not damaged.
13. Install the PTO unit.
14. Install the differential locking sleeve using the tool shown in figure 2, page 2. See figure 25. Install the spring in the end plate. Put the locking sleeve on the tool with the splines away from the handle of the tool. Using the tool, put the locking sleeve into the axle casing. Push the tool toward the differential until the groove of the locking sleeve is behind the inner gusset of the casing.




FIGURE 28 GEARBOX MOUNTING

- A. Mounting bolt
B. Bush
C. Range gearbox
D. Main frame

NOTE: Do not permit the tool to go into the spring or it will be difficult to engage the selector fork into the groove of the locking sleeve. Move the selector fork until it is in alignment with the groove on the locking sleeve. Turn the tool clockwise to engage the locking sleeve with the selector fork. Push the tool a small amount toward the differential until the end of the tool is in the spring. Push the pedal to engage the differential lock. Use wire to hold the pedal in position.

136 Nm	14 kg m	100 lb ft
0.40 mm		0.016 in
0.53 mm		0.021 in
100 Nm	10.5 kg m.	75 lb ft

- Remove the tool.
15. Before you install the oil seal housing make sure:
That the oil seals are in good condition.
That on 1212 tractors, both oil seal lips are toward the differential. That on 1412 tractors, the lip on the inner seal is toward the differential, and the lip on the outer seal is toward the reduction unit.
 16. Put jointing compound on the face of the oil seal housing.
 17. Install the oil seal housing on to the axle casing using a soft faced hammer.
 18. Install the two reduction units, tighten the bolts to 100 Nm.
 19. Connect the brake rods or pipes.
 20. Install the rear wheels and lower the tractor to the ground.
 21. Install new gaskets onto the main frame then put the gearbox cover in position.
NOTE: Early model tractors have no hole in the gearbox cover for checking the pump pressure. See figure 29 if one is needed.
 22. Install the bolts which fasten the gearbox cover to the main frame and the axle case.
 23. Tighten the bolts which fasten the gearbox cover to the axle case to 70 Nm.
 24. Tighten the bolts which fasten the gearbox cover to the main frame to 70 Nm.
 25. Put the clutch housing in position then install the bolts which fasten the clutch housing to the main frame. Tighten the bolts to 70 Nm.
 26. Install the wedge between the gearbox cover and the clutch housing. Hit the wedge with a soft faced hammer until it is tight. Install the bolts which fasten the gearbox cover and the wedge to the clutch housing. Tighten the bolts to 100 Nm.
 27. Install the high pressure hydraulic pipe.
 28. Fill the transmission casing with the correct amount of oil. If you use the old oil, use a funnel with a fine filter and destroy the last 4.5 litres.




FIGURE 29 SIDE VIEW OF GEARBOX COVER

A. 280 mm

B. 58 mm

C. 19.05 mm (minimum)

29. Install the starter motor and connect the battery cable.
30. On models without 'Q'-cab:
Install the steering column together with the steering wheel and Orbitrol valve. See figure 26. Connect the steering pipes to the Orbitrol valve. See figure 26.
Install the fuel tank and the instrument panel. Connect the Hydra-Shift lever linkage to the spool valve.
31. Install the bonnet and the silencer.
32. On Q-cab models, install the cab.
33. Remove the air from the hydraulic brakes and the hydrostatic steering system.

Method B—Splitting the Tractor at the Gearbox Axle Joint

1. On 'Q'-cab models, remove the cab.
2. Clean the outside of the clutch housing, gearbox top, main frame and rear axle.
3. Put the tractor on hard, level ground.
4. Remove the oil from the transmission housing and the rear axle. Keep the oil in a clean, covered container. The container must have a minimum capacity of 40 litres.
5. Disconnect the battery cable and remove the starter motor.
6. Put wooden wedges between the front axle and front frame. Make sure the wedges are tight.
7. Remove the silencer and the bonnet.
8. Remove the drawbar frame.
9. On models without 'Q'-cab:
Remove the seat.
Remove the bolts which fasten the fenders to the footplates.
Disconnect the Hydra-Shift lever linkage at the spool valve.
Remove the fuel tank and the instrument panel.
Disconnect the steering pipes from the Orbitrol valve. Install plugs or caps on open pipe ends.
Remove the steering column together with the steering wheel and Orbitrol valve. See figure 26.
10. Push the spool valve down fully.
11. Remove the clutch housing and the gearbox cover.
12. Remove the PTO rear cover plate, the sensing unit and the PTO top shaft.
13. Pull the cardan shaft out of the gearbox.
15. Remove the high pressure hydraulic pipe.
15. Remove the spring pin from the hand brake lever. Disconnect the brake rods on models without 'Q'-cab.
16. Remove the two gearbox mounting bolts and bushes.

17. Install the gearbox to rear axle locating jig using the two gearbox mounting bolts and one rear axle case bolt. See figure 5, page 3.
18. Use a Churchill MS2700 splitting frame to support both ends of the tractor.
19. Remove the bolts which fasten the rear axle to the main frame.
20. Pull either the front or the rear half of the tractor away from the other half.

Method B—Assembly of the Tractor

1. Clean the inside of the main frame.
2. Make sure that the transmission clutch release bearing sleeve is correctly engaged in the fork. See figure 27.
3. Push the two halves of the tractor together. Make sure that the clutch bearing sleeve slides on the support snout. Make sure that the 'O'-rings at the front end of the gearbox are not damaged.
NOTE: It is easier to push the gearbox into position if you engage high range and turn the crown wheel while pushing the tractor together. Or you can turn any of the planetary pinions.
4. Install the bolts which fasten the rear axle case to the main frame. Tighten the bolts to 100 Nm.
5. Remove the gearbox to rear axle locating jig.
6. Install the two bushes (part number K920656) into

15 Nm . . .	1.5 Kg m . . .	50 lb ft
70 Nm . . .	7 Kg m . . .	50 lb ft
100 Nm . . .	10.5 Kg m . . .	75 lb ft
280 mm . . .	11 ¹ / ₈ in	
58 mm . . .	2 ⁵ / ₈ in	
19.05 mm . . .	3/4 in	
4.5 litres . . .	1 gal	
40 litres . . .	9 gal	

the mounting bolt holes at the rear of the range gearbox. See figure 30.

7. Move the gearbox until the bushes fall into the main frame bolt holes.
8. Install the two mounting bolts and tighten them to 136 Nm.
9. Use a feeler gauge to check the clearance between the bolt heads and the top of the gearbox lug. This must be between 0.40 and 0.53 mm.
10. Remove the splitting frame.
11. Install a new full-flow filter element in the Selecta-matic system. Wash the two filter screens in clean fuel. Assemble the filter and install the cover plate.
12. Install the spring pin in the hand brake lever. Connect the brake rods on models without 'Q'-cab.
13. Install the high pressure pipe.
14. Install the cardan shaft. Make sure that the oil seal inside the gearbox is not damaged.
15. Install the PTO top shaft, the sensing unit and the PTO rear cover plate.
16. Install new gaskets onto the main frame then put the gearbox cover in position.
NOTE: Early model tractors have no hole in the gearbox cover for checking the pump pressure. See figure 31 if one is needed.
17. Install the bolts which fasten the gearbox cover to the main frame and the axle case. Tighten the bolts to 15 Nm.
18. Tighten the bolts which fasten the gearbox cover to the axle case to 70 Nm.
19. Tighten the bolts which fasten the gearbox cover to the main frame to 70 Nm.
20. Put the clutch housing in position then install the bolts which fasten the clutch housing to the main frame. Tighten the bolts to 70 Nm.
21. Install the wedge between the gearbox cover and the clutch housing. Hit the wedge with a soft faced hammer until it is tight. Install the bolts which fasten the gearbox cover and the wedge to the clutch housing. Tighten the bolts to 100 Nm.
22. Fill the transmission casing with the correct amount of oil. If you use the old oil, use a funnel with a fine filter and destroy the last 4.5 litres.
23. Install the starter motor and connect the battery cable.




FIGURE 30 GEARBOX MOUNTING

- | | |
|------------------|------------------|
| A. Mounting bolt | C. Range gearbox |
| B. Bush | D. Main frame |




FIGURE 31 SIDE VIEW OF GEARBOX COVER

- | | |
|-----------|-----------------------|
| A. 280 mm | B. 58 mm |
| | C. 19.05 mm (minimum) |

24. On models without 'Q'-cab:
Install the steering column together with the steering wheel and Orbitrol valve. See figure 32.
Connect the steering pipes to the Orbitrol valve. See figure 32.
Install the fuel tank and the instrument panel.
Connect the Hydra-Shift lever linkage to the spool valve.
Install the bolts which fasten the fenders to the foot plates.
Install the seat.
25. Install the drawbar frame then install the bonnet and the silencer.
26. On models with 'Q'-cab, install the cab.
27. Remove the air from the hydraulic brakes and the hydrostatic steering system.

Disassembly of the Gearbox

1. To disassemble the gearbox and the crown wheel and pinion, remove the gearbox as shown in method 'A', then install the gearbox on the stand. See figure 1, page 2.
To disassemble the four-speed section or the range section (but not the crown wheel and pinion), split the tractor as shown in method 'B'.
2. Remove the oil pipes and the control valve. See figure 33.
3. Remove the two sequence valves.
NOTE: The sequence valves have different pressure settings. Make sure you know the position of each valve.
4. Remove the support snout then remove the four nuts which fasten the front end plate.
5. Pull the front end plate from the studs and dowel bolts.
NOTE: Do the jobs 6 to 16 only if you are disassembling the four speed section of the gearbox.

15 Nm	1.5 kg m	10 lb ft
70 Nm	7 Kg m	50 lb ft
100 Nm	10.5 Kg m	75 lb ft
136 Nm	14 Kg m	100 lb ft
0.40 mm		0.016 in
0.53 mm		0.021 in
19.05 mm		$\frac{3}{4}$ in
58 mm		$2\frac{5}{8}$ in
280 mm		$11\frac{1}{8}$ in
4.5 litres		1 gal




FIGURE 32 STEERING COLUMN

- A. Steering pipes
B. Orbitrol valve bolts
C. Throttle linkage
D. Steering column




FIGURE 33 FOUR SPEED SECTION

- A. Oil pipes
B. Control valve
C. Sequence valve
D. Support snout

6. Remove the two brake cylinders.
7. Release the locking plates from the fixed ends of the brake bands, then loosen the nuts.
8. Remove the circlip and the flat washer from inside each spring sleeve, then remove the nuts from the ends of the brake bands.
9. Remove the springs and the piston stops.
10. Remove the nuts and the spherical washers from the fixed ends of the brake bands.
11. Remove the front brake band. To do this job, turn the front unit until one of the planet gears is at the top. Push the ends of the brake band inside the casing. Move the band over the carrier then pull the band toward the front and out of the unit.
12. Turn the front unit until one of the planet gears is at the top, then using a lever, carefully move the front unit forward until it is clear of the bearing. Remove the unit from the gearbox.
13. Remove the abutment washer and the freewheel clutch from the inside of the centre web.
NOTE: Remember which way the free-wheel clutch and abutment washer were installed.
14. Remove the four speed section casing from the range section.
15. Remove the rear brake band using the method shown in job 11.
16. Remove the rear unit using the lifting bracket. See figure 3, page 2.
NOTE: Do the jobs 17 to 31 only if you are disassembling the range gearbox (but not the crown wheel and pinion).
17. Install four spacer tubes on the case studs. The tubes must be 343 mm long with a bore of 13 mm.
18. Install four flat washers and four nuts on the studs. Tighten the nuts to 100 Nm.
19. Check the amount of movement on the top shaft, lay shaft and pinion shaft.
This must be:
Top shaft, 0.05–0.10 mm.
Layshaft, 0.05–0.10 mm.
Pinion shaft, 0 ± 0.05 mm.
If the amount of movement is not correct, remember what corrections are needed when you assemble the gearbox.




FIGURE 34 BRAKE BAND ASSEMBLY

- | | |
|----------------|---------------------|
| A. Cylinder | F. Spherical washer |
| B. Piston | G. Circlip |
| C. Spring | H. Brake band |
| D. Sleeve | J. Adjusting nut |
| E. Piston stop | K. Stop screw |

20. Remove the four nuts, washers and spacer tubes.
21. Remove the screw which fastens the locknuts to the pinion shaft.
NOTE: Later model tractors use a tension pin to fasten the locknuts.
22. Use a lever to move one selector fork out of the neutral position, into a forward gear.

23. Put a soft metal punch between two gears to stop the pinion shaft turning.
24. Remove the two pinion shaft lock nuts and the plain washer.
NOTE: The locknuts have a left hand thread.
25. Remove the taper roller bearing and the spacer.
26. Remove the bolt which fastens the end plate to the casing.
27. Remove the end plate by pulling it off the dowels and over the studs.
28. Remove the distance pieces, gears, bearings etc., from the casing. Put them on a clean surface in the same sequence that they are removed.
29. Remove the layshaft and the topshaft.
30. Hold the 2nd/Rev selector rod in the neutral position, then push the 1st/3rd selector rod forward until it is clear of the detent ball. Put your hand over the detent hole to prevent loss of the ball and spring.
31. Push the 2nd/Rev selector rod forward until it is clear of the detent ball. Put your hand over the detent hole to prevent loss of the ball and spring.
32. Remove the two selector rods together with the selector forks.
33. Remove the gear lock plunger. The plunger is installed between the two selector rods inside a hole drilled through the rear web at the right hand side of the casing. Use a piece of bent wire to move the plunger from the casing.
NOTE: Do the jobs 34 to 36 only if you are disassembling the range gearbox and the crown wheel and pinion.
34. Put a mark on the two differential bearing caps and the end plate.
35. Put a support under the differential then remove the bearing caps and the differential.
36. Do the jobs 17 to 33.




FIGURE 35 PINION SHAFT AND END PLATE

A. Tension pin
B. Locknuts
C. Plain washer
D. Bearing
E. Bolt

F. Spacer
G. Shim
H. End plate
J. Pinion shaft
K. Casing

R78 222




FIGURE 36 SELECTOR MECHANISM

A. Gearlock plunger
B. Detent spring
C. Detent ball
D. Selector rod

E. Selector rod
F. Selector fork
G. Selector fork
H. Pin

R78 223

343 mm	13 1/2 in
13 mm	1/2 in
0.05 mm	0.002 in
0.10 mm	0.004 in
100 Nm	10.5 Kg m
	75 lb ft

Disassembling the Four Speed Units

1. Put a mark on the three parts of the carrier unit.
2. Remove the six bolts and the tabwashers from the front of the carrier.
NOTE: Loosen the bolts evenly because one half of the unit will be pushed away from the other by the springs. If the springs do not separate the unit use a soft-faced hammer to separate them. DO NOT USE A CHISEL OR OTHER HARD LEVER.
3. Remove the clutch plates and springs.
5. Remove the clutch piston. Do this by hitting the front half of the carrier on a block of wood.
6. Mark the bearings so that you can install them correctly.

Removing the Transmission Oil Pump

1. Remove the six bolts which fasten the oil pump to the range gearbox end plate.
NOTE: The four long bolts also fasten the pump outlet connector.
2. Push the pump body from the dowels then remove the pump from the casing.
3. Remove the driven gear from the pump.
NOTE: The gear is installed on a tapered shaft. It must be removed with an extractor. Do not use a hammer to remove the gear.

Inspection of Parts

Wash all the parts that have been removed from the gearbox in clean fuel. Put the parts on a clean surface and make the following checks.

Clutch Plates

1. Make sure that the plates are free from distortion and that they do not show signs of damage. The maximum amount of distortion that is permitted is 0.13 mm measured with a straight edge and feeler gauge.




FIGURE 37 LOCK-UP CLUTCH

- | | |
|-----------------------------|------------------------------|
| A. Clutch cylinder | F. Sun gear |
| B. Clutch piston | G. Planet gears |
| C. Steel clutch plate, thin | H. Planet carrier |
| D. Steel clutch plate, thin | J. Return springs |
| E. Planet gears | K. Steel clutch plate, thick |
| | L. Bronze clutch plate |




FIGURE 38 TRANSMISSION OIL PUMP REMOVAL

- | | |
|---------------------|----------------|
| A. Outlet connector | C. Driven gear |
| B. Body | D. Dowel |

2. Check that the plates are parallel to a maximum of 0.05 mm.
3. Make sure that the clutch plates, backing plates and piston are dry. Assemble the parts, then put a weight of 1130 kg onto the assembly. See figure 39.
4. Measure the thickness of the assembly, this must not be below:
Front clutch: 30.74–30.48 mm.
Rear clutch: 39.24–38.98 mm.
5. Check that the depth of the clutch plate grooves is not below 0.075 mm and that the height of the buffer springs above the plate is 1.27 mm.
6. If the thickness of the assembly is below the dimensions shown, or if the clutch plate grooves are below 0.075 mm, you must install new clutch plate packs. The part number of the front pack is K963593. The part number of the rear pack is K963594. The old piston can be installed with a new pack.




FIGURE 39 CHECKING THE CLUTCH PLATES

- A. Plate 16 mm thick, 154 mm diameter
B. Static load of 1130 kg
C. Loaded height of clutches
D. Clutch backing plate

Spool Valve

1. Remove the plug from the side of the valve body. Remove the spring and the detent ball. See figure 40.
2. Pull the spool down and out of the valve body.
3. Make sure that the spool is not scratched and that it moves freely in the valve body.
4. Install two new seals at the top of the valve body. The lip of the upper seal must be toward the top of the valve, the lip of the lower seal must be toward the bottom of the valve.
5. Use air pressure to clean the restrictor in the centre of the spool.

0.13 mm	0.005 in
0.051 mm	0.002 in
30.74 mm	1.21 in
30.48 mm	1.20 in
39.24 mm	1.545 in
38.98 mm	1.534 in
0.075 mm	0.003 in
1.27 mm	0.050 in
1130 kg	2500 lb

6. Put some oil on the spool and some grease on the oil seals, then install the spool into the valve body.
7. Turn the spool so that the detent grooves are opposite the plughole. Install the detent ball, spring and plug.
8. Remove the roll pin which fastens the relief valve in the spool valve body.
9. Remove the washers, shims and spring.
10. Hold the spool valve upside down.
11. Close the outlet holes then use air pressure in the inlet port to blow the relief valve piston out.
12. Make sure the 'O'-ring is in position on the piston and that it is not damaged.
NOTE: The 'O'-ring is used to stabilise the piston. It is not used as a seal.
13. Make sure that the piston, the inlet and outlet holes and the relief valve housing are free from dirt.
14. Install the piston, spring, washers and shims.
NOTE: Do not try to increase oil pressure by adding shims or changing the spring.
15. Install the roll pin so that it is tight.
NOTE: See page 33 for pressure adjustment.

Oil Pump—See Figure 41

1. Remove the rotors and bearings from the pump body. Remember which way the machined grooves on the bearings go.
2. Check the bearings for scratches or other damage. Replace if necessary.
3. Install new 'O'-rings onto the inner bearing, then install the bearings and rotors.
NOTE: Make sure the machined grooves on the bearings are toward the pressure side of the pump.




FIGURE 40 SPOOL VALVE

- | | |
|----------------|------------------------|
| A. Valve body | D. Oil seals |
| B. Valve spool | E. Relief valve piston |
| C. Detent ball | F. Inlet connection |

R7B 227




FIGURE 41 OIL PUMP

- | | |
|---------------|-------------------|
| A. Drive gear | C. Driven rotor |
| B. Pump body | D. Bearing bushes |
| | E. 'O'-rings |

R7B 228


4. Put a straight edge across the pump body. If the bearing faces are below the level of the pump body, you must replace the bearings. New bearings will be 0.30 to 0.40 mm above the level of the pump body.

NOTE: You must install the bearings in the same position from which they were removed.

5. Install the pump gear onto the shaft. Do not hammer the gear.
6. Install the nut which fastens the gear to the shaft. Hold the gear to stop it turning.

Support Sleeve Sealing Rings

1. Make sure that the sealing rings are not broken or worn. You do not need to remove the rings to do this job.
2. Replace the rings if they are broken or worn. Do not replace them if they have small marks on them. New rings must be installed correctly with the chamfered sides of the rings toward the outsides. See figure 42.



R78 229

FIGURE 42 SUPPORT SLEEVE SEALING RINGS


A. Sealing rings

Sequence Valves

The pressure setting of a sequence valve is the pressure at which the piston will move far enough against the spring to permit oil to get to the clutch cylinder.

All sequence valves are adjusted to give the correct pressure setting during manufacture. To get this setting during service do the following procedure:

1. Disassemble the sequence valve. See figure 44.
2. Put tape over the piston orifice.
3. Assemble the sequence valve.



R78 230

FIGURE 43 SEQUENCE VALVE PRESSURE CHECK

A. Pressure gauge
B. Adaptor

C. Grease gun
D. 90° Adaptor

0.30 mm	0.012 in
0.40 mm	0.016 in
2.3 lit/min	0.5 g/m
45°C	113°F
50°C	122°F
230 kPa	.	2.3 bar	.	.	.	2.4 kg/cm ²	.	.	.	34 lb/in ²
250 kPa	.	2.5 bar	.	.	.	2.5 kg/cm ²	.	.	.	36 lb/in ²

4. Use adaptors to connect the sequence valve to the brake band piston actuator and a pressure gauge. See figure 43.
5. Connect a lever type grease gun filled with transmission oil (at normal air temperature) to the actuator. Operate the grease gun lever to bring the pressure up gradually. Look at the pressure gauge carefully and remember at what pressure the gauge needle gives a fast downward movement.
NOTE: The pressure at which the needle moves should be between 210 and 220 kPa.

6. If the pressure is below that shown above, turn the adjusting screw to the right, then repeat the procedure until it is correct.
If the pressure is above that shown above, turn the adjusting screw to the left, then repeat the procedure until it is correct.

7. Remove the tape from the piston orifice.

If new sequence valves are to be installed or if the old sequence valves have been adjusted make sure that you use the following procedure.

1. The front sequence valve must be adjusted to increase the pressure setting by turning the adjusting screw **two full turns to the right**.
2. The rear sequence valve **must not be adjusted**.

Assembling the Gearbox

If you have made repairs to the crown wheel and pinion, or if you have installed new parts which will change the setting of the pinion shaft, you must make a temporary assembly of the gearbox. This is so that you can find out what thickness of shims you will need to give the correct setting distance for the bevel pinion and the correct amount of clearance for the top shaft and the layshaft. To make the temporary assembly use the following procedure.




FIGURE 44 SEQUENCE TIMING VALVE

- | | |
|-------------------|----------------------------------|
| A. Oil inlet pipe | D. Adjusting screw |
| B. Piston | E. Connection to clutch cylinder |
| C. Spring | F. Spill port |

1. Turn the range gearbox so that the rear end plate is toward the floor and the four studs are vertical.
2. Install the top shaft and the lay shaft, then install the end plate.
3. Install the four spacer tubes on the case studs.
4. Install four flat washers and four nuts on the studs. Tighten the nuts to 100 Nm.
5. Check the amount of movement on the top shaft and the lay shaft. This must be between 0.05 and 0.10 mm. If the amount of movement is not correct, remember what corrections are needed when you

make the final assembly of the gearbox. Turn the top shaft when checking for movement.

6. Install the pinion shaft without the gears but with the rear bearing installed.
7. Install the front bearing, the washer and the inner nut, do not install the shims.
8. Tighten the inner nut until all movement of the shaft is removed and the bearings are tight. Turn the pinion while you tighten the nut to make sure that the rear bearing track is fully against the support plate.
9. Assemble the setting gauge, see figure 4, page 2, by installing the thickest (6.3125 in) spacer on the probe, then screw the probe as far as possible in to the mandrel.
10. Install the tool onto the end plate with the dummy bearings in the end plate bores. Use bolts to fasten the bearing caps in position to hold the tool in place, see figure 45.
11. Slide the mandrel and turn the probe so that the tip of the probe makes light contact with the rear face of the pinion bearing.
12. Tighten the locknut to prevent the probe turning. Make sure the tip of the probe is still making light contact with the rear face of the pinion bearing.
13. Look at the correction figure which is on the face of the pinion. If the figure is minus (-), subtract it from 0.030 in. If the figure is plus (+), add it to 0.030 in.
14. Use a feeler gauge to measure the distance between the spacer and the mandrel.
15. Use the following procedure to find the correct amount of shims needed to set the pinion in the correct position.

- a. If the figure on the pinion is -0.007 and the feeler gauge measurement is 0.057, then:

Constant dimension 0.030 in
Minus (-) 0.007 in

0.023 in

Gap measurement 0.057 in
Minus (-) 0.023 in

Amount of shims 0.034 in

- b. If there is no correction figure on the face of the pinion you will see the letters O.K. marked on it. Use the following procedure to find the correct amount of shims needed.

Gap measurement 0.057 in
Minus constant dimension 0.030 in

Amount of shims 0.027 in




FIGURE 45 PINION SETTING DISTANCE

A. Rear end plate
B. Pinion bearing

C. Probe
D. Measured gap

16. Check these figures again, then when you are sure they are correct remove the pinion setting gauge.
17. Remove the four spacer tubes and the end plate.
18. Remove the pinion shaft, top shaft and lay shaft.

0.05 mm	0.002 in
0.10 mm	0.004 in
100 Nm	10.5 kg m 75 lb ft
210 kPa	2.1 bar 2.25 kg/cm ² 31 lb/in ²
220 kPa	2.2 bar 2.25 kg/cm ² 32 lb/in ²

19. Remove the rear pinion bearing track from the end plate, then install the number of shims needed in the end plate.
20. Install the rear pinion bearing track into the end plate. Do this job by hitting the track with a soft-faced hammer until it is tight against the shims and end plate.
21. Install the medium/reverse range detent ball and spring into the hole in the casing.
22. Slide the medium/reverse selector rod, together with the selector fork into position.
NOTE: You must hold the detent ball down against the spring pressure when you do this job. Use the tool (figure 6 page 3). Turn the flat side of the tool toward the end of the selector rod. Push the ball down and slide the rod until it makes contact with the tool. Push the rod against the tool, then lift the tool out.
23. Put the medium/reverse selector rod into the neutral position.
24. Install the gear lock plunger into the hole between the selector rods, then install the high/low range detent ball and spring.
25. Use the procedure shown in job 22 and install the high/low range selector rod and fork.
26. Turn the range gearbox so that the rear end plate is toward the floor and the four studs are vertical.





FIGURE 46 RANGE GEARBOX

A. Top shaft
B. Pinion shaft
C. Gear: low range

D. Gear: medium range
E. Gear: high range
F. Gear: reverse range

G. Pinion: front bearing
H. Pinion: rear bearing
J. Cover plate: rear bearing

27. Install the layshaft and the top shaft.
28. Install the pinion shaft gears, the dog clutches and the distance pieces in the correct order, see figure 46. Make sure the selector forks are engaged in the dog clutch rings.
29. Add shims of 0.20 mm the old shims at the front of the pinion shaft.
30. Slide the end plate over the four studs. Hold the selector rods in the correct position until the end plate is installed on the dowels.
31. Hold the pinion shaft up so that it can go through the distance pieces, dog clutches, shims etc.
32. Install the pinion front bearing, the flat washer and the inner lock nut.
33. Install the four spacer tubes on the case studs.
34. Install four flat washers and four nuts on the studs. Tighten the nuts to 100 Nm.
35. Use a lever to move one selector fork out of the neutral position.
36. Put a soft metal punch between two gears to stop the pinion shaft turning.
37. Tighten the inner locknut to 270 Nm.
38. Install the outer locknut and fully tighten it.
NOTE: The locknuts must be locked.
Early model tractors use a screw to lock the nuts, see figure 47. Later models use a tension pin and the outer lock nut is castlated.
39. Check the amount of movement on the lay shaft, top shaft and pinion shaft. This must be:
Layshaft: 0.05–0.10 mm
Topshaft: 0.05–0.10 mm
Pinion shaft: 0 ± 0.05 mm
40. If the pinion shaft movement is not correct, it must be corrected by removing the lock nuts, flat washer, bearing, end plate and spacer, then changing the thickness of the shims.
41. When the pinion shaft movement is correct and you have assembled the spacer, end plate, bearing, flat washer and you have tightened and locked the nuts, remove the spacer tubes and install the bolt which fastens the end plate to the range gearbox casing.



R78 234

FIGURE 47 LOCKING PINION SHAFT NUTS – EARLY MODELS

- | | |
|-----------------|------------------|
| A. Bearing | C. Inner nut |
| B. Pinion shaft | D. Outer nut |
| | E. Locking screw |

Use the following procedure to assemble the four speed section of the gearbox.

42. Put the rear carrier unit on a clean surface with the bearing pins to the top. Put oil on the pins.
43. Make sure that each planet gear has two needle roller bearings separated by a distance piece.

0.05 mm	0.002 in
0.10 mm	0.004 in
0.20 mm	0.008 in
100 Nm	10.5 kg m 75 lb ft
270 Nm	28 kg m 200 lb ft

44. Install the planet gears on the pins, turn them so that the centre punch marks are toward the centre. See figure 48.
45. Install the sun gear on the shoulders of the planet gears.
46. Install the end plate, make sure the assembly marks are aligned, then push the plate onto the dowels.
47. Install the locking plates and bolts which fasten the end plate to the carrier unit. Tighten the bolts evenly to 40 Nm.
48. Lock the bolts with the plates, make sure the plates cover the dowels and that the ends of the plates are turned over correctly so that they do not make contact with the pinion nut.
49. Turn the carrier over then put oil onto the small thrust washer. Install the washer into the sun gear.
50. Install the drive shaft into the centre of the planetary gears.
51. Install the thick clutch plate into the carrier unit, see figure 49.
52. Install the eight thin clutch plates, a bronze plate first, then a steel plate, and then a bronze plate and so on, a steel plate must be at the top.
NOTE: One bronze plate is not grooved. This plate must be installed in the second or third bronze plate position.
53. Make sure the clutch cylinder is clean, install new 'O'-rings on to the clutch piston. Install the piston into the cylinder.
54. Install the eighteen springs in the holes in the carrier unit. Install the nine springs into the piston.
NOTE: Put grease onto the piston springs to keep them in position when the cylinder is turned over.




FIGURE 48 ASSEMBLING PLANETARY GEARS




FIGURE 49 PLANETARY UNIT LOCK-UP CLUTCH

- | | |
|-----------------------------|------------------------------|
| A. Clutch cylinder | E. Steel clutch plate: thick |
| B. Clutch piston | F. Return springs |
| C. Steel clutch plate: thin | G. Carrier unit |
| D. Bronze clutch plate | H. Planet gears |
| | J. Sun gear |

55. Turn the cylinder over and hold it a short distance above the carrier unit. Make sure that the springs are still in position, then install the cylinder on to the carrier unit. Make sure that the assembly marks are aligned.
 56. Install the bolts and the tabwashers which fasten the clutch cylinder to the carrier unit. Tighten the bolts evenly to 27 Nm, then lock the bolts with the tabwashers.
 57. Use the same procedure to assemble the front unit.
- NOTE: The front unit uses only two bronze clutch plates (both grooved) and two thin steel clutch plates. A thick steel clutch plate is used but there are only six springs.

If you have removed or repaired only the front unit of the four speed section, use method A to complete the assembly of the gearbox.

If you have removed or repaired only the rear unit of the four speed section, use methods B and C to complete the assembly of the gearbox.

If you have removed or repaired only the range section, use method C to complete the assembly of the gearbox.

Method A

1. Install the free-wheel clutch into the housing.
NOTE: The flange on the free-wheel cage must be toward the differential end of the gearbox. See figure 50.
2. Install the abutment plate with the outside shoulder outward.
3. Install the front unit into the casing.
4. Turn the carrier unit so that one of the planet gears is opposite the gap in the casing. Engage the sun gear on the splines of the rear unit drive shaft.
5. Slide the carrier into the free-wheel clutch. Turn the unit in a clockwise direction, then push the carrier until the bearing is at the bottom of the casing.
6. Push the brake band over the carrier and into position in the casing.
7. Push the ends of the band through the holes in the casing. The end with the longest thread must be toward the brake piston. Do not install the adjusting nuts.




FIGURE 50 FREEWHEEL CLUTCH

- A. Cage
B. Sprag
C. Direction of free rotation

8. Install the small thrust washer into the centre of the sun gear. Make sure that the bush and seal are installed inside the drive shaft, then install the drive shaft through the clutch plates. Engage the drive shaft splines with the planet gears.
9. Make sure that the sealing rings and the thrust washer are in position on the front end plate.

27 Nm	2.75 kg m	20 lb ft
40 Nm	4 kg m	30 lb ft

10. Install the end plate onto the studs.
NOTE: Make sure the sealing rings are in the centre of the grooves.
11. Push the end plate until the bearing race enters the plate bore. Install the four washers and nuts which fasten the end plate. Tighten the nuts to 100 Nm.

Method B

1. Install the rear brake band (this is the longest band) into the rear end of the casing.
2. Push the ends of the band through holes in the casing. The end with the longest thread must be toward the brake piston. Do not install the adjusting nuts.
3. Install the rear unit into the casing. Make sure that the brake band is in the correct position around the unit, and that the sealing rings are in the correct position.
4. Push the rear unit fully into position.
5. Use method A to install the front unit.

Method C

1. Install the free-wheel clutch into the housing.
NOTE: The flange on the free-wheel cage must be toward the differential end of the gearbox. See figure 50.
2. Install the abutment plate with the outside shoulder outward.
3. Slide the four speed section onto the four long studs. Make sure that the rear spigot is engaged in the free-wheel clutch. You may need to turn the rear unit in a clockwise direction to do this.
4. Install the four washers and nuts which fasten the four speed section to the range gearbox. Tighten the nuts to 100 Nm.

You can now complete the assembly of the gearbox.

57. Install a new oil seal onto the clutch drive shaft. The lip of the oil seal must be toward the gearbox.
58. Move the oil seal over the shoulder on the shaft. Use a soft faced hammer and lightly hit the seal into position.
59. Install the support snout and the bolts which fasten the support snout. Tighten the bolts to 12 Nm.
60. Install a new 'O'-ring onto the flange of the support snout.
61. Make sure that both carrier units turn in the direction of engine rotation. They must not turn in the opposite direction. The movement must be free.
62. Release the brake band stop screws and turn them fully out.
63. Align the brake bands so that the fixed ends are central in the casing holes, then install the spherical washers and nuts to both ends of the brake bands. See figure 52.
64. Push downward on the springs at the piston end of the bands, then turn the nuts at the fixed ends until they contact the spherical washers and are level with the threaded ends of the brake bands.

65. Make sure that the bands are in the correct position, then tighten the lower adjusting nuts until the faces of the spring sleeves are 30.16 mm from the machined face of the casting, see figure 53.
NOTE: If you have installed new brake bands, this distance must be 28.6 mm.
66. Make sure that the band does not come through the nut so far that the end of the thread is above the face of the sleeve. Install the washer and the circlip.
67. Turn the brake band stop screws (there are three on the front unit and four on the rear unit) until they make contact with the bands.
68. Turn the front stop screws three quarters of a turn to the left. Turn the rear stop screws half a turn to the left. Hold the screws in this position and tighten the lock nuts.
69. Install the pistons into the brake cylinders, then install the cylinders with the pipe connections toward the centre.
70. Install the two sequence valves. Make sure that you use new 'O'-rings and that the valves are installed in the same positions from which they were removed.
71. Install the spool valve stop, then install the oil control valve. Make sure that the spool valve moves freely in the stop in all positions.
72. Install the oil pipes, make sure that you install the restrictors at the spool valve end of the brake pipes.
73. Install new 'O'-rings into the ports in the range gearbox front and plate, then install the oil pump and the connector.
74. Install the oil pump body dowels into the holes in the end plate, then install the bolts and tighten them to 27 Nm.
75. Connect the high pressure oil pipes to the pump. Make sure that the pipe unions are fully tightened.

28.6 mm			1 ¹ / ₈ in
30.16 mm			1 ³ / ₁₆ in
12 Nm	1.25 kg m		9 lb ft
27 Nm	2.75 kg m		20 lb ft
100 Nm	10.5 kg m		75 lb ft




FIGURE 52 BRAKE BAND ASSEMBLY

- | | |
|----------------|---------------------|
| A. Cylinder | F. Spherical washer |
| B. Piston | G. Circlip |
| C. Spring | H. Brake band |
| D. Sleeve | J. Adjusting nut |
| E. Piston stop | K. Stop screw |




FIGURE 53 SLEEVE SETTING DISTANCE

TRANSMISSION FAULT FINDING

Before you make any adjustments or repairs to the transmission, you must operate the tractor to make sure that you know exactly what defects there are, and how to correct them.

To do this you must operate the tractor at an engine speed of 1800 r/min, in high range. Use the hand throttle lever to get this speed.

Normal Gear Changes—Up

Operate the tractor on level ground, in high range at 1800 r/min. If you select a higher gear the engine noise will increase as the tractor speed increases and the engine speed decreases. This must occur one second after the Hydra-Shift lever has been moved.

Normal Gear Changes—Down

Operate the tractor on level ground, in high range at 1800 r/min. If you select a lower gear the engine noise will decrease as the tractor speed decreases and the engine speed increases. This must occur two to three seconds after the Hydra-Shift lever has been moved.

Gear Selection Defects

When changes between 1st and 2nd or 3rd and 4th gears are made, the clutch in the front unit is engaged or disengaged.

Changes to higher gears can be made correctly only if there is the correct amount of oil flowing to the clutch in the front unit.

A defect in the change from 1st to 2nd gear will show up as a delayed change, several seconds between moving the Hydra-Shift lever and the change occurring.

A defect in the change from 3rd to 4th gear will also show up as a delayed change. This will be caused by a low volume of oil, or a possible change down to 1st gear caused by a very low volume of oil which cannot operate the two clutch cylinders at the same time.

A defect in changes from 2nd to 1st and 4th to 3rd will also show up as a delayed change. The probable cause of this is brake band wear.

When changes between 2nd and 3rd gears are made, both clutches are engaged and disengaged. This is controlled by the sequence valves. When a change from 2nd to 3rd gear is made the rear clutch is engaged as the front clutch is disengaged. If the rear clutch engages before the front clutch has disengaged, an **overlap** defect has occurred.

If the front clutch disengages before the rear clutch engages, an **underlap** defect has occurred.

Overlap—This shows up if, when changing from 2nd to 3rd gear, you feel a sudden thrust forward as 3rd gear is engaged. This happens because the transmission tries to engage 4th gear.

Overlap will also show up if, when changing from 3rd to 2nd gear on 'over-run', the tractor free-wheels for a distance before engine braking occurs. You will also hear the engine governor operate just before engine braking occurs. This happens because 4th gear is engaged before 2nd gear.

Underlap—This shows up if, when changing from 2nd to 3rd gear, the tractor slows down before increasing speed with a surge into 3rd gear. This happens because 1st gear is engaged before 3rd gear.

Underlap will also show up if, when changing from 3rd to 2nd gear, the tractor free-wheels before engine braking occurs. The engine governor will not operate. This happens because for a short time both clutches are disengaged (1st gear) and both brake bands are partly disengaged (the front brake band is releasing as the rear brake band is engaging). The units then rotate in the forward direction for a short time and a higher ratio than 3rd gear occurs.

A possible cause of 'overlap' or 'underlap' is that the sequence valves need adjusting.

Sequence Valve Adjustment—In Tractor

It is not normally necessary to adjust the sequence valves, but if you need to, the following notes will help you to adjust them correctly.

1. The front sequence valve controls the release of the front clutch (changing from 2nd to 3rd gear).
2. The rear sequence valve controls the release of the rear clutch (changing from 3rd to 2nd gear).
3. 'Underlap' is corrected by turning the adjusting screw out to give a slower clutch release.
4. 'Overlap' is corrected by turning the adjusting screw in to give a faster clutch release.

Procedure for Checking the Gear Changes

Make sure that the transmission is filled with the correct grade of oil and that it is at the correct level. Check that the Hydra-Shift lever moves freely and that the spool valve engages in four positive positions. Start the engine. With the range lever in the neutral position, operate the engine at 1500 r/min until the transmission oil reaches a minimum temperature of 45°C (113°F). To reduce the time needed for this, move the Hydra-Shift lever to 4th gear and operate the hydraulic system at the maximum T.C.U. pressure.

Check 1—Engage high speed with the range lever. Operate the tractor on level ground with the Hydra-Shift lever in 1st gear at an engine speed of 1800 r/min. Move the Hydra-Shift lever to 2nd gear, then to 3rd gear, then to 4th gear. Do not move the Hydra-Shift lever directly from 1st to 4th gear. Move the Hydra-Shift lever to 3rd gear, then to 2nd gear, then to 1st gear. All movements of the Hydra-Shift lever must be fast and positive. Look at 'Normal Gear Changes' and 'Gear Selection Defects' above to see if the transmission is operating correctly.

Check 2—Repeat Check 1 operating the tractor on a gradient or towing a loaded trailer. Make the up changes when moving up the gradient. If the gradient is very steep you may not be able to operate in 4th gear. Make the down changes when moving down the gradient, starting in 4th gear at an engine speed of 1800 r/min. Move the Hydra-Shift lever to 3rd gear and make sure that the change happens correctly. Use the tractor brakes to slow the tractor until the engine speed is at 1800 r/min (do not use the hand throttle lever), then make a change to 2nd gear. Make sure the change happens correctly then use the same procedure to change into 1st gear.

If a defect shows up during checks 1 and 2, use the chart on pages 35 to 37, to find the cause of the defect and what action to take to correct it.

If no defect shows up during checks 1 and 2, do check 3.

Check 3—Engage high speed with the range lever. Operate the tractor on level ground with the Hydra-Shift lever in 1st gear, at an engine speed of 1000 r/min. Engage 2nd, 3rd and 4th gears in sequence, make sure each change occurs before engaging the next gear. The changes must be smooth but may take several seconds to occur.

If the transmission does not move out of 1st gear, increase the engine speed gradually until the change does occur. If the change occurs at or below 1200 r/min, no action is needed if the transmission oil is at the correct pressure. If the change occurs above 1200 r/min, low oil pressure is a possible cause.

Procedure for Checking the Oil Pressure

Use oil pressure gauge DB8267 to check the transmission oil pressure. Connect the gauge to the tapping point in the control valve, see figure 54.

NOTE: Early tractors had a 0.488 in AF brass plug in the tapping point. Later tractors have a 0.500 in AF plug.

Access to the tapping point is through a hole in the side of the gearbox after removing a blanking plug on later tractors. On early tractors access to the tapping point is by removing the gearbox cover. You can make a modification to the early model to make an access hole. See figure 31.

Start the engine. With the range lever in the neutral position, operate the engine at 1500 r/min until the transmission oil reaches a temperature of 45°C. To reduce the time needed for this, move the Hydra-Shift lever to 4th gear and operate the hydraulic system at the maximum T.C.U. pressure. Do not put the hydraulic control lever into the SELECT position to heat the oil, this will put air into the oil and give a wrong pressure reading.

When the transmission oil temperature is at 45°C, put the range lever into the neutral position, stop the engine and do the following checks.




FIGURE 54 INSTALLING THE PRESSURE GAUGE

A. Pressure gauge DB8267 C. DB8440
B. Control valve X. Access points

Check 1—Install the pressure gauge, see figure 54. Start the engine and operate it at 1500 r/min. If the transmission oil pressure is below 4.85 kg/cm², look at the tractor serial number and use one of the following procedures.

On 1212 tractors below serial number 1003279 install a new relief valve piston, part number K918743 (with a head thickness of 3.2 mm) and install a new relief valve piston 'O'-ring, part number 625400. Increase the oil pressure to between 5 and 5.25 kg/cm² by installing additional 0.5 mm. shims (part number K626743). See figure 55.




FIGURE 55 RELIEF VALVE SHIMS

NOTE: One shim will raise the oil pressure by 0.21 kg/cm².

On 1212 tractors between serial numbers 1003279 and 11151506, and on 1412 tractors below serial number 11200321, use the same procedure, but you do not need to install a new piston unless the old one is damaged.

On 1212 tractors from serial number 11151506 and on 1412 tractors from serial number 11200321 a dashpot type relief valve is installed. With this type of piston the most probable cause of low oil pressure is either a weak spring, or that the piston is not moving freely in the piston bore. To correct the problem, install a new spring and use fine emery cloth to clean the piston before you install any new shims.

NOTE: Before you make a pressure test on these later tractors, you must modify the pressure test adaptor, DB8440, to make the threaded part of the adaptor 6.4 mm long.

Check 2—At the engine speed of 1500 r/min, move the Hydra-Shift lever to 2nd gear. The pressure will decrease for a short time, then increase to approximately 0.02 kg/cm² less than the pressure recorded in check 1. If the pressure is different from this, the front unit clutch oil line is leaking.

Check 3—At an engine speed of 1500 r/min, move the Hydra-Shift lever to 3rd gear.

The pressure will decrease for a short time, then increase to a minimum pressure of 0.18 kg/cm² above the pressure recorded in check 1. If the pressure is different from this, the rear unit clutch oil line is leaking.

Check 4—At an engine speed of 1500 r/min, move the Hydra-Shift lever to 4th gear.

The pressure will decrease for a short time, then increase to approximately 0.26 kg/cm², above the pressure recorded in check 1. If the pressure is different from this, either or both the clutch unit oil lines are leaking.

Brake Band Adjustment

During the life of the tractor the brake bands will gradually wear and prevent correct operation of the transmission.

45°C	113°F
0.5 mm	0.020 in
3.2 mm	$\frac{1}{8}$ in
6.4 mm	$\frac{1}{4}$ in
0.02 kg/cm ²	0.25 lb/in ²
0.18 kg/cm ²	0.26 lb/in ²
0.21 kg/cm ²	3 lb/in ²
0.26 kg/cm ²	3.7 lb/in ²
4.85 kg/cm ²	69 lb/in ²
5 kg/cm ²	70 lb/in ²
5.25 kg/cm ²	75 lb/in ²




FIGURE 56 BRAKE BAND ADJUSTMENT

- | | |
|------------------------|-------------------|
| A. Spool valve | D. Pressure gauge |
| B. Male/male connector | E. Actuator |
| C. 90° adaptor | F. Grease gun |

The brake bands are used to hold the transmission when the tractor is in the overrun condition. When the bands wear there will be a delay before the gears engage when changing downward, or the gears will not hold. When this occurs you must adjust the brake bands. You can do this job without removing the gearbox cover on all 1412 tractors and on 1212 tractors from serial number 1001333.

Adjustment: 1212 Tractors Before Serial Number 1001333

1. Remove all dirt from the gearbox cover.
2. Remove the fuel tank, steering column and gearbox cover.
3. Remove the oil pipes and the two sequence valves.
4. Connect the brake band piston actuator and the pressure gauge to the front sequence valve connection in the spool valve body, see figure 56. Put the valve spool in the upper, first gear position.
5. Connect a lever type grease gun to the actuator. The grease gun must be filled with the correct grade of transmission oil.
6. With the valve spool still in the first gear position, operate the grease gun at a constant pressure of 5 kg/cm² until the brake piston is held against the stop.
7. With the pressure still applied to the piston, tighten the front brake band adjusting nut using the following procedure.
Tighten the nut, checking all the time that there is some side to side movement at the threaded end of the brake band. When all side movement has gone, tighten the nut the distance of one flat more. Release the oil pressure then release the locknut four full turns. Install the locking plate on the nut.
8. Move the brake band piston actuator and the pressure gauge to the rear sequence valve connection in the spool valve body.
9. Repeat jobs 5 to 7.
10. Assemble the tractor.

Adjustment: 1212 Tractors Serial Number 1001333 onward and all 1412 Tractors

1. Remove all dirt from the access plugs on both sides of the gearbox casing.
2. Remove the plastic cap from the right hand special plug.
3. Release the locknut from the locking screw.
4. Turn the locking screw fully to the left, then remove the special plug.
5. Remove the locking screw and the locknut from the left hand special plug, then remove the plug.
6. Remove the $\frac{3}{4}$ BSP plug from the right hand side of the gearbox cover then remove the pressure tapping plug from the spool valve body.
7. Connect the pressure gauge to the tapping point with the adaptor, see figure 57.
8. Make sure that the range lever is in the neutral position, then start the engine.
9. Put the Hydra-Shift lever into fourth gear, then use the hand throttle lever to adjust the engine speed until you get a pressure gauge reading of a minimum 5 kg/cm². The engine speed will be approximately 1200 r/min.
10. Tighten the adjusting nut on the front brake band until the engine speed is reduced by approximately 25 r/min. Push the clutch pedal down **immediately** when the engine speed starts to fall. Turn the adjusting nut to the left four full turns, then release the clutch pedal.
11. Repeat job 10 on the rear brake band, stop the engine.
12. Install the plug in the left hand side of the gearbox casing. Install the locking screw and the locknut but do not tighten them.
13. Install the special plug in the right hand side of the gearbox cover. Make sure that the locking screw (if used), is installed but is turned fully back on the thread.
14. Remove the pressure gauge and the adaptor, then install the pressure tapping plug in the spool valve body. Install the plastic plug.
15. Tighten the two locking screws until they just contact the brake bands, then turn them to the left the distance of one flat. Tighten the lock nuts.
16. If a locking screw is not used the large plug is self-locking. Tighten it until it just contacts the end of the brake band then turn it to the left a $\frac{1}{2}$ turn.

NOTE: If there is not enough thread to remove side movement of the brake band, no further adjustment can be made using this procedure. You must remove the gearbox from the tractor and adjust the brake bands at the piston ends.

Sequence Valve Setting

The pressure setting of the sequence valves is the pressure needed to move the piston far enough against the spring to permit oil to flow to the clutch cylinder. See page 22 for the static pressure setting.

5 kg/cm² 70 lb/in²




FIGURE 57 BRAKE BAND ADJUSTMENT

- | | |
|--------------------------|-------------------|
| A. Pressure gauge DB8267 | C. Adaptor DB8440 |
| B. Spool valve | D. Access points |

FAULT FINDING CHART – TRANSMISSION – HYDRA-SHIFT
ENGINE SPEED 1800 r/min – OIL TEMPERATURE 55°C (131°F) MINIMUM

OVERRUN

	1	2	3	4	5
Symptom	Delay before 4th – 3rd or 2nd – 1st change takes place.	Delay before 3rd to 2nd change takes place. May change to 4th for a few seconds.	Failure to hold in 4th gear. (runs away faster than 4th).	Failure to hold in 3rd gear. (runs away faster than 3rd).	Failure to hold in 2nd gear. (runs away faster than 2nd).
Fault	Front band brake slow to clamp and stop carrier.	(1) Rear band brake slow to clamp and stop carrier. (2) Loss of sequence.	Clutch slipping in either reduction unit.	Brake band not applied on front reduction unit.	Brake band not applied on rear reduction unit.
Possible Cause	(a) Worn band (incorrect adjustment). (b) Blocked orifice in sequence valve.	(1) (a) Worn band (incorrect adjustment). (b) Blocked orifice in sequence valve. (2) (a) Low pressure (b) leakage at front unit. (c) Excessive travel on front clutch piston travel. (d) Rear sequence valve out of adjustment (Only if a new Sequence valve has been fitted).	(a) Low pressure (b) binding clutch piston. (c) Badly worn clutch plates.	(a) Badly worn brake band on front unit. (b) Sticking brake piston.	(a) Badly worn brake band on rear unit. (b) Sticking brake piston.
Action	Adjust brake band Clean sequence valve	Adjust brake band. Check pressures. Check sequence valves.	Check system pressure in all gears. Check Clutch units.	Check band adjustment Check piston.	Check band adjustment. Check piston.

FAULT FINDING CHART – TRANSMISSION – HYDRA-SHIFT TRACTOR
ENGINE SPEED 1800 r/min – OIL TEMPERATURE 55°C (131°F) MINIMUM

	DRIVE				
	1	2	3	4	5
Symptom	Failure to change from 1st gear into any any other gear	Failure to change 1st – 2nd or 3rd – 4th (can engage 3rd)	Failure to engage 3rd or 4th gear (can engage 2nd)	Occasional drop back to 1st gear when in higher gear	Slow engagement when changing 1st 2nd or 3rd – 4th.
Fault	Insufficient oil supply.	front clutch unit not engaging.	rear clutch unit not engaging.	Intermittent oil supply.	Front clutch slow to engage.
Possible Cause	(a) Thick oil (b) Blocked filter (c) Faulty relief valve. (d) Worn pump. (e) Excessive leakage on both units-possible caused as (a) (b) and (c) for symptoms 2 and 3 (f) Pump sucking air at joint face. (g) spool valve turned 180°.	Excessive leakage on front unit: (a) At muff sealing rings. (b) At clutch piston 'O' rings. (c) Along supply line, due to broken pipe or sequence valve.	Excessive leakage on rear unit: (a) At muff sealing rings. (b) At clutch piston 'O' rings. (c) Along supply line, due to broken pipe or sequence valve.	(a) Low oil level (b) Partially blocked filter.	(a) Low pressure (b) Leak at front clutch muff. (c) Excessive front clutch piston travel. (d) Front sequence valve sticking.
Action	Check oil viscosity. Check pressure in 1st gear prior to investigation. Check for 4 positive detent positions on the spool valve.	Check pressures in all gears to confirm before stripping down.	Check pressures in all gears to confirm before stripping down.	Check oil level Clean filter.	Check pressures in all gears to eliminate (a) and (b). Adjust brake band before stripping.

FAULT FINDING CHART TRANSMISSION – HYDRA-SHIFT
ENGINE SPEED 1800 r/min – OIL TEMPERATURE 55°C (131°F) MINIMUM

DRIVE

	6	7	8	9
Symptom	When changing 2nd to 3rd, 1st is temporarily engaged – 'Overlap' or	When changing 2nd to 3rd, 4th is temporarily engaged—'Overlap' or remains in 4th.	Selects intermediate ratio between 1st and 2nd or 3rd and 4th.	Selects intermediate ratio between 2nd and 3rd or 3rd and 4th.
Fault	Loss of sequence	Loss of sequence	Front clutch unit slipping slightly.	Rear clutch unit slipping slightly.
Possible Cause	(a) Low oil pressure. (b) Leak at front muff sealing rings. (c) Excessive piston travel on rear clutch. (d) Front sequence valve out of adjustment. (if new). (e) Front Brake Piston sticking.	(a) Front sequence valve sticking or blocked. (b) Front sequence valve out of adjustment. <i>Note: (b) applies only if a new Sequence valve has been fitted.</i>	(a) Low pressure (b) Excessive leakage on front unit. (c) Sticking front clutch pinion	(a) Low pressure. (b) Excessive leakage on rear unit. (c) Sticking rear clutch unit piston.
Action	Check pressures in all gears to eliminate (a) and (b). Check brake band and retest – if still under-lapped adjust front sequence valve <i>before stripping</i> . (if new).	Clean front sequence valve and retest. If necessary adjust front sequence valve.	Check pressures in all gears to eliminate (a) and (b). Strip down.	Check pressures in all gears to eliminate (a) and (b). Strip down

SPECIFICATION

Planetary Units

Reduction ratio	First Reduction	Second Reduction
Overall reduction	1.37:1	1.82:1
		2.49:1

Clutch

Number of driving plates	2	4
Number of driven plates	2	4
Driven plates	Grooved	3 grooved, 1 plain
Maximum pressure on facing	21 kg/cm ² (300 lb/in ²)	21 kg/cm ² (300 lb/in ²)
Driven plate diameter	155.6 mm (6.125 in)	155.6 mm (6.125 in)
Drive plate diameter	158.7 mm (6.25 in) P.C.D.	158.7 mm (6.25 in) P.C.D.
Total friction area	303 cm ² (47 in ²)	606 cm ² (94 in ²)
Operating pressure	5–5.7 kg/cm ² (71–75 lb/in ²)	5–5.7 kg/cm ² (71–75 lb/in ²)
Piston area	149 cm ² (23 in ²)	149 cm ² (23 in ²)
Clamping force	745 kg (1640 lb)	745 kg (1640 lb)

Brake

Piston diameter	63.5 mm (2.5 in)	63.5 mm (2.5 in)
Piston area	31.6 cm ² (4.9 in ²)	31.6 cm ² (4.9 in ²)
Piston travel	6.35 mm (0.25 in)	6.35 mm (0.25 in)
Piston force	158 kg (347 lb)	158 kg (347 lb)
Spring rate	33 kg/cm (186 lb/in)	33 kg/cm (186 lb/in)
Spring load-brake on	91.2 kg (201 lb)	91.2 kg (201 lb)
Spring load-brake off	107 kg (236 lb)	107 kg (236 lb)
Brake band width	15.9 mm (0.625 in)	15.9 mm (0.625 in)
Brake band contact area	144.2 cm ² (22.35 in ²)	217.4 cm ² (33.7 in ²)

Hydraulics

- Pump—pressure balanced gear type
 - driven from reverse gear in range box
 - minimum oil flow 2.76 litre/min (0.6 gal/min) at 300 r/min and 7.03 kg/cm² (100 lb/in²)
 - maximum pump speed 2400 r/min
 - delivery at maximum revs, minimum of 21.8 litre/min
- Control Valve—four position spool valve
 - oil by-passed from planetary unit and brakes is used for lubrication of planetary units.

Range Gearbox

- Constant mesh gears
- Three forward, one reverse range

DATA

Settings

Pinion shaft bearing movement	0 ± 0.050 mm (0.002 in)
Crown wheel teeth backlash	0.18 to 0.23 mm (0.007 to 0.009 in)
Differential bearing side movement	0 to 0.050 mm (0.002 in)
Top shaft bearing movement	0.01 to 0.05 mm (0.002 to 0.004 in)
Layshaft bearing movement	0.01 to 0.05 mm (0.002 to 0.004 in)
Pinion shaft setting distance	160.337 mm (6.3125 in)

Tightening Torques

	Nm	Kg m	lb ft
Brake band cylinder bolts, $\frac{5}{8}$ in	27	2.75	20
Brake band locking plate bolts, $\frac{1}{2}$ in	12	1.25	9
Clutch cover to main frame bolts, $\frac{1}{2}$ in	102	10.5	75
Clutch cylinder to planet carrier bolt, $\frac{5}{8}$ in	27	2.75	20
Differential ring nut locking plate bolts, $\frac{5}{8}$ in	27	2.75	20
Transmission pump to connection bolts, $\frac{5}{8}$ in	27	2.75	20
Differential cap bolts, $\frac{5}{8}$ in	163	16.5	120
Free-wheel housing bolts (second reduction) $\frac{3}{8}$ in	41	4.0	30
Front end plate nuts, $\frac{1}{2}$ in	102	10.5	75
Gearbox cover to main frame bolts, $\frac{1}{2}$ in	102	10.5	75
Gearbox mounting bolts, $\frac{5}{8}$ in	136	13.75	100
Pinion bearing support plate bolts, $\frac{3}{8}$ in	41	4.0	30
Pinion nut, $1\frac{1}{8}$ in	271	27.5	200
Planet carrier end cover bolts, $\frac{3}{8}$ in	41	4.0	30
Range unit end plate bolt, $\frac{3}{8}$ in	41	4.0	30
Rear axle case to main frame bolts, $\frac{1}{2}$ in	102	10.5	75
Rear wheel nuts, $\frac{5}{8}$ in	163	16.5	120
Reduction units to axle case bolts, $\frac{1}{2}$ in	102	10.5	75
Support sleeve cap bolts, $\frac{1}{2}$ in	12	1.25	9
Support snout bolts, $\frac{1}{2}$ in	12	1.25	9

David Brown®

Service Repair Manual

1200 & 1210 4WD Mk 1 (Kramer) Tractors

Section C6 (Pub. 9-37171) January 1976



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

© Published by David Brown Tractors Ltd.

Printed in England

REMOVING THE TRANSFER BOX

1200 and 1210 Tractors

1. Drain the transmission oil
2. Remove the gearbox top
3. Remove the muff coupling bolt
4. Slide the muff coupling (Part No. 1-02410-0026 1200 tractors
1-02410-0126 1210 tractors) completely onto the gearbox pinion shaft.
5. Disconnect driveshaft (transfer box to front axle) at transfer box.
6. Remove the transfer box securing bolts and then lower the transfer box from the main frame.

DISMANTLING TRANSFER BOX - FIGURE 1

Note: No gaskets are used on Kramer units. The following compounds are used for sealing purposes:-

- a) Terosan spline sealing and jointing compound (spline seal)
- b) Terolan 2105 rubber jointing compound (joint seal)

Operations

1. Remove lower cover (2)
2. Clean magnetic filter (3) in drain plug
3. Position the transfer box with the drive flange upwards on the bench
4. Remove drive flange retaining plate (36)
5. Remove drive flange (35) from drive shaft using two legged puller (see page 31 for special tools)
6. Remove cap screws (40) holding oil seal housing to transfer box
7. Bolt the driveshaft withdrawal plate (see page 31 for special tools) to the end of driveshaft (29) (This secures the driveshaft (29) to the oil seal housing (39)).
8. Remove oil seal housing (39) complete with circlip (31) bearing (30) washer (33) and driveshaft (29) by jacking the oil seal housing, etc., from the transfer box case using the two jacking bolts (M10 x 60) which should be positioned in the threaded holes in the oil seal housing.

This method of removal ensures that the bearing is withdrawn with the shaft. If the oil seal housing is withdrawn on its own the bearing will be left in the casing and will be more difficult to remove. The same procedure should be used when it is only necessary to replace the flange oil seal (34).

9. Remove needle roller bearings (32) from the driven shaft (16)
10. Drive selector fork spring pin (26) through the selector fork into a hole in the transfer box casing.
11. Remove the selector shaft (25) out through the oil seal (28) in the side of the transfer box casing, support the selector fork when doing so.
12. Remove the selector fork (23) complete with shoes (24)
13. Remove the sliding coupling (22)
14. Remove the spring pin (26) from the hole in casing

Note: Front bearing has a circlip
Centre bearing has no circlip
Rear bearing has a circlip

} same dimensions

15. Remove circlip (20) support ring (19) from the inner end of driven shaft (16)
16. Remove selector shaft oil seal (28) if damaged
17. Remove split flange from inner race of bearing (17)




Figure 1

18. Place the assembly on its side and remove cover plate (42)
19. Position the transfer box with the front (drive flange end) upwards

Note: The pinion shaft is longer on 1210 tractors and therefore the muff coupling is shorter.

20. Support the bottom of the casting and then press out the driven shaft (16)
21. Remove circlip (20) support ring (19) circlip (21) and bearing (18) from the rear end of the driven shaft (16) if required.
22. Turn the transfer box over and fit inner race of bearing (17) back into position to get sufficient clearance to remove gear (15) downwards.
23. Remove bearing (17) from the housing.
24. Remove intermediate shaft circlip (13)
25. Turn the transfer box over, support the casting and then press out the intermediate shaft (12)

Note: The intermediate gear is now loose inside the transfer box but cannot be removed yet.

26. Remove the two large circlips (9) from pinion shaft (7)
27. Press out the pinion shaft (7)
One bearing (8) will remain in the housing but can now be removed. It is important not to mix the bearings (8) and their inner races. The inner races can be removed from the shaft using a small drift between the pinion teeth.
28. Turn the assembly upside down and remove the intermediate gear (10) bearings (11) and washer (14)
29. Clean all parts in diesel or paraffin etc.
30. Replace any worn or damaged parts

ASSEMBLING THE TRANSFER BOX

1. Refit the inner race of rear bearing (18) to the driven shaft (16) bearing race should be tight to splines. Fit bearing (18) on the inner race with the circlip (21) to the outside.
2. Refit inner race split flange, support ring (19) and circlip (20) to the driven shaft (16)
3. Place the housing rear upwards
4. Insert large gear (15) and support it with 2 x $\frac{1}{2}$ in bars
5. Press in driven shaft (16) complete with bearing, support ring and circlip
6. Turn the assembly over (front upwards)
7. Support the end of the driven shaft (16) and then press on inner race of centre bearing (17) (Flange towards gear)
8. Fit centre bearing (17) onto inner race
9. Refit inner race split flange, support ring (19) and circlip (20)


Note: Check gear and shaft spin freely

10. Refit the cover plate (42) using rubber jointing compound (no gaskets)

REPLACING SELECTOR ASSEMBLY

11. Replace selector shaft oil seal (28) using a jointing compound (not rubber)
12. Replace cup seal (27) if it has been removed
13. Refit sliding coupling (22) flange down onto driven shaft (16)
14. Replace selector fork shoes (24) to selector fork (23). Grease will hold them in place.
15. Replace selector fork (23) on sliding coupling
16. Refit selector shaft (25) aligning the holes in the shaft and selector fork

Figure 1
6



17. Replace spring pin (26)
18. Check operation of selector

REPLACING FRONT DRIVE FLANGE

19. Fit a new seal (34) into housing - using jointing compound (seal to be flush with outer edge of housing)
20. Refit oil seal housing (39) complete with seal onto the flange (35)
21. Refit bearing (30) onto flange (35) with the circlip (31) in the recess in the oil seal housing.
22. Replace washer (33) onto driveshaft (29)
23. Refit driveshaft (29) into flange (35) using jointing compound (not rubber) sparingly under retainer plate (36) - compound will run down splines.

Note: Allow 10 minutes for the compound to set.

24. Refit plate (36) and retaining bolts (37) torque 80 lbs ft (11 Kgm)
The flange holding tool shown on page 30. can be used for this operation
25. Refit locking wire (38)
26. Clean off excess jointing compound from the gear teeth
27. Replace the needle bearing (32) into the recess in the driven shaft (16)
28. Replace the flange assembly into the transfer housing using a rubber jointing compound
29. Ensure drive shaft (29) is located in the bearing (32) before cap screws (40) are used to pull together the oil seal housing (39) and transfer box housing (1). Tap the end of driveshaft (29) occasionally to make assembly easier.
30. Torque the cap screws (40) to 34 lbs ft (4.7 Kgm)

REPLACEMENT OF INTERGEAR

31. Place the assembly on its side (drive flange upwards)
32. With the intermediate gear opposite the top bearing bore replace one bearing (11) followed by washer (14) and second bearing (11) into the intermediate gear.

Note: Washer (14) to be held in place by grease

33. Lubricate shaft (12) and drive into housing
34. Replace circlip (13)
35. Check tooth engagement and freedom of spin.

REPLACEMENT OF PINION SHAFT ASSEMBLY

36. Replace inner races of bearings (8) on the pinion shaft (7) with shoulders to gear.
37. Fit the outer race of one bearing (8) halfway into the housing.
38. Position the pinion shaft onto the intermediate gear (spline to rear) and tap the bearing fully home.
39. Fit second circlip (9)
40. Check the pinion shaft has a slight end float by tapping backward and forward.
41. Check that all gears are free to rotate.
42. Check that selector operates correctly.
43. Check that the magnet and plug (3) are clean and then fit into the lower cover (2)
44. Replace lower cover (2) using a rubber jointing compound on both faces.

8

REMOVAL AND DISMANTLING OF DIFFERENTIAL - FIGURE 2

1. Apply the hand brake
2. Jack up the front axle
3. Remove right-hand front wheel
4. Remove prop shaft (transfer box to front axle)
5. Remove track rod (right-hand end)
6. Drain differential oil
7. Remove short axle case complete with final drive assembly (right-hand)
8. Remove differential assembly from large axle case (left-hand)

TO REMOVE SPIRAL GEAR (CROWN WHEEL)

9. Remove front cover (57) after removing 12 bolts (58)
10. Loosen all spiral gear retaining screws (50) and bolts (46) approx. $1\frac{1}{2}$ turns
11. Loosen the bevel pinion shaft nut (33) after removing the split pin (34) This nut is torqued to 400 ft lbs (60 Kgm)

Note: Use a 1 13/16 AF (46mm) spanner and the special drive flange holding tool as shown on page 30.

12. Remove differential bearing adjuster wheel lock plates (53)
13. Remove differential bearing adjuster wheels (52) - mark left or right-hand side
14. Remove the bearing (51) facing the spiral gear (crown wheel 41) - Tap out progressively by turning the differential and using a drift on the inner race. The outer race should be a loose sliding fit in the differential housing.
15. Turn the assembly over until the side which contains the remaining bearing rests on the bench.
16. Drift the differential assembly down until the crown wheel locating bolts (46) come against the casing.
17. Remove allen screws (50) which hold the sleeve (48) to the spiral gear (41)
18. Lift out sleeve (48)
19. Remove thrust washer (43)
20. Tap the outer race of the remaining differential bearing (51) as far out as possible.
21. The differential assembly may now be removed (across corners)
22. Remove bolts (46)
23. Tap spiral gear off the register and locating dowels (47)
24. Remove differential wheel (35) followed by differential pin (39) two differential pinions (36) thrust plates (40) remaining differential wheel (35) and thrust washer (43)
25. Remove the remaining differential carrier bearing inner race (51) if necessary.

Note: Differential pinions have replaceable bushes (38)
Differential cage also has a replaceable bush (44)
Sleeve (48) has a replaceable bush (44)

BEVEL PINION REMOVAL

26. Remove the bevel pinion nut (33) 1 13/16 AF (46mm) spanner
27. Remove washer (32) and driver flange (30)

BEVEL PINION SETTING










Figure 3A - H

28. Stand the differential casing with the bevel pinion vertical
29. Tap the bevel pinion (2) down complete with large bearing inner race (10) sleeve (11) and distance piece (12-29)

Note: This will leave small bearings (9) oil seals (31) and large bearing outer race (10) in the housing.

30. Remove oil seal (31)
31. Remove inner race of bearing (9)
32. Remove remaining outer tracks from the casing if necessary.

BEVEL PINION SETTING - FIGURE 3

Example 1

Apex Distance

To obtain correct meshing between the bevel pinion and spiral gear the pinion shaft apex distance must be correct. Due to production tolerances the actual apex distance is affected by variations in the machining of the differential housing and of the bevel pinion.

Correction factors which take account of these variations are etched or stamped on the front face of the differential housing and on the end of the bevel pinion shaft.

Below is an example to show how these correction factors are used to obtain the correct thickness of shims to fit behind the head of the bevel pinion shaft to ensure correct meshing of the spiral gear (crown wheel) Refer to Figure 3 when reading this example.

Bevel Pinion Shaft

Nominal apex distance 'E' (Figure 3)	122.00mm
Correction factor (marked on pinion shaft) 'G' (Figure 3)	-0.30mm
Actual apex distance	121.70mm
Add bearing (10) depth(measured) 'F' (Figure 3)	45.50mm
Distance 'A'	167.20mm

Differential Housing

Nominal case depth 'A' (Figure 3)	168.50mm
Correction factor (marked on differential housing) 'C' (Figure 3)	+0.20mm
Actual case depth	168.70mm
Subtract distance 'A' (see above)	167.20mm
Shims required between bevel pinion (2) and bearing (10)	1.50mm

PINION SHAFT ENDFLOAT

Example 2

Pinion shaft end float is adjusted by special spacers (12-29) which are of different thicknesses.

The thickness of spaces required to give correct end float (no pre-load) depends on the actual dimensions of the bearings and of the differential housing. Various measurements can be taken of these components (see figure 4) and the actual spacer thickness required calculated as shown below in the following example.




Figure 4A-D

Measured distance from differential housing face to sleeve (11) (distance 'A' Figure 4)	49.60mm
Subtract distance from differential housing face to small bearing face (9) when assembled (distance 'B' Figure 4)	18.30mm
	<hr/>
	31.30mm
Subtract width of small bearing inner race (9) (measured distance 'C' Figure 4)	-27.00mm
	<hr/>
Width of special distance piece (12-29) to give no end float and no pre-load.	4.30mm
	<hr/>

REASSEMBLY AND ADJUSTMENT OF BEVEL PINION

1. Measure depth of bearing (10) - see figure 3.

Note: Differential housing and bevel pinion correction factors and calculate the thickness of shims required (figure 3)

2. Fit required number of shims (3/8) onto bevel pinion (2) as calculated (figure 3)
3. Fit inner roller race (10) onto top of the shims
4. Refit bevel pinion shaft (2) shims (3/8) and roller race (10) to casing (1)
5. Refit sleeve (11) chamfer down.
6. Support pinion shaft until differential casing does not rest on bench and measure 'A' (figure 4)
7. Remove pinion shaft from housing and fit inner race of bearing (9) measure 'B' (figure 4)
8. Remove inner race of bearing (9) and measure 'C' (figure 4) with bearing on a flat plate.
9. Calculate thickness of shims as in example 2 above.
10. Refit bevel pinion shaft complete with shims, bearing and sleeve into casing.
11. Support pinion shaft as in D (figure 4) and fit correct thickness of shims.

REBUILDING DIFFERENTIAL

1. Fit new bush (44) in differential cage if necessary
2. Refit inner race of bearing (51) to differential case if removed
3. Fit differential wheel (35) and thrust washer (43) into cage. Check for tight spots or too much float.
4. Fit new bushes (38) to differential pinions (36) if necessary.
5. Refit the differential pinions (36) pin (39) and thrust washers (40) (Check for bolt location)
6. Refit second differential wheel (35) and thrust washer (43)
7. Replace spiral gear (41) onto dowels (47) in cage (42) (either way)

Note: Ensure spiral gear is square on the register

8. Fit bolts (46)
9. Fit two spare bolts into spiral gear (crown wheel) - teeth side. The bolts should be opposite each other and protrude 1 $\frac{1}{2}$ to 2 inches. Hold these bolts in a vice to hold assembly rigid while tightening bolts (46). Torque bolts to 100ft lbs and (14kgm) and wire up.




Figure 2

10. Position the differential in the casing
11. Replace sleeve (48) and bolt to spiral gear using cap screws (50) and washers (49) torque to 50 lb ft. (7 kgm)
12. Replace differential bearing inner race (sleeve end)
13. Replace differential bearing (51) - below thread depth
14. Replace differential adjuster wheel (52) (sleeve end) - screw the adjuster flush with casing face.
15. Turn the assembly over and replace the second bearing (51)
16. Screw in the adjuster wheel (52) - one behind spiral gear to give no backlash.

Note: Spiral gear and bevel pinion are completely in mesh

17. Screw in the adjuster wheel (52) - sleeve end until 0.005 to 0.007 inch backlash is obtainable. When this amount of backlash has been achieved the correct pre-load will have been put on the differential bearings.
18. Refit locking plates (53) to adjuster wheels
19. Replace front cover (57)
20. Fill with correct grade of oil

FINAL DRIVE ASSEMBLY

There are two types of final drive assemblies Series I and II. The general layout of series I and II are similar. The main difference being the carrier housing which is a single casting on series II axle (3) Figure 5 but consists of two components on a series I axle (4) and (5) Figure 8. Only a small number of series one axles are fitted, all of which were on initial production 1200 tractors.


Dismantling on both axles is identical except for the removal of drive-shaft and pinion bearings.

REMOVAL AND REPLACEMENT OF FINAL DRIVE OIL SEAL (23) - Figure 5

1. Drain oil from final drive assembly
2. Remove capscrews (29) from carrier housing (3) and cover housing (22) - locked in pairs with wire.
3. Using six jacking screws 8mm, jack the cover housing (22) complete with final driveshaft (18) and perhaps inner bearing (28) off
4. Remove jacking bolts and inner bearing (28) if it has come away with the final driveshaft.
5. Check thread protrusion through locknut (27) on final driveshaft (18) - note for assembly.
6. Remove final driveshaft locknut (27) and tabwasher (26) - wheel studs (20) will require locking to prevent the shaft turning when removing the locknut (27)
- 6A. Count number of threads protruding.
7. Pull off reduction drum (21) using a special adapter, see page 30. if no adapter is available drop on the end of the shaft.
8. Remove circlips (25) if bearing (24) requires replacing.
9. Using 10mm jacking bolts jack the final driveshaft (18) from the cover housing (22)
10. Remove jacking bolts

Note: Wheel studs (20) are replaceable (knock-out - knock-in)

11. Remove final driveshaft bearing (24) and seal (23)



Series II Axle
Figure 5
16

Note: The seal is fitted as an oil seal not a dirt seal. A sealant should be used on the outside edge of the seal.

REASSEMBLY OF THE FINAL DRIVE

1. Replace bearing (24) and circlip (25) in housing (22)
2. Treat the seal (23) with sealant and refit up to the bearing (24)
3. Lubricate the seal lip and its location on the final drive shaft (18)
4. Place final driveshaft on its end and lower the cover housing (22) complete with bearing (24) circlip (25) and oil seal (23) onto the bearing location on the final driveshaft.
5. Position reduction drum (21) onto splines using the special adapter page 23 for lifting
6. Press or drift the reduction gear drum (21) onto the final drive-shaft (18) until the locknut threads appear.

Note: Tighten the locknut down until the correct number of threads protrude through the locknut (counted when dismantled) approximate check 5 threads.

7. Refit the tabwasher (26) and locknut (27)
8. Replace inner final drive bearing (28) onto shaft after checking the bearing.
9. Replace the final drive and reduction drum assembly to the carrier housing (3)

Note: Small boss on cover housing (22) must be fitted to the top, thus ensuring the oil drain for the final driveshaft outer bearing housing is at the bottom of the assembly.

10. The assembly will require driving on until cap screws (29) can be fitted.
11. Refit cap screws (29) which secure cover housing (22) to carrier housing (3)
12. Continue tapping the assembly as the cap screws are tightened.
13. Wire up the capscrews in pairs.

TO REPLACE DRIVESHAFT STEADY BEARING AND OIL SEALS LOCATED IN THE AXLE CASE - FIGURE 6

1. Remove bolts (38) from the swivel pin (39) and steering lever (33) - top and bottom. Right-hand reduction has two swivel pins.
2. Using special jacking screws 10mm, remove the steering lever (33) swivel pin (39) and shims.


Note: Shims must be kept with their own swivel pin. Do not mix the top and bottom swivel pins on the right-hand reduction, the left-hand reduction swivel pins are also different.

3. Remove the final drive reduction assembly complete with driveshaft.
4. Using the universal puller (page 29) remove outer oil seal (52)
5. Remove circlip (51)
6. Using the universal puller (page 29) remove needle bearing (50)

Note: Position of open end of needle bearing (innermost)

7. Using the universal puller (page 29) remove inner seal fitted as a dirt excluder (49) to allow excessive grease into the axle case.

Figure 6
18



ASSEMBLY PROCEDURE

1. Fit a new seal (49) as a dirt excluder to the bottom of the recess after first lubricating the bore.
2. Fit the needle bearing (50) up to the seal - open end to seal.
3. Refit circlip (51)
4. Refit outer seal (52) as an oil seal to keep the lubricant in the bearing.
5. Refit reduction assembly to the axle case.

Note: Replace swivel pins from where they were removed complete with their own shims.

6. If swivel pin taper bearings (54) are to be replaced, greaser seals, (53) complete with 'O' rings (55) will also require replacing.

SWIVEL PIN ADJUSTMENTS

If any of the following parts are to be replaced, axle case (46/47), steering lever (33), swivel pins (39), swivel bearings (54), and carrier housing (3), settings will be upset and will need to be recalculated.

Note: If new axle casings (46/47) are required then they should be fitted with new bearings (54) greaser seals (53) and 'O' rings (55)

Jacking bolts (page 29) are required for replacing swivel bearings.

TOP SWIVEL PIN ADJUSTMENT - FIGURE 7

1. Fit the outer race of the top bearing (54) to axle
2. Place inner bearing race on the outer race
3. Measure the distance from the top face of the inner race to the top face of the axle - figure 7a (4.5 - 5.0mm Nominally 4.6mm in example)
4. Fit grease seal (53) and 'O' ring (55)
5. Measure top swivel pin or steering lever shoulder depth - figure 7B (Nominally 36.5mm) - 36.5 in example

CALCULATION - FIGURE 7

Centre line of the axle to the top face of the axle fork - nominal 144.00mm (figure 7c)

Centre line of the carrier housing to the top face of the carrier housing - nominal 175.00mm (figure 7D)

Note: Carrier housing carries a dimension on the top face.



Axle fork top face also carries a dimension

These are correction factors, indicating how much individual parts vary from the nominal dimension.


	<u>AXLE FORK</u>	<u>CARRIER HOUSING</u>
Centre line to top face - nominal distance	144.00mm	175.00mm
Correction factor	+0.10mm	-0.20mm
Centre line to top face - actual distance	144.10mm	174.80mm

upper swivel pin

swivel pin adjustment




7D



7B


upper swivel pin
shoulder depth

7E




lower swivel pin
shoulder depth


nominal





7F



lower bearing depth



7A



lower swivel pin

Figures 7A-7F

AXLE FORKCARRIER HOUSING

Subtract upper bearing depth	4.60mm - figure 7a
	<hr/>
	139.50mm

Add swivel pin shoulder depth	36.50mm - figure 7b
	<hr/>
	176.00mm

Subtract the actual distance from the centre line to the top face of the carrier housing	174.80mm
	<hr/>
	1.20mm

Therefore 1.20mm thickness of shims (34-37) are required at the top swivel pin to centralise the reduction housing with the axle.

BOTTOM SWIVEL PIN - FIGURE 7

1. Fit the outer race of the bottom taper bearing (54) to the axle
2. Fit the inner race and grease seal (53) complete with 'O' ring (55)
3. Assemble the final drive assembly to the axle fork with the correct shims (34-37) at the top swivel pin.
4. Measure the lower swivel pin shoulder depth - figure 7e (nominally 36.5mm) - 36.5 in example
5. Measure the distance from the carrier housing face to the face of the bottom bearing inner race (lower bearing depth) - figure 7f (nominally 35.5mm:- 35.5 in example
6. Subtract the lower bearing depth - figure 7f from swivel pin shoulder depth - figure 7c.

Swivel pin shoulder depth	36.50mm
Lower bearing depth	-35.50mm
	<hr/>
Clearance	1.00mm

7. The bearings should have 0.2mm pre-load, therefore subtract 0.2mm from the above figure.


Clearance	1.00mm
Pre-load	0.20mm
	<hr/>
Shims required	0.80mm

8. Therefore 0.80mm thickness of shims (34-37) are required at the bottom swivel pin (39) to give the correct bearing pre-load.
9. Assemble the bottom swivel pin with the correct shims.

REMOVAL OF DRIVESHAFT AND PINION BEARINGS - Figure 5
SERIES II AXLE

1. Remove cap screws (36)
2. Remove carrier housing (29) complete with final driveshaft assembly using 8mm jacking screws.

FIGURE 6



3. Remove steering lever (33) or top swivel pin (39) - right-hand side
4. Remove bottom swivel pin (39)

Note: Do not mix swivel pins and shims

5. Remove carrier housing assembly complete with driveshaft from the axle.
6. Examine grease seals (53) and bearings (9)
7. Remove countersunk screw (8) from the end of the driveshaft assembly (1/2)

Note: The countersunk screw (8) is locked in position by punching the end of it with a centre punch. The punch mark will require removing by drilling. On reassembly a new thrust washer (7) and screw (8) will be required because the originals will be damaged while drilling.

8. Remove thrust washer (7) which is held in position by a spring dowel (9)
9. Remove spring dowel

Note: Thrust washer is only located on the inner bearing face.


10. Fit spare bolt in the end of the driveshaft assembly (1/2) - for jacking and drifting on.
11. The pinion gear (1) should be able to be turned but not fall out when the driveshaft is removed providing the pre-load of 0.20mm is correct.
12. Drift out the driveshaft (1/2)

Note: If driveshaft only requires replacing and pinion preload is correct no further dismantling is necessary. Additional shims can be added after removing circlip (45) on series II axles. For complete dismantling proceed as follows.

13. The pinion shaft (10) and distance piece (13) are now loose and can be removed.
14. Remove circlip (45)
15. Remove shims (17) distance piece (15) complete oil seal (16)
16. Remove taper bearing (14)

TO REASSEMBLE OF DRIVESHAFT AND PINION BEARINGS (Series II axle) Figure 5

1. Position carrier assembly with the driveshaft bore vertical. Final driveshaft side downhill.
2. Fit the outer race of bearing (11) into the carrier housing and then lay the inner race on top of it.
3. Place small distance piece (12) on top of inner race
4. Place pinion (10) on top of small distance piece
5. Place large distance piece (13) on top of pinion
6. Place inner race of bearing (14) on top of large distance piece (13)
7. Centralise bearings and pinion with special mandrel, see page 30.
8. Fit outer race over mandrel and drive fully home.
9. Fit distance piece (15) complete with oil seal (16) and shims to give 0.2mm preload.
10. Fit circlip (45) This will require tapping into position.
11. Withdraw mandrel



Series II Axle
Figure 5

Note: If pinion moves out of position more shims will be required.

12. Replace Driveshaft (1/2)
13. Pull into position using the driveshaft puller and 10mm bolt.
see page 22.
14. Replace tension pin, thrust washer and new countersunk screw.

REMOVAL OF PINION BEARINGS (Series I) Figure 8

1. Remove the reduction and final drive assembly - previously outlined.
2. Remove the countersunk screw (15) from the end of the driveshaft assembly (1/2)

Note: The countersunk screw (15) is locked in position by punching the end of it with a centre punch. The punch mark will require removing by drilling. On reassembly a new thrust washer (14) and screw (15) will be required because the originals will be damaged while drilling.

3. Remove thrust washer (14) which is held in position by a spring dowel (16)
4. Remove spring dowel (16)

Note: Thrust washer is only located on the inner bearing face

5. Fit a spare bolt in the end of the driveshaft assembly (1/2) - for jacking and drifting on.
6. Drift out the driveshaft (1/2)
7. If the driveshaft only requires replacing and the pinion preload is correct no further dismantling is necessary. For complete strip down proceed as follows. Pinion preload 0.20mm
8. Remove retaining bolts (7) and (12) bolts (12) are countersunk
9. Remove level plug (13)
10. Remove drain plug (51)
11. Remove drain pipe locating bolt (53)
12. Drive taper wedge between the carrier plate (5) and axle support (4)
13. Remove shims (24)

Note: Additional shims can be added at this stage and then assembled


14. Tap the pinion gear (17) out of location, support whilst taking out the centre bearing (18) inner race (21) small distance piece (19) and large distance piece (20)

Note: Position of distance pieces - large one to pinion gear (17)

15. Remove oil seal housing (22) complete with oil seal (23) by drifting out.
16. Remove outer bearing tracks.

Note: These bearings are not interchangeable. The narrow bearing with the largest quantity of rollers fits at the pinion gear (17) end.

Figure 8
Series I Axle
26



REPLACING THE HALFSHAFT AND PINION BEARING

1. Place the carrier plate with the pinion bore vertical. Final drive -shaft at the bottom.
2. Replace the outer race of bearing (18) and position the inner race in it.
3. Replace the smaller distance plate (19) on top of inner race.
4. Place the pinion gear on top of the distance piece (19)
5. Place distance piece (20) on top of pinion and inner race of bearing (21).
6. Centralise the bearings (18-21) and pinion gear using a mandrel (see page 30).
7. Replace the outer race of bearing (21).
8. Replace the oil seal housing (22) complete with oil seal (23)
9. Fit shims to give 0.20mm preload (approximately 0.8mm thickness of shims).
10. Connect the carrier plate (5) to axle support (4) Coat both faces with jointing compound.
11. Remove the mandril and check the pinion gear pre-load to see if correct.
12. Replace the driveshaft (1/2) pulling into position with special tool page 24.
13. Replace thrust washer (14) and spring dowel (16)
14. Replace countersunk screw (15) and lock using a centre punch.
15. Replace drain pipe (49)
16. Replace drain plug (51)
17. Replace carrier assembly to axle case
18. Replace reduction and final drive assembly to carrier housing.
19. Refill with correct grade of oil.




Figure 8
Series I, Axle
28

KRAMER AXLE TOOLS

The following represents 1 set of tools

JACKING BOLTS

<u>Quantity</u>	<u>Thread</u>	<u>Length</u>	<u>Specification</u>	<u>Tensile Strength</u>	<u>Type</u>
6	M10	60mm	Din 933	8G	Bolt
2	M10	60mm	Din 912	8G	Allen Screw
8	M8	100mm	Din 933	8G	Bolt

SPANNER

One No. 17mm Ring Spanner }
One No. 19mm Ring Spanner } on the same spanner

SOCKET

One 46mm (1 13/16 AF)

ALLEN KEYS

No. 3, 4, 6, 8 and 10mm

BEARING PULLER

One inner bearing type Kukku 21/7 Pat. No. 46/56

UNIVERSAL PULLER

0 to 6in diameters


SUPPORT BARS

Two 1/2in diameter or square section bars 12in long

MANDREL FOR RE-ASSEMBLY OF FINAL DRIVES


Total length of mandrel 8.35in (212mm)

Dimension	A	B	C	D	E	F	G	H	J	O
Inches	0.78	3.15	0.47	0.98	2.95	1.63	1.95	2.15	1.58	1.56
Millimeters	20	80	12	25	75	41.5	49.5	54.5	40	39.5




DRIVE FLANGE HOLDING TOOL

Dimension	A	B	C	D	E	F	G	H
Inches	12	2 x 0.13	1	0.25	0.38	4 P.C.D.	3	5
Millimeters	305	50.8 x 3.17	25.4	6.35	9.52	101.6	76.2	139.7



REDUCTION DRUM EXTRACTOR


Dimension	A	B	C
Inches	5.5	Machine { 3.688/3.676 } Thread M95 x 15	0.75
Millimeters	139.7	to { 93.68/93.38 }	19.05



FINAL DRIVE LOCKNUT SPANNER


Use with a $\frac{3}{4}$ x 24in (19 x 610mm) tommy bar

Dimension	A	B	C	D	E	F - Six Equally spaced lugs
Inches	5.5	4.38	0.75	3.23	0.19	0.375 x 0.375 square
Millimeters	140	111	19	82	4.76	9.52 x 9.52



TRANSFER BOX FLANGE AND DRIVESHAFT PULLER


Dimension	A	B	C	D	E
Inches	4	2	0.50	0.56	0.53
Millimeters	102	51	12.7	14.28	13.49



UNIVERSAL DRIVESHAFT PULLER FOR REDUCTION CASE

Use with a 4in (102mm) M10 x 1.5 bolt and nut

Dimensions	A	B	C	D
Inches	4	3	1	0.44
Millimeters	102	76	25.4	11.1



MAINTENANCE

Refer to illustration below for grease points, fill points and drain plugs. There is an additional grease point at each end of the track rod and three more on the cardan shaft; one on each universal joint and one to lubricate the splines of the sliding section.

FIRST 50 HOURS SERVICE

At the completion of the first 100 hours with a new machine, the oil from the front differential and both front hubs should be drained. Refill with new oil.

WEEKLY SERVICE

Apply grease to the six grease points on the front axle and the three on the cardan shaft, with a grease gun. One shot only should be given to the steady bearing greaser, A. Fig. 1. Check the oil levels in the front hubs and differential and top up if necessary.

500 HOUR SERVICE

Transfer Gearbox


The transfer gearbox is in the same sump as the main gearbox and filling is from the one plug in the gearbox cover. Draining is carried out from the plug under the transfer gearbox and also from the rear axle case.

The standard tractor instruction book should be consulted for details of servicing the full flow filter and oil changes on the gearbox.

1000 HOUR SERVICE (at least once a year)

Renew the oil in the front differential and both front hubs.

- A. Steady bearing greaser
- B. Steering pivot greaser
- C. Hub drain plug
- D. Hub level and filler plug
- E. Differential drain plug
- F. Differential level and drain plug



SERVICE NOTES

APPROVED LUBRICANTS

<u>Application</u>	<u>Grade</u>	<u>Approved Lubricant</u>	
Front differential and front hubs.	SAE 90	<u>AMOCO</u>	Amoco Gear Lubricant SAE 90
		<u>B.P.</u>	Gear Oil SAE 90
		<u>CASTROL</u>	Castrol ST or Agricastrol.
			Gear Oil Light
		<u>ESSO</u>	Gear Oil ST 90
		<u>MOBIL</u>	Mobilube C90
Grease points	2	<u>SHELL</u>	Dentax 90
		<u>AMOCO</u>	Amolith Grease 2
		<u>B.P.</u>	Energrease L2
		<u>CASTROL</u>	LM Grease
		<u>ESSO</u>	Beacon 2
		<u>MOBIL</u>	Mobilgrease MP
		<u>SHELL</u>	Retinax A

OIL CHANGING

Drain when the oil is warm. Clean off all the dirt from the plugs and grease points. Remove both the filter and drain plugs and allow a few minutes for all the oil to drain out.

Replace the drain plug and refill with oil until it just overflows. Replace the plug. After running the tractor for a short time (half an hour or so) check the level for settlement and top up if necessary.

CAPACITIES (Approx. refill)

Front hubs 3 pt (1.75 litre) each
Front differential - 6½ pt (3.8 litre)

TYRES

To prevent undue 'wind-up' between the front and rear axles the correct rolling radius of front and rear tyres should be maintained. The correct tyre pressures according to the loading of the tractor should be maintained. Water ballast may be used if required in the manner described in the basic tractor instruction book.

When it becomes necessary to replace tyres, the same size as originally fitted should be used. As the rolling radius differs for different makes of nominally the same size, it is preferable to replace with the same make of tyre. New tyres on one axle should not be mixed with worn tyres on the other.

TYRE PRESSURES

Road Work : front (10-24 6-ply rating) 26 lb/in² (1.82 kg/cm²)
(11-24 4-ply rating) 14 lb/in² (0.98 kg/cm²)
: rear 17 lb/in² (1.9 kg/cm²)


Field Work : front 12 lb/in² (0.84 kg/cm²)
: rear 12 lb/in² (0.84 kg/cm²)

With front loader : front (10-24 6-ply rating) 26 lb/in² (1.82 kg/cm²)
(11-24 4-ply rating) 14 lb/in² (0.98 kg/cm²)
: rear 12 lb/in² (0.84 kg/cm²)

TRACK WIDTH

It may appear that the front track width may be altered by changing the wheel centres round. This must not be done because the steering will be affected.

The front track is 66 in (1.70 m). The toe-in of the front track should be zero to 3/64 in (1.0 mm).



FINAL DRIVES


The 4-wheel drive is only fitted to tractors with 9/50 final drive ratios. This must not be altered otherwise the ratio between the front and rear axles will be wrong.

FRONT AXLE WEIGHT

Maximum recommended loading on the front axle is 7000 lb (3200 kg).

GEAR SELECTOR

Adjustment is provided on the gear linkage. When difficulty in gear selection occurs disconnect adjusting rod 'B' from lever 'A'. Move lever 'A' until it is midway between its two extremes. Move operating lever 'C' until it is midway between the two notches and then connect the two levers with the adjusting rod.



David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this book went to press.

Moreover, as David Brown products are offered in a variety of forms to cover a large number of markets and applications, this manual may contain details not applicable to the component undergoing repair.

PRINTED IN ENGLAND

David Brown®

Service Repair Manual

1210 4WD. Mk. II Tractors

Pub. 9-37172 February 1976



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



CONTENTS

	<i>Page</i>
Removing a final drive unit from front axle	3
Removing half-shaft bearing from axle case	3
Refitting half-shaft bearing	4
Refitting final drive unit to axle case	4
Replacement of final drive oil seals or half-shaft	6
Removing half-shaft from final drive carrier	7
Assembling a final drive unit	8
Fitting half-shaft into final drive carrier	9
Assembling final drive carrier to housing	10
Dismantling and re-assembly of differential	11
Removing pinion shaft from differential housing	13
Re-assembly of differential	13
Mounting pinion shaft in differential housing	15
Assembly of differential gears and crown wheel	16
Removing transfer box from tractor	17
Removing the output shaft	17
Removal of engagement mechanism	17
Removal of driven shaft with gear	17
Removal of intermediate gear	19
Removal of 22-teeth drive gear	19
Re-assembly of 22-teeth drive gear	19
Fitting the 25-teeth intermediate gear	19
Assembling driven shaft	19
Fitting the engagement mechanism	19
Re-assembling the output shaft	19
Fitting output shaft into housing	20
Fitting transfer box into tractor	20
Special Service Tools	21

Removal of a final drive unit from front axle

Secure tractor so that it cannot roll away. Loosen wheel nuts, jack up the relevant side of axle then remove wheel.

Remove covering for half shaft and disconnect track rod, also steering ram if left-hand side, from final drive unit. Drain oil from unit by removing the filler level plug and drain plug.

Remove tab washer and adjusting nut from underneath the king pin. Using the special tool (ref. 12) extract king pin (in three stages).

Thread in king pin lower end is M14 and pulling screw M14 x 90mm.

Withdraw final drive unit (with half-shaft) from axle case. (Take care not to damage the half-shaft bearings). Remove the 'O' ring, sealing ring, distance washer and bearing-inner race.

Unless it is to be renewed the king pin upper bearing can remain in the axle case fork.

Removal of half-shaft bearing from axle case

If necessary the half-shaft bearing in the axle case can be pulled out of the axle case with an internal puller after first removing the oil seal and circlip.




Figure E1
EXTRACTING KING PIN




Figure E2
REMOVING FINAL DRIVE




Figure E3
KING PIN BEARINGS



Figure E4
FITTING HALF-SHAFT BEARING



Figure E5
FITTING CIRCLIP



Figure E6
FITTING OIL SEAL

Refitting half-shaft bearing into front axle case

Using a hammer and special tool (ref. 13), drive needle bearing into the axle case sufficient to allow circlip to be inserted. Apply sealing compound to the outer surface of sealing ring and drive it into the axle case, using same tool as for bearing.

Refitting final drive unit to axle case

If the axle case, final drive housing, upper bearing

or distance piece have been renewed the following dimensional procedure must be followed. Otherwise the two parts of the half-shaft will not be in line and the shaft joint will be subjected to unnecessary wear.

During machining of the final drive housing and axle case plus or minus deviations from the reference dimension can occur, i.e. + deviations are added to the reference dimension – deviations are subtracted from the reference dimension.

These deviations from the reference dimensions are stamped in the axle case and final drive housing figure E7.




Figure E7
FINAL DRIVE AND AXLE CASE REFERENCE DIMENSIONS

The following dimensions should be noted before refitting a final drive unit to the axle case.

1. The reference dimension of the final drive housing is 107.00 mm.
2. The + or - deviation is to be added or subtracted. The deviation from reference dimension (for example + 0.10) is stamped in the upper part of the housing near the king pin bore. If there is no deviation, the stamping is "O".
3. The reference dimension of the axle case 72.90 mm.
4. The + or - deviation is to be added or subtracted. The deviation from reference dimension (for example - 0.10) is stamped on the upper part of the axle case bearing arm. If there is no deviation, the stamping is "O".
5. To calculate the required thickness of **distance ring**, the overall width of bearing to be fitted into in the upper part of the axle case must also be determined.

The standard bearing width is 25,6 mm but the width should be measured as deviations are possible.

The above measured or calculated dimensions 1 to 5 are necessary to determine the correct thickness of the distance ring fitted between the upper bearing and final drive housing.

Example 1 : Assuming no plus or minus deviations in the axle case or final drive housing, i.e. both are stamped with "O" and the bearing width is 25,60mm.

1. Reference dimension of final drive housing = 107.00mm
Plus or minus deviation (in this example no deviation) - 0.00mm

Gives dimension for final drive housing = 107.00mm
2. Reference dimension of axle case = 72.90mm
Plus or minus deviation (in this example no deviation) - 0.00mm

Gives dimension for axle case = 72.90mm

3. Final drive housing minus axle case (107.0 - 72.9) = 34,10mm
4. Minus bearing width - 25,60mm

5. Gives distance ring thickness of (34.10 - 25.60) = 8,50mm

Example II : Final drive housing stamped, +0,20 axle case stamped, -0,10: Upper bearing measures, 25,40mm

1. Reference dimension of final drive housing = 107,00mm
plus deviation + 0,20mm

gives dimension for final drive housing = 107,20mm
2. Reference dimension of axle case = 72,90mm
minus deviation - 0,10mm

gives dimension for axle case = 72,80mm
3. Final drive housing minus axle case 107,20 - 72,80 = 34,40mm
4. Minus bearing width - 25,40mm

5. gives distance ring thickness of = 9,00mm

When the distance ring thickness has been determined, outer race of bearing can be fitted into the axle case using the special tool (ref. 14) and a hammer.

Fit bearing inner race, distance ring, 'O' ring and sealing ring into the upper bearing seat using grease to hold them in position.

Now place the final drive housing (with half-shaft) in the axle case, taking care not to damage the half-shaft sealing ring.

Fit the king pin from underneath through the final drive housing and into the upper bearing. In order to avoid damage to the lower end of king pin, a safety screw (M14 x 30mm) should be screwed into the extraction hole. Remove screw after driving king pin into position.




Figure E8
FITTING UPPER BEARING



Figure E9
REFITTING FINAL DRIVE




Figure E10
FITTING KING PIN



Figure E11
FITTING SEALS



Figure E12
FITTING LOWER BEARING



Figure E13
FITTING ADJUSTING NUT

Fit sealing ring, 'O' ring and distance ring into the lower bearing seat with the special tool (ref. 15).

The bearing inner race is fitted to the lower part of the king pin, using the special tool (ref. 16) and the bearing outer race fitted using the special tool (ref. 15).

Smear the adjusting nut with oil, insert into the lower bearing arm and tighten until bearings have pre-load.

Pre-load approx 0,2mm—the final drive unit should turn when a torque of 3 kg metres (22 lb ft.) is applied.

Fit the tab washer to lock adjusting nut.

Refit half shaft cover, reconnect track rod and, if the left-hand side, steering cylinder to the final drive housing.

Fit oil drain plug and sealing ring. Fill to the level plug with an approved grade of oil.

Leave for some time and then re-check oil level. Capacity per final drive unit is about 1,60 litres. Apply grease to the grease fittings (final drive housing bearings, half-shaft). Fit front wheel. Lower tractor to ground.

Replacement of final drive oil seals or half-shaft

The final drive unit must first be removed from the axle case.

When the final drive unit has been removed, secure it in the clamp shown under ref. 1 in the special tools list.

Remove the 14 M10 setscrews which secure the final drive housing to the final drive carrier. Remove the plug from the upper face of the final drive housing.

If the plug thread in upper face of the final drive housing is M12 x 1.5, then a setscrew M12 x 1.5 x 90 should be screwed in to press out bearing (but not if the plug hole thread is 22 x 1.5).

In the final drive carrier are two M10 tapped holes into which two M10 x 60mm setscrews should be screwed.

If the plug hole thread is M12 x 1.5, the bearing is pressed off the half-shaft together with final drive shaft and gear by equal progressive turning of the three removal bolts. If the plug hole thread in the upper face of the final drive housing is M22 x 1.5 then a drift is inserted through the final drive shaft and into the plug hole until it is against the half shaft. By turning the two removal bolts equally and by tapping the drift, the bearing is removed from the half shaft and the final drive housing with final drive shaft and gear is removed from the final drive carrier.

Note: Bearing may bind during removal so the half shaft must be turned from time to time (at least three times) through one revolution. To do this it is necessary to remove the removal screw M12 x 1.5 or the drift (whichever is the case). The two M10 x 60 screws can be left in. Turn the half shaft one revolution and reinsert the M12 screw, or the drift, and continue removal.



Figure E14
FINAL DRIVE CARRIER EXTRACTION BOLTS

When the final drive housing has been pressed off, attach special tool ref. 10—clamp for half shaft. This protects the seal from damage.

Measure and note the distance between the locknut and the end of the final drive shaft.

The locknut (M62) on the final drive shaft is secured with a tab washer. Loosen the tab washer and using a "C" spanner (70-100mm width) and a tube extension, loosen the locknut. To do this, attach the final drive shaft by its wheel bolt side to a suitable clamp.



Figure E15
REMOVING FINAL DRIVE GEAR

In order that the gear can be pulled off the final drive shaft, there are two tapped holes with M16 thread in the gear, fasten special tool, ref. 2, to these holes. The gear can now be pulled off using a press against the central spigot. If a press is not available, heavy hammer blows may be applied, tighten up the pulling screws after each blow.

Now press the final drive housing off the final drive shaft. In the final drive shaft are two tapped holes with M10 thread. Screw two M10 x 100 setscrews into these two holes. By equal and progressive turns of these two bolts, tapping the final drive shaft between turns, the final drive housing can be pressed off the final drive shaft together with the parts fitted in it, i.e. circlip, bearing, and seal.

Remove the circlip fitted in the final drive housing. Insert special tool (ref. 5) from the outside inwards (through seal) against bearing and remove this bearing from the final drive housing. The seal can now be removed from the final drive housing, tapping it from the outside towards the inside.

Removal of half-shaft from final drive carrier

Unbolt the half-shaft clamp, which was attached after removal of the final drive housing, from the final drive carrier.

Drive the bearing far enough into the final drive carrier using special tool (ref. 9) to enable the split bush, fitted as a safety measure, to be taken out. Whilst doing this, hold the half-shaft firmly as support.

Using a soft hammer, drive the half-shaft out of bearing and out of the final drive carrier. Seal and the outer race of bearing can now be removed.



Figure E16
REMOVING FINAL DRIVE SHAFT



Figure E17
REMOVING SPLIT BUSH



Figure E18
REMOVING HALF-SHAFT

Assembly of final drive unit

Cleanliness is essential for successful assembly. After dismantling, thoroughly clean all the parts with flushing oil or paraffin. Before re-assembling, inspect all parts for wear or damage. Carefully smear all the parts to be assembled with oil.

Assemble the following parts into the final drive housing in the given sequence:

Seal, distance ring, bearing, circlip, half shaft bearing in upper final drive housing, final drive shaft, gear, tab washer and locknut.




Figure E19
FITTING AN OIL SEAL

Coat the outer side of seal with sealing compound. Using special tool (ref. 3), fit it into the final drive housing. Apply grease to the inside. Position distance ring and then fit bearing using special tool (ref. 6). Fit circlip.

Before the final drive shaft and gear are fitted, bearing of half-shaft in upper final drive housing must be fitted into the final drive housing using special tool (ref. 5).




Figure E20
FITTING FINAL DRIVE GEAR

Inspect the spline profile on the gear and final drive shaft and remove any burrs with a stone or file.

Heat the gear in an oven to 100°F—110°C, (not with an open flame). Place the final drive shaft with the wheel studs downwards and support it so that the wheel studs are not touching the bench. Apply oil to the splined sections. Place the pre-assembled final drive housing on the final drive shaft. Lead gear into the splines, place special tool ref. 4 on gear then press (or drive with a hammer) the gear, and final drive housing, on to the final drive shaft.



Figure E21
TIGHTENING THE GEAR RING NUT

Fit tab washer and locking nut and tighten with "C"-spanner. Check the distance from locknut to end of drive shaft; this should be the same as before dismantling.

With locking nut tightened, there should be about 3mm ($\frac{1}{8}$ in.) of final drive shaft thread exposed.

Secure locking nut by bending the tab washer into the grooves in the nut and the gear.




Figure E22
FITTING DRIVESHAFT BEARING

Assemble inner bearing on to final drive shaft.

Fitting half-shaft assembly into the final drive carrier

Smear seal on its outer face with jointing compound. Fit seal in the final drive carrier, using special tool ref. 7 and a hammer, or press. Smear inside of seal with grease.




Figure E23
FITTING HALF-SHAFT OIL SEAL

Attach final drive carrier to the clamp (ref. 1) and insert outer race of bearing with special tool (ref. 6).




Figure E24
FITTING BEARING OUTER RACE

Carefully enter the half-shaft upwards into carrier through seal then hold half-shaft in that position.




Figure E25
REPLACING HALF-SHAFT




Figure E26
FITTING HALF-SHAFT BEARING

Whilst holding half-shaft firmly, fit inner race of bearing on to shaft, using special tool (ref. 9).

Drive bearing far enough on to half-shaft to enable the split bush to be fitted with its flat side uppermost. Using a soft hammer, drive the half-shaft back until the gear sits well on to the split bush.



Figure E27
REPLACING SPLIT BUSH

Fit outer ring of bearing with special tool ref. 11 and smear with grease.



Figure E28
FITTING BEARING OUTER RING

To avoid damage to seal through movement of the half-shaft during subsequent assembly, place clamp (ref. 10) between half-shaft and final drive carrier and secure it in place.




Figure E29
FITTING HALF-SHAFT CLAMP

Assembling final drive carrier, with half-shaft, to final drive housing

The bearings of the half-shaft in the final drive unit must have 0,25mm pre-load and to establish the thickness of distance ring required it is necessary to make certain measurements.

1. Measure from the upper face of final drive housing to the inner race of bearing (fig. E30) Say this distance is 72,5mm, for example.



Figure E30
MEASURING FINAL DRIVE HOUSING

2. Next measure from the upper edge of gear teeth on half-shaft to the upper face of final drive carrier which, for example, we will say is 70,5mm, (fig. E31).



Figure E31
MEASURING HALF-SHAFT

Sample calculation of shim thickness

Measurement (1) above	72,5mm
less Measurement (2) above	- 70,5mm
<hr/>	
gives difference of	2,0mm
add pre-load (0,25mm)	+ 0,25mm
<hr/>	
This gives a distance ring thickness of	= 2,25mm

The distance ring, of correct thickness, should be smeared on one side with grease and placed with the greased side against bearing in the final drive housing, ensure that flat side of the ring is placed against bearing.



Figure E32
FITTING DISTANCE RING

Apply sealing compound to the faces of final drive housing and final drive carrier. Take final drive carrier out of the clamp and screw eyebolts into the two M10 tapped holes in carrier. Lift carrier with a suitable lifting device and lower it on to the final drive housing.



Figure E33
FITTING FINAL DRIVE CARRIER

It is important to ensure that the final drive shaft and half-shaft are inserted carefully into the bearings. The bearing is a push fit on the half-shaft and it is therefore, necessary to use a hammer and suitable drift to tap the half-shaft in.




Figure E34
FITTING HALF-SHAFT INTO BEARINGS



Figure E35
ASSEMBLING REDUCTION UNIT

Insert two diametrically opposite bolts and screw up half tight.

Secure final drive unit once more in the clamp.

Insert and tighten bolts round final drive carrier.

Take off the clamp from between half-shaft and final drive carrier. Turn the half-shaft by hand to check if unit has been properly assembled.

Insert and tighten level plug and oil drain plug.

Insert oil filler screw with sealing ring.

To mount final drive unit on to axle case, refer to page 4.

Dismantling and reassembly of differential

Attach the complete differential to clamp (ref. 17) in order to loosen the locknut on driving flange. Grip the clamp, with differential in it, in a vice and remove pin securing the pinion nut. Using a 46mm socket spanner loosen the nut about two turns.




Figure E36
REMOVING PINION NUT

Remove securing wire from the 12 setscrews attaching crown wheel to differential cage. Loosen the screws about two turns. For further dismantling remove differential from clamp and lay it on bench.

Remove setscrews and tabwashers locking bearing adjusters to sides of differential housing. Screw out adjusting nuts from both sides of housing.

Remove bearing, which is on opposite side to crown wheel and carries the differential in the housing from inside towards the outside. To do this use a suitable drift (350mm long, tapered from 10mm dia. at one end to about 15-20mm dia at the other). Place the drift against the bearing inner race and strike with a hammer to push bearing out.



Figure E37
REMOVING RIGHT-HAND BEARING

Stand differential unit on bench with cage end-plate downwards. The differential cage is now uppermost. Place special tool (ref. 26) on the differential cage, revealed by the removal of bearing. Using a hammer, drive cage downwards until setscrews in end-plate touch wall of differential housing. The other side bearing is thus driven out.



Figure E38
REMOVING LEFT-HAND BEARING



Figure E39
REMOVING DIFFERENTIAL ASSEMBLY

The differential can now be taken out of the differential housing.

Take out the 12 setscrews which secure crown wheel and end-plate to differential cage. The end plate can now be removed. In the differential cage are two tapped holes (thread M10) into which 2 extractor screws (M10 x 60) are screwed. By evenly tightening the screws, the crown wheel can be pushed off the differential cage.



Figure E40
REMOVING CROWN WHEEL

The differential pin is removed, the planet assemblies taken out and the pinion fitted in the differential cage removed with its thrust washer.

Removal of pinion shaft from differential housing

Remove the loosened nut and take off the washer. The flange can now be pulled off using a suitable extractor.




Figure E41
REMOVING PINION FLANGE




Figure E42
REMOVING PINION

The pinion shaft can now be driven out downwards using a hammer and drift.

Take the shim and the distance piece off the pinion shaft.

Remove the inner race of bearing from the pinion shaft.

The seal is now removed from the differential housing and then the inner race of bearing taken out. Remove outer race of bearing with shim from differential housing.

Re-assembly of differential

Cleanliness is necessary for successful re-assembly of a differential. All parts should be thoroughly cleaned with flushing oil or paraffin.

Before reassembly the parts should be checked for wear and damage. It is a mistake to reassemble parts which are not completely free from defects.

When reassembling, all parts should be smeared with clean oil.

IMPORTANT

Crown wheel and pinion must only be renewed in pairs.

The parts are identified with inspection numbers; pinion and crown wheel bear the same number.

The lapping mark (variation or tolerance) of the bevel pinion is etched on the front of pinion should also correspond to that on the crown wheel.

Pinion setting

If a new pinion, or pinion bearings, are being fitted it will be necessary to fit the appropriate shim behind the pinion inner bearing, so that the correct pinion setting is maintained. This ensures that the crown wheel and pinion teeth are then in correct mesh.

To calculate the thickness of shim required:

1. Note the housing setting dimension, this is 158,00mm.
2. Check what deviation was made during machining the differential housing. This is marked on the flange face of housing; plus dimensions should be added to the setting dimension and minus dimensions subtracted. If there is no deviation the face is marked "O,O."



Figure E43
DIFFERENTIAL HOUSING DEVIATION

3. Note the pinion setting dimensions, this is 124,70mm.
4. Check what deviation was made during machining of pinion. This is marked on the pinion face, and also on crown wheel; plus dimensions should be added to the setting dimension and minus dimensions subtracted. If there is no deviation the marking is "O,O."




Figure E44
DIFFERENTIAL PINION DEVIATION

5. Measure the width of the pinion inner bearing. The standard width of bearing is 29,25mm but bearing must be measured as deviations up to 0,5mm are possible.

6. Calculate the thickness of shim by comparing measurements 3, 4 and 5 with measurements 1 and 2 as in the following example.

The shim is fitted **behind** the inner bearing.

Example 1

Differential housing and pinion shaft are, in this example, without + or - deviations, i.e. they are marked "0".

Setting dimension of differential housing (no + or - deviation)	158.00mm
Minus setting dimension of pinion shaft (no + or - deviation)	- 124.70mm

Gives a difference; housing to pinion shaft of	= 33.30mm
Minus width of bearing (standard width)	- 29.25mm

Gives a shim thickness of	= 4.05mm
---------------------------	----------

Example 2

For this example, the differential housing is marked with +0,20.

The pinion shaft is marked with -0,10.

The bearing K951832 is its standard width = 29,25mm

To the given setting dimension of the differential housing	= 158,00mm
add the deviation +0,20	+ 0,20mm
This gives a dimension for the differential housing of	= 158,20mm

From the given setting dimension of the pinion shaft	= 124,70mm
subtract the deviation -0,10mm	- 0,10mm
This gives a dimension for the pinion shaft of	= 124,60mm

giving a distance between differential housing and pinion shaft of	= 33,60mm
From this distance subtract the width of bearing to obtain the required shim thickness of	- 29,25mm
	= 4,35mm




Figure E45
SECTION THROUGH DIFFERENTIAL

Mounting pinion shaft in differential housing

After calculating the shim thickness for the correct setting of the spiral bevel gears, the fitting of the pinion shaft bearings can be commenced.

The two pinion bearings must be assembled without pre-load or end float and it is, therefore necessary to calculate the thickness of shim required to obtain this setting when the pinion flange nut is fully tightened.

Firstly the width of the second (outer) pinion shaft bearing must be measured. The standard width is 25,00mm but bearings can have deviations of up to 0,5mm. Measure the width of the bearing inner track only, not the overall width as measured on previous bearing. Note this measurement as it is necessary for determining the thickness of shim required.



Figure E46
MEASURING PINION BEARING

Mount inner race of bearing on pinion shaft behind the gear teeth, using special tool (ref. 27).

Place the pinion setting shim, of thickness previously determined, on the seat area for outer race of bearing in the differential housing. Press on bearing outer race, ensuring that shim and bearing outer race sit firmly on seat.

Press outer race of bearing into coupling flange side of differential housing as far as the seat area, using special tools (ref. 26 and 28).

Place pinion shaft, with bearing inner race—from underside of the differential—into the differential housing.

Next, lay the differential housing, with pinion shaft in it, on to the front face of the pinion shaft, a suitable support being placed under the pinion. Fit distance sleeve against inner bearing, then fit outer bearing through neck of differential housing.

To determine the thickness of shim required between distance sleeve and bearing, the distance from the end of the differential housing to the distance sleeve must first be measured.




Figure E47
MEASURING TO FACE OF DISTANCE SLEEVE

In this example, a distance of 49,60mm is measured.

Take the pinion shaft out of the differential housing and fit the inner race of bearing into its outer race already pressed into the differential housing.

Now measure the distance from end of differential housing to bearing.

In this example a distance of 18,20mm is measured.




Figure E48
MEASURING TO FACE OF PINION BEARINGS

The width of the bearing inner race is in this example 25,00mm as already measured at the commencement of the reassembly.

The measurements described above must be made in every case. The values given here are only examples and cannot be used in practice.

The measurements are used in the following calculation to determine the correct thickness of shim to fit between distance sleeve and bearing.

Measurement from end of differential housing to distance sleeve— in this example	49,60mm
---	---------

Subtract the distance—end of differential housing to bearing in this example	18,20mm
---	---------

giving a distance of	31,40mm
----------------------	---------

From this result, subtract the width of bearing inner track in this example	- 25,00mm
---	-----------

giving the remaining distance between distance sleeve and bearing—i.e. the thickness of the shim required to give no pre-load and no clearance	= 6,40mm
--	----------

The pinion, with bearing inner race fitted to it, can now be replaced in the differential housing.

Place differential housing, containing pinion shaft, on a suitable support placed under face of pinion.

Fit distance sleeve and bearing setting shim, of calculated thickness, on pinion shaft. Fit the inner race of bearing on pinion shaft in the neck of differential housing, using special tool (ref. 29) and—if necessary—a hydraulic press.

To check the bearing adjustment,—i.e. to check that the calculated shim thickness is correct, fit the drive shaft coupling, nut and washer and firmly tighten nut. To do this use special clamp (ref. 17) for pulling on the flange and the nut.

If an hydraulic press is available, place differential housing, with pinion shaft, supported under the press in such a manner that the flange can be pressed against inner race of bearing instead of using the locknut and washer. (When using the press, pinion shaft should be so supported that the differential housing can be turned and special tool (ref. 29) used to press against driving flange.)

The pinion shaft, whether fully assembled with flange, washer and nut or held under the press, must not bind. The bearings must have no play, when flange has been assembled and pinion shaft should be able to be turned by hand.

If the adjustment is too tight or too slack, the shim (between distance sleeve and bearing) must be replaced by a thicker or thinner one, as required.

When bearing setting is correct, remove driving flange and fit seal into the differential housing after smearing outside of seal with sealing compound: use special tool to press seal into position and smear lips with grease.

Before fitting drive shaft coupling flange, apply sealing compound to the front face (the face next to the bearing). Press flange on to pinion shaft, using special tool (ref. 29).

Replace nut and washer. Use clamp (ref. 17) to hold flange and after fully tightening nut, secure with split pin.

Assembly of differential gears and crown wheel

The bushes which support the gears can be pressed into the differential cage and end-plate, using special tool (ref. 31).

Smear the thrust washers with oil then fit these on the gears before placing one gear in cage and the other in the end-plate. Fit pinions and thrust washers in cage then fit pin through cage and pinions. Locate pin with dowel pin then, whilst holding gear from falling out, turn end-plate over and fit on cage.

To fit the crown wheel, hold cage and end-plate together then turn them over so that end-plate is on bench and the long boss of cage is pointing upwards. Fit dowel pins into crown wheel bores then warm crown wheel in an oven (**not with an open flame**) to 120°C before fitting it in position on cage: if no oven is available, carefully tap the crown wheel into position with a soft-faced hammer.

Replace the 12 setscrews with spring washers, and tighten evenly to 20,5 kg metres (145 lb ft). Tap the crown wheel whilst tightening and when screws are fully tightened, check that crown wheel is fully seated all the way round.

Place the differential assembly in the differential housing, positioned so that crown wheel will be on right-hand side of pinion when unit is installed on tractor. Lay the whole unit (housing and differential) on bench, sideways so that long boss of differential cage is pointing upwards.

Drive inner track of bearing on to diff. cage, using special tool (ref. 30) and outer track into diff. housing, with tool (ref. 20), until the adjusting nut thread is fully exposed.




Figure E49
FITTING DIFFERENTIAL BEARINGS

Screw bearing adjusting nut in position until about two threads are showing proud of diff. housing then turn assembly over and fit the other side bearing in the same manner.

Attach differential to special tool (ref. 17) and clamp in vice then tighten crown wheel setscrews to 20,5 kg metres (145 lb ft.) before securing with wire.




Figure E50

TIGHTENING CROWN WHEEL BOLTS

To adjust differential side bearings remove clamp from pinion then hold diff. housing in vice. Turn bearing adjuster on crown wheel side inwards until crown wheel tooth backlash is 0,15 to 0,18mm and tighten adjuster on other side until bearings have no free-play but not more than 0.2mm pre-load.

First check the bearing setting, then the tooth backlash and finally the tooth contact marking.

Check that the side bearings have no free-play then check that pinion and crown wheel can be turned quite freely. If pinion is considerably harder to turn than it was before the differential was fitted the bearings have excessive pre-load.

Mount a dial gauge at right-angles to a crown wheel tooth then, whilst holding pinion stationary, move crown wheel and observe gauge reading; this should be 0.15 - 0.18mm.

Smear a few crown wheel teeth with marking compound and turn these against pinion until a clean contact marking is obtained. If the contact mark is not in the middle of the tooth and towards the inner end, a mistake has occurred when calculating the thickness of the pinion meshing shim fitted behind bearing K951832.

Secure bearing adjusters with tabwashers and setscrews.

Removal of transfer box from tractor

Drain the transmission oil (capacity approx 41 litres (9 gal) and disconnect engagement lever.

Remove gearbox top to gain access to coupling. Remove bolt from coupling then slide coupling rearwards on to pinion and clear of transfer box. Disconnect driveshaft from output flange and place a jack under transfer box. Remove bolts attaching transfer box to main frame then lower box from tractor.

Removing the output shaft

Lay transfer box upside down on the bench and remove base plate.

Fasten clamp (ref. 17) to output shaft flange and grip the clamp in a vice. Remove securing wire from the two setscrews and remove these from flange.

Remove locking washer. Take transfer box out of clamp and lay it once more upside down on bench. Withdraw flange with a suitable puller.

Remove the six cap screws securing front cover to box case.

In the pitch circle of these screws are two tapped holes and into these holes screw two extraction screws (thread M10 x 100mm).

Lay clamp (ref. 18) across front cover and insert two setscrews through clamp and into output shaft.

By equally tightening the two setscrews in the front cover, output shaft can be withdrawn from transfer box housing together with the following; seal (fitted in front cover), front cover and bearing with circlip.

Remove seal from front cover.

The needle roller bearing which carries the front output shaft is fitted inside driven shaft and can now be removed.

Removal of engagement mechanism

To remove engagement mechanism, remove pin which holds the selector fork on selector shaft, using a drift (8mm dia) inserted through hole in front of case and driving pin rearwards.

Selector shaft can then be pulled sideways out of fork and housing. The sliding dog clutch can be removed through the bore for the front cover. Take selector pins out of selector fork and remove fork from the bottom of housing. Remove selector shaft oil seal from case.

Removal of driven shaft with gear

Remove circlip from driven shaft. The thin spacer behind circlip can then be removed.

Lay transfer box on its front and take off rear cover after removing the eight setscrews.

Return transfer box to its upside down position.

Place special tool (ref. 19) on output shaft (front-flange end) and, using either a press or a hammer, remove shaft by pushing it rearwards out of housing.

If gear cannot be removed from underside of transfer box housing, turn housing through 180° and drive the front main shaft bearing—still fitted in housing—sufficiently far towards the front to allow to be taken out.

Return transfer box back to its upside down position.

Front bearing can now be removed with special tool (ref. 20) driving it from front towards the rear.

Remove circlip and extract rear bearing with a suitable puller.




Figure E51
SECTION THROUGH TRANSFER GEARBOX

Removal of the Intermediate gear

Remove circlip from the transfer housing. Intermediate shaft can be pressed out using a suitable drift and a press. This frees the intermediate gear which can then be removed from the underside. Pull off roller bearing, which will remain on the shaft, using a suitable puller, or press.

The other bearing which remains in the housing can be removed with a hammer and a suitable drift.

Removal of 22-teeth drive gear

Place transfer box with its lower face on the bench. Remove circlips on either side of bearings which carry the drive gear. Using special tool ref. 22 remove the two bearings and the gear from the housing, driving them from the front towards the back.

Reassembly

All parts should be carefully washed in flushing oil or paraffin.

Inspect the parts for wear or damage. Smear all parts with oil during assembly.

Reassembly of 22-teeth drive gear

Place transfer box with its lower face on the bench. Press bearings on to the gear and fit circlip in the front bearing bore. The gear, with both bearings fitted, can now be pressed or driven with a soft hammer into housing far enough to enable circlip to be fitted behind bearing. By gently tapping, the bearing inner races any tension in the bearings which may have been caused in the reassembly can be relieved.

Fitting the 25-teeth intermediate gear

Place transfer box with its rear on the bench and place a suitable support under the intermediate gear bore so that the housing lies horizontally.

Press an inner race of one of the roller bearings on to the intermediate shaft in such a manner that the side of the bearing is against the shoulder of the shaft. Keep outer race handy so that it can later be fitted on to inner race.

Heat up the intermediate gear to 120°–150°C in an oven (not in an open flame) and insert it into the housing from the bottom with the long boss of the gear pointing upwards (forwards, towards the flange side).

The intermediate shaft can now easily be fitted into the warmed-up gear using a soft hammer. Care should be taken to ensure that the inner race sits correctly on boss of intermediate gear. The outer race is now driven into the housing sufficiently far to allow circlip to be fitted. Now turn the transfer box housing through 180° so that the flange side (front) is at the bottom.

Drive the second inner race of roller bearing on to the intermediate shaft using a hammer and suitable drift. Using special tool (ref. 21) fit the remaining outer race followed by circlip.

Any tension in the bearings which may have resulted during assembly can be relieved by gently tapping the inner races with a soft-faced hammer. Check that intermediate gear turns freely by hand.

Assembly of driven shaft with 40-teeth gear in transfer box housing

Press rear main shaft bearing with circlip on to driven shaft at the **opposite end** to the splines. Fit spacer and circlip.

Place transfer box housing with its front on bench. Support housing so that it is horizontal. Insert the 40-teeth gear into housing.

Insert driven shaft through bore in rear face of the housing—now facing upwards—until bearing on shaft touches the gear. To do this, a hydraulic or hand press can be used. If neither is available, use a soft hammer.

The second bearing is now pressed on to the shaft from the front using special tool and a press or soft hammer. Fit spacer and circlip.

Strike the shaft gently on both ends with a soft-faced hammer whilst turning the gear to relieve any tension which may have been caused in the bearings during assembly.

Apply sealing compound to the rear cover and housing face, or renew gasket, attach cover with the eight bolts and spring washers.

Fitting the engagement mechanism

Place transfer box housing with front face uppermost, supporting it so that it lies horizontally.

Apply sealing compound to outside of seal and fit it into the selector shaft bore using special tool (ref. 23).

Slide dog clutch on to splines of driven shaft, taking care to fit it with the shouldered side towards the gear.

Fit pins into selector fork, applying some grease, before fitting fork from the bottom into the dog clutch. Insert selector shaft through bore in housing and into the selector fork. Fasten the two together by inserting retaining pin. Applying sealing compound to core plug and insert plug with special tool (ref. 24) in selector shaft bore.

Reassembly of the output shaft

Fit seal in front cover after first applying sealing compound to outside of seal. Smear inside of seal with grease then fit cover on flange.

Fit circlip to bearing then press the bearing on flange—circlip towards flange and against front cover.

Put spacer on output shaft and press shaft into bearing and flange using special tool (ref. 25).

If end of output shaft is not sealed with an 'O' ring, apply sealing compound to this face of shaft and also to inner face of locking washer which fits on shaft to secure flange. Fit the two setscrews, tightening to 11 kg metres (80 lb ft). To tighten the two screws, use special clamp (ref. 17) and wire screws together, when tight.

Fitting output shaft assembly into housing

Place the transfer box housing with its rear face on bench; the front uppermost.

Fit needle roller bearing in the centre of shaft. Apply sealing compound to the front cover flange and the surface of housing then insert output shaft assembly into housing.

By gently tapping with a soft hammer on flange and turning the flange at the same time, drive output shaft assembly into housing far enough to allow the cap screws to be fitted through cover.

Tighten the screws equally, tapping the flange at the same time.

By turning the flange and operating the engaging mechanism, check that the assembled parts operate satisfactorily.

Clean base plate thoroughly with compressed air. Apply sealing compound to the surfaces of base plate and housing, or renew gasket, refit base plate, with the magnetic plug, and replace the 12 setscrews.

Fitting the transfer box into the tractor

With main frame and transfer box facings clean, and, if possible, using the original gasket, ensure that coupling is in position on tractor gearbox pinion shaft then lift transfer box into position.




Ensure that transfer case seats squarely against tractor main frame then tighten the retaining nuts.

When the nuts are fully tight, check that the drive coupling slides quite freely into the transfer box gear. If a new gasket is fitted between main frame and transfer box it will be necessary to adjust the thickness of the gasket, by peeling off some laminations, until the coupling slides freely into the transfer gear splines.



Replace bolt through coupling then refit gearbox top. Replace drive shaft to front axle then fit a new filter element before refilling transmission with an approved grade of oil.

SPECIAL TOOLS — MK II FRONT AXLE AND TRANSFER BOX


These tools are not available from David Brown Tractors or Churchill. Full dimensions etc. are given so that Distributors and Dealers can manufacture these tools in their own workshops.




CLAMP — FINAL DRIVE UNIT




EXTRACTOR — FINAL DRIVE GEAR




ALL DIMENSIONS IN MILLIMETRES




REPLACER — FINAL DRIVESHAFT OIL SEAL




REPLACER — FINAL DRIVE GEAR




REPLACER — HALF-SHAFT OUTER BEARING



REPLACER — FINAL DRIVESHAFT BEARING




REPLACER — HALF-SHAFT OIL SEAL




REPLACER — OUTER SHAFT BEARING


ALL DIMENSIONS IN MILLIMETRES






REPLACER — HALF-SHAFT CENTRE BEARING



REPLACER — FINAL DRIVESHAFT INNER BEARING









CLAMP — HALF-SHAFT




EXTRACTOR — KING PIN


ALL DIMENSIONS IN MILLIMETRES




ALL DIMENSIONS IN MILLIMETRES




REMOVER — DRIVEN SHAFT




REPLACER — INTER GEAR BEARING




REPLACER — SELECTOR
SHAFT OIL SEAL




REMOVER — DIFFERENTIAL SIDE BEARING




REMOVER — DRIVE GEAR




REPLACER — CORE PLUG




REPLACER — OUTPUT SHAFT




REMOVER — DIFFERENTIAL SIDE BEARING




REPLACER — OUTER RING




REPLACER — OUTER RING & SEAL BEARING



REPLACER — FLANGE



REPLACER — BUSHES



REPLACER — INNER RACE BEARING

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.


Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

Published by David Brown Tractors Ltd. ©

Printed in England by Waddington & Ledger Limited, Dewsbury



4WD TRANSMISSION AND FRONT AXLE Mk II



David Brown®

Service Repair Manual

POWER TAKE-OFF (PTO)

Section C8 (Pub. 9-37182) October 1978



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



**David Brown Tractors Ltd. will continue to improve their products.
As a result, the specification details can have changed after this issue
was made.**

SECTION	DETAILS	PAGE
Multi-speed PTO		
Unit Maintenance and Repair		
	Disassembly	1
	Assembly	1
Single speed PTO		
Single-speed PTO		
Unit Maintenance and Repair		
	Disassembly	3
	Assembly	3
Reversible Shaft Pto		
	Removal and Installing	5
	Illustration of Parts	6
	Disassembly	7
	Inspection	8
	Assembly	8
	Adjustment	10
	Control Lever and Selector	11
	Data	12
	Special Tools	12

Pages 1 — 4 were originally issued as part of 1410, 1412 Service Information Pub. 9-38124. Please remove and destroy these pages from the 1410, 1412 Service Information section.

Pages 5 — 12 were prepared for Update No. 1 to 1410, 1412 Service Information as Pub. 9-38173, but not issued.

MULTI-SPEED POWER TAKE-OFF UNIT

Dismantling Power Take-Off Unit

Having removed unit from tractor, first tip out any oil remaining in case then place unit on bench.

Remove rear cover, taking care of the bearing shims so that they can be refitted as removed. Push the top shaft rearwards out of case: the rear bearing bore being just large enough to allow gear to pass through.

Whilst using a lever to hold the selector stationary otherwise it may jam on rod—tap the selector rod rearwards out of the case: be prepared to catch the detent ball and spring which will be released as rod is withdrawn. Lift out the selector after removing selector rod.

Using a suitable punch on shaft end carefully tap output shaft rearwards out of case. Push rear bearing out of case then allow gear to rest against case whilst shaft is tapped out of front bearing and gear. When shaft has been removed, lift gear and bearing through top of case.

Assembling Power Take-off Unit

If the front bearing tracks have been removed ensure that these have been refitted and tapped firmly against their bore shoulders.

Smear output shaft rear bearing with grease then place it in its outer track. Fit change speed gear in case, larger gear to front, then fit output shaft through case and gear. Push shaft through until it comes against rear bearing then carefully tap shaft end with a soft-faced hammer until it is pushed into bearing. Replace outer track of rear bearing.

Place selector fork in vice and replace detent spring and ball. Hold ball against spring with a screwdriver so that a short piece of 10mm ($\frac{3}{8}$ in) diameter rod—a bolt shank is satisfactory—can be pushed into selector to hold ball against its spring. Fit selector fork in gear and engage it in operating lever then push selector rod through rear of case. Allow rod to enter selector fork then whilst holding fork stationary push rod through fork and over detent ball: guide rod will be pushed out of fork at same time and can be retrieved. Push selector rod fully into case, compressing circlip so that it enters recess in case face.

Replace input shaft; passing it through rear of case until it seats in front bearing then replace outer track of rear bearing.

If cover oil seal is to be renewed, carefully press a new seal into cover bore. Position seal lip towards inside of cover and press seal in until it is level with inner face of cover.

Replace shims in end cover; a smear of grease will help retain them in position. Smear cover face with grease then fit a new gasket in position on cover. Pack inside of oil seal with grease and refit cover, taking special care not to cut the seal lip on shaft splines.

Tighten cover bolts and nuts evenly; bolts to 2.8 kg metre (20 lb ft) and nuts to 6.9 kg metre (50 lb ft) then check that shafts rotate freely and have 0.05 to 0.10mm (0.002 to 0.004in) end float. If necessary remove cover and adjust end float by removing, or adding, shims.

Check that speed change lever operates correctly then refit PTO shaft cover.




FIGURE 1. GEARS AND SHAFTS — MULTI-SPEED PTO




FIGURE 2. COMPONENTS OF MULTI-SPEED POWER TAKE-OFF

SINGLE-SPEED POWER TAKE-OFF UNIT

Dismantling Power Take-off Unit

Having removed unit from tractor, first tip out any oil remaining in case then place unit on bench.

Remove rear cover, taking care of bearing shims, then tap topshaft rearwards out of case. Remove oil reservoir from front of case then push selector rod out rearwards; hold selector fork stationary whilst doing this and prepare to catch detent ball, which will be displaced from selector fork when rod is removed.

Stand unit with its rear face over end of bench or packing case then, whilst an assistant is holding splined end of output shaft, tap shaft downwards out of case: do not use a large drift against shaft end as this is a separate thick washer but use a drift small enough to fit inside oil feed hole.

Having the case vertical will hold components central whilst shaft is driven out and enable them to be removed after withdrawing shaft: take special care not to damage the needle rollers.

Assembling Power Take-off Unit

If front bearing tracks have been removed from case, ensure that these are refitted and tapped firmly against their bore shoulders.

Fit collar and sliding dog on gear: relieved end of dog teeth towards gear. Replace driveshaft inner bearing in case then fit gear inside case: collar towards bearing.

Smear needle roller bearings and distance piece with grease then place them on driveshaft: distance piece between

bearings. Turn shaft so that key is opposite keyway in collar then carefully push shaft into collar. Hold collar against gear, to keep needle rollers in place, then carefully tap shaft into bearing. When shaft has fully entered front bearing, tap outer track of rear bearing into case.

Place selector fork in vice and replace detent spring and ball. Hold ball against spring with a screwdriver so that a short piece of 12mm ($\frac{1}{2}$ in) diameter rod—a bolt shank is satisfactory—can be pushed through selector to hold ball against its spring. Fit selector fork in gear and engage it in operating lever then push selector rod through rear of case. Allow rod to enter selector fork then whilst holding fork stationary push rod through fork and over detent ball: guide rod will be pushed out of fork at same time and can be retrieved. Push selector rod fully into case, compressing circlip on rod so that it enters recess in case.

If cover oil seal is to be renewed carefully press a new seal into cover bore. Position seal lip towards inside of cover and press seal in until it is level with inner face of cover.

Replace shims and distance piece against lower bearing track and fit topshaft bearing shims in cover recess: a smear of grease will retain shims in position. Smear face of cover with grease then fit a new gasket in position on cover. Pack seal cavity with grease before fitting cover. Take special care not to cut seal on shaft splines and carefully work seal lip over shaft chamfer. Tighten cover bolts evenly then check that shafts rotate freely and with end float. Shafts should have 0.05 to 0.10mm (0.002 to 0.004in) end float and can be adjusted by removing cover and removing shims to increase end float or adding shims to reduce end float.

Replace oil reservoir and refit PTO shaft cover.




FIGURE 3. GEARS AND SHAFTS—SINGLE-SPEED POWER TAKE-OFF




FIGURE 4. COMPONENTS OF SINGLE-SPEED POWER TAKE-OFF

REVERSIBLE SHAFT POWER TAKE-OFF UNIT

Removing

1. Ensure that there is at least 2 metre (6 ft) of working space behind the tractor and that the floor is level.
2. Drain transmission oil into a clean container with a capacity of more than 48 litres (10½ gallon). Make sure that dirt does not get into the oil.
3. If fitted, remove the bolts attaching the pipe support brackets to the PTO case and fasten the brackets and pipes out of the way with wire.
4. Support the drawbar and remove the eight setscrews which attach the hitch plates to the PTO case. Note the size and position of the shims fitted between the hitch plates and the PTO case.
5. Lower the drawbar to the ground.
6. Support the PTO with suitable equipment and remove the setscrews which fasten the PTO to the rear axle case.

NOTE: A moveable hoist or trolley jack is essential as the cardan shaft (1500 mm—5 ft) long, will be withdrawn attached to the PTO.

7. Withdraw PTO, taking care that no strain is placed on the cardan shaft.

Installing

1. Reverse operations 3 to 7.
2. Re-fill transmission case with original oil but do not use the last gallon as this will contain sediment. Top up to level with clean oil.




FIGURE 5

- A. Hitch Plate
B. Setscrews (Hitch plate to PTO casing)

R77.62

POWER TAKE-OFF




FIGURE 6

- | | |
|-----------------------------|-----------------------------|
| A. Cardan shaft | L. Needle roller bearings |
| B. Dog clutch | M. Oil seal |
| C. Taper roller bearing | N. Oil seal |
| D. Input shaft 21/13 teeth | P. Taper roller bearing |
| E. Taper roller bearing | R. Driven gear, low speed, |
| F. Shims | 50 teeth |
| G. End cover | S. Driven gear, high speed, |
| H. Shims | 43 teeth |
| J. Output shaft, low speed | T. Taper roller bearing |
| K. Output shaft, high speed | U. Bearing retainer |
| | V. Setscrews |

Disassembly

1. Pull the cardan shaft out of the input shaft bearing. If it is difficult to extract, stand the PTO unit on a piece of wood, cardan shaft upwards. Obtain an assistant to take the weight of the cardan shaft, and tap the PTO case flange with a heavy soft-faced hammer at a point nearest to the shaft.
2. Place PTO on bench with the end cover upwards.
3. Remove the thirteen setscrews and lift off the end cover.

NOTE: Attached to the end cover are the output shafts, bearings and both driven gears. This operation will be made easier by screwing two bolts into the tapped holes for the PTO guard and connecting them with wire to make a lifting handle.

4. Bend down tabs on tabwasher and remove the three setscrews and the bearing retainer.
5. Use a suitable puller and remove the bearing. Alternatively use a suitable puller and remove the 43 teeth driven gear which will force the bearing off its location.
6. Lift off the 43 teeth driven gear, the special washer, the needle thrust bearing, the 50 teeth driven gear and the two halves of the split ring.
7. Withdraw the high speed output shaft and remove the two needle roller bearings, the distance piece and the special washer.
8. Taking care not to damage the splines, press the low speed output shaft out of the end cover. Alternatively use a soft-faced hammer and drive the output shaft out of the end cover.





FIGURE 7

R77.61

FIGURE 8



- A. Setscrew
- B. Tabwasher
- C. Bearing retainer
- D. Shims
- E. Taper roller bearing
- F. Special washer
- G. Driven gear (high speed)
- H. Needle thrust bearing
- J. Driven gear (low speed)
- K. Split ring
- L. Taper roller bearing
- M. Special washer
- N. Oil seal
- P. Output shaft (low speed)
- R. Special washer
- S. Oil seal

R77.59




FIGURE 9

- A. Needle roller bearing
- B. Distance piece
- C. Output shaft (high speed)

R77.60




FIGURE 10

- A. Dog clutch
- B. Ball bearing
- C. Shims
- D. Taper roller bearing
- E. Input shaft
- F. Taper roller bearing

R77.58

POWER TAKE-OFF

Inspection

1. Check all bearings for damaged tracks and rollers and renew as necessary.
2. Check gear teeth for wear or damage and renew as necessary.

Assembly

1. Fit new oil seals to end cover and the low-speed output shaft. Grease both seal lips. The correct position for the output shaft oil seal is just contacting the special washer R.
2. Fit the low-speed output shaft into the end cover and place together on a firm surface with a wood block of suitable thickness supporting the output shaft flange.
3. Place the special washer M over the splines, chamfered side towards end cover and tap into position with a mild steel drift. Ensure that the special washer is seated against the register on the output shaft.
4. Place the taper roller bearing cone over the splines and tap into position with a mild steel drift. Do not oil the bearing.
5. Assemble the two halves of the split washers on to the output shaft and refit the low-speed driven gear.
6. Insert the high-speed output shaft into the low-speed output shaft and insert the two needle roller bearings with the distance piece between them. Oil the needle roller bearings with transmission oil before assembly.
7. Place the needle roller thrust bearing on to its seat on the low-speed driven gear and fit the high-speed driven gear and the special washer, F.
8. Tap the bearing into position and assemble the bearing retainer, tabwasher and setscrews. Do not oil the bearing.
9. Tighten the setscrews to 2.8 kg m (20 lb ft) and lock with the tabwasher.




FIGURE 11

- A. Setscrew
- B. Tabwasher
- C. Bearing retainer
- D. Shim
- E. Taper roller bearing
- F. Special washer
- G. Driven gear (high speed)
- H. Needle thrust bearing
- J. Driven gear (low speed)
- K. Split ring
- L. Taper roller bearing
- M. Special washer
- N. Oil seal
- P. Output shaft (low speed)
- R. Special washer
- S. Oil seal

R7759




FIGURE 12

- A. Needle roller bearing
- B. Distance piece
- C. Output shaft (high speed)

R7780

10. Position PTO case with end cover flange upwards. Place the input shaft in position and press down firmly with a turning motion to seat the bearing rollers.
11. Smear the end cover face with Wellseal and place a new gasket in position.
12. Screw two setscrews, 7/16UNC, into the end cover to assist in handling, and lower the end cover with gears and shafts into position in the PTO case.
13. Tap the dowel into position and refit and tighten the thirteen end cover to PTO case setscrews to 2.8 kg m (20 lb ft).
14. Refit the dog clutch and place the lever in the engaged position to hold the dog clutch in position during handling.
15. Refit the cardan shaft and the PTO guard.
16. Pour some transmission oil into the PTO case and manipulate the casing to lubricate the bearings which were assembled dry.




FIGURE 13

R77.83




FIGURE 14

R77.81

POWER TAKE-OFF

Shaft end float adjustment

This adjustment must be made whenever new bearings, shafts or gears are fitted. The correct end float on both shafts is 0.05 to 0.10 mm (0.002 to 0.004 in). It is essential that the end float is accurately adjusted and must never be set at 0.05 mm (0.002 in) or less. Insufficient end float will cause bearing failure. Excessive end float can cause gear teeth wear and dog clutch disengagement when under load.

1. Using a mild steel drift, drive out both bearing cups from the PTO case and remove all the shims from between the bearing cups and the PTO case. Refit the cups, making sure that they are fully seated and wiped clean.
2. Remove all traces of oil from the roller bearing cones, the needle thrust bearing, and the bearing cups in the end cover.
3. Assemble PTO: operation 1 to 13.
4. Fit the reversible shaft with six spline end outwards and tighten the retaining screws.
5. Position PTO unit with shafts vertical and the end cover downwards. Use wood blocks to support PTO unit so that the reversible shaft is clear and can be reached by hand.
6. Rotate and rock the shaft to ensure that the bearings are seated and attach a dial gauge so that the measuring probe is parallel to the shaft and in contact with the bearing retainer.
7. Push up on the reversible shaft and then down on the bearing retainer and note the measurement.
8. Re-position the dial gauge so that the measuring probe contacts the input shaft, lift shaft up and then push down and note the measurement.

Example:

Measurement is 0.05 mm (0.002 in).

End-float required is 0.076 mm (0.003 in).

Shims required are 0.43 mm (0.017 in)

Always avoid using a large number of thin shims.

9. Disassemble, fit shims of the required thickness between the bearing cups and the PTO case and assemble PTO unit.

Control lever and selector.**Disassembly**

1. Place PTO casing on bench standing on the end cover.
2. Select disengage position, operating lever upwards, and slide the dog clutch gear out of the selector fork.
3. Remove circlip, place a finger over the hole in the side of the selector fork to prevent the detent ball and spring from becoming displaced, and withdraw selector fork from the selector rod.
4. Drive the pin out of the boss and withdraw the boss from the selector lever shaft.
5. Slide out the selector shaft and lever from inside the PTO casing.
6. Remove the two setscrews which fasten the retaining plate to the PTO casing, and remove the retaining plate.
7. Drive out the selector rod using a mild steel drift.

NOTE: Operation 6 and 7 can only be carried out after the end cover and gears have been removed.


Inspection

Check for wear, particularly detent ball grooves in selector rod and faces of selector fork.

Assembly:

1. Fit new 'O' ring to selector lever shaft and coat the shaft with grease.
2. Reverse operations 2 to 7.


NOTE: Plug the holes in the PTO case with lint-free cloth or paper before fitting the detent ball and spring to prevent the detent ball falling into the PTO case if it becomes displaced whilst being fitted.



R7765

FIGURE 15

- A. Dog clutch gear
B. Selector fork
C. Selector lever



R7757

FIGURE 16

- | | |
|--------------------|-------------------------|
| A. Operating lever | H. Locknut |
| B. Selector rod | J. Selector lever |
| C. Retaining plate | K. 'O' ring |
| D. Setscrew | L. Operating lever boss |
| E. Selector fork | M. Pin |
| F. Steel ball | N. Circlip |
| G. Spring | |

SPECIFICATION AND DATA

Input shaft end float	(0.05 to 0.10 mm)	0.002—0.004 in
Output shaft end float	(0.05 to 0.10 mm)	0.002—0.004 in
Output shaft setscrews tightening torque	(2.8 kg m)	20 lb ft
End cover setscrews tightening torque	(2.8 kg m)	20 lb ft
Selector rod retainer plate screw tightening torque	(1.3 kg m)	9 lb ft

Tools required: manufacture locally from mild steel plate





FIGURE 17

R77.86

Tool	A.	B.
Oil Seal Replacer	12.7 mm (0.5 in)	70 mm (2.75 in)
Support Pad	35 mm (1.375 in)	89 mm (3.5 in)
Support Pad/Oil Seal Replacer	17.5 mm (0.688 in)	133 mm (5.25 in)





POWER TAKE-OFF (PTO)

DAVID BROWN  

CARRARO FRONT AXLE AND TRANSFER GEARBOX 990 4WD, 995 4WD AND 996 4WD TRACTORS

Section C9 (Pub. 9-37176) March 1979

Written In *Clear
And
Simple
English*

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



The information in this section is for the repair of the CARRARO 4WD front axle and transfer gearbox fitted to 990, 995 and 996 tractors only. DO NOT use for the axle and gearbox fitted to the 1690 tractor.

David Brown procedure is one of continuing development and improvement. As a result, the specification details may have changed after this issue was made.

Also, as the David Brown Tractor is made to variable specifications for different countries and uses, this manual may give details of items which are not part of any specific tractor.

© **Published by David Brown Tractors Ltd.**

Printed in England by The Cloister Press, Heaton Mersey, Stockport, March 1978
Reprinted March 1979

CONTENTS

	Page
Specification	C9/1
Special Tools	C9/2
How it Works	C9/3
Removing the Axle from the Tractor	C9/4
Installing the Axle on the Tractor	C9/5
Disassembling the Axle:	
Reduction Unit	C9/6
Wheel Hubs	C9/7
Swivel Housings	C9/7
Drive Shafts	C9/8
Differential	C9/9
Bevel Pinion	C9/10
Setting of the Bevel Pinion Shaft	C9/10
Setting for the Pinion Bearings	C9/11
Assembling the Axle:	
Differential	C9/12
Installing the Differential in the End Plate	C9/12
Setting the Pre-load for the Differential Bearings	C9/14
Setting the Backlash	C9/14
Installing the Differential Unit	C9/15
Assembling the Drive Shafts	C9/15
Installing the Drive Shafts	C9/15
Installing the Swivel Housings	C9/16
Setting for the Bearing Clearance	C9/16
Installing the Wheel Hubs	C9/17
Assembling the Reduction Unit	C9/18
Transfer Gearbox:	
Removal	C9/19
Installation	C9/19
Disassembly	C9/20
Inspection of Parts	C9/20
Arrangement of Transfer Gearbox Parts	C9/21
Assembly	C9/22
Diagram of Assembled Transfer Gearbox	C9/23

DATA

Spiral Gear/Pinion ratio	35/8	
Reduction	4.375:1	
Epicyclic Hub Reduction	3.666:1	
Total Axle Reduction	16.038:1	
Minimum Tread	1550 mm	61 in
Maximum Tread	1800 mm	72 in
Ground Clearance (11.2/10-24 tyres)	365 mm	14.4 in
Steering Angle	40°-2°	
Toe in (measured at the rims)	0 to 1 mm	0 to 0.04 in
Weight (approximate)	225 kg	492 lb

Tyre arrangements

FRONT

1. 9.5/9-24
2. 11.2/10-24
3. 11.2/10-24

REAR

- 14.9/13-30
- 12.4/11-36
- 16.9/14-30

IMPORTANT: Do not use any other tyre arrangement or damage will be caused to the differential and transmission.

TORQUE SETTINGS

Hub cover setscrews	48 N m	35 lb ft
Hub ring nuts	1160 N m	850 lb ft
Stub axle nuts	130 N m	96 lb ft
Swivel bearing cover nuts	130 N m	96 lb ft
Special screw locknuts	180 N m	130 lb ft
Differential to axle case nuts	87 N m	65 lb ft
Differential bearing cap nuts	130 N m	96 lb ft
Differential cage setscrew	48 N m	35 lb ft
Spiral gear setscrews	89 N m	66 lb ft
Pinion shaft cover setscrews	25 N m	18 lb ft
Pinion shaft ring nut	450 N m	330 lb ft
Track rod ball joint nuts	140 N m	100 lb ft
Wheel nuts	130 N m	96 lb ft

CAPACITIES (refill)

Differential case	3.4 litres	6 pints
Reduction hubs (each)	0.85 litres	1.5 pints

LUBRICATION

COMPONENT	CAPACITY		BP	CASTROL	ESSO	MOBIL	SHELL	TOTAL
	litre	pt						
DIFF HUBS (each)	3.4 0.85	6.0 1.5	Gear Oil 90EP	Agricastrol Gear Oil EP90/140	Esso Gear Oil GP90/140	Mobilube GX90 Gear Oil	Spirax 90EP	Transmission 90
STUB AXLES PIV. BUSHES SPL SLEEVE	Grease Fittings		Energrease Universal	L.M. Grease	Beacon 2	Mobilgrease MP	Retinax A	Multis

SPECIAL TOOLS







	LC. 305 (Churchill)	Tool for removing Bearing Pins from the Swivel Housings
	LC. 306 (Churchill)	Tool for Setting the Pinion
	LC. 309 (Churchill) 94014 (Carraro) 965854 (David Brown) 94041 (Carraro) 965855 (David Brown)	Wrench and Extension for Pinion Shaft Nut Wrench for Pinion Shaft Nut Extension for Wrench
	LC. 310 (Churchill) 94017 (Carraro) 965856 (David Brown) 94042 (Carraro) 965857 (David Brown)	Wrench and Extension for Hub Ring Nut Wrench for Hub Ring Nut Extension for Wrench
	LC. 550-14 (Churchill)	Tool for Installing Oil Seals

FIGURE 27 SPECIAL TOOLS

FRONT AXLE



DESCRIPTION

The axles in this group are of the double reduction type. The main parts are as follows:

1. A differential assembly with bevel gear and pinion drive.
2. Two drive shafts with double universal joints.
3. Two steering housings held in position by four stub axles on taper roller bearings.
4. Two epicyclic reduction hubs.

HOW IT WORKS:

The drive to the axle is taken from a transfer gearbox installed below the main gearbox. The dog clutch for engaging and disengaging the drive is inside the transfer gearbox. The movement of the dog clutch is controlled by a lever in the cab. A rigid propeller shaft and two splined sleeves connect the output shaft of the transfer gearbox to the bevel pinion of the axle. The bevel pinion engages in the spiral gear which is fastened to the differential casing. Inside the differential casing are four bevel pinions which are engaged in two bevel wheels. The bevel wheels are machined so that the splined ends of the drive shafts can be installed. A spur gear fitted to each end of the drive shafts engages in three planetary gears. These gears turn in housings which are fastened to the wheel hubs. The planetary gears also engage the ring gear which is fastened to the axle housing.

When the dog clutch is in the engaged position, the drive is sent through the bevel gear and differential to the spur gears on the ends of the drive shafts. As the ring gears are fastened to the axle housings and cannot move, the planetary gears turn inside the ring gears. This causes the wheel hubs to turn in the same direction as the drive shafts, but at a decreased speed.

FIGURE 1

ARRANGEMENT OF THE CARRARO AXLE

UNIT REMOVAL

Removing the Axle from the Tractor: Figures 2, 3, 4, 5.

1. Remove the propeller shaft cover A.
2. Remove the bolts which clamp the splined sleeve to the bevel pinion shaft. Push the splined sleeve away from the bevel pinion shaft. See Figure 4.
NOTE: There is an anti-rattle spring, inside the propeller shaft which contacts the end of the bevel pinion shaft.
3. Remove the front end of the steering ram from the steering arm on the axle. Use wire to fasten the steering ram to the main frame. See Figure 5.
4. Put an acceptable jack (minimum capacity 3 tonnes) under the differential case of the front axle.
5. Loosen the front wheel nuts.
6. Raise the front of the tractor with the jack and put supports between the main frame and the ground.
7. Remove the front wheels.
8. Lower the tractor on to the supports, but keep the jack in position under the differential case to hold the axle in position.
9. Remove the front and rear caps from the axle pivot bushes.
10. Get assistance to keep the axle in position on the jack and lower the axle to the ground.
11. Use a hoist to lift the axle away from the jack.




FIGURE 2 REMOVING AXLE

- A. Propeller Shaft Cover
- B. Bush Cap Nuts
- C. Bush Locating Adaptor
- D. Rear Bush Cap




FIGURE 3 TRUNNION BUSH

- E. Bush Cap Nuts
- F. Front Bush Cap
- G. Bush
- H. Bush Locating Adaptor




FIGURE 4 DRIVE SHAFT

- A. Splined Sleeve
- B. Anti-Rattle Spring
- C. Clamp Bolt

Installing the Axle on the Tractor:

1. Put the anti-rattle spring in position in the propeller shaft. Use grease to keep the spring in position.
2. Use a hoist to put the axle in position on the jack.
3. Check that the pivot bushes have not been moved out of position.
To do this, put each end cap in position under the pivot bush on the axle.
Make sure that the locating adaptor in the end cap goes into the hole in the pivot bush.
If necessary turn the pivot bushes so that when the axle is raised into position, the end caps are correctly aligned.
4. Get assistance to keep the axle in position on the jack and raise the axle until the pivot bushes contact the pivot housing.
5. Install the end caps.

IMPORTANT: If an end cap cannot be put in position easily DO NOT use force. Remove the locating adaptor and use a bar through the hole to align the bush. Then install the locating adaptor.

6. Tighten the end cap nuts to 230 N m (170 lb ft).
7. Align the propeller shaft sleeve with the bevel pinion shaft and move the sleeve forward until the clamp bolt can be installed.
Tighten the clamp bolt to 57 N m (42 lb ft).
8. Install the steering ram end on to the steering arm.
Tighten the nut to 140 N m (100 lb ft).
9. Install the front wheels.
10. Tighten the wheel nuts enough to keep the wheels in position.
11. Raise the front of the tractor with the jack and remove the supports.
12. Lower the tractor to the ground and remove the jack.
13. Tighten the wheel nuts to 130 N m (95 lb ft).




FIGURE 5 STEERING ARM

A. Steering Ram End Nut

R78.5

DISASSEMBLING THE AXLE

Special Tools

Before you disassemble the axle, make sure that the correct tools are available. These are as follows:

1. A tube wrench with adaptor for removing ring nuts.
2. A puller for removing the stub axles.

Disassembling the Reduction Unit: Figure 8

1. Remove the oil from the differential and front hubs. See Figures 6 and 7.
 2. Remove the ten setscrews N, which fasten the cover to the hub.
 3. Remove the cover K, complete with the planet pinions.
 4. Use a hammer and a small punch to remove the spring pins, P.
 5. Use a hammer and soft metal punch to remove the shafts L, which hold the planet gears in position.
- NOTE:** The shafts must be removed in the direction as shown, and will, when being removed, push out the core plugs, M.
6. Remove the planet gears G, with the needle roller bearings, F.
 7. Remove the thrust plates D and J, and retainers, E and H.

NOTE: Keep the planet gears, thrust plates and retainers together as you remove them. Do this to make sure that you install them in the correct position.




FIGURE 6 DRAIN POINT

A. Drain Plug




FIGURE 7 HUB LUBRICATION POINTS

B. Drain Plug
C. Level Plug




FIGURE 8 ARRANGEMENT OF HUB COVER

D. Thrust Plate	K. Cover
E. Retainer	L. Planet Gear Shaft
F. Roller Bearing	M. Core Plug
G. Planet Gear	N. Setscrew
H. Retainer	P. Spring Pin
J. Thrust Plate	

Disassembling the Differential:
Figures 12 and 13

1. Remove the nuts which fasten the differential unit to the axle case.
 2. Remove the differential unit.
 3. Put the differential unit on an acceptable stand or in a vice.
- NOTE:** If you use a vice, make sure that the vice has soft metal jaws.
4. Put a mark on the bearing caps A, and the end plate C, so that you can assemble them in the correct position.
 5. Remove the nuts B, which fasten the bearing caps to the end plate.
 6. Hold the spiral gear and differential cage in position. Remove the bearing caps and ring nuts, D. Remove the lock pins, M.
 7. Remove the spiral gear and differential cage.
 8. Remove the setscrews F, which fasten the cover to the differential cage.
 9. Remove the cover, V.
 10. Remove the bevel wheel, U.
 11. Remove the pins H, which hold the bevel pinion shafts in position.
 12. Remove the bevel pinion shafts G, the spider T, the thrust washers S, and the bevel pinions, R.
 - †13. Remove the bevel wheel Q, the thrust washer P, and the bush N.
 14. Remove the setscrews L, which fasten the spiral gear to the differential cage.
 15. Remove the spiral gear J.
 16. Use an acceptable puller to remove the bearings E, from the cover and the differential cage.




FIGURE 12 DIFFERENTIAL END PLATE

- †A. Bearing cap
B. Nut
C. End plate




FIGURE 13 DIFFERENTIAL COMPONENTS

- | | | | |
|-----------------|----------------|------------------|-------------------|
| †D. Ring nut | H. Pin | M. Lock pin | R. Bevel pinion |
| E. Bearing | J. Spiral gear | N. Bush | S. Thrust washer |
| F. Setscrew | K. Cage | P. Thrust washer | T. Spider journal |
| G. Pinion shaft | L. Setscrew | Q. Bevel wheel | U. Bevel wheel |

† Amerided December 1980

MAINTENANCE AND REPAIR

Disassembling the Bevel Pinion: Figure 14

1. Remove the setscrews A, which fasten the cover B, to the end plate.
2. Remove the cover.
3. Use the special tool to remove the ring nut, L.
4. Push the splined end of the bevel pinion shaft G, toward the centre of the end plate.
5. Remove the bearing cone E, the spacer K, and the spacer, F.
6. Remove the bearing cone J and the spacer H.
7. Remove the bearing cups from the end plate.




FIGURE 14 BEVEL PINION ASSEMBLY

A. Setscrew	G. Bevel pinion shaft
B. Cover	H. Spacer
C. Gasket	J. Bearing
D. Oil seal	K. Spacer
E. Bearing	L. Nut
F. Spacer	

SETTING OF THE BEVEL PINION SHAFT

Tools needed:

A 150 mm (6 in) Depth Gauge
A clamp E as shown in Figure 15.
A shaft F as shown in Figure 15.
An inside micrometer 0-150 mm (0-6 in) capacity.

Setting for the Correct Position: Figure 15

1. Install the bearing cups A and B, in the end plate.
2. Install the bearing caps G and J, on the end plate.
3. Install and tighten the bearing cap nuts.
4. Put the bearing cones C and D, in position.
5. Install the clamp, E.
6. Tighten the clamp nut until the bearing cones are difficult to turn. Do this job carefully or damage to the bearings can result.
7. Use the inside micrometer to measure the diameter of the bore K. Make a note of this measurement.
8. Put the shaft F, in position with the depth gauge H, through the hole in the shaft.
9. Measure the distance between the top of the shaft and the face of the bearing cone. Make a note of this measurement L.
10. Look at the end face of the bevel pinion. Make a note of the Apex Distance N. See Figure 16 for an example.
11. It is necessary to find the pinion distance M. To do this, make the following calculation.

$$M = L - 25 \text{ mm (shaft diameter)} + \frac{K}{2}$$

12. To find the correct spacer needed, subtract the Apex Distance N from M.
13. Remove the clamp and the outer bearing cone.
14. Put the correct size spacer H Figure 14, on the pinion shaft.
15. Install the pinion shaft through the inner bearing into the end plate.
16. Remove the bearing caps from the end plate.




FIGURE 15 SETTING POSITION OF BEVEL PINION




FIGURE 16 BEVEL PINION MARKS
N. Apex Distance

† Amended December 1980

Disassembling the Differential:
Figures 12 and 13

1. Remove the nuts which fasten the differential unit to the axle case.
 2. Remove the differential unit.
 3. Put the differential unit on an acceptable stand or in a vice.
- NOTE:** If you use a vice, make sure that the vice has soft metal jaws.
4. Put a mark on the bearing caps A, and the end plate C, so that you can assemble them in the correct position.
 5. Remove the nuts B, which fasten the bearing caps to the end plate.
 6. Hold the spiral gear and differential cage in position. Remove the bearing caps and ring nuts, D. Remove the lock pins, M.
 7. Remove the spiral gear and differential cage.
 8. Remove the setscrews F, which fasten the cover to the differential cage.
 9. Remove the cover, V.
 10. Remove the bevel wheel, U.
 11. Remove the pins H, which hold the bevel pinion shafts in position.
 12. Remove the bevel pinion shafts G, the spider T, the thrust washers S, and the bevel pinions, R.
 13. Remove the bevel wheel J, the thrust washer P, and the bush N.
 14. Remove the setscrews L, which fasten the spiral gear to the differential cage.
 15. Remove the spiral gear J.
 16. Use an acceptable puller to remove the bearings E, from the cover and the differential cage.




FIGURE 12 END PLATE

- A. Bearing Caps
- B. Nyloc Nut
- C. End Plate

R78 12




FIGURE 13 DIFFERENTIAL

- | | | |
|---------------------------|----------------------|---------------------|
| D. Ring Nut | K. Differential Cage | R. Bevel Pinion |
| E. Taper Roller Bearing | L. Setscrew | S. Spherical Washer |
| F. Setscrew | M. Spring Pin | T. Spider |
| G. Bevel Pinion Pin | N. Bush | U. Bevel Wheel |
| H. Dowel Pin | P. Thrust Washer | V. Cover |
| J. Spiral Gear and Pinion | Q. Bevel Wheel | |

R78 13

MAINTENANCE AND REPAIR

Disassembling the Bevel Pinion: Figure 14

1. Remove the setscrews A, which fasten the cover B, to the end plate.
2. Remove the cover.
3. Use the special tool to remove the ring nut, L.
4. Push the splined end of the bevel pinion shaft G, toward the centre of the end plate.
5. Remove the bearing cone E, the shims K, and the spacer, F.
6. Remove the bearing cone J and the shims H.
7. Remove the bearing cups from the end plate.




FIGURE 14 BEVEL PINION

- | | |
|-------------------------|-------------------------|
| A. Setscrew | G. Bevel Pinion |
| B. Cover | H. Shim |
| C. Gasket | J. Taper Roller Bearing |
| D. Oil Seal | K. Shim |
| E. Taper Roller Bearing | L. Locknut |
| F. Distance Piece | |

SETTING OF THE BEVEL PINION SHAFT: Figure 15

Tools needed:

- A 150 mm (6 in) Depth Gauge
- A clamp E as shown in Figure 15.
- A shaft F as shown in Figure 15.
- An inside micrometer 0-150 mm (0-6 in) capacity.

Setting for the Correct Position:

1. Install the bearing cups A and B, in the end plate.
2. Install the bearing caps G and J, on the end plate.
3. Install and tighten the bearing cap nuts. See Figure 15 for the next operations.
4. Put the bearings cones C and D, in position.
5. Install the clamp, E.
6. Tighten the clamp nut until the bearing cones are difficult to turn. Do this job carefully or damage to the bearings could result.
7. Use the inside micrometer to measure the diameter of the bore. Make a note of this measurement (K).
8. Put the shaft F, in position with the depth gauge H, through the hole in the shaft.
9. Measure the distance between the top of the shaft and the face of the bearing cone. Make a note of this measurement (L).
10. Look at the face of the bevel pinion. Make a note of the number (N). See Figure 16.
11. It is necessary to find the pinion distance (M). To do this, make the following calculation.

$$M = L - 25 (\text{shaft diameter}) + \frac{K}{2}$$

12. To find the correct amount of shims needed, subtract the number N from M.
13. Remove the clamp and the outer bearing cone.
14. Put the correct amount of shims H, on the pinion shaft.
15. Install the pinion shaft through the inner bearing into the end plate.
16. Remove the bearing caps from the end plate.




FIGURE 15 SETTING THE BEVEL PINION

- | | |
|------------------|---|
| A. Bearing Cup | G. Bearing Cap |
| B. Bearing Cup | H. Depth Gauge |
| C. Bearing Cone | J. Bearing Cap |
| D. Bearing Cone | K. Diameter of Bore |
| E. Clamp | L. Distance from top of shaft to face of bearing cone |
| F. Special Shaft | |




FIGURE 16

SETTING FOR THE PINION BEARINGS: Figures 14, 17 and 18

Tools needed:

- A dial gauge.
- A small spring balance.
- A piece of string approximately 600 mm (24 in) long.

The pinion bearings need a pre-load of 0.05 mm (0.002 in). To get this amount of pre-load do the procedure as follows:

IMPORTANT: This setting must only be made with new bearings and before the cover and oil seal are installed.

1. Put the distance piece F, on the pinion shaft.
2. Put the shims K, plus an extra shim 0.5 mm (0.020 in) thick on the pinion shaft against the distance piece.
3. Put the outer bearing cone E, on the pinion shaft.
4. Install and tighten a NEW ring nut L.

NOTE: To tighten the ring nut to the correct torque, it is necessary to wait until the differential has been installed.

5. Put the dial gauge in a position so that the probe is against the face of the pinion. See Figure 17.
6. Move the pinion shaft backwards and forwards and measure the amount of clearance. Make a note of this figure.

To find the correct amount of shims needed:

EXAMPLE:

Amount of clearance 0.55 (0.022 in)
Pre-load needed 0.05 mm (0.002 in)
Amount of shims to be removed 0.060 mm (0.024 in)

7. Remove the ring nut and the outer bearing cone.
8. Remove shims of the correct amount from against the distance piece.
9. Install the outer bearing cone and the ring nut.
10. Tighten the ring nut. See NOTE for operation 4.

To check the pre-load setting, do the following procedure:

1. Make a loop in one end of the piece of string.
 2. Put the other end of the string around the groove in the pinion shaft. Make two or three turns so that the string is tight on the shaft. See Figure 18.
 3. Put the hook of the spring balance through the loop in the string.
 4. Carefully pull the spring balance until the pinion shaft turns.
 5. Look at the scale on the spring balance and make a note of the weight that is shown.
 6. When the pre-load setting is correct, the weight shown will be 0.48 kg (1.051 lb).
- If the scale shows a difference from this figure it is necessary to remove or add shims between the outer bearing E, and the distance piece, F.

NOTE: If the weight shown is too much: Add shims. If the weight shown is not enough: Remove shims.
THIS OPERATION IS IMPORTANT.




FIGURE 17 POSITION OF DIAL GAUGE




FIGURE 18 CHECKING PRE-LOAD

R78.17

R78.18

ASSEMBLING THE AXLE

Assembling the Differential: Figure 21

1. Clean the faces of the spiral gear J and the differential cage, K.
2. Put the spiral gear in position on the differential cage.
3. Install the setscrews L, with new tabwashers.
4. Tighten the setscrews to 89 N m (66 lb ft). Bend the tabwashers to hold the setscrews in position.
5. Install the bush N, thrust washer P, and bevel wheel Q, in the differential cage.
6. Install the spider T, bevel pinions R, thrust washers S and bevel pinion shafts, G.

NOTE: Install the spider first.

7. Align the holes in the spider and the bevel pinion shafts and install the pins, H.
8. Install the bevel wheel U, on the bevel pinions.
9. Install the cover, V.
10. Install the setscrews F, with new tabwashers.
11. Tighten the setscrews to 48 N m (35 lb ft).
12. Bend the tabwashers to hold the setscrews in position.
13. Install the taper roller bearings E, on the end cover V and differential cage, K.

Installing the Differential Unit in the End Plate: Figures 19 and 20.

1. Put the end plate C, on an acceptable stand or in a vice.

NOTE: If you use a vice, make sure that the vice has soft metal jaws.

2. Put the differential unit in position in the end plate.
3. Install the bearing caps A and nuts, B.
4. Install the ring nuts.
5. Carefully tighten the bearing cap nuts.

IMPORTANT: Make sure when you tighten the bearing cap nuts that there is always a clearance between the spiral gear and the bevel pinion. Move the ring nuts if necessary to keep a clearance. If this is not done, damage can be caused to the spiral gear and pinion.

6. Tighten the bearing cap nuts to 130 N m (96 lb ft).
7. Put an acceptable piece of metal bar between the differential cage and the end plate. Make sure that the metal bar will prevent the differential cage from moving when you tighten the ring nut on the bevel pinion shaft. If necessary get assistance to hold the bar in position.




FIGURE 19 END PLATE

- A. Bearing Cap
- B. Nyloc Nut
- C. End Plate

8. Use the special spanner and a bar one metre (39 in) long to tighten the ring nut L, to a torque equal to 450 N m (330 lb ft).
9. Install a new oil seal D, in the cover, B.
10. Install the cover with a new gasket, C.
11. Install the setscrews A and tighten to 25 N m (18 lb ft).




FIGURE 20 LOCKNUT AND OIL SEAL

- | | |
|-------------|-------------|
| A. Setscrew | D. Oil Seal |
| B. Cover | L. Locknut |
| C. Gasket | |




FIGURE 21 DIFFERENTIAL

- | | | |
|---------------------------|----------------------|---------------------|
| D. Ring Nut | K. Differential Cage | R. Bevel Pinion |
| E. Taper Roller Bearing | L. Setscrew | S. Spherical Washer |
| F. Setscrew | M. Spring Pin | T. Spider |
| G. Bevel Pinion Pin | N. Bush | U. Bevel Wheel |
| H. Dowel Pin | P. Thrust Washer | V. Cover |
| J. Spiral Gear and Pinion | Q. Bevel Wheel | |

MAINTENANCE AND REPAIR

Setting the Pre-load for the Differential Bearings:

The correct amount of pre-load is 0.08 to 0.10 mm (0.003 to 0.004 in).

1. Turn the ring nut, B, clockwise until the spiral gear is pushed away from the pinion. At the same time hit the bearing caps with a soft faced hammer to align the bearings.
2. Turn the other ring nut, A, clockwise until all clearance in the bearings has been removed. Move the spiral gear wheel while you turn the ring nut and stop turning as soon as the spiral gear wheel is difficult to move.
3. Tighten, (turn clockwise) each ring nut one notch more.
Put a mark on each ring nut for reference.

Setting the Backlash:

1. Put a dial gauge in position so that the probe is in contact with, and at ninety degrees to a tooth on the spiral gear.
2. Check the amount of clearance between the spiral gear and the bevel pinion.
Repeat operations 1 and 2 on two or more teeth at equal distances around the spiral gear.
3. Make a note of the clearances shown by the dial gauge. If there is any difference, put the probe of the dial gauge on the tooth that has the smallest clearance.
4. The correct amount of clearance is 0.15 to 0.30 mm (0.006 to 0.012 in).
Move the spiral gear away from or toward the bevel pinion by turning each ring nut an equal amount until the clearance is correct.
5. Install the pins, C, which prevent the ring nuts from moving.
6. Tighten the bearing cap nuts to 130 N m (96 lb ft).
7. Check again to make sure the clearance is correct.




FIGURE 22

- A. Ring Nut
B. Ring Nut
C. Spring Pins

R7B 22

Installing the Differential Unit in the Axle Case: Figure 23

1. Clean the faces of the end plate and the axle case.
2. Put a new gasket A, in position on the studs of the axle case.
3. Install the differential unit in the axle case.
4. Install the nuts and tighten to 87 N m (65 lb ft).




FIGURE 23

A. Gasket

Assembling the Drive Shafts: Figure 24

1. Install the two spiders F and G, on the central body, H.
2. Install the needle rollers and cups.
3. Install the circlips.
4. Install each fork end separately with needle rollers, cups and circlips.
5. Install the bearing L, the washer D and the circlip C.




FIGURE 24 DRIVE SHAFTS

A. Special Screw
B. Oil Seal
C. Circlip
D. Grease Baffle
E. Circlip
F. Spider Assembly

G. Needle Roller Cup
H. Centre Body
J. Special Screw
K. Support Bearing
L. Drive Shaft (Long)

Installing the Drive Shafts in the Axle Case: Figure 24

1. Before you install the drive shafts, replace the oil seals B, in the axle case.
2. Put the drive shaft in the axle case with the bearing toward the differential. Put your hand inside the axle case to make a support for the fork end of the drive shaft.
3. Turn the drive shaft until the splines on the fork end engage in the splines in the differential.
4. Push the drive shaft into the axle case. Hit the end of the drive shaft with a soft faced hammer to make sure that the support bearing is in the correct position in the bearing housing.
5. Install the special screws A and J, which hold the support bearing in the axle case.
6. Use a hexagon wrench to tighten the special screws.
7. Install the lock nuts and tighten to 180 N m (130 lb ft).

MAINTENANCE AND REPAIR

Installing the Swivel Housings: Figure 25

1. Make an inspection of the bush B, in the stub axle for wear or damage. If necessary replace the bush.
2. Replace the oil seal A, in the stub axle.
3. Put a new gasket M, in position on the studs inside the swivel housing.
4. Install the stub axle C and the nuts.
5. Tighten the nuts to 130 N m (96 lb ft).
6. Replace the oil seal K, in the swivel housing.
7. Get assistance to hold the swivel housing in position on the axle case.
8. Install as a unit the bearing shafts, the oil seal and the bearings F, G and H.

Use a hammer and a soft metal punch to put the bearing shafts in the holes in the axle case.

IMPORTANT: When you do this job, be careful not to cause damage to the hole with a thread in the centre of the bearing shafts.

Setting for the Bearing Clearance:

The correct setting for the swivel bearings is zero. (No clearance, no pre-load). It is made by adding or removing shims E, between the bearing cups F and the covers, D. Do the procedure as follows:

1. Install the bottom cover D, with no shims. Install the setscrews and tighten to 130 N m (96 lb ft).
2. Take all the shims that were removed from both covers. Add to these shims another shim 0.5 mm (0.020 in) in thickness.
3. Put all the shims in position on the top bearing cup.
4. Put the top cover in position.
5. Install the setscrews. Tighten the setscrews evenly to 20 N m (15 lb ft).
6. Use a feeler gauge to measure the gap between the cover and the face of the swivel housing. Make a note of this measurement (A).
7. Remove the top cover and ALL the shims.
8. Use a micrometer to measure the total thickness of ALL the shims. Make a note of this measurement (B).

To find the TOTAL thickness of shims needed:

EXAMPLE:

Measurement of shims (B)	0.80 mm (0.032 in)
Minus (-) measurement of gap A	0.30 mm (0.012 in)
TOTAL shims needed	0.50 mm (0.020 in)

To hold the swivel housing in the correct position in the axle case, an equal amount of shims must be installed under each cover.

Using the example, the amount of shims needed under EACH cover is:




FIGURE 25 ARRANGEMENT OF SWIVEL HOUSING

A. Oil Seal	G. Oil Seal
B. Stub Axle Bush	H. Bearing Pin
C. Stub Axle	J. Seal
D. Cover	K. Seal
E. Shims	L. Swivel Housing
F. Bearing	M. Gasket

TOTAL shims needed 0.50 mm (0.020 in).
 Shims needed under each cover $\frac{0.50 \text{ mm (0.020 in)}}{2}$
 = 0.25 mm (0.010 in).

9. Remove the bottom cover, put the correct amount of shims in position on the bearing cup and install the cover.
10. Install the setscrews and tighten to 130 N m (96 lb ft).
11. Put the correct amount of shims on the top bearing cup and install the cover.
12. Install the setscrews and tighten to 130 N m (96 lb ft).
13. When you have installed both swivel housings, install the track rod.




FIGURE 26 ARRANGEMENT OF HUB

R78.26

Installing the Wheel Hubs: Figure 26

1. Put the support gear H, in the internal gear K, install the circlips, A.
2. Install the outer bearing F and the circlip G in the hub.
3. Install the spacer C and the inner bearing, D.
4. Put a new dirt excluder on the inner face of the hub, N.
5. Put the internal gear unit in the hub.
6. Install the hub on the stub axle.
7. Install the centering ring B and a new ring nut, J.
8. Use the special spanner and two bars one metre (39 in) long to tighten the ring nut to a torque equal to 1160 N m (850 lb ft).
9. Install the sun gear L and circlip M, on the drive shaft.

Assembling the Reduction Unit: Figure 27

Special Tools

A piece of shaft 21.6 mm (0.85 in) diameter and 35.6 mm (1.40 in) long.

1. Put the needle rollers F, in the bore of a planet pinion. Use a small amount of grease to keep the needle rollers in position.
 2. Put the special shaft inside the needle rollers.
 3. Put a retainer E and a thrust plate D, at each end of the planet pinion. Use a small amount of grease to keep them in position.
 4. Install a planet pinion with the shaft, retainers and thrust plates in the cover.
 5. Align the hole in the cover with the shaft inside the needle rollers. Align the pin hole in the shaft with the pin hole in the cover and push the pinion shaft L, through the thrust washers, the retainers and the needle rollers. If necessary use a soft-faced hammer to put the shaft in position. When the pinion shaft is pushed in position, it will push the special shaft out of the cover.
 6. Use the special shaft to install the other pinions using the same procedure.
 7. When the pinion shafts are in position, install the spring pins, P.
 8. Install new core plugs M, in the holes in the cover.
 9. Put a new gasket on the wheel hub. Use a small amount of grease to keep the gasket in position.
- IMPORTANT:** Make sure that the gasket is clear of the port for oil removal in the wheel hub.
10. Align the hole for the drain plug in the cover with the port for oil removal in the wheel hub.
 11. Install the cover. Install the setscrews N and tighten to 48 N m (35 lb ft).
 12. Fill the hubs and the axle case to the correct level with new oil of the correct grade.
 13. Tighten all the level and drain plugs.




FIGURE 27 ARRANGEMENT OF HUB COVER

D. Thrust Plate	K. Cover
E. Retainer	L. Planet Gear Shaft
F. Roller Bearing	M. Core Plug
G. Planet Gear	N. Setscrew
H. Retainer	P. Spring Pin
J. Thrust Plate	

R78 27

TRANSFER GEARBOX

Removal

1. Clean the area around the transfer gearbox and the drive shaft guard.
2. Clean around the transmission and transfer gearbox drain plugs. Put a container of at least 45 litre capacity under the drain plugs. Remove the drain plugs.
3. When the oil has stopped flowing install and tighten the drain plugs. Put a cover over the container if the old oil is to be used again.
4. To disconnect the drive shaft from the axle, first remove the guard C, Figure 28. Remove the four nuts and bolts D from the drive shaft couplings. Hold the shaft and slide the couplings towards the centre of the shaft.

NOTE: There is a spring between the front of the shaft and the axle bevel pinion shaft. Put a hand around the front of the shaft when lowering to prevent loss of the spring.

5. Make sure the 4 wheel drive control is in the disengaged position then disconnect the control rod.
6. Put a trolley jack under the transfer gearbox as a support.
7. Remove the six normal and two special setscrews which fasten the gearbox to the frame. Make a note of the position of the special setscrews for assembly.
8. Lower the gearbox with the jack and remove.

Installation

1. Clean the flange which connects to the frame. Put a new gasket on the flange. Clean the flange of the main frame.
2. Put the gearbox on a trolley jack and raise it into position in the frame. Enter the dowels carefully and keep the gearbox level during this operation.
3. Install the two special setscrews in the correct positions. Install the other six setscrews which fasten the gearbox to the frame. Tighten all setscrews. Use new spring washers.
4. Put the drive shaft to the front axle in position with the spring at the front end.
5. Make sure the slots of the couplings are aligned. Slide the couplings on to the bevel pinion and gearbox output shafts. Align the bolt holes in the couplings with the grooves around the shafts.
6. Install the four bolts, spring washers and nuts in the couplings and tighten.
7. Install the guard for the driveshaft.
8. Fill the transmission with oil to the correct level. If the old oil is used, DO NOT use the last 5 litres in the bottom of the container. Add new oil to replace this amount.
9. Test the tractor in 4 wheel and 2 wheel drive to check correct operation.

5 litres = 1 gal = 5 U.S. qt.
45 litres = 10 gal. = 48 U.S. qt.




FIGURE 28 TRANSFER GEARBOX REMOVAL AND INSTALLATION

- | | |
|--------------------------------|--------------------------------|
| A. Selector gear | E. Spring |
| B. Connection to control lever | F. Setscrews, gearbox to frame |
| C. Drive shaft guard | G. Drain plug |
| D. Coupling bolts and nuts | |

MAINTENANCE AND REPAIR

Disassembly:

1. Clean the transfer gearbox.
2. Put the transfer gearbox in a vice with the operation lever on top and the input shaft towards you.
3. Use a hammer and a parallel punch to remove the spring pins from the selector fork and jaw.
4. Use a hammer and a soft metal punch to hit the selector rod through the fork and jaw toward the front.
5. Hold a cloth around the selector gear J to prevent the loss of the three detent balls and springs H. Pull the selector gear off the input shaft G and remove the detent balls and springs.
6. Remove the small circlip D from the front end of the input shaft.
Use a hammer and soft metal punch to remove the input shaft toward the rear. Hold the shaft when the bearing is clear of the case, or the shaft will fall.
7. Remove the front bearing and the input gear from the casing. If necessary remove the rear bearing from the input shaft with a 3 leg puller.
8. Remove the circlip which holds the idler shaft front bearing in position.
Use a hammer and soft metal punch to remove the idler shaft M with front bearing toward the front.
9. Remove the inner race for the rear bearing and the idler gear B from the casing.
10. Remove the rear circlip and outer bearing race from the casing.
11. Use a 13 mm spanner to remove the four set-screws which fasten the oil seal housing Q for the output shaft.
Remove the housing with gasket and any shims from in front of the front bearing.
12. Remove the rear cover plate T for the output shaft.
13. Use a hammer and a soft metal punch to remove the output shaft R toward the front. Remove the spacer, inner race, and output gear from the casing.
14. Remove the outer race of the rear bearing from the casing.
Remove the inner race of front bearing from the shaft.
15. Remove the spring pin which fastens the operating lever to the operating shaft.
Remove the lever from the shaft.
Remove the shaft from inside the casing.
16. Use a lever to remove the oil seal for the selector shaft from the casing.

Inspection of Parts:

1. Clean all parts and check for wear and damage. Remove paint from front of output shaft.
2. Replace any part which shows too much wear or damage.

NOTE: The gears must be replaced as a set. Rapid wear and failure will occur if a single gear is replaced.

3. Remove any protrusions and sharp edges from the parts with a hone or fine file. Check the ends of the shafts and outer edges of splines especially.
4. Clean and check all flange faces, bores and circlip grooves for damage.
5. Clean and check all threads and holes for damage.
6. Remove the drive coupling from the front of the gearbox pinionshaft and check for wear and damage. Install again, or replace the coupling, if damaged or worn.




FIGURE 29 TRANSFER GEARBOX DISASSEMBLED

- | | |
|----------------------------------|---------------------|
| A. Input gear | O. Oil seal housing |
| B. Idler gear | P. Gasket |
| C. Output gear | Q. Oil seal |
| D. Small circlip | R. Output shaft |
| E. Large circlip | S. Spacer |
| F. Ball bearings | T. Rear cover |
| G. Input shaft | U. Spring pins |
| H. Detent ball and spring (3 of) | V. Selector jaw |
| J. Selector gear | W. Selector fork |
| K. Driving gear | X. Selector rod |
| L. Roller bearings | Y. Operating shaft |
| M. Idler shaft | Z. Operating lever |
| N. Setscrew | |

R7939

MAINTENANCE AND REPAIR

Assembly:

Apply gear oil to each component when assembling.

1. Press a new oil seal into the bore for the selector operating shaft. Make sure the lip is toward the inside of the case.
Apply oil to the lip of the seal.
2. Make sure there are no sharp edges on the end of the operating shaft or damage will be caused to the seal.
Install the operating shaft from the inside of the casing.
3. Install the operating lever and fasten with the spring pin.
4. Press the front roller bearing for the output shaft into the front bore of the casing.
Make sure the thick edge of the inner race is toward the inside of the casing.
5. Install the oil seal housing with all setscrews but without a seal and gasket.
6. Install the spacer and the inner race for the rear bearing on the output shaft. Make sure the shoulder of the inner race is against the spacer.
7. Hold the output gear in position inside the casing with the large boss toward the oil seal housing.
8. Put oil on the front edge of the output shaft. Enter the shaft through the rear bore of casing and output gear into front bearing.
9. Push the shaft through the front bearing.
10. Press the outer race for the rear bearing into the casing and on the shaft.
11. Install the rear cover. Use a new gasket.
12. Remove the front oil seal housing and install a new oil seal, lip toward the gear. Put a new gasket on the housing and install it with any shims which were removed.

NOTE: Be careful when sliding the seal on the shaft or damage will be caused to the lip of the seal.

13. Install the front bearing for the idler shaft.
Make sure the shoulder of the inner race is toward the gear.
Install the front circlip.
14. Hold the gear in position inside the casing with the large boss toward the rear.
Push the idler shaft through the gear and into the front bearing.
15. Install the rear bearing with the thick edge of the inner race toward the gear.
Install the rear circlip.
16. Install the front bearing for the input shaft, into the casing.
17. Press the rear bearing on to the input shaft.
18. Hold the input gear in position inside the casing with the large boss toward the rear.
Push the input shaft through the gear and press it into the front bearing.
19. Install the small circlip to the front of the input shaft.
20. If the selector gear has been removed, put the detent springs and balls in the input shaft gear.
Hold the balls down and press the selector gear on the input shaft gear.

21. Put the selector jaw and fork in position and insert the selector rod from the front. Install the spring pins which fasten the selector jaw and fork to the selector rod.

IMPORTANT: Make sure all circlips are fully in the groove.

Use a hammer and punch to hit into location if necessary.

22. Install the drive gear F, Figure 31, on the pinion shaft of the main gear box.





FIGURE 30 SELECTOR ARRANGEMENT

- | | |
|--------------------|--------------------|
| A. Selector fork | E. Oil seal |
| B. Selector jaw | F. Spring pins |
| C. Selector rod | G. Operating lever |
| D. Operating shaft | |



R79-40

FIGURE 31 TRANSFER GEARBOX ASSEMBLED

- | | |
|----------------------------------|--------------------------------------|
| A. Small circlip | M. Special setscrew (2 of), to frame |
| B. Large circlip | N. Setscrew, oil seal housing |
| C. Input gear | O. Spacer |
| D. Selector gear | P. Output shaft |
| E. Detent spring and ball (3 of) | Q. Oil Seal |
| F. Drive gear | R. Oil seal housing |
| G. Circlip | S. Output gear |
| H. Idler gear | T. Rear cover, output shaft |
| J. Circlip | U. Ball bearings |
| K. Idler shaft | V. Roller bearings |
| L. Setscrews (6 of), to frame | X. Shims |

NOTE: Item F is installed on the pinion shaft of the main gearbox when installing the transfer gearbox.

DAVID BROWN  **case**

**CARRARO FRONT AXLE
AND TRANSFER
GEARBOX
990 4WD, 995 4WD AND
996 4WD TRACTORS**

Section C9 (Pub. 9-37176) March 1979

Written In *Clear
And
Simple
English*

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



The information in this section is for the repair of the CARRARO 4WD front axle and transfer gearbox fitted to 990, 995 and 996 tractors only.
DO NOT use for the axle and gearbox fitted to the 1690 tractor.

David Brown procedure is one of continuing development and improvement. As a result, the specification details may have changed after this issue was made.

Also, as the David Brown Tractor is made to variable specifications for different countries and uses, this manual may give details of items which are not part of any specific tractor.

© **Published by David Brown Tractors Ltd.**

Printed in England by The Cloister Press, Heaton Mersey, Stockport, March 1978
Reprinted March 1979

CONTENTS

	Page
Specification	C9/1
Special Tools	C9/2
How it Works	C9/3
Removing the Axle from the Tractor	C9/4
Installing the Axle on the Tractor	C9/5
Disassembling the Axle:	
Reduction Unit	C9/6
Wheel Hubs	C9/7
Swivel Housings	C9/7
Drive Shafts	C9/8
Differential	C9/9
Bevel Pinion	C9/10
Setting of the Bevel Pinion Shaft	C9/10
Setting for the Pinion Bearings	C9/11
Assembling the Axle:	
Differential	C9/12
Installing the Differential in the End Plate	C9/12
Setting the Pre-load for the Differential Bearings	C9/14
Setting the Backlash	C9/14
Installing the Differential Unit	C9/15
Assembling the Drive Shafts	C9/15
Installing the Drive Shafts	C9/15
Installing the Swivel Housings	C9/16
Setting for the Bearing Clearance	C9/16
Installing the Wheel Hubs	C9/17
Assembling the Reduction Unit	C9/18
Transfer Gearbox:	
Removal	C9/19
Installation	C9/19
Disassembly	C9/20
Inspection of Parts	C9/20
Arrangement of Transfer Gearbox Parts	C9/21
Assembly	C9/22
Diagram of Assembled Transfer Gearbox	C9/23



DATA

Spiral Gear/Pinion ratio	35/8	
Reduction	4.375:1	
Epicyclic Hub Reduction	3.666:1	
Total Axle Reduction	16.038:1	
Minimum Tread	1550 mm	61 in
Maximum Tread	1800 mm	72 in
Ground Clearance (11.2/10-24 tyres)	365 mm	14.4 in
Steering Angle	40°-2°	
Toe in (measured at the rims)	0 to 1 mm	0 to 0.04 in
Weight (approximate)	225 kg	492 lb

Tyre arrangements

FRONT

1. 9.5/9-24
2. 11.2/10-24
3. 11.2/10-24

REAR

- 14.9/13-30
- 12.4/11-36
- 16.9/14-30

IMPORTANT: Do not use any other tyre arrangement or damage will be caused to the differential and transmission.

TORQUE SETTINGS

Hub cover setscrews	48 N m	35 lb ft
Hub ring nuts	1160 N m	850 lb ft
Stub axle nuts	130 N m	96 lb ft
Swivel bearing cover nuts	130 N m	96 lb ft
Special screw locknuts	180 N m	130 lb ft
Differential to axle case nuts	87 N m	65 lb ft
Differential bearing cap nuts	130 N m	96 lb ft
Differential cage setscrew	48 N m	35 lb ft
Spiral gear setscrews	89 N m	66 lb ft
Pinion shaft cover setscrews	25 N m	18 lb ft
Pinion shaft ring nut	450 N m	330 lb ft
Track rod ball joint nuts	140 N m	100 lb ft
Wheel nuts	130 N m	96 lb ft

CAPACITIES (refill)

Differential case	3.4 litres	6 pints
Reduction hubs (each)	0.85 litres	1.5 pints

LUBRICATION

COMPONENT	CAPACITY		BP	CASTROL	ESSO	MOBIL	SHELL	TOTAL
	litre	pt						
DIFF HUBS (each)	3.4 0.85	6.0 1.5	Gear Oil 90EP	Agricastrol Gear Oil EP90/140	Esso Gear Oil GP90/140	Mobilube GX90 Gear Oil	Spirax 90EP	Transmission 90
STUB AXLES PIV. BUSHES SPL. SLEEVE	Grease Fittings		Energrease Universal	L.M. Grease	Beacon 2	Mobilgrease MP	Retinax A	Multis

SPECIAL TOOLS







	<p>LC. 305 (Churchill)</p>	<p>Tool for removing Bearing Pins from the Swivel Housings</p>
	<p>LC. 306 (Churchill)</p>	<p>Tool for Setting the Pinion</p>
	<p>LC. 309 (Churchill) 94014 (Carraro) 965854 (David Brown) 94041 (Carraro) 965855 (David Brown)</p>	<p>Wrench and Extension for Pinion Shaft Nut Wrench for Pinion Shaft Nut Extension for Wrench</p>
	<p>LC. 310 (Churchill) 94017 (Carraro) 965856 (David Brown) 94042 (Carraro) 965857 (David Brown)</p>	<p>Wrench and Extension for Hub Ring Nut Wrench for Hub Ring Nut Extension for Wrench</p>
	<p>LC. 550-14 (Churchill)</p>	<p>Tool for Installing Oil Seals</p>

FIGURE 27 SPECIAL TOOLS

FRONT AXLE



DESCRIPTION

The axles in this group are of the double reduction type. The main parts are as follows:

1. A differential assembly with bevel gear and pinion drive.
2. Two drive shafts with double universal joints.
3. Two steering housings held in position by four stub axles on taper roller bearings.
4. Two epicyclic reduction hubs.

HOW IT WORKS:

The drive to the axle is taken from a transfer gearbox installed below the main gearbox. The dog clutch for engaging and disengaging the drive is inside the transfer gearbox. The movement of the dog clutch is controlled by a lever in the cab. A rigid propeller shaft and two splined sleeves connect the output shaft of the transfer gearbox to the bevel pinion of the axle. The bevel pinion engages in the spiral gear which is fastened to the differential casing. Inside the differential casing are four bevel pinions which are engaged in two bevel wheels. The bevel wheels are machined so that the splined ends of the drive shafts can be installed. A spur gear fitted to each end of the drive shafts engages in three planetary gears. These gears turn in housings which are fastened to the wheel hubs. The planetary gears also engage the ring gear which is fastened to the axle housing.

When the dog clutch is in the engaged position, the drive is sent through the bevel gear and differential to the spur gears on the ends of the drive shafts. As the ring gears are fastened to the axle housings and cannot move, the planetary gears turn inside the ring gears. This causes the wheel hubs to turn in the same direction as the drive shafts, but at a decreased speed.

FIGURE 1

ARRANGEMENT OF THE CARRARO AXLE

UNIT REMOVAL

Removing the Axle from the Tractor: Figures 2, 3, 4, 5.

1. Remove the propeller shaft cover A.
2. Remove the bolts which clamp the splined sleeve to the bevel pinion shaft. Push the splined sleeve away from the bevel pinion shaft. See Figure 4.
NOTE: There is an anti-rattle spring, inside the propeller shaft which contacts the end of the bevel pinion shaft.
3. Remove the front end of the steering ram from the steering arm on the axle. Use wire to fasten the steering ram to the main frame. See Figure 5.
4. Put an acceptable jack (minimum capacity 3 tonnes) under the differential case of the front axle.
5. Loosen the front wheel nuts.
6. Raise the front of the tractor with the jack and put supports between the main frame and the ground.
7. Remove the front wheels.
8. Lower the tractor on to the supports, but keep the jack in position under the differential case to hold the axle in position.
9. Remove the front and rear caps from the axle pivot bushes.
10. Get assistance to keep the axle in position on the jack and lower the axle to the ground.
11. Use a hoist to lift the axle away from the jack.




FIGURE 2 REMOVING AXLE

- A. Propeller Shaft Cover
- B. Bush Cap Nuts
- C. Bush Locating Adaptor
- D. Rear Bush Cap




FIGURE 3 TRUNNION BUSH

- E. Bush Cap Nuts
- F. Front Bush Cap
- G. Bush
- H. Bush Locating Adaptor




FIGURE 4 DRIVE SHAFT

- A. Splined Sleeve
- B. Anti-Rattle Spring
- C. Clamp Bolt

Installing the Axle on the Tractor:

1. Put the anti-rattle spring in position in the propeller shaft. Use grease to keep the spring in position.
2. Use a hoist to put the axle in position on the jack.
3. Check that the pivot bushes have not been moved out of position.
To do this, put each end cap in position under the pivot bush on the axle.
Make sure that the locating adaptor in the end cap goes into the hole in the pivot bush.
If necessary turn the pivot bushes so that when the axle is raised into position, the end caps are correctly aligned.
4. Get assistance to keep the axle in position on the jack and raise the axle until the pivot bushes contact the pivot housing.
5. Install the end caps.

IMPORTANT: If an end cap cannot be put in position easily DO NOT use force. Remove the locating adaptor and use a bar through the hole to align the bush. Then install the locating adaptor.

6. Tighten the end cap nuts to 230 N m (170 lb ft).
7. Align the propeller shaft sleeve with the bevel pinion shaft and move the sleeve forward until the clamp bolt can be installed.
Tighten the clamp bolt to 57 N m (42 lb ft).
8. Install the steering ram end on to the steering arm.
Tighten the nut to 140 N m (100 lb ft).
9. Install the front wheels.
10. Tighten the wheel nuts enough to keep the wheels in position.
11. Raise the front of the tractor with the jack and remove the supports.
12. Lower the tractor to the ground and remove the jack.
13. Tighten the wheel nuts to 130 N m (95 lb ft).




FIGURE 5 STEERING ARM
A. Steering Ram End Nut

R78.5

MAINTENANCE AND REPAIR

DISASSEMBLING THE AXLE

Special Tools

Before you disassemble the axle, make sure that the correct tools are available. These are as follows:

1. A tube wrench with adaptor for removing ring nuts.
2. A puller for removing the stub axles.

Disassembling the Reduction Unit: Figure 8

1. Remove the oil from the differential and front hubs. See Figures 6 and 7.
2. Remove the ten setscrews N, which fasten the cover to the hub.
3. Remove the cover K, complete with the planet pinions.
4. Use a hammer and a small punch to remove the spring pins, P.
5. Use a hammer and soft metal punch to remove the shafts L, which hold the planet gears in position.
6. Remove the planet gears G, with the needle roller bearings, F.
7. Remove the thrust plates D and J, and retainers, E and H.

NOTE: The shafts must be removed in the direction as shown, and will, when being removed, push out the core plugs, M.

NOTE: Keep the planet gears, thrust plates and retainers together as you remove them. Do this to make sure that you install them in the correct position.




FIGURE 8 ARRANGEMENT OF HUB COVER

- | | |
|-------------------|----------------------|
| D. Thrust Plate | K. Cover |
| E. Retainer | L. Planet Gear Shaft |
| F. Roller Bearing | M. Core Plug |
| G. Planet Gear | N. Setscrew |
| H. Retainer | P. Spring Pin |
| J. Thrust Plate | |




FIGURE 6 DRAIN POINT

- A. Drain Plug




FIGURE 7 HUB LUBRICATION POINTS

- B. Drain Plug
C. Level Plug

Disassembling the Differential:
Figures 12 and 13

1. Remove the nuts which fasten the differential unit to the axle case.
 2. Remove the differential unit.
 3. Put the differential unit on an acceptable stand or in a vice.
- NOTE:** If you use a vice, make sure that the vice has soft metal jaws.
4. Put a mark on the bearing caps A, and the end plate C, so that you can assemble them in the correct position.
 5. Remove the nuts B, which fasten the bearing caps to the end plate.
 6. Hold the spiral gear and differential cage in position. Remove the bearing caps and ring nuts, D. Remove the lock pins, M.
 7. Remove the spiral gear and differential cage.
 8. Remove the setscrews F, which fasten the cover to the differential cage.
 9. Remove the cover, V.
 10. Remove the bevel wheel, U.
 11. Remove the pins H, which hold the bevel pinion shafts in position.
 12. Remove the bevel pinion shafts G, the spider T, the thrust washers S, and the bevel pinions, R.
 - †13. Remove the bevel wheel Q, the thrust washer P, and the bush N.
 14. Remove the setscrews L, which fasten the spiral gear to the differential cage.
 15. Remove the spiral gear J.
 16. Use an acceptable puller to remove the bearings E, from the cover and the differential cage.




FIGURE 12 DIFFERENTIAL END PLATE

- †A. Bearing cap
B. Nut
C. End plate




FIGURE 13 DIFFERENTIAL COMPONENTS

- | | | | |
|-----------------|----------------|------------------|-------------------|
| †D. Ring nut | H. Pin | M. Lock pin | R. Bevel pinion |
| E. Bearing | J. Spiral gear | N. Bush | S. Thrust washer |
| F. Setscrew | K. Cage | P. Thrust washer | T. Spider journal |
| G. Pinion shaft | L. Setscrew | Q. Bevel wheel | U. Bevel wheel |

† Amended December 1980

MAINTENANCE AND REPAIR

Disassembling the Bevel Pinion: Figure 14

1. Remove the setscrews A, which fasten the cover B, to the end plate.
2. Remove the cover.
3. Use the special tool to remove the ring nut, L.
4. Push the splined end of the bevel pinion shaft G, toward the centre of the end plate.
5. Remove the bearing cone E, the spacer K, and the spacer, F.
6. Remove the bearing cone J and the spacer H.
7. Remove the bearing cups from the end plate.




FIGURE 14 BEVEL PINION ASSEMBLY

- | | |
|-------------|-----------------------|
| A. Setscrew | G. Bevel pinion shaft |
| B. Cover | H. Spacer |
| C. Gasket | J. Bearing |
| D. Oil seal | K. Spacer |
| E. Bearing | L. Nut |
| F. Spacer | |

SETTING OF THE BEVEL PINION SHAFT

Tools needed:

- A 150 mm (6 in) Depth Gauge
- A clamp E as shown in Figure 15.
- A shaft F as shown in Figure 15.
- An inside micrometer 0-150 mm (0-6 in) capacity.

Setting for the Correct Position: Figure 15

1. Install the bearing cups A and B, in the end plate.
2. Install the bearing caps G and J, on the end plate.
3. Install and tighten the bearing cap nuts.
4. Put the bearing cones C and D, in position.
5. Install the clamp, E.
6. Tighten the clamp nut until the bearing cones are difficult to turn. Do this job carefully or damage to the bearings can result.
Use the inside micrometer to measure the diameter of the bore K. Make a note of this measurement.
8. Put the shaft F, in position with the depth gauge H, through the hole in the shaft.
9. Measure the distance between the top of the shaft and the face of the bearing cone. Make a note of this measurement L.
10. Look at the end face of the bevel pinion. Make a note of the Apex Distance N. See Figure 16 for an example.
NOTE: The other numbers on the pinion are for identification.
11. It is necessary to find the pinion distance M. To do this, make the following calculation.

$$M = L - 25 \text{ mm (shaft diameter)} + \frac{K}{2}$$

12. To find the correct spacer needed, subtract the Apex Distance N from M.
13. Remove the clamp and the outer bearing cone.
14. Put the correct size spacer H Figure 14, on the pinion shaft.
15. Install the pinion shaft through the inner bearing into the end plate.
16. Remove the bearing caps from the end plate.




FIGURE 15 SETTING POSITION OF BEVEL PINION




FIGURE 16 BEVEL PINION MARKS

N. Apex Distance

Disassembling the Differential:
Figures 12 and 13

1. Remove the nuts which fasten the differential unit to the axle case.
 2. Remove the differential unit.
 3. Put the differential unit on an acceptable stand or in a vice.
- NOTE:** If you use a vice, make sure that the vice has soft metal jaws.
4. Put a mark on the bearing caps A, and the end plate C, so that you can assemble them in the correct position.
 5. Remove the nuts B, which fasten the bearing caps to the end plate.
 6. Hold the spiral gear and differential cage in position. Remove the bearing caps and ring nuts, D. Remove the lock pins, M.
 7. Remove the spiral gear and differential cage.
 8. Remove the setscrews F, which fasten the cover to the differential cage.
 9. Remove the cover, V.
 10. Remove the bevel wheel, U.
 11. Remove the pins H, which hold the bevel pinion shafts in position.
 12. Remove the bevel pinion shafts G, the spider T, the thrust washers S, and the bevel pinions, R.
 13. Remove the bevel wheel J, the thrust washer P, and the bush N.
 14. Remove the setscrews L, which fasten the spiral gear to the differential cage.
 15. Remove the spiral gear J.
 16. Use an acceptable puller to remove the bearings E, from the cover and the differential cage.




FIGURE 12 END PLATE

- A. Bearing Caps
- B. Nyloc Nut
- C. End Plate

R78.12




FIGURE 13 DIFFERENTIAL

- | | | |
|---------------------------|----------------------|---------------------|
| D. Ring Nut | K. Differential Cage | R. Bevel Pinion |
| E. Taper Roller Bearing | L. Setscrew | S. Spherical Washer |
| F. Setscrew | M. Spring Pin | T. Spider |
| G. Bevel Pinion Pin | N. Bush | U. Bevel Wheel |
| H. Dowel Pin | P. Thrust Washer | V. Cover |
| J. Spiral Gear and Pinion | Q. Bevel Wheel | |

R78.13

MAINTENANCE AND REPAIR

Disassembling the Bevel Pinion: Figure 14

1. Remove the setscrews A, which fasten the cover B, to the end plate.
2. Remove the cover.
3. Use the special tool to remove the ring nut, L.
4. Push the splined end of the bevel pinion shaft G, toward the centre of the end plate.
5. Remove the bearing cone E, the shims K, and the spacer, F.
6. Remove the bearing cone J and the shims H.
7. Remove the bearing cups from the end plate.




FIGURE 14 BEVEL PINION

- | | |
|-------------------------|-------------------------|
| A. Setscrew | G. Bevel Pinion |
| B. Cover | H. Shim |
| C. Gasket | J. Taper Roller Bearing |
| D. Oil Seal | K. Shim |
| E. Taper Roller Bearing | L. Locknut |
| F. Distance Piece | |

SETTING OF THE BEVEL PINION SHAFT: Figure 15

Tools needed:

- A 150 mm (6 in) Depth Gauge
- A clamp E as shown in Figure 15.
- A shaft F as shown in Figure 15.
- An inside micrometer 0-150 mm (0-6 in) capacity.

Setting for the Correct Position:

1. Install the bearing cups A and B, in the end plate.
2. Install the bearing caps G and J, on the end plate.
3. Install and tighten the bearing cap nuts. See Figure 15 for the next operations.
4. Put the bearings cones C and D, in position.
5. Install the clamp, E.
6. Tighten the clamp nut until the bearing cones are difficult to turn. Do this job carefully or damage to the bearings could result.
7. Use the inside micrometer to measure the diameter of the bore. Make a note of this measurement (K).
8. Put the shaft F, in position with the depth gauge H, through the hole in the shaft.
9. Measure the distance between the top of the shaft and the face of the bearing cone. Make a note of this measurement (L).
10. Look at the face of the bevel pinion. Make a note of the number (N). See Figure 16.
11. It is necessary to find the pinion distance (M). To do this, make the following calculation.

$$M = L - 25 (\text{shaft diameter}) + \frac{K}{2}$$

12. To find the correct amount of shims needed, subtract the number N from M.
13. Remove the clamp and the outer bearing cone.
14. Put the correct amount of shims H, on the pinion shaft.
15. Install the pinion shaft through the inner bearing into the end plate.
16. Remove the bearing caps from the end plate.




FIGURE 15 SETTING THE BEVEL PINION

- | | |
|------------------|---|
| A. Bearing Cup | G. Bearing Cap |
| B. Bearing Cup | H. Depth Gauge |
| C. Bearing Cone | J. Bearing Cap |
| D. Bearing Cone | K. Diameter of Bore |
| E. Clamp | L. Distance from top of shaft to face of bearing cone |
| F. Special Shaft | |




FIGURE 16

SETTING FOR THE PINION BEARINGS: Figures 14, 17 and 18

Tools needed:

- A dial gauge.
- A small spring balance.
- A piece of string approximately 600 mm (24 in) long.

The pinion bearings need a pre-load of 0.05 mm (0.002 in). To get this amount of pre-load do the procedure as follows:

IMPORTANT: This setting must only be made with new bearings and before the cover and oil seal are installed.

- 1 Put the distance piece F, on the pinion shaft.
- 2 Put the shims K, plus an extra shim 0.5 mm (0.020 in) thick on the pinion shaft against the distance piece.

- 3 Put the outer bearing cone E, on the pinion shaft.
- 4 Install and tighten a NEW ring nut L.

NOTE: To tighten the ring nut to the correct torque, it is necessary to wait until the differential has been installed.

- 5 Put the dial gauge in a position so that the probe is against the face of the pinion. See Figure 17.
- 6 Move the pinion shaft backwards and forwards and measure the amount of clearance. Make a note of this figure.

To find the correct amount of shims needed:

EXAMPLE:

Amount of clearance 0.55 (0.022 in)
Pre-load needed 0.05 mm (0.002 in)
Amount of shims to be removed 0.060 mm (0.024 in)

- 7 Remove the ring nut and the outer bearing cone.
- 8 Remove shims of the correct amount from against the distance piece.
- 9 Install the outer bearing cone and the ring nut.
- 10 Tighten the ring nut. See NOTE for operation 4.

To check the pre-load setting, do the following procedure:

- 1 Make a loop in one end of the piece of string.
 - 2 Put the other end of the string around the groove in the pinion shaft. Make two or three turns so that the string is tight on the shaft. See Figure 18.
 - 3 Put the hook of the spring balance through the loop in the string.
 - 4 Carefully pull the spring balance until the pinion shaft turns.
 - 5 Look at the scale on the spring balance and make a note of the weight that is shown.
 - 6 When the pre-load setting is correct, the weight shown will be 0.48 kg (1.051 lb).
- If the scale shows a difference from this figure it is necessary to remove or add shims between the outer bearing E, and the distance piece, F.

NOTE: If the weight shown is too much: Add shims. If the weight shown is not enough: Remove shims. THIS OPERATION IS IMPORTANT.




FIGURE 17 POSITION OF DIAL GAUGE




FIGURE 18 CHECKING PRE-LOAD

R78.17

R78.18

ASSEMBLING THE AXLE

Assembling the Differential: Figure 21

1. Clean the faces of the spiral gear J and the differential cage, K.
 2. Put the spiral gear in position on the differential cage.
 3. Install the setscrews L with new tabwashers.
 4. Tighten the setscrews to 89 N m (66 lb ft). Bend the tabwashers to hold the setscrews in position.
 5. Install the bush N, thrust washer P, and bevel wheel Q, in the differential cage.
 6. Install the spider T, bevel pinions R, thrust washers S and bevel pinion shafts, G.
- NOTE:** Install the spider first.
7. Align the holes in the spider and the bevel pinion shafts and install the pins, H.
 8. Install the bevel wheel U, on the bevel pinions.
 9. Install the cover, V.
 10. Install the setscrews F, with new tabwashers.
 11. Tighten the setscrews to 48 N m (35 lb ft).
 12. Bend the tabwashers to hold the setscrews in position.
 13. Install the taper roller bearings E, on the end cover V and differential cage, K.

Installing the Differential Unit in the End Plate: Figures 19 and 20.

1. Put the end plate C, on an acceptable stand or in a vice.

NOTE: If you use a vice, make sure that the vice has soft metal jaws.

2. Put the differential unit in position in the end plate.
3. Install the bearing caps A and nuts, B.
4. Install the ring nuts.
5. Carefully tighten the bearing cap nuts.

IMPORTANT: Make sure when you tighten the bearing cap nuts that there is always a clearance between the spiral gear and the bevel pinion. Move the ring nuts if necessary to keep a clearance. If this is not done, damage can be caused to the spiral gear and pinion.

6. Tighten the bearing cap nuts to 130 N m (96 lb ft).
7. Put an acceptable piece of metal bar between the differential cage and the end plate. Make sure that the metal bar will prevent the differential cage from moving when you tighten the ring nut on the bevel pinion shaft. If necessary get assistance to hold the bar in position.




FIGURE 19 END PLATE

- A. Bearing Cap
B. Nyloc Nut
C. End Plate

8. Use the special spanner and a bar one metre (39 in) long to tighten the ring nut L, to a torque equal to 450 N m (330 lb ft).
9. Install a new oil seal D, in the cover, B.
10. Install the cover with a new gasket, C.
11. Install the setscrews A and tighten to 25 N m (18 lb ft).




FIGURE 20 LOCKNUT AND OIL SEAL

- | | |
|-------------|-------------|
| A. Setscrew | D. Oil Seal |
| B. Cover | L. Locknut |
| C. Gasket | |

R78.20




FIGURE 21 DIFFERENTIAL

- | | | |
|---------------------------|----------------------|---------------------|
| D. Ring Nut | K. Differential Cage | R. Bevel Pinion |
| E. Taper Roller Bearing | L. Setscrew | S. Spherical Washer |
| F. Setscrew | M. Spring Pin | T. Spider |
| G. Bevel Pinion Pin | N. Bush | U. Bevel Wheel |
| H. Dowel Pin | P. Thrust Washer | V. Cover |
| J. Spiral Gear and Pinion | Q. Bevel Wheel | |

R78.21

MAINTENANCE AND REPAIR

Setting the Pre-load for the Differential Bearings:

The correct amount of pre-load is 0.08 to 0.10 mm (0.003 to 0.004 in).

1. Turn the ring nut, B, clockwise until the spiral gear is pushed away from the pinion. At the same time hit the bearing caps with a soft faced hammer to align the bearings.
2. Turn the other ring nut, A, clockwise until all clearance in the bearings has been removed. Move the spiral gear wheel while you turn the ring nut and stop turning as soon as the spiral gear wheel is difficult to move.
3. Tighten, (turn clockwise) each ring nut one notch more.
Put a mark on each ring nut for reference.

Setting the Backlash:

1. Put a dial gauge in position so that the probe is in contact with, and at ninety degrees to a tooth on the spiral gear.
2. Check the amount of clearance between the spiral gear and the bevel pinion.
Repeat operations 1 and 2 on two or more teeth at equal distances around the spiral gear.
3. Make a note of the clearances shown by the dial gauge. If there is any difference, put the probe of the dial gauge on the tooth that has the smallest clearance.
4. The correct amount of clearance is 0.15 to 0.30 mm (0.006 to 0.012 in).
Move the spiral gear away from or toward the bevel pinion by turning each ring nut an equal amount until the clearance is correct.
5. Install the pins, C, which prevent the ring nuts from moving.
6. Tighten the bearing cap nuts to 130 N m (96 lb ft).
7. Check again to make sure the clearance is correct.




FIGURE 22

- A. Ring Nut
- B. Ring Nut
- C. Spring Pins

A78.22

Installing the Differential Unit in the Axle Case: Figure 23

1. Clean the faces of the end plate and the axle case.
2. Put a new gasket A, in position on the studs of the axle case.
3. Install the differential unit in the axle case.
4. Install the nuts and tighten to 87 N m (65 lb ft).




FIGURE 23

A. Gasket

R78.23

Assembling the Drive Shafts: Figure 24

1. Install the two spiders F and G, on the central body, H.
2. Install the needle rollers and cups.
3. Install the circlips.
4. Install each fork end separately with needle rollers, cups and circlips.
5. Install the bearing L, the washer D and the circlip C.




FIGURE 24 DRIVE SHAFTS

- | | |
|--------------------|-----------------------|
| A. Special Screw | G. Needle Roller Cup |
| B. Oil Seal | H. Centre Body |
| C. Circlip | J. Special Screw |
| D. Grease Baffle | K. Support Bearing |
| E. Circlip | L. Drive Shaft (Long) |
| F. Spider Assembly | |

R78.24

Installing the Drive Shafts in the Axle Case: Figure 24

1. Before you install the drive shafts, replace the oil seals B, in the axle case.
2. Put the drive shaft in the axle case with the bearing toward the differential. Put your hand inside the axle case to make a support for the fork end of the drive shaft.
3. Turn the drive shaft until the splines on the fork end engage in the splines in the differential.
4. Push the drive shaft into the axle case. Hit the end of the drive shaft with a soft faced hammer to make sure that the support bearing is in the correct position in the bearing housing.
5. Install the special screws A and J, which hold the support bearing in the axle case.
6. Use a hexagon wrench to tighten the special screws.
7. Install the lock nuts and tighten to 180 N m (130 lb ft).

MAINTENANCE AND REPAIR

Installing the Swivel Housings: Figure 25

1. Make an inspection of the bush B, in the stub axle for wear or damage. If necessary replace the bush.
2. Replace the oil seal A, in the stub axle.
3. Put a new gasket M, in position on the studs inside the swivel housing.
4. Install the stub axle C and the nuts.
5. Tighten the nuts to 130 N m (96 lb ft).
6. Replace the oil seal K, in the swivel housing.
7. Get assistance to hold the swivel housing in position on the axle case.
8. Install as a unit the bearing shafts, the oil seal and the bearings F, G and H.

Use a hammer and a soft metal punch to put the bearing shafts in the holes in the axle case.

IMPORTANT: When you do this job, be careful not to cause damage to the hole with a thread in the centre of the bearing shafts.

Setting for the Bearing Clearance:

The correct setting for the swivel bearings is zero. (No clearance, no pre-load). It is made by adding or removing shims E, between the bearing cups F and the covers, D. Do the procedure as follows:

1. Install the bottom cover D, with no shims. Install the setscrews and tighten to 130 N m (96 lb ft).
2. Take all the shims that were removed from both covers. Add to these shims another shim 0.5 mm (0.020 in) in thickness.
3. Put all the shims in position on the top bearing cup.
4. Put the top cover in position.
5. Install the setscrews. Tighten the setscrews evenly to 20 N m (15 lb ft).
6. Use a feeler gauge to measure the gap between the cover and the face of the swivel housing. Make a note of this measurement (A).
7. Remove the top cover and ALL the shims.
8. Use a micrometer to measure the total thickness of ALL the shims. Make a note of this measurement (B).

To find the TOTAL thickness of shims needed:

EXAMPLE:

Measurement of shims (B)	0.80 mm (0.032 in)
Minus (-) measurement of gap A	0.30 mm (0.012 in)
TOTAL shims needed	0.50 mm (0.020 in)

To hold the swivel housing in the correct position in the axle case, an equal amount of shims must be installed under each cover.

Using the example, the amount of shims needed under EACH cover is:




FIGURE 25 ARRANGEMENT OF SWIVEL HOUSING

A. Oil Seal	G. Oil Seal
B. Stub Axle Bush	H. Bearing Pin
C. Stub Axle	J. Seal
D. Cover	K. Seal
E. Shims	L. Swivel Housing
F. Bearing	M. Gasket

TOTAL shims needed 0.50 mm (0.020 in).

Shims needed under each cover $\frac{0.50 \text{ mm}}{2}$ (0.020 in)

$$= 0.25 \text{ mm (0.010 in)}.$$

9. Remove the bottom cover, put the correct amount of shims in position on the bearing cup and install the cover.
10. Install the setscrews and tighten to 130 N m (96 lb ft).
11. Put the correct amount of shims on the top bearing cup and install the cover.
12. Install the setscrews and tighten to 130 N m (96 lb ft).
13. When you have installed both swivel housings, install the track rod.




FIGURE 26 ARRANGEMENT OF HUB

- | | |
|-----------------|-----------------|
| A. Circlip | G. Circlip |
| B. Spacer | H. Support Gear |
| C. Spacer | J. Ring Nut |
| D. Ball Bearing | K. Annulus Gear |
| E. Gasket | L. Sun Gear |
| F. Ball Bearing | M. Circlip |
| | N. Hub |

R78.26

Installing the Wheel Hubs: Figure 26

1. Put the support gear H, in the internal gear K, install the circlips, A.
2. Install the outer bearing F and the circlip G in the hub.
3. Install the spacer C and the inner bearing, D.
4. Put a new dirt excluder on the inner face of the hub, N.
5. Put the internal gear unit in the hub.
6. Install the hub on the stub axle.
7. Install the centering ring B and a new ring nut, J.
8. Use the special spanner and two bars one metre (39 in) long to tighten the ring nut to a torque equal to 1160 N m (850 lb ft).
9. Install the sun gear L and circlip M, on the drive shaft.

Assembling the Reduction Unit: Figure 27

Special Tools

A piece of shaft 21.6 mm (0.85 in) diameter and 35.6 mm (1.40 in) long.

1. Put the needle rollers F, in the bore of a planet pinion. Use a small amount of grease to keep the needle rollers in position.
 2. Put the special shaft inside the needle rollers.
 3. Put a retainer E and a thrust plate D, at each end of the planet pinion. Use a small amount of grease to keep them in position.
 4. Install a planet pinion with the shaft, retainers and thrust plates in the cover.
 5. Align the hole in the cover with the shaft inside the needle rollers. Align the pin hole in the shaft with the pin hole in the cover and push the pinion shaft L, through the thrust washers, the retainers and the needle rollers. If necessary use a soft faced hammer to put the shaft in position. When the pinion shaft is pushed in position, it will push the special shaft out of the cover.
 6. Use the special shaft to install the other pinions using the same procedure.
 7. When the pinion shafts are in position, install the spring pins, P.
 8. Install new core plugs M, in the holes in the cover.
 9. Put a new gasket on the wheel hub. Use a small amount of grease to keep the gasket in position.
- IMPORTANT:** Make sure that the gasket is clear of the port for oil removal in the wheel hub.
10. Align the hole for the drain plug in the cover with the port for oil removal in the wheel hub.
 11. Install the cover. Install the setscrews N and tighten to 48 N m (35 lb ft).
 12. Fill the hubs and the axle case to the correct level with new oil of the correct grade.
 13. Tighten all the level and drain plugs.




FIGURE 27 ARRANGEMENT OF HUB COVER

D. Thrust Plate	K. Cover
E. Retainer	L. Planet Gear Shaft
F. Roller Bearing	M. Core Plug
G. Planet Gear	N. Setscrew
H. Retainer	P. Spring Pin
J. Thrust Plate	

R78 27

TRANSFER GEARBOX

Removal

1. Clean the area around the transfer gearbox and the drive shaft guard.
2. Clean around the transmission and transfer gearbox drain plugs. Put a container of at least 45 litre capacity under the drain plugs. Remove the drain plugs.
3. When the oil has stopped flowing install and tighten the drain plugs. Put a cover over the container if the old oil is to be used again.
4. To disconnect the drive shaft from the axle, first remove the guard C, Figure 28. Remove the four nuts and bolts D from the drive shaft couplings. Hold the shaft and slide the couplings towards the centre of the shaft.

NOTE: There is a spring between the front of the shaft and the axle bevel pinion shaft. Put a hand around the front of the shaft when lowering to prevent loss of the spring.

5. Make sure the 4 wheel drive control is in the disengaged position then disconnect the control rod.
6. Put a trolley jack under the transfer gearbox as a support.
7. Remove the six normal and two special setscrews which fasten the gearbox to the frame. Make a note of the position of the special setscrews for assembly.
8. Lower the gearbox with the jack and remove.

Installation

1. Clean the flange which connects to the frame. Put a new gasket on the flange. Clean the flange of the main frame.
2. Put the gearbox on a trolley jack and raise it into position in the frame. Enter the dowels carefully and keep the gearbox level during this operation.
3. Install the two special setscrews in the correct positions. Install the other six setscrews which fasten the gearbox to the frame. Tighten all setscrews. Use new spring washers.
4. Put the drive shaft to the front axle in position with the spring at the front end.
5. Make sure the slots of the couplings are aligned. Slide the couplings on to the bevel pinion and gearbox output shafts. Align the bolt holes in the couplings with the grooves around the shafts.
6. Install the four bolts, spring washers and nuts in the couplings and tighten.
7. Install the guard for the driveshaft.
8. Fill the transmission with oil to the correct level. If the old oil is used, DO NOT use the last 5 litres in the bottom of the container. Add new oil to replace this amount.
9. Test the tractor in 4 wheel and 2 wheel drive to check correct operation.

5 litres = 1 gal = 5 U.S. qt.
45 litres = 10 gal. = 48 U.S. qt.




FIGURE 28 TRANSFER GEARBOX REMOVAL AND INSTALLATION

- | | |
|--------------------------------|--------------------------------|
| A. Selector gear | E. Spring |
| B. Connection to control lever | F. Setscrews, gearbox to frame |
| C. Drive shaft guard | G. Drain plug |
| D. Coupling bolts and nuts | |

MAINTENANCE AND REPAIR

Disassembly:

1. Clean the transfer gearbox.
2. Put the transfer gearbox in a vice with the operation lever on top and the input shaft towards you.
3. Use a hammer and a parallel punch to remove the spring pins from the selector fork and jaw.
4. Use a hammer and a soft metal punch to hit the selector rod through the fork and jaw toward the front.
5. Hold a cloth around the selector gear J to prevent the loss of the three detent balls and springs H. Pull the selector gear off the input shaft G and remove the detent balls and springs.
6. Remove the small circlip D from the front end of the input shaft.
Use a hammer and soft metal punch to remove the input shaft toward the rear. Hold the shaft when the bearing is clear of the case, or the shaft will fall.
7. Remove the front bearing and the input gear from the casing. If necessary remove the rear bearing from the input shaft with a 3 leg puller.
8. Remove the circlip which holds the idler shaft front bearing in position.
Use a hammer and soft metal punch to remove the idler shaft M with front bearing toward the front.
9. Remove the inner race for the rear bearing and the idler gear B from the casing.
10. Remove the rear circlip and outer bearing race from the casing.
11. Use a 13 mm spanner to remove the four set-screws which fasten the oil seal housing O for the output shaft.
Remove the housing with gasket and any shims from in front of the front bearing.
12. Remove the rear cover plate T for the output shaft.
13. Use a hammer and a soft metal punch to remove the output shaft R toward the front. Remove the spacer, inner race, and output gear from the casing.
14. Remove the outer race of the rear bearing from the casing.
Remove the inner race of front bearing from the shaft.
15. Remove the spring pin which fastens the operating lever to the operating shaft.
Remove the lever from the shaft.
Remove the shaft from inside the casing.
16. Use a lever to remove the oil seal for the selector shaft from the casing.

Inspection of Parts:

1. Clean all parts and check for wear and damage. Remove paint from front of output shaft.
2. Replace any part which shows too much wear or damage.

NOTE: The gears must be replaced as a set. Rapid wear and failure will occur if a single gear is replaced.

3. Remove any protrusions and sharp edges from the parts with a hone or fine file. Check the ends of the shafts and outer edges of splines especially.
4. Clean and check all flange faces, bores and circlip grooves for damage.
5. Clean and check all threads and holes for damage.
6. Remove the drive coupling from the front of the gearbox pinionshaft and check for wear and damage. Install again, or replace the coupling, if damaged or worn.




FIGURE 29 TRANSFER GEARBOX DISASSEMBLED

- | | |
|----------------------------------|---------------------|
| A. Input gear | O. Oil seal housing |
| B. Idler gear | P. Gasket |
| C. Output gear | Q. Oil seal |
| D. Small circlip | R. Output shaft |
| E. Large circlip | S. Spacer |
| F. Ball bearings | T. Rear cover |
| G. Input shaft | U. Spring pins |
| H. Detent ball and spring (3 of) | V. Selector jaw |
| J. Selector gear | W. Selector fork |
| K. Driving gear | X. Selector rod |
| L. Roller bearings | Y. Operating shaft |
| M. Idler shaft | Z. Operating lever |
| N. Setscrew | |

R7939

MAINTENANCE AND REPAIR

Assembly:

Apply gear oil to each component when assembling.

1. Press a new oil seal into the bore for the selector operating shaft. Make sure the lip is toward the inside of the case.
Apply oil to the lip of the seal.
2. Make sure there are no sharp edges on the end of the operating shaft or damage will be caused to the seal.
Install the operating shaft from the inside of the casing.
3. Install the operating lever and fasten with the spring pin.
4. Press the front roller bearing for the output shaft into the front bore of the casing.
Make sure the thick edge of the inner race is toward the inside of the casing.
5. Install the oil seal housing with all setscrews but without a seal and gasket.
6. Install the spacer and the inner race for the rear bearing on the output shaft. Make sure the shoulder of the inner race is against the spacer.
7. Hold the output gear in position inside the casing with the large boss toward the oil seal housing.
8. Put oil on the front edge of the output shaft. Enter the shaft through the rear bore of casing and output gear into front bearing.
9. Push the shaft through the front bearing.
10. Press the outer race for the rear bearing into the casing and on the shaft.
11. Install the rear cover. Use a new gasket.
12. Remove the front oil seal housing and install a new oil seal, lip toward the gear. Put a new gasket on the housing and install it with any shims which were removed.

NOTE: Be careful when sliding the seal on the shaft or damage will be caused to the lip of the seal.

13. Install the front bearing for the idler shaft.
Make sure the shoulder of the inner race is toward the gear.
Install the front circlip.
14. Hold the gear in position inside the casing with the large boss toward the rear.
Push the idler shaft through the gear and into the front bearing.
15. Install the rear bearing with the thick edge of the inner race toward the gear.
Install the rear circlip.
16. Install the front bearing for the input shaft, into the casing.
17. Press the rear bearing on to the input shaft.
18. Hold the input gear in position inside the casing with the large boss toward the rear.
Push the input shaft through the gear and press it into the front bearing.
19. Install the small circlip to the front of the input shaft.
20. If the selector gear has been removed, put the detent springs and balls in the input shaft gear.
Hold the balls down and press the selector gear on the input shaft gear.

21. Put the selector jaw and fork in position and insert the selector rod from the front. Install the spring pins which fasten the selector jaw and fork to the selector rod.

IMPORTANT: Make sure all circlips are fully in the groove.

Use a hammer and punch to hit into location if necessary.

22. Install the drive gear F, Figure 31, on the pinion shaft of the main gear box.




FIGURE 30 SELECTOR ARRANGEMENT

- | | |
|--------------------|--------------------|
| A. Selector fork | E. Oil seal |
| B. Selector jaw | F. Spring pins |
| C. Selector rod | G. Operating lever |
| D. Operating shaft | |




FIGURE 31 TRANSFER GEARBOX ASSEMBLED

- | | |
|----------------------------------|--------------------------------------|
| A. Small circlip | M. Special setscrew (2 of), to frame |
| B. Large circlip | N. Setscrew, oil seal housing |
| C. Input gear | O. Spacer |
| D. Selector gear | P. Output shaft |
| E. Detent spring and ball (3 of) | Q. Oil Seal |
| F. Drive gear | R. Oil seal housing |
| G. Circlip | S. Output gear |
| H. Idler gear | T. Rear cover, output shaft |
| J. Circlip | U. Ball bearings |
| K. Idler shaft | V. Roller bearings |
| L. Setscrews (6 of), to frame | X. Shims |

NOTE: Item F is installed on the pinion shaft of the main gearbox when installing the transfer gearbox.

R79 40

David Brown®

Service Repair Manual

4WD TRANSMISSION AND FRONT AXLE Mk4 (David Brown)

Section C10 (Pub. 9-37185) April 1979

*Written in Clear
And
Simple
English*

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.

Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual may give details of items which are not part of any specific tractor.

CONTENTS

	Page
INTRODUCTION	C3
SPECIAL TOOLS	C5
HOW IT WORKS	C9
MAINTENANCE	C11
TRANSFER GEARBOX	C13
DRIVE FLANGE OIL SEAL	C13
REMOVING	C14
INSTALLING	C14
DISASSEMBLING	C15
ASSEMBLING	C17
AXLE TO TRANSFER GEARBOX DRIVE SHAFT	C18
FRONT DRIVE AXLE	
DRIVE FLANGE OIL SEAL	C19
REMOVING THE AXLE	C20
INSTALLING THE AXLE	C21
DISASSEMBLY AND ASSEMBLY	C22
Reduction gears	C22
Hubs	C23
Stub axles	C25
Drive shafts	C27
Differential	C28
Steering ram	C35
SPECIFICATIONS	C39

INTRODUCTION

The information in this manual is for the repair of the David Brown Mk 4 front drive axle, and the transfer gearbox.

It also tells you how it works and gives regular lubrication procedures.

For information on parts, see publication 9-39021.

For information on other four wheel drive systems, see the following publications or revisions of these:

		Parts	Repair
Mk 1	Selene	—	Section C2
Mk 2	Kramer for 12 series tractors	9-39051	Section C7
	for 14 series tractors	9-39102	Section C7
Mk 3	Carraro	9-39021	Section C9

SPECIAL TOOLS




FIGURE 1. TOOL FOR REMOVING BUSHES FROM
AXLE AND HUB

- A. 184 mm (7 $\frac{1}{4}$ in)
- B. 38 mm (1 $\frac{1}{2}$ in)
- C. 19 mm ($\frac{3}{4}$ in)
- D. 46.03 to 45.96 mm (1.8125 to 1.8095 in)
- E. 44.45 to 44.46 mm (1.750 to 1.7505 in)
- F. 32 mm (1 $\frac{1}{4}$ in), diameter




FIGURE 2. TOOL FOR INSTALLING AXLE AND
HUB BUSHES

- A. 181 mm (7 $\frac{1}{8}$ in)
- B. 44.4 mm (1 $\frac{3}{4}$ in)
- C. 16 mm ($\frac{5}{8}$ in)
- D. 2.4 mm ($\frac{3}{32}$ in)
- E. 46.82 mm (1 $\frac{13}{16}$ in)
- F. 44.45 to 44.46 mm (1.750 to 1.7505 in)
- G. 1.5 mm ($\frac{1}{16}$ in), radius
- H. 32 mm (1 $\frac{1}{4}$ in), diameter
- J. 63.5 mm (2 $\frac{1}{2}$ in), diameter




FIGURE 3. TOOL FOR INSTALLING OIL SEALS
FOR DRIVE SHAFTS

- A. 171 mm (6 $\frac{3}{4}$ in)
- B. 38 mm (1 $\frac{1}{2}$ in)
- C. 16 mm ($\frac{5}{8}$ in)
- D. 57.94 mm (2 $\frac{3}{4}$ in), diameter
- E. 44.4 mm (1 $\frac{3}{4}$ in), diameter
- F. 41.4 mm (1 $\frac{5}{8}$ in), diameter
- G. 32 mm (1 $\frac{1}{4}$ in), diameter
- H. 62.5 mm (2 $\frac{1}{2}$ in), diameter




FIGURE 4. TOOL FOR INSTALLING HUB OIL SEAL

- A. 110.42 mm (4 $\frac{1}{4}$ in)
- B. 88.1 mm (3 $\frac{1}{2}$ in)
- C. 2.4 mm ($\frac{1}{8}$ in)
- D. 4.7 mm ($\frac{3}{16}$ in)
- E. 11 mm ($\frac{7}{8}$ in)
- F. 28.5 mm (1 $\frac{1}{8}$ in)
- G. 120.6 mm (4 $\frac{3}{4}$ in)






FIGURE 5. SPANNER FOR HUB RING NUT

- A. 77.8 mm ($3\frac{1}{8}$ in), diameter
- B. 88.9 mm ($3\frac{1}{2}$ in), diameter
- C. 15.8 mm ($\frac{5}{8}$ in)
- D. 76.2 mm (3 in)
- E. 101.6 mm (4 in), diameter
- F. 101.6 mm (4 in)
- G. 25.4 mm (1 in), diameter
- H. 2.36 mm ($\frac{1}{8}$ in)

NOTE: Use Churchill tool DB 1008A, which has a $\frac{1}{2}$ in square drive, if available.

FIGURE 6. TOOL FOR SETTING BEVEL PINION SHAFT
(Service Tool DB 8208)

- A. Disc
- B. Shaft
- C. Spacer
- D. Probe, DB 9721A




R79-6

FIGURE 7. TOOL FOR INSTALLING DRIVE FLANGE OIL SEAL

- | | |
|--|---|
| A. 68 mm ($2\frac{1}{8}$ in) | H. & J. 38 mm ($1\frac{1}{2}$ in) diameter |
| B. 6 mm ($\frac{1}{4}$ in) | K. 50 mm (2 in) diameter |
| C. 11 mm ($\frac{7}{8}$ in) | L. 9 mm ($\frac{3}{8}$ in) radius |
| D. 38 mm ($1\frac{1}{2}$ in) | M. 13 mm ($\frac{1}{2}$ in) |
| E. Welded joint | N. 4.5 mm ($\frac{3}{16}$ in) |
| F. 78 mm ($3\frac{1}{8}$ in), diameter | P. 13 mm ($\frac{1}{2}$ in) |
| G. 49.7 mm ± 0.05 mm (1.965 in ± 0.002 in) | R. 3 mm ($\frac{1}{8}$ in) |

NOTE: The surface at 'L' must be very smooth with no tool marks or scratches.



R79-7

FIGURE 8. TOOL FOR REMOVING CUPS OF DRIVE SHAFT UNIVERSAL JOINTS

- | |
|-------------------------------------|
| A. 25 mm (0.98 in) |
| B. 25.4 mm (1 in) |
| C. 8 in \times 1 thread |
| D. Thread same size as slide hammer |
| E. 25.4 mm (1 in) diameter |
| F. Welded joint |

HOW IT WORKS

The drive for the front axle is taken from the gearbox bevel pinion shaft. A transfer gearbox is installed under the main frame, forward of the gearbox. The front of the bevel pinion shaft is connected to the input shaft of the transfer gearbox. A muff coupling is used for this purpose.

The transfer gearbox has a vertical drive train of three gears. The top gear is fastened to the input shaft by splines. The top gear is permanently engaged with the idler gear which is engaged with the output gear. The output gear rotates on the output shaft on six bearing pads, made of phosphor-bronze, installed in between the splines.

When 4-wheel drive is selected, the bottom gear is connected to the output shaft by a dog clutch. The dog clutch is operated by a cable.

The output shaft of the transfer gearbox is connected to the front axle by a drive shaft. The shaft is designed to connect components which are not aligned. The drive shaft has a universal joint at each end. One universal joint is on a splined sliding

coupling to give a variable shaft length as the front axle tilts. The shaft is connected to the bevel pinion of the front axle differential.

The bevel pinion is engaged with the spiral gear (crown wheel). The spiral gear is fastened to the differential cage. Inside the cage are two bevel gears on a shaft which is fitted to the cage. The complete assembly rotates. The two bevel gears are engaged with two bevel wheels. The bevel wheels are fitted on splines at the inner end of each drive shaft. The drive shafts run in bushes pressed into the axle casing. Each drive shaft has a sun gear fitted on splines at the hub end. The sun gear is permanently engaged with three planet gears which are engaged with an annulus gear. The annulus is fitted on splines on the stub axle and held stationary. The bearing pins on which the planet gears rotate, fit into holes in the hub end plate. The other end of the pin fits into the planet carrier which is fastened to the end plate.




FIGURE 9. DRIVE TRAIN FOR 4-WHEEL DRIVE

- A. Input shaft
- B. Input gear of transfer box
- C. Idler gear of transfer box
- D. Output gear of transfer box
- E. Drive shaft to front axle differential
- F. Differential of front axle
- G. Drive shafts to hub units
- H. Sun gear in hub reduction unit
- J. Planet gear
- K. Annulus gear

When the drive shaft rotates, the sun gear rotates the planet gears inside the annulus. The planet gears move around the annulus and rotate the hub at a slower speed than the drive shafts. Approximate ratio is 3.75:1.

The stub axles are connected to the axle case by bearing pins and taper roller bearings. The drive shafts have a universal joint at the same position. This permits steering movement of the front wheels.

Operation

Never try to engage 4-wheel drive if the rear wheels have a loss of traction.

Always look for ground conditions where 4-wheel drive can be needed and engage 4WD before you reach it.

Engage 4-wheel drive when there is little or no load on the transmission.




FIGURE 10. HUB REDUCTION GEARS

- A. Annulus gear, (stationary)
- B. Planet gears
- C. Sun gear
- D. Drive shaft
- E. Needle roller bearing
- F. Bearing pin




FIGURE 11. STUB AXLE AND UNIVERSAL JOINT

- A. Stub axle
- B. Bearing pin
- C. Universal joint
- D. Axle case

MAINTENANCE

TRANSFER GEARBOX

The transfer gearbox uses the same oil as the main gearbox.

Change the oil at the First Service 50/100 hours.

Check the level of the oil in the main gearbox every 60 hours.

Change the oil every 500 hours. Use a container of at least 42 litre capacity.

FRONT AXLE

If ground conditions are wet or dusty, put grease in the following grease fittings each day. See Figure 12.

(a) Swivel bearings, 4 fittings. Remove the square plug to gain access to the top fittings.

(b) Axle drive shaft, 3 fittings.

(c) Trunnion pin, 2 fittings, use SAE 90 EP Oil, not grease for these fittings.

If conditions are not wet or dusty, add grease every 60 hours to the fittings above.

NOTE: Clean all grease fittings before you put the grease gun on the fitting.

Add grease until it comes out of the gaps between components. Remove this grease.

At the First Service, 50/100 hours, change the oil in the differential and hubs as follows.

Differential:

1. Clean around the drain plug B and filler/level plug A, Figure 13.
2. Put a container of at least 8 litre capacity under the drain plug B.
3. Remove the filler/level plug A and the drain plug. Let the old oil flow into the container.
4. When the oil has stopped flowing, install and tighten the drain plug B.
5. Put new oil in through the hole for the filler/level plug. Add oil until it is level with the bottom of the hole.
6. Install the filler/level plug and tighten.

Hubs:

1. Clean area around all plugs.
2. Move the tractor until one of the plugs on each hub is at the lowest point. See D Figure 13.
If the tractor cannot be moved use the following method.
Use a jack to raise the front wheels clear of the ground and turn the wheels.
3. Put a 1 litre container under the lower plug D and remove plugs D and C.
4. When the oil stops flowing, install plug D and tighten.

5. Fill with new oil through the hole for plug C until level with the bottom of the hole.

6. Install the filler/level plug C and tighten.

Every 250 hours, check the level of the oil in the front hubs and the differential. See Figure 13.

Make sure the axle case breathers are free from dirt.

If dirty, remove, and clean with compressed air.

Every 500 hours, do the same as for 250 hours, plus:

Put grease through the 2 fittings at D Figure 12 until it comes out from the hub to stub axle joint.

The fitting is at the front on the left-hand stub axle and at the rear on the right-hand.

Every 1000 hours, remove the oil from the hubs and differential. Fill the hubs and differential to the correct level with the correct grade of oil.




FIGURE 12. GREASE FITTINGS FRONT AXLE 4WD

- | | |
|-----------------------------------|----------------------------|
| A. Rear fitting for trunnion pin | E. Bottom bearing pin |
| B. Front fitting for trunnion pin | F. Universal joint fitting |
| C. Top fitting for bearing pin | G. Front joint fitting |
| (Remove access plug) | H. Sliding joint fitting |
| D. Stub axle fitting | J. Rear joint fitting |




FIGURE 13. FRONT AXLE 4WD:
LEVEL AND DRAIN PLUGS

- | | |
|-----------------------------|---------------------|
| A. Level plug, differential | C. Level plug, hubs |
| B. Drain plug, differential | D. Drain plug, hubs |

1 litre = 1 1/4 pt = 1 U.S.qt
42 litres = 9 1/2 gal = 44 U.S.qt
8 litres = 14 pt = 8 1/2 U.S.qt

TRANSFER GEARBOX

DRIVE FLANGE OIL SEAL

Replacement

1. Put a container which can hold at least 42 litres under the gearbox. Remove the drain plugs for the transmission and transfer box.
2. Install drain plugs when the oil has stopped flowing.
3. Remove the bolts which fasten the drive shaft to transfer gearbox flange and lower to the ground.
4. Engage a gear in the main gearbox and 4-wheel drive, check hand brake is fully applied.
5. Remove the flange nut, washer and cork seal from the end of the shaft.
6. Use a 3 leg puller to pull off the drive flange.
7. Remove the four setscrews holding the oil seal housing to the transfer box case. Remove the oil seal housing and the gasket.
8. Use a lever to remove the old oil seal.
9. Clean and check all parts for wear or damage, especially the oil seal location on the drive flange. Replace the drive flange if necessary.
10. Press a new seal into the housing with an oil seal replacing tool as shown in Figure 7.
11. Install the oil seal housing with a new gasket.
12. Install the drive flange with a new cork seal, washer and nut.
13. Tighten nut to 190 Nm.
14. Fasten the drive shaft to transfer gearbox flange.
15. Fill the transmission casing with oil to the correct level.

NOTE: If the old oil is used again, **do not** use the last 5 litres in the container. Add new oil to replace the last 5 litres. Make sure the container has a cover if the old oil is used.




FIGURE 14. DRIVE FLANGE ASSEMBLY

- A. Nut
- B. Washer
- C. Seal washer
- D. Flange and shield
- E. Oil seal
- F. Bolt
- G. Seal housing

190 Nm = 19.3 kg m = 140 lb ft
 42 litres = 9½ gal = 44 U.S. qt
 5 litres = 8 pt = 6 U.S. qt

REMOVING THE TRANSFER GEARBOX

1. Put a container which can hold at least 42 litres under the transmission drain plugs. Remove the plugs.
2. Install the drain plugs when the oil has stopped flowing.
3. Remove the bolts which fasten the drive shaft to the transfer box. Lower the shaft to the ground.
4. If the output shaft or oil seal is to be removed, loosen the nut which fastens the flange and guard.
5. Remove the cab if fitted and remove the gearbox cover.
6. Remove the bolt which fastens the muff coupling to the bevel pinion shaft. Slide the coupling backward clear of the transfer box input shaft.
7. Put an acceptable jack under the transfer box to hold it in position.
8. Remove the nuts and bolts which fasten the transfer box to the main frame.
9. Lower the transfer box and remove to a work bench.

INSTALLING THE TRANSFER GEARBOX

1. Clean the faces of the transfer gearbox and the main frame.
2. Remove layers of the new gasket until it is the same thickness as the old gasket. Put the gasket on the transfer gearbox.
3. Put the gearbox on an acceptable jack and raise into position in the main frame. Be careful when the casing goes over the studs to prevent damage to the threads.
4. Install the nuts and bolts and tighten to 163 Nm.
5. If the drive flange nut has been removed, tighten to 190 Nm.
6. Make sure the muff coupling will slide on to the input shaft easily.
7. If it does not, then the transfer gearbox must be removed and the position adjusted up or down. This is done by removing layers of the gasket.
9. Install the coupling bolt.
10. Install the main gearbox cover.
11. Install the cab.
12. Raise the axle drive shaft into position and fasten it to the transfer gearbox output shaft. Tighten the bolts to 54 Nm.
13. Fill the transmission with the correct grade of oil to the correct level.




FIGURE 15. REMOVING THE TRANSFER GEARBOX

- A. Drive shaft
- B. Selector cable connection
- C. Front bolts
- D. Rear nuts
- E. Bolt and nut, coupling
- F. Coupling, to main gearbox

42 litres = 9 $\frac{1}{2}$ gal = 44 U.S. qt
 163 Nm = 16.6 kg m = 120 lb ft
 190 Nm = 19.4 kg m = 140 lb ft
 54 Nm = 5.5 kg m = 40 lb ft

DISASSEMBLY OF THE TRANSFER GEARBOX

Figure 16.

1. Remove the setscrews which fasten the end cover A for the input shaft C.
2. Remove the end cover and shims.
3. Press out the input shaft complete with taper roller bearing.
4. Remove the bearing cup which comes out with the input shaft.
5. Use a hammer and soft metal punch to remove the bearing cone from the input shaft.
6. Remove the other bearing cone and input gear B from the casing.
7. Use the hammer and soft metal punch to remove the other bearing cup from the casing.
8. Remove the setscrews which fasten the end covers F for the idler shaft H.
9. Remove the end covers and shims.
10. Press the idler shaft complete with bearing out of the casing.
11. Remove the bearing cup which comes out with the shaft.
12. Remove the idler gear and the bearing cup from the casing.
13. Use a hammer and soft metal punch to remove the bearing cone from the idler shaft.
14. Remove the setscrews which fasten the bottom cover R to the transfer box. Remove the bottom cover.
15. Remove the nut I and washers from the front of the output shaft.
16. Use a 3 leg puller to remove the drive flange K and guard.
17. Remove the setscrews which fasten the oil seal housing to the transfer gearbox. Remove the oil seal housing.
18. Remove the setscrews which fasten the rear end cover U and cable bracket V to the transfer box. Remove the shims.
19. Press the output shaft out through the rear of the transfer gearbox. Make sure the threads are protected while doing this.
Make sure the gear is kept aligned with the shaft while pressing the shaft out.
20. Remove the six bearing pads Q from the shaft.
21. Remove the bearing cup which comes out with the output shaft.
22. Use a hammer and soft metal punch to remove the bearing cone from the shaft.
23. Remove the distance piece T.
24. Remove the output gear through the bottom of the casing.
25. Remove the fixed gear from the dog clutch.
26. Remove the dog clutch gear from the selector fork.
27. Use a hammer and punch to remove the pin which fastens the selector fork to the selector shaft Z.
28. Remove the fork and shaft.
29. Remove the special bush and bearing cone. Do not remove the cone from the bush unless a new bearing is to be fitted.
30. Use a hammer and soft metal punch to remove the bearing cup from the casing.




FIGURE 16. TRANSFER GEARBOX ASSEMBLY

- | | |
|--|--------------------|
| A. Front cover, input and idler shafts | N. Bush |
| B. Input gear | O. Dog gear |
| C. Input shaft | P. Output shaft |
| D. Taper roller bearings | Q. Bearing pad (6) |
| E. Shims | R. Bottom cover |
| F. Rear covers | S. Output gear |
| G. Idler gear | T. Distance piece |
| H. Idler shaft | U. Rear end cover |
| I. Nut | V. Cable bracket |
| J. Washers | W. Trunnion pin |
| K. Flange and shield | X. Dog clutch |
| L. Oil seal | Y. Selector fork |
| M. Oil seal housing | Z. Selector shaft |

ASSEMBLING THE TRANSFER GEARBOX

1. Clean all faces of the end covers, oil seal housing and transfer gearbox casing.
2. Install the front bush N Figure 16 and bearing cone on to the output shaft.
3. Enter the output shaft P through the bottom front hole of the casing.
4. Install the fixed gear O, dog clutch X and output gear S on to the output shaft through the bottom of the casing.
5. Put the front bearing cup on to the front bearing cone.
6. Install a new oil seal.
7. Put a new gasket on the seal housing M.
8. Put the seal housing in position. Install the setscrews and tighten evenly to push the front bearing cup into position. Tighten the setscrews to 27 Nm.
9. Install the six bearing pads Q into the bore of the output gear through the rear hole.
10. Install the rear spacer T and bearing cone on to the output shaft. Hold the transfer box and seal housing while pushing or pulling the bearing into position.
11. Press the rear bearing cup into the casing, rotate the shaft while doing this.
12. To find the correct amount of shims E needed for the bearing adjustment use the following procedure.
 - (a) Use a depth micrometer to measure the distance between the rear bearing cup and the rear face.
 - (b) Make a note of the measurement and add 0.25 mm for the gasket thickness.
 - (c) Subtract 0.075 mm from the total.
 - (d) Select shims to the thickness of the final result.
- NOTE: The tolerance permitted is 0.05 to 0.0 mm.
13. Install the shims with a 0.75 mm shim next to the end cap.
14. Put a new gasket on the end cover U. Fasten the cover to the casing with the bottom two setscrews.
15. Fasten the cable bracket V to the end cover with the top two setscrews.
16. Tighten the four setscrews to 27 Nm.
17. Put oil on the lip of the oil seal L. Install the flange and guard K on to the output shaft. Be careful when pushing the flange through the oil seal, to prevent damage.
18. Install the washer, seal and nut on to the shaft. Tighten the nut after the transfer gearbox has been installed in the tractor.
19. Install a new selector shaft oil seal.
20. Install the selector fork Y through the bottom of the casing. Enter the trunnion pins W in the groove of the dog clutch X.
21. Remove any protrusions and put grease on the selector shaft. Push the selector shaft through the bores of the casing and the fork.
22. Install the pin which fastens the fork to the shaft. Put Loctite on a new core plug and press it into the casing, if old plug is removed.
23. Press the front bearing cup for the idler shaft H into the casing.
24. Install the front cover and tighten the setscrews to 27 Nm.
25. Press the rear bearing cone on to the idler shaft, thick edge to the shoulder.
26. Put the front bearing cone and the idler gear in position inside the casing.
27. Press the idler shaft through the gear and into the front bearing cone.
28. Press the rear bearing cup into the casing.
29. Use the same procedure to select the correct amount of shims as for the output shaft. See step 12.
30. Install the rear cover and tighten the setscrews to 27 Nm.
31. Repeat steps 23 to 30 to install the input shaft.
32. Put a new gasket on the bottom cover and fasten it to the casing. Tighten the setscrews to 27 Nm.

0.25 mm	= 0.010 in
0.075 mm	= 0.003 in
0.75 mm	= 0.030 in
0.010 mm	= 0.004 in
0.05 mm	= 0.002 in
27 Nm	= 2.8 kg m = 20 lb ft

AXLE TO TRANSFER GEARBOX DRIVE SHAFT

DISASSEMBLY

Figure 17

1. Remove the eight bolts and nuts from each flange and remove the shaft from the tractor.
2. Clean the shaft before disassembling.
3. Remove the sliding joint by turning the cap counter-clockwise, then slide the joint off the shaft.
4. Release the tension on the circlips by lightly hitting or pressing each cup away from circlip.
Use circlip pliers to remove the circlips from the universal joint cups.
Remove all paint from around the cups and circlip grooves.
Remove any protrusions from around the cups and grooves.
Repeat this on all cups.
5. Press out one cup on each side of the joint as shown in Figure 17.
6. Hold the part of the cup which is out in a vice as shown.
Turn and pull up on the yoke at the same time to remove the cup.
Hit with a soft face hammer at F as shown if necessary to help the operation.
7. Repeat steps 5 and 6 on all other cups.
8. Remove the cross journal.

ASSEMBLY

Figure 18

1. Insert the cross journal into the yoke of the shaft as far as it can go.
2. Carefully put a cup complete with needle bearings on to the cross journal. Make sure the bearings do not move out of position when doing this.
3. Use a 6 in vice as shown to press the cup into the yoke as shown in Figure 18.
Hold the cross journal towards the yoke while doing this.
Use a spacer which will push the cup into the yoke until the circlip groove is clear.
4. Install the circlip and press into position with the same spacer used for the cup. Make sure the circlip fully enters the groove. Use a hammer and punch to hit lightly into position if necessary.
5. Carefully move the cross journal towards the opposite side of the yoke as far as possible.
Make sure it stays in the cup which has been fitted.
6. Carefully put the second cup in position on the journal and press into place with the vice as shown.
7. Repeat operations 3 and 4.
8. Install the cross journal in the other yoke and repeat operations 2 to 7.

9. After the assembly is complete move the joint to see if it is free.
If it is not free, hit the yokes lightly with a hammer while moving the joint.
If the joint still feels tight, it can indicate a bearing is out of position.
The joint must be disassembled and the bearings checked.
 10. Align the arrows on shaft and sliding joint, as shown in Figure 19.
Slide the sliding joint on to the splines and fasten the cap.
- IMPORTANT:** Make sure the universal joints are aligned as shown in Figure 19, or the joints will fail.




FIGURE 17. REMOVING BEARING CUPS FROM UNIVERSAL JOINT

- | | |
|----------------|--------------------------------|
| A. Press | D. Piece of metal tube |
| B. Spacer | E. 6 in vice |
| C. Bearing cup | F. Position to hit with hammer |




FIGURE 18. INSTALLING BEARING CUPS IN A UNIVERSAL JOINT

- | | | |
|--------------|-----------------|-----------|
| A. 6 in vice | B. Bearing cups | C. Spacer |
|--------------|-----------------|-----------|




FIGURE 19. INSTALLING THE SLIDING JOINT

FRONT DRIVE AXLE

DRIVE FLANGE OIL SEAL

1. Put a container which can hold at least 9 litres under the differential. Remove the drain plug.
2. Install the drain plug when the oil has stopped flowing.
3. Remove the bolts which fasten the drive shaft to bevel pinion flange and lower the shaft to the ground.
4. Make sure the hand brake is fully applied and engage a gear in the main gearbox.
5. Remove the flange nut, washer and cork seal.
6. Use a 3 leg puller to pull off the drive flange.
7. Use a lever to remove the old oil seal.
8. Clean and check all parts for wear and damage, especially the oil seal location on driveshaft flange. Replace drive flange if necessary.
9. Press a new seal into the differential housing until it is against the distance piece.
Use a tool made to the dimensions shown in the Figure 7.
10. Install the drive flange with a new cork seal, washer and nut.
11. Tighten nut to 190 Nm.
12. Fasten the drive shaft to differential flange.
13. Fill the differential with oil to the correct level.
14. Put gears in neutral.
15. Test the tractor on the highway, then check for oil leaks.




FIGURE 20. DRIVE FLANGE ASSEMBLY

- A. Nut
- B. Washer
- C. Seal washer
- D. Flange and shield
- E. Oil seal
- F. Spacer

9 litre = 16 pt = 10 U.S. qt
190 Nm = 19.3 kg m = 140 lb ft

REMOVING AND INSTALLING

REMOVING THE AXLE

1. Apply the hand brake and put blocks in front of and behind the rear wheels. Drain the oil from the differential and hubs if the axle is going to be disassembled.
2. Remove the bolts which fasten the drive shaft to the axle bevel pinion shaft.
3. Put an acceptable container under the steering ram and remove the hydraulic pipes.
4. Put a jack of at least 3 tons capacity under the centre of the axle as a support.
5. Loosen the front wheel nuts.
6. Raise the front of the tractor and put supports between the main frame and the ground.
7. Remove the front wheels.
8. Lower the tractor on to the supports but keep the jack under the axle.
9. Loosen the locking bolt for the trunnion pin five turns. Hit the head of the locking bolt to push the sleeve clear of the trunnion pin. Remove the bolt and sleeve.

NOTE: On later tractors the bolt and sleeve have been replaced with a cotter pin. The trunnion pin has a flat on it.

10. Remove the core plug from the trunnion pin bore.
11. Adjust the jack to hold the weight of the axle with the tractor weight firmly on the supports.
12. Use a slide hammer to remove the trunnion pin from the front extension. The pin has a hole in the centre which has a $\frac{1}{2}$ UNC thread.
13. Get assistance to hold the axle while it is lowered to the ground and moved clear of the tractor.
14. Use a hoist to lift the axle to a work bench or stand.




FIGURE 21. REMOVING THE AXLE

- A. Front frame
- B. Trunnion bracket
- C. Trunnion pin
- D. Locking bolt
- E. Sleeve

163 Nm = 16.6 kg m = 120 lb ft

INSTALLING THE AXLE

1. Use a hoist to lift the axle on to a jack.
 2. Install the 'O' rings on the thrust washers for the trunnion pin.
 3. Put thick grease on both sides of the thrust washers and install into the axle trunnion bracket.
 4. Raise the axle into position under the tractor. Make sure the thrust washers are not moved out of place when doing this. Make sure the axle is kept level.
 5. Use a bar to align the holes of the axle and front extension. Put grease on the trunnion pin, install the 'O' ring.
 6. Enter the pin into the front extension. Turn the pin until the chamfer of the bolt hole is toward the left-hand side of the tractor.
 7. Use a soft face hammer to hit the pin into position.
 8. Install the bolt and sleeve which fastens the trunnion pin in position. The sleeve fits in the left-hand side of the trunnion bracket.
 9. Tighten the bolt then install new locking wire to hold it.
 10. Raise the drive shaft into position. Install the bolts and nuts through the flanges and tighten.
 11. Connect the steering pipes to the steering ram.
- NOTE: Make sure the pipes are connected to the correct positions.
12. Fill the steering reservoir with the correct oil, with steering straight forward.
 13. Remove air from the system as follows:
 - (a) Run the engine at idle speed.
 - (b) Loosen the left-hand bleed screw and turn the steering to the right. Tighten the bleed screw.
 - (c) Loosen the right-hand bleed screw and turn the steering to the left. Tighten the bleed screw.
 14. Install the front wheels and nuts.
 15. Raise the tractor and remove the supports from the frame.
 16. Lower the tractor to the ground and tighten the wheel nuts to 163 Nm.
Remove the jack.
 17. Check the oil level in the steering reservoir with the wheels straight forward.




FIGURE 22. COMPONENTS OF THE TRUNNION PIN

- A. Core plug
- B. Bush, (two off)
- C. Trunnion pin
- D. Seal, (two off)
- E. Thrust washer, (two off)
- F. 'O' ring


DISASSEMBLY AND ASSEMBLY

DISASSEMBLING THE REDUCTION GEARS

1. Remove the oil from the differential and front hubs.
2. Remove the eight setscrews which fasten the end plate to the front hub.
3. Remove the end plate complete with planet gears and carrier.
4. Remove the six setscrews which fasten the planet carrier to the end plate.
5. Remove the planet carrier and gears.
6. Remove the needle roller bearings.
7. Use a hammer and soft metal punch to remove the bearing pins from the planet carrier.

If the bearing pins stay in the end plate B, do not remove unless new pins are to be fitted.

To remove the pins from the end plate, hold the pins in a vice. Pull up on the end plate and turn it at the same time.



R79-20

ASSEMBLING THE REDUCTION GEARS

1. Press the bearing pins for the planet gears into the end plate.
2. Put the needle roller bearings on to the pins.
3. Put the planet gears on to the bearings.
4. Put the planet carrier on the end plate. Install the tabwashers and the six setscrews which fasten the planet carrier to the end plate. Tighten the setscrews to 41 Nm, bend the tabwashers against the setscrews.
5. Clean the faces of the end plate and hub housing.
6. Install a new gasket on the dowels of the hub housing.
7. Install the end plate on the hub housing.

Install the eight setscrews which fasten the end plate to the housing.

Tighten the setscrews to 101 Nm.

FIGURE 23. HUB UNIT DISASSEMBLED

A. Setscrews, end plate	N. Setscrew, planet carrier
B. End plate	O. Ring nut
C. Gasket	P. Tabwasher
D. Split ring	R. Annulus gear
E. Sun gear	S. Taper roller bearing
F. Spacer	T. Shims
G. Bearing pin	U. Spacer
H. Needle roller bearing	V. Plug
J. Planet gears	W. Housing
K. Planet carrier	X. Taper roller bearing
L. Dowel	Y. Oil seal
M. Tabwasher	Z. Wear sleeve

41 Nm = 4 kg m = 30 lb ft
101 Nm = 10 kg m = 75 lb ft

THE HUBS

DISASSEMBLING THE HUBS

1. Carefully, pull the sun gear drive shaft out approximately 5 mm. Push the sun gear in until the split ring can be removed.

NOTE: Damage can be caused to the drive shaft oil seal if the shaft is pulled out too far.

2. Remove the sun gear and the thrust washer.
Do not push the drive shaft into the axle, this will cause damage to the oil seal.
3. Bend the tabwasher away from the ring nut. Use the special spanner to remove the ring nut. See Figure 5.
Remove the tabwasher.
4. Remove the annulus ring and the outer bearing cone together.
5. Remove the shims and spacer from the stub axle.
6. Carefully remove the hub housing from the stub axle.
7. Remove the bearing cone from the annulus ring.
8. Remove the bearing cone and the oil seal from the stub axle.
9. Use a hammer and soft metal punch to remove the two bearing cups from the hub housing.




FIGURE 24. HUB ASSEMBLED

- | | |
|----------------|-----------------|
| A. End plate | F. Annulus gear |
| B. Housing | G. Shims |
| C. Sun gear | H. Ring nut |
| D. Planet gear | J. Stub axle |
| E. Bearing pin | |

ASSEMBLING THE HUBS

1. Check the wear sleeve for the oil seal on the stub axle for wear or damage. Replace if necessary.
2. Use the special tool shown in Figure 1 on page 3 to remove the bush.
Align the sleeve with the shoulder of the stub axle, when installing.
3. Install the complete inner bearing into the hub housing.
4. Press the oil seal, lip toward the bearing, into the hub housing.
5. Put the hub housing in position on the stub axle.
6. Slide the spacer on to the stub axle, chamfer toward inner bearing.
7. Install shims to the value of 2.03 mm next to the spacer.
8. Press the outer bearing cone on to the annulus ring and the cup into the hub housing.
9. Put the annulus ring in position on the stub axle.
10. Install the nut without the tabwasher.

Use tool No. DB 1008 to tighten to 203 Nm. See Figure 5 on page 7.




FIGURE 25. ARRANGEMENT OF OIL SEALS

- | | |
|----------------|-------------------|
| A. Hub housing | D. Oil seal |
| B. Oil seal | E. Drive shaft |
| C. Stub axle | F. Grease fitting |

5 mm = 0.19 in
2.03 mm = 0.079 in
203 Nm = 21 kg m = 150 lb ft

11. Put the probe of a dial gauge against the outside face of the hub housing.

Move the housing inward then outward and rotate the housing at the same time.

Make a note of the amount of movement.

12. To find the correct amount of shims to remove, use the following example:

Example: Amount of movement	0.41 mm
Amount of preload	0.10 mm
Thickness of shims to remove	0.51 mm

NOTE: Tolerance on preload is 0.08 to 0.13 mm

13. Remove the nut, annulus ring and the shims.

14. Install the correct amount of shims.

Install the annulus ring and the tabwasher and nut.

Tighten the nut to 203 Nm and bend the tabwasher to hold it.

15. Install the thrust washer and then the sun gear on to the drive shaft.

16. Pull the drive shaft out just far enough to install the split ring. Push the drive shaft in when the split ring is in position.




FIGURE 26. CHECKING END MOVEMENT OF HUB HOUSING

- A. Housing
B. Dial gauge

0.41 mm	= 0.016 in
0.10 mm	= 0.004 in
0.50 mm	= 0.020 in
0.08 mm	= 0.003 in
0.13 mm	= 0.005 in
203 Nm	= 21 kg m = 150 lb ft

STUB AXLES

DISASSEMBLING THE STUB AXLES

This operation can be done without disassembling the hubs, if necessary.

1. Remove the nut which fastens the ball socket to the steering lever.
2. Use a copper face hammer to hit the steering link until the ball socket is released. Remove ball socket assembly.
3. Remove the four bolts which fasten the steering lever to the stub axle.
Remove the steering lever.
4. Remove the four setscrews which fasten the bottom bearing pin to the stub axle.
5. Install two of the setscrews into the two holes which have threads in the bearing pin.
Tighten the setscrews equal amounts until the pin is pulled from the bearing.
6. Remove the four setscrews which fasten the top bearing pin to the stub axle.
7. Install two of the setscrews into the two holes which have threads in the bearing pin. Get assistance to hold the stub axle.
Tighten the setscrews equal amounts until the pin is pulled from the stub axle.
Remove the bearing pin and shims.

NOTE: When the stub axle is being removed complete with the hub, use a sling and hoist or jack. The drive shaft will come away with the assembly. Get assistance to hold the drive shaft as it comes out of the case.

A new seal must be installed in the axle case when assembling.

8. Slide the stub axle off the drive shaft.
9. Remove the setscrews from the bearing pins.
10. Remove the sealing discs and 'O' rings.
11. Remove the bearing cones.
12. Use a hammer and a soft metal punch to remove the bearing cups.
13. Remove the grease shields from the axle case.
14. Remove the oil seal from the stub axle with a lever.
15. Remove the wear sleeve (mild steel) for the hub oil seal from the stub axle as follows:
 - (a) Use a hacksaw to cut almost through the sleeve.
 - (b) Use a chisel to finish cutting through the sleeve. Take care not to damage the stub axle surface under the sleeve.
16. Use the special tool in Figure 1 to remove the bush from the stub axle.




FIGURE 27. STUB AXLE ASSEMBLY

- | | |
|--------------------------|-------------------|
| A. Nut, ball socket | K. Shims |
| B. Ball socket | L. Sealing discs |
| C. Steering link | M. 'O' ring |
| D. Steering lever | N. Bearings |
| E. Setscrew lever | P. Grease shield |
| F. Steering stop screw | R. Axle case |
| G. Stub axle | S. Grease fitting |
| H. Setscrew, bearing pin | T. Bush |
| J. Bearing pin | U. Oil seal |

ASSEMBLING THE STUB AXLES

1. Check the bush in the stub axle for wear or damage. Replace if necessary.
2. Press a new oil seal into the stub axle. Make sure the lip is toward the end of the hollow shaft.
3. Install the grease shields and taper roller bearings into the ends of the axle case.
4. Check the 'O' rings on the sealing discs for wear or damage.

Replace if necessary. Install the discs into the axle case.

5. Get assistance to hold the stub axle or front hub reduction unit in position on the axle case.
6. Install the bottom bearing pin. Install the four setscrews which fasten the pin to the stub axle and tighten to 68 Nm.

7. Install the top bearing pin without shims.

Install the four setscrews.

Tighten each setscrew an equal amount until all free up and down movement of the pin is just removed.

8. Use a feeler gauge to measure the gap under the bearing pin flange. Make a note of the measurement.

9. Remove the top bearing pin.

Install shims 0.38 mm less than the measurement of the gap on the pin.

NOTE: This will give the correct bearing preload of 0.10 to 0.15 mm with full load on the axle.

10. Install the bearing pin and shims.

Install the four setscrews and tighten to 68 Nm.

11. Install the steering lever and the four bolts which fastens the lever to the stub axle.

Tighten the bolts to 163 Nm.

12. Install the steering link.

Install the nut which fastens the link to the steering lever and tighten to 135 Nm.

13. Put grease in the grease fittings for the swivel pins.

Remove the square plug to gain access to the top fittings.




FIGURE 28. TOP BEARING PIN ARRANGEMENT

- | | |
|------------------|-------------------------|
| A. Stub axle | E. Taper roller bearing |
| B. Bearing pin | F. Sealing disc |
| C. Axle case | G. Shims |
| D. Grease shield | |

0.15 mm = 0.006 in
0.10 mm = 0.004 in
0.38 mm = 0.015 in
68 Nm = 7 kg m = 50 lb ft
135 Nm = 14 kg m = 100 lb ft
163 Nm = 17 kg m = 130 lb ft

DRIVE SHAFTS

DISASSEMBLY

1. Carefully slide the shaft out of the axle case and clean before disassembling.
2. Remove any tension from the circlips which hold the bearing cups by pressing down on the cup.
3. Use circlip pliers to remove each circlip.
4. Use a 12 mm spanner to remove the plugs from the 4 bearing cups in the centre housing of the universal joint.
5. Use the tool shown in Figure 8 on page 8 and a slide hammer to remove these cups. See B Figure 29.
6. *Cups without plugs must be removed by pressing on one cup to push the opposite cup out. See Figure 30.*
Hold the cup in a vice as shown at C and pull up and turn the yoke at the same time.
Do the same for the other cups.
7. Use a lever to remove the oil seal from the axle case. Use the special tool shown in Figure 4 on page 6 to insert a new seal, lip towards differential.
8. If the bush in the axle case is worn remove the half case from the differential. Use the special tool shown in Figure 1 on page 5 to remove the bush. This job must be done before installing a new oil seal.

ASSEMBLY

Make sure all parts are clean and there are no protrusions in the bores of the yokes. Remove any protrusions from around the circlip grooves.

1. Insert one of the cross journals into the centre housing.
2. Carefully put one of the bearing cups on the cross journal.
Make sure the needle bearings stay in position while doing this.
3. Use a 150 mm vice to press the cup into the housing as shown in Figure 31.
4. Hold the cross journal towards the cup while doing this.
5. Use a spacer to press the cup into the housing until clear of the circlip groove. Install the circlip and press it into the groove with the spacer.
Repeat this for the other cup.
6. Repeat steps 1 to 5 for the other cross journal.
Then install the 4 plugs.
7. Insert the cross journals into the half shafts and repeat steps 1 to 5 to insert the bearing cups.

IMPORTANT: Make sure all the circlips are fully in the grooves.

Use a hammer and punch to hit into position, if necessary.




FIGURE 29. REMOVING CUPS FROM CENTRE HOUSING OF UNIVERSAL JOINT

- | | |
|-----------------|-------------------|
| A. Slide hammer | C. Bearing cup |
| B. Special tool | D. Centre housing |




FIGURE 30. REMOVING CUPS FROM HALF SHAFT YOKES

- | | |
|-----------------|---------------------|
| A. Press | D. Metal tube |
| B. Spacer | E. Vice |
| C. Bearing cups | F. Soft face hammer |




FIGURE 31. INSTALLING THE BEARING CUPS

- | | | |
|--------------|-----------------|-----------|
| A. 6 in Vice | B. Bearing cups | C. Spacer |
|--------------|-----------------|-----------|

12 mm = 0.47 in
150 mm = 6 in

DIFFERENTIAL

REMOVAL AND DISASSEMBLY OF DIFFERENTIAL

1. Remove the four bolts which hold the steering ram caps to the differential support bracket. Remove the ram cylinder.
2. If the bevel pinion shaft is to be removed, loosen the nut on the end of the shaft.
3. Remove the setscrews which fasten the differential unit to the axle case. Remove the differential unit.
4. Put the differential unit on an acceptable stand or in a vice.

NOTE: Use soft metal jaws if a vice is used.

5. Remove the setscrews and locking plates which hold the ring nuts.
6. Make a mark on the bearing caps and the support bracket for correct identification when assembling.
7. Remove the bolts which fasten the bearing caps to the support bracket.
8. Hold the spiral gear and differential cage while removing the bearing caps and ring nuts.
9. Remove the spiral gear and differential unit from the support bracket.
10. Remove the bearings from the differential cage with a 3 leg puller. If the outer race only comes off, put it with the thick edge towards the cage. Insert three balls and use the puller again to remove the inner race.
11. Remove the nine setscrews which fasten the end plate to the cage. Remove the end plate and differential wheel.
12. Remove the twelve setscrews which fasten the spiral gear to the cage. Remove the spiral gear.
13. Use a hammer and soft metal punch to remove the differential pin.
14. Remove the two differential pinions and the other differential wheel.




FIGURE 32. DIFFERENTIAL SUPPORT BRACKET

- A. Cap bolt, steering ram
- B. Cap, steering ram
- C. Steering ram
- D. Bolt, to axle
- E. Dowel
- F. Support bracket
- G. Gasket
- H. Bolt, bearing cap, differential
- J. Bearing cap, differential

Disassembling the Bevel Pinion Shaft

1. Remove the nut and washers from the end of the bevel pinion shaft.
2. Remove the flange and guard.
3. Remove the oil seal and distance collar from the support bracket.
4. Remove the outer bearing cone and the distance pieces and shims.
5. Remove the bevel pinion shaft from the support bracket.
6. Remove the inner bearing cone from the bevel pinion shaft.
7. Use a hammer and punch to remove the bearing cups from the support bracket. Remove the shims from behind the inner bearing cup.
8. Clean and examine all parts for wear or damage. Replace parts which are found with wear or damage.




FIGURE 33. DIFFERENTIAL UNIT ASSEMBLY

A. Ring nut	N. Taper roller bearing
B. Taper roller bearing	O. Shims
C. Spiral gear	P. Distance piece
D. Cage	R. Shims
E. Setscrew	S. Distance piece
F. Differential wheel	T. Taper roller bearing
G. Differential pinion	U. Distance collar
H. End plate	V. Oil seal
J. Pin	W. Flange and guard
K. Dowel	X. Seal washer
L. Setscrew	Y. Thick washer
M. Bevel pinion shaft	Z. Nut

ASSEMBLING AND SETTING THE PINION SHAFT

1. Use a hammer and a steel punch or a three leg slide hammer, remove the inner bearing cup from the differential support bracket. Make sure there is no damage of the bearing seats.
2. Remove the shims which are installed behind the bearing cup.
3. Install the bearing cup without the shims and make sure it is pressed fully into the support bracket.
4. Install the inner bearing cone on to the bevel pinion shaft.
5. Put the bevel pinion shaft in position in the support bracket.
6. Put the outer bearing cone, flange and guard on to the shaft.
7. Install the washers and nut.
8. Rotate the shaft by hand and tighten the nut. Tighten until all end movement of the shaft is just removed. Then tighten the nut a small amount to give the bearings preload. If necessary, install the spiral gear to enable the nut to be tightened. Remove it when the nut is tight enough.
9. Assemble the setting gauge, number DB 8208. Use probe number SK/DB 9721 and spacer number SK/DB 9721/2 5.1875/4WD. Install the probe with spacer into the shaft. Install the lock nut.
10. Put the gauge in position in the support bracket as shown in Figure 34. Install the bearing caps and bolts and tighten to 163 Nm.
11. Make sure the shaft B rotates easily in the discs A. Put the point of the probe C against the end face of the bevel pinion shaft J.
12. Adjust the probe until the point is just making contact with the face. Tighten the lock nut and check the setting of the probe again. Set again if not correct.
13. Use a feeler gauge to measure the gap at X between the shaft B and the spacer E. Make a record of the measurement.




FIGURE 34. SETTING THE BEVEL PINION SHAFT POSITION

- A. Disc
- B. Shaft
- C. Probe
- D. Special lock nut
- E. Spacer 5.1875 in
- F. Inner bearing cone
- G. Shims
- H. Inner bearing cup
- J. Bevel pinion shaft
- K. Flat distance piece
- L. Shims
- M. Distance piece with shoulder
- N. Distance collar
- O. Oil seal
- P. Flange and dirt shield
- R. Washers
- S. Nut
- T. Outer bearing
- X. Gap

163 Nm = 16.5 kg m = 120 lb ft
5.1875 in = 131.75 mm

14. Look for the correction mark on the end of the bevel pinion gear. The amount of correction is shown as -7 or +7 for example, which is plus or minus 0.007 in.

15. Find the correct amount of shims to install as follows:

Example 1: If a minus (-) number is shown on the gear

Normal dimension	0.76 mm	0.030 in
Minus correction	<u>-0.18 mm</u>	<u>-0.007 in</u>
Result A	0.58 mm	0.023 in
Measurement of gap X	1.45 mm	0.057 in
Minus result A above	<u>-0.58 mm</u>	<u>-0.023 in</u>
Thickness of shims needed	0.87 mm	0.034 in

Example 2: If a plus (+) number is shown on the gear.

Normal dimension	0.76 mm	0.030 in
Plus correction	<u>+0.18 mm</u>	<u>0.007 in</u>
Result B	0.94 mm	0.037 in
Measurement of gap X	1.45 mm	0.057 in
Minus result B above	<u>-0.94 mm</u>	<u>-0.037 in</u>
Thickness of shims needed	0.51 mm	0.020 in

16. Remove the setting gauge when the amount of shims needed have been found.
17. Remove the nut, washers, flange and guard, and outer bearing cone from the bevel pinion shaft.
18. Remove the bevel pinion shaft from the support bracket.
19. Use a steel punch and a hammer or a 3 leg puller to remove the inner bearing cup from the support bracket.
20. Install the correct amount of shims and the inner bearing cup.
Make sure the cup is pressed in as far as it can go.
21. Install the pinion shaft into the support bracket.
22. Slide the flat distance piece on to the pinion shaft.
Install shims to a thickness of 1.27 mm.
Install the distance piece which has the shoulder, largest diameter toward the shims.
23. Install the outer bearing cone, flange and guard, washers and nut.
24. Install the spiral gear and tighten the nut on the bevel pinion shaft to 190 Nm. Remove the spiral gear when the nut is tight and rotate the shaft in both directions.
25. Put the support bracket on a support with the flange of the bevel pinion shaft up.

26. Put the probe of a dial gauge against the end face of the flange. Move the pinion shaft up and down and make a note of the amount of movement shown.

Turn the shaft and do the check again. Repeat this several times to get the correct reading.

27. Use the following example to find the correct amount of shims to install.

Example:

Amount of movement	0.25 mm	0.010 in
Movement needed	<u>-0.00 mm</u>	<u>-0.00 in</u>
Shims to be removed	0.25 mm	0.010 in

NOTE: The tolerance is + or - 0.05 mm.

28. Remove the nut, washers, flange and guard, outer bearing cone, and distance piece.

29. Remove shims as necessary.

Install the distance piece with the largest diameter toward the shims.

Install the outer bearing cone, the oil seal spacer, oil seal, flange and guard, washers and nut.

Tighten the nut to 190 Nm.

<p>0.05 mm = 0.002 in 1.27 mm = 0.049 in 190 Nm = 19 kg m = 140 lb ft</p>

ASSEMBLING THE DIFFERENTIAL

NOTE: During assembly, put molybdenum disulphide paste on all bores, pins and thrust faces.

1. Put the differential cage A on a bench with the open end up.
2. Install one of the differential wheels B in the cage.
3. Put the two differential pinions C in position on the wheel.
4. Push the differential pin D through the cage and pinions.
5. Install the other differential wheel.
6. Align the dowels and holes for the end plate. Press the end plate E into position.
7. Put Loctite 270 on the threads of the nine setscrews for the end plate.
Install the tabwashers and setscrews and tighten the setscrews to 40 Nm.

NOTE: Long tabwashers must be installed over dowel holes.

Bend the tabwashers against the heads of the setscrews.

8. Press the bearing on to the end plate. The thin edge of the bearing cup must be toward the end plate.
9. Press the bearing on to the cage. The thin edge of the bearing cup must be towards the cage.
10. Clean the faces of the spiral gear and differential cage and press the gear on to the cage.
11. Install the tabwashers and twelve setscrews which fasten the spiral gear to the cage. Tighten the setscrews to 68 Nm. Bend the tabwashers against the heads of the setscrews.
12. Put the differential support bracket in a stand or vice. Use soft metal jaws if a vice is used.
13. Put the differential unit in position in the support bracket.
14. Put the ring nuts in position against the bearings and install the bearing caps and bolts.
Before tightening the bolts, make sure the ring nuts are correctly in the threads and easy to turn.
15. Carefully tighten the bearing cap bolts to 163 Nm.

IMPORTANT: Make sure there is a clearance between the teeth of the spiral gear and bevel pinion when tightening. Move the ring nuts if necessary. Damage can be caused if this is not done.




FIGURE 35. DIFFERENTIAL UNIT ASSEMBLED

- A. Cage
- B. Wheels
- C. Pinions
- D. Pin
- E. End plate
- F. Spiral gear
- G. Ball bearings

40 Nm = 4 Kg m = 29 lb ft
68 Nm = 7 Kg m = 50 lb ft
163 Nm = 16.6 Kg m = 120 lb ft

ADJUSTING THE DIFFERENTIAL

1. Turn both ring nuts counterclockwise until there is a small clearance between the nuts and the bearings.

NOTE: If the ring nuts are difficult to turn loosen the bearing caps a small amount.

DO NOT loosen the caps more than is necessary.

2. Turn the ring nut on the spiral gear side counterclockwise and the other ring nut clockwise. Do this until the spiral gear can move freely between the pinion teeth.
3. Turn the ring nut on the spiral gear side clockwise until the spiral gear just becomes difficult to move.
4. Loosen the bearing caps a small amount. Hit the bearing caps with a copper hammer to align the bearings.
Tighten the caps to 163 Nm.
Check that the spiral gear is still just difficult to move, if not repeat steps 3 and 4.
5. Put the point of a 150 mm screwdriver in between two of the bolt heads. Move the spiral gear until screwdriver is horizontal.
6. Loosen one bearing cap a small amount.
Loosen the ring nut one slot.
Hit the bearing cap with a copper hammer.
Tighten the cap bolts to 163 Nm.
7. Repeat step 6 until the weight of the screwdriver will just rotate the differential through the backlash.
Check the movement at several different positions through one revolution of the spiral gear.
8. Make a mark on each ring nut and cap for adjustment reference.
8. The ring nuts B, must be turned in the same direction, exactly the same amount for further adjustment.
9. Fasten a dial gauge to the support bracket. See Figure 36. Put the probe of the dial gauge against the drive face of a tooth of the spiral gear. The probe must be at right angles to the tooth.
40. Turn the ring nuts the same amount to move the spiral gear toward the bevel pinion. Do this until the backlash between the spiral gear and pinion teeth is 0.18 to 0.23 mm.




FIGURE 36. ADJUSTING DIFFERENTIAL BEARINGS

- A. Spiral gear
B. Adjuster ring nut
C. 150 mm screwdriver

150 mm = 6 in
0.18 mm = 0.007 in
0.23 mm = 0.009 in
20 Nm = 2 kg m = 15 lb ft
163 Nm = 16.6 kg m = 120 lb ft

11. Remove the dial gauge.

Loosen the bearing caps a small amount and hit with a copper hammer to align the bearings. Tighten the caps to 163 Nm.

12. Use the dial gauge to check the backlash setting again at three positions at 120 degree intervals.

NOTE: The backlash must never be below the minimum specification. If the variation is too much, remove the spiral gear and clean the rear face. Also clean the face of the cage where the spiral gear is fastened. Repeat the adjustment procedure.

13. When the adjustment is correct, install the locking plates for the ring nuts. Tighten the setscrews for the plates to 20 Nm.

14. Check the torque is correct on the bearing cap bolts.

INSTALLING THE DIFFERENTIAL ASSEMBLY

1. Clean the faces of the support bracket and the axle case.
2. Put a new gasket in position on the dowels of the axle case.
3. Install the differential unit into the axle case. Make sure damage is not caused to the gasket when doing this operation.
4. Install the fourteen setscrews which fasten the support bracket to the axle case. Tighten the setscrews to 68 Nm.

INSTALLING THE DRIVE SHAFTS

1. Fit new bushes and oil seals in the axle case.
2. Make sure the oil seal recesses are free from rust, paint and damage. Clean with fine emery paper if necessary.
Remove any sharp edges from splines. Put a little grease on the splines and lip of oil seal then install.
3. Install the drive shafts, long end first, into the axle case. Make sure damage is not caused to the oil seals when doing this operation.
4. Turn each drive shaft until the splines at the inner end engage with the differential wheels. Push the shaft in fully.




FIGURE 37. CHECKING BACKLASH

STEERING RAM

DISASSEMBLING THE STEERING RAM

1. Loosen the nuts on the ball sockets which connect the steering ram to the steering links.
2. Hit the steering link with a hammer around the ball socket taper to release it. Remove the nut.
3. Loosen the locknuts which hold the ball sockets to the steering ram rod.
4. Remove the four bolts which fasten the steering ram caps to the differential support bracket.
5. Remove the ram and remove any oil into a container, before putting the ram on a bench.
6. Remove the two ball sockets from the ram rod.
7. Remove the four circlips which hold the ram sleeves in position in the cylinder.
8. Pull the ram rod out of the ram cylinder complete with the ram piston and one sleeve. Remove the sleeve from the rod.
9. Remove the other sleeve from the ram cylinder.
10. Remove the back-up ring and 'O' ring from the outside of the sleeves.
11. Remove the dirt seal, large 'O' ring, small 'O' ring and back-up ring from inside the sleeves.
12. Remove the two circlips which hold the piston in position on the ram rod. Remove the piston.
13. Remove the 'O' ring from the groove in the ram rod.
14. Remove the 'O' ring and the two back-up rings from the piston.




FIGURE 38. STEERING RAM ASSEMBLY

A. Circlip	K. Back-up ring
B. 'O' ring	L. Seal
C. Piston	M. 'O' ring
D. Ram rod	N. Back-up ring
E. 'O' ring	O. Sleeve
F. Back-up ring	P. Dirt seal
G. Bleed screw	R. Circlip
H. Ram cylinder	S. Ball socket
J. 'O' ring	

ASSEMBLING THE STEERING RAM

1. Put the back-up rings in clean oil for a minimum of half an hour before installing.
2. Install the 'O' ring on to the ram piston. Install nylon back-up ring each side of the 'O' ring.
3. Install the 'O' ring in the groove at the centre of the ram rod.
4. Slide the piston on to the ram rod.
5. Install the circlips which hold the piston in position on the ram rod.
6. Install the thick 'O' rings in the bores of the ram sleeves, in the grooves away from the piston.
7. Install the back-up rings in the bores of the sleeves, in the grooves nearest the piston. Install the thin 'O' rings in the same grooves.

Make sure the 'O' rings are nearest the piston when installed.

8. Install the dirt seals into the sleeves, in the outer grooves.
9. Install the back-up rings and the 'O' rings on the outside of the sleeves. Make sure the 'O' rings are nearest the piston when installed.

10. Remove any sharp edges from the outer ends of the ram cylinder.

Put a little grease on the inside ends of the cylinder and on the piston and sleeve 'O' rings. Install one of the sleeves into the ram cylinder and install the circlips.

11. Carefully install the ram rod into the cylinder. Take care when entering the 'O' rings into the cylinder.

12. Install the other sleeve and circlips.

13. Put the ball sockets in the ends of the ram rod but do not tighten.

14. Install the ram on the differential support bracket, with the bleed screws up.

15. Install the caps, spring washer and bolts which fasten the ram to the support bracket. Tighten the bolts to 68 Nm.

16. Adjust one ball socket so that the centre of socket is 42.9 mm from the end of the ram rod. See Figure 41.

NOTE: The tolerance on this dimension is +0 to -1.6 mm.

17. Adjust the other ball socket until the distance between the socket centres is 730 mm.

NOTE: The tolerance on this dimension is 0 to -3.17 mm.




FIGURE 39. RAM PISTON ASSEMBLY

- | | |
|------------------|-------------|
| A. Ram rod | E. Circlips |
| B. Ram cylinder | F. 'O' ring |
| C. Piston | G. 'O' ring |
| D. Back-up rings | |





FIGURE 40. END SLEEVE ASSEMBLY

- | | |
|----------------------------|-----------------|
| A. Ram rod | F. Back-up ring |
| B. Ram cylinder | G. 'O' ring |
| C. Circlips | H. 'O' ring |
| D. Sleeve | J. Back-up ring |
| E. Large diameter 'O' ring | K. Dirt seal |

0.25 mm = 0.010 in
 1.5 mm = 0.059 in
 1.6 mm = 0.062 in
 42.9 mm = 1.68 in
 3.17 mm = $\frac{1}{8}$ in
 730 mm = 28 $\frac{3}{4}$ in
 68 Nm = 7 kg m = 50 lb ft
 135 Nm = 13.8 kg m = 100 lb ft


18. Install the steering links.
Install the ball sockets to the links with the taper parts down.
19. Install the nuts on the ball sockets and tighten to 135 Nm.
20. Move the ram rod so that the distance between the ends of the rod and the cylinder is equal. Connect the link ball sockets to the steering levers. Adjust the ball sockets at the ends of the links until both hubs are straight forward.
Install nuts on ball sockets and tighten temporarily.
21. Set the toe-in of the front wheels after the axle has been installed on the tractor.
The toe-in must be 0 to 1.5 mm at the wheel rims.
Tighten ball socket nuts to 135 Nm.
22. Turn the steering until the ram reaches maximum lock and adjust the four steering stop bolts.
Adjust the bolts until there is a clearance of 0.25 mm between the bolt head and the axle case.
Tighten the locknuts when the setting is correct.



R79.35

FIGURE 41. BALL SOCKET SETTING

- A. Ball socket
B. Ram rod
C. Locknut
D. Taper
E. Distance of 42.9 mm



R79.36

FIGURE 42. STEERING STOP SETTING

- A. Clearance of 0.25 mm between bolt and axle case

135 Nm = 14 kg m = 100 lb ft
1.5 mm = 0.059 in
0.25 mm = 0.010 in

SPECIFICATIONS

FRONT AXLE

Spiral Gear/Pinion ratio	37/10	
Reduction	3·7:1	
Hub Reduction	3·75:1	
Total Axle Reduction	13·875:1	
Minimum Track	1524 mm	60 in
Maximum Track	1828 mm	72 in
Ground Clearance (11·2/10-24 tyres)	356 mm	14 in
Steering Angle	40°	
Toe-in (measured at the wheel rims)	0 to 1·5 mm	0 to 0·06 in

TYRE ARRANGEMENTS

	FRONT	REAR
1.	9·5/9-24	16·9/14-30
2.	9·5/9-24	12·4/11-36
3.	11·2/10-24	13·6/12-36

IMPORTANT: Do not use any other tyre arrangements or damage will be caused to the differential and transmission.

TORQUE SETTINGS

	Nm	Kg m	lb ft
Hub end plate setscrews	101	10·4	75
Planet carrier setscrews	40	4·15	30
Drive shaft ring nuts	203	20·7	150
Bearing pin setscrews	68	6·9	50
Steering lever bolts	163	16·6	120
Ball socket nuts	135	13·8	100
Drive shaft housing setscrews	101	10·4	75
Trunnion bracket setscrews	163	16·6	120
Steering ram cap bolts	68	6·9	50
Differential support bracket setscrews	68	6·9	50
Differential bearing cap bolts	163	16·6	120
Ring nut lockplate setscrews	27	2·8	20
Spiral gear setscrews	68	6·9	50
Differential end plate setscrews	40	4·15	30
Bevel pinion shaft nut	190	19·4	140
Wheel nuts	163	16·6	120

CAPACITIES

	Metric	Imperial	U.S.
Differential case	7.96 litres	14 pints	8.4 qt
Reduction Hubs (each)	0.85 litres	1.5 pints	0.9 qt

LUBRICATION

COMPONENT	B.P.	CASTROL	ESSO	MOBIL	SHELL
Differential, Front Hubs (each)	Gear Oil 90EP or Farm Gear Oil Universal	Agricastrol Gear Oil EP90/140	Gear Oil GP90/140	Mobilube GX90 Gear Oil	Spirax 90EP
Stub Axles Universal Joints Trunnion Pin	Energrease Universal or Energrease L2	Agricastrol Multi-use Grease	Beacon 2	Mobilgrease MP or Mobilgrease Super	Retinax A or Farm Grease Universal

TRANSFER GEARBOX

Reduction ratio	1.5:1	
End movement of all shafts	0.05 to 0.10 mm	0.002 to 0.004 in


TORQUE SETTINGS

Cover plate setscrews	27	2.8	20
Oil seal housing setscrews	27	2.8	20
Output shaft nut	190	19.4	140
Drive shaft flange bolts	54	5.5	40
Transfer box to frame	163	16.6	120

9-37185
C41

C10

4WD TRANSMISSION & FRONT AXLE Mk 4 (DAVID BROWN)



David Brown®

Service Repair Manual

SYNCHROMESH TRANSMISSION

1210, 1210 4WD, 1410 AND 1410 4WD TRACTORS

Section C11 (Pub. 9-37155) April 1979

*Written in Clear
And
Simple
English*

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case





WARNING: *This safety symbol is used in this manual to indicate important safety messages.*

When you see this symbol, read the message carefully. It is shown when possible injury or death can be caused.

David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.

Also, as the David Brown tractor is made to variable specifications for varying uses and countries, this manual can give details of items which are not part of any specific tractor.

CONTENTS

	Page
SPECIAL TOOLS	C3
12-SPEED GEARBOX	C11
HOW IT WORKS	C13
Gear Levers	C14
Selector assemblies	C16
Gear assemblies	C20
Transfer gearbox 4WD	C24
Differential	C25
Final drive	C25
MAINTENANCE	C27
Oil levels	C27
Oil changes	C27
Hydraulic filter, pressure, external	C28
Hydraulic filter, suction, internal	C29
REMOVAL AND INSTALLATION OF GEARBOX	C31
REMOVAL OF FINAL DRIVE UNITS	C34
DISASSEMBLY AND ASSEMBLY OF GEARBOX	C39
1210 Tractor without cab	C39
1210 Tractor with cab	C53
1410 Tractor without cab	C59
1410 Tractor with cab	C66
INSPECTION OF PARTS	C42
Selector parts	C42
Gears	C43
Bearings	C43
ADJUSTMENTS BEFORE ASSEMBLING	C44
Slow/Normal layshaft	C44
Main Layshaft clearance	C45
Topshaft Clearance	C46
Pinion Shaft Adjustment	C47

	Page
GEAR LEVERS	C72
DIFFERENTIAL 1210 TRACTOR	C73
Disassembly	C73
Assembly	C74
DIFFERENTIAL 1410 TRACTOR	C75
Disassembly	C75
Assembly	C76
ADJUSTMENTS	C77
Bearing Adjustment	C77
Tooth Clearance	C78
FINAL DRIVES	C79
Maintenance	C79
FINAL DRIVE 1210 TRACTOR	C81
Disassembly	C81
Inspection of Parts	C82
Installing Spur Pinion Shaft	C83
Installing Final Drive Shaft	C84
FINAL DRIVE 1410 TRACTOR	C86
Disassembly	C86
Inspection of Parts	C88
Installing Spur Pinion Shaft	C89
Installing Final Drive Shaft	C90
REAR AXLE OIL SEALS	C92
DRUM BRAKES 1210	C93
DISC BRAKES 1410	C95
HYDRAULIC BRAKES	C101
SPECIFICATIONS	C105

SPECIAL TOOLS




FIGURE 1. GEARBOX STAND
Made to Service Drawing Misc 1747.




FIGURE 2
TOOL FOR INSTALLING DETENT BALLS

- A. 9.5 mm ($\frac{3}{8}$ in)
- B. 15.9 mm ($\frac{5}{8}$ in)
- C. 4.8 mm ($\frac{3}{16}$ in)
- D. 150 mm (6 in)
- E. Gear lever knob





FIGURE 3
TOOL FOR CHECKING DEPTH OF
DETENT SPRING HOLES


- A. Round bar 9.5 mm ($\frac{3}{8}$ in) diameter
- B. 28 mm (1.10 in)



R78.239

FIGURE 4. DIFFERENTIAL BEARING
REMOVAL WITH 3 LEG PULLER

- A. Legs
- B. Thrust pad
- C. Links
- D. Puller bolt



R78.240

FIGURE 5. TOOL FOR REMOVING
REAR AXLE OIL SEAL HOUSING

- A. Tool No. 900207
- B. Tool No. 900208




FIGURE 6. TOOL FOR REMOVING BRAKE DRUMS

- | | |
|--------------------------------|-----------------------------------|
| A. Main tool, No. 960618 | E. Spacer |
| B. Large round bar (not shown) | F. Two $\frac{1}{2}$ in BSF bolts |
| C. & D. Two distance pieces | G. Two $\frac{3}{8}$ in BSF bolts |





FIGURE 7. MODIFICATIONS TO BRAKE DRUM REMOVAL TOOL

- | | |
|--|------------------------------|
| A. Service tool 960618 | |
| B. Additional pair of 13.5 mm ($\frac{1}{2}$ in) dia. holes at 104.8 mm ($4\frac{1}{8}$ in) centres | |
| C. Holes in distance piece changed to 13.5 mm ($\frac{1}{2}$ in) wide by 7.9 mm ($\frac{5}{16}$ in) deep slots | |
| D. 47.6 mm ($1\frac{7}{8}$ in) | } Collar |
| E. 82.5 mm ($3\frac{1}{4}$ in) | |
| F. 44.5 mm ($1\frac{3}{4}$ in) | |
| G. 88.9 mm ($3\frac{1}{2}$ in) | } Distance tube (two needed) |
| H. 22.2 mm ($\frac{7}{8}$ in) | |
| J. 14.3 mm ($\frac{9}{16}$ in) | |


R77 118

FIGURE 8
TOOL FOR REMOVING DISC BRAKE HUB, 1410

- A. 105 mm (4 $\frac{1}{8}$ in) centres
- B. 20 mm ($\frac{3}{4}$ in)
- C. 170 mm (6 $\frac{3}{4}$ in) diameter
- D. 79 mm (3 $\frac{1}{2}$ in) diameter
- E. 3.2 mm ($\frac{1}{8}$ in) recess
- F. 1.6 mm ($\frac{1}{16}$ in) radius
- G. 67.5 mm (2 $\frac{3}{4}$ in)
- H. $\frac{1}{2}$ in UNC thread




R78 244




R78 324

FIGURE 9. TOOL FOR REMOVING FINAL DRIVE SHAFT
A. Bolts No. DB K900207 B. Plate C. Thrust pad



R78-311

FIGURE 10. PLATE FOR REMOVING 14 SERIES TRACTOR FINAL DRIVE SHAFT



R77-122

FIGURE 11. PLATE FOR REMOVING 12 SERIES TRACTOR FINAL DRIVE SHAFT

- A. 114.3 mm (4½ in)
- B. 57.1 mm (2¼ in)
- C. 93.7 mm (3⅞ in)
- D. 38.9 mm (1½ in)
- E. 85.7 mm (3⅜ in)
- F. 76.2 mm (3 in)
- G. 70.6 mm (2¾ in)

- H. 29.4 mm (1½ in)

- J. 4 holes
20.5 mm (⅞ in) diameter

- K. 4 holes
17.5 mm (⅝ in) diameter

- *L. 2 holes
11.1 mm (⅞ in) diameter and tap ½-16BSF

* NOTE: If BSF taps are not available, cut thread to the same thread as bolts, minimum 20 mm (¾ in) diameter.




FIGURE 12. PINION SETTING GAUGE
(Service Tool DB 8208)

- | | |
|----------|-----------|
| A. Disc | C. Spacer |
| B. Shaft | D. Probe |




FIGURE 13. TOOL FOR INSTALLING DIFFERENTIAL LOCK SLEEVE

- | | | | |
|---------------------|---------------------|--------------------|---------------------|
| A. 609.6 mm (24 in) | C. 101.6 mm (4 in) | E. 38.1 mm (1½ in) | G. Hose clip |
| B. 228.6 mm (9 in) | D. 304.8 mm (12 in) | F. 25.4 mm (1 in) | H. 103.2 mm (4½ in) |




FIGURE 14. LIFTING BRACKET FOR FINAL DRIVE UNIT ON 14 SERIES TRACTORS

- A. Mild steel bar, $40 \times 13 \text{ mm}$ ($1\frac{1}{2} \times \frac{1}{2} \text{ in}$)
- B. 127 mm (5 in)
- C. 16.7 mm ($\frac{5}{8} \text{ in}$) diameter holes
- D. Drill and cut thread to install eye bolt for lifting
- E. 54 mm ($2\frac{1}{8} \text{ in}$)
- F. 89 mm ($3\frac{1}{2} \text{ in}$)

TWELVE SPEED GEARBOX


INTRODUCTION

The information in this section of the Repair Manual is for 1410 tractors and 1210 tractors made after 1975. For 1210 tractors made before 1975, see section C4, Transmission — Synchromesh Gearbox 1200 and 1210 tractors.

For information for 1210 Power-Shift, 1212 and 1412 tractors, see section C5, Transmission — Hydra-Shift.

For parts information, see publication 9-39052 for 1210 tractors, or 9-39102 for 1410 tractors, or any revisions of these.

The information given in this section includes the final drive reductions and brakes installed on these models.



R78 245

FIGURE 15. TWELVE-SPEED SYNCHROMESH GEARBOX FOR 1210 TRACTOR

- | | |
|--------------------------|-----------------------------|
| A. Topshaft | H. Second gear |
| B. High/Low range pinion | J. Third gear |
| C. Reverse idler gear | K. Synchroniser unit |
| D. Pinion shaft | L. Spiral gear |
| E. Front bearing | M. Differential |
| F. Rear bearing | N. Slow/Normal driven gear |
| G. First/Reverse gear | P. Slow/Normal driving gear |

NOTE: Layshafts are not shown to permit main gears and shafts to be seen.

HOW IT WORKS

GENERAL

The 1210 and 1410 gearboxes are of similar design and construction, but use different components. Do not use 1210 parts for the 1410 gearbox. Do not use 1410 parts for the 1210 gearbox.

The gearbox case has three main parts:

- (a) Front end plate.
- (b) Spacer.
- (c) Rear end plate (differential housing).

The gearbox is held in position in the rear end of the main frame by two bolts D Figure 16.

The bolts are tightened on to two bushes E through the gearbox lugs. A clearance is permitted between the bushes and the lugs and the lugs and the bolt heads. This permits the gearbox to move a small amount vertically and horizontally for alignment purposes. For clearances see Data at the end of the section.

A muff coupling is used to connect the clutch drive shaft to the slow/normal range driving gear. Circlips hold the coupling in position.

On 4 Wheel-drive tractors another muff coupling connects the transfer gearbox to the pinion shaft of the gearbox. This coupling is held in position by a bolt.




FIGURE 16. GEARBOX CASING PARTS

- A. Front end plate
- B. Spacer
- C. Rear end plate
- D. Bolt, gearbox to frame
- E. Bush
- F. Top casing bolt
- G. Bottom casing stud


GEAR LEVERS

On tractors with a cab, three levers control the gearbox, see Figure 17.

These are:

- (a) Slow/Normal range, lever F.
- (b) High/Low range, lever G.
- (c) 1, 2, 3 and Reverse, lever E.

Selection of slow, normal, high, low, first and reverse must be made with the tractor stopped. Gear changes from first to second, second to third and third to second can be made while moving.



R78.247


FIGURE 17. LEVERS AND PEDALS
TRACTORS WITH A CAB

- | | |
|------------------|------------------------|
| A. Clutch pedal | F and G. Range levers |
| B. Brake pedals | H. Engine stop control |
| C. Locking bar | J. Hand throttle |
| D. Foot throttle | K. Differential lock |
| E. Gear lever | |

A small lever is installed at the front of the seat, for the selection of 4-wheel drive. With the lever to the left 4-wheel drive is engaged through the transfer gearbox to the front axle.

Selection of 4-wheel drive must be made with the tractor moving and little or no load on the transmission.

Do not select 4-wheel drive if either of the rear wheels has a loss of traction.



R78.248

FIGURE 18. 4WD CONTROL LEVER
TRACTOR WITH A CAB

- A. Engaged position

On tractors without a cab, a single lever controls both Slow/Normal and High/Low.

The lever has a centre position for neutral which is used for stationary PTO work.

The lever on the right is used to select first, second, third and reverse gears.

Selection of slow, normal, high, low, first and reverse must be made with the tractor stopped.

Gear changes from first to second, second to third and third to second can be made while moving.




FIGURE 19. 1410 GEAR LEVERS

A. Range lever

B. Gear Lever

A small lever next to the clutch pedal is used for the selection of 4-wheel drive. With the lever up, 4-wheel drive is engaged through the transfer gearbox to the front axle.

Selection of 4-wheel drive must be made with the tractor moving, and little or no load on the transmission. Do not select 4-wheel drive if either of the rear wheels has a loss of traction.




FIGURE 20. 4WD CONTROL LEVER
TRACTORS WITHOUT A CAB

A. Engaged position

SELECTOR ASSEMBLIES

Selector Rods, Forks and Jaws

The selector assemblies have a different arrangement in the gearbox on a tractor with a cab, to one without. This makes assembly and disassembly of the gearbox different for each model. See Figures 22 and 23.

The gearbox has four selector rods each with a fork and jaw fastened to it by pins.

The four assemblies are used as follows:

- (a) Slow/Normal
- (b) High/Low
- (c) First/Reverse
- (d) Second/Third

Each rod has three grooves across it at one end. When the rod is moved to one of three positions the detent ball enters one of the grooves. A spring holds the ball in the groove, which holds the rod in the selected position. The centre groove is used for the neutral position.

To prevent two gears being selected at the same time gear locks are installed. The gear locks are installed in the front end plate between selector rods for all gears except Slow/Normal.

When a selector rod is moved, it pushes the lock into a groove in the rod next to it. This prevents the other rod from moving at the same time, see Figure 21.




FIGURE 21. GEAR LOCK METHOD

- | | |
|--------------------|----------------------------|
| A. Front end plate | C. Gear lock plunger |
| B. Selector rod | D. Stationary selector rod |




FIGURE 22. SELECTORS ON A TRACTOR WITH A CAB

- | | |
|---------------------|-----------------------------------|
| A. Slow/Normal rod | J. 2nd/3rd jaw |
| B. Slow/Normal fork | K. 1st/Rev. rod |
| C. Slow/Normal jaw | L. 1st/Rev. fork |
| D. High/Low rod | M. 1st/Rev. jaw |
| E. High/Low fork | N. Slow/Normal detent ball hole |
| F. High/Low jaw | P. High/Low detent ball hole |
| G. 2nd/3rd rod | R. First/Reverse detent ball hole |
| H. 2nd/3rd fork | S. Second/Third detent ball hole |




FIGURE 23. SELECTORS ON A TRACTOR WITHOUT A CAB

- | | |
|-----------------------------|-----------------------------------|
| A. Slow/Normal rod | J. 2nd/3rd jaw |
| B. Slow/Normal fork and jaw | K. 1st/Rev. rod |
| D. High/Low rod | L. 1st/Rev. fork |
| E. High/Low fork | M. 1st/Rev. jaw |
| F. High/Low jaw | N. Slow/Normal detent ball hole |
| G. 2nd/3rd rod | P. High/Low detent ball hole |
| H. 2nd/3rd fork | R. First/Reverse detent ball hole |
| | S. Second/Third detent ball hole |

Gears and Dog Clutch

Selection of slow or normal on the 1210 gearbox is made by moving the slow/normal driven gear. On the 1410 gearbox the driven gear is permanently engaged with the slow/normal layshaft. Selection is made by a dog clutch.

Selection of high or low on the 1210 gearbox is made by moving the high/low pinion.

On the 1410 gearbox the gears for high and low are permanently engaged with the main layshaft. The range is selected by a dog clutch, see Figure 24.

A torque lock principle is used to help prevent gears disengaging. The following method is used for the first/reverse gear on the bevel pinion shaft. It is also used for the range pinion in the gearbox of the 1210 tractor.

The width of the shaft splines are reduced on the drive side where a gear is engaged. When drive is applied to the gear the gear turns a small amount on the shaft. This puts the splines of the shaft and the gear out of alignment. The gear cannot move along the shaft and is kept engaged.

A similar method is used on dog clutch gears. The teeth of the gears are reduced in width for part of the length on both sides. When drive is applied, the teeth of the gear and selector gear move out of alignment. The selector cannot move and the gear is kept engaged.




FIGURE 24. DOG CLUTCH ASSEMBLY (1410)

- A. Dog clutch
- B. Reduced part of tooth, on dog gear
- C. Dog teeth on gear
- D. Dog gear




FIGURE 25. TORQUE LOCK PRINCIPLE

- A. Sliding gear
- B. Reduced part of splines on shaft

Synchroniser Unit

The synchroniser unit has three main parts: See Figure 26.

- (a) A selector assembly
- (b) Two dog clutch gears

The selector assembly has two cone rings G which are fastened to three special pins H.


The pins are free to slide through holes in the selector gear F.

The selector gear has two sets of teeth on the inside bore. These engage with the outside teeth of the two dog clutch gears. The dog clutch gears are engaged with the pinion shaft by splines.

When the selector fork moves the selector assembly, a cone ring moves against the cup of a gear. The cone rings have a molybdenum surface.

This surface is hard and rough which prevents seizure and removes oil from the surface rapidly.

NOTE: When doing gearbox repairs, make sure this surface has protection from damage.



R78 256

FIGURE 26. SYNCHRONISER UNIT IN NEUTRAL

- | | |
|--------------------|--------------------|
| A. Second gear | E. Dog clutch gear |
| B. Second gear cup | F. Selector gear |
| C. Third gear | G. Cone rings |
| D. Third gear cup | H. Special pins |





FIGURE 27. SYNCHRONISER UNIT

R78 257

When the selector assembly is in the centre position both second and third gears are free.

When a gear is selected:


- (a) the selector assembly is moved toward one of the gears.
- (b) the cone ring comes in contact with the cup of the gear.
- (c) the cone ring is gradually rotated by the gear.
- (d) the selector assembly is rotated by the pins which move out of alignment with the holes.
- (e) when the speed of the selector and the gear are the same the pins align with the holes. This is done by springs at each end of the pins.
- (f) the selector slides over the pins and the inside teeth of the selector engage with the dog teeth of the gear. The selector gear is held in engagement by the reduced part of the dog clutch gear teeth. See page 17 for more detail of this.



R78.258

FIGURE 28. CONE RING CONTACT

A. Cone ring making contact with gear cup



R78.259

FIGURE 29. GEAR ENGAGEMENT

A. Selector gear engaged with second gear dog teeth

GEAR ASSEMBLIES

Slow/Normal

The Slow/Normal gear assembly is installed in the front end plate. It has four gears, two of these are on a common layshaft. The Layshaft is hollow and runs on needle roller bearings on a stationary spindle.

The clutch driveshaft is connected to the driving gear which has 18 teeth. The driving gear is permanently engaged with the gear with 26 teeth on the layshaft.

When SLOW is selected, the driven gear on the gearbox topshaft is moved toward the rear. The driven gear which has 28 teeth is engaged with the gear with 16 teeth on the layshaft. The driven gear is engaged to the topshaft splines.

When NORMAL is selected, the driven gear is moved forward along the topshaft. The teeth on the inside of the driven gear engage with the dog teeth on the driving gear. This gives a direct drive to the topshaft without a reduction.

NOTE: The explanation of the operation is for the 1210 gearbox. The 1410 gearbox has a dog clutch for engaging the range. The driven and driving gears are permanently engaged with the layshaft gears. See Figure 30.




FIGURE 30. SLOW AND NORMAL RANGES

- A. Drive gear assembly
- B. Slow/Normal layshaft
- C. Driven gear with 28 teeth
- D. Top shaft
- E. Dog clutch (14 series only)

NOTE: On 1210 gearbox gear C slides on the topshaft.

High/Low

The High/Low gear assembly is installed inside the spacer part of the gearbox. It has four gears, two on the topshaft and two on the layshaft.

When HIGH is selected, the range pinion is moved toward the rear along the splines of the topshaft. The gear with 26 teeth on the range pinion engages with the gear with 21 teeth on the layshaft.

When LOW is selected, the range pinion is moved forward along the topshaft. The gear with 18 teeth engages with the gear with 29 teeth on the layshaft.

NOTE: This explanation is for the 1210 gearbox. The 1410 gearbox has a dog clutch for selecting the range. The gears on the topshaft are permanently engaged with the main layshaft gears. See Figure 31.




FIGURE 31. HIGH AND LOW RANGES

- | | |
|-----------------------|---------------------------|
| A. Topshaft | E. Dog clutch (14 series) |
| B. Layshaft | F. Gear with 18 teeth |
| C. Gear with 26 teeth | G. Gear with 29 teeth |
| D. Gear with 21 teeth | |



First Gear

The drive through the Slow/Normal and High/Low gear assemblies goes to the main layshaft.

With the gear lever in position 1, the gear with 41 teeth on the bevel pinion shaft is engaged with the gear with 15 teeth on the layshaft.

Reverse Gear

With the lever in the R position, the gear with 41 teeth on the bevel pinion shaft is engaged with the idler gear with 22 teeth on the topshaft. The idler gear is free to rotate on the topshaft. The idler gear is permanently engaged with the gear on the layshaft which has 25 teeth.



R78.262

FIGURE 32. FIRST AND REVERSE GEAR DRIVE TRAINS

- | | |
|-----------------------|-----------------------------|
| A. Topshaft | D. Idler gear with 22 teeth |
| B. Bevel pinion shaft | E. Gear with 15 teeth |
| C. Gear with 41 teeth | F. Layshaft |

Second Gear

With the lever in position 2, the gear with 35 teeth on the bevel pinion shaft is engaged. The gear is always engaged with the gear with 21 teeth on the layshaft. Selection is made by moving the synchroniser gear rearward.

Third Gear

With the lever in position 3, the gear with 28 teeth on the bevel pinion shaft is engaged. This gear is always engaged with the gear with 29 teeth on the layshaft. Selection is made by moving the synchroniser gear forward.




FIGURE 33. SECOND AND THIRD GEAR DRIVE TRAINS

- | | |
|-----------------------|-----------------------|
| A. Bevel pinion shaft | D. Gear with 35 teeth |
| B. Layshaft | E. Gear with 29 teeth |
| C. Gear with 21 teeth | F. Gear with 28 teeth |

R78263

TRANSFER GEARBOX: 4WD Tractors

The drive gear of the transfer gearbox is connected to the gearbox bevel pinion shaft by a muff coupling. The muff coupling is held in position by a bolt and nut. The muff coupling is connected to the drive gear and pinion shaft by splines.

The drive gear which has 22 teeth is permanently engaged with an intermediate gear which has 25 teeth.

The intermediate gear is permanently engaged with the driven gear which has 40 teeth.

When 4-wheel drive is selected, a sliding dog clutch connects the driven gear to the output shaft. The output shaft is connected to the front axle differential by a drive shaft.

The transfer gearbox uses the same oil as the main gearbox. It has a drain plug, and is filled when the main gearbox is filled.




FIGURE 34. TRANSFER GEARBOX DRIVE TRAIN

- A. Gearbox pinion shaft
- B. Muff coupling
- C. Drive gear
- D. Intermediate gear
- E. Driven gear and shaft

DIFFERENTIAL UNIT

The bevel pinion shaft is the output shaft of the gearbox. The pinion is engaged with the spiral gear of the differential unit.

The pinion on the 1210 has 7 teeth and the spiral gear has 43 teeth.


The pinion on the 1410 tractor has 8 teeth and the spiral gear has 41 teeth.

The spiral gear is fastened to the differential housing. Inside the housing are two bevel pinions on the 1210 and four bevel pinions on the 1410 tractor. The bevel pinions rotate on shafts fastened to the housing and the complete assembly rotates with the spiral gear.

The bevel pinions are permanently engaged with two bevel wheels. These are connected by splines to the spur pinion shafts of the final drives.

The differential unit permits each road wheel to rotate at a different speed when turning a corner.

The differential lock connects the right-hand drive shaft to the differential housing. This stops the differential function and the road wheels can only turn at the same speed.



R76265

FIGURE 35. DIFFERENTIAL UNIT: 1410 TRACTOR

- | | |
|----------------------|-----------------------|
| A. Housing | H. Bearing |
| B. Spider | J. Bevel pinion |
| C. Spiral gear | K. Bevel wheel |
| D. Bevel wheel | L. Bearing |
| E. Spur-pinion shaft | M. Spur-pinion shaft |
| F. Diff-lock sleeve | N. Bevel pinion shaft |
| G. Ball bearing | |

FINAL DRIVE UNIT

The spur pinion shaft splines are engaged permanently with the bevel wheels of the differential unit.

The spur pinion shafts have a small pinion at the final drive end which is permanently engaged with the spur wheel.

The spur wheels are connected to the final drive shafts by splines. The rear wheels are fastened to the flanges of the drive shafts by bolts and nuts.




FIGURE 36. FINAL DRIVE UNIT: 1210 TRACTOR

- | | |
|----------------------|---------------------|
| A. Case | F. Oil seal |
| B. Spur-pinion shaft | G. Spur wheel |
| C. Roller bearings | H. Final driveshaft |
| D. Cover | J. Oil seal |
| E. Circlip | K. Seal housing |

MAINTENANCE

OIL LEVEL

Check the level of the oil in the gearbox every 60 hours or each week.

IMPORTANT: Always clean around filler plugs and the dipstick before removing. Dirt must not enter the gearbox.

1. On tractors which have a cab, a sight glass is installed in the left-hand side of the main frame. See Figure 37 item A.

The oil level must be at least half way up the glass. Add oil to this level if necessary through the filler plug on the side of the PTO casing. See Figure 37 item B.

2. On tractors without a cab a dipstick is installed in the gearbox cover. See Figure 38 item B. The oil level must be between the two marks on the bottom of the dipstick. Add oil through the filler plug on the right-hand side of the cover if necessary.

OIL CHANGES

Change the oil in the gearbox at the first 50/100 hours service and every 500 hours or every six months. Install a new element in the hydraulic filter at the same time.

NOTE: It is a recommendation that the oil is drained when warm, after the tractor has been used.

IMPORTANT: Use clean containers when doing this job. The hydraulic system uses the same oil and the components are made to fine tolerances. Dirt **MUST NOT** enter the gearbox. Always clean around the filler and drain plugs before removing.

1. Put a container of at least 45 litres capacity under the transmission drain plugs. See Figure 39.
2. Remove the drain plugs from the axle case, filter housing, and transfer box on 4-wheel drive tractors. Install the plugs when the oil has stopped flowing.
3. Remove the paper element from the hydraulic oil filter and destroy. See procedure pages 28 and 29.
Install a new paper element.
4. Fill the gearbox to the correct level with the correct grade of oil. Install and tighten the filler plug.




FIGURE 37. TRACTOR WITH CAB

A. Sight glass for level B. Filler plug on PTO housing




FIGURE 38. TRACTOR WITHOUT CAB

A. Filler plug B. Dipstick




FIGURE 39. DRAIN PLUGS

A. Suction filter C. Gearbox drain plug
B. Rear axle drain plug

45 litres = 10 gal = 48 U.S. qt

EXTERNAL HYDRAULIC FILTER

Installed from serial numbers: 1210, 11152617; 1410, 11200753.


To change the filter element use the following procedure.

1. Clean around the outside of the filter.
2. Use a $1\frac{5}{16}$ AF spanner to remove the filter bowl which has an hexagon A Figure 40 on the bottom.
Turn the bowl counterclockwise.
3. Remove the clip B, (if used), from the bowl. Remove the element and destroy.
4. Wash the inside of the bowl with clean fuel oil and install a new element. DO NOT use a cloth for cleaning.
5. Use a tool which has a sharp point to remove the "O" ring and back up ring. Install new "O" ring and back up ring in that sequence into the filter body. Make sure the rings are in the correct position and correctly installed.

NOTE: Install a back up ring on all filters when replacing element.

6. Put a small amount of grease on the top edge of the bowl and on the rings.
7. Install a new element, with the flat face up, into the bowl. Fit the retaining clip (if used). Install bowl to filter body.

NOTE: The clip B is not installed on later tractors. Some tractors do not have a back-up ring installed. A new type back-up ring was installed from the following serial numbers: 1210, 11157412; 1410, 11202961.



R78 270

FIGURE 40. FILTER POSITION

A. Bowl hexagon B. Element retainer clip




FIGURE 41. EXTERNAL HYDRAULIC FILTER

A. Back-up ring B. "O" ring

INTERNAL SUCTION FILTER

1. Remove the ten screws G which fasten the filter housing to the main frame.
2. Loosen the hose clip H which connects the filter housing to the inlet pipe.
3. Remove the filter housing F from the main frame.
4. Remove the filter cover B, valve and screen C, and paper element D from the housing.
5. Destroy the paper element D. Clean all other components in new fuel oil. Clean magnet J.
6. Assemble the filter, use a new paper element and 'O' rings.
7. Remove the old gasket from the main frame and housing faces.
8. Install the housing with a new gasket.

IMPORTANT: Make sure the paper element is installed without damage.

NOTE: The paper element was replaced by a screen when the pressure filter was installed.

Clean the screen with clean fuel oil and dry with compressed air. Install a new 'O' ring P when assembling.

Items B, C and J Figure 42 were not fitted from the serial numbers shown.

The changes were made at the following serial numbers:

1210: 11152576; 1410: 11200752;

1210Q: 11152617; 1410Q: 11200753




FIGURE 42. SUCTION FILTER

- | | |
|-----------------------|----------------------|
| A. New type screen | H. Hose clip |
| B. Cover | J. Magnet |
| C. Old type screen | K. Cover for housing |
| D. Paper type element | L. Gasket |
| E. Gasket | M. 'O' ring |
| F. Filter housing | N. Spacer |
| G. Bolt, housing | P. 'O' ring |

R78 323

REMOVAL AND INSTALLATION

REMOVAL OF THE GEARBOX

On tractors fitted with a Quiet cab or Weather-frame cab, remove the cab first, see Pub 9-38162 or any revisions. Also remove the fenders, all tractors. The following procedure is for a tractor without a cab. Some of the operations will not be needed when a cab has been removed. Some extra jobs have to be done, for example, on hydraulic brakes on a tractor with a cab. Make sure there is space at the rear of the tractor for PTO removal, etc.

1. Clean the tractor. Clean the gearbox cover and the rear axle case.
2. Disconnect the battery leads from the battery.
3. Disconnect the drive cable from the engine speed indicator.
4. Disconnect the wiring from the instrument panel.
5. Remove the fuel from the tank into a clean container with cover.



WARNING: Diesel fuel is very flammable. Keep container away from heat and sparks. These can cause fires and result in injury or death.

6. Disconnect the fuel pipes from the tank.
7. Disconnect and remove the hand throttle lever.
8. Remove the bracket for the stop control from the steering box.
- 9A On tractors with hydrostatic steering:
Remove the oil from the pump/reservoir.
Disconnect the four pipes from the servo valve, see Figure 43.
Put plastic plugs in holes to stop dirt entering.
Remove the bolts which fasten the servo valve to the gearbox cover.
- 9B On tractors with manual steering:
Disconnect the drag link from the drop arm, see Figure 44.
Remove the bolts which fasten the steering box to the gearbox cover.
10. Remove the steering column assembly.
NOTE: Do not turn the steering wheel after the column has been removed from the tractor.
(a) Oil will come out of the servo valve on the hydrostatic column.
(b) The ball bearings will fall out of the mechanical column.




FIGURE 43. HYDROSTATIC STEERING

- A. Throttle linkage
B. Oil pipes
C. Bolts, bracket to casing




FIGURE 44. MECHANICAL STEERING

- A. Bolts, column to casing.
B. Connection, draglink to droparm.

11. Remove the oil from the transmission. Use a container which can hold at least 45 litres. Remove the drain plugs from both the rear axle and the suction filter housing.

NOTE: If the oil is to be used again, use a clean container with a cover. Discard the last 5 litres of oil at the bottom of the container.

12. Remove the bolts which fasten the seat bracket to the tractor.
Remove the seat.
13. Remove the bolts which fasten the gearbox cover to the clutch housing and main frame. Lift out the wedge see D Figure 46.
14. Remove the five bolts which fasten the rear axle case to the gearbox cover. Lift off the gearbox cover.
15. Remove the transfer gearbox on 4-wheel drive tractors as follows:
 - (a) Remove the bolt from the muff coupling which connects the transfer gearbox to the main pinion shaft.
 - (b) Push the muff coupling rearwards onto the pinion shaft.
 - (c) Remove the bolts which connect the axle driving shaft to the output shaft of the transfer gearbox.
 - (d) Put a trolley jack under the transfer gearbox as a support.
 - (e) Remove the four nuts and spring washers which fasten the transfer gearbox to the tractor main frame.
 - (f) Disconnect the operating lever linkage.
 - (g) Lower the jack and remove the transfer gearbox from under the tractor. Put a cover over the open top to prevent dirt from entering.
16. Put a jack under the drawbar.
Remove the bolts which fasten the drawbar frame to the hitch brackets. Lower the drawbar frame.
NOTE: If a pick up hitch is fitted, lower the hitch and disconnect the chains.
17. Disconnect the cable from the sensing unit. Remove the bolts which fasten the sensing unit to the PTO case. Remove the sensing unit.




FIGURE 45. DRAIN PLUGS

- | | |
|-------------------------|----------------------------|
| A. Filter housing | C. Transmission drain plug |
| B. Rear axle drain plug | |





FIGURE 46. GEARBOX COVER

- | |
|--------------------------------|
| A. Cover to frame bolts |
| B. Axle case to cover bolts |
| C. Cover to clutch cover bolts |
| D. Wedge |

CONTENTS

Pub	Section	Subject
9-38114	A1	4-cylinder diesel engine (4/47)
9-37102	A2	3-cylinder diesel engine
9-37122	A4	4-cylinder diesel engine (4/49, 4/55)
9-37132	B1	Clutch
9-37133	B2	Clutch 770, 780, 880, 990, 1200, 3800 & 4600 Tractors-19
9-38115	C1	Transmission, non-synchromesh-770, 780, 880 & 990 Tractors
9-38116	C2	4WD Transmission and front axle (Selene)
9-37142	C3	Transmission, synchromesh, 885, 990, 995 & 996 tractors
9-37152	C4	Transmission, 1200 & 1210 Tractors
9-37162	C5	Transmission, Hydra-Shift
9-37171	C6	4WD Transmission and front axle Mk1 (Kramer)
9-37172	C7	4WD Transmission and front axle Mk2 (Kramer)
9-37182	C8	Power Take-Off (PTO)
9-37176	C9	4WD Transmission and Front axle (Carraro)
9-37185	C10	4WD Transmission and Front Axle (David Brown)
9-37155	C11	Transmission, 1210, 1210 4WD, 1410 & 1410 4WD Tractors
9-37201	D1	Modification of axle case before conversion to High Clear
9-37205	D2	Axle Loads and Tyre Pressure
9-37195	E2	Steering and front axle (2WD)
9-37242	G2	Hydraulic system, front-mounted pump
9-37214	G3	Hydraulic system, 885, 990, 995 & 996 tractors
9-37222	H1	Electrical equipment
9-38127		1410, 1412 Service information, including Q-cab models
9-38162	-	Preliminary Service Information - Tractors with Q-cabs
9-38194	-	Preliminary Service Information - Highway tractors with Q-cabs

8-23090



18. Remove the lift rod, levelling lever and lower links.
19. Put a sling around the PTO unit. Use a hoist to hold the weight of the PTO unit. Remove the bolts which fasten the PTO unit to the rear axle.



WARNING: The PTO unit is heavy. Take care when removing the unit, it can cause injury if it falls.

Remove the PTO unit and pull out the PTO driveshaft from the gearbox.

20. Put wedges of wood between each side of the front axle and the frame. Use a 5 ton jack to raise the rear of the tractor. Put stands under the rear axle and tractor main frame. Remove the rear wheels.
 21. Remove the final drive units, see page 34.
 22. Make sure that the spring and sleeve for the differential lock are clear of the differential. To do this you must:
 - (a) Remove the oil seal housing from the flange of the rear axle (right-hand).
 - (b) Put your hand into the rear axle, pull back the sleeve and the spring of the differential lock.
 - (c) If necessary, move the pedal for the differential lock to make sure that components are free.
 23. Disconnect the muff coupling between the clutch and the gearbox. To do this, remove the circlip from the clutch driveshaft. Then move the muff coupling forward until it is clear of the gearbox shaft. Remove any shims that are on the shaft.
- NOTE:** It is a recommendation that you must make an identification of all parts. This will make assembly easier.
24. Remove the lubrication pipes and the two bolts and bushes which fasten the gearbox to the main frame.
 25. Remove the rear axle case complete with hydraulic equipment and ramshaft, as follows:
 - (a) Disconnect hydraulic pipes and control lever connections.
 - (b) Disconnect the brake rods, cables, and hydraulic cylinders.
 - (c) Put a sling around the axle. Fasten the sling to a hoist.
 - (d) Remove the bolts which fasten the axle case to the main frame.
 - (e) Carefully, pull the axle case away from the main frame. Lower the axle case to the ground when clear of the differential.
 26. Use a hoist to remove the gearbox toward the rear.




FIGURE 47. REAR OF TRACTOR

- A. Hitch plate
- B. Setscrews (Hitch plate to PTO casing)
- C. Sensing unit cable
- D. PTO
- E. Level lever
- F. Lift rod
- G. Lower link
- H. Hitch plate bolt




FIGURE 48. LUBRICATION PIPE

- A. Slow/Normal layshaft
- B. Front end plate
- C. Lubrication pipe
- D. Muff coupling

5 litre = 1 gal = 5 U.S. qt
45 litre = 10 gal = 48 U.S. qt

REMOVAL OF THE FINAL DRIVES



WARNING: *The final drive units are very heavy. Take care when removing or installing. If it falls it can cause injury.*

1210 TRACTOR

1. Turn the adjusting nut for each brake drum counter-clockwise, until adjustment is released.
2. Push down the pedal for the differential lock and use wire to fasten it in this position, see Figure 49.
3. Remove the oil from the final drive units.
4. Remove the nuts which fasten the final drive units to the flanges of the rear axle.
5. Put a lever between the ends of the studs and the axle case. Push against the studs to push the final drive away from the axle case.
6. Carefully, move the final drive until the studs are clear of the axle case. Let the unit turn until the cover plate is at the bottom.
7. Use a jack to support the final drive unit and remove the final drive unit completely. Repeat procedure to remove the other final drive unit.

1410 TRACTOR

1. Disconnect the brake rod from each final drive unit. Remove the nuts from the cotter pins in the camshaft for each brake. Remove the cotter pins and make sure that the cam levers are free on the shafts.
2. Push down the pedal for the differential lock and use wire to fasten it in this position see Figure 49.
3. Remove the oil from the final drive units.
4. Remove the nuts which fasten the final drive units to the flanges of the rear axle.
5. Use the lifting bracket, see Figure 14, or a lifting sling and hoist to hold the weight of the unit.



WARNING: *1410 tractors have very heavy final drive units. Approximate weight 225 kg. Use care when removing the units or injury can result.*

6. Remove the unit. Repeat procedure to remove the other unit.




FIGURE 49. DIFFERENTIAL LOCK PEDAL HELD IN ENGAGED POSITION

A. Pedal
B. Operating lever

C. Wire




FIGURE 50. REMOVING THE FINAL DRIVE

INSTALLING THE GEARBOX

1. Install the shims on the auxiliary drive gear shaft.
2. Install a new oil seal in the rear end of the clutch driveshaft. Put a small amount of grease on the seal.
3. Install the gearbox into the frame.
4. Install the two bolts which fasten the gearbox to the frame but without the bushes.
5. Make sure that all four lugs of the end plates are flat on the frame.

If the lugs are not flat on the frame, loosen the four Nyloc nuts on the gearbox casing. Use a soft hammer to align the end plates as necessary.

Tighten the four nuts to 95 Nm when the lugs are flat on the frame.

6. Remove the two bolts which fasten the gearbox to the frame.

Install the two bushes and then the bolts, tighten to 135 Nm. Use a feeler gauge to check clearance between the bolt heads and the lugs of the case. This must be between 0.076 to 0.5 mm.

7. Move the muff coupling rearward on to the drive gear against the shims.

Install the circlip into the groove of the clutch driveshaft to hold the muff coupling in position.

8. Check the clearance between the circlip and the muff coupling. The clearance must be 0.20 to 1.02 mm.

Remove or add shims behind the muff coupling to get the correct clearance.

9. Use a hone or fine file to remove any sharp edges from the splines of the PTO drive shaft. Do this on the front edges and outer edges along the full length of each spline.

Apply a small amount of grease. Carefully push the shaft through the topshaft of the gearbox until fully forward.

NOTE: If the splines will not enter the clutch plate disengage the PTO clutch. Turn and push the shaft at the same time until fully forward into the flywheel.

10. Clean the faces of the rear frame and the axle case.
11. Put a new gasket on the axle case with compound which does not become hard.
12. Install the rear axle case complete with hydraulic equipment and ramshaft.




FIGURE 51. INSTALLING THE GEARBOX


- A. Checking muff coupling clearance
B. Checking bolt to casing clearance

225 kg = 496 lb
95 Nm = 10 kg m = 70 lb ft
135 Nm = 14 kg m = 100 lb ft
0.20 mm = 0.008 in
1.02 mm = 0.040 in
0.076 mm = 0.003 in
0.5 mm = 0.020 in

13. Put the spring for the differential lock sleeve in position on the differential.
14. Put the lock sleeve on the tool with splines towards differential and enter it into the axle casing. Stop when the groove of the sleeve is behind the inner gusset of the casing.
NOTE: Do not let the tool enter the spring. The fork cannot be engaged.
15. Align the selector fork with the groove in the sleeve. Turn the tool clockwise until the fork is engaged with the groove.
16. Engage the splines of the sleeve with the differential. Push the pedal down to engage the differential lock. Use a piece of wire to hold the pedal in this position. Remove the tool.
17. Make sure the breather plugs are clear in the axle case flanges on 1410 tractors.
18. Install new seals in the axle case in the following positions. 12 series, all seals to face inwards towards differential. 14 series, install seals in each seal housing back to back.

NOTE: Put high melting point grease in between the seals in each housing on the 12 series tractor. Apply jointing compound to the seal housings before installing into axle casing.


19. Check brake linings for wear and damage. Clean the inside of the brake drum on 12 series tractor.
20. Clean the joint flanges of the axle case and final drive unit. Fit a new 'O' ring seal to the final drive flange on the 1410 tractors.
21. Install the final drive units. Tighten the bolts to 135 Nm.
22. Install the rear wheels.
23. Connect the brake rods and adjust the brakes.
24. Remove the supports from under the tractor and lower it to the ground. Remove the wedges between the frame and front axle.



R78.280

FIGURE 52. DIFFERENTIAL LOCK 1210

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | D. Pedal |
| B. Sleeve | E. Return spring |
| C. Operating fork | F. End plate — differential cage |



R77.171

FIGURE 53. AXLE CASE OIL SEALS

- | | |
|--------------|------------|
| A. Oil seals | B. Housing |
|--------------|------------|

NOTE: Seals must be fitted back to back on 1410 tractors.

25. Use a hoist to install the PTO. Tighten the bolts to 102 Nm.
26. Connect the lubrication and the hydraulic pipes.
27. Install the gearbox cover using a new gasket. Make sure the gear levers are correctly aligned with the selector jaws when installing. Check the operation of the levers after the cover is in position, before tightening bolts.
28. Install and tighten cover bolts to 13 Nm. Install the bolts which fasten the cover to the rear axle casing. Tighten to 68 Nm. Tighten the bolts which fasten the cover to the frame to 68 Nm.
29. Install the wedge between the gearbox cover and the clutch housing. Install and tighten the bolts to 68 Nm.
30. Install steering column and bracket. Fill the steering box on tractors with manual steering. Connect drag link to drop arm.
31. Connect the oil pipes to the control valve on tractors with hydrostatic steering. Fill system with the correct grade of oil.
32. Install the transmission drain plugs and tighten. Fill the transmission with the correct oil to the correct level. Use a funnel with a filter installed.
NOTE: Discard the last 5 litres of oil if using old oil. Add new oil to the correct level.
33. Install the sensing unit and connect the cable.
34. Install the three point linkage and drawbar.
35. Install the fuel tank and instrument panel. Connect all wires and pipes. Fill fuel tank if necessary.
36. Connect: throttle linkage, engine stop control and the cable for the engine speed indicator.
37. Install seat on tractors without cab.
38. Install the cab.
39. On tractors with hydrostatic steering raise the front axle off the ground. Run the engine at idle speed. Turn the steering from lock to lock several times to remove air from the system. Do not permit the steering to reach full lock when doing this operation.
On tractors with the steering ram behind and parallel with the axle do the following.
Release left-hand bleed screw, turn steering to the right; tighten bleed screw.
Release right-hand bleed screw, turn steering to the left, tighten the bleed screw.
Fill reservoir to correct level.
Check the level of the oil in the reservoir with the front wheels as follows:
Tractor with side ram, full right-hand lock.
Tractor with transverse ram behind axle, wheels straight forward.
Tractor with 4-wheel drive, full left-hand lock.




FIGURE 54. GEARBOX COVER AND REAR AXLE CASE

- A. Bolts, gearbox cover
B. Bolts, axle to cover
C. Bolts, cover to clutch housing
D. Wedge

135 Nm	= 14 kgm	= 100 lb ft
102 Nm	= 10 kgm	= 75 lb ft
68 Nm	= 7 kgm	= 50 lb ft
13 Nm	= 2 kgm	= 10 lb ft
5 litres	= 1 gal	= 5 U.S. qt

DISASSEMBLY AND ASSEMBLY

1210 TRACTOR WITHOUT CAB

DISASSEMBLY OF GEARBOX

Use a stand as shown in Figure 1.

1. Use the bolts which fasten the gearbox to the main frame to fasten the gearbox to the stand. The gearbox must be installed on the stand as shown in Figure 1.

2. Engage any forward gear and put a soft metal punch between the front layshaft gear and the casing spacer.

Use a $1\frac{1}{8}$ AF socket to remove the pinion shaft nut, clockwise.

The nut has a left-hand thread and is very tight, 271 Nm.

Remove the nut, washer and bearing cone.

3. Put all gears in neutral and the high/low and

slow/normal gears in the centre position.

4. Remove the pins from the high/low selector fork and the slow/normal jaw.

Use a hammer and a parallel punch.

Get assistance to hold a steel bar under each selector rod as a support.

5. Turn the slow/normal rod 90 degrees to compress the detent ball. Pull the rod out through the front end plate. Put a finger over the detent hole to prevent the ball coming out when the shaft is removed. Remove the detent ball.

6. Turn the high/low selector jaw 90 degrees and remove the pin.

271 Nm = 28 kg m = 200 lb ft




FIGURE 55. ARRANGEMENT OF SELECTORS

- | | | |
|-----------------------------|------------------|-----------------------------------|
| A. Slow/Normal rod | G. 2nd/3rd rod | M. 1st/Rev. jaw |
| B. Slow/Normal fork and jaw | H. 2nd/3rd fork | N. Slow/Normal detent ball hole |
| D. High/Low rod | J. 2nd/3rd jaw | P. High/Low detent ball hole |
| E. High/Low fork | K. 1st/Rev. rod | R. First/Reverse detent ball hole |
| F. High/Low jaw | L. 1st/Rev. fork | S. Second/Third detent ball hole |

7. Remove the pin from the second/third selector fork.
Select third gear and turn the jaw 180 degrees. Remove the pin by hitting down. Pull the rod out through the front end plate.
Put a finger over the detent hole to prevent the ball coming out when the rod is removed.
Remove the detent ball and fork.
8. Remove the pin from the first/reverse selector jaw by hitting it up from below.
9. Remove the four nyloc nuts from casing studs and bolts. Remove the two top bolts.
10. Push the high/low selector rod toward the rear until clear of the front end plate. Move the rod enough so that the high/low jaw and slow/normal fork can be removed.
11. Push the first/reverse selector rod toward the rear as far as it will go.
12. Hold the selector rod toward the rear and pull the front end plate forward.
Do this until the slow/normal sliding gear and the jaw for first/reverse can be removed.
13. Put a hand over the detent holes for first/reverse and high/low then remove the front plate.
Remove the detent balls.
14. Pull the first/reverse rod forward as far as it will go. Pull the casing spacer and layshaft forward about 12 mm.
15. Remove the bolt which holds the top shaft rear bearing in position. The washer will fall inside the gearbox, remove later. Remove the top shaft assembly and the high/low rod and fork.
16. Remove the layshaft.
17. Remove the two spacers and the shims from the front of the pinion shaft. Keep these in a clean safe place. The shims will be needed to set the bearing preload when assembling.
18. Remove the splined washer from the pinion shaft.
19. Lift the front of the pinion shaft and remove the third gear. Remove the six bronze bearing pads.
20. Move the synchroniser unit and the front dog clutch gear forward as far as possible.
21. Remove the front circlip from the groove and slide it forward.
22. Slide the second gear and rear dog clutch gear forward.
23. On tractors up to serial number 729430, remove the rear circlip from the groove and slide forward. On tractors from serial number 729430, slide special splined washer forward and remove the split-ring.




FIGURE 56. BEVEL PINION SHAFT ASSEMBLY

A. Nut	M. Dog gears
B. Washer	N. Circlip
C. Bearing, front	P. Synchroniser unit
D. Distance piece	R. Second gear
E. Distance piece	S. Special washer
F. Circlip	T. Split-ring
G. Shims	U. First/Reverse gear
H. Distance piece	V. Plate
J. Splined washer	W. Shims
K. Third gear	X. Bearing, rear
L. Bearing pad (6)	Y. Shaft

NOTE: Item S and T installed instead of circlip from serial number 729430 on 1210 tractors.

13 mm = $\frac{1}{2}$ in

24. Pull the first/reverse selector rod forward and lift out.
25. Pull the spacer forward and remove the following parts from the pinion shaft:
front dog clutch gear, synchroniser unit and selector fork, front circlip, rear dog clutch gear, second gear and the six bearing pads, rear circlip or special washer, first/reverse gear.
26. Remove the casing spacer from the bottom studs.
Remove the washer for the topshaft rear bearing from the spacer. Remove the pin for the high/low fork from the spacer.
27. Remove the two balls for the starter safety plunger from the spacer. Remove the plunger from the rear end plate.
NOTE: These balls can be removed earlier if a rod type magnet is available.
28. Remove the pinion shaft if necessary, as follows:
 - (a) Fasten the rear end plate at the other end of the stand.
 - (b) Make a punch mark on one bearing cap and on the rear end plate for identification when assembling.
IMPORTANT: The caps must be installed in exactly the same positions when assembling.
 - (c) Release the tabwashers and hold the weight of the differential unit while removing the cap bolts. Remove the caps and adjuster rings.
IMPORTANT: Do not mix the caps and adjuster rings.
 - (d) Remove the differential and then remove the pinion shaft complete with bearing cone.
29. Remove the two gear locks and the four detent springs from the front end plate.
30. Remove the tension pin from the spindle of the slow/normal layshaft.
31. Push the spindle out of the plate and layshaft.
32. Remove the small circlip from the front of the slow/normal input shaft.
33. Hold the layshaft away from the input shaft.
Hit the front of the input shaft lightly with a soft face hammer.
Remove the shaft complete with rear bearing.
IMPORTANT: Make sure the layshaft gear does not make contact with the front bearing during this operation.
34. Remove the layshaft complete with bearings, spacer and thrust washers.
35. Remove the bearing cups from the end plates if necessary.
36. If necessary, remove the front bearing for the input shaft by removing circlip and pulling forward.




FIGURE 57. SLOW/NORMAL REDUCTION UNIT

- | | |
|-----------------------|--------------------------|
| A. Input shaft | H. Rear roller bearing |
| B. Small circlip | J. Layshaft |
| C. Large circlip | K. Needle roller bearing |
| D. Front ball bearing | L. Bearing spacer |
| E. Inner circlip | M. Driven gear |
| F. Bearing spacer | N. Layshaft spindle |
| G. Tension pin | P. Thrust washers |

INSPECTION OF PARTS

Clean all parts before making an inspection.

Selector Parts

1. Check the selector rods and forks for wear, damage and distortion.
2. Check the steel balls for wear and damage.
3. Put the balls into the grooves of the selector rods.
4. Check that there is a clearance between the ball and the bottom of the groove. See Figure 58.
5. If there is no clearance, grind the bottom of the groove to give a small clearance.
6. Measure the length of each detent spring. If less than 31.7 mm install new springs.
7. Measure the depth of the spring holes using the following method, see Figure 59.
 - (a) Use a piece of metal rod A, Figure 59, approximately 152 mm long and 9.5 mm diameter.
 - (b) Make a mark B on the rod 28 mm from one end.
 - (c) Put the marked end of the rod into the spring hole.
 - (d) Look through the selector rod hole D. The mark must be in line with the lower edge of the selector rod hole. See Figure 59.
 - (e) If the mark is lower, shims must be put in the bottom of the hole. Add shims until the mark aligns with the lower edge of the selector rod hole.




FIGURE 58. SELECTOR ROD AND DETENT BALL

A. Correct B. Wrong




FIGURE 59. CHECKING DEPTH OF DETENT SPRING HOLES

A. Test rod C. End plate
B. 28 mm mark D. Selector rod hole

31.7 mm = $1\frac{1}{4}$ in
152 mm = 6 in
28 mm = $1\frac{1}{8}$ in
9.5 mm = $\frac{3}{8}$ in

Gears

1. Check the gear teeth for wear and damage.
2. Check that all teeth are evenly marked.
NOTE: When a gear has to be replaced, also replace all other gears in that ratio. Rapid wear and failure will occur if this is not done.
3. Check the operation of the synchroniser unit. Check the six springs for damage, replace as a set if necessary.

NOTE: Do not try to disassemble the synchroniser unit. Make sure the surface of the synchronising rings is not damaged during inspection.

Bearings

1. Check for wear and damage of all parts including outer cups in end plates.
Install new outer cups when a new taper roller bearing is installed.
Make sure the cups are correctly installed to prevent moving after installation.
2. Check the slow/normal layshaft spindle, needle bearings and layshaft bore for wear and damage.
When a defect is found on any part, replace all parts. Use new type bearings and spacer when making a repair to an early type gearbox.
NOTE: Rapid wear and failure will occur if only part of the assembly is replaced.
3. Check the bush in the front end of the top shaft for wear and damage.




FIGURE 60. SLOW/NORMAL LAYSHAFT

- | | |
|------------------|-------------------|
| A. Pin | E. Needle bearing |
| B. Spindle | F. Spacer |
| C. Plug | G. Layshaft gears |
| D. Thrust washer | |

R78.290

ADJUSTMENTS BEFORE ASSEMBLY**Slow/Normal Layshaft**

1. Put the layshaft, with the bore vertical and the large gear on a flat surface.
2. Install the bearings with the distance piece between into the bore of the layshaft. Push the bearings and distance piece in until level with the end with the large gear.
3. Put a straight edge across the small gear as shown in Figure 61. Use a feeler gauge to measure the gap between the top bearing and the straight edge.

The clearance must be between 0.25 mm and 1.3 mm.

4. If the clearance is not correct check:
 - (a) The bearing Part Number K620273.
 - (b) The length of the distance piece, which must be 42.54 mm to 42.67 mm.




FIGURE 61. CHECKING BEARING CLEARANCE

A. Straight edge

B. Feeler gauge

0.25 mm = 0.010 in
1.30 mm = 0.050 in
42.54 mm = 1.675 in
42.67 mm = 1.680 in

Main Layshaft Clearance

1. Measure the front shoulder of the layshaft as shown in Figure 62.
2. Remove the bearing cup from the front or rear end plate, see Figure 62.
3. Remove shims 0.20 mm in thickness. Install the bearing cup again.
4. Assemble the gearbox case with the layshaft in position. Install the four Nyloc nuts which fasten the assembly together. Tighten to a torque of 95 Nm.
5. Turn the layshaft in both directions to align the bearings.
6. Put a dial gauge against the end of the layshaft, to measure the free movement.
7. Move the layshaft backwards and forwards turning it at the same time and applying a small load.
8. Read the amount of movement shown on the dial gauge. The correct amount of free movement must be 0.05 to 0.10 mm.
9. To find the correct amount of shims needed, subtract the movement needed from the movement measured.
 Example: Movement measured 0.25 mm
 Movement needed 0.07 mm
 Shims needed 0.18 mm
10. Disassemble the gearbox and install the correct amount of shims between the bearing cup and the end plate.
11. Do steps 4 to 8 again and check that the movement is correct.




FIGURE 62. FRONT END OF LAYSHAFT

If A = 1.5 to 1.73 mm

Install shims in the front end plate

If A = 3.33 to 3.58 mm

Install shims in the rear end plate


1.50 mm	= 0.058 in
1.73 mm	= 0.068 in
3.33 mm	= 0.131 in
3.58 mm	= 0.141 in
0.20 mm	= 0.008 in
0.10 mm	= 0.004 in
0.05 mm	= 0.002 in
0.25 mm	= 0.010 in
0.07 mm	= 0.003 in
0.18 mm	= 0.007 in
95 Nm	= 10 kg m = 70 lb ft

Topshaft Clearance

1. Remove the shims from between the rear end plate and rear bearing. See B Figure 63.
2. Assemble the gearbox case with the topshaft complete in position. Tighten the four Nyloc nuts which fasten the assembly together to a torque of 95 Nm.
3. Push the topshaft, including rear bearing towards the front of the gearbox as far as it can go.
4. Use a feeler gauge to measure the gap between the rear plate and the rear bearing.
5. Subtract 0.05 mm from the measurement to find the thickness of shims needed.

Example:

Gap	0.50 mm
Minus	0.05 mm
Shims needed	0.45 mm



R78.287


FIGURE 63. TOPSHAFT CLEARANCE ADJUSTMENT

- A. Lubrication muff, 14 series tractors only
 B. Shims for adjustment
 C. Bolt which fastens rear bearing
 D. Special washer
 E. Topshaft
 F. Thrust washer

0.05 mm	= 0.002 in
0.45 mm	= 0.018 in
0.50 mm	= 0.020 in
95 Nm	= 10 kg m = 70 lb ft

Pinion Shaft Adjustment


1. Remove the outer cup of the rear bearing from the rear end plate.
Remove the shims from the end plate and install the cup again.
2. Assemble the gearbox casing.
Install the pinion shaft without the gears and distance piece behind the front bearing.
3. Tighten the pinion shaft nut while turning the shaft by hand, until all free movement is removed. Hit both ends of the shaft with a soft face hammer and check again.
4. Loosen the nut until the shaft can be turned but still has a small amount of bearing friction.
5. Assemble the setting gauge, (Service Tool DB8208) as follows:
Put the 6-3215 in spacer on to the probe of the tool.
Screw the probe into the shaft B, Figure 64.
Install the locknut, but do not tighten it.
6. Install the tool into the rear end plate of the gearbox as shown in Figure 65.
Tighten the differential bearing caps to hold the tool in the correct position.
7. Turn the probe counterclockwise until the end is just in contact with the face of the bearing cone.
Tighten the lock nut of the probe then check that the probe has not moved.
8. Use a feeler gauge to measure the gap between the spacer D and the shaft B, Figure 64.
Make a note of the measurement.
9. Make a note of the measurement marked on the end of the pinion gear. This is shown as + or - and -7 = -0.007 in for example.
10. To find the correct amount of shims to install use the following method:
 - (a) If the pinion is marked minus (-), subtract the number shown from 0.030 in.



R77119

FIGURE 64. PINION SETTING GAUGE
(Service Tool DB 8208)

A. Disc C. Spacer
B. Shaft D. Probe



R78292

FIGURE 65. CHECKING PINION SETTING

A. Rear end-plate D. Spacer
B. Pinion bearing E. Mark on pinion
C. Probe

0.18 mm = 0.007 in
0.76 mm = 0.030 in

- (b) If the pinion is marked plus (+), add the number to 0.030 in.
- (c) Subtract the result from the gap measurement between the spacer and the shaft of the gauge.

Example:	(a)	(b)
Constant dimension	0.030 in	0.030 in
Pinion mark	-0.007 in	+0.007 in
Result	0.023 in	0.037 in
Gap measurement	0.057 in	0.057 in
Result	-0.023 in	-0.037 in
Shims needed	0.034 in	0.020 in

Make sure the result is correct and make a note of it before disassembling the gearbox.

11. Remove the setting gauge from the end plate.
12. Remove the pinion shaft and disassemble the casing.
13. Use a hammer and soft metal punch to remove the outer bearing cup from the rear end plate.
14. Put the correct amount of shims in the end plate and install the bearing cup again.
Make sure the bearing cup is tight against the shims.

0.76 mm = 0.030 in
0.18 mm = 0.007 in
0.58 mm = 0.023 in
0.93 mm = 0.037 in
1.45 mm = 0.057 in
0.88 mm = 0.034 in
0.50 mm = 0.020 in

ASSEMBLY OF GEARBOX

1. Install the front bearing for the input shaft and install all bearing cups which have been removed.
2. Put the slow/normal layshaft in the front end plate complete with bearings and spacer.
3. Hold the end plate so that the layshaft is kept away from the input shaft.

Install the input shaft and fit front circlip.

4. Put a new thrust washer each end of the layshaft and install the layshaft spindle. Fit the tension pin which holds the spindle in position.
5. Put the four detent springs and the first/reverse gear lock in the front end plate.
6. Remove the circlip from the rear of the topshaft. Remove the rear bearing and install it in the rear end plate with the correct amount of shims. See page 46 for topshaft adjustment.
7. Fasten the bearing in position with the bolt and special washer.

Use a new tabwasher to lock the bolt.

Make sure the washer is correctly installed.

8. Install the pinion shaft in the rear end plate with the correct amount of shims. See page 47 for pinion shaft adjustment.
9. Install the differential with the spiral gear as far to the right as possible.

For final adjustments after assembly see pages 77 and 78.

Make sure the caps and adjuster rings are in the correct positions then tighten the cap bolts, with your fingers.

10. Insert a wedge of wood between the end of the pinion shaft and the differential cage. This will hold the shaft in position while assembling.
11. Slide the casing spacer on to the bottom two studs until the studs just enter the front holes.
12. Slide the first/reverse gear on to the pinion shaft with the selector groove toward the differential.
13. Push the spacer rearward until the ends of the studs are level with the front face.
14. Push the first/reverse gear toward the rear as far as possible.
15. On tractors up to serial number 729430 slide the rear circlip on the shaft until between the circlip grooves.

The circlip will be pushed into the rear groove later.

On tractors from serial number 729430 install the special splined washer with the flat face forward. The washer must be forward of the rear groove in the shaft.




FIGURE 66. SLOW/NORMAL GEAR ASSEMBLY

- | | |
|----------------|---------------------|
| A. Input shaft | H. Roller bearing |
| B. Circlip | J. Layshaft |
| C. Circlip | K. Needle bearings |
| D. Bearing | L. Spacer |
| E. Circlip | M. Driven gear |
| F. Spacer | N. Layshaft spindle |
| G. Spring pin | P. Thrust washers |

16. Slide the second gear on to the shaft with the synchroniser cup toward the front.
Put a small amount of grease on the six bronze bearing pads.
Insert the bearing pads into the bore of the gear, in the splines of the shaft.
17. Install the rear dog clutch gear with the reduced part of the teeth toward the front.
Make a note of the position of the punch mark on the side of the gear.
18. Slide the front circlip on the shaft but not into the groove.
19. Install the front dog clutch gear with the reduced teeth toward the rear. Align the punch mark on the side of the gear with the mark on the rear gear.
20. Install the synchroniser gear on the dog clutch gears.
21. Install the selector fork into the groove of the synchroniser gear with the flat face forward.
22. Put the selector fork for first and reverse into the groove on the first/reverse gear.
23. Push the casing spacer toward the rear until 25 mm from the rear end plate.
24. On tractors from serial number 729430, put the split-ring in the rear groove of the pinion shaft. Slide the special splined washer over the split-ring.
25. Push the synchroniser gear, dog gears and second gear against the special washer. On tractors up to serial number 729430, push up to the circlip.
The circlip between the dog clutch gears will go into the groove on the shaft. Check by trying to pull the second gear forward. It will not move if the circlip is in the groove.
26. Slide the third gear on the shaft with the synchroniser cup toward the synchroniser gear.
Put a small amount of grease on the six bronze bearing pads. Install the bearing pads into the bore of the gear in the splines of the shaft.
27. Put grease on one side of the splined washer and install it with the grease toward the third gear.
28. Put the layshaft in position in the casing spacer with the smaller gear at the rear.
29. Put the high/low selector fork on the high/low selector rod with the flat face toward the front. Make sure the three detent grooves are down.
30. Put the fork in the high/low pinion groove, on the topshaft.
Install the topshaft assembly with the high/low selector rod and fork into the rear end plate.




FIGURE 67. BEVEL PINION SHAFT ASSEMBLY

A. Nut	M. Dog gears
B. Washer	N. Circlip
C. Bearing, front	P. Synchroniser
D. Distance piece	R. Second gear
E. Distance piece	S. Special washer
F. Circlip	T. Split-ring
G. Shims	U. First/Reverse gear
H. Distance piece	V. Plate
J. Splined washer	W. Shims
K. Third gear	X. Bearing, rear
L. Bearing pad (6)	Y. Shaft

NOTE: Items S and T installed instead of circlip from serial number 729430 on 1210 tractors.

25 mm = 1 in

31. Push casing spacer against the rear end plate. Enter the layshaft rear bearing at the same time into the rear end plate.
32. Push the high/low selector rod through the rear plate for about 150 mm.
33. Use a soft face hammer to push the topshaft into the rear bearing as far as it will go.
NOTE: Make sure the front bearing of the topshaft does not come into contact with the front layshaft gear.
34. Fit the outer cup to front bearing of topshaft.
35. Install the front end plate as follows:
 - (a) Enter the first/reverse selector rod in the front end plate and install the detent ball. Use the tool as shown in Figure 68.
 - (b) Push the front plate rearward until just on the bottom studs.
 - (c) Put the first/reverse selector jaw on the selector rod, open jaw outward.
 - (d) Install high/low detent ball and push the selector rod through the front plate.
 - (e) Install the high/low gear lock.
 - (f) Put the slow/normal sliding gear on the rear of the input shaft, with selector jaw and fork. Make sure the pin hole is toward the front.
 - (g) Put the high/low selector jaw on the high/low rod.
 - (h) Push the front plate against the casing spacer. At the same time engage the splines of the topshaft in the slow/normal sliding gear.
36. Push the two top casing bolts in from the front. Install the four nyloc nuts and tighten to 95 Nm.
37. Fit the pin for the first/reverse selector jaw from above. The pin must have 1.6 mm showing above the surface of the jaw.
38. Select reverse gear.
39. Check that the splined washer is still in position on the front of the pinion shaft.
40. Add 0.25 mm to the shims for the pinion shaft. Install the shims between the two spacers on the front of the pinion shaft. The small face of the front spacer must be toward the bearing. Install the front bearing cone, flat washer and nut.
41. Insert a soft metal punch between the front layshaft gear and the casing.




FIGURE 68. INSTALLING THE DETENT BALLS

- | | |
|-----------------|------------------|
| A. Tool | D. Detent ball |
| B. End plate | E. Detent spring |
| C. Selector rod | |




FIGURE 69. PINION SHAFT FRONT PARTS

- | | |
|-------------------|---------------------------------|
| A. Nut | D. Special spacer with shoulder |
| B. Washer | E. Shims |
| C. Roller bearing | |

1.6 mm = $\frac{1}{16}$ in
 95 Nm = 10 kg m = 70 lb ft
 150 mm = 6 in
 0.25 mm = 0.010 in

42. Tighten the pinion shaft nut counter-clockwise to 271 Nm.

NOTE: If there is not one and a half threads showing through the nut, remove and check splined washer.

43. Remove the wedge of wood from between the end of the pinion shaft and the differential.

44. Check the end movement of the pinion shaft by moving it forward then backward. Turn the shaft and apply load by hand while doing this. Measure the amount of movement with a dial gauge.

Remove shims to the same value as the movement plus 0.05 mm. This will give a bearing preload of 0.05 mm.

45. Push the high/low selector rod towards the front until the pins for the fork and jaw can be fitted.

Pins must have 1.6 mm showing above the surface.

46. Select high or low gear range.

47. Install slow/normal selector rod with detent groove to the front and down.

Install the pin for the jaw and fork.

48. Put the first/reverse selector in the neutral position.

49. Install the second and third selector rod with the three grooves to the front and down.

Install the pins for the jaw and fork.

50. Install the circlip on the rear end of the topshaft.

51. Install the balls and plunger for the starter safety switch.

1.6 mm = $\frac{1}{16}$ in
0.05 mm = 0.002 in
0.25 mm = 0.010 in
271 Nm = 28 kg m = 200 lb ft




FIGURE 70. ARRANGEMENT OF SELECTORS

- A. Slow/Normal rod
B. Slow/Normal fork and jaw
D. High/Low rod
E. High/Low fork
F. High/Low jaw

- G. 2nd/3rd rod
H. 2nd/3rd fork
J. 2nd/3rd jaw
K. 1st/Rev. rod
L. 1st/Rev. fork

- M. 1st/Rev. jaw
N. Slow/Normal detent ball hole
P. High/Low detent ball hole
R. First/Reverse detent ball hole
S. Second/Third detent ball hole

1210 TRACTOR WITH A CAB**DISASSEMBLY OF GEARBOX**

For procedure for a tractor without a cab see page 39.

1. Fasten the gearbox to the stand as shown in Figure 1.
2. Select any forward gear and put a soft metal punch between the teeth of the layshaft and the casing.
3. Use a $1\frac{1}{8}$ AF socket to remove the nut from the pinion shaft.
Turn the nut clockwise, it has a left-hand thread, and is very tight.
Remove the washer and front bearing cone.
4. Put a bar under the slow/normal selector rod A as a support. Use a hammer and punch to remove the pins which fasten the fork B and jaw C to the rod.
5. Put a finger over the hole N for the detent ball to prevent the loss of the ball.
Slide the selector rod out through the front.
Remove the detent ball from the rod hole in the end plate.
6. Select SECOND gear, remove the four nuts from the casing bolts and studs.
Remove the two top bolts out through the front.
7. Hold the SECOND gear in the engaged position.
Put a finger over the holes for the detent ball to prevent the loss of the ball.
Pull the front end plate forward until it is clear of the second/third selector rod G.
Remove the detent ball from the rod hole in the plate.




FIGURE 71. ARRANGEMENT OF SELECTORS

- | | | |
|---------------------|------------------|-----------------------------------|
| A. Slow/Normal rod | G. 2nd/3rd rod | M. 1st/Rev. jaw |
| B. Slow/Normal fork | H. 2nd/3rd fork | N. Slow/Normal detent ball hole |
| C. Slow/Normal jaw | J. 2nd/3rd jaw | P. High/Low detent ball hole |
| D. High/Low rod | K. 1st/Rev. rod | R. First/Reverse detent ball hole |
| E. High/Low fork | L. 1st/Rev. fork | S. Second/Third detent ball hole |
| F. High/Low jaw | | |

8. Select REVERSE gear.
Put a finger over the hole R, Figure 71 for the detent ball to prevent the loss of the ball.
Pull the front plate forward until clear of the first/reverse selector rod K.
Remove the detent ball from the rod hole in the plate.
9. Put a finger over the hole P for the detent ball of the high/low selector rod.
Push the high/low selector rod toward the rear end plate.
Pull the front plate forward until clear of the rod.
Remove the detent ball.
10. Remove the front plate and the slow/normal gears. Remove the slow/normal driven gear M, Figure 72 and selector from the front plate.
Remove the spring pin G which holds the layshaft spindle N and remove the spindle.
11. Remove the circlip B from the front end of the slow/normal input shaft.
Push the input shaft out of the front plate from the front. Keep the layshaft clear while doing this.
12. Remove the bolt which holds the rear bearing for the topshaft in position.
The washer will fall inside the casing; remove later.




FIGURE 72. SLOW/NORMAL GEARS

- | | |
|-------------------|---------------------|
| A. Input shaft | H. Roller bearing |
| B. Circlip (gear) | J. Layshaft |
| C. Outer circlip | K. Needle bearing |
| D. Bearing | L. Distance piece |
| E. Inner circlip | M. Driven gear |
| F. Distance piece | N. Layshaft spindle |
| G. Spring pin | P. Thrust washers |




FIGURE 73. TOP-SHAFT ASSEMBLY 1210 TRACTOR

- | | | |
|-------------------|-------------------------|------------------|
| A. Circlip | G. Shaft | M. Bolt |
| B. Front bearing | H. Bush | N. Shims |
| C. Distance piece | J. Reverse idler gear | P. Circlip |
| D. Circlip | K. Washer, rear bearing | R. Rear bearing |
| E. Bush | L. Tabwasher | S. Thrust washer |
| F. Range pin | | |

13. Move the casing spacer forward approximately 25 mm.

Remove the topshaft complete and the high/low selector assembly.

Remove the shims from behind the rear bearing and keep safe for assembly.

14. Remove the layshaft from the casing.
15. To remove the pinion shaft, first remove the differential.

Make marks on the bearing caps and the rear end plate to make sure of correct assembly.

Remove the bearing caps while holding the weight of the unit.

16. Remove the two distance pieces and the shims from the front of the pinion shaft. Keep shims safe for assembly.
17. Remove the splined washer, third gear and the six bearing pads, from the pinion shaft.
18. Move the synchroniser unit and the front dog gear forward as far as possible. Release the circlip behind the front dog gear from the groove and slide the circlip forward.
19. Slide the rear dog gear and second gear forward. Remove circlip from rear groove on early tractors and slide forward on later tractors.
20. Slide the first/reverse gear and selector forward until the selector rod is clear of the rear plate. Lift the selector assembly out.
21. Remove the selector assembly for second and third gears.
22. Lift the front of the pinion shaft and remove all the components from the front.
Remove the pinion shaft from the rear.
23. Remove the washer for the topshaft rear bearing from the bottom of the casing.
24. If necessary, disassemble the topshaft in the following sequence.
(a) Front bearing, washer and circlip.
(b) High/Low gear assembly.
(c) Rear circlip and bearing, thrust washer and reverse idler gear.




FIGURE 74. BEVEL PINION SHAFT ASSEMBLY

A. Nut	M. Dog gears
B. Washer	N. Circlip
C. Bearing, front	P. Synchroniser
D. Distance piece	R. Second gear
E. Distance piece	S. Special washer
F. Circlip	T. Split-ring
G. Shims	U. First/Reverse gear
H. Distance piece	V. Plate
J. Splined washer	W. Shims
K. Third gear	X. Bearing, rear
L. Bearing pad (6)	Y. Shaft

NOTE: Items S and T installed instead of circlip from serial number 729430 on 1210 tractors.

R78 284

Inspection of Parts

Clean all parts and check for wear and damage. See pages 42 and 43 for details.

Adjustments

Do the adjustments on pages 44 to 48 before assembling the gearbox.

25 mm = 1 in

ASSEMBLY see Figure 74

1. Install the casing spacer so that the front face is level with the ends of the bottom studs.
2. Remove the circlip and bearing from the rear end of the topshaft. Install the bearing in the rear end plate complete with the correct amount of shims. See page 46 for adjustment.
Install the bolt and special washer to hold the bearing in position. Use a new tabwasher on the bolt.
3. Install the pinion shaft and differential. Use a wedge of wood to hold pinion shaft in position.
4. Slide the first/reverse gear onto the pinion shaft. Make sure the selector groove is towards the rear end plate.
5. On early tractors install the rear circlip on the shaft but not in groove.
6. Put the second gear R on the pinion shaft with the synchromesh surface towards the front. Install the six bearing pads L with a small amount of grease.
7. Put the rear dog gear on the pinion shaft. Make sure the thin part of the teeth is towards the front. Make a note of the position of the mark on the side of the gear.
8. Slide the circlip N on to the pinion shaft but not into the groove.
9. Install the front dog gear, with the thin part of the teeth towards the rear end plate. Align the mark on the side of the gear with the mark on the rear dog gear.
10. Install the synchroniser unit P, onto the dog gears.
11. Install the selector assembly for second and

third gears. Do not enter the rod into the rear end plate.

12. Install the selector assembly for first and reverse gears. Enter the rod into the rear end plate. Move the casing spacer towards the rear approximately 50 mm at the same time.

Put the split ring T in the groove on the pinion shaft and slide the special washer S over the ring.

13. Push the synchroniser unit P, dog gears M, circlip N and second gear R, towards the rear. Enter the selector rod for second and third gears into the rear end plate. Keep pushing until the circlip between the dog gears, enters the groove on the shaft.

Check that the circlip has entered the groove by pulling the second gear forward. The gear will not move forward if the circlip is in the groove.

14. Install the third gear K, with the synchromesh surface towards the rear. Put grease on the six bearing pads and push into position.
15. Put grease on one side of the splined washer J. Put the washer on the pinion shaft with the grease against third gear.
16. Put the layshaft in position inside the casing spacer.
17. Assemble the top shaft as follows, see Figure 75.
 - (a) Put the range Pinion F on the topshaft, small gear to front.
 - (b) Install circlip D and washer C on the front of the shaft.
 - (c) Install bush H, idler gear J and thrust washer S, on to the rear of the shaft.

50 mm = 2 in




FIGURE 75.
TOPSHAFT ASSEMBLY 1210 TRACTOR

- A. Circlip
- B. Front bearing
- C. Distance piece
- D. Circlip
- E. Bush
- F. Range pinion
- G. Shaft
- H. Bush
- J. Reverse idler gear
- K. Washer, rear bearing idler
- L. Tabwasher, rear bearing idler
- M. Bolt, rear bearing idler
- N. Shims
- P. Circlip
- R. Rear bearing
- S. Thrust washer

18. Put the topshaft complete and the selector assembly in position inside the casing spacer. Enter the end of the topshaft and selector rod into the rear end plate.
19. Move the spacer toward the rear end plate. Enter the rear bearing of the layshaft into the end plate. Hit the front of the topshaft with a soft face hammer to push it into the rear bearing. Install the circlip on the rear end of the topshaft when in position.
20. Remove the outer cup of the front bearing for the topshaft from the front plate. Install the cup onto the bearing cone on the shaft.
21. Install the slow/normal layshaft large gear toward the front.
Do not install the spindle until the driving gear is installed.
22. Push the driving gear assembly into the front plate from the rear. Install the circlip on the front end.
23. Put all the springs for the detent balls in the front end plate. Put the gear lock in position.
NOTE: The range selector rods do not have a gear lock.
Install layshaft spindle and spring pin.
24. Put the front end plate onto the bottom studs and move it towards the spacer.
Do this until the driven gear M Figure 72 can be put on the topshaft. Install the gear with the selector groove toward the front.
25. Enter the first/reverse selector rod into the front end plate. Use the tool shown in Figure 76 to install the detent ball as follows:
Put the flat of the tool towards the end of the selector rod. Push the tool down and push the rod up to the flat. Remove the tool and push the rod over the ball.
26. Push the front end plate toward the spacer. Push the first/reverse selector rod forward until the gear lock enters the groove, **NEUTRAL POSITION**.
27. Enter the selector rod for second and third gears into the front plate. Use the tool to install the detent ball. Move the selector rod forward.
28. Put the selector rod for high/low in position. Use the tool to install the detent ball and move the rod forward.
29. Enter the layshaft and topshaft bearings into the front end plate. Use a soft face hammer to hit the front plate until it is against the spacer.
30. Install the two top casing bolts from the front. Install the four Nyloc nuts and tighten to 95 Nm.
31. Engage reverse gear and put a soft metal punch between the layshaft and the case. Make sure the splined washer is still in position.

32. Install the front bearing, the two distance pieces with the shims between, onto the pinion shaft. Make sure the small face of the front distance piece is toward the front bearing.




FIGURE 76. INSTALLING DETENT BALLS

- | | |
|-----------------|------------------|
| A. Tool | D. Detent ball |
| B. End plate | E. Detent spring |
| C. Selector rod | |




FIGURE 77. PINION SHAFT NUT

- | | |
|------------|---|
| A. Nut | D. Special distance piece with shoulder |
| B. Washer | E. Shims |
| C. Bearing | |

95 Nm = 10 kg m = 70 lb ft

33. Install the washer and nut onto the pinion shaft.

NOTE: There must be at least $1\frac{1}{2}$ threads showing through the nut. Check splined washer is in position if less, before tightening the nut. Tighten the nut counter-clockwise to 271 Nm.

34. Put all gears in neutral and then select high or low range.

35. Put the slow/normal selector fork into the selector groove. Enter the selector rod in the front plate and use the tool to install the detent ball. Push the rod toward the rear through the fork and selector jaw.

36. Align the holes in the rod, fork and jaw. Install the pins which fasten the fork and jaw.

37. Install the balls and plunger for the starter safety switch.

271 Nm = 28 kg m = 200 lb ft




FIGURE 78. ARRANGEMENT OF SELECTORS

- | | |
|---------------------|-----------------------------------|
| A. Slow/Normal rod | J. 2nd/3rd jaw |
| B. Slow/Normal fork | K. 1st/Rev rod |
| C. Slow/Normal jaw | L. 1st/Rev fork |
| D. High/Low rod | M. 1st/Rev jaw |
| E. High/Low fork | N. Slow/Normal detent ball hole |
| F. High/Low jaw | P. High/Low detent ball hole |
| G. 2nd/3rd rod | R. First/Reverse detent ball hole |
| H. 2nd/3rd fork | S. Second/Third detent ball hole |

1410 TRACTOR WITHOUT A CAB

DISASSEMBLY OF GEARBOX

For procedure for tractor with a cab, see page 66.

1. Install the gearbox in the stand as shown in Figure 1.
2. Remove the circlip A and washer B, Figure 79, which holds the front bearing for the input shaft assembly in position.
3. Align the gap in the teeth of the driving gear with the teeth of the layshaft.
Pull the input shaft assembly out through the front of the front end plate.
4. Remove the circlip K, Figure 79, from the front of the topshaft. Move the dog clutch gear L, forward as far as possible.
5. Remove the pin which fastens the slow/normal selector fork to the selector rod. See Figure 78.
6. Pull the slow/normal rod out through the front and remove the fork. Put a finger over hole N for the detent ball to prevent loss of the ball. Remove the ball through the selector rod hole.
7. Remove the pin which fastens the selector jaw to the high/low selector rod.
8. Remove the pins which fasten the selector jaw and fork to the second/third selector rod. Put a finger over hole S for the detent ball to prevent loss of the ball. Pull the rod out through the front, while holding the jaw.
Remove the detent ball through the selector rod hole.
9. Engage first gear and remove the pin which fastens the jaw to the first/reverse selector rod. Put a soft metal punch between the layshaft gears and the casing.
10. Remove the pinion shaft nut, washer and front bearing. Turn the nut clockwise, it has a left-hand thread and is very tight.
11. Remove the four Nyloc nuts from the casing bolts and studs. Remove the two top bolts, towards the front.
12. Push the high/low and first/reverse selector rods to the rear as far as possible. Pull the front end plate forward.
13. Remove the front end plate complete with the components inside. Put your hand over the holes for the detent balls while pulling the end plate forward. Remove the first/reverse selector jaw as the rod clears it.
Remove the detent balls.
NOTE: Make sure the high/low and first/reverse rods do not move forward while removing the front plate.
14. Remove the driven gear M, Figure 79, dog clutch gear, slow/normal selector and fork, high/low and first/reverse jaws.




FIGURE 79. SLOW/NORMAL GEARS 1410 TRACTOR TRACTOR

- | | |
|--------------------|--------------------|
| A. Circlip | M. Driven gear |
| B. Washer | N. Splined washer |
| C. Bearing, front | P. Circlip |
| D. Distance piece | R. Pin |
| E. Distance piece | S. Spindle |
| F. Bearing, rear | T. Plug |
| G. Input shaft | U. Thrust washers |
| H. Dog gear, front | V. Needle bearings |
| J. Selector gear | W. Distance piece |
| K. Circlip | X. Layshaft gears |
| L. Dog gear, rear | |




FIGURE 80. TOP SHAFT REAR END

- | | |
|---------------------|-------------------|
| A. Lubrication muff | D. Special washer |
| B. Shims | E. Top shaft |
| C. Bolt | F. Thrust washer |

15. Remove the gear locks and detent springs from the front end plate.
16. Remove the lubrication muff A Figure 80 from the rear of the topshaft.
17. Remove the bolt which holds the topshaft rear bearing in position. The washer will fall inside the casing, remove later.
18. Remove the topshaft complete and high/low selector rod and fork.
19. Remove the layshaft and pull the casing spacer forward approximately 25 mm.
20. Remove the distance pieces, shims G and splined washer J, from the front of the pinion shaft. Keep safe, the shims are important when assembling. See Figure 81.
21. Remove the third gear K, and the six bearing pads L, from the pinion shaft.
22. Move the synchroniser unit P, selector fork and front dog clutch gear as far forward as possible. Release the circlip N, behind the front dog clutch gear and move it forward along the shaft.
23. Move the second gear R, and rear dog clutch gear forward as far as possible.
24. Move the special washer S, which holds the split ring T, in position forward and remove the split ring.
25. Move the first/reverse gear U, forward and remove the selector rod and fork.
26. Remove from the pinion shaft:
 - (a) the synchroniser unit and selector fork,
 - (b) dog clutch gears and circlip,
 - (c) second gear and bearing pads,
 - (d) split-ring washer and first/reverse gear.
27. Remove the special washer for the topshaft rear bearing from the casing.




FIGURE 81. BEVEL PINION SHAFT ASSEMBLY

A. Nut	M. Dog gears
B. Washer	N. Circlip
C. Bearing, front	P. Synchroniser unit
D. Distance piece	R. Second gear
E. Distance piece	S. Special washer
F. Circlip	T. Split ring
G. Shims	U. First/reverse gear
H. Distance piece	V. Plate
J. Splined washer	W. Shims
K. Third gear	X. Bearing, rear
L. Bearing pad (6)	Y. Shaft

25 mm = 1 in

28. To remove the slow/normal layshaft, first remove the spring pin which holds the spindle in position.

Push the spindle out and lift the layshaft out of the end plate.

Remove the thrust washers.

Remove the bearings and distance piece from the layshaft. See Figure 79.

29. Disassemble the topshaft as follows if necessary; see Figure 82.

Remove:

- (a) front splined washer and circlip A.
- (b) front bearing B, and bush C.
- (c) low gear D, sliding gear E, and front dog clutch gear F, six bearing pads J.
- (d) circlip G, and rear dog clutch gear H,
- (e) high gear K, and six bearing pads R.
- (f) splined washer L, and circlip M,
- (g) rear circlip W, and bearing V,
- (h) thrust washer U, reverse gear T, and bush S.

30. To remove the pinion shaft, remove the differential unit as follows:

- (a) Make a mark on one of the differential bearing caps and the end plate to make sure of correct assembly.
- (b) Remove the bearing caps while holding the weight of the unit.
- (c) Remove the differential unit.
- (d) Remove the pinion shaft from the rear.

NOTE: **DO NOT** mix, or cause damage to the bearing caps and adjuster rings.

Inspection of Parts

Check all parts for wear and damage after cleaning. See pages 42 and 43.

Adjustments

Do the adjustments on pages 44 to 48 before assembling the gearbox.




FIGURE 82. TOPSHAFT ASSEMBLY 1410 TRACTOR

- | | | |
|--------------------|------------------------|----------------------------|
| A. Circlip | J. Bearing pad (6) | T. Reverse idler gear |
| B. Bearing, front | K. Low range gear | U. Thrust washer |
| C. Distance piece | L. Splined washer | V. Bearing, rear |
| D. High range gear | M. Circlip | W. Circlip |
| E. Selector gear | N. Bush | X. Lubrication muff |
| F. Dog gear | P. Topshaft | Y. Washer, rear bearing |
| G. Circlip | R. Bearing pad (6 off) | Z. Tabwasher, rear bearing |
| H. Dog gear, rear | S. Bush | a. Bolt, rear bearing |

R78-286

ASSEMBLY

1. Remove the circlip and bearing from the rear end of the topshaft if still fitted. Press the bearing into the rear end plate, with the correct amount of shims behind it.

Install the bolt and washer which holds the bearing in position. Use a new tabwasher to lock the bolt.

2. Slide the casing spacer on the bottom studs until the front face is level with the stud ends.
3. Install the pinion shaft and differential. Make sure caps and adjuster rings are correctly installed.
4. Assemble the pinion shaft components in the following sequence: see Figure 83.

- (a) first/reverse gear U, selector groove toward the rear,
- (b) special washer S, flat face toward the front,
- (c) second gear R, synchromesh cup toward the front, and the six bearing pads L, with grease,
- (d) rear dog gear, thin part of the teeth toward the front.

NOTE: Make a note of the position of the mark on the side face of the gear.

- (e) circlip N, (Not in groove),
- (f) front dog gear, thin part of the teeth toward the rear.

Align the mark on the side face with the mark on the rear dog-gear.

- (g) synchroniser unit P, and selector fork,
- (h) first/reverse selector rod and fork.

5. Enter the first/reverse selector rod into the rear end plate and push the casing spacer toward the rear.

6. Put the split-ring T into the groove on the pinion shaft. Move the special washer S, toward the rear to hold the split-ring in position.

7. Push the synchroniser unit, dog gears and circlip toward the rear until the circlip enters the groove.

Check that the circlip N, has entered the groove by pulling the second gear R, forward. It will not move if the circlip has entered the groove.

8. Install the third gear K. Put grease on the six bearing pads and install.

9. Put a small amount of grease on one side face of the splined washer J.

Install the washer on to the shaft, grease against third gear.

10. Put the layshaft into position inside the spacer.




FIGURE 83. BEVEL PINION SHAFT ASSEMBLY

A. Nut	M. Dog gears
B. Washer	N. Circlip
C. Bearing, front	P. Synchroniser unit
D. Distance piece	R. Second gear
E. Distance piece	S. Special washer
F. Circlip	T. Split ring
G. Shims	U. First/Reverse gear
H. Distance piece	V. Plate
J. Splined washer	W. Shims
K. Third gear	X. Bearing, rear
L. Bearing pad (6)	Y. Shaft

11. Assemble the topshaft as follows; see Figure 84.
 - (a) Put the circlip M, and the splined washer L, on the shaft from the front.
 - (b) Install the high range gear K and bearing pads, dog teeth toward the front.
 - (c) Install dog gear H, with the thin part of the teeth toward the front. Make a note of the mark on the side of the gear.
 - (d) Install the circlip G.
 - (e) Install the dog gear F, with the thin part of the teeth toward the rear. Align the mark on the side with the rear dog gear.
 - (f) Slide the dog clutch E, over the dog gears.
 - (g) Install the low range gear D, and distance piece C.
12. Put the topshaft complete with the high/low selector fork into position in the spacer.
13. Enter the rear end of the topshaft and the selector rod into the rear end plate.
14. Move the spacer and layshaft toward the rear. Enter layshaft into the rear bearing.
15. Hit the front end of the topshaft with a soft face hammer to push it into the rear bearing. Install the circlip on the rear end of the shaft when the shaft is in correct position.
16. Install the lubrication muff X, to the rear end of the topshaft. DO NOT tighten the nuts completely, permit a free movement of 0.8 mm.
17. Remove the outer cup of the topshaft front bearing from the front end plate. Install the cup on to the bearing cone on the top shaft.




FIGURE 84. TOPSHAFT ASSEMBLY 1410 TRACTOR

- | | | |
|--------------------|-------------------------|----------------------------|
| A. Circlip | J. Bearing pad (6) | T. Reverse idler gear |
| B. Bearing, front | K. Low range gear | U. Thrust washer |
| C. Distance piece | L. Splined washer | V. Bearing, rear |
| D. High range gear | M. Circlip | W. Circlip |
| E. Selector gear | N. Bush | X. Lubrication muff |
| F. Dog gear | P. Topshaft | Y. Washer, rear bearing |
| G. Circlip | R. Bearing pad, (6 off) | Z. Tabwasher, rear bearing |
| H. Dog gear, rear | S. Bush | a. Bolt, rear bearing |

0.76 mm = 0.030 in

18. Engage reverse gear. Install the gear locks and detent springs into the front end plate.
Install the slow/normal layshaft.
19. Put the front plate into position and enter the high/low selector rod. Install the detent ball.
20. Put the end plate toward the rear, enter the first/reverse selector rod into the end plate. Install the detent ball.
21. Install the jaws for high/low and first/reverse onto the selector rods.
22. Push the front end plate toward the rear until the slow/normal driven gear can be installed. Install the six bearing pads.
23. Install slow/normal selector ring and fork.
24. Install the dog clutch gear onto the topshaft, thin part of teeth toward the front.
25. Install the high/low and slow/normal gear locks into the end plate. Push the spacer fully backward against the rear end plate.
26. Push the front end plate toward the rear, entering the topshaft and layshaft front bearings. Push the plate against the spacer.
27. Install the circlip on the front of the topshaft.
28. Put the top casing bolts in position from the front. Install the Nyloc nuts on to the bolts and bottom studs and tighten to 95 Nm.
29. Install the pins which fasten the selector jaws to the selector rods for high/low and first/reverse.
30. Select reverse gear. Check that the splined washer is still in position on the front of the pinion shaft.
31. Install the distance pieces, shims, bearing, washer and nut onto the pinion shaft.

Make sure the small end of the front distance piece is toward the front. Tighten the nut counterclockwise (left-hand thread) to a torque of 271 Nm.

NOTE: Check that at least one and a half threads are showing through the nut before tightening. If there is less, check splined washer location again.




FIGURE 85. INSTALLING DETENT BALLS

- | | |
|-----------------|------------------|
| A. Tool | D. Detent ball |
| B. End plate | E. Detent spring |
| C. Selector rod | |

95 Nm = 10 kg m = 70 lb ft
271 Nm = 28 kg m = 200 lb

32. Select the neutral position for first/reverse.
33. Install the second/third selector rod G, through the front end plate, jaw and fork. Install the pins which fasten the jaw and fork to the selector rod.
34. Select high or low range.
35. Install the slow/normal selector rod A, and detent ball. Install the pin to fasten the slow/normal fork to rod.
36. Install the input shaft assembly complete with bearings. Install circlip and washer.




FIGURE 86. ARRANGEMENT OF SELECTORS

- | | | |
|-----------------------------|------------------|-----------------------------------|
| A. Slow/Normal rod | G. 2nd/3rd rod | M. 1st/Rev. jaw |
| B. Slow/Normal fork and jaw | H. 2nd/3rd fork | N. Slow/Normal detent ball hole |
| D. High/Low rod | J. 2nd/3rd jaw | P. High/Low detent ball hole |
| E. High/Low fork | K. 1st/Rev. rod | R. First/Reverse detent ball hole |
| F. High/Low jaw | L. 1st/Rev. fork | S. Second/Third detent ball hole |

1410 TRACTOR WITH A CAB**DISASSEMBLY OF GEARBOX**

For procedure for a tractor without a cab, see page 59.

1. Fasten the gearbox to the stand as shown in Figure 1.
2. Remove the circlip and washer which holds the front bearing of the input shaft assembly in position.
3. Align the gap in the teeth of the input shaft with the teeth of the slow/normal layshaft. Pull the input shaft assembly forward out of the front end plate.
4. Remove the circlip from the front of the top shaft. Move the dog clutch gear forward as far as possible.
5. Put a bar under the slow/normal selector rod A, as a support. Use a hammer and punch to remove the pins which fasten the selector jaw C, and fork B, to the rod. See Figure 87.
6. Remove the rod forward out through the front end plate. Put a finger over the hole N for the detent ball to prevent loss of the ball. Remove the ball through the selector rod hole.
7. Select first gear and put a soft metal punch between the casing and the front gear of the layshaft.
8. Remove the pinion shaft nut clockwise, (it has a left-hand thread) washer and front bearing. Put the first gear in the neutral position and remove the punch from between the casing and the layshaft.
9. Select second gear. Remove the four Nyloc nuts from the casing bolts and studs. Remove the two top bolts.




FIGURE 87. ARRANGEMENT OF SELECTORS

- | | | | |
|---------------------|------------------|------------------|-----------------------------------|
| A. Slow/Normal rod | E. High/Low fork | J. 2nd/3rd jaw | N. Slow/Normal detent ball hole |
| B. Slow/Normal fork | F. High/Low jaw | K. 1st/Rev. rod | P. High/Low detent ball hole |
| C. Slow/Normal jaw | G. 2nd/3rd rod | L. 1st/Rev. fork | R. First/Reverse detent ball hole |
| D. High/Low rod | H. 2nd/3rd fork | M. 1st/Rev. jaw | S. Second/Third detent ball hole |

10. Hold second gear in the engaged position. Put a finger over the hole S, for the detent ball. Pull the front end plate forward until it is clear of the selector rod G, for second and third gears. Remove the detent ball.
11. Select reverse gear. Move front plate forward until it is clear of the first/reverse selector rod K. Put a finger over the hole R, for the detent ball while doing this. Remove the ball out through the selector rod hole.
12. Put a finger over the hole P, for the detent ball for the high/low selector rod. Push the rod D, towards the rear until it is clear of the front plate. Remove the detent ball.
NOTE: The high/low rod does not have a gear lock.
13. Remove the slow/normal dog gear L, Figure 88 and the sliding selector from the front of the topshaft.
14. Move the front end plate forward until the slow/normal driven gear M, can be removed from the topshaft.
Remove the gear and the six bearing pads.




FIGURE 88. SLOW/NORMAL GEARS 1410 TRACTOR

- | | |
|--------------------|-------------------|
| A. Circlip | L. Dog gear, rear |
| B. Washer | M. Driven gear |
| C. Bearing, front | N. Splined washer |
| D. Distance piece | P. Circlip |
| E. Distance piece | R. Pin |
| F. Bearing, rear | S. Thrust washers |
| G. Input shaft | U. Needle bearing |
| H. Dog gear, front | V. Distance piece |
| J. Selector gear | W. Layshaft gears |
| K. Circlip | |

15. Remove the front end plate with the slow/normal layshaft in position.
If it is necessary to remove the layshaft, first remove the pin which fastens the spindle. Push the spindle out of the shaft and front plate. Remove the layshaft assembly and the two thrust washers. Use a press to push the bearings and distance piece out of the layshaft, if necessary.
16. Remove the lubrication muff A, Figure 89, from the rear of the topshaft.
17. Remove the bolt C which holds the rear bearing for the topshaft in position. The washer D will fall inside the casing, remove later.
18. Move the casing spacer forward approximately 25 mm.
Remove the topshaft complete and the high/low selector assembly.
Remove the shims from behind the rear bearing and keep safe for assembly.
19. Remove the main layshaft.




FIGURE 89. TOPSHAFT REAR END

- | | |
|---------------------|------------------|
| A. Lubrication muff | D. Washer |
| B. Shims | E. Topshaft |
| C. Bolt | F. Thrust washer |

25 mm = 1 in

See Figure 90.

20. Remove the two distance pieces E and H, and the shims G, from the front of the pinion shaft. Keep the shims safe, these will be needed for assembly.
21. Remove the splined washer J, third gear K, and the six bearing pads L, from the pinion shaft.
22. Move the synchroniser unit and the front dog gear forward as far as possible.
Release the circlip N, from the groove and slide it forward along the shaft.
23. Slide, rear dog gear and second gear R, forward. Move the special washer S, forward and remove the split ring T.
24. Slide the first/reverse gear U and selector forward until the selector rod is clear of the rear plate.
Lift the selector assembly out.
25. Remove the selector assembly for second and third gears.
26. Lift the front of the pinion shaft and remove all the components by sliding them forward.
27. Remove the washer for the rear topshaft bearing from the inside of the casing.
28. If necessary, disassemble the topshaft in the following sequence:
 - (a) front bearing, washer and circlip,
 - (b) high/low gear assembly complete with selector and bearing pads,
 - (c) rear circlip, rear bearing, distance piece and reverse idler gear.
29. If the pinion shaft has to be removed, first remove the differential assembly. Make a mark on one bearing cap and the end plate to make sure of correct assembly. Do not mix the caps and adjuster rings after removal.

Inspection of Parts

Check all parts for wear and damage after cleaning.
See pages 42 and 43 for procedure.

Adjustments

For adjustments before assembly see pages 44 to 48.

ASSEMBLY

See Figure 90.

1. Install the casing spacer so that the front face is level with the ends of the bottom studs.
2. Remove the circlip and bearing from the rear end of the topshaft. Install the bearing in the rear end plate complete with the correct amount of shims. See page 46 for adjustment. Install the bolt and washer to hold the bearing in position. Use a new tabwasher on the bolt.
3. Install the pinion shaft and differential. Use a wedge of wood to hold the pinion shaft in position.





FIGURE 90. BEVEL PINION SHAFT ASSEMBLY

- | | |
|--------------------|-----------------------|
| A. Nut | M. Dog gears |
| B. Washer | N. Circlip |
| C. Bearing, front | P. Synchroniser |
| D. Distance piece | R. Second gear |
| E. Distance piece | S. Special washer |
| F. Circlip | T. Split ring |
| G. Shims | U. First/Reverse gear |
| H. Distance piece | V. Plate |
| J. Splined washer | W. Shims |
| K. Third gear | X. Bearing, rear |
| L. Bearing pad (6) | Y. Shaft |

4. Slide the first/reverse gear T, onto the pinion shaft Y. Make sure the selector groove is towards the rear end plate.
5. Put the second gear R, on the pinion shaft with the synchroniser cup towards the front. Install the six bearing pads L, with a small amount of grease.
6. Put the rear dog gear M, on the pinion shaft. Make sure the thin part of the teeth is towards the front. Make a note of the position of the mark on the side of the gear.
7. Slide the circlip N, on to the pinion shaft but not into the groove.

8. Install the front dog gear with the thin part of the teeth towards the rear end plate. Align the mark on the side of the gear with the mark on the rear dog gear.
 9. Install the synchroniser unit on the dog gears.
 10. Install the selector assembly for second and third gears. Do not enter the rod into the rear end plate.
 11. Install the selector assembly for first and reverse gears. Enter the rod into the rear end plate. Move the casing spacer towards the rear approximately 50 mm at the same time.
 12. Put the split ring T, in the groove on the pinion shaft and slide the special washer S, over the ring.
 13. Push the synchroniser unit P, dog gears M, circlip N, and second gear R, towards the rear. Enter the selector rod for second and third gears into the rear end plate. Keep pushing until the circlip between the dog gears enters the groove on the shaft.
- Check that the circlip N, has entered the groove by pulling the second gear R, forward. It will not move if the circlip is in the groove.
14. Install the third gear K, with the synchroniser cup towards the rear. Put grease on the six bearing pads and push into position.
 15. Put grease on one side of the splined washer J, and put into position on the pinion shaft. Grease toward the gear.
 16. Put the layshaft in position inside the casing spacer.




R78 287

FIGURE 91. TOPSHAFT REAR END

- | | |
|---------------------|-------------------|
| A. Lubrication muff | D. Special washer |
| B. Shims | E. Topshaft |
| C. Bolt | F. Thrust washer |

0.8 mm = 0.031 in
50 mm = 2 in



R78 286

FIGURE 92. TOPSHAFT ASSEMBLY 1410 TRACTOR

- | | | |
|--------------------|--------------------|---------------------------|
| A. Circlip | J. Bearing pad (6) | T. Reverse idler gear |
| B. Bearing, front | K. Low gear | U. Thrust washer |
| C. Distance piece | L. Splined washer | V. Bearing, rear |
| D. High range gear | M. Circlip | W. Circlip |
| E. Selector gear | N. Bush | X. Lubrication muff |
| F. Dog gear | P. Topshaft | Y. Washer, rear bearing |
| G. Circlip | R. Bearing pad (6) | Z. Tabwasher rear bearing |
| H. Dog gear, rear | S. Bush | a. Bolt, rear bearing |

See Figure 91.

17. Put the topshaft complete and the selector assembly in position inside the casing spacer. Enter the end of the topshaft and selector rod into the rear end plate.
18. Move the spacer toward the rear end plate. Enter the rear bearing of the layshaft into the end plate. Hit the front of the topshaft with a soft face hammer to push it into the rear bearing. Install the circlip on the rear end of the topshaft when in position.
Install the bolt C and special washer D to hold the rear bearing in place.
19. Install the lubrication muff A at the rear end of the topshaft. Do not tighten the two nuts completely, permit a free movement of 0.8 mm.
20. Remove the outer cup of the front bearing for the topshaft from the end plate.
Install the cup on to the bearing cone on the shaft.
21. Put all the springs for the detent balls in the front end plate. Put the gear locks in position. Install the slow/normal layshaft, large gear toward the front.
22. Put the front end plate on to the bottom studs and move towards the spacer. Do this until the driven gear M, Figure 94 can be put on the topshaft. Install the gear with the dog teeth toward the front and install the six bearing pads.
23. Enter the first/reverse selector rod into the front end plate. Use the tool shown in Figure 93 to install the detent ball as follows:




FIGURE 93. INSTALLING DETENT BALL

- | | |
|-----------------|------------------|
| A. Tool | D. Detent ball |
| B. End plate | E. Detent spring |
| C. Selector rod | |




FIGURE 94.
SLOW/NORMAL GEARS 1410 TRACTOR

- | |
|--------------------|
| A. Circlip |
| B. Washer |
| C. Bearing, front |
| D. Distance piece |
| E. Distance piece |
| F. Bearing, rear |
| G. Input shaft |
| H. Dog gear, front |
| J. Selector gear |
| K. Circlip |
| L. Dog gear, rear |
| M. Driven gear |
| N. Splined washer |
| P. Circlip |
| R. Pin |
| S. Spindle |
| T. Plug |
| U. Thrust washer |
| V. Needle bearing |
| W. Distance piece |
| X. Layshaft gear |

- Put the flat of the tool towards the end of the selector rod. Push the tool down and push the rod up to the flat. Remove the tool and push the rod over the ball.
24. Push the front end plate toward the spacer. Push the first/reverse selector rod forward until the gear lock enters the groove, **NEUTRAL POSITION**.
 25. Install the selector gear J, Figure 94 and the dog gear H, for slow/normal on the topshaft. Make sure the thin part of the teeth of the dog gear is toward the front.
 26. Enter the selector rod for second and third gears into the front plate. Use the tool to install the detent ball. Move the selector rod forward.
 27. Put the selector rod for high/low in position. Use the tool to install the detent ball and move the rod forward.
 28. Enter the layshaft and topshaft bearings into the front end plate. Use a soft face hammer to hit the front plate until it is against the spacer.
 29. Install the two top casing bolts from the front. Install the four Nyloc nuts and tighten to 95 Nm.
 30. Engage reverse gear and put a soft metal punch between the casing and the layshaft. Make sure the splined washer is still in position.
 31. Install the front bearing, the two distance pieces with the shims between, on the pinion shaft. Make sure the small face of the front distance piece is toward the front.
 32. Install the washer and nut on to the pinion shaft. **NOTE:** There must be at least $1\frac{1}{2}$ threads showing through the nut. Check splined washer is in position if less, before tightening the nut. Tighten the nut counter-clockwise to 271 Nm.
 33. Install the circlip K, Figure 94 on the front of the topshaft.
 34. Put all gears in neutral and then select high or low range.

271 Nm = 28 kg m = 200 lb ft
 95 Nm = 10 kg m = 70 lb ft
 0.8 mm = 0.031 in




FIGURE 95. ARRANGEMENT OF SELECTORS

- | | | |
|---------------------|------------------|-----------------------------------|
| A. Slow/Normal rod | G. 2nd/3rd rod | M. 1st/Rev. jaw |
| B. Slow/Normal fork | H. 2nd/3rd fork | N. Slow/Normal detent ball hole |
| C. Slow/Normal jaw | J. 2nd/3rd jaw | P. High/Low detent ball hole |
| D. High/Low rod | K. 1st/Rev. rod | R. First/Reverse detent ball hole |
| E. High/Low fork | L. 1st/Rev. fork | S. Second/Third detent ball hole |
| F. High/Low jaw | | |

35. Put the slow/normal selector fork into the sliding gear. Enter the selector rod in the front plate and use the tool to install the detent ball. Push the rod toward the rear through the fork and selector jaw.
36. Align the holes in the rod, fork and jaw; install the pins which fasten the fork and jaw.
37. Align the gap in the teeth of the input shaft gear with the teeth of the layshaft. Push the input shaft assembly into the front plate and install the washer and circlip.
38. Install the balls and plunger for the starter safety switch.

GEAR LEVERS

Removing

1. Clean the gearbox cover and the ball housings.
2. Remove the setscrews which fasten the ball housings to the gearbox cover.
3. Remove the ball housings with the gear levers.
4. Put a cover over the holes in the gearbox cover to prevent dirt falling into the gearbox.
5. Remove the gear lever knobs by turning the knobs counterclockwise.
6. Bend the tabwashers away from the support plate setscrews.
Remove the support plate setscrews and the support plate.
7. Hold the ball end of the gear lever.
Carefully pull the gear lever through the dirt excluder.

Installing

1. Put grease in the ball housing.
2. Hold the ball end of the gear lever. Push the lever in position through the dirt excluder.
3. Install the support plate, setscrews and new tabwashers.
4. Tighten the support plate setscrews to 5.4 Nm.
Bend the tabwashers to keep the setscrews in position.
5. Install the gear lever knob.
6. Use a new gasket. Install the ball housing on the gearbox cover.
Check that the lever is engaged in the selector jaws.
7. Install the setscrews. Tighten to 9.5 Nm.

Dirt Excluders

1. Check the dirt excluders for wear and damage.
Replace if not correct.
2. Make sure that when the clip is in position the dirt excluder is tight against the ball housing.

NOTE: A hose clip can be used to hold the dirt excluder in position.




FIGURE 96. GEAR SELECTOR LEVERS

- | | |
|------------------|------------------|
| A. Range lever | D. Dirt excluder |
| B. Housing | E. Gear lever |
| C. Support plate | F. Housing |

5.4 Nm = 0.6 kg m = 4 lb ft
9.5 Nm = 1 kg m = 7 lb ft

DIFFERENTIAL UNIT

DIFFERENTIAL: 1210 TRACTOR Disassembly

1. Bend the tabwashers and remove the nine set-screws which fasten the cage to the end plate.
2. Put a mark on the cage and the end plate so that you can assemble the parts in the correct position. This job is important.
3. Use a soft faced hammer to remove the end plate C.
4. Use external circlip pliers to remove a circlip from the bevel pinion pin E.
5. Use a mild steel punch and a hammer to remove the pin.
6. Remove the bevel wheels G and bevel pinions F.
- NOTE: It is not necessary to remove the spiral gear from the cage unless it is to be replaced.
- If a new spiral gear is being installed, do steps 7 and 8.
7. Bend the tabwashers and remove the nuts and bolts which fasten the spiral gear A to the cage B.
8. Use a soft faced hammer to remove the spiral gear.
9. Check the two ball bearings D for wear and damage.
10. If there is wear or damage, use Service Tool K960605 Figure 98 to remove the bearings.

NOTE: If the Service Tool K960605 is not available, do the following:—

- (a) Make a thrust pad to fit the bearings.
 - (b) Use a puller which has two or three legs.
- If the outer part of the bearing is pulled off the inner part, do the following:—
- (a) Put the outer part over the inner part with the thick edge next to the differential.
 - (b) Insert three balls in between the inner and outer parts.
 - (c) Install the puller with the feet of the legs under the outer part.
 - (d) Tighten the puller to remove the inner part.




FIGURE 97. 1210 DIFFERENTIAL

- | | |
|------------------------|------------------|
| A. Spiral gear | E. Pin |
| B. Cage | F. Bevel pinions |
| C. End Plate | G. Bevel wheels |
| D. Ball thrust bearing | H. Circlip |




FIGURE 98. REMOVING BEARINGS

- | | |
|-----------------------|-----------------------------|
| A. Puller Claw legs | C. Adjuster arms |
| B. Adaptor thrust pad | D. Puller, Churchill No. 55 |

Assembly


1. Before you install new bearings, look for the word THRUST on the outer track of each bearing.
2. Install the bearings with the word THRUST toward the adjuster wheels.
Use a press to push the bearings into position.
3. Before you install a new spiral gear, make sure that the faces of the cage and the spiral gear are clean.
NOTE: Spiral gears and bevel pinions are made as a set.
Do not replace one part unless the other part is also replaced.
4. Put the Spiral gear in position on the cage and install the bolts.
Replace the tabwashers and install the nuts.
Tighten the nuts evenly to 68 Nm.
Bend the tabwashers to keep the nuts in position.
5. Put a small amount of moly sulfide paste on the faces of the bevel wheels and bevel pinions.
6. Install a bevel wheel in the cage.
Install the bevel pinions in the cage.
7. Align the holes in the bevel pinions with the holes in the cage and install the pin.
8. Use external circlip pliers to install the circlip on the bevel pinion pin.
9. Install the other bevel wheel.
10. Align the marks on the end plate and the cage and use a soft faced hammer to hit the end plate in position.
11. Use new tabwashers and install the setscrews. Make sure that the tabwashers are over the dowels.
12. Tighten the setscrews to 40 Nm.
13. Bend the tabwashers to keep the setscrews in position.

<p>40 Nm = 4.2 kgm = 30 lb ft 68 Nm = 7 kgm = 50 lb ft</p>
--

DIFFERENTIAL: 1410 TRACTOR

Disassembly

1. Make a mark on both halves of the differential cage to make sure of correct assembly.
2. Release the lock washers E and remove the twelve bolts which fasten the unit together.
3. Use a soft face hammer to remove the end plate N and spiral gear M.
4. Separate the halves of the cage and remove the bevel wheels H, bevel pinions K, and spider J.
5. Remove the circlip T which holds the differential lock ring S, remove the differential lock ring.
6. Remove bearings from end plate and cage if necessary. Use Service tool K960605.
DO NOT use a puller which pulls on the bearing outer cup.



R78 295

FIGURE 99. DIFFERENTIAL UNIT 1410 TRACTOR

A. Bolt	G. Thrust washer	N. End Plate
B. Adjuster	H. Bevel wheel (2)	P. Bearing
C. Locking tap	J. Spider	R. Adjuster
D. Bearing	K. Bevel pinion (4)	S. Differential lock
E. Locking tab	L. Cage	T. Circlip
F. Cage	M. Spiral gear	U. Bolt

Assembly

1. Press the bearings onto the end plate and cage. Make sure the word **THRUST**, which is on the outer cup of the bearings is outwards.
The bearings are of the angular contact type.
2. Put the differential lock ring on the end plate and install the circlip.
3. Assemble the end plate, spiral gear, and inner half of the cage onto two bolts.
4. Put moly sulfide paste on the bearing faces of the bevel wheels, bevel pinions and spider arms. Put the pinions on the spider.
5. Put the thrust washers on to the bevel wheels. Install the bevel wheels, pinions and spider into the cage.
6. Put the outer half of the cage into position. Install the remainder of the bolts and lock washers.
7. Make sure all parts are correctly assembled then tighten the bolts to a torque of 100 Nm. Bend the lock washers into position to prevent the bolts moving.

NOTE: If a new spiral gear is installed a new pinion shaft must be installed also.

100 Nm = 14 kg m = 74 lb ft




FIGURE 100. DIFFERENTIAL ASSEMBLED

- | | | |
|-------------------|-----------------------------|----------------------|
| A. Adjuster wheel | F. Adjuster wheel | L. Bevel pinion |
| B. Cage | G. Spur pinion shaft | M. Bevel wheel |
| C. Spider | H. Differential lock sleeve | N. Bearing |
| D. Spiral gear | J. Return spring | P. Spur pinion shaft |
| E. Bevel wheel | K. Bearing | |

ADJUSTMENTS

ADJUSTING BEARINGS

1. Remove the screws and locking plates from the adjuster wheels B.
2. Turn the right-hand adjuster wheel counter-clockwise and the left-hand adjuster wheel clockwise. Hit the bearing caps with a soft face hammer while doing this operation.
3. Turn the adjuster wheels until there is maximum clearance between the spiral gear and bevel pinion teeth.
4. Put a 30 cm screwdriver C in the slot of the differential cage, parallel with the floor. See Figure 101.

NOTE: On the 14 series tractor put the blade of the screwdriver between two cage bolts.

5. Adjust the wheels so that the weight of the screwdriver will just turn the cage.

Remove the screwdriver and turn the cage 180 degrees.

Put the screwdriver in the other slot and check the adjustment again.

6. When the adjustment is correct, make a mark on each adjuster wheel. Make marks on the end plate which aligns with the marks on the adjuster wheels.




FIGURE 101. ADJUSTING DIFFERENTIAL BEARINGS

- A. Spiral gear
- B. Bearing adjuster
- C. Screwdriver 30 cm long

30 cm = 12 in

TOOTH CLEARANCE

1. Turn the left-hand adjuster wheel counter-clockwise then the right-hand adjuster wheel clockwise. Turn the wheels the same amount using the marks as a guide.
2. Do this operation until the clearance between the spiral gear and bevel pinion teeth is 0.18 to 0.23 mm.
3. To measure the clearance fasten a dial gauge to the rear end plate. Put the probe of the gauge against a tooth of the spiral gear.
4. Hold the pinion to stop it turning and move the spiral gear backwards and forwards.
Make a note of the reading on the gauge. Repeat the check on three different teeth at 120 degree intervals around the spiral gear. Use the tooth which shows the smallest reading for the final adjustment. Mark the tooth so that all future adjustments can be done on it.
5. When the clearance is correct:
Tighten the differential bearing caps to 163 Nm.
Check the adjustment again.
Bend locking tabs over bearing cap bolts.
Install locking plates and screws for adjuster wheels.
Bend locking tabs over screws.




FIGURE 102. CHECKING TOOTH CLEARANCE

163 Nm = 17 kg m = 120 lb
 0.18 mm = 0.007 in
 0.23 mm = 0.009 in
 30 cm = 12 in

FINAL DRIVES

MAINTENANCE

1. Every 60 hours put grease in the hub seal housing through the grease fittings D. Operate the grease gun two times only when doing this job.
2. Every 125 hours check the level of the oil in the unit. Remember to clean around the level and filler plugs before removing. Make sure the breather bolts are clear on 12 series tractors.

NOTE: On 1410 4-wheel drive tractors the plug for the brake adjuster is used for both filling and level. The normal level plug is not used. See Figure 106.

On 1210 4-wheel drive tractors the plug on top of the casing is used for filling. See Figure 104.

3. Every 1000 hours change the oil in the unit. This is best done after the tractor has been used and the oil is warm.

NOTE: Clean around plugs before removing. Use clean oil containers see page 108 for correct grade of oil and capacity.




FIGURE 103. 1210 2WD TRACTOR

- | | |
|------------------------|-------------------|
| A. Filler / Level plug | C. Breather bolt |
| B. Drain plug | D. Grease fitting |

Breathers

Check that the breathers are free from restrictions every 125 hours when you check the oil levels.

On 1210 2WD tractors the top bolt of the cover has a hole through the centre. This bolt must only be replaced with a normal bolt if the tractor is changed to High Clearance. 1210 High Clearance tractors have a pipe installed for the breather. 1210 4WD tractors have a hole through the filler plug, A Figure 104.

On 1410 tractors the breather plugs are installed in the axle end flanges. The plugs cannot be checked from outside. Any pressure in the final drive releases into the axle case.




FIGURE 104. 1210 4WD TRACTOR

- | | |
|---------------------------|---------------|
| A. Filler / Breather plug | C. Drain plug |
| B. Level plug | |




FIGURE 105. FINAL DRIVE UNIT
1410 2WD TRACTOR

- A. Filler/Level plug
B. Drain plug
C. Hub grease fitting




FIGURE 106. FINAL DRIVE UNIT
1410 4WD TRACTOR

- A. Filler/Level plug
(Brake adjuster plug)
B. Drain plug

FINAL DRIVE: 1210 TRACTOR

Disassembly

1. Remove the oil from the reduction case.
2. Remove the cover.
3. Bend the tabwasher away from the ring nut which fastens the spur wheel to the final drive-shaft.
4. Use a 'C' spanner (Service Tool K909842) and a hammer to loosen the ring nut. Turn the nut until it is against the inner bearing.
5. NOTE: The following step only applies to earlier tractors, later models do not have the threaded holes.
Use a $\frac{1}{8}$ " BSF thread tap to clean the two threaded holes in the flange of the final driveshaft. Install the two bolts (Service Tool K900207) in the holes. Put the two thrust blocks in position between the ends of the bolts and the casing.
6. Tighten each bolt the same amount until the shaft is clear of the casing. Make sure the ring nut is clear of the threads of the shaft during this procedure.
7. For later tractors make the special plate as shown in Figure 11. Install the tool as shown in Figure 108. Tighten each bolt the same amount until the shaft is clear of the casing.
8. Remove the ring nut, tabwasher and inner bearing from the casing.
9. Remove the bolts which fasten the oil seal housing to the casing.
10. Remove the oil seal housing, collar and dirt shield.
11. Remove the spur wheel, oil seal sleeve, oil seal and outer bearing.




FIGURE 107. "C" SPANNER K909842 FOR RING NUT




FIGURE 108. REMOVAL OF FINAL DRIVE SHAFT

A. Tool No. K900207 C. Thrust block
B. Special plate

11. Use Service Tool K960618 to remove the brake drum as follows: See Figure 109.

- (a) Put the two $\frac{1}{2}$ in UNC \times 5 in bolts H through the holes in the flange on the tool.
- (b) Put the two distance tubes G on the bolts.
- (c) Slide the collar F and tool A over the spur pinion shaft.
- (d) Fasten the flange of the tool to the drum with the bolts.
- (e) Use a bar through the lug of the tool to prevent it from turning.
- (f) Tighten the centre bolt of the tool to remove the drum.

NOTE: If the drum is difficult to move hit the end of the centre bolt with a 7 lb hammer.

12. Remove the circlip from the cover over the end of the spur pinion shaft.
13. Hit the splined end of the shaft with a soft face hammer until the cover, shims and bearing are pushed out. Remove the shaft from the casing.
14. Remove the bearings from the shaft.
15. Use a long punch through the casing to remove the oil seal. Remove the circlip and distance piece.
16. Use a punch to remove the bearing cups from the casing. Hit both cups toward the inside of the casing.
17. Remove the collar from spur pinion shaft. Remove the 'O' ring from the collar.
18. Remove the adjusting screw and shims, for the final drive shaft.
19. Use a soft metal punch through the screw hole to remove the bearing thrust plate and bearing cup.

Inspection of Parts

1. Check all the bearing cups and cones for wear or damage.
2. Check the gear teeth for wear or damage.
3. Check the outside face of the collar for wear.
4. Replace any parts that show wear or damage.
5. Replace all the oil seals and 'O' rings. Destroy the old seals and 'O' rings.
6. Check the brake drums for wear. See the Data Section for the maximum wear before replacement is necessary.




FIGURE 109. BRAKE DRUM REMOVAL

- | | |
|---------------------------------|--|
| A. Service tool | G. Distance tube |
| E. Brake drum $3\frac{1}{2}$ in | H. Bolts $\frac{1}{2}$ UNC \times 5 in |
| F. Collar | |

Installing the Spur Pinion Shaft

1. Install the circlip C into the casing. Figure 110.
2. Install the oil seal B, with the lip toward the circlip, from the brake drum side of the casing.
3. Install the distance piece E next to the circlip.
4. Press the cup of the inner bearing into the casing with the thick edge toward the distance piece.
5. Press the bearing cones on to the shaft. Make sure the thick edges are against the spur gear.
6. Install a new 'O' ring into the collar D.
7. Remove any sharp edges from the splines of the spur pinion shaft.
8. Put a small amount of Hydraulic Seal Loctite on the inside of the collar D.
Install the collar on the shaft, small face toward the inner bearing.
9. Fit the keys into the grooves of the shaft, for the brake drum.
10. Install the spur pinion shaft into the casing. Press the cup of the outer bearing into the casing.
11. Use the following procedure to find the correct amount of shims to install for bearing preload.
 - (a) Install the end cover and circlip without shims.
 - (b) Push the end cover toward the bearing while turning the shaft.
 - (c) Use the feeler gauge to measure the gap between the circlip and the end cover. Do this in three different positions around the cover, see Figure 113, to find smallest gap. Make a note of the smallest measurement. Remove the circlip and end cover.
 - (d) Select shims of the same size as the smallest measurement, plus 0.076 mm, which is the bearing preload.

Example:	Measurement	0.304 mm
	Plus preload	<u>+0.076 mm</u>
	Shims needed	<u>0.38 mm</u>
12. Make sure the circlip groove has no sharp edges to cause damage to the 'O' ring.
Install the correct amount of shims, a new 'O' ring and the end cover.
Turn the shaft to align the bearings and hit the end cover with a soft face hammer.
Install the circlip while turning the shaft.
13. Hit the circlip with a hammer and large parallel punch to make sure it is fully in the groove.
14. Press the brake drum on to the shaft until against the collar D.




FIGURE 110. SPUR PINION SHAFT

A. Brake drum	H. Key
B. Oil seal	J. Shaft
C. Circlip	K. Bearing
D. Collar	L. Shims
E. Distance piece	M. End cover
F. 'O' ring	N. 'O' ring
G. Bearing	P. Circlip




FIGURE 111. BEARING ADJUSTMENT

A. Positions to check gap

0.304 mm	= 0.012 in
0.076 mm	= 0.003 in
0.38 mm	= 0.015 in
50 mm	= 2 in

Installing the Final Drive Shaft

1. Install the thrust plate A for the adjuster screw in the casing. Figure 112.
2. Press the inner bearing cup B, thick edge toward the thrust plate, into the casing.
3. Use a steel plate 13 mm thick and 110 mm diameter to press the inner oil seal G (single lip type) into the bore of the casing. Make sure the lip is toward the inside of the casing. Press the seal in until it is 25 mm from the outer face of the casing.
4. Use a steel plate 13 mm thick and 107 mm diameter to press the outer oil seal (double lip type) fully into the oil seal housing. Make sure the lips are toward the drive shaft flange. Put heavy grade grease between the lips of the seal.
5. Put the dirt shield P in position on the collar S. Put a new 'O' ring R on to the drive shaft and slide it against the flange. Push the collar and dirt shield on to the shaft until against the flange.
6. Install the oil seal housing on to the shaft.
7. Press the outer bearing cup into the oil seal housing, thick edge toward the oil seal.
8. Install the bearing cone on to the shaft and push it against the collar S and cup.

9. Install the oil seal sleeve F on to the shaft with the chamfer inward away from the bearing.
10. Clean the splines of the drive shaft with Loctite cleaning fluid and apply Loctite (stud-lock grade) to the splines.
11. Put the spur wheel in the casing and hold it in position while installing the drive shaft. Install the drive shaft into the casing and through the spur wheel.
Install the tabwasher D, ring nut C, and bearing cone B on the end of the shaft. Tighten the ring nut with your fingers.
12. Turn the oil seal housing until the grease fitting will be toward the rear of the tractor.
Install the bolts which fasten the seal housing to the casing. Tighten the bolts to 68 Nm.

25 mm = 1 in
68 Nm = 7 kgm = 50 lb ft
13 mm = 0.5 in
110 mm = 4.31 in
107 mm = 4.21 in




FIGURE 112.
FINAL DRIVE SHAFT
ASSEMBLY 1210

- A. Thrust plate
- B. Bearing
- C. Ring nut
- D. Tabwasher
- E. Spur wheel
- F. Sleeve
- G. Oil seal
- H. Bearing
- J. Gasket
- K. Housing, oil seal
- L. Bolt, oil seal housing
- M. Bolt, flange
- N. Drive shaft
- P. Dirt shield
- R. 'O' ring
- S. Collar
- T. Oil seal
- U. Adjuster screw
- V. Shims

13. Use a 'C' spanner (Service Tool K909842) and a hammer to tighten the ring nut.
NOTE: The nut must be tight or damage and rapid wear can be caused to the unit. Bend tab-washer lugs into nut.
14. Hit the flange of the drive shaft while turning it to align the bearings.
Install the adjusting screw without the shims. Turn the screw in until the end is against the thrust plate. Now turn the screw until all the free movement of the shaft is removed.
15. Use a feeler gauge to measure the gap between the head of the adjusting screw and the casing. Make a note of the measurement.
16. Remove the screw and install shims on to it. Select an amount 0.15 mm less than the measurement. Install the screw and tighten, lock with wire.
17. Put grease in through hub grease fitting until grease shows at top of inner seal.
18. Clean rear face of case and fit a new gasket. Install end cover and make sure breather bolt is fitted at top centre position. Make sure the hole in the bolt is not restricted.
19. Install the unit on to the tractor.
20. Adjust the brakes and fill the case with the correct grade of oil to the correct level.




FIGURE 113. TIGHTENING RING NUT

- A. "C" Spanner (Service Tool K909842)
B. Spur wheel

R78-305


0.15 mm = 0.006 in

FINAL DRIVE: 1410 TRACTOR**Disassembly**

1. Put the unit on the floor with the spur pinion shaft vertical and the drive flange on the floor. Put a block under the unit to hold it in this position.
2. On tractors which have mechanical brakes, remove the small cover plate from the brake housing.
Remove the shouldered clevis pin. Use a $\frac{1}{2}$ UNC Bolt in the threaded hole to remove if necessary.
3. On tractors with hydraulic brakes, remove the nut and pin from the operating lever. Remove the lever spacer and dirt seal from the shaft.
4. Remove the bolts which fasten the brake housing to the reduction casing. Lift the housing clear of the spur pinion shaft.

NOTE: The connecting link on mechanical brakes is removed with the housing but the pivot lever is not. The brake adjuster will have to be released if the lever does not clear the housing.


5. Remove the circlips from the brake link pins. Remove the pins and lift off the brake discs.
6. Remove the brake actuator assembly and the remainder of the brake disc plates.
Put all the parts on the bench in the sequence of removal.
7. Use a sling and hoist to lift the unit on to a bench or stand.



R7B-309

FIGURE 114. DISASSEMBLING BRAKES

- | | |
|-----------------------|-----------------------|
| A. Spur pinion shaft | E. Reduction case |
| B. Brake camshaft | F. Block |
| C. Stepped clevis pin | G. Drive shaft flange |
| D. Brake housing | |



R7B-310

FIGURE 115. FINAL DRIVE

- | |
|--------------------------|
| A. Disc brake assembly |
| B. Taper roller bearings |
| C. Final drive shaft |
| D. Oil seal housing |
| E. Spur wheel |
| F. Brake actuator |
| G. Disc hub |
| H. Spur pinion shaft |

Final Drive Shaft Removal

1. The final drive shaft can be removed with the final drive installed on the tractor if necessary.
2. Remove the spur wheel cover.
3. Remove the circlip between the inner bearing and the spur wheel from the groove.
4. Put a socket spanner through the holes in the flange of the drive shaft. Remove the bolts which fasten the oil seal housing to the reduction casing.

5. Use a lever to pull the drive shaft out of the casing. Use a lever to remove the inner bearing from the end of the shaft at the same time.

DO NOT try to pull the shaft out with the bearing in position. The rollers will be pushed out of the cage.

6. Remove the spur wheel, circlip or special washer and inner bearing from the casing.
7. Remove the locking screw from the ring nut on the final drive shaft. Use the special spanner DB 8009 to remove the ring nut.
8. Use a $\frac{1}{2}$ inch BSF thread tap to clean the two threaded holes in the drive shaft flange.

NOTE: Not later tractors.

9. Install the two extractor bolts K900207 in the holes. Put a thrust block of metal between the end of each bolt and the casing. Tighten the bolts evenly to push the seal housing and bearing off the shaft.
10. On later tractors without threaded holes in the flange a plate must be made as shown in Figure 10.

Install the tool as shown in Figure 117. Turn each bolt the same amount until the housing is off the shaft.

Use a lever to remove the oil seals and remove the bearing from the seal housing.




FIGURE 116. SPECIAL SPANNER DB 8009 FOR RING NUT




FIGURE 117. REMOVING FINAL DRIVE SHAFT


- A. Tool DB900207
- B. Special plate
- C. Wheel nuts
- D. Thrust block

Spur Pinion Shaft Removal

1. Remove the circlip which holds the cover in position over the end of the spur pinion shaft.
 2. Hit the splined end of the shaft with a soft face hammer to remove the cover, bearing and shaft.
 3. If it is necessary to remove the bearing cups from the casing, use a soft metal punch. Hit all the cups towards the centre of the casing.
 4. Make the plate shown in Figure 118. Fasten the plate to the flange of the brake drum removal tool K960618. Put the plate in the groove of the brake disc hub. Use the tool to pull the hub off the shaft.
 5. Remove distance piece and bearing if necessary.
- NOTE: If the disc hub only is to be replaced, use the tool to remove hub after the housing has been removed. This will save time.

Inspection of Parts

1. Clean all parts.
2. Look for wear and damage to gears, bearings, shafts and casing.
3. Discard all oil seals and 'O' rings.
4. Check brake components for wear and damage.



R75.244

FIGURE 118. TOOL FOR REMOVING DISC BRAKE HUB

- A. 105 mm = $4\frac{1}{8}$ in centres
- B. 20 mm = $\frac{1}{2}$ in
- C. 170 mm = $6\frac{3}{4}$ in diameter
- D. 79 mm = $3\frac{1}{2}$ in diameter
- E. 3.2 mm = $\frac{1}{8}$ in recess
- F. 1.6 mm = $\frac{1}{16}$ in radius
- G. 67.5 mm = $2\frac{11}{16}$ in
- H. Holes with $\frac{1}{8}$ UNC thread

ASSEMBLY

Installing Spur Pinion Shaft

1. Fit the bearings on the spur pinion shaft, thick edges against the gear.
2. Slide the distance piece, chamfers toward inner bearing, on the shaft until against the bearing.
3. Put the keys for the brake disc hub in the grooves of the shaft.
4. Install the brake disc hub with the long splines toward the distance piece. Use a hammer or press and hollow tube for this job.
5. Install the circlip, distance piece and inner bearing cup into the reduction casing. Make sure the thick edge of the cup is against the distance piece.
6. Put grease on the bearings and install the spur pinion shaft into the casing.
7. Install the cup of the outer bearing into the casing.
8. Adjust the bearing preload as follows:
 - (a) Install the end cover and circlip without shims.
 - (b) Push the cover toward the end of the shaft while turning the shaft to align the bearings.
 - (c) Use a feeler gauge to measure the gap between the circlip and the cover.
 - (d) Make a note of the smallest measurement.
 - (e) Select shims of the same amount as the smallest gap measurement.
Add 0.076 mm which is the amount of bearing preload needed.
 - (f) Remove the circlip and cover and install the correct amount of shims. Install the cover.
 - (g) Install the circlip and use a hammer and punch to hit it fully into the groove.




FIGURE 119. FINAL DRIVE ASSEMBLY

- | | |
|--------------------------|----------------------|
| A. Brake discs | E. Spur wheel |
| B. Taper roller bearings | F. Brake actuator |
| C. Final drive shaft | G. Hub for discs |
| D. Oil seal housing | H. Spur pinion shaft |




FIGURE 120. BEARING ADJUSTMENT

- A. Positions to check gap

0.076 mm = 0.003 in

Installing Final Drive Shaft

1. Put a new 'O' ring on the flange end of the final drive shaft. Install the dirt shield and oil seal collar.
2. Install a new seal in the outer face of the seal housing. Use a steel plate 13 mm thick and 125 mm diameter to press the seal in evenly. Make sure the lip is toward the drive shaft flange. Fill seal with heavy duty grease. Install bearing cup into the seal housing, thick edge towards shaft flange.
3. Put a small amount of Loctite 270 in the bore of the bearing cone and install in cup.
4. Use a steel plate 13 mm thick and 138 mm diameter to press a new seal into the inner face of the seal housing. Make sure the lip is toward the spur wheel. Put heavy grade grease in between the seals and on the bearings.
5. Hold the drive shaft flange in a vice and push the seal housing and bearing onto the shaft.
6. Put the special locknut on the drive shaft and tighten with the special spanner, D.B.8009 and 1 kg hammer.

NOTE: Make sure the nut is tight or rapid wear and damage will be caused to the unit. Use nut K945534 with $\frac{1}{8}$ UNC thread.

7. Put Loctite 270 on the locking screw for the special locknut. Install the screw in a hole which is aligned with a spline groove and tighten.
8. Install the circlip in the groove next to the locknut on tractors before serial number 11204637. After this number a special washer is installed instead of the circlip. The washer is available in different sizes to give 0.10 mm to 0.66 mm shaft end movement. See D Figure 123.

To find the correct size of washer to use, do the following:

- (a) Put the drive shaft vertical on a bench, flange down.
 - (b) Install a special washer and the spur wheel.
 - (c) Hold the edge of the circlip in the groove, do not fit it. Measure the gap between the circlip and the spur wheel with a feeler gauge.
 - (d) Select and install a washer which gives a clearance of 0.10 mm to 0.66 mm between the circlip and the spur wheel.
9. Press the bearing cup for the inner bearing into the final drive case, thick edge toward axle.
 10. Put grease on the inner bearing cone and put in position in the cup.
 11. Install the final drive shaft and seal housing without shims and spur wheel. Hit the flange of the drive shaft and turn it at the same time until fully installed.




FIGURE 121. FINAL DRIVE SHAFT

- | | |
|-----------------|-------------------|
| A. Seal housing | G. Locknut |
| B. Dirt shield | H. Circlips |
| C. Collar D | J. Bearings |
| D. 'O' ring | K. Spur wheel |
| E. Oil seal | L. Grease fitting |
| F. Oil seal | |




FIGURE 122. LOCKING NUT AND LOCKING SCREW

- | | |
|----------------|------------------|
| A. Locknut | C. Locking screw |
| B. Drive shaft | |

13 mm = $\frac{1}{2}$ in
125 mm = $4\frac{11}{16}$ in
138 mm = $5\frac{7}{16}$ in

0.10 mm = 0.004 in
0.66 mm = 0.026 in
0.12 mm = 0.0047 in

12. Install three of the seal housing bolts at even distances around the seal housing. Tighten the bolts evenly and turn the shaft at the same time to align the bearings. Tighten until all free movement is just removed.
13. Use a feeler gauge to measure the gap between seal housing and casing at three positions. The gap must be the same at all three positions. Make a note of the measurement.
14. Select shims to an amount of 0.12 mm less than the gap measurement.
15. Remove the drive shaft and install the shims on the seal housing. Install a new 'O' ring on the seal housing.
16. Install the shaft again with the spur wheel in position. When the shaft is through the spur wheel put the circlip on the end of the shaft.
17. Use the setscrews for the seal housing to pull it into place. At the same time use a heavy soft face hammer to hit the flange of the drive shaft. Install the circlip into the groove on the shaft. Make sure the grease fitting on the seal housing is toward the rear of the tractor.
18. Put grease through the grease fitting until grease comes out from the inside seal.
19. Clean face of case and fit a new gasket and then the cover. Make sure the cover is installed correctly.
20. Use a sling and hoist to lift the reduction unit on to the floor. Put the unit on the floor with the spur pinion shaft vertical and drive flange on the floor.
21. Install the brake discs and brake actuator in the correct sequence. Install the link pins and circlips.
22. Install the brake housing and bolts to the reduction casing and tighten the bolts.
23. Install the shouldered clevis pin on tractors with mechanical brakes. Install a new oil seal and dirt seal on the brake shaft, on tractors with hydraulic brakes. Install the spacer and lever.
24. Install unit on to the tractor, connect and adjust the brakes. Install the covers for the clevis pins.
25. Fill unit with oil to the correct level.




FIGURE 123. FINAL DRIVE SHAFT AND GEAR

- | | |
|----------------|-----------------------------------|
| A. Drive shaft | D. Special washer, later tractors |
| B. Drive gear | E. Special locknut |
| C. Circlips | F. Bearing |

REAR AXLE CASE OIL SEALS

There are two oil seals installed at each end of the axle case.

Removing the Oil Seals

1. Use the Service Tool K900208 shown in Figure 124 to remove the seal housing.
2. Use two $\frac{1}{2}$ BSF \times 2 in bolts to fasten the tool to the housing.
3. Install the two special bolts (900207) in the tool.
4. Tighten the bolts evenly to pull the housing out of the axle case.
5. Remove the oil seals from the housing.

Installing the Oil Seals

1. Clean the oil seal housing and the inside of the axle case.
2. Push a new seal in position in the bore of the housing.

Make sure that the seal lip is away from the housing shoulder, on 1210 tractors and toward it on the 1410 tractor. Use an acceptable piece of metal or wood, 76 mm diameter, to push the seal to the end of the housing bore.

NOTE: On 1410 tractors the oil seals must be installed back to back in the housing, lips outward.

3. Put the second new seal in position in the bore of the housing. Push in until level with the housing. Make sure that the seal lip is away from the housing shoulder.

Use the same piece of wood or metal to push the seal in the housing until it is level with the housing edge.

4. Put grease in the space between the oil seals, on 1210 tractor.
5. Put jointing compound on the outside of the housing.
6. Use a soft faced hammer to hit the housing into position in the axle case. The two holes in the housing must be horizontal.

BREATHERS

On 1410 tractors there is a breather plug installed in the end flanges of the axle case. Make sure these are free from any restrictions. Remove and clean with kerosene and compressed air if necessary.




FIGURE 124. REMOVING OIL SEAL HOUSING FROM AXLE CASE

- | | |
|---------------------|----------------------------|
| A. Oil seal housing | C. Bolts into seal housing |
| B. Bridge piece | D. Extraction bolts |




FIGURE 125. REAR AXLE CASE OIL SEALS 1210 TRACTOR

- | | |
|--------------|-----------------|
| A. Oil seals | B. Seal housing |
|--------------|-----------------|

76 mm = 3 in

BRAKES

DRUM BRAKES: 1210 TRACTOR

OPERATION

The brake system has a separate pedal and linkage connected to each brake unit on each side of the rear axle. The shoe assemblies are installed on the ends of the axle case. The brake drums are installed on the spur pinion shafts of the final drive units.

The pedal on the left operates the brake on the left-hand side. The pedal on the right operates the brake on the right-hand side. The single pedals are used to give assistance to the steering for tight turns. For normal brake operation the pedals must be connected together by the locking plate on the left-hand pedal. The handbrake operates both brakes through the same linkage.

⚠ DANGER: Always connect the brake pedals together for normal braking. The tractor will make a sudden turn which can cause a roll-over if the pedals are not connected. This can cause serious injury or death.

BRAKE ADJUSTMENT

1. Put the tractor on hard and level ground.
2. Put wedges of wood under the front and rear of the front wheels.
3. Use a jack to raise the rear of the tractor until the rear wheels are just clear of the ground.
4. Put supports between the rear axle case and the ground for safety.
5. Disengage the pedal locking plate.
6. Adjust the left-hand brake rod until the left-hand wheel will not rotate. This centralises the brake shoes.
7. Loosen the left-hand brake rod adjuster until the left-hand wheel can be rotated easily. The shoes are permitted to just make contact with the drums.
8. Repeat steps 1 to 7 on the right-hand brake.




FIGURE 126. BRAKE MECHANISM ARRANGEMENT

- | | | | |
|---------------------|--------------------|-------------------|---------------|
| A. Hand lever | E. Left-hand pedal | J. Adjusting nut | N. Pin |
| B. Fork | F. Adjusting screw | K. Camshaft lever | P. Brake drum |
| C. Operating lever | G. Cross shaft | L. Camshaft | |
| D. Right-hand pedal | H. Brake rod | M. Brake shoe | |

R78-308

9. Pull the hand brake on one tooth of the ratchet.
Check the position of the pedals.
If the R.H. pedal is in front of the L.H. pedal, adjust the L.H. rod until the locking plate can be engaged.
If the L.H. pedal is in front of the R.H. pedal, adjust the R.H. rod until the locking plate can be engaged.
10. Check that the resistance of the rear wheel to rotate is the same.
11. If there is any difference, adjust the R.H. rod until both wheels have the same resistance to rotate.
12. Pull the hand brake on one more tooth of the ratchet and check the resistance of the wheels to rotate again. Repeat step 11 if necessary.
13. Repeat step 12 until both rear wheels are locked at the same time.
14. Hold the adjusting nuts stationary and tighten the locknuts on the brake rods.
15. Test the tractor on the highway and make any final adjustments if necessary.
NOTE: Use a low speed at the start of the test. Use a dry level surface for the test.
16. If for any reason the brake cross-shaft has been disassembled or the pedals replaced, do the following.
 - (a) Pull the hand brake on five teeth of the ratchet.
 - (b) Adjust the R.H. pedal until the locking plate can be engaged. Tighten the Locknut for the adjuster.
 - (c) Adjust the brakes as in steps 1 to 15.**NOTE:** Normally pedal adjustment is not necessary.

INSTALLING NEW LININGS

1. Use a drill to remove the head at the hollow end of the rivets.
2. Use a hammer and punch to remove the rivets from the shoes.
3. Remove the old lining and clean the shoe.
4. Put the new lining in position on the shoe and check that the hole in the lining and shoe align.
5. Install the new rivets starting at the centre of the lining and working toward the ends.
6. Make sure there are not any gaps between the lining and the shoe after it is installed.
7. Keep the shoes and linings away from oil and grease.

NOTE: If there is oil on the old linings, install new oil seals before the new shoes or linings are installed.

INSTALLING NEW BRAKE SHOES

1. Remove the final drive unit from the rear axle, see page 34 for procedure.
2. Remove the brake shoes and springs from the axle flanges.
3. Clean the axle flanges and install new shoes and springs.
4. Check the brake drum for damage and wear. Install a new drum if necessary.
5. Repeat step 1 to 4 on the other side.




FIGURE 127. INSTALLING BRAKE SHOES

DISC BRAKE UNIT: 1410 TRACTOR

HOW IT WORKS

The brake assemblies are installed in each final drive housing. Each unit has an actuator, four stationary discs and six discs which can rotate. The six discs which can rotate are connected by splines to the spur pinion shaft. The discs have a special friction face on each side. The stationary discs are held stationary by a large steel pin in the casing. The actuator has two separate plates pulled together by tension springs and separated by six steel balls. The steel balls roll in grooves which have a gradient. Each plate of the actuator is fastened to the brake operating linkage. When the brake is operated the linkage rotates the two plates in opposite directions. This causes the steel balls to roll up the gradient of the grooves and separate the plates. The plates press the discs against each other and against the housing which applies the brakes.

Each actuator plate has a rotating disc next to it. When the brake is applied, these discs try to rotate the actuator in the direction of rotation. See Figure 130.

One actuator plate moves until it comes in contact with a lug on the casing.

The other plate is free to move in the direction of rotation of the discs.


The more the plate moves, the more the plates are separated. This applies more pressure to the discs without more pressure being needed on the foot pedal.

When the brake is released, the tension springs pull the actuator plates together and release the discs.

A pedal is installed for each brake assembly so it can be operated separately for tight turns with the steering. A single pedal is installed between these two pedals for normal braking. See Figure 131.




DANGER: *Never use the outside pedals when travelling on the highway or at speed. The tractor will make a sudden turn which can cause a roll-over. This can cause serious injury or death.*



R78-315

FIGURE 128. ACTUATOR AND DISCS

- | | |
|---------------------|--------------------|
| A. Stationary discs | C. Steel ball |
| B. Rotary discs | D. Actuator plates |



R78-328

FIGURE 129. BRAKE RELEASED

- A. Clearance between both links and stop lugs on housing




FIGURE 130. OPERATION OF ACTUATOR ASSEMBLY

- | | |
|---|-----------------------------------|
| A. Movement of plates | C. Plate in contact with stop lug |
| B. Direction of rotation of shaft and discs | D. Plate clear of stop lug |




FIGURE 131. ARRANGEMENT OF BRAKE MECHANISM

- | | |
|-----------------|-----------------|
| A. Right pedal | G. Camshaft |
| B. Left pedal | H. Brake rods |
| C. Centre pedal | J. Adjusters |
| D. Hand brake | K. Compensator |
| E. Actuator | L. Cross shaft |
| F. Lever | M. Rod adjuster |

MAINTENANCE

Lubrication

Grease fittings are installed on the centre and left-hand pedals, compensator beam and brake housing. Use a grease gun to put grease through the fittings every 60 hours.

Disc and Rod Adjustment

1. Put the tractor on level ground and put wedges to front and rear of the wheels to prevent the tractor moving. Release the hand brake.
2. Clean around the access plugs for the brake adjusters then remove the plugs. See Figure 133.
3. Clean around the clevis pin covers then remove the covers. See Figure 133.
4. Make a line between the centres of the two front setscrew holes. See A Figure 133.
Measure the distance between the line and the front edge of the clevis pin. The measurement must be 25 mm.

Do steps 5 to 11 if the measurement is not 25 mm.


Do step 12 if the measurement is 25 mm.

NOTE: The measurement at A Figure 133 will not be 25 mm if:

- (a) the nuts M Figure 131 which adjust the pull rods, have been used to adjust the brakes,
- (b) the tractor is an early model, which had a setting of 65 mm pedal movement,
- (c) the cross-shaft has been disassembled to remove it or fit new pedals or foot plate.

5. Turn the adjuster nut, C Figure 133, counter-clockwise three full turns.
6. Loosen the bolts which fasten the stop plate to the right-hand foot plate.
7. Pull the centre foot pedal up until the pedal and hand brake operating lever are aligned.
Slide the stop plate against the centre pedal.
8. Loosen the locknuts on the adjuster screws in the pedal compensator.
Loosen the adjuster screws.
9. Pull the right and left-hand pedals up to the stop plate. Make sure that the foot pads are aligned, tighten the bolts which fasten the stop plate.
10. Hold the three pedals against the stop plate. Put the compensator parallel with the foot plate surface. Turn the adjuster screws evenly until against the left and right-hand brake pedals. Tighten the lock nuts.
11. Adjust the length of the pull rods H Figure 131 by turning nut M.


Do this until the measurement at A Figure 133 is 25 mm. Tighten the lock nuts when the measurement is correct. Do not use these nuts for future adjustment for disc wear.



R78 320

FIGURE 132. BRAKE PULL ROD ADJUSTMENT

- A. Right-hand pedal
- B. Centre pedal
- C. Left-hand pedal
- D. Adjuster nut on pull rod
- E. Compensator adjuster screw
- F. Compensator
- G. Adjuster screw
- H. Pull rod



R78 319

FIGURE 133. DISC ADJUSTMENT

- A. Setting, 25 mm (1 in)
- B. Access hole to adjuster
- C. Adjuster nut
- D. Clevis pin

NOTE: Clevis pin not installed on tractors with hydraulic brakes.

25 mm = 1 in
32 mm = 1 1/4 in
38 mm = 1 1/2 in

12. Adjust the adjuster nut C Figure 133 until the complete movement of the pedal is 32 to 38 mm. This movement is from the brake fully released to the brake fully engaged.

13. Repeat steps 4 to 12 on the other brake assembly.

NOTE: When the setting is correct at A Figure 133, normal brake adjustment must only be done by using nut C Figure 133. The nut must be adjusted until the pedal movement is correct.

When the brakes are operated, if the engagement is sudden, check the following:

- (a) Brake adjustment
- (b) Clevis pin adjustment
- (c) Compensator beam adjustment.
- (d) Correct grade and amount of oil in the housing.
- (e) Clearance between the face of the housing and the first rotary disc, this must be between 0.43 and 3.12 mm.

If the clearance is more than 3.12 mm add an extra stationary disc.

This must be installed in the position shown at D Figure 134.

NOTE: The clearance must not be less than 0.43 mm after the extra disc has been installed.

Every 60 hours or weekly, remove any chemicals or manure from steel brake pipes. These two materials cause corrosion.

Every 500 hours or six monthly check all steel pipes for corrosion and damage. Replace any pipes which are found corroded or damaged.




FIGURE 134. DISC BRAKE ASSEMBLY

- A. Rotary disc (Bronze)
- B. Stationary disc (Steel)
- C. Clearance between top disc and housing
- D. Extra steel disc No. K945755



DANGER: *Manure and chemicals cause corrosion to brake pipes, this can cause brake failure. Clean and check brake pipes at regular intervals. Serious injury or death can be caused if the brakes fail.*

0.43 mm = 0.017 in
 3.12 mm = 0.123 in
 25 mm = 1 in
 32 mm = 1 1/4 in
 38 mm = 1 1/2 in
 65 mm = 2 1/2 in

DISASSEMBLY

After the final drive has been removed from the tractor use the following procedure to disassemble:

1. Put the final drive on the floor with the spur pinion shaft up vertical. Put a block of wood under the unit to hold it in this position.
2. Remove the small cover on the brake housing. Remove the shouldered clevis pin.
Use one of the cover bolts in the threaded hole of the pin if it is tight.
Remove the operating lever, spacer and dirt shield on tractors with hydraulic brakes.
3. Remove the bolts which fasten the brake housing to the final drive casing.
Lift the housing clear of the spur pinion shaft.

NOTE: The operating link comes away with the housing but the pivot lever does not. The adjuster will have to be released if the lever will not clear the housing.

4. Remove the circlips from the link pins.
Remove the pins. Lift out the top discs.

5. Remove the actuator assembly with operating shaft and linkage.
Remove the remainder of the discs.
6. If necessary, remove the disc hub from the spur pinion shaft. This can be done without removing the discs and actuator if the hub only is to be replaced.
7. Put all the parts on the bench in the sequence of removal.

Disassembly of the Actuator

1. Remove the pin which fastens the operating rod to the links.
Remove the bolts and nuts which fasten the links to the plates.
2. Remove the tension springs which hold the actuator plates together.
3. Separate the plates and remove the six steel balls.
4. Check all parts for wear and damage.
Replace any part which has a defect.




FIGURE 135. COMPONENTS OF DISC BRAKE

- | | |
|--------------------------|----------------------------|
| A. Pin, link to pull rod | F. Rotary (Bronze) disc |
| B. Pull rod | G. Stationary (Steel) disc |
| C. Bolt, link to plate | H. Steel ball |
| D. Link | J. Tension spring |
| E. Actuating plate | |


R78 318

ASSEMBLY

1. Put an actuating plate on the bench with the grooves, for the balls, upward. Put the six balls in the grooves.

Install nuts and bolts to links and tighten to 41 Nm. Use a sharp punch to lock the nut in position.

2. Put the other plate on top, then make sure the links are in the correct positions.
3. Check that the balls are in the grooves then install new tension springs.
4. Connect the links to the operating rod.
5. Use a press or a hammer, and a hollow tube to install the disc hub on the spur pinion shaft.
6. Install one of the rotary discs on to the disc hub. Install a stationary disc on top of the rotary disc.
7. Repeat step 6 two more times then install the actuator.
8. Install a rotary disc, stationary disc and then a rotary disc, in that sequence on top of the actuator.
9. Install the link pins and circlip.
10. Install the housing and fasten the bolts.
11. Install the shouldered clevis pin on tractors with mechanical brakes.
12. Install a new oil seal, and dirt seal on the operating shaft on tractors with hydraulic brakes. Install the spacer and the operating lever on the shaft. Install the cotter pin and tighten.
13. Install the final drive on the tractor and adjust the brakes.
14. Install the small cover over the clevis pin.
15. Fill the unit with the correct oil to the correct level.



R78 314

FIGURE 136. DISC BRAKE ASSEMBLY

- A. Rotary (Bronze) plate
- B. Stationary (Steel) plate
- C. Clearance of brake plate below housing joint.
- D. Additional steel plate K945755

41 Nm = 4.1 kgm = 30 lb ft

HYDRAULIC BRAKES

HOW IT WORKS

The hydraulic system is used on tractors which have a Q-Cab or De-Luxe Cab. The disc assemblies and brake drums are the same as for tractors without a cab. Each brake unit is operated, through hydraulic pipes, by a slave cylinder instead of rods and levers.

A single reservoir is used for the brake fluid. This is connected to two separate master cylinders which are operated by separate pedals. The master cylinders are connected to a balance valve which is connected to the slave cylinders.

Each slave cylinder has a spring connected to the cam lever which retracts the piston. The fluid is then pushed back into the reservoir through the master cylinder when the brake is released.



DANGER: Only the correct fluid must be used in the system. These are Shell Tellus 37 or Castrol Hyspin AWS 32. Normal brake fluid **MUST NOT** be used. If any other oil is used, brake failure will occur and cause injury or death.

For brake operation on one wheel only one pedal is used. For normal brake operation the pedals must be connected together by the link between the pedals. A brake balance valve is installed in the system to give equal braking.

The left-hand pedal operates the left-hand brake.

The right-hand pedal operates the right-hand brake.




FIGURE 137. HYDRAULIC BRAKE SYSTEM

- | | | |
|-----------------------|-------------------|---------------------|
| A. Reservoir | F. Pedal | K. Slave cylinder |
| B. Master cylinder | G. Locking plate | L. Bleed screw |
| C. Push Rod | H. Balance valve | M. Steel pipes |
| D. Fork | J. Flexible pipes | N. Stop lamp switch |
| E. Pin, pedal to fork | | |

BALANCE VALVE

The balance valve has a plunger which has a seal around the centre. The plunger is installed in the bore of the valve and is held in the centre position by a spring. One end of the bore is connected to one side of the system, the other end to the other side. Inlet pipes are connected to the master cylinders and outlet pipes to the slave cylinders.

When the left-hand brake pedal is operated, the plunger moves to the right until against a stop, B Figure 138.

When the right-hand brake pedal is operated, the plunger moves to the left until against a stop, C Figure 138.

When both pedals are operated together, the plunger moves until the pressure is equal each end. This gives equal brake pressure to each side of the system. The plunger changes position according to different amounts of wear, adjustment, or pedal movement between each side.

NOTE: The valve cannot be repaired. Install a new valve if a fault is found.

REMOVING THE BALANCE VALVE

The valve is fastened to the front cross member under the cab. Access is under the rear of the cab.

1. Put a container under the valve for the fluid to drain into.
2. Make a note of where each flexible pipe is connected then disconnect the pipes.
3. Disconnect the two steel pipes.
4. Remove the bolts which fasten the valve to the cross member.

INSTALLING THE BALANCE VALVE

1. Fasten the valve to the cross member.
2. Connect all pipes.
3. Use the same procedure as for the master cylinder to remove air from the system.

NOTE: The balance valve cannot be repaired. If there is a fault, install a new unit.



WARNING: Make sure all brake pipes are fastened correctly and do not have contact with moving parts. This includes cab and chassis parts. A broken pipe will cause injury or death.




FIGURE 138. VALVE OPERATION

- A. Both brakes applied
B. One side only applied
C. Opposite side only applied

REMOVING A MASTER CYLINDER

1. Put a container under the master cylinders. Disconnect the feed pipe from the brake fluid reservoir. Let the fluid drain into the container.
2. Remove the link pipe between the cylinders.
3. Disconnect the pipe to the balance valve. Remove completely if removing the right-hand master cylinder.
4. Remove the reservoir feed pipe.
5. Disconnect the push rod from the pedal.
6. Remove the setscrews which fasten the cylinder to the body. Remove the cylinder.

INSTALLING A MASTER CYLINDER

1. Put the cylinder in position on the bulkhead.
2. Install the setscrews and tighten.
3. Install the hydraulic pipes.
4. Connect the pedals together with the link.
5. Install the push rod in position and adjust the fork until the pin can be installed easily. Do not move the piston of the cylinder.
6. Fill the reservoir to the correct level with the correct oil.
7. Remove air from the system.

REMOVING A SLAVE CYLINDER

1. Disconnect the return spring from the operating lever.
2. Remove the pin which connects the cylinder push rod to the operating lever.
3. Put a clamp on the flexible pipe and disconnect the pipe to the cylinder.
4. Remove the nuts and bolts which fasten the cylinder to the tractor.

NOTE: On 1210 tractor, also remove the guard.

INSTALLING A SLAVE CYLINDER

1. Fasten the cylinder to the tractor.
2. Connect the pipe, remove pipe clamp.
3. Install the pin and return spring to the operating lever.
4. Use the same procedure as for a master cylinder to remove air from the system.

5 mm = $\frac{1}{16}$ in

REMOVING AIR FROM SYSTEM

1. Loosen the bleed screw on one of the slave cylinders.
2. Use a piece of plastic or rubber tube which has a 5 mm bore. Push one end of the tube on the bleed screw. Put the other end of the tube in a clear container. Add brake oil to the container until the end of the tube is below the surface.
3. Get assistance to press the pedal down. Close the bleed screw just before the pedal is fully down. Release the pedal and then loosen the bleed screw again.
4. Repeat this procedure until no air bubbles come from the end of the tube. Tighten the bleed screw.
5. Do the same on the other side of the system until all air is removed.

NOTE: Keep the reservoir full while doing the operation or air will enter the master cylinder.

The system can be filled through the bleed screws by using a pressure oil can connected to a bleed tube. Add brake fluid by this method until the reservoir is at the correct level. Make sure the oil can is kept full during the operation. If the pedal feels hard after this method is used, removal of air will not be necessary.



WARNING: DO NOT use the oil can for any other use. Brake failure will occur if oils are mixed. This can cause injury or death.

BRAKE DEFECTS

1. If the pedal feels soft when the brake is operated then there is possibly air in the system. Use the procedure as for master cylinder to remove the air.
2. If the pedal is still soft after the correct procedure has been followed, do the following:
 - (a) Fasten a Girling T3 clamp to the flexible hose of the system being checked. (Left or Right).
 - (b) Press the pedal. If it is still soft then the master cylinder needs servicing or replacing. If the pedal is hard the slave cylinder needs servicing or replacing.
 - (c) Remove the cylinder which has the defect and repair or install a new cylinder. Remove the air from the system as before and check.
3. If the brakes do not release correctly:
 - (a) Check that the push rod is not holding the piston in the master cylinder.
 - (b) Check to see if the piston has seized in.
 - (c) Disassemble the master cylinder and check the seals if (a) and (b) are correct. Check that all oil holes are free from restrictions.

BRAKE ADJUSTMENT: 1210 TRACTOR

1. Put wedges of wood in front of and behind each front wheel. This will prevent movement of the tractor. Release the handbrake.
2. Use a jack to raise one rear wheel clear of the ground. Put a support under the axle.
3. Release the locknut A Figure 139.
4. Use a $\frac{15}{16}$ AF spanner to tighten the adjuster bolt B until the wheel cannot be rotated by hand.
5. Release the adjuster until the wheel can be rotated easily by hand.
6. Repeat 2 to 5 on the other wheel.
7. Add brake fluid to the reservoir if necessary.




FIGURE 139. 1210 BRAKE ADJUSTMENT

A. Locknut B. Adjuster bolt

BRAKE ADJUSTMENT: 1410 TRACTOR

1. Put wedges of wood under the front and rear of the front wheels.
2. Use a jack to raise one rear wheel clear of the ground. Put a support under the main frame.
3. Release the handbrake and make sure the slave cylinder pistons are fully retracted.
4. Remove the access plug for the adjuster.
5. Turn the adjuster nut clockwise until the wheel cannot be turned by hand.
6. Loosen the adjuster nut $2\frac{1}{2}$ turns counter-clockwise.
7. Repeat the adjustment on the other wheel then lower the tractor to the ground.
8. Pull the handbrake lever up fully. The brakes must be fully engaged on the third ratchet of the handbrake. Adjust the cables at the compensator bar if adjustment is necessary. Keep the compensator bar level.
9. Check the amount of movement of each pedal. The amount must be the same for both pedals. Make small adjustments if necessary and install the access plugs for the adjusters.
10. Connect the pedals together with the link and test the brakes for equal efficiency.
11. If the brakes do not work equally check the balance valve as follows:
 - (a) Put a foot on each pedal.
 - (b) Push down on one pedal. The other pedal must raise.
 - (c) Push down on the other pedal and the opposite pedal must raise.
 - (d) If the pedals do not raise as above then the balance valve piston has seized.
 Install a new balance valve complete, parts are not available.




FIGURE 140. 1410 BRAKE ADJUSTMENT

A. Setting 25 mm (1 in) C. Adjuster nut
B. Access hole to adjuster D. Clevis pin

SPECIFICATION AND DATA

CAPACITIES

		Imperial	U.S.
Gearbox and axle: 1210, 1410	46.5 litre	10 $\frac{1}{4}$ gal	12.6 gal
Gearbox, transferbox and axle: 1210 4WD, 1410 4WD	49.0 litre	10 $\frac{3}{4}$ gal	12.9 gal
Final drive unit: 1210 (each)	2.3 litre	4 pt	2.4 qts
Final drive unit: 1210 4WD (each)	2.3 litre	4 pt	2.4 qts
Final drive unit: 1410 (each)	7.4 litre	13 pt	7.8 qts
Final drive unit: 1410 4WD (each)	13.6 litre	3 gal	3.6 gal

DIMENSIONS

Gearbox and Differential		
Muff coupling clearance	0.20-1.02 mm	0.008-0.040 in
Gearbox to frame clearance:		
Vertical	0.40-0.53 mm	0.016-0.021 in
Horizontal	0.20-0.30 mm	0.008-0.012 in
Topshaft bearing clearance	0.05-0.50 mm	0.002-0.020 in
Layshaft bearing clearance	0.05-0.10 mm	0.002-0.004 in
Pinion shaft bearing setting	-0.05 to +0.05 mm	-0.002 to +0.002 in
Auxiliary layshaft bearing clearance	0.25-1.27 mm	0.010-0.050 in
Differential bearing setting	0.00-0.05 mm	0.000-0.002 in
Spiral gear/Pinion tooth clearance	0.18-0.23 mm	0.007-0.009 in
Final Drive Unit		
Spur pinion shaft bearing preload	0.02-0.07 mm	0.001-0.003 in
Final drive shaft bearing preload	0.13-0.18 mm	0.005-0.007 in
Spur wheel clearance (14 series)	0.15-0.25 mm	0.006-0.010 in

TORQUE SETTINGS

	Nm	Kg m	lb ft
Bolts, gearbox to frame	163	16.5	120
Bolts, gearbox cover to frame	100	10.5	75
Bolts, gear lever housing to cover	12	1.3	9
Nut, pinion shaft	271	28.0	200
Nuts, gearbox casing	95	10.0	70
Bolt, topshaft rear bearing	11	1.1	8
Bolts, differential bearing caps	163	16.5	120
Bolts, differential cage	40	4.2	30
Bolts, axle case to frame	100	10.5	75
Bolts, final drives to axle case	100	10.5	75
Bolts, brake housing to final drive, (1410)	100	10.5	75
Ring nut, final drive shaft	100	10.5	75
Bolts, oil seal housing to final drive	68	7.0	50
Bolts, final drive cover	34	3.5	25
Drain plugs	80	8.4	60
Wheel nut, rear, 1410 $\frac{3}{4}$ in	203	19.5	150
Wheel nut, rear, 1210 $\frac{3}{4}$ in	154	15.7	114
Wheel nut, rear, 1210 $\frac{3}{4}$ in	190	19.2	140

GEAR RATIOS

GEAR	LEVER POSITIONS			GEARBOX RATIO
	HIGH/LOW	SLOW/NORMAL	1, 2, 3, R	
1	LOW	SLOW	1	11·132
2	LOW	SLOW	2	6·788
3	HIGH	SLOW	1	5·581
4	LOW	NORMAL	1	4·404
5	LOW	SLOW	3	3·932
6	HIGH	SLOW	2	3·403
7	LOW	NORMAL	2	2·685
8	HIGH	NORMAL	1	2·208
9	HIGH	SLOW	3	1·971
10	LOW	NORMAL	3	1·556
11	HIGH	NORMAL	2	1·345
12	HIGH	NORMAL	3	0·7798
REVERSE				
1	LOW	SLOW	R	6·789
2	HIGH	SLOW	R	3·348
3	LOW	NORMAL	R	2·642
4	HIGH	NORMAL	R	1·325

ABBREVIATIONS

Inch
Millimeter
Centimeter
Kilogramme meter
Newton meter
Pound foot
Pints } Imperial
Gallons }
Litres
U.S. quarts
4-wheel drive
Power take off

in }
mm } dimension
cm }
kg m }
Nm } torque
lb ft }
pt }
gal } volume
litre }
qt }
4WD
PTO

BRAKES**DISC BRAKES**

Type	Wet disc.
Brake operation	Independent pedals for each rear wheel. Mineral hydraulic oil or rod operation of brake units.
Brake fluid	Tellus 37 or Hyspin AWS 32
Number of rotating discs	6 each side
Friction area (total)	2683 cm ² 416 in ²

Rotating disc dimensions

Thickness (new)	4·9-4·75 mm	0·193-0·187 in
Variation of thickness	0·075 mm	0·003 in maximum
Variation of surface level	0·125 mm	0·005 in maximum
Radial groove depth (min)	0·125 mm	0·005 in

Stationary disc dimensions

Thickness (new)	2·7-2·6 mm	0·106-0·101 in
Variation of thickness	0·075 mm	0·003 in maximum
Variation of surface level	0·250 mm	0·008 in maximum

DRUM BRAKES

Width of drum	89 mm	3½ in
Inside diameter of new drum	216 mm	8½ in
Maximum diameter after grinding	217·52 mm	8·560 in

APPROVED LUBRICANTS

* First Recommendation † Second Recommendation


APPLICATION	AIR TEMP.	GRADE	B.P.	CASTROL	ESSO	MOBIL	SHELL	TOTAL
Transmission and Hydraulic System, with Single Pump also Tandem Pump from Serial No. 1210/1212-11152576 1210Q/1212Q-11152617 14 Series-11200752	Below 32°C (90°F)	* Multi-purpose 20W/30 † Multi-purpose 20W/40 † SAE80	* Tractor Oil Universal † Vanellus M 20-50 † Gear Oil 80	* Agricastrol Multi-use 20W/30 † Agricastrol MP † Agricastrol 30 † Castrol ST80 † Castrol CR30	* Esso Tractorlube Universal 20W/30 † Esso Unifarm † Essolube HD30	* Mobiloil Special 20W/40 † Mobilube C80 † Mobiloil 20W/50 † Delvac Oil 1230	* Rotella SX Oil 20W/40 † Dentax 80	* Total HD2-M 20W/40 † Total HD1-B 30
	Above 32°C (90°F)	* Multi-purpose 20W/30 † Multi-purpose 20W/40 † SAE90	* Tractor Oil Universal † Vanellus M 20-50 † Gear Oil 90	* Agricastrol Multi-use 20W/30 † Agricastrol MP † Agricastrol Gear Oil Light † Castrol ST90	* Esso Tractorlube Universal 20W/30 † Esso Unifarm † Esso Gear Oil ST90/140	* Mobiloil Special 20W/40 † Mobilube C90	* Rotella SX Oil 20W/40 † Dentax 90	* Total HD2-M 20W/40 † Total Transmission 90
Transmission and Hydraulic System with Tandem Pump to Serial No. 1210/1212-11152576 1210Q/1212Q-11152617 14 Series-11200752	All temperatures	Special Hydraulic Oil	* Tractran 9	* Agricastrol MD	* Esso Torque Fluid 56	* Mobil Fluid 423	* Donax TD	* Total Equivis JD
Final Drive Reductions, 12 series Tractors	Below -7°C (20°F)	* SAE90	* Gear Oil 90	* Castrol ST90 † Agricastrol Gear Oil Light	* Esso Gear Oil ST90/140	* Mobilube C90	* Dentax 90	* Total Transmission 90
	Above -7°C (20°F)	* SAE140	* Gear Oil 140	* Castrol D † Agricastrol Gear Oil Medium	* Esso Gear Oil ST90/140	* Mobilube C140	* Dentax 140	* Total Transmission 140
Final Drive/Brake Housing, 14 series Tractors	All temperatures	* Special Disc Brake Oil		* Agricastrol MP	* Esso Unifarm	* Mobiland Super Universal Tractor Oil	* Shell Universal Farm Oil or † Donax TT	* Super Universal Tractor Oil
Grease fittings	All temperatures		* Energrease Universal † Energrease L2	* LM Grease	* Beacon 2	* Mobilgrease Super † Mobilgrease MP	* Retinax A † Farmgrease Universal	* Total Multis

LUBRICATION

SYNCHROMESH TRANSMISSION

SPECIFICATION

9-37155
C109



UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Synchromesh Transmission, Section C11, Pub 9-37155

SYNCHROMESH TRANSMISSION

REMOVAL AND INSTALLATION

† 13. Put the sleeve for the differential lock on the special tool shown in Figure 13, splines away from handle.

Enter the sleeve on the tool into the right-hand side of the axle case. Stop when the selector groove of the sleeve is just behind the inner gusset of the case.

Do NOT let the end of the tool enter the spring or the selector fork cannot be engaged.

Align the selector fork with the groove of the sleeve then turn the tool clockwise.

14. Engage the differential lock and use a piece of wire to hold the pedal down, see Figure 49. Remove the tool.

15. Install two new seals in each seal housing at the ends of the axle case.

The lips of all seals must be toward the differential.

Put good quality grease between the seals.

Apply jointing compound to housings and install into axle case.

16. Check the brake linings for wear and damage and clean the inside of the brake drums.

1410 Tractors

17. Put the sleeve for the differential lock in position inside the axle case, splines toward the centre of the case.

Put the spring for the differential lock in the right-hand side of the differential.

18. Install the rear axle case as follows; see Figure 51A.

(a) Put a piece of flat metal through the axle case and compress the differential lock spring.

(b) Slide axle case into position and then remove the piece of metal.

(c) Install the axle case bolts and tighten to 100 Nm.

Engage the differential lock and use a piece of wire to hold the pedal down, see Figure 49.

19. Make sure the breather plugs are clear in the axle case flanges.

Install two new seals in each seal housing back to back.

Apply jointing compound to the housings and install into the axle case.

All Models

20. Clean the joint flanges of the axle case and final drive unit. Fit a new 'O' ring seal to the final drive flange on the 1410 tractors.

21. Install the final drive units. Tighten the bolts to 135 Nm.

22. Install the rear wheels.

23. Connect the brake rods and adjust the brakes.

24. Remove the supports from under the tractor and lower it to the ground. Remove the wedges between the frame and front axle.




FIGURE 52. DIFFERENTIAL LOCK 1210

- | | |
|----------------------|----------------------------------|
| A. Spur pinion shaft | D. Pedal |
| B. Sleeve | E. Return spring |
| C. Operating fork | F. End plate — differential cage |




FIGURE 53. AXLE CASE OIL SEALS

- | | |
|--------------|------------|
| A. Oil seals | B. Housing |
|--------------|------------|

NOTE: Seals must be fitted back to back on 1410 tractors.

UPDATED PAGE FOR YOUR SERVICE REPAIR MANUAL

Synchromesh Transmission, Section C11, Pub 9-37155

Pub 9-38199

REMOVAL AND INSTALLATION

INSTALLING THE GEARBOX

1. Install the shims on the auxiliary drive gear shaft.
2. Install a new oil seal in the rear end of the clutch driveshaft. Put a small amount of grease on the seal.
3. Install the gearbox into the frame.
4. Install the two bolts which fasten the gearbox to the frame but without the bushes.
5. Make sure that all four lugs of the end plates are flat on the frame.

If the lugs are not flat on the frame, loosen the four Nyloc nuts on the gearbox casing. Use a soft hammer to align the end plates as necessary.

Tighten the four nuts to 95 Nm when the lugs are flat on the frame.

6. Remove the two bolts which fasten the gearbox to the frame.

Install the two bushes and then the bolts, tighten to 135 Nm. Use a feeler gauge to check clearance between the bolt heads and the lugs of the case. This must be between 0.076 to 0.5 mm.

7. Move the muff coupling rearward on to the drive gear against the shims.

Install the circlip into the groove of the clutch driveshaft to hold the muff coupling in position.

8. Check the clearance between the circlip and the muff coupling. The clearance must be 0.020 to 1.02 mm.


Remove or add shims behind the muff coupling to get the correct clearance.

9. Use a hone or fine file to remove any sharp edges from the splines of the PTO drive shaft. Do this on the front edges and outer edges along the full length of each spline.

Apply a small amount of grease. Carefully push the shaft through the topshaft of the gearbox until fully forward.

NOTE: If the splines will not enter the clutch plate disengage the PTO clutch. Turn and push the shaft at the same time until fully forward into the flywheel.


10. Clean the faces of the rear frame and the axle case.
11. Put a new gasket on the axle case with compound which does not become hard.



R78 279

FIGURE 51. INSTALLING THE GEARBOX

- A. Checking muff coupling clearance
B. Checking bolt to casing clearance



† FIGURE 51A. INSTALLING THE 1410 AXLE CASE

- A. Spring B. Sleeve C. Metal lever

† 1210 Tractors

12. Install the axle case and tighten the bolts to 100 Nm.
Install the spring for the differential lock.

225 kg = 496 lb
95 Nm = 10 kg m = 70 lb ft
100 Nm = 10 kg m = 75 lb ft
135 Nm = 14 kg m = 100 lb ft
0.20 mm = 0.008 in
1.02 mm = 0.040 in
0.076 mm = 0.003 in
0.5 mm = 0.020 in

David Brown®

Service Repair Manual

**MODIFICATION OF AXLE CASE BEFORE
CONVERSION TO HIGH CLEARANCE**

990, 995 and 996 Tractors with Q-Cab

Section D1 (Pub. 9-37201) November 1978



David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.

Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual can give details of items which are not part of any specific tractor.

Written In *Clear
And
Simple
English*

Introduction:

Before you do the conversion, it is very important that new holes are made for the dowels. DO NOT install a reduction unit without dowels. A brake adaptor plate, K920431 or K920432 must be used as a guide for drilling the new dowel holes. The accuracy of these holes is very important as the dowels prevent any movement of the reduction case after it has been installed on the axle case. If dowels are not used, or wrongly installed, any damage that is caused can not be made good by the conditions of the warranty.

Special Dowels — Fig. 1

1. Make two dowels as shown from steel bar. After being machined, the dowels must be hardened.




FIGURE 1

- | | |
|---------------------------------------|---------------------|
| A. 11.08 to 11.06 mm | 0.4365 to 0.4355 in |
| B. 14.27 to 14.25 mm | 0.562 to 0.561 in |
| C. 12.7 mm | 0.5 in |
| D. 31.75 mm | 1.25 in |
| E. Make a sharp edge by undercutting. | |

Special Bushes — Fig. 2

Make two bushes of each size as shown from steel bar. After being machined, the bushes must be hardened.




FIGURE 2

- | | |
|---|---------------------|
| A. 43.45 mm | 1.75 in |
| B. 4.76 mm | 0.1875 in |
| C. 22.22 mm | 0.875 in |
| D. Make a sharp edge without undercutting | |
| E. 14.274 to 14.249 mm | 0.562 to 0.561 in |
| F. 9.52 mm | 0.375 in |
| Pilot Drill Bush | |
| G. 6.35 mm | 0.250 in |
| Reamer and Drill Bush | |
| G. 11.11 to 11.14 mm | 0.4375 to 0.4385 in |

Modification to Dowel Holes

1. Remove the oil from both reduction units.
2. Remove the reduction units, brake shoes, brake camshafts and fulcrum pins.
3. Remove the dowels from the axle case.
4. Install the special dowels in the dowel holes in the axle case.
5. Put the adaptor plate in position on the dowels. See Fig. 3.
6. Use clamps or bolts and nuts to hold the adaptor plate in position.
7. Put a mark on two opposite holes in the adaptor plate which are two holes, 72°, away from the dowels.
8. Put a pilot drill bush in both these holes and use a drill to make two 6.35 mm (1/4 in) holes through the axle case.
9. Replace the pilot drill bushes with the reamer and drill bush. Use a drill to make two holes 10.70 mm (27/64 in) through the axle case. Use a reamer to get a finished size of 11.11 mm (7/16 in).
10. Remove the reamer and drill bush.




FIGURE 3

A. Adaptor Plate

Breather, Breather Pipe and Drain Holes

1. Replace the hollow breather bolt with a standard setscrew Part No. K600502.




FIGURE 4. POSITION OF HOLES IN THE REDUCTION CASES

- A. Drill a hole 8.8 mm and tap 1/8 in B.S.P.
B. Drill two holes 5.2 mm and tap 1/4 U.N.C.

Put joint cement on the threads to prevent oil leakage. Use a type of cement that will not become hard.

IMPORTANT: When doing the next jobs, try to prevent metal chips getting into the reduction case. Put heavy grease on drills and taps before you use them.

2. Make new holes for the breather and breather pipe as shown in Fig. 4.
3. Clean the new breather and install as shown in Fig. 5.
Put a small amount of Loctite on the breather pipe and install the pipe in the breather.
Install the pipe clips.

NOTE: The end of the breather pipe must be inside the guard stiffener or on the inside face of the guard away from the wheel.




FIGURE 5. POSITION OF BREATHER

- A. Breather Bolt

4. Make a hole in the bottom of the reduction case as shown in Fig. 6.




FIGURE 6. POSITION OF DRAIN HOLES

X. Drill a hole 12.7 mm (1/2 in) diameter.

Assembling:

Before you install the reduction units in the new position, do the following:

1. Flush all foreign material out of the inner part of the reduction case.
2. Install the original dowels in the reduction, NOT the axle case.
You can then be sure that the dowels are engaged in both the axle case and the reduction unit.
3. Install the brake parts and the reduction units.
4. Add the correct amount of oil to each reduction unit.

D1

MODIFICATION OF AXLE CASE BEFORE
CONVERSION TO HIGH CLEARANCE

Introduction:

Before you do the conversion, it is very important that new holes are made for the dowels. DO NOT install a reduction unit without dowels. A brake adaptor plate, K920431 or K920432 must be used as a guide for drilling the new dowel holes. The accuracy of these holes is very important as the dowels prevent any movement of the reduction case after it has been installed on the axle case. If dowels are not used, or wrongly installed, any damage that is caused can not be made good by the conditions of the warranty.

Special Dowels — Fig. 1

1. Make two dowels as shown from steel bar. After being machined, the dowels must be hardened.

Special Bushes — Fig. 2

Make two bushes of each size as shown from steel bar. After being machined, the bushes must be hardened.




FIGURE 1

- | | |
|---------------------------------------|---------------------|
| A. 11.08 to 11.06 mm | 0.4365 to 0.4355 in |
| B. 14.27 to 14.25 mm | 0.562 to 0.561 in |
| C. 12.7 mm | 0.5 in |
| D. 31.75 mm | 1.25 in |
| E. Make a sharp edge by undercutting. | |




FIGURE 2

- | | |
|--|---------------------|
| A. 43.45 mm | 1.75 in |
| B. 4.76 mm | 0.1875 in |
| <i>Pilot Drill Bush</i> | |
| † C. 6.35 mm | 0.250 in |
| <i>Reamer and Drill Bush</i> | |
| † C. 11.11 to 11.14 mm | 0.4375 to 0.4385 in |
| † D. 22.22 mm | 0.875 in |
| E. 14.274 to 14.249 mm | 0.562 to 0.561 in |
| F. 9.52 mm | 0.375 in |
| † G. Make a sharp edge without undercutting. | |

Modification to Dowel Holes

1. Remove the oil from both reduction units.
2. Remove the reduction units, brake shoes, brake camshafts and fulcrum pins.
3. Remove the dowels from the axle case.
4. Install the special dowels in the dowel holes in the axle case.
5. Put the adaptor plate in position on the dowels. See Fig. 3.
6. Use clamps or bolts and nuts to hold the adaptor plate in position.
7. Put a mark on two opposite holes in the adaptor plate which are two holes, 72°, away from the dowels.
8. Put a pilot drill bush in both these holes and use a drill to make two 6.35 mm (1/4 in) holes through the axle case.
9. Replace the pilot drill bushes with the reamer and drill bush. Use a drill to make two holes 10.70 mm (27/64 in) through the axle case. Use a reamer to get a finished size of 11.11 mm (7/16 in).
10. Remove the reamer and drill bush.




FIGURE 3

A. Adaptor Plate

Breather, Breather Pipe and Drain Holes

1. Replace the hollow breather bolt with a standard setscrew Part No. K600502.




FIGURE 4. POSITION OF HOLES IN THE REDUCTION CASES

- A. Drill a hole 8.8 mm and tap 1/8 in B.S.P.
B. Drill two holes 5.2 mm and tap 1/4 U.N.C.

Put joint cement on the threads to prevent oil leakage. Use a type of cement that will not become hard.

IMPORTANT: When doing the next jobs, try to prevent metal chips getting into the reduction case. Put heavy grease on drills and taps before you use them.

2. Make new holes for the breather and breather pipe as shown in Fig. 4.
3. Clean the new breather and install as shown in Fig. 5.
Put a small amount of Loctite on the breather pipe and install the pipe in the breather.
Install the pipe clips.

NOTE: The end of the breather pipe must be inside the guard stiffener or on the inside face of the guard away from the wheel.




FIGURE 5. POSITION OF BREATHER

A. Breather Bolt



Service Repair Manual
AXLE LOADS
AND TYRE PRESSURES

Section D2 Pub. 9-37205 November 1978 Reprinted 1983

David Brown Tractors Ltd

Affiliate of J I Case

David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.

Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual can give details of items which are not part of any specific tractor.

Written In *Clear
And
Simple
English*

Introduction

Most tyre failures in agriculture are caused by too much distortion of the casing. The load on a tyre will bend the casing to a specific amount, but a traction tyre is also bent in a different direction by the force needed to move the tractor. If there is too much weight on a tyre or the pressure is not correct, the distortion of the casing will cause the plies to separate. This will cause early or sudden failure of the tyre which can result in injury or death.

A tyre which is kept at the correct pressure and load will have the following characteristics.

1. It will be safe.
2. Wear will be even and at the minimum rate.
3. It will have the best traction and flotation ability.
4. The rolling resistance will be kept to the minimum.

Tyre Pressures:

It is a recommendation that the same pressures are used for both cross ply and radial ply tyres. For road work these pressures must be increased to the maximum for the size of tyre to prevent rapid wear. This is especially important when radial ply tyres have been installed.

When the tyre pressures have been increased for road work, it is necessary to reduce the pressures before operating in field conditions.

IMPORTANT: Before tractors leave the factory, the tyre pressures are increased to approximately 200kPa (30 lb/in²). Before the tractor is used, the tyres must be checked and adjusted to the correct pressure for the operating conditions and axle loads.

How to Use the Tables:

1. See the list of tractor details shown in Table 1 to find the weight of each axle.

NOTE: Front ballast weights have a lever action using the centre of the rear axle as a fulcrum. For this reason the amount of weight added to a front axle is more than the weight of the ballast.

2. Make a note of the tyre sizes and ply rating (PR) of the tyres on the tractor.
3. Use Tables 2 and 3 to check the tyre size and ply rating with the safe working load.
Look at the top of the column selected for the pressure recommendations.

NOTE: To make reference easy, the safe working loads shown are the total capacities of both tyres.

4. See the notes at the bottom of each table for information on loads and speeds.

TABLE ONE

MODEL	FRONT AXLE						REAR AXLE							
	EXCLUDING CAB			INCLUDING CAB			EXCLUDING CAB				INCLUDING CAB			
	Load without Ballast	Load with U1362 or U1865 Ballasts	Load with U1848 or U4086 Ballasts	Load without Ballast	Load with U1362 or U1865 Ballasts	Load with U1848 or U4086 Ballasts	Load without Ballast	Load 2 weights per Wheel	Load with Water Ballast	Load with Water Ballast and 2 weights per Wheel	Load without Ballast	Load 2 weights per Wheel	Load with Water Ballast	Load with Water Ballast and 2 weights per Wheel
885N	585 kg 1290 lb	835 kg 1840 lb	*	*	*	*	1045 kg 2300 lb	1205 kg 2660 lb	1320 kg 2910 lb	1483 kg 3270 lb	*	*	*	*
885	630 kg 1390 lb	880 kg 1940 lb	*	710 kg 1560 lb	960 kg 2110 lb	*	1125 kg 2480 lb	1285 kg 2840 lb	1533 kg 3380 lb	1697 kg 3740 lb	1480 kg 3270 lb	1640 kg 3630 lb	1892 kg 4170 lb	2055 kg 4530 lb
990/5/6	790 kg 1750 lb	1040 kg 2300 lb	*	875 kg 1930 lb	1125 kg 2480 lb	*	1430 kg 3150 lb	1590 kg 3510 lb	1996 kg 4400 lb	2159 kg 4760 lb	1740 kg 3820 lb	1900 kg 4180 lb	2300 kg 5070 lb	2463 kg 5430 lb
996 4 WD	1100 kg 2425 lb	1350 kg 2975 lb	1680 kg 3695 lb	1185 kg 2610 lb	1435 kg 3160 lb	1765 kg 3880 lb	1495 kg 3300 lb	1655 kg 3660 lb	2064 kg 4550 lb	2227 kg 4910 lb	1865 kg 4110 lb	2025 kg 4470 lb	2431 kg 5360 lb	2595 kg 5720 lb
1210/12	1090 kg 2400 lb	1340 kg 2950 lb	1670 kg 3670 lb	1155 kg 2550 lb	1405 kg 3100 lb	1735 kg 3820 lb	1665 kg 3670 lb	1825 kg 4030 lb	2291 kg 5050 lb	2454 kg 5410 lb	1955 kg 4310 lb	2115 kg 4670 lb	2581 kg 5690 lb	2744 kg 6050 lb
1210 4 WD	1290 kg 2850 lb	1540 kg 3400 lb	1870 kg 4120 lb	1350 kg 2975 lb	1600 kg 3525 lb	1930 kg 4245 lb	1765 kg 3890 lb	1925 kg 4250 lb	2391 kg 5270 lb	2554 kg 5630 lb	2080 kg 4585 lb	2240 kg 4945 lb	2706 kg 5965 lb	2869 kg 6325 lb
1410/12	1135 kg 2500 lb	*	1715 kg 3770 lb	1165 kg 2575 lb	*	1745 kg 3845 lb	2040 kg 4500 lb	2200 kg 4860 lb	2667 kg 5880 lb	2831 kg 6240 lb	2290 kg 5045 lb	2450 kg 5405 lb	2914 kg 6425 lb	3078 kg 6785 lb
1410 4 WD	1305 kg 2880 lb	*	1885 kg 4150 lb	1380 kg 3050 lb	*	1960 kg 4320 lb	2065 kg 4550 lb	2225 kg 4910 lb	2690 kg 5930 lb	2853 kg 6290 lb	2360 kg 5200 lb	2520 kg 5560 lb	2895 kg 6580 lb	3148 kg 6940 lb

* Not used

The weights given for water ballast are for 75% fill using anti-freeze solution.

TABLE TWO – MAXIMUM SAFE WORKING LOADS FOR FRONT AXLES (NOT 4WD)

TYRE SIZE	PLY RATING	TYRE PRESSURE - bar, kg/cm ² (16 lb/in ²) Note: 1 bar = 100 kPa								
		1.4 (20)	1.7 (24)	1.9 (28)	2.2 (32)	2.5 (36)	2.8 (40)	3.0 (44)	3.3 (48)	3.5 (50)
5.50 - 16	6	616 kg 1360 lb	671 kg 1480 lb	734 kg 1620 lb	789 kg 1740 lb	852 kg 1880 lb	907 kg 2000 lb	1000 kg 2200 lb	1065 kg 2350 lb	—
6.00 - 16	6	689 kg 1520 lb	762 kg 1680 lb	834 kg 1840 lb	907 kg 2000 lb	970 kg 2140 lb	1060 kg 2340 lb	1135 kg 2500 lb	1215 kg 2680 lb	—
6.00 - 19	6	840 kg 1850 lb	910 kg 2020 lb	990 kg 2180 lb	1070 kg 2370 lb	1150 kg 2540 lb	1220 kg 2700 lb	1290 kg 2850 lb	1360 kg 3000 lb	—
7.50 - 16	6	1010 kg 2220 lb	1120 kg 2470 lb	1220 kg 2690 lb	1320 kg 2910 lb	1420 kg 3120 lb	1500 kg 3320 lb	—	—	—
	8	1010 kg 2220 lb	1120 kg 2470 lb	1220 kg 2690 lb	1320 kg 2910 lb	1420 kg 3120 lb	1500 kg 3320 lb	1590 kg 3510 lb	1700 kg 3750 lb	1770 kg 3900 lb
7.50 - 18	6	1080 kg 2380 lb	1200 kg 2660 lb	1320 kg 2900 lb	1420 kg 3140 lb	1520 kg 3360 lb	1620 kg 3580 lb	—	—	—
	8	1080 kg 2380 lb	1120 kg 2660 lb	1320 kg 2900 lb	1420 kg 3140 lb	1520 kg 3360 lb	1620 kg 3580 lb	1700 kg 3750 lb	1770 kg 3900 lb	1840 kg 4050 lb
11L - 15	6	1420 kg 3140 lb	1560 kg 3480 lb	1730 kg 3820 lb	—	—	—	—	—	—
	8	1420 kg 3140 lb	1560 kg 3480 lb	1730 kg 3820 lb	1870 kg 4120 lb	2000 kg 4420 lb	2130 kg 4700 lb	—	—	—
10 - 16	8	1580 kg 3500 lb	1770 kg 3900 lb	1935 kg 4260 lb	2090 kg 4620 lb	2240 kg 4940 lb	2380 kg 5260 lb	—	—	—

NOTE:

1. FOR SPEEDS UNDER 8 km/h (5 mile/h) IT IS PERMITTED TO INCREASE LOADS BY 100 %*
2. FOR SPEEDS BETWEEN 8 & 20 km/h (5 & 12 mile/h) IT IS PERMITTED TO INCREASE LOADS BY 35%

* Must only be used when travelling intermittent distances of less than 100 metres with full load. For example: front loading.


TABLE THREE - MAXIMUM SAFE WORKING LOADS FOR DRIVE AXLES INCLUDING 4WD

TYRE SIZE	PLY RATING	TYRE PRESSURE - bar, kg/cm ² (lb/in ²) Note: 1 bar = 100 kPa							
		0.8 (12)	1.0 (14)	1.1 (16)	1.2 (18)	1.4 (20)	1.7 (24)	1.9 (28)	2.8 (40)
9 - 24	8	1100 kg 2430 lb	1210 kg 2660 lb	1300 kg 2870 lb	1390 kg 3070 lb	1480 kg 3270 lb	1660 kg 3650 lb	1810 kg 3980 lb	2220 kg 4910 lb
10 - 24	6	1340 kg 2950 lb	1460 kg 3220 lb	1570 kg 3470 lb	1690 kg 3720 lb	1800 kg 3970 lb	2000 kg 4420 lb	—	—
11.2/10-28	6	1430 kg 3150 lb	1560 kg 3440 lb	1690 kg 3720 lb	1810 kg 3980 lb	1920 kg 4240 lb	2130 kg 4700 lb	—	—
12.4/11-28	6	1720 kg 3780 lb	1880 kg 4140 lb	2020 kg 4460 lb	2160 kg 4770 lb	2310 kg 5100 lb	2550 kg 5620 lb	—	—
12.4/11-32	6	1820 kg 4000 lb	2000 kg 4400 lb	2150 kg 4740 lb	2310 kg 5080 lb	2450 kg 5400 lb	2720 kg 6000 lb	—	—
13.6/12-28	6	—	2200 kg 4860 lb	2380 kg 5240 lb	2560 kg 5640 lb	2720 kg 6000 lb	—	—	—
14.9/13-28	6	—	2600 kg 5740 lb	2800 kg 6200 lb	3010 kg 6640 lb	3160 kg 6960 lb	—	—	—
12.4/11-36	6	1920 kg 4240 lb	2100 kg 4640 lb	2280 kg 5020 lb	2436 kg 5370 lb	2590 kg 5720 lb	2890 kg 6360 lb	—	—
16.9/14-30	6	—	3290 kg 7260 lb	3560 kg 7840 lb	3810 kg 8400 lb	—	—	—	—
13.6/12-36	6	—	2480 kg 5460 lb	2680 kg 5900 lb	2880 kg 6350 lb	3050 kg 6730 lb	—	—	—
12.4/11-38	6	1980 kg 4370 lb	2170 kg 4780 lb	2340 kg 5160 lb	2510 kg 5540 lb	2680 kg 5900 lb	2960 kg 6520 lb	—	—
13.6/12-38	6	—	2550 kg 5620 lb	2760 kg 6080 lb	2960 kg 6520 lb	3150 kg 6940 lb	—	—	—
18.4/15-30	6	—	3900 kg 8600 lb	4220 kg 9300 lb	—	—	—	—	—
16.9/14-34	6	—	—	3780 kg 8340 lb	4050 kg 8920 lb	—	—	—	—
	8	—	—	3780 kg 8340 lb	4050 kg 8920 lb	4290 kg 9440 lb	4760 kg 10500 lb	—	—
18.4/15-34	6	—	—	4490 kg 9900 lb	—	—	—	—	—

NOTE:

1. For operating speeds up to 8 km/h (5 mile/h) it is permitted to increase loads by 40%* on 9-24 and 10-24 tyres ONLY with an increase in pressure of 25%.
2. For speeds between 8 & 20 km/h (5 & 12 mile/h) it is permitted to increase loads by 20% on all tyres.
3. For speeds between 20 & 25 km/h (12 & 15 mile/h) it is permitted to increase loads by 7% on all tyres.

* Must only be used when moving short distances of less than 100 metres with full load. For example: front loading.



Service Repair Manual

STEERING AND FRONT AXLE

Section E2 (Pub. 9-37195) April 1978

This publication is an update of 9-37194,
with amendments on pages E36 and E37



DANGER — Hydraulic equipment can be dangerous.



FOR YOUR SAFETY

Before commencing work on the machine ensure all pressure has been released from the system.

Do not disconnect or work on any part of the system whilst the engine is running.

Never check for oil leaks with the hands and do not approach very close to a pipe, or component, suspected of leaking.

The most dangerous type of oil leak is a leak so small as to be almost invisible. A very fine jet of oil under a pressure far less than is used in hydrostatic power steering systems can penetrate the skin even through clothing, and cause PERMANENT tissue damage.

An oil injection through the skin is relatively painless and may not be noticed at the time. It may later become painful however, and give the impression of a cut which has become infected. If this occurs obtain medical attention immediately. The damaged tissues must be removed without delay otherwise the affected area will spread and major surgery may be required to prevent it becoming fatal.

Painful burns can be caused by only a small amount of hot oil coming into contact with the skin.

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

CONTENTS

SECTION	DETAILS	PAGE
Manual Steering		
Unit Removal and Replacement		
	Drop Arm	E3
	Drop Arm Shaft	E4
	Front Axle	E2
	Front Hubs	E1
	Steering Box	E3
	Steering Column	E4
	Stub Axles	E1
Unit Maintenance and Repair		
	Ball Peg Setting	E5
	Drag Link Length	E7
	Drop Arm Shaft Bearings	E9
	Front Hub Bearings	E7
	Front Wheel Alignment	E7
	Steering Column	E10
	Steering Column Bearing	E11
	Steering Stops	E8
	Stub Axle Bushes	E7
	Thrust Washers and Seals	E8
	Trunnion Pin Bushes	E8
Hydrostatic Power Steering		
	Fault Finding	E16
	How It Works	E13
Unit Removal and Replacement		
	Front Axle	E17
	Front Hubs	E17
	Hydraulic Ram	E21
	Orbitrol Valve	E19
	Pump	E20
	Reservoir	E20
	Steering Column	E18
	Stub Axles	E17
Unit Maintenance and Repair		
	Filter Element	E29
	Front Wheel Alignment	E24
	General Maintenance	E23
	Hydraulic Ram	E32
	Hydraulic Ram - Centralising	E24
	Orbitrol Valve	E30
	Pump	E26
	Ram Ball Joints	E33
	Steering Column Bearing	E25
	Track Rod Joints	E24
	Venting the System	E23
Specification and Data		E36
Summary of Design Changes		E37

NEW FORMAT

This new Steering and Front Axle section of the Service and Repair Manual is presented in a new style. This provides a step by step guide to the fitter for each operation, employing more use of illustrations which are, wherever practicable, directly related to the accompanying text by numerical annotations.

Each operation is titled with the component description and sub-titled according to the operation to be performed, Removal, Dismantling, Replacement etc., followed by the relevant illustration figure number. Each item number of the operation is directly allied to the appropriate component number in the illustration.


Example

Front Hub

Removal - Fig 1

1. Raise front of tractor and place suitable supports beneath axle beam extensions.
2. Remove front wheel, centre cover, gasket and split pin.
3. Remove stub axle nut and washer, withdraw hub from stub axle and remove outer bearing.
4. Prise oil seal from hub and remove inner bearing, discard oil seal.
5. Remove sleeve and dirt excluder.

Fig. 1



This method affects page layout only and the established sequence of operations is unchanged ("How it Works", "Unit Removal and Replacement", "Unit Maintenance and Repair" etc).

Although new to David Brown Publications, this form of presentation is in use by other manufacturers in both the automotive and agricultural machinery industries. We have studied these and have, we feel, been able to improve on them and pass on the benefits to the user of the David Brown Service Repair Manual.

This section covers 885, 990 synchromesh, 995, 996, 1210, 1210 4WD Mk II, 1212, 1410 and 1412 tractors from first manufacture. Section E1 (Pub. 9-37191) should be retained for use relative to earlier Selectamatic tractors.

Instructional Drawings

The latest set of instructional drawings covers Front axle and steering. At the time of going to press two drawings are available: 9-38541 - Front Axle and Transfer Box : 1210 4WD Mk II tractor (two drawings).

STEERING AND FRONT AXLE

8, 9 and 12 series tractors are fitted with manually operated, light recirculating, ball type steering. The steering levers being directly coupled by gears and linkage to the steering column.

Hydrostatic power steering is an optional fitting on these tractors and is a standard fitting on the 1212 model, 14 series and all Q-cab tractors.

UNIT REMOVAL AND REPLACEMENT MANUALLY STEERED TRACTORS

Front Hub Removal — Fig. E1

1. Raise front of tractor and place supports beneath axle beam extensions.
2. Remove front wheel, brake drums (if fitted), centre cover, gasket and split pin.
3. Remove stub axle nut (right-hand thread) and washer, withdraw hub from stub axle and remove outer bearing.
4. Prise out oil seal from hub and remove inner bearing, discard oil seal.
5. Remove sleeve and dirt excluder.

Replacement — Fig. E2

6. Refit inner bearing and press in new oil seal using a flat plate to ensure even fitment.
- NOTE:** Seal lip should face outwards unless front wheel brakes are fitted when lip should face inwards.
7. Pack inside of hub with grease and position hub on stub axle; ensure oil seal slides onto seal collar then replace outer bearing.
 8. Refit flat washer and nut; tighten nut whilst rotating hub so that bearings are fully seated. Slacken nut one flat and fit split pin.
 9. Fit new gasket and replace hub cover, pump grease through fitting until grease escapes past oil seal.
 10. Refit front wheel and lower tractor to ground.

Stub Axle Removal — Fig. E3


The stub axles pivot in steel backed bushes in the beam extensions and are retained in place by the steering levers.

1. Raise front of tractor and place supports beneath axle beam extensions.
2. Remove front wheel, steering lever bolt and washer.
3. Refit steering lever bolt without washer until finger tight, unscrew two full turns, then with a solid support under beam extension, strike the bolt a sharp blow squarely on the head. This will release the steering lever from the stub axle taper.
4. Remove bolt, steering lever and stub axle.
5. Note positions of and remove thrust washer and bearing, remove and discard 'O' rings.

Replacement


6. Clean stub axle and fit new 'O' ring.
7. Smear bearing and thrust washer with grease and fit to stub axle.

Fig. E1




R761

Fig. E2



R762

Fig. E3



R763

REMOVAL AND REPLACEMENT

8. Smear inside of stub axle bushes with oil and fit new 'O' ring.
9. Fit stub axle into beam and replace steering lever; ensure lever is fitted to correct splines and special washer is fitted to bolt.
10. Tighten bolt to 16.6 kg m (120 lb ft) then lubricate with SAE140 through fitting on front of beam extension.
11. Refit front wheel and lower tractor to ground.

Front Axle

Fabricated axles are a standard fitting on all tractors, but heavy duty forged axles were an optional fitting on 990 and 995 model tractors.

Removal — Fig. E4

1. Disconnect steering drag link and turn rearwards clear of work area.
2. Raise front of tractor and remove front wheels.
3. Place suitable supports under main frame, positioned as far forward as possible but clear of front axle.
4. Cut locking wire; unscrew trunnion pin locking bolt five full turns. Tap bolt head to push screwed sleeve clear of the trunnion pin then remove bolt.
5. Pierce welch plug and lever out of front extension.
6. With weight of tractor resting on supports and the jack supporting only the weight of the axle, pull trunnion forward clear of extension. There is a $\frac{1}{8}$ in UNC tapped hole in centre, front end of the trunnion pin to enable a slide hammer with an adaptor to be used for withdrawing the pin.
7. Lower axle to the ground ensuring jack is positioned so that axle does not tilt rearwards.

NOTE: Trunnion pins fitted to early model tractors were fitted from the rear of the main frame extension. To remove the front axle on these tractors it is necessary to remove the front extension from the main frame.


Replacement

8. Fit new 'O' rings on outside of thrust washers, then smear washers with grease and place in axle beam recess.

NOTE: Different thickness washers are available for tractors fitted with heavy duty front axles. The washers used should be of a size to require the two beams to be levered together in order to fit the front washer, giving a pre-load of 1.52 mm (0.060 in).

9. Place axle on jack and raise towards extension. Take care not to damage 'O' rings or displace thrust washers when entering beam into extension. Ensure beam remains level and when it is raised high enough, push a bar into extension to align holes.
10. Fit new 'O' ring on trunnion pin, smear pin with grease and push into extension.
11. Turn pin so that chamfered end of bolt hole is towards top then tap into position taking care not to damage extraction hole thread.
12. Replace locking bolt, fit screwed sleeve to bolt, then tighten bolt and lock with wire.
13. Fit new welch plug, grease trunnion pin bearings and refit front wheels; lower tractor to the ground.

Fig. E4



Steering Box


A recirculating ball type steering box is fitted to all models. The box case is bolted to the gearbox cover and is lubricated by an oil bath formed in the cover casting.

Removal — Fig. E5

CAUTION: Do not commence steering box removal by removing the four bolts from the base of the steering column and turning the steering wheel. This will turn the screw out of the nut and allow the steel balls to drop into the oil bath.

1. Remove bonnet top and drain oil from steering box 1210 model.
2. Remove instrument panel complete with fuel tank - 1210 model.
3. Disconnect throttle control and remove hand throttle lever - 9 series.
4. Remove bonnet then remove two rear bolts securing fuel tank support brackets to clutch housing - 8 and 9 series.
5. Raise instrument panel allowing tank to pivot on front bolts, then refit rear bolts under brackets to hold rear of tank clear of steering box bolts - 8 and 9 series.
6. Disconnect steering drag link from drop-arm.
7. Remove bolts securing steering box to gearbox cover.
8. Remove steering box complete with column and wheel; retrieve two ring dowels fitted between box and cover.

Fig. E5



Replacement

9. Remove all trace of old gasket and thoroughly clean gearbox cover face.
10. Top up oil bath to a maximum of 25 mm (1 in) below cover face - 8 and 9 series.
11. Fit new gasket; locate box and secure to gearbox cover, tighten bolts to 4.0 kg m (30 lb ft).
12. Fill steering box with oil to the level of the filler plug - 1210 models.
13. Lubricate drop-arm shaft and column bearings through grease fittings.
14. Refit steering drag link to drop-arm.

Steering Drop-Arm 8 and 9 Series

Removal

The drop-arm is fitted on parallel splines and is retained by a clamp bolt.

1. Disconnect steering drag link from drop-arm.
2. Remove clamp bolt; note marking to ensure correct refitting and slide arm off shaft splines.

Replacement

3. Ensure that dust seal is in position then fit drop-arm shaft ensuring marks line up (Fig. E5).
4. Refit clamp bolt and tighten to 4.0 kg m (30 lb ft).

Steering Drop-Arm - 1210 Model

Removal

The drop-arm is fitted on taper splines and is retained by a washer and bolt in the centre of the shaft.

1. Disconnect steering drag link from drop-arm.
2. Remove retaining bolt and washer; refit bolt without washer, tighten bolt then unscrew two full turns. Note marking to ensure correct refitting.
3. Use a two jaw extractor to grip the arm and tighten the jacking screw against retaining bolt head until arm is pulled free.

Replacement

4. Ensure that seal is in position then fit drop-arm on shaft ensuring marks line up.
5. Refit washer and retaining bolt and tighten to 16.6 kg m (120 lb ft).

REMOVAL AND REPLACEMENT

Drop-Arm Shaft - 8 and 9 Series

Removal — Fig. E6

The drop-arm shaft is retained by a large split pin through the rocker arm.


1. Lever out welch plug and remove rocker arm pin.
2. Tap shaft (from welch plug side) with a hammer and drift and remove shaft complete with drop-arm; remove rocker arm.

Replacement

Renew shaft if worn or twisted; a twisted shaft will allow the rocker arm to foul the case and may cause damage.

3. Smear inside of bushes with grease and wipe shaft clean.
4. Place rocker arm in steering box housing - positioned with split pin hole on opposite side of case to drop-arm.
5. If drop-arm is on shaft, ensure rubber shaft seals are in position.
6. Align split pin holes, push shaft into rocker arm and fit split pin.
7. Fit a new welch plug and apply a few shots of lubricant through grease fittings.

Fig. E.6



Drop-Arm Shaft - 1210 Model

Removal — Fig. E7

1. Remove steering drop-arm.
2. Remove four securing screws, shaft cover, thrust plate and shims.
3. Remove two rocker arm clamping screws then tap drop-arm end of the shaft, turning rocker arm frequently so that end bush will be pushed evenly out of casting by rocker arm key. Do not remove shaft by using a drift against thrust plate end.


NOTE: The rocker arm key will not pass through the drop arm side of the steering box housing.

Replacement

Renew shaft if worn or twisted; a twisted shaft will allow the rocker arm to foul the case and may cause damage.

4. Smear inside of bushes with grease and wipe shaft clean.
5. Fit shaft key and place rocker arm in steering box housing - positioned so that clamping screws can be fitted after shaft has been replaced. Tighten clamping screws to 4.0 kg m (30 lb ft).
6. Fit new 'O' ring into end of shaft then replace bush, thrust washer, shims and cover.
7. Ensure sufficient shims have been fitted to position rocker arm centrally under column aperture.
8. Fit cover bolts and tighten to 2.75 kg m (20 lb ft).
9. Refit steering drop-arm.

Fig. E7



Steering Column

Removal

1. Remove steering box.
2. Lay box on bench and remove four bolts from ball pegs.
3. Remove ball pegs and retrieve shims, then remove four bolts from steering column flange.

4. Remove column from box and secure nut to screw with adhesive tape - to prevent the column nut being turned to the end of the screw and releasing the balls.

Replacement

5. Insert column shaft into steering box and position column nut so that transfer tube is on the opposite side to the drop-arm shaft.
6. Set column in correct position i.e. 8 and 9 series - with throttle lever bracket towards drop-arm side. 1210 model - with tank mounting bracket towards front of tractor.
7. Fit the four flange bolts and tighten to 6.9 kg m (50 lb ft).


Setting Ball Pegs — Fig. E8

1. Align steering nut and rocker arm peg locations.
2. Fit one peg with the original thickness of shims and fully tighten the screws.
3. Fit other peg without shims and tighten the screws until peg just commences to hold steering nut. Measure distance between peg flange and rocker arm face. Subtract 0.05 mm (0.002 in) from reading obtained and select shims to make up this thickness.

Example: If reading is 0.018 in then shim thickness required is 0.018 in minus 0.002 : Equals 0.016 in. This will give the required peg setting of 0.02 to 0.08 mm (0.001 to 0.003 in) preload.

4. Remove peg and fit shims of required thickness.
5. Fully tighten all screws then check that steering nut is central in rocker arm. If not, transfer shims from one side to the other.
6. When steering nut is central, firmly tighten the four screws then lock with a tabwasher or by centre punching according to type being serviced.

Fig. E8



R/89

UNIT MAINTENANCE AND REPAIR MANUALLY STEERED TRACTORS


Front Wheel Alignment — Fig. E9

The front wheels should be set so that they have 1.6 to 3.2 mm (0.062 to 0.125 in) toe-in when in the straight ahead position. This setting is determined by the length of the track rod, and if the track rod is disturbed, or if incorrect wheel alignment is suspected, the setting should be checked as follows.

1. Measure distance between wheel rims at points level with the wheel centres and parallel to the centre line of the front axle (A). The distance between the front of the rims should be 1.6 to 3.2 mm (0.062 to 0.125 in) less than the distance between the rear of the rims (B). If incorrect; adjust track rod length as follows:-
2. Release one lock nut and remove the track rod clamp bolt.
3. Turn the track rod so that the ball joint is screwed in or out as required.
4. Refit clamp bolt, tighten locknut then recheck wheel alignment.

As the track setting holes in the track rod are drilled the same distance apart as the holes in the beam extension, wheel alignment is not altered when the wheel track is changed. If the wheel alignment is correct at one track setting, it will remain correct at all track settings.

Fig. E9



Drag Link Length

Setting

To obtain full steering lock in each direction and at all track settings, the drag link should be set so that the distance between the centre of each ball joint is as follows:-

885	-	116.84 cm (46.000 in)
990	}	118.27 cm (46.562 in)
995		
996	-	129.06 cm (49.687 in)
1210	-	133.35 cm (52.500 in)

Front Hub Bearings — Fig. E10

1. Remove front hub.
2. Remove both bearing inner tracks, clean inside of hub and examine bearings. If surfaces of rollers or bearing tracks are pitted or worn, bearing should be renewed.
3. Drive outer track from hub then press in track supplied with the new bearing - thinnest edge of track towards outside of hub - until firmly in hub recess.

NOTE: It is not necessary to renew both bearings if one is serviceable, but it is essential that the complete bearing is renewed.


4. Refit front hub.

Stub Axle Bushes

Two stub axle bushes are pressed into each beam extension and these should be renewed if worn.

1. Remove stub axle.
2. Drive bushes out with a suitable drift, taking care not to damage bush locations.

Fig. E10



3. Clean all components and remove any burrs from axle bores.
4. Press new bushes into position using a mandrel and holder made to the following dimensions. If a mandrel is used the bushes will not be damaged during fitting and reaming will not be necessary.

Mandrels — Fig. E11

Mandrel No.	A	B
1	28.45mm (1.120in)	25.77mm (0.995in)
2	34.80mm (1.370in)	31.52mm (1.245in)
3	37.97mm (1.495in)	34.80mm (1.370in)
4	41.15mm (1.60in)	37.97mm (1.495in)
5	47.50mm (1.870in)	44.22mm (1.745in)

Holder — Fig. E12

- A. Mild steel bar 25mm (1.0in)
- B. 30.5cm (12.0in)
- C. $\frac{1}{2}$ in UNC x $\frac{1}{2}$ in (19.50mm)
- D. Stud $\frac{1}{2}$ in UNC x 1. $\frac{1}{2}$ in (38mm)

Thrust Washers and Seals

990 and 995 models fitted with heavy duty front axles are fitted with roller thrust bearings. These bearings are fitted with a steel washer at each side and as two different types of bearing are supplied, ensure that correct washers are used. Thrust washers fitted to other tractors do not require steel backing washers. Always fit new bearings, washers and sealing rings when fitting new bushes.

Heavy Duty Front Axle Bearings and Washers — Fig. E13

- A - Bearing 620180 (INA AXK 4565).
- B - Thrust washers 626692. 1mm (0.39in).
- C - Bearing 620184 (Torrington NTA 284).
- D - Thrust washers 626859. 1.5mm (0.060in).

Steering Stops — Fig. E14

Front wheel movement is limited by means of stops on the beam extensions. If the stops become worn remove the extension and build the stops up to the original shape with welding. If the steering box reaches the end of its travel before the stub axles touch the stops a heavy impact against the front wheels may damage the steering box casting.

Trunnion Pin Bushes — Fig. E15

The bushes may be driven out with a suitable sized mandrel, but where the bushes are in a blind hole they must be collapsed by driving a small round nose chisel down the side of the split and then extracted with pliers.

Fig. E11




Fig. E12




Fig. E13




Fig. E14





Fig. E15



Drop-Arm Shaft Bearings

885 model tractors are fitted with two bushes in the steering box case and these should be removed by pushing both bushes inwards with Service Tool 901724. Use large end of mandrel for drop-arm side bush and small end for other side (see Fig. E20).

9 Series tractors are fitted with three bushes and these can also be pushed out with Service Tool 901724 (Fig. E16). Slide mandrel into case and fit the horseshoe-recess towards large end of mandrel. Press both inner bushes out then remove horseshoe and withdraw mandrel. Replace horseshoe on mandrel then press outer bush through centre bush location so that it will not fall out when mandrel is withdrawn.

1210 Model tractors are fitted with two bushes and a needle roller bearing inside the drop-arm end of case (Fig. E21). The bearing can be levered out with the oil seal, but as the bearing will be damaged during removal do not remove unless it has to be renewed. The two bushes can be pressed inwards using mandrel No. 4 (page E8).

NOTE: If Service Tool 901724 is not available the centre bush can be removed by making a collar (Fig. E18) to the following dimensions and using this collar with mandrel No. 1 (page E8).

A-34.9mm (1.375in)	B-25.4mm (1.000in)
C-31.7mm (1.250in)	D-6.35mm (0.250in)
E-3.17mm (0.125in)	


Fit new bushes in reverse order of removal. Ensure case bores are free from burrs and scratches, smear outside of bush with oil and use correct diameter mandrel so that it will not be necessary to ream the bushes after fitting.

On 8 and 9 Series tractors use Service Tool 901724 to press the bushes into position, ensuring that holes through bushes are opposite grease fitting holes in case.

On 1210 Model tractors use mandrel No. 4 to press centre bush into case and use mandrel of the following dimensions to fit new roller bearing (Fig. E19).


A-36.83mm (1.450in)	B-47.50mm (1.870in)
C-54.0mm (2.125in)	D-31.7mm (1.250in)
E-7.94mm (0.312in)	F-12.7mm (0.500in)

Fig. E16




R/6 16

Fig. E17




R/6 17

Fig. E18




R/6 18

Fig. E19




R/6 20

Fig. E20



Steering Box - 885, 990, 995, 996
A - Cross shaft B - Bush C - Rocker arm
D - Ball peg E - Nut F - Shaft
G - Column

Fig. E21




Steering Box - 1210
A - Cross shaft B - Roller bearing
C - Bearing bush D - Thrust plate
E - Shims F - Rocker arm
G - Ball peg H - Nut J - Shaft K - Column

Steering Column

Dismantling — Fig. E22

1. Remove steering column.
2. Remove domed nut and washer.
3. Remove steering wheel using three jawed extractor fitted beneath the wheel boss. Do not remove wheel with hammer.
4. Remove key from shaft and remove dirt excluder, locknut and adjustable bearing cone, discard 'O' ring.
5. Invert column over a suitable container to catch the steel balls, and withdraw screwed shaft out of column.
6. Remove lower bearing cone, spherical seating and rubber baffle from shaft.
7. Remove two bolts securing guide tube to column nut, then unscrew nut from shaft catching the steel balls as they are released.

Fig. E22



Re-assembly

3. Fit rubber baffle, spherical seating and lower bearing cone in position on shaft.
9. Slide shaft into column and fit twelve steel balls, smeared with grease, and fit adjustable bearing cone with new 'O' ring, to hold steel balls in position, secure with locknut but do not tighten fully.
10. Assemble column nut. Smear steel balls with grease and fit them into the groove. Partly screw the shaft into the nut and continue fitting balls until groove is full.
11. Screw nut fully onto shaft, fit remaining balls in transfer tube and fit transfer tube to column nut.
12. Refit steering column.
13. Adjust steering column bearing.

Steering Column Bearing

Adjustment

1. Screw down adjustable bearing cone until all play is taken up but without pre-loading the bearing.
2. Back off cone $\frac{1}{4}$ th turn to give 0 to 0.76mm (0 to 0.003in) end float with shaft central in tube.
3. Hold cone in this position and tighten locknut to 16.6 kg m (120 lb ft). The locknut has a recess on one side which **must be fitted against cone**.
4. Fit dust excluder and shaft key then refit steering wheel and secure with washer and nut. Do not overtighten the wheel nut, a torque of 2.76 kg m (20 lb ft) is sufficient.

HYDROSTATIC POWER STEERING

HOW IT WORKS

Hydrostatic steering consists of an oil reservoir, hydraulic pump, servo valve (orbitrol unit), steering column and double-acting hydraulic ram. The oil pump is engine driven and therefore, is in operation whenever the engine is running.

The Orbitrol unit is attached to the base of the steering column, connected directly to the steering wheel.

The hydraulic ram is mounted as follows:-

8 and 9 series: Mounted on the left-hand side, attached to the left-hand steering lever.

12 series: Mounted on the left-hand side, attached to the left-hand steering lever.

In some territories these tractors are fitted with 14 series (transverse) steering rams.

1210 4WD Mk II: Mounted transversely behind the front axle at the left-hand side attached to the left-hand steering lever.


14 series: Mounted transversely behind the front axle connected to the stub axles by track rods.

The front wheels are therefore, steered hydraulically, there being no mechanical connection between the steering wheel and front axle.

The pump draws oil from the reservoir and circulates it to the Orbitrol valve. When the steering wheel is stationary the valve directs oil to the reservoir and closes both connections to the hydraulic ram. The pump then only circulates oil at a low pressure, and the ram is hydraulically locked to hold the front wheels in a fixed position. When the steering wheel is moved the Orbitrol valve directs oil to the appropriate side of the ram, and connects the other side of the ram to the reservoir. A rapid build up of pressure then occurs and a pre-determined volume of oil is pumped into the ram to turn the wheels a fixed amount. As the volume of oil passed through the valve is dependant on the amount of steering wheel movement, the front wheels move in direct response to the steering wheel in exactly the same manner as they would if they were connected by mechanical linkage, but all the steering effort is supplied by the pump, the effort at the steering wheel being only sufficient to turn the Orbitrol valve. If for any reason the pump fails to deliver oil pressure the tractor can be steered manually. If this occurs, turning the steering wheel will not only direct oil into the ram cylinder but the metering unit in the Orbitrol valve will act as a pump, so that the front wheels will be steered in the same way as they are when power operated, but the effort required to steer the wheels must be applied through the steering wheel.


Steering Column: The steering column consists of an outer tube and an inner shaft with a bearing at the top next to the steering wheel. The bearing supports the shaft and on non-Q cab tractors can be adjusted to eliminate end float or loading of the shaft. The shaft has splines at the lower end which locate in the Orbitrol valve splines.

Fig. E23-885




1176 192

Fig. E24-9 and 12 series



1176 40

Fig. E25-12 and 14 series



1176 84

Orbitrol Valve: The Orbitrol valve consists of two units; a rotary valve and a metering valve. The rotary valve consists of an inner sleeve which is connected to the steering column, and an outer sleeve connected to the metering unit. The outer sleeve is free to rotate in the valve body and is connected to the metering unit by a pin which passes through the clearance holes in the inner-sleeve. The two sleeves can therefore, revolve together, but relative movement between the sleeves is limited by the diameter of the clearance holes in the inner-sleeve, and resisted by centering springs which hold the inner-sleeve so that the outer-sleeve pin is in the centre of the clearance holes. When the steering wheel is stationary the centering springs hold the inner-sleeve in a neutral position so that the ports in both sleeves line up to close both ram connections and divert pump output to the reservoir. When the steering wheel is turned, the inner-sleeve overcomes the tension of the centering springs and turns so that the sleeve ports are changed to direct pump output to one side of the ram via the metering unit, and the other side of the ram is connected to the reservoir.

The metering unit consists of an outer stator which has seven lobes, and a rotor which has six lobes. The stationary stator is bolted on the end of the valve body but the inner rotor is free to rotate inside the stator, and is connected to the outer sleeve pin by means of a short shaft. As the rotor has less lobes than the stator it cannot fit centrally in the stator, but must always be disposed off centre so that as it rolls inside the stator it will follow a circular path, and the spaces between the inner and outer lobes will increase and decrease. If oil is fed into the spaces on one side of the rotor it will be pushed round and operate as a hydraulic motor. When the steering wheel is turned the inner sleeve is turned, but initially the outer sleeve remains stationary so that the sleeve ports are lined up to direct pump output to one side of the rotor, and the other side of the rotor is connected to one side of the hydraulic ram. Pump pressure then rises until it is sufficient to turn the rotor and push oil from the outlet side of the rotor into the ram cylinder. As the rotor follows a circular path inside the stator it will also turn - one lobe for each revolution - and in doing so, turn the outer sleeve and change the sleeve ports to shut off the pump output to the rotor and direct it to the reservoir.

Movement of the rotor, and therefore, the volume of oil fed to the hydraulic ram, is entirely dependant on the amount of steering wheel movement. The further the wheel is turned, the further the rotor must revolve to restore the outer sleeve to its neutral position. The front wheels are therefore, turned to exactly follow the

Fig. E26




Fig. E27




Fig. E26. Orbitrol Valve

- | | |
|---------------------|-----------------|
| A. Column spline | E. Inner sleeve |
| B. Centering spring | F. Shaft |
| C. Drive pin | G. Rotor |
| D. Outer sleeve | H. Stator |
| J. Pipe connections | |

Fig. E27. Oil Flow Through Servo Valve

- | | |
|------------------------|-------------------|
| A. Valve unit | D. Feed from pump |
| B. Metering unit | E. Ram connection |
| C. Return to reservoir | F. Ram connection |

movement of the steering wheel, but the only effort required to turn the steering wheel is the small effort required to overcome the centering spring tension and displace the two sleeves.

If, for any reason, the pump fails to deliver oil, turning the steering wheel will displace the two sleeves but the rotor, and therefore, the outer sleeve, will not turn. As the relative movement between the two sleeves is limited to eight degrees in either direction, by the diameter of the clearance holes in the inner sleeve, turning the steering wheel more than eight degrees with the pump in-operative will cause the inner sleeve to turn the rotor, via the outer sleeve peg and connecting shaft. When this occurs the operation of the rotor will be changed from that of a motor to a pump. The ball valve in the body will be lifted off its seat so that oil can be drawn into one side of the rotor and then pumped in the normal way to the hydraulic ram. Under these conditions the steering ratio is the same as when operating under power, but the actual effort required to steer the tractor must be applied to the steering wheel.

Hydraulic Pump: The twin rotor pump incorporates pressure balanced bearings. The rotor being supported in bushes which not only provide bearings for the rotor shafts but also seal the rotor side faces against oil leakage. Most of the leakage which takes place in rotor type pumps is through the clearance between the rotor side faces and the shaft bearings. The bearings are therefore, pressure loaded by feeding oil from the outlet side of the pump into the annular space between the bearings and the pump body. These spaces are sealed by 'O' rings, and as the area under pressure in the space is slightly greater than the area under pressure between the rotors, the pressure in the spaces will press the bearings against the rotors. The bearings are therefore, held in close contact with the rotors at all output pressures, and leakage past the rotor side faces reduced to a minimum.


To prevent the system being subjected to excessive oil pressure should the steering wheel be held hard into full steering lock, the pump incorporates a relief valve which allows oil to return direct to the pump reservoir when the pressure reaches 70 kg cm² (1000 lb in²). Return oil from the Orbitrol valve is fed to the centre of the reservoir cover, where it passes through a paper element filter before being returned to the reservoir.

Hydraulic Ram: 8, 9 and 12 series tractors are fitted with a double-acting ram of unequal displacement which is mounted on the left-hand side of the tractor attached to the left-hand steering lever. As the volume of oil required to fully extend the ram is greater than the volume required to fully retract it, due to the presence of the ram rod in the front end of the cylinder, the number of steering wheel turns into full left-hand steering lock will be greater than those to the right. This does not affect the steering in any way and is not noticeable when driving the tractor.

NOTE: In some territories 12 series tractors are fitted with 14 series (transverse) steering rams.

14 series and some 12 series tractors are fitted with an equal displacement double-acting ram mounted transversely behind the front axle. The ram rod and piston are

Fig. E28



Oil Flow Through Pump

A. Pressure relief valve
C. Oil outlet
E. Oil return

B. Vent valve
D. Oil reservoir
F. Filter element

rigidly mounted and the ram cylinder moves when oil is pumped into the cylinder via the hollow rods. The cylinder swivels in a yoke which has two equal length track rods connecting the ram to the steering levers. The cylinder is protected by a heavy sump plate which is integral with the front axle.

The 1210 4WD Mk II tractor is fitted with an unequal displacement double-acting ram mounted transversely behind the front axle at the left-hand side. It is connected at one end to the left-hand steering lever, and pivots on the axle casing at the other. The cylinder is mounted rigidly at its pivot and the ram piston is moved when oil is pumped into the cylinder.

HYDROSTATIC POWER STEERING

FAULT FINDING

Faulty operation may be experienced if dirt is allowed to enter the system, or if units receive damage due to neglect or abuse. If incorrect operation is experienced, the following checks will enable the fault to be located as quickly as possible.

Heavy Steering: Ensure mechanical faults such as seized King pins or steering joints are not the cause, then check pump pressure. If pump pressure is incorrect check Orbitrol valve and hydraulic ram.

Delayed Steering Action: If front wheels do not steer immediately the wheel is turned more than 2° , this could indicate the presence of air in the system which should be vented.

Erratic Steering Action: Check for mechanical binding, then vent the system. If Orbitrol valve has been disturbed, check for correct assembly of rotor.

Wheels Steer in Wrong Direction: Check ram pipes for correct fitting, i.e. reverse fitting at ram end or Orbitrol then vent the system. If Orbitrol valve has been disturbed, check for correct assembly of rotor.

Steering Wheel Operates as a Motor: This is caused by the Orbitrol valve outer sleeve being unable to centre due

to dirt jamming the sleeve. Check also for broken centering springs.

Steering Wheel Creep: When the wheels reach full steering lock the steering wheel also reaches the end of its travel. It will not however, lock solid, as a slight leakage occurs inside the Orbitrol valve and allows the steering wheel to creep. A small amount of creep is therefore normal, but should not exceed 4 rev/min when a torque of 1.6 kg m (12 lb ft) is applied. Creep in excess of this indicates excessive leakage in the Orbitrol valve.

Steering Wander: If wheels do not remain in a set position with the steering wheel stationary, check ram piston seals, if satisfactory check Orbitrol valve for excessive internal leakage.

Complete Loss of Steering: First check the oil level in the reservoir then vent the system. If still not satisfactory or if difficulty is experienced raising sufficient pressure to vent the system, blank off the two ram cylinder pipes and check the amount of slip in the Orbitrol valve.

Steering Rattle: With engine running and an assistant turning the steering wheel half-a-turn in each direction alternately, check for play in ball joints and track rods. Check steering lever bolts and ram anchor bracket bolts for tightness.

HYDROSTATIC POWER STEERED TRACTORS

Front Hubs

Removal and Replacement

Removal and replacement of front hubs is the same as for manually steered tractors. See publication 9-37172 for 1210 4WD Mk II tractors.

Stub Axes

Removal and Replacement

Removal and replacement of stub axes is the same as for manually steered tractors.

Front Axle - Side Mounted Rams

Removal and Replacement

Removal and replacement of front axle is the same as for manually steered tractors, except for the hydraulic steering ram which has to be disconnected at the left-hand steering lever.

Front Axle - Transverse Rams

Removal - Figs E29 and E30

1. Disconnect steering pipes at rear of axle using a suitable container beneath pipe ends.
2. Raise tractor with jack beneath axle and remove front wheels.
3. Place supports under main frame, positioned as far forward as possible but clear of front axle.
4. Cut locking wire, then unscrew trunnion pin locking bolt five full turns. Tap bolt head to push the screwed sleeve clear of trunnion pin, then remove bolt.
5. Pierce weich plug and lever out of front extension.
6. With weight of tractor resting on supports and a jack supporting only the weight of the axle, pull trunnion pin forward, clear of front extension. Front end of trunnion pin has a $\frac{1}{8}$ in UNC tapped hole in the centre to enable a slide hammer with adaptor to be used for withdrawing pin.
7. Lower axle to ground ensuring jack is placed so that axle does not tilt rearwards.

Replacement

8. Fit new 'O' rings on outside of thrust washers, then smear washers with grease and place in axle beam recess.
9. Place axle on jack and raise towards extension. Take care not to damage 'O' rings or displace thrust washers when entering beam into extension. Ensure beam remains level and when it is raised high enough, push a bar into extension to align holes.
10. Fit 'O' ring on trunnion pin, smear pin with grease and push into extension.
11. Turn pin so that chamfered end of bolt hole is towards top then tap pin into position taking care not to damage extraction hole thread.
12. Replace locking bolt, fit screwed sleeve to bolt, then tighten bolt and lock with wire.
13. Reconnect steering pipes, fit new weich plug, then vent the steering system.
14. Grease trunnion pin bearings and refit front wheels.

Fig. E29





Fig. E30



REMOVAL AND REPLACEMENT

Front Axle - 1210 4WD Mk II

Removal and Replacement

Removal and replacement of front axle is the same as for conventional 12 series tractors except for the driveshaft which has to be disconnected at the differential housing flange.

Steering Column - 'Q' Cab Tractors

Removal - Fig. E31


1. Disconnect battery.
2. Carefully note position of steering hoses and disconnect from steering ram and pump pipes.
3. Remove steering wheel and four screws securing instrument panel to console. Lift instrument panel clear of console and disconnect engine speed indicator cable, fuel gauge lamp lead and wiring harness at the three multi-pin connectors; remove instrument panel.
4. Remove six bolts and washers securing console cover plate, lift plate clear of console then remove connector block assembly from plate; remove cover plate after releasing grommet and cables.
5. Restrain weight of steering column, then remove four bolts and washers securing column to console wall; lower column to rest on transmission casing.
6. Remove the four column mounting bushes (these are secured by grommet type rubber inserts).
7. Turn column a quarter-turn to the left and lift clear of console.

Replacement

8. Tie a 122 cm (48 in) length of cord to each pair of steering hoses.
9. Lower steering column assembly into console using cords to guide and pull steering hoses into correct positions. When column assembly is resting on transmission housing, turn assembly to the right so that Orbitrol valve is facing towards front of tractor.
10. Dismantle each column mounting assembly by pressing the rubber insert complete with inner bush from the outer bush, and then pressing the inner bush from the rubber insert.
11. Refit column mounting assemblies to console wall in the following manner: Fit rubber insert to hole in console wall, lightly oil internal bore of outer sleeve and push over rubber insert. Lightly oil outside of inner bush, and push into rubber insert.
12. Reverse operations 1 to 5.
13. Vent the steering system.


NOTE: If removing the steering column with the cab raised, the steering hoses can be disconnected at the Orbitrol valve and the column lifted out as described above. It is essential that the steering hoses are reconnected to the correct ports, so extreme care should be taken to identify them when disconnecting.

Fig. E31



11/70 Mk II

Fig. E32



11/70 Mk II

Steering Column - Not 'Q' Cab Tractors

Fig. E33

Removal — Fig. E33 (showing 885)

1. Carefully note positions of, and disconnect four pipes from Orbitrol valve using a suitable container beneath pipe ends.
2. Remove bolts and washers securing column unit support bracket to gearbox cover.
3. On 12 and 14 series tractors, remove fuel tank mounting bolts and bolt securing fuel tank to steering column. Raise rear of fuel tank.
4. On 9 series tractors, the hand throttle lever passes through the instrument panel and it is necessary to remove the lever from the lower end of the hand lever spindle, then unscrew the nylon nut at the top of the spindle, so that the hand lever can be withdrawn through the instrument panel.
5. Disconnect throttle linkage - 885.
6. Remove complete column assembly and support bracket.

Replacement

7. Reverse operations 1 to 6.
8. Vent the steering system.


Orbitrol Valve

Removal

1. Remove steering column.
2. If still fitted, carefully note positions of, and disconnect steering hoses from Orbitrol valve.
3. Remove four bolts securing Orbitrol valve, and remove valve from column.

Replacement

4. Reverse operations 1 to 3.



H76 468

REMOVAL AND REPLACEMENT

Hydraulic Pump - Not 885

Removal - Fig. E34

1. Clean outside of pump and reservoir, then slacken union nut at tank end of fuel-feed pipe; this prevents siphoning when pipe is disconnected from fuel feed pump.
2. Disconnect pipes from fuel feed pump and remove securing bolts.
3. Slacken alternator mounting bolts and remove alternator drive belt.
4. Disconnect alternator adjuster strap and swing alternator upwards; tighten mounting bolts to hold alternator in this position.
5. Disconnect feed and return pipes from steering pump then remove the two securing bolts; the upper bolt requires a shortened $\frac{1}{2}$ in AF spanner.
6. Carefully withdraw pump rearwards until clear of timing gear, remove and discard gasket.

Replacement

7. Thoroughly clean carrier plate and fit new gasket to pump.
8. Refit pump to engine and replace securing bolts. Ensure pump fits flat up to carrier plate then tighten bolts evenly.
9. Reverse operations 1 to 5.
10. Fill reservoir with new, clean oil then vent system. Check for oil or fuel leaks then top up reservoir.

Hydraulic Pump - 885

Removal - Fig. E35

1. Place a suitable container beneath pump and disconnect pump inlet and by-pass hoses, and union nut at outlet pipe.
2. Slacken two bolts securing pump bracket to tractor main frame and slide pump downwards to slacken drive belt.
3. Remove drive belt and bolts securing pump bracket to main frame then remove pump and bracket assembly.
4. Reverse operations 1 to 3.
5. If pump has been stripped or a replacement pump has been fitted, clean out reservoir, flush pipes with clean oil and fit new filter element.
6. Fill reservoir with new, clean oil then vent system. Check for oil leaks then top up reservoir.

Hydraulic Pump Reservoir - 385


Removal - Fig. E36

1. Place a suitable container beneath reservoir and disconnect pump inlet and by-pass hoses at the reservoir.
2. Remove three screws securing reservoir to bracket.
3. Remove reservoir assembly.

Replacement


4. Reverse operations 1 to 3.
5. Fill reservoir with new, clean oil then vent system. Check for oil leaks then top up reservoir.

Fig. E34




11/70 1/2

Fig. E35



11/70 1/2

Fig. E36



11/70 1/2

Hydraulic Steering Ram - Transverse

Fig. E37

Removal — Fig. E37

1. Remove Front axle.
2. Disconnect track rods from steering levers and remove circlips from ram rod connectors.
3. Remove pipes then unscrew connectors from ends of ram rod.
4. Remove split pin, nut and bolt securing pivot beam to axle then lift out the ram and yoke assembly, retrieve distance pieces from each end of ram rod.
5. Remove four screws securing ball pegs.
6. Lever ball pegs from yoke retrieving shims from beneath each peg; separate ram from yoke.

Replacement

7. Thoroughly soak felt ball peg seals in clean engine oil.
8. Refit lower ball peg (with grease fitting), seal and shim, then fit upper ball peg, seal and shim.
9. Check that screws lightly grip the cylinder when fully tightened. If tight, remove shim beneath upper ball peg.
10. Locate ram and yoke assembly on axle, ensuring distance pieces are fitted at each end of ram rod; these are selectively assembled to obtain 0.13 mm (0.005 in) clearance to 0.02 mm (0.001 in) preload before connectors are tightened.
11. Refit pivot beam bolt and two washers then tighten nut to give zero end float to 0.1 mm (0.004 in) preload. Fit split pin.
12. Reverse operations 1 to 3.
13. Centralise steering ram and set wheel alignment.
14. Fill reservoir with clean, new oil and vent the system. Check for oil leaks then top up reservoir.




Fig. E38




Fig. E39


Hydraulic Steering Ram - Side Mounted

Removal — Figs. E38 and E39

1. Place a suitable container beneath ram then disconnect both pipes.
2. Disconnect both ball joints by first slackening the locknut at the front joint and then turning the ram rod until it is screwed out of the joint. The complete ram can then be turned to unscrew the rear joint.

Replacement

3. Reverse operations 1 and 2.
4. Fill reservoir with clean, new oil and vent the system. Check for oil leaks then top up reservoir.



REMOVAL AND REPLACEMENT

Hydraulic Steering Ram - 1210 Mk II 4WD


Fig. E40

Removal -- Fig. E40

1. Place a suitable container beneath ram then disconnect both pipes.
2. Remove split pin and nut securing ram cylinder to axle assembly.
3. Remove split pin and nut securing ram rod to left-hand steering lever.
4. Remove steering ram from axle.

Replacement

5. Reverse operations 1 to 4.
6. Fill reservoir with clean, new oil and vent the system. Check for oil leaks then top up reservoir.



General Maintenance

The pump and valve components operate with very small clearances, it is essential that great care is taken to ensure that dirt and other foreign matter is prevented from entering the system. Whenever the pump or Orbitrol valve is serviced or replaced the reservoir must be cleaned, the filter (if servicing) renewed, and the system flushed with clean, new steering oil.

THE ONLY OIL RECOMMENDED FOR USE IN THE HYDROSTATIC STEERING SYSTEM IS SHELL TELLUS 27.

When carrying out tractor maintenance include the following items:-

1. Lubricate king pins, hubs, steering column (not Q cab tractors), ram yoke (if fitted) and trunnion pin. The yoke and front trunnion pin grease fittings are accessible from underneath the axle. The rear trunnion pin grease fitting has an extension pipe into the front extension.

NOTE: To ensure effective lubrication of the ram yoke (transverse rams), it is essential that SAE 140 oil and not grease is used. Pump oil slowly into lubrication point until a small quantity of oil is expelled from the overflow valve.

2. Check the level of oil in the reservoir. This should be to within 10mm ($\frac{3}{8}$ in) of filler rim on 885 tractors, and to the level of the filler hole on all others. Top up with the recommended grade of oil if not to the correct level.

Inspect pipes and connections for oil leakage which should be rectified immediately. Do not use the tractor if there is any sign of leakage: The steering will not operate if the oil level falls so low that the pump draws air.

Renew filter element after first 500 hours (6 months) of operation and then every 1000 hours or 12 months, whichever occurs first, examine track rod joints and renew if play is apparent.

Venting the System - Side Mounted Rams and 1210, Mk II 4WD

1. Top up reservoir with correct grade of oil to within 10 mm ($\frac{3}{8}$ in) of filler rim on 885 tractors and to level of filler hole on all others. Replace filler cap.
2. Raise front of tractor so that wheels are clear of the ground.
3. 885 only: With fuel cut-off control in the Stop position, use the starter to turn the engine over for 10 - 15 seconds (to prime the pump) then check the reservoir level.
4. All tractors: Start engine and run at idling speed. Turn steering wheel one full turn in each direction several times but do not allow the front wheels to reach full steering lock.
5. Check reservoir oil level, then with engine running at idling speed, turn the steering wheel so that full steering lock is reached several times in each direction. Do not hold the wheels against the steering stops for more than a few seconds at a time.
6. Lower front wheels to the ground, check oil level then drive tractor at slow speed in a figure-of-eight to check steering action. Steering should operate smoothly and without hesitation.

Venting the System - Transverse Rams

1. Top up reservoir with correct grade of oil to level of filler hole.
2. Raise front of tractor so that wheels are clear of the ground, then start engine and run at idling speed.
3. Open vent valve in left-hand side of steering cylinder one full turn, then turn steering wheel to right and allow front wheels to reach full right-hand steering lock. Close left-hand valve then open right-hand valve one full turn and turn steering wheel to left. Allow front wheels to reach full left-hand steering lock then close valve.
4. Turn steering wheel from lock-to-lock several times to check correct operation, then stop engine, lower front wheels to ground and check oil level.

Track Rod Joints - Transverse Rams

The track rod ball joints are fitted into taper holes in the steering levers and yoke. It is essential to rigidly support the lever or yoke before attempting to remove the joint. This should be done with a sharp blow from a soft faced hammer.

When replacing the track rod inner joints, clean the threads then smear them with Loctite (Grade 270) before screwing joint in, until centre of joint is 33.34 mm (1.5/16 in) from end of track rod tube. The joints should not then be disturbed; adjustments being made at the outer joints which are secured with locknuts.

Front Wheel Alignment - Side Mounted Rams and 1210 Mk II 4WD


Front wheel alignment is the same as for manually steered tractors.

Front Wheel Alignment - Transverse Rams - Fig. E41

Front wheels should have 3.2 mm (0.125 in) toe-in when in the straight ahead position. This setting is determined by the length of the track rod and should be checked by measuring the distance between the wheel rims at points level with the wheel centres and parallel to centre line of the front axle. Adjust wheel alignment as follows:

1. Remove both track rod clamp bolts.
 2. Slacken both ball joint locknuts.
 3. Screw both track rods an equal number of turns in, or out as required.
- NOTE: If track rods are not turned equally the ram cylinder will not remain central.
4. Re-fit both clamp bolts and tighten ball joint locknuts.

Fig. E41



Hydraulic Ram Cylinder

Centralising - Fig. E41

If the track rods are disturbed the ram cylinder should be centralised as follows:

1. Remove track rod clamp bolts from both sides and release both ball joint lock nuts. Raise front wheels clear of the ground.
2. Turn steering wheel to left until steering ram reaches end of its travel.
3. Swing right-hand wheel into full left-hand steering lock, and with wheel held against its stop and ram at its full right-hand stroke, screw track rod in, or out of ball joint until bolt hole in tube is opposite the correct hole in track rod; do not fit clamp bolt at this stage.

4. Turn steering wheel to right until steering ram reaches end of its travel, then swing left-hand wheel into full right-hand lock and set length of left-hand rod as described above.
5. Fit both track rod clamp bolts, turn wheels into straight ahead position and measure wheel alignment. Set the wheels to 3.2 mm (0.125 in) toe-in when measured at wheel rims, by removing both clamp bolts and screwing both track rods an equal number of turns in, or out of the ball joints. If both track rods are not adjusted equally, the ram will not remain central and full steering lock may not be obtainable.
6. When wheel alignment is correct, fully tighten clamp bolts and ball joint lock nuts.

Steering Column Bearing - Not Q Cab Tractors

Adjustment:

Preloading the column bearing will cause heavy operation of hydrostatic steering. The play should be maintained between 0 and 0.076 mm (0 and 0.003 in).

1. Screw down the adjustable cone bearing until it just contacts the balls, then unscrew $\frac{1}{4}$ th of a turn.
2. Hold in this position and tighten locknut to 16.6 kg m (120 lb ft).

NOTE: The locknut has a recess on one side which must be fitted against the bearing cone, no tab-washer is required.

Steering Column Bearing - Q Cab Tractors

Adjustment:

No adjustment is required for this bearing except that the steering wheel nut should be tightened as far as possible whilst steering wheel is held.

Steering Column Bearing - Not Q Cab Tractors


Dismantling: Fig. E42

1. Remove steering column and Orbitrol valve.
2. Remove domed nut and washer then withdraw steering wheel using a three-jawed extractor.
3. Remove dirt excluder and locknut.
4. With shaft vertical (to prevent balls falling into tube) unscrew bearing cone and carefully pull shaft upwards to push balls out of tube. Do not pull shaft too far out of tube as this will displace the oil baffle.

Re-assembly:

5. Smear steel balls with grease and fit them into tube groove.
6. Screw bearing cone on to shaft until it contacts balls then fit locknut, recessed side of nut against cone.
7. Adjust bearing free play.
8. Fit dirt excluder and replace steering wheel. Secure with flat washer and domed nut and tighten to 2.76 kg m (20 lb ft).
9. Lubricate bearing through grease fitting.

Fig. E42



Steering Column Bearing - Q Cab Tractors

Dismantling: Fig. E43

1. Remove steering column and Orbitrol valve.
2. Remove felt washer and spacer.
3. Remove circlip, then using a soft faced hammer gently tap splined end of shaft until bearing is clear of tube.
4. Withdraw bearing using a suitable extractor.

Re-assembly:

5. Reverse operations 1 to 4.

Hydraulic Steering Pump - 885

Dismantling: Figs. E44, E45 and E46

1. Thoroughly clean outside of pump and scribe marks on the pump cover, body and flange, or bracket to assist re-assembly.
2. Clamp pump body in a vice and withdraw pulley; this is on a parallel shaft and not very tight, remove key.
3. Remove four screws securing bearing retainer and bracket to pump body. Remove bearing (if necessary) and oil seal.
4. Lay pump, drive end downwards on bench, and remove six screws securing cover to body.
5. Withdraw cover vertically ensuring rollers do not fall out. The carrier is not tight on the shaft and should remain in the body, but if withdrawn with cover, remove it from the shaft and extract key.
6. Turn body over; and allow carrier and rollers to fall out, then remove cam ring and locking peg. Remove shaft by gently tapping forwards out of body with a soft faced hammer.
7. Wash all parts in paraffin and place in clean container. Handle components with care and ensure no foreign matter is allowed to enter pump during assembly.

Inspection:

8. Examine pump body and cover for signs of wear, renew either if faces or bushes are worn.
9. Inspect cam, carrier and rollers for wear or scoring, paying particular attention to roller ends. These components can not be replaced individually, a new assembly being required if cam, carrier, or any of the rollers are worn.
10. Fit cam locking peg in hole on body pocket and fit cam. Ensure cam seats on pocket face and that slot in cam locates on locking peg.
11. Fit carrier in cam ring, carrier must be fitted so that larger angle 'a' is toward direction of rotation; replace rollers (Fig. E44).
12. Place a straight-edge across the body face and check end clearance of carrier and rollers (Fig. E45). If end clearance exceeds 0.05 mm (0.002 in), a new cam, carrier and roller assembly is required.
13. Examine shaft and bearing. If bearing shows signs of roughness, or if excessive grease has seeped out, it should be renewed.
14. Unscrew flow control valve cap and remove valve spool and spring from body.
15. Check flow control valve spring. This should have a tension of 3.5 to 4.0 kg (8 to 9 lbs) when compressed to a length of 20.3 mm (0.82 in). Renew spring if outside these limits.

Fig. E43





Fig. E44



Re-assembly:

16. Press new oil seal into pump body; ensuring that seal lip is not damaged and is facing towards inside of body.
17. Fit new bearing (if required) to shaft, smear inside of oil seal with grease and insert shaft and bearing into pump body, ensuring there are no sharp edges on shaft which could cut oil seal.
18. Fit cam locking peg in hole on body pocket and fit cam. Ensure cam seats on pocket face and that slot in cam locates on locking peg.
19. Fit carrier in cam ring, carrier must be fitted as described in operation 11, replace rollers.
20. Fit carrier key in shaft keyway and fit new 'O' rings in cover face.
21. Smear shaft with clean oil then insert it into carrier ensuring that key is not dislodged and 'O' rings not displaced.
22. When body and cover faces are together, secure with six screws and tighten by diagonal selection to 2.5 kg m (18 lb ft).
23. Refit support bracket and bearing retainer and secure with four screws.
24. Replace pulley drive key then replace pulley, secure with retaining bolt and tighten to 2.7 kg m (20 lb ft).

If pump is not to be fitted to a tractor immediately, seal ports with adhesive tape to prevent ingress of foreign matter during storage.

Hobourn Eaton Roller Pump - 885 only

- | | |
|---------------|------------------------|
| A. Driveshaft | F. Carrier |
| B. Bearing | G. Body |
| C. Oilseal | H. Control valve spool |
| D. Roller | J. Outlet connection |
| E. Cam | K. Inlet connection |

Fig. E45





Fig. E46



Flow Control Valve - 885

Dismantling: Fig. E47

1. Unscrew valve cap and withdraw valve spool and spring from pump body.
2. If faulty relief valve operation is suspected, fit a new spool assembly, ensuring that the valve in the new spool is set to the correct pressure.
3. If spool is not quite free in body bore, carefully lap in with metal polish then thoroughly clean body and valve to remove all trace of polish.


NOTE: Do not attempt to dismantle spool valve, the pressure relief valve inside the spool is non-adjustable and should not be disturbed.

4. Check operation of valve spring.

Replacement:

5. Place spring and valve spool in pump body bore and replace valve cap.

Fig. E47



- | | |
|------------------------|--------------------------|
| A. Valve cap | D. Valve spool |
| B. Spring (relief) | E. Spring (flow control) |
| C. Ball (relief valve) | F. Outlet connection |

Hydraulic Steering Pump - Not 885

Dismantling — Figs. E48, E49 and E50

1. Remove pump.
2. Release bolt in centre of reservoir cover, remove cover and element; hold pump over a suitable container when removing cover as the reservoir contents will be released.
3. Release tab washer then remove shaft nut.
4. Remove drive gear from shaft taper using a suitable extractor. Do not attempt to remove gear by hammering shaft end as this may cause rotor teeth to damage the faces of the soft alloy bearings.
5. Remove key from drive shaft and remove four body bolts.
6. Carefully separate mounting flange, and cover from pump body. If body dowels are tight, lightly tap cover with a soft faced hammer.
7. Withdraw rotors and bearings from pump body. Carefully note position of bearings and lightly mark the top of each bearing to enable them to be re-assembled in their original positions.
8. Remove circlip from mounting flange, place flange downwards on suitable supports and tap seal out with a hammer and drift.
9. Remove relief valve plug and spring, carefully noting number of shims fitted under spring. Invert cover and tap it gently on a piece of wood to extract relief valve plunger.

Inspection

10. Thoroughly clean all parts in paraffin and place on a clean bench. Inspect pump body for external damage or cracks and the rotor bores for wear. It is normal for rotors to cut a light track on the inlet side of body, and, if track is not excessively scored, or does not exceed 0.10 mm (0.004 in) at its deepest point, the body is serviceable, and only requires any burrs on edge of gear track to be removed with a very fine abrasive cloth lubricated with paraffin. The body must then be thoroughly flushed clean. If maximum depth of tracks is more than 0.10 mm (0.004 in), pump should be scrapped as a new body, rotors and bearings are required.
11. Examine each bearing for wear in the bores and on the face. Pay particular attention to the condition of lubricating scrolls and the portion of the bearing face between the bores. This portion is known as the seal bridge, any score marks or damage across the bridge can cause high leakage losses. If bearings are worn or scored on the face they may be renewed, but new bearings must not be fitted if body is worn as this would lift the rotors away from the inlet side of the pump body allowing excessive oil leakage between the tips of the rotor teeth and the body.
12. Inspect rotors for worn or scored side faces and journals, and for damage or surface cracks on the teeth. Check also that the thread is not damaged or the keyway worn. Slight wear or scoring of journals can be erased by polishing between lathe centres using 'O' grade emery paper lubricated with paraffin. If bearings are being renewed because of side face scoring, side faces of rotor can be polished by sandwiching a piece of 'O' grade emery paper between the rotor face, and the unworn side of the discarded bearing. As rotors must be selected so that

Fig. E48





Fig. E49



A. Seal bridge
B. Relieved radius
C. Plain face

D. Oil inlet
E. Recess on rotor side
F. Lubrication scrolls

teeth widths are equal within 0.005 mm (0.002 in), and the journal diameters equal within 0.013 mm (0.005 in), rotors must not be renewed singly, but always in a matched pair.

13. Measure the overall length of the rotor and bearing assembly and compare this with the length of the pump body. If the difference is not within 0.20 mm (0.008 in), the bearing 'O' rings will be unable to maintain pump balancing pressure and the pump may not be able to reach the full output pressure, Fig. E50.

Re-assembly

Carry out all operations on a clean work bench and ensure that all components are clean and dry. Handle components with care as any burrs or bruise marks on machined surfaces will render them unserviceable.

14. Refit relief valve plunger, shims, spring, bonded seal and cap.
15. Place pump flange with machined face downwards on a clean, flat surface. Apply a small amount of grease to the oil seal then press seal in position. Do not fit seal with a hammer and punch, use a 28.8 mm (1.0937 in) diameter tool; replace circlip.
16. Fit new sealing rings into mounting flange and pump cover recesses. Place pump cover over dowels on pump body ensuring that point of sealing ring is toward inlet port on body.
17. Place pump body on bench, cover downwards and inlet port toward you. Lightly oil bearing bores and faces then fit cover-end bearing into body; ensure that recessed face is uppermost and that the relieved radii on outside diameters is towards the outlet side of pump body. If original bearings are being refitted check that they are assembled in their original positions.
18. Fit rotors in position - driving rotor to the right. Replace top bearing; recessed face toward rotors, and relieved radii toward outlet side of pump body.
19. Smear inside of oil seal with grease then fit flange in position. To avoid shaft keyway cutting the seal edge, cover keyway with adhesive tape.
20. Turn assembly over and place on two wooden blocks so that driveshaft is clear of bench. Fit cover to pump body, positioned so that relief valve cap is toward inlet port side of pump, secure with four bolts and tighten evenly to 4.0 kg m (30 lb ft).
21. Fit drive key to shaft keyway, replace gear, tabwasher and nut. Do not hammer gear onto shaft as this may cause rotor teeth to damage the face of the soft alloy bearings, but hold gear stationary and tighten nut to 6.22 kg m (45 lb ft), lock nut with tabwasher.
22. Replace filter element and reservoir cover.



If pump is not to be fitted to a tractor immediately, seal ports with adhesive tape to prevent ingress of foreign matter during storage.

Filter Element - 885

Replacing — Fig. E51

1. Remove reservoir assembly.
2. Remove retaining bolt from centre of reservoir cover, lift off cover and remove spring and filter cap.


Fig. E50



BODY AND ROTOR PACK DIMENSIONS

Dimension 'A' to be within 0.20 mm (0.008 in) of dimension 'B'.

Fig. E51




3. Lift out separator then remove and discard filter element.
4. Wash separator and inside of reservoir with paraffin and leave to drain.
5. Fit new filter element and replace separator, filter cap and spring.
6. Fit new sealing ring to reservoir cover, fit cover and replace retaining bolt. Position cover so that filler cap aperture is opposite to mounting bracket, then tighten bolt to 5.5 kg m (41 lb ft).
7. Refit reservoir assembly.

Filter Element - Not 885

Replacing — Fig. 52

1. Remove steering pump.
2. Release bolt in centre of reservoir cover, remove cover and discard filter element; hold pump over a suitable container when removing cover as the reservoir contents will be released.
3. Hold pump with gear downwards then fit new filter element on locating pad on pump cover.
4. Note position of locating plate on inside of reservoir, then push reservoir on to pump so that locating plate engages on pump locating peg.
5. Hold reservoir against element spring and replace centre bolt. Do not overtighten bolt as this will damage sealing washer and cause leakage. Whilst holding cover, screw bolt up to washer then tighten a further three-quarters to one turn only.
6. Refit steering pump.

Fig. E52



H/6 1/3

Orbitrol Steering Valve


Servicing

On no account should the Orbitrol valve be dismantled during the warranty period, to do so will render the warranty invalid. Servicing after this period should be confined to the replacing of seals, and the cleaning of parts only, as the components are match fitted. The unit is manufactured to extremely close tolerances, therefore absolute cleanliness is essential.

Dismantling — Figs. E53 and E54.

1. Remove seven socket screws from end cap, note position of screw fitted with roll pin. Remove and discard sealing washers from beneath screws.
2. Remove end cap, orbit set, spacer and valve plate; remove and discard 'O' rings.
3. Remove drive shaft; note position of and remove threaded bush and steel ball.
4. Push out valve spool and sleeve. If difficulty is experienced check for scoring of sleeve.
5. Remove washer, bearing, bearing race and centering spring retaining ring from valve spool and sleeve. Note sequence of removal to facilitate reassembly.
6. Remove drive pin then separate valve spool from sleeve by pushing spool in direction of centering springs.
7. Remove six centering springs from valve spool. Discard all six if one or more are broken or damaged.
8. Carefully remove valve spool shaft seal, then remove and discard 'O' ring and 'Ken-ring' seal from valve body.

Fig. E53



H/6 34

9. Thoroughly clean all components using clean fuel and lint free cloth. Examine all parts for damage or wear. If spool valve is found to be scored to a small degree, it can be polished out using lapping compound. However it should be remembered that unnecessary polishing will increase the tolerances of the mating parts and create other problems such as excessive steering wheel slip.


Re-assembly — Figs. E55 to E58

10. Lubricate all parts with steering oil then assemble valve spool and sleeve with centering spring slots aligned. The fit between these parts is very close, so perfect alignment is required during assembly.
11. Insert Special Tool K964173 into centering spring slot in spool valve and sleeve and position springs into protruding end of tool. Using finger pressure compress ends of springs, then slide springs into valve spool and sleeve as special tool is pushed out, until springs have equal protrusion at both sides.
12. Replace drive pin which should be flush with sleeve.
13. Refit ring, bearing race, bearing and washer onto spool valve shaft. Internal diameter chamfer on bearing race must face away from bearing.
14. Using a suitable driver, refit valve spool shaft seal with lip to the outside.
15. Refit 'O' ring and 'Ken-ring' seal to the valve body. This should be done by coating the 'O' ring with grease and then mounting it on outside of 'Ken-ring' seal. Position both on spindle of Special Tool K964172 then push spindle into sleeve of Special Tool until firm resistance is met.
16. Insert tool into Orbitrol valve housing until sleeve bottoms in housing. Press tool with a rotating motion until 'O' ring seats in housing then remove tool.
17. Insert valve spool and sleeve complete with bearing assembly into housing, perfect alignment is necessary because of close fitting of parts. Rotate assembly whilst passing through 'Ken-ring' seal and ensure drive pin is at right-angles to machined surface where hoses attach, this is necessary for timing rotor.

NOTE: If valve spool and sleeve are chilled in a refrigerator, mounting the assembly into housing is easier.


18. Refit non-return valve steel ball into correct port in Orbitrol valve housing, then screw in the threaded bush, do not overtighten bush.
19. Fit new housing 'O' ring.
20. Refit drive shaft ensuring drive slot is at right-angles to connecting flange for steering hoses. Ensure that drive pin is in position to accept slot in driveshaft. It may be necessary to rotate valve spool and sleeve to obtain engagement of slot and drive pin.
21. Refit valve plate so that ports line up with corresponding ports in Orbitrol housing: Position drive shaft so that splines rest on valve plate.
22. Fit two new 'O' rings, one each side of orbit set.
23. Refit orbit set to valve plate, engaging drive shaft splines so that one valley of rotor lines up with drive pin slot in drive shaft. This times the rotor section to the spool valve. If set incorrectly, tractor will steer in opposite direction to that of the steering wheel. When installed, turn outer ring of orbit set until seven bolt holes are aligned.

Fig. E54




11/76/35

Fig. E55




11/76/36

Fig. E56



11/76/37

Fig. E57



11/76/38

24. Refit spacer on top of drive shaft to retain shaft correctly in orbit set.
25. Refit end cap with holes aligned, fit new sealing rings to screws and secure end cap ensuring correct location of screw fitted with roll pin. Tighten screws to 2.75 kg m (20 lb ft).
26. Test Orbitrol valve by applying a torque to the splined sleeve. This torque must not exceed 2.48 kg m (18 lb ft).

Steering Ram - Side Mounted

Dismantling — Fig. E59

1. Remove steering ram.
2. Drain oil by holding ram with pipe connections downwards and moving ram rod over its full stroke, remove scraper seal.
3. Remove two circlips from inside front end of outer tube then withdraw ram rod complete with sleeve and piston.
4. Hold ram rod in a soft jawed vice by gripping sleeve, do not grip ram rod - then remove piston nut, piston and sleeve.
5. Remove and discard 'O' ring and back-up washers from piston.
6. Remove and discard internal 'O' ring, anti-extrusion ring and 'Nu-Lip' ring, and external 'O' ring and anti-extrusion ring from sleeve.

Inspection

7. Clean and examine cylinder case and ram rod, these must be smooth and free from score marks.
8. If the piston or ram rod have any sharp edges, these should be carefully removed with a stone then thoroughly cleaned.


Re-assembly — Figs. E50 and E51

9. Fit new 'Nu-Lip' ring to front internal groove on sleeve, then fit two new leather anti-extrusion rings to remaining internal groove, and external groove, with hairgrain side towards piston end of cylinder. Fit new 'O' rings against hairgrain sides of anti-extrusion rings.

NOTE: Leather anti-extrusion rings should be soaked in light engine oil for 30 minutes prior to fitting. A further 30 minutes should be allowed for drying before completing assembly.


10. Fit new 'O' ring and back-up washers to piston groove.
11. Smear the ram rod with clean oil then fit it through scraper seal and sleeve.
12. Place piston on ram rod, chamfered end of hole against rod shoulder. Replace piston nut and tighten to 13.8 kg m (100 lb ft). Grip sleeve when tightening nut; do not grip ram rod in vice.
13. Smear inside of cylinder case with oil then carefully push ram rod, piston and sleeve into position. Sleeve should be pushed in until tapered shoulder seats in case recess.
14. Fit two circlips ensuring correct seating in groove and that their ends are diametrically opposite.

Fig. E58




11/6 39

Fig. E59




11/6 40

Fig. E50



11/6 41

Fig. E51



11/6 42

15. Locate scraper seal in case recess.
16. Refit steering ram.

If steering ram is not to be fitted to a tractor immediately, plug pipe connections to prevent the ingress of foreign matter during storage.

Ram Ball Joints - Side Mounted Rams

Replacing

The ball joints at each end of the ram are self-adjusting and do not require lubrication. If a joint develops wear, or becomes seized due to the ingress of water, the joint should be renewed. When replacing joints, screw the front joint into the full depth of thread in the ram rod sleeve then tighten the locknut. Screw the rear joint into the case until the centre-to-centre distance between the joints is 68.6 cm (27.0 in) when ram is fully retracted, then tighten locknut.

Steering ram - Transverse Rams


Dismantling — Figs. E52 and E53

1. Remove ram from yoke assembly.
2. Drain oil from ram by pumping ram rod over its full stroke.
3. Hold ram vertically in a soft jawed vice, compress circlip and tap ram rod upwards. If circlip is held centrally in cylinder, it will clear groove and allow sleeve to be pushed out of cylinder case.

NOTE: Do not grip ram rod in vice.

4. Invert cylinder and remove opposite end sleeve in same manner.
5. Thoroughly clean and examine case and ram rod, which should be smooth and free from score marks. Remove and discard all seals and 'O' rings.
6. If removing piston; remove six socket screws and clamping plate, withdraw piston from ram rod over reduced diameter end.
7. Remove and discard 'O' ring from groove inside piston and retrieve split ring halves.

Figs. E52




H/6 23

Re-assembly — Figs. E54 and E55

8. Fit new 'O' ring to groove inside piston.
 9. Locate piston to ram rod: piston must pass over reduced diameter end of rod to prevent damage to 'O' ring.
 10. Refit split ring halves to groove and secure piston with clamping plate and six socket screws. Screws should be smeared with Loctite 270 and tightened to a torque of 1.1 kg m (8 lb ft).
 11. Carefully fit two back-up washers to external groove on piston and place a new 'O' ring between them. Do not overstretch 'O' ring and ensure both 'O' rings and back-up washers fit snugly in groove.
 12. Fit leather anti-extrusion ring to sleeve outer groove with hair grain side of leather towards piston.
- NOTE:** Leather rings should be soaked in light engine oil for 30 minutes prior to fitting to enable them to stretch over sleeve. A further 30 minutes should be allowed for drying before completing assembly.
13. Fit new 'O' ring against hair grain side of leather: ring e.g. 'O' ring towards piston, leather ring on outside of groove. Ensure both rings fit snugly in groove.

Figs. E53



H/6 25

14. Fit plastic back-up washer to inner sleeve groove then fit new 'O' ring to piston side of washer. Ensure both rings fit snugly in groove.
15. Fit 'Nu-Lip' seal to centre inner sleeve groove.

NOTE: Early steering ram sleeves were not fitted with the 'Nu-Lip' seal.

16. Fit back-up 'O' ring to wiper seal groove, then using a special tool, push wiper seal against 'O' ring until outer lip of seal springs into sleeve recess. Do not use screwdriver or punch to fit seal as damage will result.
17. Thoroughly clean inside of cylinder bore then fill circlip grooves with thick grease.
18. Wipe ram rod clean, smear inside of one sleeve with clean oil and fit sleeve to ram rod. Push ram rod through sleeve seals with a screwing motion so that chamfered end of rod will enlarge seals as rod passes through.
19. Fit ram rod, with one sleeve fitted, into cylinder, carefully pushing piston seal and sleeve past circlip groove.
20. Compress circlip and push sleeve into cylinder until circlip springs out and engages in groove.
21. Smear inside of other sleeve with clean oil then fit sleeve to ram rod in same way as described above.
22. Check that both circlips are correctly seated in their grooves.
23. Refit ram to yoke assembly.

Ram Cylinder 1210 4 WD Mk. II


Dismantling — Figs. E56 and E57

1. Remove ram cylinder from front axle.
2. Release ball joint locking clamp and unscrew ball joint assembly.
3. Remove cylinder end cover using 'C' spanner (Fig. 72), then remove and discard dirt excluder.
4. Withdraw ram rod complete with piston and sleeve assemblies.
5. Remove nyloc nut and withdraw piston assembly. Separate piston halves then remove and discard back-up washers, seal, anti-extrusion ring and 'O' ring.
6. Remove sleeve assembly, then remove and discard 'O' ring, seal and anti-extrusion ring.
7. To remove pivot pin, prise out spring ring retainer and lift ball joint from cylinder case.

Reassembly — Figs. E58 to E71


8. Thoroughly clean all components and examine case and ram rod which should be smooth and free from score marks.
9. Fit new seal and anti-extrusion ring to sleeve with ring towards recess, then fit sleeve to ram rod from reduced diameter end.
10. Fit new 'O' ring to outer groove in sleeve.
11. Fit flat piston half with shoulder towards nut end of ram rod.
12. Fit back-up washer to piston half and two anti-extrusion rings to piston seal, then fit seal back to ram rod.
13. Fit second piston half and back-up washer to ram rod and secure piston assembly with nyloc nut.
14. Smear oil over ram rod, piston and sleeve, and locate in cylinder. Push sleeve into cylinder by gently tapping with a soft hammer. Do not press into position with cylinder end cover as damage to threads will result.

Fig. E54




H/70/24

Fig. E55




H/70/22

Fig. E56



H/70/28


Fig. E57



H/70/20


15. Fit new dirt excluder to cylinder end cover, then refit cover to cylinder; do not over tighten end cover.
16. If necessary refit pivot pin.
17. Refit ball joint assembly to ram rod and secure with clamp.
18. Refit ram cylinder to front axle.

Fig. E68




H76 26

Fig. E70




H76 30

Fig. E69




H76 31

Fig. E71



H76 32

Fig. E72



H76 27

- | | |
|-----------------------|-------------------------------|
| A. 88.9 mm (3 1/2 in) | F. 30.48 cm (12 in) |
| B. 85.7 mm (3 3/8 in) | G. 12.7 mm (1/2 in) radius |
| C. 12.7 mm (1/2 in) | H. 37.5 mm (1 7/16 in) radius |
| D. 14.28 mm (9/16 in) | J. 50.8 mm (2 in) radius |
| E. 50.8 mm (2 in) | K. 60.3 mm (2 1/4 in) radius |

CYLINDER END COVER REMOVAL TOOL

SPECIFICATIONS AND DATA

Front wheel alignment	1.6-3.2 mm (0.0625-0.125 in)
Front hub bearing clearance	0.02-0.08 mm (0.001-0.003 in)
Stub Axle diameter 995, 996 heavy duty, 1210, 1212, 1410, 1412	upper 38.11-38.10 mm (1.501-1.500 in)
	lower 44.52-44.41 mm (1.749-1.7485 in)
885, 990, 995, 996	34.29-34.88 mm (1.374-1.3735 in)
Stub axle bush bores 995, 996 heavy duty, 1210, 1212, 1410, 1412	upper 38.14-38.16 mm (1.5015-1.5025 in)
	lower 44.55-44.49 mm (1.751-1.753 in)
Stub axle end float	0.08-0.63 mm (0.003-0.025 in)
Trunnion pin diameter 885	31.39-31.36 mm (1.250-1.249 in)
990, 995, 996, 1210, 1212, 1410, 1412	38.10-38.07 mm (1.500-1.499 in)
Trunnion pin bush bore 885	31.85-31.82 mm (1.254-1.253 in)
990, 995, 996, 1210, 1212, 1410, 1412	38.14-38.16 mm (1.5015-1.5025 in)
Ram ball peg pre-load, transverse rams	0.02-0.07 mm (0.001-0.003 in)
Column top bearing clearance (not 'Q' cab)	0-0.07 mm (0-0.003 in)
Steering pump type K944379-885	Hobourn-Eaton HE3601/7035/56
Maximum flow	15.9 litre/min (3.5 gall/min)
Maximum pressure	49.2 kg/cm ² (700 lb/in ²)
Steering pump type K944944-990, 995, 996, 1210, 1212, 1410, 1412	Plessey A23-17331
Output at 1000 rev/min (pump speed)	10.46 litre/min (2.3 gall/min)
Output at 1000 rev/min (engine speed)	13.41 litre/min (2.95 gall/min)
† Relief valve pressure at engine idling speed	70 kg/cm ² (1000 lb/in ²)
Servo (Orbitrol) valve K946083	Danfoss OSP125-150-0035
Displacement (per revolution)	125 cm ³ (7.62 in ³)
Steering ram 885, 990, 995, 996, 1210, 1212	K945702
Stroke	36.19 cm (14.250 in)
Bore	47.16 mm (1.875 in)
Piston rod diameter	25 mm (1.000 in)
Steering ram transverse	K948609
Stroke	102 mm (4.000 in)
Bore	70.8 mm (2.752 in)
Piston rod diameter	31.39 mm (1.250 in)
Steering ram 1210 4WD Mk. II	K950325
Stroke	173 mm (6.811 in)
Bore	50 mm (1.968 in)
Piston rod diameter	22 mm (0.866 in)
Tightening Torques	
Axle beam extension bolts	13.83 kg.m (100 lb ft)
990, 995 heavy duty	19.3 kg.m (140 lb ft)
Front wheel bolts	9.62 kg.m (70 lb ft)
Steering column flange bolts	6.9 kg.m (50 lb ft)
Steering wheel nut (not 'Q' cab tractors)	2.76 kg.m (20 lb ft)
Steering pump body bolts - 885	2.5 kg.m (18 lb ft)
990, 995, 996, 1210, 1212, 1410, 1412	4.0 kg.m (30 lb ft)
Steering pump pulley bolt - 885	2.7 kg.m (20 lb ft)
Steering pump drive gear nut (not 885)	6.22 kg.m (45 lb ft)
Ram piston socket screws Transverse	1.1 kg.m (8 lb ft)
Ram piston nut 885, 990, 995, 996, 1210, 1212	13.83 kg.m (100 lb ft)
Steering arm bolts	16.6 kg.m (120 lb ft)
Drop arm retaining bolt 885, 990, 995, 996	4.0 kg.m (30 lb ft)
1210	16.6 kg.m (120 lb ft)
Reservoir cover bolt 885	5.5 kg.m (41 lb ft)
Rocker arm clamp bolts	4.0 kg.m (30 lb ft)
Steering box bolts	4.0 kg.m (30 lb ft)
Steering box and cover bolts	2.7 kg.m (20 lb ft)

General Tightening Torques

The following torque figures apply to bolts of standard material with either course (UNC) or fine (UNF) threads and may be used for bolts and nuts not listed in the above table:

Thread diameter	Tightening Torque
1/4"	0.97 kg.m (7 lb ft)
5/16"	2.07 kg.m (15 lb ft)
3/8"	3.46 kg.m (25 lb ft)
7/16"	6.22 kg.m (45 lb ft)
1/2"	3.38 kg.m (65 lb ft)
5/8"	15.2 kg.m (110 lb ft)
3/4"	19.3 kg.m (140 lb ft)

Details of Change

Redesigned steering pump pulley guard. Changed from K944381 to K944975 - March 1973

Orbitrol valve to reservoir pressure pipe re-routed to afford improved accessibility - March 1973

Orbitrol valve reduced in capacity from an OSP160 to OSP125 on all tractors - November 1974

Steering pump and reservoir combined in a single unit on all tractors except 855 - November 1974

Steering ram line valve incorporated into cylinder port. Steering ram K929055 becomes K945702 - February 1974

Centre beam, main frame and trunnion pin on 885 narrow tractors redesigned to accept standard 885 trunnion pin on 1.250 diameter - October 1975

Centre beam, main frame, and trunnion pin on 990, 995 and 996 tractors redesigned to enable axle to be removed without removing front extension - November 1975

† Transverse power steering ram K948609 changed to include an extra nu-lip type seal (TB49 steering).

† Changes to the droparm, drag link, and ball socket assemblies on the manual steering of 9 series tractors.

Introduced at

885: 625425

885G: 651239

885: 625425

885G: 651239

TB42 steering (1277)

TB42 steering (1277)

885: 629960

885G: 651438

990: 858243

995: 928254

996: 983736

1210: 723982

1212: 1002222

885N: 647025

990: 866452

995: 934315

996: 987778

1210/1212: 11153508

1410/1414: 11200991

TB50 steering (1380)



DAVID BROWN

case

Service Repair Manual

HYDRAULIC SYSTEM

Front Mounted Pump

1200, 1210, 1212, 1410 and 1412 Tractors

Section G2 (Pub. 9-37242) October 1979

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case





WARNING: *Do not feel for oil leakage with your hands. Use a piece of thick cardboard or wood. If the oil is hot it will burn your skin. Oil with high pressure will pass through your skin. This can cause serious injury and even death. If oil does pass through your skin get medical attention immediately.*



WARNING: *Before working on the hydraulic system you must lower the linkage to the ground. If you need to work on the system when the linkage is in the raised position, put supports under the ramshaft arm.*

David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made.

Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual can give details of items which are not part of any specific tractor.

CONTENTS

	Page
SPECIFICATIONS	1
SELECTAMATIC HYDRAULIC SYSTEM — FRONT MOUNTED PUMP	6
HYDRAULIC OIL PUMP	8
RELIEF VALVE	18
VENT VALVE	20
HYDRAULIC OIL FILTER	22
LIVE TAKE-OFF VALVE	26
SELECTAMATIC CONTROL VALVE	32
DIAL POINTER MECHANISM	43
DUMP VALVE	46
THREE-WAY VALVE	49
SUPPORT RAM FOR THE LINKAGE	52
SENSING UNIT	54
CABLE FOR THE SENSING UNIT	65
RAM CYLINDER	66
REMOVAL OF THE RAMSHAFT	70
HYDRAULIC OIL COOLER	76
CONTROL AND FLOW VALVE ASSEMBLY FOR THE HYDRAULIC OIL COOLER	78
THREE-POINT LINKAGE	82
FAULT FINDING	84

SPECIFICATIONS

LUBRICANTS

The following are the recommended lubricants for the selectamatic hydraulic system fitted with a front mounted pump. The lubricant in the system must be replaced after each 1000 hour period. Use one of the recommended lubricants only.

Do not use SAE 80EP oil which is used for hypoid rear axles.

UNITED KINGDOM

All Tractors

BP Tractor Oil Universal or BP Super T.O.U.
Agricastrol MP or Multi-use
Esso Tractor Universal or Unifarm
Mobil Mobiland Universal
Shell Tractor Oil Universal or Super
Universal Farm Oil
Total Super Universal Farm Oil
Filtrate Maxifarm
Gulf Multipurpose Tractor Oil 20W/30
Carburol Tractormaster 20W/30

NORTH AMERICA

All Tractors

Case TFD

WORLDWIDE

(Except United Kingdom and North America.)

Tractors with Tandem Hydraulic Pump and Internal Oil Filter

Amoco 303 fluid
BP Tractran 9
Agricastrol MD
Esso Torque Fluid 56
Mobilfluid 423
Shell Donax TD

All Tractors when the Ambient Temperature is below -7°C

Amoco 303 fluid
BP Tractran 9
Agricastrol MD
Esso Torque Fluid 56
Mobilfluid 423
Shell Donax TD

All Tractors when the Ambient Temperature is above -7°C

(Except Tractors with Tandem Hydraulic Pump and Internal Oil Filter)
Amoco HD-M Motor Oil 20W/30
BP Tractor Oil Universal
BP Vanellus M20-50
Agricastrol MD or Multi-use 20W/30
Esso Tractorlube Universal 20W/30
Esso Unifarm
Mobil and Super
Shell Rotella SX Oil 20W/40

FILTER**External Filter Assembly K952363**

Element K946095

Hold particles larger than

Pall CAF 3968/M
10 micron**Internal Filter Assembly K929853**

Element for 1200 and early 1210 tractors K920522

Element for later 1210 and 1212, 1410, 1412 tractors K929095

Holds particles larger than

Valve and Screen Assembly K920521

Opening vacuum

AC Delco 7973324
AC Delco E/OF14910
40 micron

200-220 mm (7.8-8.7 in) Hg

Tightening Torques $\frac{1}{8}$ UNC bolt: housing to mainframe $\frac{1}{8}$ UNC bolt: cover to housing

21 Nm (2.1 kg m) (15 lb ft)

21 Nm (2.1 kg m) (15 lb ft)

HYDRAULIC PUMPS**Single Pump**1200, 1210 and 1212 tractors { K919048
K9244591410, 1412 tractors { K944907
K949605Output rates at 2000 r/min, 105.5 kg/cm² pressure and 45°C oil temperature

K919048 and K924459

K944907

K949605

Plessey A25UT
Dowty 7116A/3036
Plessey A33/17268
Plessey A40/18529

21 litre/min (4.6 gal/min)

28.3 litre/min (6.2 gal/min)

34.2 litre/min (7.5 gal/min)

The output rates given are for new pumps. Old pumps can be used if their output rates are not less than 90% of an equivalent new pump.

Tandem Pump

All tractors K916535

Output rates at 2000 r/min, 105.5 kg/cm² pressure and 45°C oil temperature.

K916535 front pump

rear pump

Plessey A33/25, 07724

21 litre/min (4.6 gal/min)

28.3 litre/min (6.2 gal/min)

The output rates given are for a new pump. An old pump can be used if its output rates are not less than 90% of a new pump.

Tightening Torques $\frac{1}{2}$ UNF bolt: through Plessey pump body $\frac{1}{2}$ UNF bolt: through Dowty pump body $\frac{1}{8}$ UNF nut: pump coupling to shaft

60 Nm (6.0 kg m) (43.5 lb ft)

48 Nm (4.8 kg m) (35 lb ft)

62 Nm (6.2 kg m) (45 lb ft)

RELIEF VALVE

Free length of spring

Rate of spring

Opening pressure of valve

40.6 mm (1.6 in)

37.5 kg/cm (210 lb/in)

15.5 kg/cm² (2200 lb/in²)**Tightening Torques** $\frac{1}{8}$ UNC bolt: valve body to mainframe $\frac{1}{8}$ UNC bolt: valve body to pipe flange

62 Nm (6.2 kg m) (45 lb ft)

35 Nm (3.5 kg m) (25 lb ft)

VENT VALVE

Free length of spring

Rate of spring

Closing pressure of valve

5.6 mm (0.221 in)

0.75 kg/cm (4.24 lb/in)

2.25 kg/cm² (32 lb/in²)

SELECTAMATIC VALVE**Relief Valve**

Free length of spring	18.6 mm (0.73 in)
Rate of spring	21.8 kg/cm (122 lb/in)
Opening pressure of valve	17.6 kg/cm ² (2500 lb/in ²)

Sensing Valve

Free length of spring	19 mm (0.75 in)
Rate of spring	3.04 kg/cm (17 lb/in)

Lowering Valve

Free length of spring	35.6 mm (1.40 in)
Rate of spring	2.34 kg/cm (13.2 lb/in)

TCU Valve

Free length of spring	20.3 mm (0.80 in)
Rate of spring	33.0 kg/cm (185 lb/in)
Maximum pressure	52.7 kg/cm ² (750 lb/in ²)

Steel Ball Diameters

For TCU valve K17063	6.3 mm (0.23 in)
For by-pass valve plunger K11548	3.2 mm (0.125 in)
For hold valve plunger K11548	3.2 mm (0.125 in)

Tightening Torques

$\frac{5}{16}$ UNC nuts and bolts: valve body to bracket	21 Nm (2.1 kg m) (15 lb ft)
$\frac{5}{16}$ UNC bolts: valve body to pipe flange	21 Nm (2.1 kg m) (15 lb ft)

RAM CYLINDER**Bore Size**

12 Series standard	88.9 mm (3.501 in)
12 Series oversize	89.43 mm (3.521 in)
14 Series standard	101.63 mm (4.001 in)

Piston Stroke

12 Series	139 mm (5.474 in)
14 Series	168 mm (6.625 in)

Piston Size

12 Series standard	88.87 mm (3.499 in)
12 Series oversize	89.38 mm (3.519 in)
14 Series standard	101.50 mm (3.996 in)

Tightening Torques

12 Series	
$\frac{1}{2}$ UNC bolts: cover to ram cylinder	90 Nm (9 kg m) (65 lb ft)
UNC bolts: ram cylinder to rear axle	194 Nm (19.4 kg m) (140 lb ft)
UNC bolts: ram cylinder to rear axle	104 Nm (10.4 kg m) (75 lb ft)
BSP vent valve	11 Nm (1.1 kg m) (8 lb ft)
14 Series	
UNC bolts: cover to ram cylinder	35 Nm (3.5 kg m) (25 lb ft)
UNC bolts: cover to ram cylinder	166 Nm (16.6 kg m) (120 lb ft)

SUPPORT RAM FOR THE LINKAGE

Rod diameter	44.45 mm (1.750 in)
Stroke	279 mm (11 in)
Sleeve diameter	63.58 mm (2.503 in)
Sleeve bore diameter	44.50 mm (1.752 in)

SINGLE RATE SENSING UNIT

Free length of spring	108 mm (4.250 in)
Rate of spring	1930 kg/cm (10800 lb/in)
Maximum operating force	15000 N (1500 kg) (3300 lb)
	6250 N (625 kg) (1350 lb)

ADJUSTABLE SENSING UNIT

Free length of spring	108 mm (4.250 in)
Rate of spring	1930 kg/cm (10800 lb/in)

Maximum Operating Forces

Extra light draught	{ compression tension	7150 N (715 kg) (1575 lb) 4290 N (429 kg) (945 lb)
Light draught	{ compression tension	9750 N (975 kg) (2150 lb) 5850 N (585 kg) (1290 lb)
Medium draught	{ compression tension	17600 N (1760 kg) (3880 lb) 10570 N (1057 kg) (2330 lb)
Heavy draught	{ compression tension	26440 N (2644 kg) (5830 lb) 15870 N (1587 kg) (3500 lb)

SELECTIVE SENSING UNIT

Free length of strong spring	70.64 mm (2.781 in)
Rate of strong spring	3750 kg/cm (21000 lb/in)
Free length of weak spring	56.36 mm (2.219 in)
Rate of weak spring	1930 kg/cm (10800 lb/in)

Maximum Operating Forces

Light draught	{ compression tension	9070 N (907 kg) (2000 lb) 4780 N (478 kg) (1100 lb)
Medium draught	{ compression tension	13600 N (1360 kg) (3000 lb) 7250 N (725 kg) (1600 lb)
Heavy draught	{ compression tension	27210 N (2721 kg) (6000 lb) 14960 N (1496 kg) (3300 lb)

Tightening Torques

$\frac{1}{2}$ UNC bolt: end plate to housing	42 Nm (4.2 kg m) (30 lb ft)
$\frac{1}{2}$ UNC bolt: housing to PTO unit	105 Nm (10.5 kg m) (75 lb ft)

HITCH BRACKETS**Tightening Torques**

Hitch brackets to studs	(14 Series)	97 Nm (9.7 kg m) (70 lb ft)
Nuts	(14 Series)	300 Nm (30 kg m) (220 lb ft)

THREE-POINT LINKAGE**Length of Levelling Lever**

12 Series	maximum	570 mm (22.50 in)
	minimum	454 mm (17.875 in)
14 Series	maximum	667 mm (26.250 in)
	minimum	524 mm (20.625 in)

Length of Lift Rod

12 Series	maximum	584 mm (23 in)
	minimum	457 mm (18 in)
14 Series	maximum	654 mm (25.750 in)
	minimum	527 mm (20.750 in)

Tightening Torques

7/8 UNC bolts: cap to gear housing	42 Nm (4.2 kg m) (30 lb ft)
3/4 UNF bolts: hitch bracket to rear axle 12 Series	194 Nm (19.4 kg m) (140 lb ft)
3/4 UNF bolts: hitch bracket to rear axle 14 Series	300 Nm (30 kg m) (220 lb ft)

STABILISER BARS

Free movement of telescopic type

75 mm (3 in)

Tightening Torques

3/4 UNC bolts: bracket to reduction case	90 Nm (9 kg m) (65 lb ft)
3/4 UNC nuts: pin to lower link	190 Nm (19 kg m) (140 lb ft)

THREE-WAY VALVE

3/4 UNC bolts: valve body to ram cylinder
Connections for take-off pipes

35 Nm (3.5 kg m) (25 lb ft)
3/4 UNF nut

LIVE TAKE-OFF VALVE

Throw-out pressure
3/4 UNC bolts: valve body to distribution block
Connections for take-off pipes

158 kg/cm² (2250 lb/in²)
35 Nm (3.5 kg m) (25 lb ft)
3/4 UNF nuts

SELECTAMATIC HYDRAULIC SYSTEM — FRONT MOUNTED PUMP

HOW IT WORKS

Tractors with Single Hydraulic Pump

This system uses the transmission oil. The oil is taken from the reservoir in the main frame through a suction strainer 'A' to the hydraulic pump 'B'. The pump pushes the oil through the external filter 'C' to the distribution block 'D'.

When the lever for the live take-off valve is in the neutral (centre) position, the oil will flow to the selectamatic valve. The Selectamatic valve

will send oil to the ram cylinder 'H' and the three-way valve 'J'.

When the lever for the live take-off valve is not in the neutral position oil will not flow to the selectamatic valve. The oil will only flow to external equipment connected to the live take-off valve.

An oil cooler 'L' is fitted to Hydra-Shift tractor.




FIGURE 1. SELECTAMATIC HYDRAULIC SYSTEM FOR TRACTORS WITH SINGLE HYDRAULIC PUMP

- A. Suction strainer
- B. Hydraulic pump
- C. External filter
- D. Distribution block
- E. Live take-off valve
- F. External ram
- G. Selectamatic valve
- H. Ram cylinder

- J. Three-way valve
- K. External ram
- L. Oil cooler
- M. Vent valve
- N. Relief valve
- O. Take-off port
- P. Lubrication pipes
- Q. Ramshaft

HOW IT WORKS

Tractors with Tandem Hydraulic Pump

This system is the same as for single hydraulic pump except:

- (i) Two pumps are used in a single unit (tandem pump).

One pump in the unit is used to supply oil to the internal system. The other pump in the unit will supply oil to the take-off valve. The oil going to the take-off valve does not go through the external filter or the distribution block. The internal system can therefore be used at the same time as external equipment attached to the take-off valve.

- (ii) A combining valve is fitted. This will make the output from the two pumps in the unit go to the take-off valve only. The oil will not go through the external filter or the distribution block.

- (iii) Two relief valves are fitted, one for each of the two pumps in the unit.




FIGURE 2. SELECTAMATIC HYDRAULIC SYSTEM FOR TRACTORS WITH TANDEM HYDRAULIC PUMP

- | | |
|--|-----------------------|
| A. Suction strainer | J. Selectamatic valve |
| B. Hydraulic pump for 12 series tractors | K. Ram cylinder |
| C. Hydraulic pump for 14 series tractors | L. Three-way valve |
| D. Combining valve | M. External ram |
| E. External filter | N. Oil cooler |
| F. Distribution block | O. Vent valve |
| G. Live take-off valve | P. Relief valve |
| H. External ram | Q. Take-off port |
| | R. Lubrication pipes |
| | S. Ramshaft |

HYDRAULIC PUMP

HOW IT WORKS

The hydraulic pump is mounted in front of the radiator. It is driven by a shaft which is connected to the crankshaft pulley. The pump will work whenever the crankshaft pulley turns.

Oil enters the inlet side of the pump and moves round the rotors between the teeth. As the teeth come into mesh the oil is pushed out of the pump outlet.

Each rotor has a shaft for a support. The shafts run in bearings which are close to the sides of the rotors. They make a seal with the rotors. If the seal gets broken, oil will flow between the rotors and the bearings. This will decrease the efficiency of the pump. There is a small space between the bearings and the pump body. 'O' rings are used to make a seal between the bearings and the pump body. Some of the oil from the outlet side of the pump is pushed back behind the 'O' rings. This makes the pressure at both sides of the bearings equal. It will stop the oil around the rotors from pushing the bearings apart and so keep the seal.




FIGURE 3. HYDRAULIC PUMP

A. Pump body X. Inlet
B. Rotors Z. Outlet

REMOVAL OF THE HYDRAULIC PUMP

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

To remove the hydraulic pump first take off the louvre from the bonnet front. Disconnect the battery leads and take out the battery. Remove the air cleaner on 12 series tractors. Clean all dirt from and around hydraulic pump. Remove the two bolts holding the elbow to the inlet side of the pump. For single hydraulic pump, remove the four screws holding the outlet pipe on to the outlet side of the pump. For tandem hydraulic pump, remove the eight screws holding the two outlet pipes on to the outlet side of the pump. The pump is fastened to a bracket which is held on to the main frame with four bolts. You must remove the pump and bracket together.




FIGURE 4. REMOVAL OF THE HYDRAULIC PUMP

A. Hydraulic pump B. Inlet pipe

THE PLESSEY HYDRAULIC PUMP

Disassembly of the Plessey Hydraulic Pump

1. Prepare a clean working surface where you can disassemble and store components of the pump.
2. If a hydraulic and/or an engine oil cooler are fitted, remove them from the assembly.
3. Hold the pump coupling in a vice. Bend the lug of the tabwasher away from the nut. Remove the nut and tabwasher.

4. Carefully hold the pump body in a vice as shown in Figure 5. Use a puller to remove the coupling 'A' from the shaft. Take out the Woodruff key from its keyway on the shaft and remove any sharp edges.

NOTE: Use only the correct puller to remove the coupling. Other types of tools will make the rotor teeth cut into the bearings. This will break the seal and so decrease pump output.

5. Use a marker with a fibre tip to make a mark on the pump flange, body, end cover, and bracket. Do this so that you know which way to assemble the parts.
6. Remove the four nuts and bolts holding the bracket 'B' to the pump flange. Store the bracket.
7. Remove the four nuts and bolts holding the pump flange, body and end cover together.
8. Hold the pump body in the vice as shown in Figure 6. Carefully pull the pump flange away from the body. As soon as the pump flange is clear of the dowels, hold it at an angle. Do this so that the keyway will not cut the seal in the flange when you pull it clear of the rotor shaft. Pull the flange clear of the rotor shaft. If the flange will not separate easily from the body, lightly hit it with a soft faced hammer or a piece of soft wood. This will free the flange from the dowels.

NOTE: Do not try to separate the flange from the body with a screwdriver or a knife. If you do, the seal between the parts will be broken and there will be leakage.

9. Use a marker with a fibre tip to make a mark on the bearing at the inlet side of the pump. Do this so that you know which way to assemble the parts.
10. Remove the pump body from the vice. Hold the pump in one hand so that it is vertical and the flange end is at the bottom. Lightly hit the body with a hammer with a soft face or a soft piece of wood. This will release the bearings and rotors from the body. Store the bearings and rotors with the pump flange and bracket.




FIGURE 5. REMOVAL OF THE PUMP COUPLING

- | | |
|------------------|----------------|
| A. Pump coupling | D. Pump flange |
| B. Bracket | E. Pump body |
| C. Puller | F. Vice |




FIGURE 6. REMOVAL OF THE PUMP FLANGE

- | | |
|----------------|----------|
| D. Pump flange | F. Vice |
| E. Pump body | G. Dowel |

11. Remove the end cover. Use a marker with a fibre tip to make a mark on the bearings at the inlet side of the pump. Do this so that you know which way to assemble the parts. Remove the bearings and store with the end cover.
12. Remove the circlip which holds the seal in the pump flange. Carefully press out the seal with a soft drift.

INSPECTION AND REPAIR OF THE PLESSEY HYDRAULIC PUMP

The Pump Body

As the bearings wear, the rotors are pushed to the inlet side of the pump body. They will cut into the pump body. If the marks are deep, the pump must be discarded. You must not fit new bearings to a pump in this condition. The new bearings will hold the rotors away from the damaged face. This will cause leakage and a decrease in the pump output. You can only use the pump body if there are no marks or if the marks are not deep. If there are marks you must carefully remove any sharp edges with a scraper or fine emery cloth.

The Bearings

The bearings are made of an aluminium tin alloy. Make sure that the edges are not damaged and that there is no dirt on the bearings. If there is damage to the edges, discard the bearings. Look at the bearings to see if there is any wear on the faces and bores. If there are deep marks between the bores, discard the bearings. If the lubrication grooves in the bores are damaged, discard the bearings. If there is wear on the faces but not deep marks, do the following test:

Partly assemble the pump as shown in Figure 8. Do not use the nuts, bolts, seals or the pump flange. The face of the top bearing must be between 0.1 and 0.2 mm below the top face of the pump body. If it is more than 0.2 mm below the top face of the pump body, discard the bearings. When the bearings are too low the 'O' rings will not make a seal when the pump is assembled. This will cause leakage and a decrease in pump output. If the position of the bearings is within the limits, do the following:

Put a sheet of 'O' grade emery cloth on a flat surface. Use paraffin for lubrication. Put the face of the bearings on the emery cloth and lightly press down. Move the bearing in a rotary motion. Do this until there are no marks on the face. Repeat the operation for the other face and both faces of the other bearing.

Repeat the test. If the face of the bearing is too low, discard the bearings. If the position of the bearing is still within the limits, check around the outside of the bearing. If there are any sharp edges, remove them with emery cloth. There must be no restriction when you assemble the bearings in the body.




FIGURE 7. INSPECTION OF THE PUMP BEARINGS




FIGURE 8. CHECKING THE DISTANCE X
 $X = 0.1-0.2 \text{ mm}$




FIGURE 9. REMOVING MARKS FROM THE FACES OF THE BEARINGS

$0.1 \text{ mm} = 0.004 \text{ in}$ $0.2 \text{ mm} = 0.008 \text{ in}$
--

The Rotors

Make sure that the edges of the teeth are not damaged and that there are no cracks on the teeth. If the edges are damaged or there are cracks, discard the rotors. Look for wear and marks on the side faces and outside diameter of the rotors. If there are deep marks discard the rotors. If the marks are not deep, do the following:

Put one of the rotors between centres on a lathe. Remove the marks using 'O' grade emery cloth. Use paraffin for lubrication. Repeat operation for other rotor.

The outside diameter and width of a rotor must almost be the same as the other rotor. The limits are 0.013 mm on the outside diameter and 0.005 mm on the width of the rotors. If the rotors are not within the limits, there will be a decrease in pump output.

ASSEMBLY OF PLESSEY HYDRAULIC PUMP

Clean the working surface. Wash all components in paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts. Do not use other cleaning fluids, they can damage the rubber seals.

1. Carefully press a new seal into the pump flange. Put a little grease on the faces and bore of the seal. Fit the circlip in position.
2. Fit new sealing rings into the grooves in the pump flange and end cover. Fit the P.T.F.E. backup strip (see Figure 10.). If a backup strip was not fitted, fit one now.
3. Assemble end cover to pump body. The end cover must be fitted so that the sealing rings are in the position shown in Figure 11.
4. Use clean oil to lubricate the bearing faces and bores. Fit the bearing into the pump body as shown in Figure 12. Note: The 'Y' shaped groove must be to the left (towards the rotor) and the groove on the radius towards the outlet side of the pump. If the original bearings are to be used, you must fit them in their original positions.
5. Fit the rotors so that the driving rotor is at the bottom when the outlet side of the pump is to the right.
6. Use clean oil to lubricate the second bearing. Fit the bearing into the pump body, 'Y' shaped groove towards the rotors, and the groove on the radius towards the outlet side of the pump (see Figure 13).
7. Carefully, push the pump flange on to the end of the rotor shaft. Hold the flange at an angle so that the sharp keyway does not cut the seal. Push the flange on the shaft then fit the flange on the dowels.




FIGURE 10. FITTING SEALS INTO THE PUMP FLANGE AND END COVER

A. Sealing rings
B. Backup strip
X. Inlet
Z. Outlet




FIGURE 11. FITTING THE END COVER TO THE PUMP BODY

C. Pump body
D. End cover
X. Inlet
Z. Outlet





FIGURE 12. FITTING THE BEARINGS AND ROTORS

E. Bearing
F. Driving rotor
X. Inlet
Y. 'Y' shaped groove
Z. Outlet

0.013 mm = 0.0005 in
0.005 mm = 0.0002 in

8. Push the four bolts through the assembly and put a little oil on the bolt threads. Fit the washers and the nuts and tighten to a

torque of 60 Nm. Put a cover over the inlet and outlet holes.



R76-102

FIGURE 13. PLESSEY SINGLE HYDRAULIC PUMP


A. Sealing rings
B. Backup strip

C. Body
D. End cover

E. Bearing
F. Rotors

G. Pump flange
H. Seal

J. Bracket
K. Coupling



R76-103

FIGURE 14. PLESSEY TANDEM HYDRAULIC PUMP

A. Sealing rings
B. Backup strip

C. Body
D. End cover

E. Bearing
F. Rotors

G. Pump flange
H. Seal

TO RUN IN THE PUMP

When a new pump or a pump which has been serviced is fitted to a tractor, you must run in the pump.

Put the dial pointer in the 'TCU/EXT' position and the quadrant lever in the 'LOWER' position. Start the engine and run at 1500 r/min. Very slowly move the quadrant lever to the 'SELECT' position. Take 8 or 9 minutes to do this. Hold the quadrant lever in the 'SELECT' position for 3 seconds. Move the quadrant lever away from the 'SELECT' position for 3 seconds. Move the quadrant lever to the 'SELECT' position and hold for another

3 seconds. Repeat moving the quadrant lever backwards and forwards for a total of 1 minute.

Check the output of the pump. If it is correct and the pump is not hot, you can use the pump at full output.

NOTE: Do not hold the quadrant lever in the 'SELECT' position for more than 3 seconds. If you do, the oil will damage the seals and there will be a decrease in pump output.

60 Nm = 6 kg m = 43.4 lb ft

THE DOWTY HYDRAULIC PUMP

DISASSEMBLY OF THE DOWTY HYDRAULIC PUMP

1. Prepare a clean working surface where you can disassemble and store components of the pump.
2. If a hydraulic and/or an engine oil cooler are fitted, remove them from the assembly.
3. Hold the pump coupling in a vice. Bend the lug of the tabwasher away from the nut. Remove the nut and tabwasher.
4. Carefully hold the pump body in a vice as shown in Figure 15. Use a puller to remove the coupling 'A' from the shaft. Take out the Woodruff key from its keyway on the shaft and remove any sharp edges.

NOTE: Do not use a hammer or levers to remove the coupling. If you do, the rotor teeth will cut into the bearings. This will break the seal and so decrease pump output.

5. Use a marker with a fibre tip to make a mark on the pump flange, body, end cover and bracket. Do this so that you know which way to assemble the parts.
6. Remove the four nuts and bolts holding the bracket 'B' to the pump flange. Store the bracket.
7. Remove the four nuts and bolts holding the pump flange, body, and end cover together.
8. Hold the pump body in the vice as shown in Figure 16. Carefully pull the pump flange away from the body. As soon as the pump flange is clear of the dowels, hold it at an angle. Do this so that the keyway will not cut the seal in the flange when you pull it clear of the rotor shaft. Pull the flange clear of the rotor shaft. If the flange will not separate easily from the body, lightly hit it with a soft faced hammer or a piece of soft wood. This will free the flange from the dowels.

NOTE: Do not try to separate the flange from the body with a screwdriver or a knife. If you do, the seal between the parts will be broken and there will be leakage.

9. Carefully remove the body seal, backup washers and lobe seal. Store them with the pump flange.
10. Remove the pump body from the vice. Hold the pump in one hand so that it is vertical and the flange end is at the bottom. Lightly hit the body with a hammer with a soft face or a soft piece of wood. This will release the bearings and rotors from the body. Use a marker with a fibre tip to make a mark on the bearings. Do this so you know which way to assemble the parts. Store the bearings and rotors with the pump flange and seals.




FIGURE 15. REMOVAL OF THE PUMP COUPLING

- | | |
|------------------|----------------|
| A. Pump coupling | D. Pump flange |
| B. Bracket | E. Pump body |
| C. Puller | F. Vice |




FIGURE 16. REMOVAL OF THE PUMP FLANGE

- | | |
|----------------|----------|
| D. Pump flange | F. Vice |
| E. Pump body | G. Dowel |

11. Remove the end cover and seals. Take out the bearings and store them with the end cover and seals.
12. Remove the circlip which holds the seal in the pump flange. Carefully press out the seal with a soft drift.

INSPECTION AND REPAIR OF THE DOWTY HYDRAULIC PUMP

The Pump Body

As the bearings wear, the rotors are pushed to the inlet side of the pump body. They will cut into the pump body. If the marks are deep, the pump must be discarded. You must not fit new bearings to a pump in this condition. The new bearings will hold the rotors away from the damaged face. This will cause leakage and a decrease in the pump output. You can only use the pump body if there are no marks or if the marks are not deep. If there are marks you must carefully remove any sharp edges with a scraper or fine emery cloth.

The Bearings

Make sure that there is no dirt on the bearings and that the edges are not damaged. If there is damage to the edges, discard the bearings. Look at the bearings to see if there is any wear on the faces and the bores. If there are deep marks, discard the bearings. If there is little wear on the faces but not deep marks, do the following test:

Partly assemble the pump as shown in Figure 18. Do not use the nuts, bolts, seals or the pump flange. The face of the top bearings must be no more than 0.25 mm below the top face of the pump body. If they are more than 0.25 mm below the top face of the pump body, discard the bearings. When the bearings are too low, the seals will not seal when the pump is assembled. This will cause leakage and a decrease in pump output. If the position of the bearings is within the limit, do the following:

Put a sheet of 'O' grade emery cloth on a flat surface. Use paraffin for lubrication. Put the flat faces of a set of bearings on the emery cloth and lightly press down. Move the bearings in a rotary motion (see Figure 19). Do this until there are no marks on the faces of the bearings. Repeat the operation for the other set of bearings.

NOTE: Do this operation with the bearings in the correct sets.

Repeat the test. If the faces of the bearings are too low, discard the bearings. If the position of the bearings are still within the limit, check around the outside of the bearings. If there are any sharp edges, remove them with emery cloth. There must be no restriction when you assemble the bearings in the body.




FIGURE 17. INSPECTION OF THE PUMP BEARINGS




FIGURE 18. CHECKING THE DISTANCE X
X = 0–0.25 mm




FIGURE 19. REMOVING MARKS FROM THE FACES OF THE BEARING

The Rotors

Make sure that the edges of the teeth are not damaged and that there are no cracks on the teeth. If the edges are damaged or there are cracks, discard the rotors. Look for wear and marks on the side faces and outside diameter of the rotors. If there are deep marks discard the rotors. If the marks are not deep, do the following:

Put one of the rotors between centres on a lathe. Remove the marks using 'O' grade emery cloth. Use paraffin for lubrication. Repeat operation for other rotor.

0.25 mm = 0.010 in

The outside diameter and width of a rotor must almost be the same as the other rotor. The limits are 0.013 mm on the outside diameter and 0.005 mm on the width of the rotors. If the rotors are not within the limits, there will be a decrease in pump output.

ASSEMBLY OF THE DOWTY HYDRAULIC PUMP

Clean the working surface. Wash all components in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts. Do not use other cleaning fluids, they can damage the rubber seals.

Fit new seals if any one of the seals are damaged.

1. Carefully press a new seal into the pump flange. Put a little grease on the faces and bores of the seal. Fit the circlip in position.

NOTE: Use only a mineral base grease.

2. Put the bearing for the flange end on the working surface as shown in Figure 20. The flats on the bearings must be together with lugs at the same side. Put a little grease on the lobe seal and fit it in position. Fit the backing washers on the inside of the lobe seal. The top surface of the backing washers must be level with the top surface of the lobe.
3. Put a little grease on the body seal and fit it in the groove on the flange end of the body. Put grease with a high melting point in the space around the seal.

NOTE: Use only a mineral base grease.

4. Hold the body of the pump vertically in one hand so that the flange end is at the top (see Figure 22). Put your fingers inside the pump body. Use them as supports for the bearings. Pick up the bearing assembly with the other hand and carefully slide it into the pump body. The seal must be facing upwards with the lobe to the inlet side. If you are using the original bearings, check the position with the marks on the bearings. There must be no restriction when you put the bearing in the pump body.

0.013 mm = 0.0005 in
0.005 mm = 0.0002 in




FIGURE 20. ASSEMBLY OF THE PUMP BEARINGS AND SEALS

A. Lobe seal

B. Backing washer




FIGURE 21. ASSEMBLY OF THE PUMP BEARINGS AND SEALS

E. Drive shaft

X. Inlet

Z. Outlet




FIGURE 22. FITTING THE BEARINGS

D. Bearings

X. Inlet

Z. Outlet

5. Fit the pump flange on to the dowels. Check the position of the flange with the marks on the flange and pump body. Carefully turn the assembly upside down and hold in the vice as shown in Figure 23.
6. Check that the bearing assembly is against the pump flange and the seals and backing washers are in position. Carefully fit the driving rotor, make sure that the shaft is vertical when you push it through the bearing and oil seal in the pump flange. Do this so that the keyway in the shaft does not cut the seal. Check that the rotor is against the bearing face. Fit the driven rotor. If you are fitting the original rotors, fit them in their original position.
7. Repeat operation number 2 for the other two bearings.





FIGURE 23. FITTING THE ROTORS

E. Driving rotor X. Inlet
F. Driven rotor Z. Outlet

8. Carefully fit the bearing assembly into the pump body, seals to the top, lobe to the inlet side (see Figure 24.) There must be no restriction when you put the bearing assembly into the pump body.
9. Put a little grease on the body seal and fit it in the groove in the pump body. Fit the end cover. Check its position with the marks on the pump flange and body.
10. Push the four bolts through the assembly and put a little oil on the bolt threads. Fit the washers and nuts and tighten to a torque of 48 Nm.
11. Put a small quantity of the recommended hydraulic oil into the pump. Check that the rotors will turn freely. Put a cover over the inlet and outlet holes.
12. Fit the bracket to the pump flange using the four nuts and bolts.
13. Put the Woodruff key in the keyway on the shaft. Fit the coupling on the shaft and fasten it in position with the tabwasher and nut. Hold the coupling in a vice and tighten the nut to a torque of 62 Nm. Bend the lug on the tabwasher to hold the nut in position.

FIGURE 24. ASSEMBLY OF THE PUMP
G. Bearings H. Cover

NOTE: Do not use a hammer to hit the coupling onto the shaft.

48 Nm = 4.8 kg m = 34.7 lb ft
62 Nm = 6.2 kg m = 44.8 lb ft




FIGURE 25. DOWTY HYDRAULIC PUMP

- | | |
|-------------------|-------------|
| A. Lobe seal | H. Cover |
| B. Backing washer | J. Flange |
| C. Seal | K. Oil seal |
| D. Bearings | L. Body |
| E. Driving rotor | X. Inlet |
| F. Driven rotor | Z. Outlet |
| G. Bearings | |

TO RUN IN THE PUMP

When a new pump or a pump which has been serviced is fitted to a tractor, you must run in the pump.

Put the dial pointer in the 'TCU/EXT' position and the quadrant lever in the 'LOWER' position. Start the engine and run at 1500 r/min. Very slowly move the quadrant lever to the 'SELECT' position. Take 8 or 9 minutes to do this. Hold the quadrant lever in the 'SELECT' position for 3 seconds. Move the quadrant lever away from the 'SELECT' position for 3 seconds. Move the quadrant lever to the 'SELECT' position and hold for another 3 seconds. Repeat moving the quadrant lever backwards and forwards for a total of 1 minute.

Check the output of the pump. If it is correct and the pump is not hot, you can use the pump at full output.

NOTE: Do not hold the quadrant lever in the 'SELECT' position for more than 3 seconds. If you do, the oil will damage the seals and there will be a decrease in pump output.

RELIEF VALVE

HOW IT WORKS

To prevent the oil pressure increasing to a dangerous level when there is little or no flow, a relief valve is fitted. This consists of a plunger and spring. When the oil pressure is greater than the spring pressure, the plunger is moved off its seat and oil flows into the transmission housing. The oil pressure is therefore kept below the maximum set by the relief valve spring. The spring pressure can be adjusted by adding or subtracting shims.




FIGURE 26. RELIEF VALVE CLOSED

A. Seat
B. Plunger
C. Cap
D. Spring
E. Shims
X. Inlet




FIGURE 27. RELIEF VALVE OPEN

X. Inlet
Z. Outlet

REMOVAL OF THE RELIEF VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system.

The position of the relief valve changed with the introduction of the external hydraulic filter.

Tractors fitted with Internal Hydraulic Filter

On 2-wheel drive tractors the relief valve is fitted in the position shown in Figure 28. You must drain the transmission oil from the reservoir before removing the relief valve. To remove the oil take out the drain plug 'F'. If you are to use the oil again, put it in a clean container. Put a cover over the container to stop dirt getting into the oil.

Remove the two bolts 'G' (Figure 28.) holding the pressure pipe to the relief valve. Carefully pull the pressure pipe clear of the relief valve and remove the vent valve. Remove the two bolts which hold the relief valve to the main frame.

On 4-wheel drive tractors the relief valve is fitted behind the rear axle and below the ramshaft. The relief valve can be removed without draining the transmission oil.




FIGURE 28. REMOVING THE RELIEF VALVE

F. Drain plug
G. Bolt
H. Relief valve
J. Vent valve

Tractors fitted with External Hydraulic Filter

The relief valve is fitted in the same position for both 2 and 4-wheel drive tractors (see Figure 29.) The relief valve on these tractors can be removed without draining the transmission oil. Remove the two bolts 'A' (Figure 29.) Carefully pull the pressure pipe clear of the relief valve then remove the vent valve. Remove the two bolts 'B' which hold the relief valve to the mainframe.

DISASSEMBLY AND INSPECTION OF THE RELIEF VALVE

Prepare a clean working surface where you can disassemble and inspect components of the relief valve.

1. Remove the seat, plunger, cap, shims and spring from the housing. Do not discard the shims. They are used to set the pressure of the spring.
2. Wash all the components in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts.
3. Fit the cap to the seat. Make sure that there are no restrictions.
4. Fit the plunger to the seat. Look at the faces where the plunger and seat make contact. They must be free from damage. If any of the components are damaged, replace the complete assembly with a new relief valve.

ASSEMBLY OF THE RELIEF VALVE

1. Put a little oil on the inside of the cap. Fit the plunger into the cap.
2. Fit the cap to the seat making sure that there is no restriction.
3. Put the shims and spring in position then fit the parts into the housing. Make sure that you use all the original shims.
4. Replace the 'O' ring at the outlet side of the relief valve.

INSTALLATION OF THE RELIEF VALVE

Before installing the relief valve on to the main frame make sure that the faces are clean and the 'O' ring is in position. Fasten the valve in position using the two bolts. Tighten them to a torque of 62 Nm. Put the vent valve in position (see Installation of Vent Valve page 21). Fasten the pressure pipe to the valve housing using the two bolts. Tighten them to a torque of 35 Nm.

Add oil to the transmission reservoir. If you are using the original oil, pour it through a fine screen. Do not use the last 4.5 litres. If there was any dirt in the oil it will be in the bottom of the container. Start engine and look for leakage around the relief valve. Stop engine and check transmission oil level. Add more oil if the level is low.




FIGURE 29. REMOVING THE RELIEF VALVE

A. Bolt
B. Bolt
C. Relief valve
D. Vent valve




FIGURE 30. RELIEF VALVE

A. Seat
B. Plunger
C. Cap
D. Spring
E. Shims
F. Housing
G. 'O' ring

62 Nm = 6.2 kg m = 44.8 lb ft
35 Nm = 3.5 kg m = 25.3 lb ft
4.5 litres = 8 pt = 4.8 US qt

VENT VALVE

HOW IT WORKS

A vent valve is fitted in the system between the hydraulic pump and the relief valve. It is used to remove any air from the system. A steel ball is held off its seat by a plunger and spring (see Figure 31). The seat has a small hole in its side which permits air to pass into the reservoir. When the tractor engine is running, the oil and any air in the system is pushed into the valve. The air has little pressure. It goes past the steel ball, through the hole in the seat and into the reservoir. The oil has pressure and pushes the steel ball on to its seat (see Figure 32.) Each time the engine stops, the pressure of the oil decreases and the steel ball is pushed off its seat by the spring.




FIGURE 31. VENT VALVE OPEN

- | | | |
|-------------|------------|-----------|
| A. Plug | D. Plunger | F. Washer |
| B. 'O' ring | E. Seat | G. Ball |
| C. Spring | | |




FIGURE 32. VENT VALVE CLOSED

REMOVAL OF THE VENT VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system.

The position of the vent valve changed with the introduction of the external hydraulic filter.

Tractors fitted with Internal Hydraulic Filter

On 2-wheel drive tractors the vent valve is fitted in the position shown in Figure 33. You must drain the transmission oil from the reservoir before removing the vent valve. To remove the oil take out the drain plug 'J'. If you are to use the oil again, put it in a clean container. Put a cover over the container to stop dirt getting into the oil.

Remove the two bolts 'K' which hold the pressure pipe to the relief valve. Carefully pull the pressure pipe clear of the relief valve and remove the vent valve.

On 4-wheel drive tractors the vent valve is fitted behind the rear axle and below the ramshaft. The vent valve can be removed without draining the transmission oil.




FIGURE 33. REMOVING THE VENT VALVE

- | | |
|---------------|---------------|
| J. Drain plug | L. Vent valve |
| K. Bolt | |

Tractors fitted with External Hydraulic Filter

The vent valve is fitted in the same position for both 2- and 4-wheel drive tractors (see Figure 34.) The vent valve on these tractors can be removed without draining the transmission oil.

Remove the two bolts 'K' (Figure 34.) Carefully pull the pressure pipe clear of the relief valve and remove the vent valve.

DISASSEMBLY AND INSPECTION OF THE VENT VALVE

Prepare a clean working surface where you can disassemble and inspect components of the vent valve.

1. Carefully hold the vent valve in a vice as shown in Figure 35. Do not tighten the vice too much.
2. There are two marks where the plug fits into the body. The softer metal of the body has been pushed over the end of the plug at these points. This is done at the factory to keep the plug in position. Carefully remove this metal from the body using a sharp scraper. Use a screwdriver to remove the plug from the body.
3. Remove the 'O' ring, spring, plunger, seat, washer, ball and retainer.
4. Wash all the parts in clean paraffin or fuel oil and dry in air.
5. Look at the steel ball. Make sure that there are no marks on the ball. If there are, the ball will not form a good seal with the seat. You must discard a steel ball in this condition.
6. Look at the seat. If there is damage to the contact face, discard the seat.

ASSEMBLY OF THE VENT VALVE

1. Before assembling the parts put the steel ball in position on the seat as shown in Figure 36. A groove has been cut in the outside diameter at one end of the seat. This has been done so that you know which end to put the steel ball. Lightly hit the ball with a hammer. The softer metal of the seat will take the shape of the steel ball. This will make sure that there is a good seal between the steel ball and the seat.
2. Put the retainer, steel ball, washer, seat and plunger into the body. Make sure that the retainer and washer are on their seats and that the contact face of the seat is towards the steel ball.
3. Fit a new 'O' ring and the spring to the plug. Put the plug in the body and tighten. Use a punch with a sharp end to peen over the body at two points opposite each other.




FIGURE 34. REMOVING THE VENT VALVE
K. Bolt L. Vent valve




FIGURE 35. DISASSEMBLY OF THE VENT VALVE
A. Plug B. 'O' ring C. Spring D. Plunger E. Seat F. Washer G. Ball H. Retainer




FIGURE 36. MAKING A SEAL BETWEEN THE SEAT AND THE BALL

E. Seat G. Ball Y. Groove

INSTALLATION OF THE VENT VALVE

Before installing the vent valve make sure that the faces are clean. Put an 'O' ring in the groove on the flange for the pressure pipe. Fit an 'O' ring in the groove on the vent valve. Put a new gasket in position on the vent valve. Make sure that the small hole in the gasket is opposite the small hole in the vent valve. Put the vent valve in position on the relief valve. Make sure that the small holes are opposite. If they are not the vent valve will not work. Put the pipe flange in position. Fit the two bolts and tighten to a torque of 35 Nm.

35 Nm = 3.5 kg m = 25.3 lb ft

HYDRAULIC OIL FILTER

Two different hydraulic oil filters have been fitted to David Brown tractors. An internal hydraulic filter was fitted to tractors up to the following serial numbers:

1210-1212 : 11152164 1210Q-1212Q : 11152617
1410-1412 : 11200752 1410Q-1412Q : 11200753

External hydraulic filters have been fitted to tractors from the following serial numbers:

1210-1212 : 11152576 1210Q-1212Q : 11152617
1410-1412 : 11200752 1410Q-1412Q : 11200753

These tractors are also fitted with a suction screen in the reservoir for the transmission oil.

There are tractors which were made between the above serial numbers. These tractors have been fitted with either an internal or an external hydraulic oil filter.

EXTERNAL OIL FILTER

HOW IT WORKS

The external oil filter is fitted behind the rear axle on the right-hand side (see Figure 37). It is fitted in the system between the hydraulic pump and the distribution block (see Figures 1 and 2). The parts of the filter are assembled as shown in Figure 38. The oil flows into the bowl, through the paper element and out of the pressure pipe towards the distribution block. When the element gets dirty the oil will not flow through it. The pressure of the oil in the bowl will increase and open a relief valve fitted to the filter head. The oil then flows to the distribution block without going through the paper element. This will result in damage to the system.

REPLACEMENT OF THE PAPER ELEMENT

Before working on the hydraulic system you must clean any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system.

The paper element must be replaced:

- After the first 50 hours.
- 50 hours after working on the inside of the transmission or hydraulic system.
- 500 hours after a paper element has been replaced.

Use a $1\frac{1}{8}$ in AF spanner to remove the filter bowl from the filter head. To do this turn the filter bowl counterclockwise. If a retaining clip is fitted over the filter, remove it. Pull out




FIGURE 37. EXTERNAL HYDRAULIC FILTER

A. External hydraulic filter




FIGURE 38. EXTERNAL HYDRAULIC FILTER

A. 'O' ring
B. Backup ring
C. Element
D. Bowl
E. Filter head

and destroy the paper element. Remove the backup ring (if fitted) and 'O' ring from the filter head. Wash the filter head in clean paraffin or fuel oil and dry in air. Do not use a cloth to clean or dry the filter bowl.

Fit a new 'O' ring into the filter head. Make sure that the 'O' ring is on its seat and is not twisted. Apply a little grease to the 'O' ring. Fit a new backup ring into the filter head. Make sure that the backup ring is on its seat and is not twisted. Apply a little grease to the backup ring. If a backup ring was not fitted, fit one now. Put a new element into the filter bowl. Make sure that the element is fitted with its closed end towards the bottom of the filter bowl. Check that the edges of the new element are not split. An element with any damage must not be used. If there is a retaining clip, fit it. Fit the filter bowl to the filter head. Use a $1\frac{5}{8}$ in AF spanner to turn the filter bowl clockwise.

SUCTION SCREEN

HOW IT WORKS

A suction screen is used when an external filter is fitted. It is fitted in the reservoir for the transmission oil and is on the suction side of the hydraulic pump (see Figures 1 and 2). When the engine is running the hydraulic pump takes oil from the reservoir. Before the oil goes into the inlet pipe for the pump it must go through the suction screen. The screen stops all the large particles of dirt getting into the system.

REMOVAL AND INSPECTION OF THE SUCTION SCREEN

The suction screen must only be removed when you are replacing the transmission oil.

Use a $\frac{15}{16}$ in AF spanner to remove the drain plug 'A' Figure 39. Discard the oil. An inlet filter is fitted on Hydra-Shift tractors. Use a $1\frac{1}{8}$ in AF spanner to take out the filter before removing the suction screen and cover. Take out the ten bolts holding the cover in position. Remove the cover with the suction screen and destroy the gasket. Wash all components in paraffin or fuel oil and dry in air. Do not use a cloth to clean or dry the components.

INSTALLATION OF THE SUCTION SCREEN

Fit a new 'O' ring and suction screen to the cover as shown in Figure 40. Make sure that the 'O' ring is in the correct position and is not twisted. Fit a new gasket then fasten the cover in position using the ten bolts. Tighten the bolts to a torque of 21 Nm. Fit the drain plug and inlet filter (Hydra-Shift tractors). Add the recommended new oil to the transmission reservoir. Make sure that the level of oil is correct. Start the engine and look for leakage around the cover for the suction screen. Put the control lever in the 'LOWER' position for 30 seconds. This will remove air in the system. Stop the engine and check the transmission oil level. Add more oil if the level is low.

Check the transmission oil level. Add the recommended oil if the level is low. Start the engine and look for leakage around the external filter. Put the quadrant lever in the 'LOWER' position for 30 seconds. This will remove any air from the system. Stop the engine and check the level of the transmission oil. Add more oil if the level is low.




FIGURE 39. REMOVING THE SUCTION SCREEN
A. Drain plug B. Inlet filter C. Cover




FIGURE 40. SUCTION SCREEN
C. Cover E. Suction screen
D. 'O' ring F. Gasket

21 Nm = 2.1 kg m = 15.2 lb ft

INTERNAL OIL FILTER

HOW IT WORKS

The internal filter is fitted under the main frame in the position shown in Figure 42. It is fitted on the suction side of the hydraulic pump (replaced by a suction screen on later tractors). The parts of the filter are assembled as shown in Figure 41. The oil flows from the reservoir into the housing and through the paper element. When the element gets dirty the oil will not flow through it. When this happens the pump makes a vacuum in the inlet pipe for the pump. This pulls the by-pass valve off its seat. Oil will now flow through the screen and past the magnetic plug towards the pump. The valve opens at 0.28 kg/cm^2 . A vacuum switch is fitted in the filter (see Figure 41.) When the pressure in the inlet pipe decreases to 0.28 kg/cm^2 , the switch actuates a yellow light on the instrument panel. This tells the operator to replace the paper element.




FIGURE 41. INTERNAL OIL FILTER

- | | |
|------------|------------------|
| A. Screen | D. By-pass valve |
| B. Element | E. Vacuum switch |
| C. Magnet | F. Drain plug |

REPLACEMENT OF THE PAPER ELEMENT

The paper element in this filter must be replaced:

- after the first 50 hours
- 50 hours after working on the inside of the hydraulic or transmission system.
- 500 hours after an element has been replaced.

If the yellow warning light illuminates 30 minutes after starting the engine:

- at 1800 r/min, you must fit a new paper element.
- at engine idle r/min, take no action.

You must remove the transmission oil before replacing the paper element. To do this take out the drain plug (see Figure 42). If you are replacing the element but not the oil, put the oil in a clean container. Put a cover over the container so that dirt does not get into the oil.

An inlet filter is fitted on Hydra-Shift tractors. Use a $1\frac{1}{2}$ AF spanner to take out the filter before removing the cover for the internal filter.

Take out the ten bolts which hold the cover in position. The cover, paper element and valve and screen can now be removed. Remove and destroy the gasket. Separate the valve and screen from the paper element, then destroy the element. Wash all parts in clean paraffin or fuel oil and dry in air. Make sure that all the dirt is removed from the magnetic plug. Do not use a cloth to clean or dry the parts.





FIGURE 42. REMOVING THE INTERNAL FILTER

- | | | |
|---------------|-----------------|----------|
| F. Drain plug | G. Inlet filter | H. Cover |
|---------------|-----------------|----------|

$0.28 \text{ kg/cm}^2 = 27.6 \text{ kPa} = 4 \text{ lb/in}^2$

Fit the valve and screen on a new paper element. Check that the edges of the new element are not split. An element with any damage must not be used. Fit the paper element and valve and screen in the cover. Make sure that the 'O' rings are in the correct position and are not twisted. Clean the housing face and fit a new gasket. Put the cover in position and fasten with the ten bolts. Tighten the bolts to a torque of 21 Nm. Fit the drain plug and inlet filter (Hydra-Shift tractors).

Add oil to the transmission reservoir. If you are using the original oil, pour it through a fine screen. Do not use the last 4.5 litres. If there was any dirt in the oil it will be in the bottom of the container. Start the engine and look for leakage around the cover for the internal filter. Put the quadrant lever in the 'LOWER' position for 30 seconds. This will remove any air in the system. Stop the engine and check the level of the transmission oil. Add more oil if the level is low.



R76-101

FIGURE 43. INTERNAL OIL FILTER

- | | |
|---------------------|-------------|
| A. Valve and screen | J. Gasket |
| B. Element | K. 'O' ring |
| H. Cover | |

21 Nm = 2.1 kg m = 15.2 lb ft
4.5 litres = 8 pt = 4.8 US qt

LIVE TAKE-OFF VALVE

HOW IT WORKS

The live take-off valve is fitted on top of the rear axle case on the right-hand side. The parts are assembled as shown in Figures 44 and 45. When the engine is running, the pump pushes oil through the filter to the distribution block.

If the operating lever for the valve is in the neutral (centre) position, the oil will flow to the selectamatic valve. (See Figure 44). When the operating lever is moved forward the oil will flow as shown in Figure 45. Port 'A' is the outlet port taking oil to the external equipment. Port 'B' is the inlet port returning oil to the valve.

A throw-out mechanism is fitted to the valve spool. If the operating lever is moved fully in either direction, a detent inside the valve holds the valve spool in this position. When the ram cylinder on the external equipment reaches the end of its travel, the oil pressure in the valve increases. This moves a piston in the valve which releases the valve spool from the detent. The valve spool and operating lever will now return to the neutral position.

A non-return valve is fitted to the live take-off valve. When the engine stops the non-return valve closes. This will keep the pressure in the outlet pipe constant. An external ram connected to the valve will stay in position. If two outlet ports are needed, two valves can be fitted, one on top of the other.




FIGURE 44. LIVE TAKE-OFF VALVE WITH THE OPERATING LEVER IN THE NEUTRAL POSITION

A. Outlet port B. Inlet port C. Throw-out mechanism D. Non-return valve




FIGURE 45. LIVE TAKE-OFF VALVE WITH THE OPERATING LEVER FULLY FORWARD

A. Outlet port B. Inlet port E. Detent ball F. Piston G. Spool

REMOVAL OF THE LIVE TAKE-OFF VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system. The live take-off valve is fitted on top of the rear axle case on the right-hand side (see Figure 46). Disconnect the operating rod from the valve spool (tractors with cab only). Remove the inlet and outlet pipes from the side of the valve body. Remove the five bolts which hold the valve body to the distribution block.

Make a note of the position of the bolts, they are not all the same length. If you need to remove the valve body and the distribution block, do not remove the two bolts at the front. They hold the valve body and distribution block together.

DISASSEMBLY OF THE LIVE TAKE-OFF VALVE

It is not normally necessary to completely disassemble the live take-off valve. The seals for the valve spool can be replaced without disassembling the throw-out mechanism. The throw-out mechanism can be disassembled without removing the seals for the valve spool.

REPLACEMENT OF SEALS FOR THE VALVE SPOOL

Prepare a clean working surface where you can disassemble and store components of the live take-off valve.

1. Remove the spring link which holds the spool to the operating lever (see Figure 47, tractors without cab).
2. Remove any dirt or loose paint from the end of the valve spool.
3. Turn the end cap 'E' counterclockwise until it is clear of the threads in the valve body. Pull the end cap and spool from the valve body.
4. Do not remove the end cap from the spool. It is holding the detent ball and other parts of the throw-out mechanism in position.
5. Remove and destroy the seal 'F' and 'O' ring 'G' from the valve bore. Remove the bush 'H' and the 'O' ring 'J'. Destroy the 'O' ring.
6. Wash the valve spool in clean paraffin or fuel oil then dry in air.
7. Fit a new 'O' ring and seal into the valve bore. Make sure that they are on their seat and are not twisted. Apply a little grease to the 'O' ring and the seal.
8. Put a new 'O' ring on to the smaller diameter of the bush. Do this so that the 'O' ring




FIGURE 46. REMOVING THE LIVE TAKE-OFF VALVE
A. Distribution block B. Live take-off valve C. Cover




FIGURE 47. DISASSEMBLY OF THE LIVE TAKE-OFF VALVE
D. Spring link E. End cap




FIGURE 48. REPLACEMENT OF SEALS FOR THE VALVE SPOOL

- | | | |
|------------|-------------|-------------|
| E. End cap | G. 'O' ring | J. 'O' ring |
| F. Seal | H. Bush | K. Spool |

does not come in contact with any sharp edges on the valve spool.

9. Slide the bush and the 'O' ring on to the spool until the bush is against the thread of the end cap.
10. Carefully pull the 'O' ring off the bush into its correct position on the spool in front of the bush. Make sure that the 'O' ring is not twisted. Apply a layer of oil on the spool.
11. Fit the spool into the valve body then tighten the end cap.
12. Connect the operating lever. Make sure that the spool will move easily in the valve bore.

DISASSEMBLY OF THE THROW-OUT MECHANISM

Prepare a clean working surface where you can disassemble and store components of the throw-out mechanism.

1. Remove the spring link which holds the spool to the operating lever (tractors without cab).
2. Remove any dirt or loose paint from the end of the valve spool.
3. Turn the end cap counterclockwise until it is clear of the threads in the valve body. Pull the end cap and spool from the valve body.
4. Carefully hold the spool in the vice as shown in Figure 49. Do not hold the spool on a diameter.
5. Remove the plug 'L' from the end of the end cap.
6. Use circlip pliers to remove the circlip from its groove. Pull the end cap, circlip and washer clear of the spool. Be careful not to lose the detent balls when you do this. They will fall from the holes.
7. Remove the plunger and spring from the retainer.
8. Put a rod through one of the holes in the retainer. Use this to turn the retainer counterclockwise until it is clear of the threads. Be careful when you do this, the spring is in compression, it will push the retainer off the spool.
9. Remove the retainer, washer, spring restrictor (if fitted) and shims from the




FIGURE 49. DISASSEMBLY OF THE THROW-OUT MECHANISM

E. End cap

K. Spool

L. Plug

spool. Do not destroy the shims, they must be fitted in the original position when you assemble the parts. Use a dowel to remove the piston from the retainer.

10. Remove the spring and ball (or plunger) from the bore of the spool.
11. Wash all the parts in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts.

ASSEMBLY OF THE THROW-OUT MECHANISM

Before assembling the throw-out mechanism look at the parts. Three different retainers 'R' (see Figure 50) have been fitted. You can use the original retainer if:

- (a) the spring end is flat
- (b) there is a groove in the spring end and there is a restrictor 'W' and shims 'X'.

If the retainer has a groove in the spring end and there are shims 'X' but not a restrictor, you must fit a new retainer and a restrictor. An example of the serial numbers for these values is given below. The serial number is on the side of the valve body.

300-080-AAD: Fit a new retainer K964500 and restrictor K964499. Use the original shims.

300-080-AAB and 300-080-AAC: Fit a new retainer K964500 and restrictor K964499. You will need more than the original shims when you assemble the parts.

The new retainer and restrictor will stop the circlip 'M' (see Figure 50) from breaking.

1. Look at the 'O' rings on the piston and the retainer. If either are damaged fit new 'O' rings. Put some oil on the 'O' rings.
2. Put the ball (or plunger) into the bore of the spool. If a spring guide was removed from the bore fit it on top of the ball. Put a layer of grease on the small spring 'Y' then fit it in the bore. The grease will keep the spring in the centre of the bore.
3. Put a layer of grease on the spring 'T'. Fit the washers and spring on to the retainer. On early take-off valves the spring end of the retainer is flat. Apply grease to the shims then put them in position in the centre of the flat end of the retainer. Make sure that the shims are clear of the threads. Later take-off valves have a groove in the spring end of the retainer. Put a layer of grease on the restrictor (if fitted) and the shims then fit them in the groove. For live take-off valves with a serial number similar to 300-080-AAB or 300-080-AAC add shims until the last shim is level with the end of the retainer.
4. Fit the retainer assembly to the spindle. Use a rod through one of the holes to turn the retainer clockwise. Do this until the retainer is tight.
5. Put the plunger, spring and washer into the retainer. Fit the circlip into its groove in the retainer.
6. Put grease on the detent balls then fit them into their holes in the retainer. The grease will hold the detent balls in position.
7. Carefully slide the end cap on to the retainer until it is against the detent balls. Hit the end cap with a soft hammer. The end cap will slide over the detent balls until they engage with a groove in the end cap.
8. Put grease into the assembly through the hole in the end cap. Fit the plug into the end cap.
9. Fit the spool and throw-out mechanism into the valve body. Turn the end cap clockwise until it is tight.
10. Connect the operating lever to the spool. Make sure that the spool will move correctly in the bore.

INSTALLATION OF THE LIVE TAKE-OFF VALVE

Make sure that the faces of the distribution block and live take-off valve are clean. Look at the 'O' rings which fit between the distribution block and the live take-off valve. Replace the 'O' rings if they are damaged. Put the live take-off valve in position on top of the distribution block. Use the five bolts to hold it in position. Evenly tighten the bolts to a torque of 35 Nm.




FIGURE 50. ASSEMBLY OF THE THROW-OUT MECHANISM

E. End cap	Q. Plunger	W. Restrictor
L. Plug	R. Retainer	X. Shim
M. Circlip	S. Washer	Y. Spring
N. Washer	T. Spring	Z. Ball
O. Spring	U. Piston	
P. Detent ball	V. Washer	




FIGURE 51. INSTALLATION OF THE LIVE TAKE-OFF VALVE

A. Distribution block	C. Cover
B. Live take-off valve	

Connect the operating rod (tractors with cab). Make sure that the spindle will move correctly in its bore. If the bolts have not been tightened evenly the spindle will not move correctly. Connect the inlet and outlet pipes to the valve body.

35 Nm = 3.5 kg m = 25 lb ft

TO TEST AND SET THE THROW-OUT MECHANISM

The throw-out mechanism can only be set when the live take-off valve is fitted to the tractor except where special equipment is available.

1. Remove any dirt from and around the live take-off valve. Connect the inlet pipe for the flowmeter to the rear port on the live take-off valve (see Figure 52.) Connect the outlet pipe from the flowmeter to the distribution block. If a flowmeter is not available, use a pressure gauge and screw type valve.
2. Start the engine. The oil must be at the correct operating temperature before you check the throw-out mechanism. To make the oil the correct temperature select TCU/EXT on the dial pointer. Run the engine at 1800 r/min. Push the quadrant lever forward into the full 'TCU' position and hold it there for 15 minutes. Do not hold the quadrant lever in the 'SELECT' position. If you do, air will get into the system and damage the pump.
3. Move the operating lever for the take-off valve until the detent balls engage. Look at the pressure gauge. Slowly close the valve until the throw-out mechanism moves the operating lever into its neutral position. Make a note of the pressure reading, it must be between 125–140 kg/cm². Do the following operations if the reading is not between the limits:
4. Disconnect the operating rod or lever from the spindle. Turn the end cap counterclockwise until it is free of the threads. Carefully pull the end cap and spindle clear of the valve body.
5. Hold the spindle vertically in a vice by its flats. Do not hold the spindle on a diameter.
6. Use circlip pliers to remove the circlip from its groove. Pull the end cap, circlip and washer clear of the spool. Be careful not to lose the detent balls when you do this. They will fall from their holes.




FIGURE 52. TESTING THE THROW-OUT MECHANISM

A. Take-off valve
B. Flowmeter

C. Union

R79-160




FIGURE 53. REMOVING THE THROW-OUT MECHANISM

C. Spring link

D. End cap

R79-161

125 kg/cm ²	= 12100 kPa	= 1750 lb/in ²
140 kg/cm ²	= 13800 kPa	= 2000 lb/in ²

7. Remove the plunger and spring from the retainer.
8. Put a rod through one of the holes in the retainer. Use this to turn the retainer counterclockwise until it is clear of the threads. Be careful when you do this. The spring is in compression, it will push the retainer off the spool.
9. Remove the retainer, washer, spring restrictor (if fitted) and shims from the spool.
10. If the pressure reading was more than 140 kg/cm² remove shims. The shims are 0.127 mm thick. If you remove one shim the pressure reading will be 14 kg/cm² less. If the pressure reading is less than 125 kg/cm² add shims. One shim will increase the pressure reading by 14 kg/cm².
11. Put a layer of grease on the spring 'N'. Fit the washers and spring on to the retainer. On early take-off valves the spring end of the retainer is flat. Apply grease to the shims then put them in position in the centre of the flat end of the retainer. Make sure that the shims are clear of the threads. Later take-off valves have a groove in the spring end of the retainer. Put a layer of grease on the restrictor (if fitted) and shims then fit them in the groove.
12. Fit the retainer assembly to the spool. Use a rod through one of the holes to turn the retainer clockwise. Do this until the retainer is tight.
13. Put the plunger, spring and washer into the retainer. Fit the circlip into its groove in the retainer.
14. Put grease on the detent balls then fit them into their holes in the retainer. The grease will hold the detent balls in position.
15. Carefully slide the end cap on to the retainer until it is against the detent balls. Hit the end cap with a soft hammer. The end cap will slide over the detent balls until they engage with a groove in the end cap.
16. Put grease into the assembly through the hole in the end cap. Fit the plug into the end cap.
17. Fit the spool and throw-out mechanism into the valve body. Turn the end cap clockwise until it is tight.
18. Connect the operating lever to the spool. Make sure that the spool will move correctly in the bore.
19. Repeat operations 1, 2 and 3 until the pressure reading is correct.

125 kg/cm ² = 12100 kPa = 1750 lb/in ²
140 kg/cm ² = 13800 kPa = 2000 lb/in ²
14 kg/cm ² = 1380 kPa = 200 lb/in ²
0.127 mm = 0.005 in




FIGURE 54. ASSEMBLING THE THROW-OUT MECHANISM

- | | | |
|------------|----------------|---------------|
| D. End cap | J. Plunger | O. Washer |
| E. Plug | K. Detent ball | P. Restrictor |
| F. Circlip | L. Retainer | Q. Shims |
| G. Washer | M. Washer | |
| H. Spring | N. Spring | |




FIGURE 55. INSTALLATION OF THE THROW-OUT MECHANISM

C. Spring link


D. End cap

SELECTAMATIC CONTROL VALVE

HOW IT WORKS

The selectamatic control valve is fitted inside the rear axle case on the right-hand side. The parts are as shown in Figure 56. There are eight

different valves in the body. The three main valves are, the by-pass valve, hold valve and the spool valve.



R79 163

FIGURE 56. SELECTAMATIC CONTROL VALVE

- | | |
|----------------------------|----------------------------------|
| A. <i>By-pass valve</i> | E. <i>Relief valve</i> |
| B. <i>Hold valve</i> | F. <i>TCU valve</i> |
| C. <i>Spool valve</i> | G. <i>Sensing valve</i> |
| D. <i>Non-return valve</i> | H. <i>Rate of lowering valve</i> |

The By-Pass Valve

The parts of the by-pass valve are assembled as shown in Figure 57. The plunger is held on its seat by a weak spring. When the oil reaches the valve, it pushes the plunger off its seat. Some of the oil flows through the hole in the plunger and out of the port towards the spool valve. In some positions the spool valve closes the port. When the port is closed the pressure of oil increases and pushes against the plunger. The plunger will go on its seat when the pressure of oil is equal on both sides of the plunger. When the spool valve opens the port, the pressure of oil in the port decreases and the plunger is pushed off its seat.




FIGURE 57. BY-PASS VALVE

- | | |
|-----------------|------------------------|
| A. Valve open | D. Port to spool valve |
| B. Valve closed | E. Outlet |
| C. Plunger | F. Inlet |

R76-50

The Hold Valve

The parts of the hold valve are assembled as shown in Figure 58. The valve works in the same way as the by-pass valve. The only difference is that a steel ball is fitted in the plunger. It is used as a non-return valve to stop oil flowing down through the plunger from its port.




FIGURE 58. HOLD VALVE

- | | | |
|-----------|------------------------|-----------|
| A. Inlet | C. Port to spool valve | E. Seat |
| B. Outlet | D. Plunger | F. Spring |


R76-52

The Spool Valve

This valve controls the by-pass and hold valves. It is connected to the quadrant lever. When the quadrant lever is moved to the 'RAISE' position, the oil flow is as shown in Figure 59. The spool valve closes the ports from both the by-pass and hold valves. Both the valves are held on their seats. The oil pushes the non-return valve 'D', off its seat and then flows to the ram cylinder. This will raise the linkage.

FIGURE 59. SPOOL VALVE WHEN THE QUADRANT LEVER IS IN THE 'RAISE' POSITION

- | |
|---------------------|
| A. Spool valve |
| B. By-pass valve |
| C. Hold valve |
| D. Non-return valve |
| E. Relief valve |
| F. Inlet |
| G. Outlet |
| H. To ram cylinder |



R76-51

When the quadrant lever is in the 'HOLD' position the oil will flow as shown in Figure 60. The spool valve opens the port from the by-pass valve. Only the hold valve is held on its seat. The oil flows past the by-pass valve and out of the body to the oil reservoir. There is a decrease

in the pressure of oil at the non-return valve. The spring in the valve pushes the plunger against its seat. No more oil goes to the ram cylinder and no oil will drain out of the cylinder. The linkage will stay in position.

FIGURE 60. SPOOL VALVE WHEN THE QUADRANT LEVER IS IN THE 'HOLD' POSITION

- A. Spool valve
- B. By-pass valve
- C. Hold valve
- D. Non-return valve
- E. Relief valve
- F. Inlet
- G. Outlet
- H. To ram cylinder





Figure 61 shows the oil flow when the quadrant lever is in the 'LOWER' position. The spool valve opens the by-pass and hold valve ports. Both their plungers are pushed off their seats. Oil from the pump flows past the by-pass valve

and out of the body. The weight of the linkage pushes the piston into the ram cylinder. The oil in the cylinder is pushed into the body and past the hold valve.

FIGURE 61. SPOOL VALVE WHEN THE QUADRANT LEVER IS IN THE 'LOWER' POSITION

- A. Spool valve
- B. By-pass valve
- C. Hold valve
- D. Non-return valve
- E. Relief valve
- F. Inlet
- G. Outlet
- H. From ram cylinder



Non-Return Valve

This valve is fitted between the by-pass valve and hold valve in the body. It is used to let the oil flow to the ram cylinder but stops oil returning to the body. The plunger is held on its seat by a spring and when:

- (a) there is weight on the linkage;
- (b) the by-pass valve is open (quadrant lever in 'HOLD' or 'LOWER' position);
- (c) the ram cylinder is full of oil;
- (d) the pump is not working.

The plunger is pushed off its seat when the by-pass valve is closed (quadrant lever in 'RAISE' position).




FIGURE 62. NON-RETURN VALVE

- A. Spool valve D. Non-return valve G. Outlet
- B. By-pass valve E. Relief valve H. To ram cylinder
- C. Hold valve F. Inlet

Relief Valve

A relief valve is fitted in the port between the hold valve and spool valve (see Figure 63). It is used to decrease high oil pressure between the ram cylinder, hold valve and spool valve. This occurs when you transport a heavy implement connected to the linkage, over rough ground. When the oil pressure increases, the relief valve opens and oil flows out. This makes the oil pressure in the port less than that on the other side of the hold valve. The plunger is then pushed off its seat. When the oil pressure decreases enough the relief and hold valves close.




FIGURE 63. RELIEF VALVE

- B. By-pass valve C. Hold valve E. Relief valve

The TCU Valve

The valve is fitted in the body as shown in Figure 64. It works when the selector dial is in the TCU/EXTERNAL position. The valve is used as a restrictor for the oil from the spool valve. The amount of restriction is controlled by the position of the quadrant lever. Moving the quadrant lever forward will increase the pressure of oil in the ports for the by-pass and hold valves. The plungers will slowly move on to their seats. Before they reach their seats some oil will get past the plungers from the ports. This oil is pushed into the ram cylinder, moving the linkage upwards by a small amount.

This will take the load off the implement and transfer it to the rear wheels of the tractor.




FIGURE 64. TCU VALVE

- A. Spool valve K. To by-pass valve
- G. Outlet L. To hold valve
- J. TCU valve

The Sensing Valve

This valve is fitted in the body as shown in Figure 65. It is used to actuate the by-pass valve for a small movement of the spool valve. When the spool valve is moved a small amount across the port, the increase in oil pressure will close the sensing valve. The pressure between the by-pass valve and sensing valve will increase and the by-pass valve will close. This occurs rapidly.

As soon as the oil pressure on the sensing valve decreases, the valve will open. The oil from the by-pass valve will flow and the by-pass valve will open. The sensing valve makes the by-pass valve open and close fast. If the movement is not fast, there will be damage to the hydraulic pump.

The fast movement of the plunger for the by-pass valve is not required when using TCU. The port from the TCU valve is on the spring side of the sensing valve. The TCU valve does not actuate the sensing valve in any position.

The Rate of Lowering Valve


This valve is controlled by the position of the lowering adjuster (see Figure 66). If the adjuster is turned clockwise, it goes into the body. This causes a restriction in the oil flow and increases the oil pressure in the port.

The plunger in the rate of lowering valve is pushed against its spring. The port from the hold valve is normally opposite a hole in the plunger. When the plunger is pushed against its spring the holes are not opposite. This causes a restriction in the flow of oil from the port. The linkage will lower slowly.


When the adjuster is turned counterclockwise, the hole in the plunger and port align. There is no restriction of oil and the linkage will lower rapidly.

FIGURE 66. RATE OF LOWERING VALVE

- C. Hold valve
- E. Relief valve
- G. Outlet
- H. Ram cylinder
- N. Rate of lowering valve
- O. Lowering adjuster



R76:55



R76:57

FIGURE 65. SENSING VALVE
A. Spool valve J. TCU valve
B. By-pass valve M. Sensing valve

REMOVAL OF THE SELECTAMATIC VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system. Remove the right-hand ramshaft bracket (see Page 70). Put the ramshaft bracket on a clean working surface. Remove the two bolts holding the

guide bracket 'A' to the ramshaft bracket. Pull the guide bracket clear and store. Remove the bolt 'B' and two nuts 'C'. Pull the selectamatic valve clear of the ramshaft bracket. Two dowels are used for location. If the valve will not easily pull off the bracket, lightly hit the valve with a rubber hammer. Do not use a blade or a screwdriver to separate the parts.




FIGURE 67. REMOVAL OF THE SELECTAMATIC VALVE

A. Guide bracket
B. Bolt

C. Nut
D. Ramshaft bracket

E. Selectamatic valve
F. Rocker lever

DISASSEMBLY OF THE SELECTAMATIC VALVE

Prepare a clean working surface where you can disassemble and store components of the selectamatic valve.

1. Carefully hold the valve body in a vice as shown in Figure 68. Do not tighten the vice too much.
2. Remove the screw 'J', plate 'K' and shims 'L'. Store these parts together. Do not discard the shims.
3. Remove the two nuts 'M' from the top of the spool valve. Pull out the spool and spring. Do not remove the sleeve for the spool. This can only be removed and installed with special equipment.
4. Remove the two plugs 'O' and sealing washers from the top of the hold and bypass valves. There will only be one plug if a dump valve was fitted over the hold valve (12 series only). Loosen the plug 'P' for the relief valve.




FIGURE 68. DISASSEMBLY OF THE SELECTAMATIC VALVE

J. Screw
K. Plate
L. Shims
M. Nuts

N. Spool
O. Plugs
P. Plug

5. Remove the valve body from the vice. Put a hand over the valve ports then turn the valve body (see Figure 69). A ball, spring and retainer will fall from the hold valve and by-pass valve. Earlier by-pass valves were fitted with a spring or a spring and metering pin. Use a 12 mm dowel made of plastic or wood to remove the plungers. Store the plungers with their parts.
6. Remove the plug 'P', spring, plunger, shims, seat and restrictor washer from the relief valve. Keep the parts together and the shims in sequence. The shims must be installed in the same sequence to keep the original pressure on the plunger.
7. Carefully hold the valve body in the vice and remove the plugs for the non-return and lowering valves. Loosen the plug for the sensing valve. Put a hand over the valve ports and remove the valve body from the vice. Turn the valve body until the plungers and springs for the two valves fall out.
8. Remove the plug, spring and plunger for the sensing valve.
9. Remove the ferrule, plunger, spring, ball and washer for the TCU valve.
10. Turn the lowering adjuster 'I' counter-clockwise until it is free of the threads.

NOTE: The remainder of the valves in the body must not be removed. They can only be replaced with special equipment.




FIGURE 69. REMOVING THE BY-PASS AND HOLD VALVES

A. By-pass valve B. Hold valve P. Plug




FIGURE 70. REMOVING THE RATE OF LOWERING AND NON-RETURN VALVE

D. Non-return valve H. Rate of lowering valve
G. Sensing valve I. Lowering adjuster




FIGURE 71. SELECTAMATIC CONTROL VALVE

A. By-pass valve
B. Hold valve
C. Spool valve
D. Non-return valve
E. Relief valve
F. TCU valve
G. Sensing valve
H. Rate of lowering valve
I. Lowering adjuster
J. Screw
K. Plate
L. Shim

12 mm = 0.5 in

INSPECTION AND REPAIR OF THE SELECTAMATIC VALVE

Clean the working surface. Wash all the components in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts. Do not use other cleaning fluids, they can damage the rubber seals.

Some by-pass valves are fitted with a metering pin (see Figure 73), the others have a nylon screen. Do the following to the valves with the nylon screen.

Remove the plug 'E' and washer 'C' from the plunger 'A'. Do not try to remove the nylon screen 'B'. Use air to clean the nylon screen from the spring side of the plunger (see Figure 72). Clean the washer and plug, then fit them in the plunger. Make sure that the plug is tight.

Before assembling the selectamatic valve, you must do the following test. Look at the plungers and bores for the hold and by-pass valves. If

NOTE: The by-pass valve for the S4 control valve is similar to that for the S5 and the S6 valve. Use the instructions for the S4 valve if an S5 or S6 valve is fitted.




FIGURE 72. CLEANING THE FILTER FOR THE BY-PASS VALVE

A. Plunger

there are any deep grooves you must fit a new selectamatic valve. The plungers and bores are matched at the factory. You cannot get a new plunger to fit in an old valve body. Slide the plunger for the hold valve into its bore. Lightly push the plunger on to its seat. Turn the plunger. If there is a restriction in either direction, remove it with lapping compound. Do not use any other compound. Repeat the operation for the by-pass valve.

FIGURE 73. ASSEMBLY OF THE BY-PASS VALVE

- A Plunger
- a Depth of bore
- B Nylon filter
- C Washer
- c Hole diameter
- D Gasket
- E Plug
- e Length of plug
- F Spring
- G Plug
- g Length of thread
- H Metering pin
- J Washer
- K Retainer
- L Steel ball

	K915356 (S2)	K944678 (S3)	K947765 (S4) (vertical grooves)	K947765 (S4) (grooves at an angle)
	Type 1	Type 2	Type 2	Type 3
a	31.75 mm (1.25 in)	25.4 mm (1.00 in)	25.4 mm (1.00 in)	25.4 mm (1.00 in)
B	K921154	—	K921154	K921154
C	K913621	K944289	K913621	K913621
c	0.51 mm (0.020 in)	1.75 mm (0.069 in)	0.51 mm (0.020 in)	0.51 mm (0.020 in)
D	—	K943899	—	—
E	K919634	K943901	K947759	K947759
e	11.81 mm (0.465 in)	9.02 mm (0.355 in)	5.71 mm (0.225 in)	5.71 mm (0.225 in)
F	K24832	K24832	K24832	K24832
G	K913242 (use K942892)	K942892	K942892	K948067
g	8.7 mm (0.344 in)	7.9 mm (0.311 in)	7.9 mm (0.311 in)	10.3 mm (0.406 in)
H	—	K944290	—	—
J	—	K626917	—	—
K	—	—	—	K947977
L	—	—	—	K11548


ASSEMBLY OF THE SELECTAMATIC VALVE

Clean the working surface. Wash the lapping compound from the valve body and plungers. Dry the parts in air.

1. Fit the spring on to the spool 'C'. Put a layer of clean oil on the spool. Push the spool and spring into the valve body. Fit the two nuts on to the threads of the spool. The position of the spool will be set later.
2. Put a layer of oil on to the plungers for the by-pass and hold valves. Fit the plungers in their bores. Put the steel ball, retainer and spring in the plunger for the hold valve. According to the type of by-pass valve fitted, put the parts into the plunger. Look at the sealing washers, if they are damaged, replace them. Fit the plugs and tighten.
3. Put clean oil on the plunger for the sensing valve. Fit the plunger, spring and plug to the valve body, making sure to tighten the plug.
4. Apply clean oil to the plunger for the non-return valve. Fit the plunger and spring into the valve body. Look at the sealing washer, if it is damaged fit a new one. Fit the plug and tighten.
5. Assemble the parts of the relief valve. Make sure that the plunger makes a good seal with its seat. If any of the parts are damaged, fit a new relief valve assembly. The new valve will have been set at the factory and will include the correct shims. Fit the restrictor washer, seat, shims, plunger and spring into the valve body. Make sure that the shims are fitted in their original sequence. Fit the plug and tighten.
6. Position the valve body so that the port for the TCU valve is at the top. Put the ball, washer, spring and plunger in the port. Fit the ferrule but do not tighten.
7. Fit the correct lowering adjuster. Use the lowering adjuster with $\frac{7}{8}$ UNC thread and the dome end (K944593) for S5 and S6 valves (see Figure 74). Use the lowering adjuster K920132 for all the other control valves. This adjuster has a $\frac{3}{4}$ UNC thread and a point at the end.

FIGURE 74. ASSEMBLY OF THE SELECTAMATIC CONTROL VALVE

- A. By-pass valve
- B. Hold valve
- C. Spool valve
- D. Non-return valve
- E. Relief valve
- F. TCU valve
- G. Sensing valve
- H. Rate of lowering valve
- J. Lowering adjuster



979 163

ADJUSTMENT OF THE SPOOL AND TCU VALVES

After the selectamatic valve has been assembled, the spool and TCU valves must be adjusted. A mark on the end of the spool will give the correct setting for the spool valve. The TCU valve setting is always the same.

ADJUSTMENT OF THE SPOOL VALVE

Make a note of the dimension on the end of the spool. Carefully hold the valve body in a vice with the spool valve horizontal. Put a dial gauge in the position shown in Figure 75. The probe of the dial gauge must be horizontal and in the centre of the spool. Make sure that the probe and spool make contact in this position. If they do not, the dial gauge will not show full movement of the spool.

Push the spool fully in. Adjust the dial gauge so that the pointer is at zero. Let the spring on the spool valve slowly push the spool out. Note the movement of the pointer of the dial gauge. Compare the pointer movement with the dimension given on the spool. If the pointer movement is more than the given dimension, tighten the nuts. If the pointer movement is less, loosen the nuts. Repeat the operation until the pointer movement is no more than 0.025 mm different to that of the given dimension. The pointer movement must not be less than the given dimension.




FIGURE 75. ADJUSTMENT OF THE SPOOL VALVE
A. Spool B. Dial gauge

ADJUSTMENT OF THE TCU VALVE

Carefully hold the valve body in a vice with the TCU plunger vertical. Tighten the ferrule until the plunger has almost no movement, then loosen the ferrule two thirds of a rotation. Put a dial gauge in the position shown in Figure 76. The probe of the dial gauge must be vertical and in the centre of the plunger. Make sure that the probe and the plunger make contact in this position. If they do not the dial gauge will not show the full movement of the plunger. Lift the plunger with pliers until it is against the ferrule. Hold the plunger in this position and adjust the dial gauge so that the pointer is at zero. Let the plunger fall slowly. Note the movement of the pointer. The plunger must move between 0.86–1.00 mm. If the pointer movement is more, tighten the ferrule by a small amount. If the pointer movement is less, loosen the ferrule by a small amount. Repeat the operation until the movement of the plunger is correct.




FIGURE 76. ADJUSTMENT OF THE TCU VALVE
A. TCU plunger B. Dial gauge

0.025 mm	= 0.001 in
0.86 mm	= 0.034 in
1.00 mm	= 0.040 in

STOP PLATE SETTING

1. Fit the original shims and stop plate 'A' on to the valve body (see Figure 78). Make sure that the shims and the stop plate are on their seat. Use the screw 'B' to hold the shims and plate in position. Make sure that the screw is tight.
2. Fit the selectamatic valve to the ramshaft bracket. Select 'TCU/EXT' on the dial pointer.
3. Put the setting gauge into the position shown in Figure 78. The top hole in the setting gauge (hole 'A' Figure 77) must be engaged with the pin for the rocker shaft. The flat face of the setting gauge must be against the shoulder on the ramshaft bracket.
4. Move the rocker so that it is against the stop plate. Use feeler gauges to measure the clearance between the rocker and the spool valve. The clearance must be between 0.025–0.075 mm.
5. Add or remove the shims under the stop plate to make the clearance correct. Make sure that the stop plate and the shims are on their seat before tightening the screw.




FIGURE 77. SETTING GAUGE
X = 11.1 mm Y = 40.1 mm




FIGURE 78. STOP PLATE SETTING
A. Stop plate D. Feeler gauge
B. Screw E. Rocker
C. Setting gauge

TCU SCREW SETTING

1. Fit the selectamatic valve to the ramshaft bracket. Select 'TCU/EXT' on the dial pointer.
2. Put the setting gauge into the position shown in Figure 79. The bottom hole in the gauge (hole 'B' Figure 77) must be engaged with the pin for the rocker shaft. The flat face of the setting gauge must be against the shoulder of the ramshaft bracket.
3. Turn the nut on the end of the TCU screw counterclockwise until it is at the end of the threads. Put a 0.05 mm feeler gauge between the TCU screw and the spool for the TCU valve.
4. Turn the ramshaft bracket through 180° so that the dial pointer is at the top.
5. Turn the TCU screw clockwise until it just comes in contact with the feeler gauge. Remove the feeler gauge then turn the TCU screw a further one rotation clockwise. Do not turn the screw more than one rotation clockwise.
6. Turn the nut clockwise until it is against the rocker.

0.025 mm	= 0.001 in
0.050 mm	= 0.002 in
0.075 mm	= 0.003 in
11.1 mm	= 0.437 in
40.1 mm	= 1.580 in




FIGURE 79. TCU SCREW SETTING
A. TCU screw D. Rocker
B. Setting gauge E. Spool valve
C. Feeler gauge

DIAL POINTER MECHANISM

HOW IT WORKS

The dial pointer mechanism is fitted inside the right-hand ramshaft bracket. It is used to change the controls for the selectamatic valve. To select a new position for the dial pointer do the following:

- move the quadrant lever to the 'SELECT' position;
- turn the dial pointer to the required position then release the quadrant lever.

When the dial pointer is in the 'DEPTH' position the rocker lever 'B' is against the spool valve. The other end of the rocker lever is connected to the cable for the sensing unit. When the cable moves, the rocker lever changes the position of the spool valve. This will actuate the other valves in the valve body and keep the implement at the correct depth.

Moving the dial pointer from the 'DEPTH' position will move the rocker lever away from the spool valve. The linkage will now be controlled by the quadrant lever only.

REMOVAL OF THE DIAL POINTER MECHANISM

Tractors With and Without Cab

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Remove the ramshaft and right-hand ramshaft bracket (see Page 70). Remove the two nuts which hold the cam on to the right-hand end of the ramshaft. Put the ramshaft bracket on a clean working surface. Remove the two bolts holding the guide bracket 'E' to the ramshaft bracket. Pull the guide bracket clear. Remove the bolt 'F' and two nuts 'G'. Pull the selectamatic valve clear of the ramshaft bracket. Two dowels are used for location. If the valve will not easily pull off the bracket, lightly hit the valve with a rubber hammer. Do not use a blade or a screwdriver to separate the parts.




FIGURE 80. DIAL POINTER MECHANISM


- | | |
|---------------------|-----------------------|
| A. Dial pointer | E. Guide bracket |
| B. Rocker lever | F. Bolt |
| C. Ramshaft bracket | G. Nut |
| D. Cam | H. Selectamatic valve |

R76-99

DISASSEMBLY OF THE DIAL POINTER MECHANISM

Prepare a clean working surface where you can disassemble and store components of the dial pointer.

1. Carefully remove the pin 'A' from the selector fork. Do not bend the selector rod when you do this.
2. Remove the plug 'B' from the side of the bracket. Use a drift through the hole for the plug, to push the selector rod. Do this until the selector fork can be pulled off the selector rod. Remove the selector fork from the bracket then push the selector rod completely out of the bracket. A detent ball will fall from its hole when you remove the selector rod. Turn the bracket until the spring falls from the hole.
3. Remove the screw 'G' which holds the rocker shaft in position. Pull the rocker lever off the rocker shaft. Turn the rocker shaft until the arm is vertical, then pull the rocker shaft into the bracket. Remove the rocker shaft from the bracket.
4. Remove the pin from the pointer then pull the pointer off the shaft (tractors without cab). Push the shaft downwards and out of the bracket.
5. Remove the two screws which hold the panel to the bracket, then remove the panel breather and 'O' ring.




R79-237

FIGURE 81. DISASSEMBLY OF THE DIAL POINTER MECHANISM

- | | |
|------------------|-----------------|
| A. Pin | G. Screw |
| B. Plug | H. Rocker lever |
| C. Selector rod | J. Rocker shaft |
| D. Selector fork | K. Pointer |
| E. Detent ball | L. Breather |
| F. Spring | M. Bearing |

ASSEMBLY OF THE DIAL POINTER MECHANISM


1. Look at the bearing for the ramshaft. If it is damaged fit a new bearing. Push the bearing into the bracket to remove it from its bore. When you fit a new bearing align the small hole in the bearing with the grease fitting. The groove in the bearing must be towards the rear axle.
2. Fit the 'O' ring, breather and panel to the top of the ramshaft bracket. Use the two screws to hold the parts in position.
3. Put a little oil on the shaft. Fit the shaft inside of the bracket. Fit the pointer on to the shaft. Use the pin to hold it in position (tractors without cab). Make sure that the pointer and shaft will turn easily.
4. Put a little oil on the rocker shaft. Turn the rocker shaft so that the arm is vertical then fit it in position in the ramshaft. Push the rocker lever on to the rocker shaft. Make sure that the rocker lever is in the position as shown in Figure 82. Fit the screw into the ramshaft bracket to hold the rocker shaft in position.
5. Put the spring and detent ball into the hole. Put oil on the selector shaft. Push the plain end of the selector shaft through the hole in the right-hand side of the ramshaft bracket. Do this until the end of the shaft is against the detent ball. Use a punch through the hole to hold the detent ball against its spring. Push the selector rod towards the inside of the ramshaft bracket then slowly remove the punch.
6. Fit the selector fork on to the rocker lever. Push the selector rod through the hole in the selector fork. Align the small hole in the selector fork with the hole in the selector rod. Fit the pin into the hole. Make sure that you can select any of the positions with the dial pointer.
7. Put the dial pointer into the 'TCU/EXT' position. Apply a little Loctite 270 grade to the plug with the threads. Fit the plug into its hole in the left-hand side of the ramshaft bracket. The plug is used as a stop for the selector rod. Turn the plug clockwise until it is against the end of the selector rod. Turn the plug $\frac{1}{2}$ of a rotation counterclockwise. Hit the edge of the hole with a hammer and a punch to lock the plug in position.
8. Fit a new plug into the hole for the selector rod in the right-hand side of the ramshaft bracket.



R79 237

FIGURE 82. ASSEMBLY OF THE DIAL POINTER MECHANISM

- | | |
|------------------|-----------------|
| A. Pin | G. Screw |
| B. Plug | H. Rocker lever |
| C. Selector rod | J. Rocker shaft |
| D. Selector fork | K. Pointer |
| E. Detent ball | L. Breather |
| F. Spring | M. Bearing |



R76 99

FIGURE 83. INSTALLATION OF THE DIAL POINTER MECHANISM

- | | |
|---------------------|-----------------------|
| A. Dial pointer | E. Guide bracket |
| B. Rocker lever | F. Bolt |
| C. Ramshaft bracket | G. Nut |
| D. Cam | H. Selectamatic valve |

INSTALLATION OF THE DIAL POINTER MECHANISM

Put grease on the bearing in the ramshaft bracket. Fit the selectamatic valve and the guide bracket to the right-hand ramshaft bracket. Do the settings for the stop plate and the TCU screw (see Page 42). Slide the right-hand ramshaft bracket on to the ramshaft. Fit the cam on to the end of the ramshaft. Use the two nuts to hold it in position. Install the ramshaft brackets and the ramshaft on to the rear of the tractor (see Page 70). Set the position of the cam and the position of the Nyloc nut on the end of the control rod. Set the cable for the sensing unit (see Page 65).

DUMP VALVE

HOW IT WORKS

A dump valve can be fitted in the hydraulic system. It is used to make the lowering of the linkage rapid. Two different types of dump valve are fitted, according to the tractor model.

12 SERIES TRACTORS

On 12 series tractors, the dump valve is fitted on top of the hold valve. When the knob is pushed down, the spring in the hold valve is put in compression (see Figure 84.) In this position the hold valve will work normally. The knob must be turned to keep the spring in compression. To use the dump valve, turn the knob and pull it up. This will release the spring. The pressure of the oil from the ram cylinder will now push the plunger for the hold valve off its seat. The linkage will lower rapidly with little or no weight connected.

REMOVAL OF THE DUMP VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Tractors Without Cab

Pull the knob up to lower the linkage. Turn the valve body counterclockwise, then pull it clear of the selectamatic valve. Put a cover over the port for the dump valve. Make sure that dirt does not get into the selectamatic valve. If it does there will be failure of the system.

Tractors With Cab

Pull the operating lever up to lower the linkage. When the linkage is at its lowest position, push the operating lever down. Remove the spring clip 'A' (see Figure 86). Pull the operating lever up. This will lift the rod clear of the dump valve. Turn the valve body counterclockwise then pull it clear of the selectamatic valve. Put a cover over the port for the dump valve. Make sure that dirt does not get into the selectamatic valve. If it does there will be failure of the system.




FIGURE 84. DUMP VALVE FOR 12 SERIES TRACTORS

- A. Knob
- B. Spring
- C. Hold valve
- D. Valve closed
- E. Valve open




FIGURE 85. REMOVAL OF THE DUMP VALVE

- A. Dump valve




FIGURE 86. REMOVAL OF THE DUMP VALVE

- A. Spring clip
- B. Dump valve

REPLACEMENT OF SEALS FOR THE DUMP VALVE

The seals must only be replaced if there is leakage from the valve.

1. Carefully hold the body of the dump valve in a vice.
2. Pull the knob 'A' up. Turn the nut 'B', counterclockwise until it is free of the thread. Pull the knob to remove the locating bush and plunger from the valve body.
3. Remove the pin 'C' from the knob and separate the parts.
4. Remove and destroy all 'O' rings and anti-extrusion rings.

NOTE: *Anti-extrusion rings were not fitted to early dump valves. Their parts cannot be used in later valves.*

5. Wash all the parts in clean paraffin or fuel oil and dry in air.
6. Fit new anti-extrusion rings (if used) and 'O' rings to the plunger and locating bush. Make sure that the rings are in the correct position and are not twisted. Apply a layer of grease to the rings.
7. Fit the locating bush in position on the plunger. Put a new 'O' ring on the plunger against the locating bush, then put the nut on the plunger. Fit the knob on the plunger and carefully push the pin in the hole.
8. Fit the plunger, nut and knob to the body of the dump valve. Tighten the nut and make




FIGURE 87. DUMP VALVE FOR 12 SERIES TRACTORS

- | | |
|---------|------------------------|
| A. Knob | E. Plunger |
| B. Nut | F. Body |
| C. Pin | G. 'O' ring |
| D. Bush | H. Anti-extrusion ring |

sure that the knob will move up and down correctly.

9. Fit a new 'O' ring on the outside of the valve body. Make sure the 'O' ring is not twisted and is on its seat. Apply a little grease to the 'O' ring.

INSTALLATION OF THE DUMP VALVE

Fit a new sealing ring to the end of the valve body. Hold it in position with a little grease. Carefully fit the dump valve to the selectamatic valve. Make sure that the spring for the hold valve is in the centre of its bore. Turn the body for the dump valve clockwise and tighten. Connect the operating rod (tractors with cab).

HOW IT WORKS

14 SERIES TRACTORS

The dump valve on 14 series tractors is fastened to the front end of the ram cylinder. When the knob is pushed down, the dump port is closed. The hydraulic system will work normally when the plunger is in this position (see Figure 88). When the knob is pulled up, the dump port is open. Oil from the ram cylinder will now flow through the dump port and past the plunger. The oil pressure in the ram cylinder will decrease and the linkage will lower rapidly. The oil does not have to flow through the selectamatic valve. The quadrant lever can, therefore, be in any position. When the dump port is open the linkage will lower with little or no weight connected.




FIGURE 88. DUMP VALVE FOR 14 SERIES TRACTORS

- | | |
|------------|-----------------|
| A. Knob | C. Valve closed |
| B. Plunger | D. Valve open |

REMOVAL OF THE DUMP VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Tractors Without Cab

Pull the knob up to lower the linkage. Remove the two screws 'A', (see Figure 89.) and pull the dump valve clear. Put a cover over the end of the ram cylinder. Make sure that dirt does not get into the system. If it does there will be failure of the system.

Tractors With Cab

Pull the operating lever up to lower the linkage. Remove the split pin 'A' and clevis pin 'B'. Pull the cable so that it is clear of the extension 'C'. Remove the two bolts 'D' which hold the support bracket to the ram cylinder. Pull the support bracket upward so that it is clear of the extension. Remove the spring then pull out the pin 'E'. The extension and cap 'F' can now be removed. Remove the two screws which hold the dump valve to the ram cylinder. Pull the dump valve clear of the ram cylinder. Put a cover over the end of the ram cylinder. Make sure that dirt does not get into the system. If it does there will be failure of the system.

REPLACEMENT OF SEALS FOR THE DUMP VALVE

The seals in this valve must only be replaced if there is leakage.

1. Remove the pin 'A' and knob 'B' from the plunger (see Figure 91). From the knob end, push the spindle out of the valve body.
2. Remove and destroy all anti-extrusion rings and 'O' rings.
3. Wash all the parts in clean paraffin or fuel oil and dry in air.
4. Fit new anti-extrusion rings and 'O' rings to plunger. Make sure that they are in the correct position and are not twisted. Apply a little grease to the rings.
5. Push the plunger into the body of the dump valve. Fit knob and plunger and carefully push the pin into the hole.
6. Make sure that the knob will move up and down correctly.

INSTALLATION OF THE DUMP VALVE

Fit a new 'O' ring into the groove in the end of the ram cylinder. Put the dump valve in position then push the knob down. This will position the plunger in the bore. Fit the two screws and tighten. Fit the cap, extension, pin, spring and support bracket. Connect the cable to the extension (tractors with cab).




FIGURE 89. REMOVAL OF THE DUMP VALVE

A. Screw

B. Dump valve




FIGURE 90. REMOVAL OF THE DUMP VALVE FOR TRACTORS WITH CAB

A. Split pin
B. Clevis pin
C. Extension

D. Bolt
E. Pin
F. Cap




FIGURE 91. DUMP VALVE FOR 14 SERIES TRACTORS

A. Pin
B. Knob
C. Body

D. Spindle
E. 'O' ring
F. Anti-extrusion ring

THREE-WAY VALVE

HOW IT WORKS

The three-way valve is fitted on to the end of the ram cylinder. It is between the selectamatic valve and ram cylinder in the system (see Figure 1). A lever is connected to the spool in the valve and can be moved into four different positions.

When the lever is in the '1' position, the oil flow is as shown in Figure 92. Oil enters the valve at the inlet port 'A', and leaves from the number 1 (top) take-off port. No oil will flow to the ram cylinder. The quadrant lever will not actuate the linkage when the spool is in this position.

Figure 93 shows the oil flow when the lever is in the '2' position. When the spool is in this position the oil leaves the valve from the number 2 (bottom) take-off port. No oil will flow to the ram cylinder.

The spool closes both the take-off ports when the lever is in the 'L' (linkage) position. The oil flows out of the valve through the outlet port 'B' to the ram cylinder (see Figure 94). The quadrant lever will actuate the linkage. Any equipment attached to the three-way valve will stay in position.

When the lever is in the 'L/1' position, oil will flow to both the number 1 take-off port and the ram cylinder (see Figure 95). The quadrant lever will actuate the tractor linkage and equipment connected to the number 1 take-off port.

REMOVAL OF THE THREE-WAY VALVE

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Lower the linkage (and any equipment attached to the three-way valve) to the ground.

Remove the two bolts holding the inlet pipe 'A', to the valve body (see Figure 96). Carefully pull the pipe clear. Disconnect any pipes connected to the take-off ports. Put covers over the pipes. Remove the four bolts holding the three-way valve to the ram cylinder.




FIGURE 92. LEVER IN THE '1' POSITION




FIGURE 93. LEVER IN THE '2' POSITION




FIGURE 94. LEVER IN THE 'L' POSITION




FIGURE 95. LEVER IN THE 'L/1' POSITION




FIGURE 96. REMOVAL OF THE THREE-WAY VALVE
A. Inlet pipe
B. Ram cylinder
C. Three-way valve
D. 'O' ring

DISASSEMBLY OF THE THREE-WAY VALVE

Prepare a clean working surface where you can disassemble and store components of the selectamatic valve.

1. Carefully hold the valve in a vice as shown in Figure 97. Move the lever into the '1' position. Remove the two screws 'A', holding the flange in position. Remove the knob and pull the lever clear of the valve body.
2. Use a dowel made of wood or plastic to push the spool down. Do this until the spool is clear of the detent balls. The breather will be pushed out of the valve body and the bottom 'O' ring out of the bore. Remove the 'O' ring from the spool. Destroy the 'O' ring and breather. A backup ring is fitted to later spool valves. Remove and destroy the backup ring.
3. Remove the three bolts holding the cover 'D' on to the valve body. Carefully pull the cover clear of the valve body keeping the detent balls and springs in position.
4. Push the spool upwards and out of the body. Remove and destroy the top 'O' ring.

INSPECTION AND REPAIR OF THE THREE-WAY VALVE

Clean the working surface. Wash all the components in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the ports.

Look at the spool and its bore. If there are any grooves in either, you must fit a new three-way valve. The spool and bore are matched at the factory. You cannot get a new spool to fit an old valve body. If there is no damage, slide the spool into the bore. Turn the spool in the bore. If there is any restriction remove it with lapping compound. Do not use emery cloth or any other compound.

ASSEMBLY OF THE THREE-WAY VALVE

Clean the working surface. Wash any lapping compound from the valve body and plunger. Dry the parts in air.

1. Fit a new 'O' ring 'G' to the spool. Put clean oil on the spool (see Figure 99).
2. Push the spool into the bore from the top of the valve body. Do this until the groove for the bottom 'O' ring is clear of the bore.

NOTE: Do not push the spool too far into the bore. If you do, the top 'O' ring 'G' will get damaged in the top take-off port. This will result in leakage.

3. Fit a new backup ring 'H' and 'O' ring 'J' into the groove on the spool. The backup ring must be at the bottom of the groove. Push the spool upwards into the working




FIGURE 97. DISASSEMBLY OF THE THREE-WAY VALVE
A. Screw B. Knob C. Lever




FIGURE 98. DISASSEMBLY OF THE THREE-WAY VALVE
D. Cover E. Spool F. Breather




FIGURE 99. ASSEMBLY OF THE THREE-WAY VALVE
E. Spool G. 'O' ring

position. The hole for the lever must be in the position shown in Figure 100.

NOTE: The back-up ring was not fitted to earlier spools. To fit the back-up ring you must increase the bottom groove. Use a grinding wheel to remove 0.38 mm of metal from each side of the groove. The new width will be 4.36 mm. Make radii at the bottom of the groove 0.51-0.76 mm the top of the groove 0.13 mm-0.25 mm. The modification will stop leakage from the bottom of the spool.

4. Fit a new breather 'F' in the bottom of the bore. Use a socket or a tube to make the breather a tight fit in the bore.
5. Put a layer of grease on a new gasket and fit it in position on top of the valve body.
6. Remove the screw 'L' from the cover. Put a spring and detent ball into the small hole.
7. Hold the valve body vertically on the working surface. Do this so that the spindle cannot push the breather out of position. Fit the cover to the valve body using a screwdriver to hold the detent ball against its spring. The detent ball must engage with the groove in the spool. It must not go into the hole for the lever. Use the three screws to hold the cover in position.
8. Put grease on the ball end of the lever. Fit the lever to the spool and hold in position with the two screws. Fit the knob to the lever. Make sure that the lever and spool will move into the four positions.
9. Fit the detent ball and spring into the hole in the cover. Put a layer of Loctite 270 grade on to the screw then fit it into the hole. Turn the screw until it is just against the spring, then turn it a further $2\frac{1}{4}$ rotations clockwise.
10. Put a cover over the inlet and outlet ports.

INSTALLATION OF THE THREE-WAY VALVE

Before installing the three-way valve make sure that the 'O' ring in the ram cylinder and inlet pipe are not damaged. Replace them if they are damaged. Make sure that the faces of the three-way valve, ram cylinder and inlet pipe are clean.

Use the four bolts to hold the valve body to the ram cylinder. Tighten the bolts evenly to a torque of 35 Nm. Connect the inlet and any take-off pipes.

0.13 mm	= 0.005 in
0.25 mm	= 0.010 in
0.38 mm	= 0.015 in
0.51 mm	= 0.020 in
0.76 mm	= 0.030 in
4.36 mm	= 0.172 in
35 Nm	= 3.5 kg m = 25 lb ft




FIGURE 100. ASSEMBLY OF THE THREE-WAY VALVE
H. Backup ring J. 'O' ring K. Hole for lever




FIGURE 101. ASSEMBLY OF THE THREE-WAY VALVE
D. Cover L. Screw M. Detent ball N. Spring




FIGURE 102. ASSEMBLY OF THE THREE-WAY VALVE
C. Lever D. Cover L. Screw

SUPPORT RAM FOR THE LINKAGE

HOW IT WORKS

The support ram is used as a support for the linkage when using heavy implements. It can only be fitted to 12 series tractors. A larger ram cylinder and ramshaft assembly are fitted to 14 series tractors. These parts are strong enough to lift heavy implements. The support ram is fastened to the right-hand lift arm and drawbar frame (see Figure 103).

NOTE: On early 4WD tractors fitted with internal hydraulic filter, the support ram was fastened to the left-hand lift arm.

A pipe connects the support ram to the number 1 (top) take-off port on the three-way valve. When the control lever for the three-way valve is in the L/1 position, the ram cylinder and support ram will work together.

REMOVAL OF THE SUPPORT RAM

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Put the control lever for the three-way valve into the L/1 position. Move the quadrant lever to the 'LOWER' position. This will lower the linkage to the ground and decrease the amount of oil in the support ram. Disconnect the oil pipe from the support ram. Remove the bolts 'A' and 'B' (see Figure 103).

DISASSEMBLY OF THE SUPPORT RAM

Prepare a clean working surface where you can disassemble and store components of the support ram.

1. Carefully hold the support ram in a vice as shown in Figure 104. Do not tighten the vice too much.
2. Use a screwdriver to remove the seal 'F' from the end of the ram case.
3. Remove the circlip 'G' from its groove in the ram case. To do this, compress the circlip using circlip pliers, then pull the ram rod. The sleeve 'H' will push the circlip clear of its groove.
4. Pull the ram rod clear of the ram case.
5. Remove the two circlips 'J', stop ring 'K' and sleeve 'H' from the end of the ram rod.

NOTE: Do not hold the ram rod in a vice. The jaws of the vice will cause damage to the ram rod. This will result in leakage.




FIGURE 103. SUPPORT RAM FOR THE LINKAGE
A. Bolt
B. Bolt
C. Support ram
D. Lift arm




FIGURE 104. DISASSEMBLY OF THE SUPPORT RAM
E. Ram rod
F. Seal
G. Circlip
H. Sleeve




FIGURE 105. DISASSEMBLY OF THE SUPPORT RAM
E. Ram rod
H. Sleeve
J. Circlip
K. Stop ring

REPLACEMENT OF SEALS FOR THE SUPPORT RAM

1. Remove and destroy all seals in the support ram.
2. Wash all the parts in clean paraffin or fuel oil and dry in air. Do not use a cloth to dry the parts.
3. Put the new leather rings in clean engine oil for at least 30 minutes. This will make the rings soft so that you can fit them in position without damage. If the rings are damaged, there will be leakage.
4. Put the small leather ring in groove 'W' (Figure 106). The smooth face must be towards the other groove. Make sure that the leather ring is on its seat and is not twisted.
5. Put the small 'O' ring in groove 'W'. Make sure that the 'O' ring is on its seat and is not twisted. Check that the rough face of the leather ring is against the 'O' ring. Apply clean oil to the rings.
6. Put the larger leather ring in groove 'Y'. The smooth face must be towards the other groove 'Z'. Make sure that the leather ring is on its seat and is not twisted.
7. Put the larger 'O' ring in groove 'Y'. Make sure that the 'O' ring is on its seat and is not twisted. Check that the rough face of the leather ring is against the 'O' ring.
8. Fit the Nu-lip seal in groove 'X'. Make sure that the edges of the seal are not damaged.

ASSEMBLY OF THE SUPPORT RAM

1. Apply clean oil to the ram rod, then fit a new seal and circlip.
2. Carefully, slide the sleeve 'H' and its seals on to the ram rod. The end of the ram rod has got a chamfer. This will make it easier to fit the seal.
3. Fit the stop ring 'K' and the two circlips.
4. Carefully, hold the ram case horizontally in a vice. Do not tighten the vice too much.
5. Put thick grease into the groove for the circlip. Do this to prevent the seals on the outside of the sleeve being damaged by the edges of the groove. Put some clean oil on the outside of the sleeve.
6. Put the circlip in groove 'Z' in the sleeve. The small holes in the circlip must be against the flat on the sleeve. Do this so that you can use circlip pliers to compress the circlip.
7. Fit the ram rod into the ram case. Take care when you push the sleeve past the groove for the circlip in the ram case.
8. Compress the circlip then push the ram rod further into the ram case until the circlip is in its groove.




FIGURE 106. FITTING SEALS TO THE SLEEVE

L. 'O' ring
M. Leather ring
N. 'O' ring
O. Leather ring
P. Nu-lip seal




FIGURE 107. ASSEMBLY OF THE SUPPORT RAM

E. Ram rod
F. Seal
G. Circlip
H. Sleeve
J. Circlips
K. Stop ring




FIGURE 108. ASSEMBLY OF THE SUPPORT RAM

E. Ram rod
F. Seal
G. Circlip
H. Sleeve

9. Push the seal 'F' on to the sleeve until the lip on the inside is in the groove 'V'.

INSTALLATION OF THE SUPPORT RAM

Look at the bushes in the end of the ram rod and ram case. If they are worn, fit new bushes. Put a layer of grease on the bushes. Push the bolts through the lift arm and the drawbar frame. Fit the washers and nut. Make sure that the nuts are tight.

SENSING UNIT

Three alternative sensing units are fitted:

- (a) Single Rate Sensing Unit.
- (b) Adjustable Sensing Unit.
- (c) Selective Sensing Unit.

Sensing units (b) and (c) have a range of adjustment for different weights of implement.

All three units control the depth of the implement by sensing the draft forces which are sent through the linkage. All three units can also control the height of the linkage by sensing from a cable connected to a cam on the end of the ramshaft. Either system of sensing can be selected by the dial pointer.




FIGURE 109. SENSING UNIT

- A. Sensing unit
- B. Top link
- C. Lower link
- D. Plough

SINGLE RATE SENSING UNIT

HOW IT WORKS

The parts for this sensing unit are as shown in Figure 110. They are similar to the parts for the adjustable sensing unit. The single rate sensing unit has one spring and is used for light to medium draft implements. It has only one setting and works as described above.




FIGURE 110. SINGLE RATE SENSING UNIT

- A. Spring
- B. Shaft

REMOVAL OF THE SINGLE RATE SENSING UNIT

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system.

Disconnect the cable from the sensing unit. Remove the pin which holds the top link to the sensing unit. Store the top link and pin together. Remove the bolts which hold the sensing unit to the PTO case. Make a note of the position of the bolts, they are not all the same length. Put a cover over the holes in the PTO case.

DISASSEMBLY OF THE SINGLE RATE SENSING UNIT

Prepare a clean working surface where you disassemble and store components of the sensing unit.

1. Carefully hold the housing in a vice. Do not tighten the vice too much.
2. Remove the screws which hold the end cover 'A' on to the housing 'B'. Put a bar through the hole in the end of the shaft, then pull the shaft assembly clear of the housing.

NOTE: Do not use a screwdriver or blade to separate the end cover and the housing. There are shims between the end cover and the housing. They must not be damaged.




FIGURE 111. REMOVAL OF THE SINGLE RATE SENSING UNIT
A. Cable




FIGURE 112. DISASSEMBLY OF THE SINGLE RATE SENSING UNIT
A. End cover B. Housing




FIGURE 113. DISASSEMBLY OF THE SINGLE RATE SENSING UNIT

- | | | | |
|--------------|------------------|-----------|-------------|
| A. End cover | D. Collar | G. Sleeve | K. 'O' ring |
| B. Housing | E. Thrust washer | H. Shims | L. Plug |
| C. Pin | F. Spring | J. Shaft | |

3. To disassemble the shaft assembly remove the pin 'C' from the collar 'D'. Remove the collar, thrust washer 'E' and spring 'F' from the shaft.
4. Carefully hold the sleeve 'G' in a vice, with the flats of the sleeve vertical. Turn the shaft counterclockwise until it is free of the threads.
5. Remove the shims, end cover and 'O' ring from the shaft. Destroy the 'O' ring. Do not destroy the shims, they must be fitted in their original position.
6. Wash all the parts in clean paraffin or fuel oil and dry in air.

ASSEMBLY OF THE SINGLE RATE SENSING UNIT

1. Make sure that the end cover will slide on to the sleeve. Fit a new 'O' ring in the end cover, then put a layer of grease on the 'O' ring and bore.
2. Put a little Loctite 270 grade on the thread of the shaft. Fit the end cover and sleeve on to the shaft. Carefully hold the sleeve in a vice, flats vertical, turn the shaft clockwise to tighten.
3. Fit the spring, thrust washer and collar to the shaft. Push the pin through the collar and the shaft. The protrusion of the pin must be equal at both sides of the collar. Fit the shaft assembly into the housing. The pin must slide in the grooves without restriction. Remove any restriction with a file.
4. Remove the shaft from the housing and check the movement of the thrust washer. It must be able to move up to 0.25 mm easily on the length of the shaft. If the movement is less, replace the thrust washer with a thinner thrust washer. If the movement is more, replace the thrust washer with a thicker thrust washer.
5. Put some grease on the collar and the pin.
6. Fit the original shims against the end cover. Put the shaft assembly into the housing, then use the screws to hold the end plate in position.

7. Evenly tighten the screws to a torque of 42 Nm. Check the movement of the shaft after each rotation of the screws. When the screws are tight, the shaft must be able to move 0.25 mm easily in the housing. Use different shims to get the correct movement. If the movement of the shaft gets less then more as you tighten the screws, the spring is being compressed. This must not happen. Add shims until the movement is correct.
8. Put grease in the collar end of the bore then put jointing compound on the plug. Fit the plug into the housing. Connect a grease gun to the fitting and operate it three times.

INSTALLATION OF THE SINGLE RATE SENSING UNIT

Remove the cover from the PTO case. Clean the surface then fit a new gasket and the sensing unit. Fit the four bolts in their original position and tighten to a torque of 105 Nm. Connect and adjust the cable (see Page 65).

LUBRICATION OF THE SINGLE RATE SENSING UNIT

Connect a grease gun to the fitting on the housing. Operate the grease gun three times. Do this after every 60 hours of work.

ADJUSTABLE SENSING UNIT

HOW IT WORKS

This unit can be adjusted to four different settings according to the position of the links 'A' and the top link attachment point as follows:

Heavy Draft

For heavy draft setting the links 'A' and the top link are connected to the sensing unit as shown in Figure 114. The maximum forces for this setting are 2640 kg in compression and 1588 kg in tension. Select this setting for heavy chisel ploughs, sub-soilers, multi-furrow mouldboards and disc ploughs.

2640 kg = 5830 lb
1588 kg = 3500 lb
42 Nm = 4.2 kg m = 30 lb ft
105 Nm = 10.5 kg m = 76 lb ft
0.25 mm = 0.010 in




FIGURE 114. ADJUSTABLE SENSING UNIT
ADJUSTED FOR HEAVY DRAFT IMPLEMENTS

A. Link	C. Top link
B. Pivot pin	D. Sensing unit

Medium Draft

Figure 115. shows the position of the links 'A' and the top link when the unit is set for medium draft. Select this setting for multi-furrow ploughs and cultivators. The maximum forces for this setting are 1760 kg in compression and 1057 kg in tension.




FIGURE 115. ADJUSTABLE SENSING UNIT
ADJUSTED FOR MEDIUM DRAFT IMPLEMENTS

A. Link
B. Pivot pin
C. Top link
D. Sensing unit

Normal Draft

This setting is used for light draft ploughs and medium cultivators (see Figure 116). The maximum forces are 975 kg in compression and 585 kg in tension.




FIGURE 116. ADJUSTABLE SENSING UNIT
ADJUSTED FOR NORMAL DRAFT IMPLEMENTS

A. Link
B. Pivot pin

Light Draft

The top link and links 'A' are connected to the sensing unit as shown in Figure 117 for the light draft setting. Use this setting for light draft ploughs and medium cultivators with a maximum force of 715 kg in compression and 429 kg in tension.




FIGURE 117. ADJUSTABLE SENSING UNIT
ADJUSTED FOR LIGHT DRAFT IMPLEMENTS

A. Link
B. Pivot pin

1760 kg	=	3880 lb
1057 kg	=	2330 lb
975 kg	=	2150 lb
715 kg	=	1575 lb
585 kg	=	1290 lb
429 kg	=	954 lb

REMOVAL OF THE ADJUSTABLE SENSING UNIT

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this dirt will get into the system. This will result in failure of the system.

Disconnect the cable from the sensing unit. Remove the pin which holds the top link to the sensing unit. Store the top link with the pin. Remove the bolts which hold the sensing unit to the PTO case. Make a note of the position of the bolts, they are not all the same length. Put a cover over the holes into the PTO case.




FIGURE 118. REMOVAL OF THE ADJUSTABLE SENSING UNIT

A. Cable

B. Top link

DISASSEMBLY OF THE ADJUSTABLE SENSING UNIT

Prepare a clean working surface where you can disassemble and store components of the sensing unit.

1. Carefully hold the housing in a vice. Do not tighten the vice too much.
2. Separate the links 'A' then remove pin 'B'. Pull the frame 'C' clear of the shaft 'D'.
3. Remove the screws which hold the end cover 'E' on to the housing. Put a bar through the hole in the end of the shaft then pull the shaft assembly clear of the housing. (See Figure 120.)

NOTE: Do not use a screwdriver or blade to separate the end cover from the housing. There are shims between the end cover and the housing. They must not get damaged.

4. To disassemble the shaft assembly remove the pin 'F' from the collar 'G'. Remove the collar, thrust washer 'H' and spring 'J' from the shaft.
5. Carefully hold the sleeve 'K' in a vice, the flats of the sleeve vertical. Turn the shaft counterclockwise until it is free of the threads.
6. Remove the shims, end cover, 'O' ring and washer from the shaft. Destroy the 'O' ring. Do not destroy the shims, they must be fitted in their original position.
7. Wash all the parts in clean paraffin or fuel oil and dry in air.




FIGURE 119. DISASSEMBLY OF THE ADJUSTABLE SENSING UNIT

A. Link
B. Pin

C. Frame
D. Shaft

ASSEMBLY OF THE ADJUSTABLE SENSING UNIT

1. Make sure that the end cover will slide on to the sleeve. Fit a new 'O' ring in the end cover, then put some grease on the 'O' ring and bore.
2. Put a little Loctite 270 grade on the thread of the shaft. Fit the washer, end cover and sleeve on to the shaft. Carefully hold the sleeve in a vice, flats vertical, then turn the shaft clockwise to tighten.
3. Fit the spring, thrust washer and collar to the shaft. Push the pin through the collar and shaft. The protrusion of the pin must be equal at both sides of the collar. Fit the shaft assembly into the housing. The pin must slide in the grooves without restriction. Remove any restriction with a file.
4. Remove the shaft from the housing and check the movement of the thrust washer. It must be able to move up to 0.25 mm easily on the length of the shaft. If the movement is less, replace the thrust washer with a thinner thrust washer. If the movement is more, replace the thrust washer with a thicker thrust washer.
5. Put some grease on the collar and the pin.
6. Fit the original shims against the end cover. Put the shaft assembly into the housing, then use the screws to hold the end plate in position.
7. Evenly tighten the screws to a torque of 42 Nm, checking the movement of the shaft after each rotation of the screws. When the screws are tight, the shaft must be able to move up to 0.25 mm easily in the housing. Use different shims to get the correct movement.
If the movement of the shaft gets less then more as you tighten the screws, the spring is being compressed. This must not happen. Add shims until the movement is correct.
8. Put grease on the collar end of the bore then put jointing compound on the plug. Fit the plug into the housing. Connect a grease gun to the fitting and operate it three times.
9. Push the pin through the frame and the end of the shaft. Fit the links to the required position.




FIGURE 120. DISASSEMBLY OF THE ADJUSTABLE SENSING UNIT

A. Link	D. Shaft	G. Collar	K. Sleeve	N. Washer
B. Pin	E. End cover	H. Thrust washer	L. Shim	O. Housing
C. Frame	F. Pin	J. Spring	M. 'O' ring	

INSTALLATION OF THE ADJUSTABLE SENSING UNIT

Remove the cover from the PTO case. Clean the surface then fit a new gasket and the sensing unit. Fit the four bolts in their original position and tighten to a torque of 105 Nm. Connect and adjust the cable (see Page 65).

LUBRICATION OF THE ADJUSTABLE SENSING UNIT

Connect a grease gun to the fitting on the housing. Operate the grease gun three times. Do this after every 60 hours of work.

42 Nm = 4.2 kg m = 30 lb ft
105 Nm = 10.5 kg m = 76 lb ft
0.25 mm = 0.010 in

SELECTIVE SENSING UNIT

HOW IT WORKS

The selective sensing unit has three different settings for sensing heavy, medium and light draft. The unit uses two springs, having different strengths. Both or either one of the springs are used according to the position of the control lever. The parts of the sensing unit are shown in Figure 121.

When the lever is in the 'HEAVY DRAFT' position, both springs are used. The thrust washers will slide on to the ends of the carrier. This will permit the shaft movement to compress both springs.

When the lever is in the 'MEDIUM DRAFT'

position, the thrust washer on the left-hand end will slide on to the carrier. This will compress the strong spring on the left-hand end. The splines on the other thrust washer are not opposite the splines on the carrier. The thrust washer will not slide on to the carrier to compress the weak spring.

The weak spring on the right-hand side will be compressed when the lever is in the 'LIGHT DRAFT' position. In this position the thrust washer on the left-hand end will not go on the carrier. The strong spring on the left-hand end will not be compressed.




FIGURE 121. SELECTIVE SENSING UNIT

A. Strong spring
B. Weak spring

C. Thrust washer
D. Shaft

E. Carrier
F. Control lever

R76-67

REMOVAL OF THE SELECTIVE SENSING UNIT

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Disconnect the cable from the sensing unit. Remove the pin which holds the top link to the sensing unit. Store the top link and pin together. Remove the bolts which hold the sensing unit to the PTO case. Make a note of the position of the bolts, they are not all the same length. Put a cover over the holes into the PTO case.

DISASSEMBLY OF THE SELECTIVE SENSING UNIT

Prepare a clean working surface where you can disassemble and store components of the sensing unit.

1. Carefully hold the housing in a vice. Do not tighten the vice too much.
2. Remove plug 'A' from the top of the housing (see Figure 123). Put the lever 'B' in the vertical position.
3. Remove the four screws which hold the end cover 'C' in position.
4. Put a bar through the hole in the end of the shaft. Pull the shaft until the teeth on the carrier 'D' are clear of the teeth on the pinion 'E'. When the teeth are clear, turn the shaft counterclockwise through 45°. This will make the teeth on the carrier opposite the groove in the housing. Pull the shaft assembly clear of the housing.

NOTE: Do not use a screwdriver or blade to separate the end cover from the housing. There are shims between the parts, they must not get damaged.

5. To disassemble the shaft assembly remove the pin 'F' from the collar 'G' (see Figure 125). Remove the collar, thrust washers, shims, springs and carrier from the shaft. Store the parts together. Do not destroy the shims.
6. Carefully hold the sleeve 'M' in a vice, the flat of the sleeve vertical. Turn the shaft counterclockwise until it is free of the threads.
7. Remove the bush, shims, end cover and seal from the shaft. Destroy the seal. Do not destroy the shims, they must be fitted in their original position.
8. Remove the screw 'S', spring and plunger from the side of the housing.
9. Turn the lever until the pin through the pinion is vertical. Carefully remove the pin, do not bend the spindle.




FIGURE 122. REMOVAL OF THE SELECTIVE SENSING UNIT
A. Cable




FIGURE 123. DISASSEMBLY OF THE SELECTIVE SENSING UNIT
A. Plug
B. Lever
C. End cover
D. Carrier
E. Pinion




FIGURE 124. REMOVING THE SLEEVE
C. End cover
M. Sleeve
R. Shaft

10. Turn the bush 'N' counterclockwise until it is free of the threads. Put a hand inside the housing then pull the lever. The pinion will be pushed off the spindle into the housing.
11. Wash all the parts in clean paraffin or fuel oil and dry in air.




FIGURE 125. DISASSEMBLY OF THE SELECTIVE SENSING UNIT

A. Plug
B. Lever
C. End cover
D. Carrier
E. Pinion
F. Pin

G. Collar
H. Thrust washer
J. Strong spring
K. Weak spring
L. Shim
M. Sleeve

N. Bush
P. Shim
Q. Seal
R. Shaft
S. Screw
T. Bush

ASSEMBLY OF THE SELECTIVE SENSING UNIT

1. Fit a new seal into the bore of the end cover. Put a layer of grease on the seal.
2. Look at the bush 'N'. If there is any damage to the bush discard it, then fit a new bush into the end cover. Put some grease on the bore of the bush.
3. Put a little Loctite 270 grade on the threads of the shaft. Fit the end cover and sleeve on to the shaft. Carefully hold the sleeve in a vice, flats vertical, then turn the shaft clockwise to tighten.
4. Put the carrier vertically on the working surface, the right-hand end to the top. Fit the shims and the spring for the right-hand end on to the carrier. Measure the distance between the top surface of the spring and the top surface of the carrier. The top surface of the spring must be 0.13-0.26 mm above the top surface of the carrier. If the distance is not correct, fit shims of different thickness until the distance is between the limits.
5. Repeat operation 4 for the left-hand end of the carrier. The limits for the distance are the same. The thickness of the shims is the same but they have a different internal diameter.




FIGURE 126. SETTING DISTANCE 'X' FOR THE RIGHT-HAND END OF THE CARRIER

D. Carrier
K. Weak spring

L. Shim
X = 0.13-0.26 mm

0.13 mm = 0.005 in
0.26 mm = 0.010 in

6. Put the thrust washer for the right-hand end on to the shaft. On early sensing units the thrust washer had a groove on one face. This face must be towards the spring and away from the end cover. If it is not, the thrust washer cannot slide on to the carrier to compress the spring. On later sensing units the thrust washer has a dowel on one face. The dowel fits in a hole in the end cover. This thrust washer cannot be fitted the wrong way.
7. Fit the carrier, springs, shims, small thrust washer and collar on to the shaft. Push the pin through the hole in the collar and the shaft. The springs must not be in compression. If they are, use the other hole in the collar. The protrusion of the pin must be equal at both sides of the collar. Put the shaft assembly into the housing. The pin must slide in the grooves without restriction. Remove any restrictions with a file.
8. Remove the shaft assembly from the housing and check the movement of the carrier. The carrier must be able to move up to 0.30 mm easily on the length of the shaft. If the movement is not correct, replace the thrust washer on the left-hand end with one of the correct thickness. The position of the collar can be changed by fitting the pin into the other hole in the collar. The distance between the centres of the holes is 0.84 mm. This will help you to get the correct movement of the carrier.
9. Put some grease on the spindle. Hold the pinion inside the housing so that its bore is opposite the hole for the spindle. Push the spindle through the hole in the housing and the hole in the pinion. Turn the bush clockwise to tighten. Carefully push a new pin through the hole in the pinion and the shaft. Do not bend the shaft.
10. Turn the lever so that a detent groove is not opposite the hole in the housing for the plunger. Put the plunger and spring in the hole in the side of the housing. Check that the plunger does not go into one of the detent grooves in the spindle.
11. Put a little Loctite 270 grade on the threads of the screw, then fit the screw in the hole. Turn the screw clockwise until it is tight then turn the screw counterclockwise for $\frac{1}{4}$ of a rotation.
12. Fit the shaft assembly into the housing. Do not use the shims which fit between the housing and the end cover. Make sure that the teeth of the pinion and the teeth of the carrier are in mesh.




FIGURE 127. SETTING THE MOVEMENT 'Y' FOR THE CARRIER

- | | |
|------------------|------------------|
| C. End cover | K. Weak spring |
| D. Carrier | L. Shim |
| G. Collar | R. Shaft |
| H. Thrust washer | Y = 0.00-0.30 mm |
| J. Strong spring | |




FIGURE 128. MEASURING THE DISTANCE BETWEEN THE END COVER AND THE HOUSING

- | | | |
|--------------|------------|-----------------|
| C. End cover | U. Housing | V. Feeler gauge |
|--------------|------------|-----------------|

13. Push the end cover towards the housing with one hand. Make sure that the end cover is parallel to the end of the housing. Use a feeler gauge to measure the gap between the end cover and the housing. If the end cover is parallel to the housing, the gap will be equal all around the end plate. Make sure that the gap is equal at each side.

0.30 mm = 0.012 in
0.84 mm = 0.033 in

14. Remove the shaft assembly from the housing. Select shims to give the same thickness as the gap between the end cover and the housing. Fit the shims on to the shaft.
15. Put the lever in the vertical position, then fit the shaft assembly into the housing. Make sure that the pinion is in the centre of the teeth on the carrier. The protrusion of the carrier must be equal at both sides of the pinion. If it is not, the sensing unit will not work correctly.
16. Evenly tighten the screws which hold the end plate to the housing to a torque of 42 Nm.
17. Make sure that the lever will move into all of its positions. Put grease on the pinion, then put sealing compound on to a new plug. Fit the plug into its groove.
18. Put grease in the collar end of the bore, then put jointing compound on the plug. Fit the plug into the housing. Connect a grease gun to the fitting and operate it three times.




FIGURE 129. PINION IN MESH WITH THE CENTRE TEETH OF THE CARRIER
D. Carrier E. Pinion

INSTALLATION OF THE SELECTIVE SENSING UNIT

Remove the cover from the PTO case. Clean the surface then fit a new gasket and the sensing unit. Fit the four bolts in their original position and tighten to a torque of 105 Nm. Connect and adjust the cable (see Page 65).

LUBRICATION OF THE SELECTIVE SENSING UNIT

Connect a grease gun to the fitting on the housing. Operate the grease gun three times. Do this after every 60 hours of work.

42 Nm = 4.2 kg m = 30 lb ft
105 Nm = 10.5 kg m = 76 lb ft

CABLE FOR THE SENSING UNIT

INSPECTION OF THE CABLE FOR THE SENSING UNIT

Always inspect the cable before doing work on the sensing unit. If the sensing unit is not working correctly the cable can be the cause. Lower the linkage to the ground. Disconnect the cable from the sensing unit. Hold the outer sleeve for the cable with one hand. Use a pair of pliers to pull the cable away from its spring at the nipple end. Release the cable. You must fit a complete new cable assembly if:

- (a) It was difficult to pull the cable away from its spring.

OR

- (b) the cable did not return to its original position when released.


ADJUSTMENT OF THE CABLE FOR THE SENSING UNIT

1. Connect weights to the lower links but not to the top link. The spring in the sensing unit must not be in tension or compression.
2. Move the quadrant lever to the 'SELECT' position then select 'DEPTH' with the selector dial. Release the quadrant lever.
3. From the rear of the tractor turn the nut 'A' and adjuster 'B' clockwise (see Figure 131). This will move the nut and adjuster towards the front of the tractor. Do this until the cable will move easily.
4. Start the engine then move the quadrant lever rearward until it is against the quadrant spring. When the linkage has reached its highest position, stop the engine. Keep the quadrant lever in this position against the spring.




WARNING: Do the next operation from the side of the tractor. Make sure that if the linkage falls, there will be no injury to you. Make sure there is no other person near the tractor.

5. Turn the adjuster counterclockwise (towards the rear of the tractor) until the linkage just starts to lower. Turn the adjuster $5\frac{1}{2}$ rotations clockwise (towards the front of the tractor). Release the quadrant lever. Hold the adjuster in position, then turn the nut 'A' counterclockwise until it is against the adjuster.



R79-200


FIGURE 130. TESTING THE CABLE FOR THE SENSING UNIT



R76-77

FIGURE 131. ADJUSTING THE CABLE FOR THE SENSING UNIT

A. Nut B. Adjuster



R79-201

FIGURE 132. LUBRICATING THE CABLE FOR THE SENSING UNIT

C. Grease fitting D. Grease gun

LUBRICATING THE CABLE FOR THE SENSING UNIT

Connect a grease gun to the fitting on the outer sleeve. Operate the grease gun three times. Do this after every 60 hours of work.

RAM CYLINDER

HOW IT WORKS

The ram cylinder is fitted inside the case for the rear axle on the left-hand side. When the quadrant lever is in the 'RAISE' position, oil will flow to the ram cylinder. Oil enters the ram cylinder at the port 'A' (see Figure 133). The pressure of the oil pushes the piston 'B' along the cylinder. The connecting link 'C' turns the ramshaft arm 'D' which raises the linkage. When the quadrant lever is in the 'HOLD' position, no oil will go to or from the ram cylinder. The linkage will stay in position. When the quadrant lever is in the 'LOWER' position, the weight of the linkage

pushes the piston in the opposite direction. The oil is pushed out of the cylinder towards the selectamatic valve.

A locking latch is fitted on 12 series tractors to hold the linkage in its highest position. When the piston reaches the end of its stroke, the ramshaft arm goes over the end of the locking pin 'E'. If the lever 'F' is pushed down, the pin will engage and hold the ramshaft arms in position.




FIGURE 133. RAM CYLINDER FOR 12 SERIES TRACTORS

- | | |
|--------------------|-----------------|
| A. Inlet port | D. Ramshaft arm |
| B. Piston | E. Locking pin |
| C. Connecting link | F. Lever |

REMOVAL OF THE RAM CYLINDER

12 Series Tractors

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

The ram cylinder on 12 series tractors is made from one casting and is removed from the back of the rear axle. (see Figure 134). Remove the ramshaft (see Page 70) and the three-way valve or connector (see Page 49). Pull the ram cylinder clear of the rear axle in the direction of the arrow. Keep the cover for the ram cylinder with the other parts.




FIGURE 134. REMOVING THE RAM CYLINDER FOR 12 SERIES TRACTORS
A. Ram cylinder

INSPECTION AND REPAIR OF THE RAM CYLINDER

12 Series Tractors

Look at the bore. If there are any deep marks of wear, the ram cylinder must be machined before being used. Measure the diameter of the bore. It is machined at the factory, to 88.9 mm — 88.94 mm diameter. Use a boring tool then a hone to make the bore 89.41 mm — 89.45 mm diameter. The surface finish must be no more than 0.00406 mm centre line average value. This is a very smooth finish. If there are still marks in the bore, discard the ram cylinder.

NOTE: You must fit a new oversize piston to a ram cylinder which you have machined to 89.41 mm — 89.45 mm diameter. The diameter of the new piston must be 0.5 mm more than the diameter of the original piston.

If the bore has already been machined and there are marks or wear, discard the ram cylinder. The 'O' rings on the piston will not seal if there is damage or wear to the bore.




FIGURE 135. INSPECTION OF THE RAM CYLINDER

X = 88.9-88.94 mm

Y = 89.41-89.45

REPLACEMENT OF SEALS FOR THE RAM CYLINDER

12 Series Tractors

Prepare a clean working surface where you can replace the seals and store components of the ram cylinder.

1. Remove and destroy the 'O' rings and leather ring from the piston and ram cylinder.
2. Wash all the parts in clean paraffin or fuel oil and dry in air.
3. Put the new leather ring in transmission oil for at least 30 minutes. This will make the ring soft so that you can fit it without damage. If the ring is damaged, there will be leakage.

0.00406 mm	= 16 micro in
0.5 mm	= 0.020 in
88.9 mm	= 3.501 in
88.94 mm	= 3.5025 in
89.41 mm	= 3.520 in
89.45 mm	= 3.5015 in

4. Fit the new leather ring in the position shown in Figure 136. The smooth face of the ring must be against the side of the groove. Make sure that the leather ring is on its seat and is not twisted.
5. Fit the smaller 'O' ring next to the leather ring. The rough face of the leather ring must be against the 'O' ring. Make sure the 'O' ring is on its seat and is not twisted.
6. Make sure that the protrusion of the leather ring is equal all the way around the piston. If it is not, the leather ring is not on its seat. Do not fit the piston into the ram cylinder for at least 30 minutes. This will permit the leather ring to return to its original size.
7. Put some clean hydraulic oil on the piston. Carefully fit the piston into the ram cylinder. There is a chamfer on the bore, it will help you to fit the piston into the bore.




FIGURE 136. PISTON FOR THE RAM CYLINDER
A. Leather ring B. 'O' ring




FIGURE 137. RAM CYLINDER AND PISTON
C. 'O' ring E. Piston
D. Ram cylinder F. Gasket

NOTE: If the ram cylinder has not been removed from the tractor, open the vent valve before fitting the piston. Do this to remove air from the cylinder. Close the vent valve when the piston is at the end of its stroke.

8. Fit the larger 'O' ring in the groove on the end of the ram cylinder. Make sure that the 'O' ring is on its seat and is not twisted. Put a layer of grease on the 'O' ring.

INSTALLATION OF THE RAM CYLINDER

12 Series Tractors

Clean the faces of the case for the rear axle. Put jointing compound on a new gasket then fit it in position on the case for the rear axle. Fit the ram cylinder into the case for the rear axle. Hold it in position with the four bolts. Tighten the two $\frac{1}{2}$ UNC bolts to 195 Nm and the two $\frac{1}{2}$ UNC bolts to 90 Nm. Install the ramshaft then the take-off valve.

DISASSEMBLY OF THE LOCKING LATCH

1. Carefully hold the cover for the ram cylinder.
2. Put the operating lever 'A' into the 'ENGAGE' position. Use circlip pliers to remove the circlip 'B'. Carefully pull the operating lever and seal 'C' clear of the latch pin. The needle roller will break easily. They are hard and will not bend.
3. Remove the screw 'D' and then the circlip 'E'.
4. Push the latch pin 'F' out of the cover in the direction of the arrow. Remove the 'O' ring, spacer and spring from the latch pin. Destroy the 'O' ring.




FIGURE 138. DISASSEMBLY OF THE LOCKING LATCH

- | | |
|--------------------|------------------|
| A. Operating lever | E. Circlip |
| B. Circlip | F. Latch pin |
| C. Seal | G. Needle roller |
| D. Screw | H. Cover |

90 Nm = 9 kg m = 65 lb ft
195 Nm = 19.5 kg m = 140 lb ft

5. Do not remove the needle rollers unless they are damaged. If the needle rollers break in their holes, do not try to drill them out. The needle rollers are too hard, they will damage the drill. Grind the needle rollers until they are level with the surface of the boss. Do not grind the boss surface. Drill the two new holes in the boss as shown in Figure 139. Use a 4.5 mm diameter drill to the depth of 19.05 mm. Ream the hole to 4.73 mm – 4.75 mm diameter to a depth of 15.9 mm.
Press the needle rollers into their holes until their end faces are 18.49 mm – 18.24 mm away from the surface of the boss. The distance must be correct. If it is not, the locking latch will not work.
6. Wash all the parts in clean paraffin or fuel oil and dry in air.

ASSEMBLY OF THE LOCKING LATCH

1. Fit the spring, spacer and new 'O' ring on the latch pin. Make sure that the 'O' ring does not get damaged on the sharp edges of the circlip groove. The 'O' ring must be on its seat and not twisted.
2. Put some clean hydraulic oil on the latch pin. Fit the latch pin in the cover. Make sure that the groove in the latch pin is opposite the hole in the boss.
3. Put a little Loctite 270 grade on the thread of the screw, then fit the screw in its hole. Tighten the screw until it is against the bottom of the groove in the latch pin. Turn the screw $\frac{1}{4}$ of a rotation counterclockwise.
4. Push the latch pin so that the left-hand circlip groove is clear of the boss. Fit the circlip into its groove. Put grease on the latch pin and the needle rollers.
5. Carefully fit the seal onto the needle rollers and latch pin. Fit the operating lever on to the latch pin in its 'ENGAGED' position. Push the latch pin in the opposite direction of the arrow then fit the second circlip. Move the operating lever in and out of its engaged position to make sure that the latch pin moves correctly.




FIGURE 139. COVER FOR THE RAM CYLINDER

R. Original holes	U = 34.92-34.97 mm
S. New holes	V = 15.9 mm
T = 17.46-17.48 mm	W = 19.05 mm




FIGURE 140. ASSEMBLY OF THE LOCKING LATCH

F. Latch pin	K. Spacer
J. Spring	L. 'O' ring

4.5 mm	= 0.172 in
4.73 mm	= 0.1865 in
4.75 mm	= 0.1870 in
15.90 mm	= 0.625 in
17.46 mm	= 0.6875 in
17.48 mm	= 0.6885 in
18.24 mm	= 0.718 in
18.49 mm	= 0.728 in
19.05 mm	= 0.750 in
34.92 mm	= 1.375 in
34.97 mm	= 1.377 in

REMOVAL OF THE RAMSHAFT

REMOVAL OF THE RAMSHAFT 12 Series Tractors Without Cab

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Disconnect any implement connected to the three-point linkage. Remove the lift rods from the ramshaft arms and the top link from the sensing unit. Disconnect the inlet and outlet pipes for the external filter (if fitted). Remove the external filter. Connect a portable crane to the ramshaft. Remove the cover and the knob for the lowering valve from the front of the quadrant housing. Remove the Nyloc nut from the end of the control rod. There are three bolts which hold the quadrant housing to the rear axle case. Two of the bolts are inside the quadrant housing, remove these two bolts first. The third bolt is on the outside of the quadrant housing. You must loosen the three bolts which hold the quadrant to the quadrant housing before removing the third bolt. disconnect the rod from the bottom of the lever for the hand brake. The lever for the hand brake and its bracket is removed with the quadrant housing. Carefully pull the quadrant housing clear of the rear axle case. A spacer and spring will fall from the control rod. Do not lose these parts.

Look inside the rear axle case through the hole for the quadrant housing. Remove the two bolts which hold the inlet pipe to the selecta-matic valve. Loosen the locknut on the clamp bolt for the lubrication pipe. The clamp bolt is on the right-hand side of the rear axle case. Turn the clamp bolt eight rotations counter-clockwise. Use wire to hold the lubrication pipe in position. Fasten the wire to the top bolt hole for the quadrant housing. Remove the needle for the lowering valve.

Disconnect the cable for the sensing unit. Remove the sensing unit then put a cover over the holes into the PTO case.

Remove the four bolts which hold the right-hand ramshaft bracket to the rear axle case. Put a clean container under the cover for the ram cylinder. Remove the bolts which hold the cover for the ram cylinder to the ram cylinder and the rear axle case. Pull the cover clear of the ram cylinder. There will be leakage from the ram cylinder (1-1.5 litres).




FIGURE 141. REMOVING THE QUADRANT HOUSING

A. Quadrant housing B. Quadrant




FIGURE 142. REMOVING THE RAMSHAFT

A. Clamp bolt C. Right-hand ramshaft bracket
B. Sensing unit




FIGURE 143. REMOVING THE COVER FOR THE RAM CYLINDER

A. Cover for ram cylinder

1 litre = 1.75 pt = 1 US qt
1.5 litres = 2.8 pt = 1.5 US qt

Carefully pull the ramshaft assembly clear of the rear axle. The selectamatic valve must not get damaged when you do this. Put supports under the ramshaft. Remove the two nuts which hold

the ramshaft cam to the ramshaft. The cam is inside the right-hand ramshaft bracket. Slide the ramshaft bracket off the ramshaft.




FIGURE 144. INSTALLATION OF THE RAMSHAFT FOR 12 SERIES TRACTORS

A. Ram cylinder

B. Bearing

C. Ramshaft

D. Right-hand ramshaft bracket

E. Clamp bolt

INSTALLATION OF THE RAMSHAFT 12 Series Tractors Without Cab

Slide the right-hand ramshaft bracket on to the ramshaft. Fit the ramshaft cam on to the end of the ramshaft. Use the two nuts to hold it in position.

Look at the lubrication pipes inside the rear axle case. Make sure that the ends of the pipes are in their correct position. They are used to lubricate the ram cylinder, PTO unit, gearbox and the distribution block. Clean the faces of the right-hand ramshaft bracket and the rear axle case. Fit a new gasket on the right-hand ramshaft bracket. Look at the 'O' rings on the front of the selectamatic valve. If they are damaged fit new 'O' rings. Use grease to hold the 'O' rings in position. Look at the bearing for the ramshaft. If either half of the bearing is damaged, fit a new bearing. Fit one half of the bearing into the ram cylinder.

Carefully fit the ramshaft into position on the rear axle. Make sure that the selectamatic valve does not get damaged when you do this. Put the other half of the bearing in the cover for the ram cylinder. Carefully fit the cover to the ram cylinder. Use the six bolts to hold the cover in position. Fit the bolts into their position. Tighten the centre two bolts to a torque of 194 Nm, the top two bolts to a torque of 90 Nm and the

bottom two bolts to a torque of 104 Nm. Put jointing compound on the plug for the end of the ramshaft. Fit the plug in the hole in the left-hand side of the ram cylinder.

Use the four bolts to hold the right-hand ramshaft bracket in position. Fit the bolts into their original position. Remove the wire from the lubrication pipe. Hold the pipe in position then tighten the clamp bolt. Fit the needle for the lowering valve. Fit the inlet pipe to the selectamatic valve. Tighten the bolts to a torque of 21 Nm. Install the external hydraulic filter. Clean the faces of the quadrant housing and the rear axle case. Put a new gasket in position on the quadrant housing. Fit the quadrant housing to the rear axle. You must fit the spring and the spacer to the control rod when you do this. Use the three bolts to hold the quadrant housing in position. Tighten the bolts which hold the quadrant to the quadrant housing. Fit the Nyloc nut on to the control rod. Set the position of the Nyloc nut (see Page 86). Fit the sensing unit. Connect and adjust the cable for the sensing unit (see Page 89).

21 Nm = 2.1 kg m = 15 lb ft
90 Nm = 9 kg m = 65 lb ft
104 Nm = 10.4 kg m = 75 lb ft
194 Nm = 19.4 kg m = 140 lb ft

REMOVAL OF THE RAMSHAFT AND RAMSHAFT BRACKETS

14 Series Tractors Without Cab

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Disconnect any implement connected to the three-point linkage. Remove the lift rods from the ramshaft arms and the top link from the sensing unit. Disconnect the inlet and outlet pipes for the external filter (if fitted). Remove the external filter. Connect a portable crane to the ramshaft. Remove the cover and the knob for the lowering valve from the front of the quadrant housing. Remove the Nyloc nut from the end of the control rod. There are three bolts which hold the quadrant housing to the rear axle case. Two of the bolts are inside the quadrant housing, remove these two bolts first. The third bolt is on the outside of the quadrant housing. You must loosen the three bolts which hold the quadrant to the quadrant housing before removing the third bolt. Disconnect the rod from the bottom of the lever for the hand brake. The lever for the hand brake and its bracket are removed with the quadrant housing. Carefully pull the quadrant housing clear of the rear axle case. A spacer and spring will fall from the control rod. Do not lose these parts.

Look inside the rear axle case through the hole for the quadrant housing. Remove the two bolts which hold the inlet pipe to the selectamatic valve. Loosen the locknut on the clamp bolt for the lubrication pipe. The clamp bolt is on the right-hand side of the rear axle case. Turn the clamp bolt eight rotations counter-clockwise. Use wire to hold the lubrication pipe in position. Fasten the wire to the top bolt hole for the quadrant housing. Remove the needle for the lowering valve from the selectamatic valve.

Disconnect the cable for the sensing unit. Remove the sensing unit then put a cover over the holes into the PTO case.

Remove the six bolts which hold the right-hand ramshaft bracket to the rear axle case. Put a clean container under the left-hand ramshaft bracket. The left-hand ramshaft bracket is removed complete with the ramshaft and right-hand ramshaft bracket.

Remove the three-way valve or connector. Remove the four bolts which hold the brackets for the PTO clutch lever to the platform. Do this so that you can remove the four bolts which hold the front of the ramshaft bracket to




FIGURE 145. REMOVING THE QUADRANT HOUSING
A. Quadrant housing B. Quadrant




FIGURE 146. CLAMP BOLT FOR THE LUBRICATION PIPE
C. Right-hand ramshaft bracket D. Clampbolt




FIGURE 147. REMOVAL OF THE RAMSHAFT AND RAMSHAFT BRACKETS

E. Left-hand ramshaft bracket F. Ramshaft

the rear axle case. On later tractors the PTO clutch lever goes through a tube. The tube is welded to the platform. Remove the eight bolts which hold the platform to the tractor frame and left-hand fender. Disconnect the rod from the bottom of the clutch lever, then pull the lever clear of the tube. Carefully remove the platform from the tractor.


Remove the front six bolts from the top of the left-hand ramshaft bracket. They hold the ram-

shaft bracket to the rear axle case. Do not remove the other six bolts, they hold the top and bottom of the ramshaft bracket together.

Carefully pull the ramshaft assembly clear of the rear axle. There will be leakage from the ram cylinder (1-1.5 litres). The selectamatic valve must not get damaged when you do this. Put supports under the ramshaft.

FIGURE 148. REMOVING THE RAMSHAFT

E. Left-hand ramshaft bracket
F. Ramshaft



INSTALLATION OF THE RAMSHAFT AND RAMSHAFT BRACKET

14 Series Tractors Without Cab

Look at the lubrication pipes inside the rear axle case. Make sure that the ends of the pipes are in their correct position. They are used to lubricate the ram cylinder, PTO unit, gearbox and distribution block. Clean the faces of the right-hand ramshaft bracket and the rear axle case. Look at the 'O' rings on the right-hand ramshaft bracket. If they are damaged fit new 'O' rings. Put a layer of grease on the 'O' rings. Look at the 'O' rings on the front of the selectamatic valve. If they are damaged fit new 'O' rings. Use grease to hold the 'O' rings in position. Carefully fit the ramshaft into position on the rear axle. Make sure that the selectamatic valve does not get damaged when you do this. Fit the six bolts which hold the left-hand ramshaft bracket to the rear axle. You must fit the bolts into their original position. Fit the six bolts which hold the right-hand ramshaft bracket to the rear axle case. You must fit the bolts into their original position. Fit the four bolts which hold the front of the left-hand ramshaft bracket to the rear axle case. Use the four bolts to hold the brackets for the PTO clutch lever to the platform. On later tractors fit the platform to the tractor frame and the fender. Put the lever in the tube then connect the rod. Fit the three-way valve or connector. Install the external hydraulic filter.

Remove the wire from the lubrication pipe. Hold the pipe in position then tighten the clamp bolt. Fit the needle for the lowering valve. Fit the inlet pipe to the selectamatic valve. Tighten the bolts to a torque of 21 Nm. Clean the faces of the quadrant housing and the rear axle case. Put a new gasket in position on the quadrant housing. Fit the quadrant housing to the rear axle. You must fit the spring and the spacer to the control rod when you do this. Use the three bolts to hold the quadrant housing in position. Tighten the bolts which hold the quadrant to the quadrant housing. Fit the Nyloc nut on to the control rod. Fit the sensing unit on to the top of the PTO unit. Connect the cable for the sensing unit. Check the level of the oil in the reservoir. Set the position of the Nyloc nut on the control rod (see Page 86). Set the cable for the sensing unit (see Page 89).

25 Nm = 2.1 kg m = 15 lb ft
1 litre = 1.75 pt = 1 US qt
1.5 litres = 2.8 pt = 1.5 US qt

REMOVAL OF THE RAMSHAFT ONLY

14 Series Tractors Without Cab

Put the tractor on hard level ground. Disconnect any implement connected to the three-point linkage. Remove the lift rods from the ramshaft and the top link from the sensing unit. Disconnect the inlet and outlet pipes from the external filter (if fitted). Remove the external filter. Put blocks in front and behind the tractor wheels. Use a jack to raise the rear wheel on the left-hand side. Remove the rear wheel and its fender. Remove the three-way valve or the connector. Remove the four bolts which hold the brackets for the PTO clutch lever to the platform. Do this so that you can remove the four bolts which hold the front of the ramshaft bracket to the rear axle case. On later tractors the PTO clutch lever goes through a tube. The tube is welded to the left-hand platform. Remove the eight bolts which hold the platform to the tractor frame and fender. Disconnect the rod from the bottom of the clutch lever then pull the lever clear of the tube. Carefully remove the platform from the tractor. Pull the ram cylinder forward until it is clear of the left-hand ramshaft bracket. Remove the six screws which hold the cover to the right-hand ramshaft bracket. Remove the cam from the end of the ramshaft. Disconnect the cable for the sensing unit. Remove the sensing unit. Remove the twelve bolts from the top of the left-hand ramshaft bracket. Pull the top of the ramshaft bracket clear. Turn the ramshaft until the ramshaft arms are in their highest position. The connecting rod for the ram cylinder piston will fall clear of the axle case. Pull the ramshaft and the ramshaft bracket to the left-hand side of the axle case. Do this until the ramshaft is clear of the right-hand ramshaft bracket. Use a portable crane to lift the ramshaft clear of the tractor. Put supports under the ramshaft.

INSTALLATION OF THE RAMSHAFT ONLY

14 Series Tractors Without Cab

Look at the 'O' rings on the ends of the ramshaft. Replace the 'O' rings if they are damaged. Look at the bearings for the left-hand ramshaft bracket. If they are damaged fit new bearings. Look at the bearing in the right-hand ramshaft bracket. If it is damaged fit a new bearing. Use the portable crane to put the ramshaft on the left-hand ramshaft bracket. Make sure that the ramshaft arms are in their highest position when you do this. Carefully slide the ramshaft to the right-hand side of the tractor. Do this until the ramshaft is in position in the right-hand ramshaft bracket. Align the connecting links for the ram cylinder piston with the ram cylinder piston. Turn the ramshaft until the connecting link is inside the ram cylinder. Use the two nuts to hold the cam on to the right-hand end of the ramshaft. Set the position of the cam later. Fit the top of the left-hand ramshaft. Put jointing compound on to the end cap then fit it in position.

Carefully push the ram cylinder rearward into its correct position. Make sure that the connecting link and the piston make contact. Use the four bolts to hold the front of the ramshaft in position. Fit the brackets for the PTO clutch lever. On later tractors fit the platform to the tractor frame and fender. Put the lever in the tube then connect the rod to the bottom of the lever. Fit the three-way valve or connector. Fit the left-hand fender and rear wheel. Lower the tractor to the ground then remove the jack. Fit the sensing unit then connect the cable for the sensing unit. Check the level of oil in the reservoir. Add more oil if the level is low. Set the position of the cam on the end of the ramshaft (see Page 86). Set the cable for the sensing unit (see Page 89).

REMOVAL OF THE RAMSHAFT 12 and 14 Series Tractors With Cab

Disconnect the control rods and cables from the following:

- (i) lift latch (12 series only)
- (ii) levelling lever
- (iii) dump valve
- (iv) PTO unit
- (v) live take-off valve
- (vi) three-way valve


Repeat the removal sequence as for tractors without cab.

INSTALLATION OF THE RAMSHAFT 12 and 14 Series Tractors with Cab

Repeat the installation sequence as for tractors without cab. Connect the control rods and cables for the following:

- (i) lift latch (12 series only)
- (ii) levelling lever
- (iii) dump valve
- (iv) PTO unit
- (v) live take-off valve
- (vi) three-way valve

NOTE: Do the setting as for tractors with cab.



R79-212

FIGURE 149. REMOVAL OF THE RAMSHAFT FOR 12 SERIES TRACTORS WITH CAB

- A. Lift latch
- B. Levelling lever
- C. Dump valve
- D. Lever for PTO

- E. Live take-off valve
- F. Three-way valve
- G. Dial pointer
- H. Ramshaft

HYDRAULIC OIL COOLER

HOW IT WORKS

The hydraulic oil cooler is fitted between the hydraulic pump and the external filter in the system. It is fitted in front of the engine radiator on the tractor. There are two valves which control the flow of the oil through the oil cooler.

The oil from the reservoir is pushed through the pump towards the control valve. When the knob for the control valve is pulled out, the valve is closed. No oil will flow to the oil cooler. When the knob is pushed in, the oil will flow to the flow valve. If the pressure of the oil is less than 56 kg/cm², the spring in the valve will hold the plunger off its seat. Oil will flow through the cooler to the inlet side of the pump. The gap between the plunger and its seat is small. Only part of the oil from the pump will flow through the oil cooler. The other components in the system will operate as normal.

When the pressure of the oil is more than 56 kg/cm², the oil will push the plunger on to its seat. No oil will flow through the cooler.




FIGURE 150. CONTROL VALVE CLOSED

A. Hydraulic pump
B. Hydraulic oil cooler
C. Control valve
D. Flow valve




FIGURE 151. CONTROL AND FLOW VALVE OPEN

A. Hydraulic pump
B. Hydraulic oil cooler
C. Control valve
D. Flow valve




FIGURE 152. CONTROL VALVE OPEN, FLOW VALVE CLOSED

A. Hydraulic pump
B. Hydraulic oil cooler
C. Control valve
D. Flow valve

$$56 \text{ kg/cm}^2 = 800 \text{ lb/in}^2$$

REMOVAL OF THE HYDRAULIC OIL COOLER

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

Remove the grille from the front of the tractor. Disconnect and remove the battery. The removal sequence for the hydraulic oil cooler is different according to the other equipment fitted to the tractor.

Single Hydraulic Pump and Hydraulic Oil Cooler

Remove the screw which holds the bracket from the top of the oil cooler to the engine radiator. Disconnect the inlet and outlet pipes for the oil cooler, at the pump end. Remove the two bolts which hold the bracket for the oil cooler to the bracket for the pump. Carefully pull the oil cooler and its bracket clear of the tractor.

Single Hydraulic Pump, Hydraulic and Engine Oil Coolers

The engine oil cooler is fitted in front of the hydraulic oil cooler. They are both fastened to the same bracket. Remove the clip which holds the inlet and outlet pipes for the engine oil cooler together. Disconnect these pipes from the engine oil cooler. Remove the screw which holds the bracket from the top of the engine oil cooler to the engine radiator. Disconnect the inlet and outlet pipes for the hydraulic oil cooler at the pump end. Remove the two screws which hold the bracket for the coolers to the bracket for the pump. Carefully pull the oil coolers and bracket clear of the tractor.

Tandem Hydraulic Pump and Hydraulic Oil Cooler

Disconnect the inlet and outlet pipes for the oil cooler at the cooler end. Carefully move the pipes so that they are clear of the oil cooler. Remove the six nuts and bolts which hold the bracket for the oil cooler to the bracket for the battery tray. Carefully pull the oil cooler and its bracket clear of the tractor.

Tandem Hydraulic Pump, Hydraulic and Engine Oil Coolers

The engine oil cooler is fitted in front of the hydraulic oil cooler. They are both fastened to the same bracket. Disconnect the inlet and outlet pipes for the hydraulic oil cooler at the cooler end. Carefully move the pipes so that they are clear of the oil cooler. Disconnect the inlet and outlet pipes for the engine oil cooler at the connection under the oil cooler. Remove the six nuts and bolts which hold the bracket for the cooler to the bracket for the battery tray. Carefully pull the oil coolers and their brackets clear of the tractors.




FIGURE 153. SINGLE HYDRAULIC PUMP AND HYDRAULIC OIL COOLER

A. Hydraulic pump B. Hydraulic oil cooler




FIGURE 154. SINGLE HYDRAULIC PUMP, HYDRAULIC AND ENGINE OIL COOLERS

A. Hydraulic pump C. Engine oil cooler
B. Hydraulic oil cooler





FIGURE 155. TANDEM HYDRAULIC PUMP, HYDRAULIC AND ENGINE OIL COOLERS

A. Hydraulic pump C. Engine oil cooler
B. Hydraulic oil cooler

CONTROL AND FLOW VALVE ASSEMBLY FOR THE HYDRAULIC OIL COOLER



R76 120

FIGURE 156. CONTROL AND FLOW VALVE ASSEMBLY FOR THE HYDRAULIC OIL COOLER
A. Control valve B. Flow valve

REMOVAL OF THE CONTROL AND FLOW VALVE ASSEMBLY

Before working on the hydraulic system you must remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.

The valve assembly is fitted to the outlet side of the pump. Disconnect the pipe to the cooler at the valve assembly end. Remove the four screws which hold the valve assembly to the pump. Carefully pull the valve assembly clear of the tractor.

DISASSEMBLY OF THE CONTROL VALVE FOR THE HYDRAULIC OIL COOLER

Prepare a clean working surface where you can disassemble and store components of the control valve.

1. Carefully hold the valve body in a vice as shown in Figure 157. Do not tighten the vice too much.
2. Remove the screw 'A' from the knob. Pull the knob clear of the spool.
3. Remove the plug 'B', felt seal and washer from the valve body.
4. Push the spool in the direction of the arrow until the 'O' ring and backup ring are just clear of the bore. Remove and destroy the rings.
5. Turn the bush 'C' counterclockwise until it is clear of the thread. Use a dowel to push the spool out of the body in the opposite direction to the arrow. Remove and destroy all the 'O' rings and backup ring from the spool and the bush.
6. Wash all the parts in clean paraffin or fuel oil and dry in air.

INSPECTION OF THE CONTROL VALVE FOR THE HYDRAULIC OIL COOLER

Look at the bore and the spool. If there are any deep marks or wear to either part, discard the complete assembly. The parts are machined at the factory to fit each other. New spools are not available.




FIGURE 157. DISASSEMBLY OF THE CONTROL VALVE

- | | |
|----------|----------------|
| A. Screw | D. Spool |
| B. Plug | E. Backup ring |
| C. Bush | F. 'O' ring |





FIGURE 158. SPOOL FOR THE CONTROL VALVE

- | | |
|----------------|-------------|
| D. Spool | H. 'O' ring |
| G. Backup ring | |

ASSEMBLY OF THE CONTROL VALVE FOR THE HYDRAULIC OIL COOLER

1. Fit a new backup ring and then a new 'O' ring into the groove 'X' as shown in Figure 158. Make sure that the rings are on their seat and are not twisted. They must be in the position shown in Figure 159.
2. Put some clean hydraulic oil on the spool and the bore.
3. Carefully push the spool into the bore in the direction of the arrow. Do this until the groove 'Y' is just clear of the bore. Do not push the spool too far. If you do, the rings in the groove 'X' will get damaged on the edges of the ports in the valve body. This will result in leakage.
4. Fit a new backup ring and then a new 'O' ring into the groove 'Y'. Make sure that the rings are on their seat and are not twisted. They must be in the position shown in Figure 159 with the backup ring at the bottom. Put a layer of clean oil on the rings.
5. Fit a new 'O' ring into the end of the bush. Make sure that the seal is on its seat and is not twisted. Put a layer of clean oil on the seal. Apply jointing compound to the threads of the bush. Fit the bush into the valve body and tighten to a torque of 83 Nm.
6. Push the spool against the bush then fit the washer, felt seal and plug into the bore.
7. Fit the knob on to the spool. Put jointing compound on to the threads of the screw. Fit the screw in the knob and tighten. Make sure that the knob will move up and down correctly.




R79-220

FIGURE 159. ASSEMBLY OF THE CONTROL VALVE

D. Spool
E. Backup ring
F. 'O' ring

G. Backup ring
H. 'O' ring



R79-221

FIGURE 160. ASSEMBLY OF THE CONTROL VALVE


A. Screw
B. Plug

C. Bush
D. Flow valve

DISASSEMBLY OF THE FLOW VALVE FOR THE HYDRAULIC OIL COOLER

Prepare a clean working surface where you can disassemble and store components of the flow valve.

1. Turn the flow valve assembly counter-clockwise until it is free of the threads. Remove and destroy the sealing washer from the bottom of the bore.
2. Carefully hold the body for the flow valve in a vice as shown in Figure 161. Do not tighten the vice too much. Turn the cap 'A' counterclockwise until it is free of the threads. Remove the cap and washer. Destroy the washer.
3. Use a pen with a fibre tip to make a mark on the plug 'B' and the spring housing 'C'. Also make a mark on the spring housing and the valve body. Do this so that you can assemble the parts to their original position.



R79-222

FIGURE 161. DISASSEMBLY OF THE FLOW VALVE

A. Cap
B. Plug

C. Spring housing

83 Nm = 8.3 kg m = 60 lb ft

NOTE: The position of the parts for the flow valve are set at the factory using special equipment. The parts must be assembled to their original setting. If they are not, the valve will not work correctly.

4. Separate the sleeve 'D' from the valve body. It is held in position by an 'O' ring. Destroy the 'O' ring.
5. Make sure that there is a mark on the plug and spring housing. Use a screwdriver to remove the plug from the spring housing. Remove the spring.
6. Remove the circlip 'G' and washer from the plunger. Destroy the washer.
7. Make sure that there is a mark on the spring housing and the valve body. Turn the spring housing counterclockwise until it is free of the threads. Remove the plunger from the spring housing.
8. Wash all the parts in clean paraffin or fuel oil and dry in air. Take care not to remove the marks when you wash the parts.

INSPECTION OF THE FLOW VALVE FOR THE HYDRAULIC OIL COOLER

Look at the plunger and the sleeve. If there is damage to either part you must fit a new valve assembly. The sleeve and end plunger are machined to fit each other at the factory. A new sleeve or plunger are not available.

ASSEMBLY OF THE FLOW VALVE FOR THE HYDRAULIC OIL COOLER

1. Put the plunger and spring into the spring housing. Fit the plug into the spring housing. Turn it clockwise until it is in its original position. The marks will show this position.
2. Put a new washer on the plunger then fit the circlip into its groove.
3. Fit the spring housing to its original position in the valve body. The marks will show this position.
4. Fit a new 'O' ring on the sleeve. Make sure that the 'O' ring is not twisted. Put some clean oil on the sleeve and the 'O' ring. Fit the sleeve into the valve body.
5. Put a new sealing washer on the body then fit the cap. Tighten the cap to a torque of 83 Nm.
6. Put a new sealing washer in the bottom of the bore for the flow valve assembly. Fit the flow valve assembly and tighten to a torque of 83 Nm.




FIGURE 162. DISASSEMBLY OF THE FLOW VALVE

B. Plug
C. Spring housing
D. Sleeve
E. Valve body
F. Washer
G. Circlip
H. Plunger




FIGURE 163. ASSEMBLY OF THE FLOW VALVE

B. Plug
C. Spring housing
H. Plunger




FIGURE 164. ASSEMBLY OF THE FLOW VALVE

D. Sleeve
E. Valve body

INSTALLATION OF THE CONTROL AND FLOW VALVE ASSEMBLY

Fit a new 'O' ring into the boss on the valve body. Make sure that the 'O' ring is on its seat and is not twisted. Put a little oil on the 'O' ring. Use the four screws to hold the valve assembly to the pump. Make sure that the screws are tight. Connect the pipe from the oil cooler.

83 Nm = 8.3 kg m = 60 lb ft

THREE-POINT LINKAGE

HOW IT WORKS

This is the connecting linkage between the tractor and the implement. Two lower links lift the implement. A stabiliser bar is connected to each of the lower links. They control the side movement of the lower links. The lower links are connected to the ramshaft by two lift rods. When the ramshaft turns, the lower links will raise or lower. The lift rod on the left-hand side

can be adjusted to give the necessary height range. A levelling lever is fitted to the right-hand lift rod. This is used to level the implement when it is in work. The top link can also be adjusted. It is used to hold the implement at the correct angle when in work. The top link is connected to the sensing unit, which controls the depth of the implement when in work.




FIGURE 165. THREE-POINT LINKAGE

- | | |
|-------------------|--------------------|
| A. Lower links | E. Top link |
| B. Stabiliser bar | F. Lift rod |
| C. Support ram | G. Levelling lever |
| D. Check chain | |

STABILISER BARS

There are two different stabiliser bars available, the rigid type and the telescopic type. They are used to control the side movement of the lower links when using an implement. The stabiliser bars are fastened to the lower links and to the reduction case. The rigid type stabiliser can be adjusted by the stabiliser screw (see Figure 166). Rigid stabilisers must be adjusted to install or remove an implement.

The telescopic stabiliser can be adjusted by turning the ball housing. An implement can be installed or removed without making any adjustment to the telescopic stabilisers.

INSTALLATION AND ADJUSTMENT OF THE TELESCOPIC STABILISERS

1. Check the free movement of the rods in both stabiliser bar assemblies. It must be 75 mm. Turn the front ball housing until the movement is correct.
2. Use the six setscrews to hold the brackets to the reduction cases (see Figure 168). Tighten the setscrews to a torque of 88 Nm.
3. Fit the stabilisers on to the brackets and the lower links. Tighten the nuts to a torque of 190 Nm.
4. Connect the implement to the linkage. Align the implement to the centre of the tractor.
5. Turn the tube for the right-hand stabiliser in the direction of the arrow. Do this until the head of the rod makes contact with the face of the bush inside the tube. Use a bar through the hole in the lug to turn the tube if it is tight on the threads.
6. Repeat operation 5 for the other stabiliser on the left-hand side.
7. To get the necessary side movement, turn the tubes counterclockwise by the same amount.

LEVELLING LEVER

The parts of the levelling lever are shown in Figure 169. To disassemble the levelling lever remove the four setscrews which hold the cover to the housing. The shaft and bearing can now be pulled clear of the housing. The pinion is held on to its shaft by a pin. Use a punch to remove the pin. Before assembling the parts make sure that there is no dirt in the housing or cover. Put grease in the housing before fitting the cover. Tighten the setscrews which hold the cover to the housing to a torque of 42 Nm.

42 Nm = 4.2 kg m = 30 ft lb
88 Nm = 8.8 kg m = 64 lb ft
190 Nm = 19.0 kg m = 140 lb ft
75 mm = 3 in




FIGURE 166. RIGID STABILISER
A. Stabiliser screw B. Locknut




FIGURE 167. TELESCOPIC STABILISER
A. Front ball housing X = 75 mm





FIGURE 168 INSTALLATION OF THE TELESCOPIC STABILISER

A. Reduction case

B. Lower link



12 SERIES

14 SERIES

FIGURE 169. LEVELLING LEVER

A. Housing
B. Cover
C. Bearing

D. Pinion
E. Shaft

FAULT FINDING

You will need the following tools to check settings and specific components of the hydraulic system.

- A. Oil pressure gauge 0-250 kg/cm² . . . K960985
 B. Adaptor plate for the distribution block K962234

- C. Union K962235
 D. Pipe $\frac{1}{2}$ B.S.P. K84522
 E. Connector K962239
 F. Setting gauge K961796
 G. Flow meter




FIGURE 170. SPECIAL TOOLS

If the selectamatic hydraulic system is not working correctly you must check the following settings before you test specific components in the system.

Before you check the settings do the following:

- (i) Make sure that the level of hydraulic oil in the reservoir is correct. Add new oil if the level is low.
- (ii) Make sure that the hydraulic oil is at the correct operating temperature. To do this select 'TCU/EXT'. Run the engine at 1800 r/min. Push the quadrant lever forward into the full 'TCU' position and hold it there for 15 minutes. Do not hold the quadrant lever in the 'SELECT' position. This will put air in the system and damage the pump.
- (iii) Remove any dirt from and around hydraulic components and controls. If you do not do this, dirt will get into the system. This will result in failure of the system.
- (iv) Make sure that there is no air in the system.

TO REMOVE AIR FROM THE HYDRAULIC SYSTEM

1. Put the tractor on level ground. Make sure that the level of hydraulic oil in the reservoir is correct. Add more oil if the level is low.
2. Select 'DEPTH' or 'HEIGHT' on the dial pointer. Push the quadrant lever fully forward.

NOTE: The dial pointer must not be in the 'EXT/TCU' position. If it is, there will be damage to the pump.

3. Disconnect the outlet pipe from the relief valve. Put a clean container below the outlet for the relief valve.
4. Put the engine stop control into the 'STOP' position. Turn the starter key into the 'START' position. Hold the starter key in this position until the oil flowing from the relief valve is free of air. Turn the starter key to the 'OFF' position.
5. Connect the outlet pipe to the relief valve.
6. Repeat the above operations removing the air at the following points in this sequence:
 - (i) The by-pass and hold valves. Turn the plugs for the valves counterclockwise until the small hole in the side of the plugs is clear of the bore. Do not remove the plugs.
 - (ii) The live take-off valve. Disconnect the outlet pipe 'B' then move the operating lever forward from the neutral position.
 - (iii) The three-way valve. Disconnect the pipe from the number 1 (top) port. Put the operating lever into the '1' position.




FIGURE 171. REMOVING AIR FROM THE SYSTEM AT THE RELIEF VALVE
A. Relief valve




FIGURE 172. REMOVING AIR FROM THE SYSTEM AT THE HOLD AND BY-PASS VALVES
A. Plugs for the by-pass and hold valves




FIGURE 173. REMOVING AIR FROM THE SYSTEM AT THE LIVE TAKE-OFF VALVE
A. Live take-off valve B. Outlet pipe

- (iv) The fitting on the ram cylinder (12 series tractors only). Put the lever for the three-way valve into the 'L' position. Turn the fitting counterclockwise until the oil will flow from it.

A. RAMSHAFT CAM SETTING

Tractors With Cab and Tractors Without Cab

1. Select the 'HEIGHT' or 'DEPTH' position on the dial pointer.
2. Remove the cover from the ramshaft bracket on the right-hand side (see Figure 175).
3. Lift the ramshaft arms to their highest position. On 12 series tractors use the locking latch to hold them in this position. Use supports to hold the ramshaft arms in position on 14 series tractors.
4. Look at the ramshaft cam 'A'. The roller 'B' must be seated in the notch in the cam. Loosen the two nuts 'C' then turn the cam until the roller is seated in the notch. Tighten the nuts.
5. Fit the cover on the ramshaft bracket. Remove the supports.




FIGURE 174. REMOVING AIR FROM THE SYSTEM AT THE RAM CYLINDER (12 SERIES TRACTORS ONLY)
A. Fitting B. Three-way valve

B. CONTROL ROD SETTING

Tractors Without Cab

1. Remove the cover and the knob from the front of the quadrant housing.
2. Remove the cover or dump valve from the top of the axle case. Do this so that you can see the selectomatic valve.
3. Select the 'HEIGHT' position on the dial pointer. Lower the linkage then move the quadrant lever to the 'SELECT' position. Hold the quadrant lever in this position.
4. Turn the Nyloc nut on the end of the control rod counterclockwise until it is at the end of the threads.
5. Put a dial gauge on top of the rear axle with its probe on the spool valve. Make sure that the probe is vertical and that it is in contact with the spool valve.
6. Turn the dial pointer from 'HEIGHT' to 'TCU/EXT' to 'HEIGHT'. The spool valve must not move when you do this. The amount of movement can be seen on the dial gauge.
7. Turn the Nyloc nut on the control rod clockwise. Do operation 5 at the same time. Turn the nut until there is no movement of the spool valve.
8. Fit the cover or the dump valve on to the top of the rear axle. Fit the cover for the quadrant housing and the control knob for the lowering valve.




FIGURE 175. RAMSHAFT CAM SETTING
A. Ramshaft cam B. Roller C. Locknuts




FIGURE 176. CONTROL ROD SETTING
A. Nyloc nut B. Dial gauge C. Quadrant lever

B. CONTROL ROD SETTING**Tractors With Cab**

Repeat sequence of operations as for tractors without cab. If a dial gauge is not available use the following alternate method.

NOTE: *The method used for tractors without cab is more accurate.*

1. Lower the linkage to the ground.
2. Connect an oil pressure gauge 0-250 kg/cm² to the number 1 (top) take-off port on the three-way valve. Put the lever for the three-way valve to the '1' position.
3. Put the quadrant lever into the 'SELECT' position. Hold it in this position.
4. Disconnect the operating rod for the dial pointer at the quadrant housing end. Put a pin through the hole in the spindle for the dial pointer. Do this so that you can feel when the dial pointer engages in any one of its positions. You cannot feel this when the operating rod is connected.
5. Remove the cover and knob from the front of the quadrant housing.
6. Turn the Nyloc nut on the end of the control rod clockwise until you can select 'TCU/EXT' easily. Keep the dial pointer in the 'TCU/EXT' position.
7. Turn the Nyloc nut counterclockwise until it is at the end of the thread on the rod.
8. Start the engine and run it at 1800 r/min.
9. Turn the Nyloc nut slowly clockwise until the reading on the oil pressure gauge is just at a maximum. This maximum pressure will occur when the relief valve for the pump just opens. You will hear the oil pushing past the relief valve.
Turn the Nyloc nut clockwise for a further one complete rotation only.
10. Make sure that you can select 'HEIGHT' and 'TCU/EXT' easily. You can turn the Nyloc nut $\frac{1}{2}$ of a rotation in either direction to make the movement easier. Do not turn the Nyloc nut more than $\frac{1}{2}$ of a rotation.
11. Fit the end cover for the quadrant housing. Make sure that the knob for the lowering valve is in its correct position.
12. Release the quadrant lever from the 'SELECT' position. Select the L/1 position on the three-way valve.
13. Raise the linkage. Make sure that you can select 'HEIGHT' and 'TCU/EXT' when the linkage is at full height.
14. Lower the linkage. Disconnect the oil pressure gauge.




FIGURE 177. CONTROL ROD SETTING

A. Pressure gauge
B. Three-way valve

C. Dial pointer




FIGURE 178. CONTROL ROD SETTING

A. Nut
B. Nyloc nut

C. Control rod

250 kg/cm² = 4000 lb/in²

C. FRICTION DISC FOR QUADRANT LEVER SETTING

Tractors With Cab and Tractors Without Cab

1. Move the quadrant lever backward and forward. It must be tight enough to stay in position when the engine is running. Any vibration from the engine must not move the quadrant lever. Tighten or loosen the nuts 'A' Figure 179 until the amount of friction is correct (for tractors without cab). Tighten or loosen the nuts 'C' Figure 181 for tractors with cab.




FIGURE 179. FRICTION DISC SETTING
A. Nut

D. QUADRANT SPRING SETTING

Tractors Without Cab

1. Select the 'HEIGHT' position on the dial pointer.
2. Start the engine then move the quadrant lever fully rearwards. When the linkage is at its full height, the relief valve for the pump will open. You will hear the oil pushing past the relief valve.
3. Slowly move the quadrant lever forward until the relief valve closes but the linkage stays in position. Hold the quadrant lever in this position.
4. Loosen the nut 'B' then carefully move the quadrant spring until it is against the quadrant lever. Tighten the nut.
5. Lower the linkage then pull the quadrant lever fully rearward. When the linkage is at its full height, release the quadrant lever. It must move forward to a position just in front of the quadrant spring. The linkage must stay in position and the relief valve must close (you will hear the relief valve close). Adjust the position of the quadrant spring until this occurs.




FIGURE 180. QUADRANT SPRING SETTING FOR TRACTORS WITHOUT CAB

A. Quadrant spring

B. Nut

D. QUADRANT SPRING SETTING

Tractors With Cab

Repeat sequence of operations as for tractors without cab. The spring carrier is fitted to the side of the quadrant housing. Loosen the nuts 'B' Figure 181 to adjust the position of the spring carrier.




FIGURE 181. QUADRANT SPRING SETTING FOR TRACTORS WITH CAB

A. Quadrant spring

B. Nut

C. Nut

E. CONTROL ROD FOR THE QUADRANT LEVER SETTING

Tractors With Cab

1. Push the quadrant lever fully forward until it is against the end of the groove in the housing.
2. Loosen the locknuts 'A' on the operating rod for the quadrant lever (see Figure 182).
3. Adjust the turnbuckle 'B' until the lever 'C' is against the lower stop 'D'. Tighten the locknuts.

Before doing any of the following tests make sure that there are weights connected to the linkage.




FIGURE 182. CONTROL ROD FOR THE QUADRANT LEVER SETTING

A. Locknuts
B. Turnbuckle

C. Lever
D. Lower stop

F. CABLE FOR THE SENSING UNIT SETTING

Tractors With Cab and Tractors Without Cab

1. Connect weights to the lower links but not to the top link. The spring in the sensing unit must not be in tension or compression.
2. Move the quadrant lever to the 'SELECT' position then select 'DEPTH' with the selector dial. Release the quadrant lever.
3. From the rear of the tractor turn the nut 'A' and adjuster 'B' clockwise (see Figure 183). This will move the nut and adjuster towards the front of the tractor. Do this until the cable will move easily.
4. Start the engine then move the quadrant lever rearward until it is against the quadrant spring. When the linkage has reached its highest position, stop the engine. Keep the quadrant lever in this position against the spring.




FIGURE 183. CABLE FOR THE SENSING UNIT SETTING

A. Nut

B. Adjuster



WARNING: Do the next operation from the side of the tractor. Make sure that if the linkage falls, there will be no injury to you. Make sure there is no other person near the tractor.

5. Turn the adjuster counterclockwise (towards the rear of the tractor) until the linkage just starts to lower. Turn the adjuster $5\frac{1}{2}$ rotations clockwise (toward the front of the tractor). Release the quadrant lever. Hold the adjuster in position then turn the nut 'A' counterclockwise until it is against the adjuster.

LIFT TEST

Select 'HEIGHT' or 'DEPTH' on the dial pointer. Start the engine then move the quadrant lever rearward until it is against the quadrant spring. If the linkage rises but not in the first 5 seconds, do the following:

1. Clean the filter for the by-pass valve (see Page 39).
2. Make sure that the sensing valve is not held in the open position.

If the linkage will not rise or rises slowly, do the following:

1. Make sure that the dump valve is closed and the valve for the oil cooler is closed (if fitted).
2. Make sure that the lever for the three-way valve is in the 'L' or L/1 position (if fitted).
3. Make sure that the lever for the live take-off valve is in the neutral (centre) position (if fitted).
4. Make sure that the level of oil in the reservoir is correct. Add more oil if the level is low. The system will need more oil if external hydraulic equipment is being used.
5. Check the pressure of the oil from the pump. Connect a pressure gauge 0-250 kg/cm² to the outlet port of a live take-off port. Move its operating lever from the neutral (centre) position. Use an adaptor plate on top of the distribution block if a live take-off valve is not fitted. Connect the pressure gauge to the adaptor (see Figure 185). Start the engine. The reading on the pressure gauge must be more than 140 kg/cm². If the reading is less than 140 kg/cm² one or more of the following will be the cause:

- (a) A dirty hydraulic filter.
- (b) A leak in the inlet pipe to the pump.
- (c) The relief valve for the pump is opening too soon, you will hear the oil pushing past the relief valve.
- (d) A worn or damaged hydraulic pump. To check the hydraulic pump, replace the pressure gauge with a flow meter. The output of the pump must be the same as the data on Page 186. Look at the specification for the pump which is fitted. Low output shows a worn or damaged pump. If the pressure and output from the pump are correct, do the next operation.

$140 \text{ kg/cm}^2 = 2000 \text{ lb/in}^2$ $250 \text{ kg/cm}^2 = 4000 \text{ lb/in}^2$
--




FIGURE 184. CHECKING THE PRESSURE OF THE OIL FROM THE PUMP

A. Live take-off valve

B. Pressure gauge




FIGURE 185. CHECKING THE PRESSURE OF THE OIL FROM THE PUMP

A. Pressure gauge

B. Adaptor plate




FIGURE 186. CHECKING THE PUMP OUTPUT

A. Flow meter

B. Live take-off valve

6. Remove the pressure gauge or flow meter from the take-off valve or adaptor plate. If a take-off valve is fitted move the operating lever to the neutral position. Fit the pressure gauge to the number 1 (top) port on the three-way valve or to the connector if a three-way valve is not fitted (see Figure 187). Put the operating lever for the three-way valve in the '1' position (if fitted). Start the engine. Move the quadrant lever rearward until it is against the quadrant spring. The reading on the pressure gauge must be more than 140 kg/cm^2 . If the pressure of the oil is less than 140 kg/cm^2 , one or more of the following will be the cause:
 - (a) Seizure to the by-pass and hold valves or dirt in the by-pass or hold valves. Remove the plungers for the valve. If the selectamatic valve is still in the case for the rear axle, run the engine at 1800 r/min for 3 minutes. This will flush the bore for the plungers, removing any dirt. Install the plungers into their bores.
 - (b) Dirt in other parts of the selectamatic valve or a loose valve seat for the non-return valve. If this is the cause there will be no reading on the pressure gauge. The relief valve will be open (you will hear the oil pushing past the relief valve).
 - (c) Damaged 'O' rings or pipes to and from the selectamatic valve.

If the pressure of the oil is more than 140 kg/cm^2 there is leakage from the ram cylinder or dump valve (if fitted).

HOLD TEST

1. Select 'TCU/EXT' with the dial pointer. Put the lever for the three-way valve into the 'L' or 'L/1' position (if fitted). Make sure that the lever for the take-off valve is in the neutral position (if fitted). Start the engine then move the quadrant lever rearward into the 'EXTERNAL LIFT' position. Release the quadrant lever when the linkage is at full height. The quadrant spring will push the lever into the 'HOLD' position.

The linkage must stay in position. If the linkage falls, there is leakage from the system. Do the following to find the cause.

2. Put the lever for the three-way valve into the '1' position. This will stop the oil flowing out of the ram cylinder. If the linkage still falls the leakage is from the ram cylinder or the three-way valve. If the linkage stops falling and stays in position, the leakage is from the selectamatic valve or its outlet pipe. Continue doing the operations to find the exact position of the leak.




FIGURE 187. CHECKING THE OIL PRESSURE IN THE SYSTEM

A. Connector

B. Pressure gauge

$140 \text{ kg/cm}^2 = 2000 \text{ lb/in}^2$

3. Remove the cover from the top of the case for the rear axle.
4. Check for leakage around the plugs for the hold and by-pass valves. Their sealing washers can be damaged. If a dump valve is fitted (12 series tractors) make sure that its 'O' rings are not damaged.
5. Hold a mirror over the top of the selectamatic valve. Move the mirror until you can see the slot for the lowering valve. Look for leakage from the slot. If there is leakage, there is damage to the hold valve or the 'O' ring under the seat for the hold valve.
6. Remove the plunger for the by-pass valve. Look at the level of the oil in the bore. If the level is rising (oil going into the bore) there is damage to the non-return valve.
7. Check for leakage around the plug for the relief valve. If there is leakage, there is damage to the relief valve.
8. Remove the cover from the ramshaft bracket on the right-hand side. Look for leakage around the spool valve. Turn the spool through 90°. If there is leakage, there is damage to the spool valve.
9. Remove the quadrant housing. Look for leakage around the oil pipe and where the pipe connects to the selectamatic valve. If there is leakage at the connection, there is damage to the 'O' rings.

TCU TEST

1. Connect a pressure gauge 0-250 kg/cm² to the number 1 (top) port on the three-way valve or use the connector. Put the lever for the three-way valve in the 'L/1' position.
2. Select TCU/EXT on the dial pointer. Start the engine then slowly move the quadrant lever forward into the TCU position. The reading on the pressure gauge will increase up to 49-52 kg/cm².
3. If the pressure of the oil is less than 49 kg/cm² one or more of the following can be the cause.
 - (a) Wrongly adjusted TCU plunger (see Page 41).
 - (b) Wrongly set adjusting screw in the rocker lever (see Page 41).
 - (c) A wrong or broken spring for the TCU valve.
4. If the reading on the pressure gauge is slow to increase the ball for the hold valve can be missing.




FIGURE 188. CHECKING THE TCU OIL PRESSURE IN THE SYSTEM

A. Pressure gauge

B. Three-way valve

49 kg/cm ² = 700 lb/in ² 52 kg/cm ² = 750 lb/in ²
--

LOWERING TEST

1. Select 'DEPTH' or 'HEIGHT' on the dial pointer. Put the lever for the three-way valve into the 'L' or 'L/1' position. Start the engine then move the quadrant lever into the 'LIFT' position. Hold it in this position until the linkage is at full height. Move the quadrant lever into the 'LOWER' position. If the linkage does not lower or lowers slowly do the following.
2. Make sure that the locking latch is disengaged (12 series tractors).
3. From the front of the tractor turn the knob for the lowering valve counterclockwise (out of the selectamatic valve). This will open the outlet port.
4. Make sure that the oil in the hydraulic system is of the correct grade and is at working temperature.
5. Check TCU setting (Page 42).
6. Make sure that the lowering valve is not held in the closed position. Check that the plunger for the lowering valve has been fitted the correct way round in its bore.
7. If the linkage will only lower at low engine r/min the sensing valve is being held in the closed position. To check this select TCU/EXT on the dial pointer. Move the quadrant lever into 'LOWER' position then into the 'HOLD' position. If the linkage rises when you do this there is seizure to the sensing valve.
8. Disconnect external rams, this can reduce the pressure of the oil in the system. If the pressure is too low the oil will not flow out of the ram cylinder and the linkage will not lower.

HEIGHT CONTROL TEST

1. Select 'HEIGHT' on the dial pointer. Put the lever for the three-way valve in the 'L' or 'L/1' position (if fitted). Start the engine then move the quadrant lever rearward. The linkage must rise as you move the quadrant lever rearward. Move the quadrant lever forward, the linkage must lower.
2. If the linkage does not smoothly follow the movement of the quadrant lever look for seizure on the connecting rods and linkages.
3. Heavy implements attached to the linkage can fall below the required position then immediately return to the correct position. This is normal. It takes a small amount of time for the hold valve to work correctly.

DEPTH CONTROL TEST

1. Select 'DEPTH' on the dial pointer. Put the lever for the three-way valve in the 'L' or 'L/1' position (if fitted).
Connect a plough to the linkage. Start the engine then move the quadrant lever into the 'LIFT' position.
2. Move the tractor then lower the plough into its correct working position. Check the depth of the plough.
3. If the plough does not work correctly do the following:
 - (a) Check that the plough is set correctly.
 - (b) If the tractor is fitted with an adjustable or selective sensing unit make sure that it is in the correct range.
 - (c) Make sure that the top link is set correctly. The force on the sensing unit must move its shaft between 1.6 mm and 3.2 mm when the plough is in work. If the movement is less or more the sensing unit will not work correctly.
 - (d) If the depth of the implement is not constant, check for damage to the sensing unit, cable and linkages for the sensing unit.

1.6 mm = 0.063 in
3.2 mm = 0.126 in

David Brown®
Service Repair Manual

HYDRAULIC SYSTEM

885, 990, 995 and 996 Synchromesh Tractors
Section G3 (Pub. 9-37214) September 1976



David Brown Tractors Ltd
A Tenneco Company
Affiliate of J I Case





DANGER — Hydraulic equipment can be dangerous.



Not only can equipment move unexpectedly but oil can, when released under pressure, pierce the skin to cause serious injuries.

FOR YOUR SAFETY

Before commencing work on a machine ensure all pressure has been relieved from the hydraulic system and the equipment is resting in a fully-lowered position. After lowering the equipment to the ground or against its fully-lowered stop, allow the engine to come to rest and then operate the control valves to relieve all oil pressure. If any equipment cannot be lowered, because for example it would interfere with access, do not support it hydraulically but use a correct support so that when all system pressure is released the equipment is safely supported.

Do not work under an implement whilst it is raised on the tractor linkage and supported only by the locking latch. Always place a support under the rear of the implement, so that it cannot drop if a mechanical failure occurs.

Never check for oil leaks with the hands and do not approach very close to a pipe, or component, suspected of leaking.

The most dangerous type of oil leak is a leak so small as to be almost invisible. A very fine jet of oil under a pressure far less than is used in tractor hydraulic systems can penetrate the skin, even through clothing, and cause PERMANENT tissue damage.

An oil injection through the skin is relatively painless and may not be noticed at the time. It may later become painful however and give the impression of a cut which has become infected. If this occurs obtain medical attention immediately. The damaged tissues must be removed without delay otherwise the affected area will spread and major surgery may be required to prevent it becoming fatal.

Painful burns can be caused by only a small amount of hot oil coming into contact with the skin.

CONTENTS

How it works	Page
Hydraulic system	5
Hydraulic pump	6
Full flow filter	7
Pump relief valve	8
Selectamatic control valve	8
Dump valve	13
Selector dial pointer mechanism	14
Traction control (TCU)	15
Ram cylinder	16
Linkage support ram	16
Sensing unit	17
Three-point linkage	19
Three-way take-off valve	20
Double-acting live take-off valve	21
 Fault finding	
Tools required	23
Fault Finding Sequence	24
Lift test	25
Hold test	26
Lowering test	26
TCU test	26
Height control test	26
Depth control test	26
 Adjustments	
Abutment plate	27
TCU valve screw	27
Ramshaft cam	28
Control lever connecting link	28
Bleeding the System	28
Quadrant spring carrier	29
Sensing unit cable	29
'Q' Cab control adjustments	30
 Unit removal and replacement	
Filters	33
Hydraulic pump	34
Pump relief valve	34
Dump valve	35
Sensing unit	35
Three-way take-off valve	35
Linkage support ram	36
Double-acting live take-off valve	36
Ramshaft	37
Ram cylinder	38
Selectamatic control valve	39
Selector dial pointer mechanism	39

	Page
Unit maintenance and repair	
Recommended lubricants	41
Full flow filter	42
Hydraulic pump (Plessey)	42
Hydraulic pump (Dowty)	44
Selectamatic control valve	46
Dump valve	49
Selector dial pointer mechanism	50
Ram cylinder	51
Locking latch	51
Ramshaft arm	52
Three-point linkage	52
Linkage support ram	53
Sensing units	54
Three-way take-off valve	56
Double-acting live take-off valve	57
Specifications and data	
Full flow filter	60
Hydraulic pump	60
Pump relief valve	60
Selectamatic control valve	60
Ram cylinder	61
Linkage support ram	61
Sensing unit	61
Three-point linkage	61
Three-way take-off valve	61
Double-acting live take-off valve	61
Summary of design changes	62

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

HOW IT WORKS

Hydraulic System: Mounted between the rear axle and power take-off unit the hydraulic pump is driven from the PTO input shaft and is, therefore, in operation whenever the PTO clutch is engaged.

The pump draws oil through the full-flow filter in the main frame reservoir and pumps it, through pipework, to the distribution block mounted on top of the rear axle case. From the distribution block oil flows to the Selectamatic® control valve and also to any live take-off valves mounted on top of the distribution block.

When the take-off valve is in neutral (hold) position, or if no take-off valve is fitted, a continuous flow of oil is supplied to the Selectamatic valve and when the tractor control lever is in the 'Raise' position oil is directed into the ram cylinder to raise the linkage, or supply oil to an attachment connected to the three-way take-off valve.

Moving the tractor control lever into either the 'Hold' or 'Lower' position diverts pump output into the low pressure pipes, which directs it into the transmission and PTO for lubrication purposes.

When a live take-off valve is moved from its neutral (central) position pump output is diverted from the Selectamatic valve and to the equipment connected to the take-off valve.

The tractor internal hydraulic system is therefore, inoperative whenever a live take-off valve is being used to operate an attachment.

If a three-way take-off valve is fitted, this is bolted to the ram cylinder so that oil flow can be diverted from the tractor ram cylinder and to an external attachment. The tractor control lever can then be used to control external equipment instead of the tractor linkage.

To prevent excessive load being placed on the system a pressure relief valve is connected into the pipe between pump and distribution block. When excessive pressure occurs in the system the valve opens and returns surplus oil into the main frame reservoir.





FIGURE 1 DIAGRAM OF HYDRAULIC SYSTEM WITH SINGLE HYDRAULIC PUMP

HOW IT WORKS




R76 135

FIGURE 2 HYDRAULIC PUMP (PLESSEY)

Hydraulic Pump: The two gear-shaped rotors are meshed together and rotate inside a close-fitting housing. As the rotors turn, the spaces between adjacent gear teeth transfer oil from the inlet to the outlet side of pump — there being no open tooth cavity at point of mesh. The rotors are supported in bearings which not only provide support for the rotor shafts but also seal the side faces of the rotors against oil leakage. Pump efficiency depends on a good seal being maintained between the rotor side faces and bearings. The bearings are, therefore, pressure balanced by feeding pump output pressure into the cavities between the bearings and pump body. The cavities are sealed by 'O' rings and positioned towards outlet side of bearings. When pump output pressure rises, the pressure in bearing cavities also rises so that the tendency of the output pressure to push the bearings apart is balanced by the pressure in the cavities pushing the bearings against the rotor side faces. Oil leakage between the rotor side faces and bearings is thus reduced to a minimum.

Note: Some early tractors have a Dowty hydraulic pump fitted. Later models have a Plessey pump. The description applies generally to both types — detail differences are noted in Unit Maintenance and Repair Section.



R76 136

FIGURE 3
PRESSURE BALANCING
OF PUMP BEARINGS

Full-flow Filter: This is attached on underside of main frame and consists of a paper element filter, a fine screen filter, valve and magnetic filter.

Transmission oil from the main frame reservoir passes through the paper element, where particles down to 40microns are removed. When the filter element becomes choked the restriction to the flow of oil through the element causes a depression, or partial vacuum, on pump side of filter. When this depression reaches 0.28kg/sq cm (4 lb/sq in) the spring-loaded valve inside screen filter is drawn from its seat and allows oil to by-pass the paper element, by flowing through the screen filter and past the magnetic filter. The pump is thus not starved of oil but fed with oil that has not been filtered through the paper element.

As it is not desirable for oil to enter the hydraulic system without first passing through the paper element a vacuum switch, which also operates at 0.28 kg/sq cm (4 lb/sq in), is connected to the pump side of the filter. When the depression in filter is sufficient to open the by-pass valve it, therefore, also closes the switch contacts and lights the warning lamp on instrument panel, to give a visual warning to the operator that the filter element is being by-passed.




FIGURE 4 FILTER BY-PASS VALVE





FIGURE 5 FULL-FLOW FILTER

HOW IT WORKS


Pump Relief Valve: Located on pump body, the relief valve prevents damage to the pump by limiting pump output pressure to a safe figure.

The small plunger is held firmly against the valve seat by the cap and spring. When oil pressure inside system is sufficient to overcome spring tension, the plunger is pushed off its seat and allows oil to escape into reservoir. When system pressure falls the spring returns the plunger to its seat and cuts off the oil flow to reservoir.

As the actual oil pressure required to unseat the valve plunger depends on the spring pressure, shims are fitted between cap and spring to adjust the valve operating pressure to the required setting.



Valve closed




Valve open

FIGURE 6 PUMP RELIEF VALVE

R76 138

Selectamatic Control Valve: This is housed inside the right-hand side of the rear axle case and consists of a body containing eight valves. (see page 12)

By-pass Valve Plunger is held closed by a light spring and has a small hole through its centre to enable oil to pass through plunger and, when upper chamber is sealed, build up equal pressure above and below plunger.



Valve Closed

Valve open

FIGURE 7 BY-PASS VALVE

R76 50

Hold valve plunger is also held against its seat by a light spring and has a hole through its centre incorporating a simple non-return valve, so that oil can flow upwards into chamber at top of plunger but cannot flow in reverse direction.




FIGURE 8 HOLD VALVE

R76 52




FIGURE 9 SPOOL VALVE

Spool Valve Plunger is spring-loaded so that when it is released, ports to both by-pass and hold valves are closed. Both valve plungers are therefore held on their seats by their springs and pump output flows into ram cylinder to raise linkage.


When spool valve plunger is held in mid-position, port from hold valve remains closed, therefore hold valve remains seated, but port from by-pass valve is opened. Oil from top of by-pass plunger then drains to reservoir and as oil cannot flow through plunger orifice fast enough to maintain an equal pressure at top of plunger, oil pressure below

plunger pushes against the light spring to lift plunger off its seat. Pump output then flows out of by-pass port and returns to reservoir: the linkage being held stationary by the oil trapped in the ram cylinder due to the hold valve plunger remaining on its seat.


When spool valve plunger is pushed upwards ports from both by-pass and hold valve plunger are opened. Oil above plungers then flows to reservoir and pressure below plungers pushes them off their seats. Pump output then flows through by-pass port and oil from ram cylinders flows out through hold valve to lower the linkage.

HOW IT WORKS

Non-return Valve is situated between by-pass and hold valve ports. It allows pump output to flow into system when by-pass plunger is on its seat, but prevents oil returning, and thus maintains linkage in raised position when hold valve is seated.



Linkage being raised — Valve open



Linkage held stationary — Valve closed

FIGURE 10 NON-RETURN VALVE

TCU Valve enables a regulated degree of back pressure to be built up in oil passing out of spool valve ports. The same amount of back pressure then builds up on the top of by-pass and hold valve plungers, which causes the plungers to move towards their seats until an equal

amount of back pressure builds up below the plungers. The resulting rise of pressure below plungers is also transmitted to the ram cylinder which gives a partial lifting effort to the linkage for weight transference (traction control) purposes.




FIGURE 11 TCU VALVE

Pressure Relief Valve is connected to the chamber at top of hold valve plunger so that if oil pressure in system rises excessively, as would occur if tractor is driven over rough ground at high speed with a heavy implement supported on linkage, relief valve will be pushed open. The higher pressure below plunger will then push plunger off its seat and allow oil to escape from system until pressure is reduced to a safe figure.




FIGURE 12
HOLD PRESSURE RELIEF VALVE

Latching Valve is in the circuit between chamber at top of by-pass valve and spool valve and the purpose of this valve is to make the by-pass valve plunger very sensitive to small movements of spool valve plunger. If spool valve is only moved by a small amount the latching valve is then closed by the small amount of back pressure and causes by-pass plunger to be pushed quickly on to its seat. This avoids the possibility of the by-pass plunger reaching a balanced condition with the oil pressure above being insufficient to push plunger fully on to its seat and placing the pump under an unnecessary load.

The latching valve therefore gives the by-pass valve quick response to small spool valve movement: as this rapid response is not required when using TCU (weight transference) a drilling from the TCU valve allows pressure to be applied on the spring side of the latching valve. Closing the TCU valve does not therefore operate the latching valve as equal pressure is applied to both sides, enabling the spring to hold the valve in the full open position.




FIGURE 13 LATCHING VALVE




FIGURE 14 BASIC FUNCTION OF VALVES IN SELECTAMATIC VALVE ASSEMBLY




FIGURE 15 RATE OF LOWERING VALVE

Rate-of-Lowering Valve controls the flow of oil coming out of the hold valve port, valve plunger is spring-loaded towards the end of its bore and back pressure of oil tends to push plunger against its spring and therefore closes ports admitting oil into plunger. Any change in back pressure caused by repositioning the control needle will make a corresponding change in position of valve plunger.

The position of valve plunger and therefore opening of lowering port, is thus controlled by the position of the lowering control needle. The valve spool automatically compensating for any difference in weight of implement, by regulating the amount of port opening to give a constant flow of oil out of the system.

Dump Valve is screwed into the Selectamatic valve chest. It is positioned over the hold valve plunger and is a two-position stop for the hold plunger spring. When the valve is pushed down and turned the hold plunger spring is compressed and plunger operates normally. When system is being used with equipment having a very low back pressure the valve can be turned and pulled upwards. This releases the plunger spring so that the low back pressure is able to push hold plunger off its seat and allow equipment to lower rapidly.




FIGURE 16 DUMP VALVE




FIGURE 17 DIAL POINTER MECHANISM

Selector Dial Pointer: Selection of the method of operation, i.e.: depth control, height control or TCU/EXT, is by means of the dial pointer on right-hand ramshaft bracket.

When in depth control, movement of the sensing unit must be transmitted to the spool in the Selectamatic valve, any variation in implement depth will then result in the spool valve being moved to counteract the change and restore the original depth. This is obtained by positioning the valve rocker lever under the depth control push rod so that movement of the push rod, which is connected to the sensing unit by flexible cable, also moves the valve spool.

The rocker lever does however, remain under the height control push rod so that when the linkage reaches full height, the ramshaft cam pushes the valve spool into the 'hold' position and relieves the pump of unnecessary load.

Turning the dial pointer from 'depth' to 'height' slides the rocker lever sideways so that the rocker heel is clear of the depth control push rod but under the height control push rod. The sensing unit is therefore, disconnected from transmitting any movement to the spool valve. As the height control push rod is in contact with the ramshaft cam any ramshaft movement will also move the push rod which in turn will move the rocker lever and valve spool. The position of the ramshaft cam thus be set by the control lever and any subsequent linkage movement will then be restored automatically, by the spool valve being moved sufficient to correct the linkage movement.

Turning dial pointer into TCU/EXT slides the rocker lever further sideways so that front end of rocker rides on to abutment plate. Rocker therefore, pivots on this plate and control lever can be moved to 'raise', 'hold', 'lower' or 'TCU' position.


Traction Control: This is the David Brown method of increasing wheel grip (traction) by transferring weight from the implement on to the tractor. The additional weight on the tractor then acts as ballast and reduces wheel slip.

When a tractor has a mounted implement raised on its hydraulic linkage the full implement weight is being supported by the tractor and the weight on the tractor rear wheels will be the normal tractor rear-wheel weight plus the implement weight; as the centre of gravity of the implement is not of course directly over the tractor rear wheels but some distance behind, the implement will when raised, have a leverage effect and add more weight on the tractor rear wheels than the actual implement weight.

When the implement is lowered into work the tractor rear-wheel weight will return to its normal unloaded weight and the weight of the implement will rest on its own depth wheel. As wheel-grip depends on rear wheel weight it will be seen that this is at maximum when implement is raised and minimum when it is in work. This is exactly opposite to what is required, for maximum wheel-grip is needed when implement is in work and requires a considerable draught to pull it through the ground.


The implement is raised out of work by oil pressure in the ram cylinder. The actual oil pressure required to raise the linkage depends on the implement weight and also the geometry of the linkage but whatever the pressure is, if less than this pressure is applied in the ram cylinder the implement will not be raised. The effect of having pressure in the ram cylinder will however, be to exert an upward, or lifting, force on the implement and whilst this will be insufficient to raise the implement it will also push downwards on the tractor with an equal force. The force pushing the tractor downwards will push the tractor rear wheels harder on the ground in exactly the same way as when raising the implement, the extra weight on the tractor rear wheels will not be the full implement but only a portion of it and this will make a very useful form of ballast.

The amount of ballast obtained in this way is called weight transference, because weight is transferred from implement to tractor rear wheels, and is determined by the oil pressure in the ram cylinder; if the pressure is reduced the amount of weight transference is reduced until the pressure reaches zero, when no transference takes place. This gives an advantage over fixed ballast in that only the required amount of weight transference need be used and this is instantly available by just pushing the control lever forward. The TCU valve is then held on its seat and gives the required amount of back pressure in the ram cylinder.




RT6 61

TRACTOR WITH IMPLEMENT RAISED ON LINKAGE
Weight on rear wheels equals tractor rear wheel weight 'A' plus weight of implement 'B'



TRACTOR WITH IMPLEMENT LOWERED AND NO PRESSURE IN HYDRAULIC SYSTEM
Weight on rear wheels 'A' is tractor rear wheel weight only. Weight of implement 'B' resting on its own depth wheel



RT6 62

TRACTOR WITH IMPLEMENT LOWERED AND REDUCED PRESSURE IN HYDRAULIC SYSTEM
Weight on tractor rear wheels 'A' equals tractor rear wheel weight plus a proportion of implement weight 'B'

FIGURE 18 WEIGHT DISTRIBUTION OF TRACTOR WITH MOUNTED IMPLEMENT

HOW IT WORKS

Ram Cylinder is housed inside left-hand side of rear axle case. When Selectamatic valve connects pump output into ram cylinder the oil pressure rises rapidly until there is sufficient pressure against piston to push piston along cylinder. The piston then turns ramshaft via connecting link and ramshaft arm, to raise the linkage. When by-pass valve is opened pump output is returned to reservoir, ram cylinder piston therefore remains stationary, hold valve and non-return valves preventing any oil passing out of cylinder.

When hold valve is raised off its seat weight of implement pushes piston, via ramshaft arm and connecting link, along cylinder and forces oil out of cylinder through hold valve and rate of lowering valve.

The ram cylinder cover incorporates a locking latch. As piston reaches end of its stroke, ramshaft arm passes end of the locking pin and if pin is released into engaged position, arm will be locked to hold linkage in raised position.




FIGURE 19 RAM CYLINDER

Linkage Support Ram: This is an additional ram cylinder which is fitted to 9 Series tractors when exceptionally heavy implements have to be supported on the linkage. Mounted on the right-hand side and bolted to the drawbar frame, the ram is connected to port 1 on the three-way take-off valve. When the take-off valve control lever is placed in position L/1 both internal ram cylinder and support ram are connected together. Both rams therefore operate together, the support ram operating directly on the right-hand ramshaft lever and the internal ram cylinder operating in its normal way.




FIGURE 20 LINKAGE SUPPORT RAM

Sensing Unit: When an implement such as a plough is in work it requires an effort, which is called draught, to pull it through the ground. The actual draught required depends on many factors, such as the number and width of the furrows and the ground conditions but whatever the draught of an implement is, it must increase with the operating depth. If the depth is increased, the amount of work done by the plough is increased therefore there is a corresponding increase in the work done by the tractor, which has to pull harder to combat the increased draught. As the only connection between tractor and plough is by means of the three-point linkage the implement draught is transmitted through the three links. Due to the linkage being positioned above the plough bodies the plough tends to pivot forward as it is pulled through the ground.

The plough cannot actually pivot forward because the top link will resist any pivoting force by holding the headstock away from the tractor. The amount of force required to hold the headstock away from

the tractor depends on various factors such as type of plough and operating conditions but whatever the force is, it will be at a minimum when shallow ploughing, which requires a light draught, and maximum when plough at full depth and, therefore, requires greatest draught. The tendency for the plough to pivot forward and compress the top link is therefore a guide to the operating depth of the implement, for as implement depth increases the amount of compression in top link will increase. If top link is not therefore rigidly attached to tractor, but connected to a spring-loaded attachment point the amount of compression, and therefore depth of implement will be 'sensed' by this attachment point, which will compress the spring according to the implement depth.

The sensing unit therefore 'senses' the implement depth, by responding to changes in top link compression, and counteracts this by moving the Selectamatic control valve, via a flexible cable, to raise, or lower, the linkage and thus maintain a constant operating depth.




FIGURE 21 LINKAGE FORCES WHEN PLOUGHING

HOW IT WORKS

Selective Sensing Unit is fitted with two springs of different strengths. When the spring support is turned so that it is clear of thrust washers at both ends of support, both springs are in operation but when support is turned so that shoulders on end of support are not opposite slots in thrust washer the spring at that end of support cannot then be

compressed and only the remaining spring is in operation.

By turning the sleeve into any of its three positions the strong, light or both springs can be brought into operation to give 'sensing' for heavy, medium or light draught implements.




FIGURE 22 SELECTIVE SENSING UNIT

R76 67

Three-point Linkage: This is the connecting link between tractor and implement. The two lower links are of fixed length but the top link is adjustable, so that the implement can be set to its most suitable working position.

The lower links are raised by the ramshaft which is connected to the links by means of two adjustable rods. The left-hand lift rod is first set to give the implement its required operating range, then the levelling lever on the right-hand side used for any levelling adjustments required when implement is in work.




FIGURE 23 THREE-POINT LINKAGE

HOW IT WORKS

Three-way Take-off Valve: Fitted on the front end of the ram cylinder — in place of the connector — this valve enables the oil flow from pump to be diverted from ram cylinder to either of the two take-off points.

The valve control lever operates a spool which has four positions. When spool is pushed down, inlet port in valve body is connected to upper take-off point and when spool is moved up into second position

inlet port is connected to lower take-off port. When spool is moved into third position valve inlet port is connected into ram cylinder and both take-off ports are closed. Tractor linkage then operates normally and any equipment connected to the take-off ports is held stationary. Moving spool valve fully upwards connects valve inlet port to both ram cylinder and upper take-off port: any equipment connected to this port will then operate simultaneously with the tractor linkage.




FIGURE 24 THREE-WAY TAKE-OFF VALVE

Double-acting Live Take-off Valve: This valve fits on right-hand side of rear axle case and provides a double-acting (i.e.: oil pressure and also oil return) take-off point which is 'live' whenever pump is in operation regardless of position of Selectamatic control lever.

If two double-acting take-off points are required a second valve can be bolted directly on top of first valve.

When valve lever is in its central (neutral) position pump output flows into the Selectamatic valve and oil flow to both ports is sealed. The tractor hydraulic system therefore, functions normally and any equipment connected to the take-off is held stationary.

Moving valve lever forwards diverts pump output from Selectamatic

valve and directs it to take-off port 'A', at the same time take-off port 'B' is connected to oil return pipe to reservoir.

When valve lever is moved rearwards the oil flow is reversed, port 'A' being oil return and 'B' the pressure supply. Equipment incorporating double-acting rams can thus be operated by moving valve lever either way to give the direction of motion required.

When valve lever is moved its full distance in either direction the spring-loaded detent holds the lever in this position until ram cylinder on equipment reaches end of its travel and oil pressure in system rises sufficiently to operate the automatic release. This causes valve to 'kick-out' automatically and lever returns to the neutral (central) position.




FIGURE 25 DOUBLE-ACTING LIVE TAKE-OFF VALVE

FAULT FINDING

Given an adequate supply of **Clean** oil the Selectamatic hydraulic system will give long and trouble-free service. Unsatisfactory operation may however be experienced if the system is incorrectly adjusted or if the transmission oil is allowed to become contaminated with dirt, or water.


If the system appears to operate incorrectly, the fault should first be located and the cause established before any dismantling is undertaken:

Tools required for fault finding:-


Pressure gauge (0-4,000lb/sq in)
Pressure gauge (0-250kg/sq cm)
Adaptor
Union $\frac{1}{2}$ BSP
Flexible pipe, $\frac{1}{2}$ BSP
Connector housing
Blanking Plunger
Connector
Setting gauge

DB960984
DB960985
DB960646
DB962235
K84522
DB961821
DB961977
DB917127
DB961796


Note: Tools with prefix DB are supplied by V. L. Churchill & Co. (or their agents outside U.K.).




Pressure gauge — DB960984




Connector housing DB961821




Adaptor DB960646



Flexible pipe
 $\frac{1}{2}$ BSP K84522 &
Union DB962235



Connector DB917127



Blanking plunger
DB961977

R76 139

FIGURE 26 FAULT-FINDING TOOLS

FAULT FINDING

Fault Finding Sequence

Ensure that the transmission reservoir is filled to the correct level with oil which is of the correct viscosity and at operating temperature.

To raise the temperature of cold oil select TCU/EXT and run engine at 1600/1800 rev/min at full TCU for 15 minutes. **Do not attempt to raise the oil temperature by holding the control lever in the Select position:** this will aerate the oil and possibly damage the pump.

Whilst waiting for oil to reach its working temperature, clean tractor of all external dust, particularly in areas of hydraulic controls and cover plates.

First Stage (checking tractor settings)

Before carrying out any detailed fault finding first check the following adjustments.

A. Ramshaft cam — affects hold when height or depth is selected.

Remove cover plate from right-hand ramshaft bracket and lift linkage by hand. Hold the linkage in the fully raised position and engage the locking latch.

With linkage at full height check that roller at end of height control push rod is seated in the cam plate indentation. If not, release the two nuts then turn the cam plate in the required direction and re-tighten the nuts.




FIGURE 27 SETTING THE RAMSHAFT CAM

B. Control rod — affects TCU pressure and lift, particularly when selector is in TCU/EXT position.

With engine stopped, remove cover plate, complete with rate-of-lowering control, from front of quadrant housing and small cover plate from right-hand side of rear axle case.

Turn dial pointer into 'Height' position and lower the linkage. Hold control lever fully rearwards against quadrant spring ('Select' positions).

Set position of Nyloc nut on control rod — this is accessible through front of housing — so that it is possible to turn the dial pointer from Height to TCU/EXT and back without lifting the spool valve. This can be observed through axle case aperture and should be done with a dial gauge, if available.




FIGURE 28 CONTROL ROD SETTING

C. Quadrant spring and friction pad adjustment — affects cancelling of pump in lift and hold positions.

Check the control lever movement: it should be free to move but not so slack that it can be moved by vibration. If necessary adjust the pivot tension by tightening, or releasing, the locknuts on the lever pivot shaft.

Turn dial pointer into 'Height' control position then start engine. Hold control lever fully rearwards, against quadrant spring, and allow linkage to rise.

When linkage reaches full height and relief valve starts 'screaming', move control lever slowly forwards until pump is unloaded and relief valve ceases to operate.

Pump should be unloaded when control lever is touching quadrant spring but should come under load when lever is moved rearwards against the spring.




FIGURE 29 SPRING CARRIER SETTING

- D. Sensing unit cable — affects hold and range of depth control on quadrant when depth selected.

Turn dial pointer into 'Depth' control position and attach test weight to lower links. If a suitable test weight is not available attach a heavy implement to lower links but use a chain to attach headstock to ramshaft instead of the top link; it is essential that the top link is disconnected so that no compression or tension load is applied to the sensing unit.

Start engine and move control lever rearwards until it touches the quadrant spring. Allow linkage to rise to full height then stop engine.

Whilst keeping clear of implement, slowly unscrew the adjuster on sensing unit cable until the linkage commences to creep down then screw the adjuster **inwards** 5½ turns. Hold adjuster stationary and tighten locknut.




FIGURE 30 SENSING UNIT CABLE SETTING

Second Stage (checking operation)

A. Lift Test

Start engine and move control lever fully rearwards against quadrant spring.

If a considerable time lag occurs before implement commences to lift this could be due to an obstruction in the by-pass valve plunger filter or, if cleaning the filter fails to correct it, the latching valve stuck in its open position.

If implement fails to lift or lifts very slowly.

1. Ensure that dump valve is closed: pushed down and turned.
2. Check that three-way valve is set in the correct position: either L or L1.
3. Check that any live 'take-off' valves fitted are in the neutral (central) position.
4. Check transmission oil level: extra oil may be required when using external rams.
5. Carry out hold test. If system drops in hold position, rectify hold fault before proceeding.
6. Check pump pressure: fit connector on top of rear axle case and connect pressure gauge then restart engine: a pressure reading of less than 140kg/sq cm (2000lb/sq in) could be caused by:-

- (a) choked inlet filter
- (b) suction leak on pump inlet pipe
- (c) worn hydraulic pump
- (d) faulty relief valve

Caution: Do not run engine faster than idling speed when carrying out this test.

7. If pressure reading is satisfactory, indicating no fault on pump side of control valve, remove adaptor plate and connect pressure gauge to three-way valve, or, if no valve is fitted, use the special connector housing.




FIGURE 31 CHECKING PUMP PRESSURE

Restart engine and hold control lever against quadrant spring and note pressure reading. A low reading here could be caused by:-

- (a) blocked, or seized, by-pass plunger. Remove plunger and clean filter with an air blast. Ensure that plunger moves quite freely and check that hold plunger is also free. Before replacing plungers run engine at idling speed for a few minutes, to flush valve bores with oil.
- (b) if gauge shows no reading but relief valve is 'screaming', showing that pump is under load, this indicates an obstruction in control valve; probably a loose non-return valve seat.
- (c) leaking 'O' rings at front of control valve or failed control valve pipe. Remove quadrant housing from front of axle case to examine pipe and 'O' rings.




FIGURE 32 CHECKING PRESSURE AT RAM CYLINDER

FAULT FINDING

B. Hold Test

1. Turn selector dial pointer into TCU/EXT then start engine and move control lever rearwards against quadrant spring. Allow implement to rise then release control lever and allow quadrant spring to move control lever into its 'hold' position.
2. Implement should remain stationary and if it gradually falls this indicates that oil is leaking from the system.
 - (a) Isolate ram cylinder by moving three-way valve lever to position I, whilst implement is raised. If implement then remains stationary the leakage is from control valve or pipe, but if there is no difference the leakage is from ram cylinder or take-off valve.
 - (b) Remove axle cover plate and check control valve for leakage.
 - (c) Examine sealing washers on plugs, or dump valve for leakage.
 - (d) Check hold plunger for leakage by using a mirror to observe any oil leaking out of lowering valve slot. Any leakage out of this slot when lever is in 'hold' position indicates a leaking hold valve or a leaking 'O' ring under hold valve seat.
 - (e) Remove by-pass valve plunger and check level of oil in plunger bore. Oil flowing into bottom of port and raising oil level indicates a leaking non-return valve.
 - (f) Oil leakage from hold relief valve plug indicates a faulty hold relief valve.
 - (g) Leakage from rear face of valve chest — drips can be seen when ramshaft bracket cover is removed — indicates a leaking spool valve. Turn spool through 90° and the rate of leakage will vary.
 - (h) Remove quadrant housing and check pressure pipe and pipe connector 'O' rings for leakage.

C. Lowering Test

1. Select 'Depth' or 'Height' position, start engine and raise linkage then move control lever into 'Lower' position. If implement is lowered correctly move on to the TCU test.
2. If implement does not lower, or lowers very slowly.
 - (a) Check that lift latch is disengaged.
 - (b) Screw rate of lowering valve fully outwards.
 - (c) Ensure that transmission is filled with oil of the correct grade: oil must also be warm.
 - (d) When operating with external rams the dimensions and positioning of the rams may result in only a small back pressure. For a reasonable rate of lowering a minimum of 7kg/sq cm (100lb/sq in) back pressure is required.
 - (e) Incorrect TCU adjustment could cause a high back pressure — see TCU test.
 - (f) A slow drop can be caused by the rate-of-lowering valve being seized in the closed position or by faulty assembly (plunger fitted wrong way round).
 - (g) If implement only lowers at slow engine speeds this could be caused by latching valve being seized in the closed position. The by-pass valve will then always be held on its seat and the implement will therefore rise in both lift and hold positions of control lever. The implement will only lower when the pump output is so low that it can escape past the rate-of-lowering valve. To check for a sticking latching valve, select TCU/EXT and place control lever in 'lower' position. If linkage then rises when control lever is moved from 'lower' to 'hold' this indicates a sticking latching valve.

D. TCU Test

1. Connect pressure gauge into three-way valve, or ram cylinder connector.
2. Select TCU/EXT then start engine. As control lever is moved slowly forward into TCU range the pressure should rise to 49–52kg/cm² (700–750lb/in²).
3. An incorrect pressure reading could be caused by:—
 - (a) incorrectly adjusted TCU plunger.
 - (b) incorrectly set adjusting screw in rocker lever.
 - (c) incorrect, or broken TCU valve spring.
 - (d) slow build-up of TCU pressure may be due to missing ball from hold valve plunger.




FIGURE 33 CHECKING TCU PRESSURE


E. Height Control Test

1. Select 'Height' control, start engine and move control lever slowly rearwards. The implement should rise and follow the control lever. Movement up, or down, of the lever causing a corresponding movement in the linkage.
2. If implement moves erratically as position of control lever is varied, check for fouling, or seizure of the control rod, push rod and other linkage.
3. Heavy implements may drop slightly below the required position and then immediately return to the correct position. This is normal and is due to the slow response of the hold valve.

F. Depth Control Test

1. Place dial pointer in 'Depth' position, start engine and move control lever into 'raise' position.
2. Drive tractor, lower implement into work and check operating depth.
3. If implement does not operate satisfactorily first check that implement is set correctly and the linkage is attached to the headstock in such a manner to give sufficient compression, or tension, in the top link.
4. If tractor is fitted with a Selective sensing unit, check that the correct range is in use. It is essential that the force on the top link is sufficient to give the sensing unit shaft 1.6 to 3.2mm ($\frac{1}{16}$ to $\frac{1}{8}$ in) movement when the implement is in work. The sensing unit cannot operate correctly if the force is so great that it holds the spring fully compressed or if it is insufficient to compress the spring at all.
5. If the implement depth fluctuates, check for a seized or damaged sensing unit, sticking or damaged cable or cable linkage: bell crank lever, push rod, etc.

ADJUSTMENTS



$X = 0.437 \text{ in. (11.1mm)}$
 $Y = 1.580 \text{ in. (40.1mm)}$

FIGURE 34 SETTING GAUGE
 (Service Tool DB961796)




FIGURE 35 SETTING THE ABUTMENT PLATE

The settings and adjustments required on the Selectamatic system may be divided into two groups.

The first group (Nos. 1 and 2) are bench settings and are only required when a control valve is fitted to a ramshaft bracket.

The second group (Nos. 3 to 7) are tractor settings and must be carried out whenever any dismantling is done which disturbs the original settings. Note that tractor settings for models fitted with a 'Q' cab (which have a different control layout) are listed separately on page 30.

ONE — Setting the abutment plate

After bolting valve assembly on to ramshaft bracket, place dial pointer in TCU/EXT position. Engage inner hole of setting gauge on the rocker shaft pin and hold gauge against face of bracket spigot. With abutment plate firmly bolted in position and touching the underside of rocker lever, check clearance between the rocker lever and spool valve this should be 0.025 to 0.075mm (0.001 to 0.003in). If the clearance is incorrect remove abutment plate and add or remove shims as required. Ensure abutment plate seats correctly when refitted and after firmly tightening retaining bolt, recheck the clearance.

TWO — Setting the TCU valve screw

With the dial pointer in the TCU/EXT position, engage outer hole of setting gauge on the rocker shaft pin and hold gauge against face of bracket spigot. After releasing the locknut tighten adjusting screw until it just touches the TCU valve, but does not compress the spring, then screw in a further **complete turn** and firmly tighten the locknut. As the point at which the ball valve just touches its seat is not easy to determine, this setting should be done with the valve inverted and a 0.05mm (0.002in) feeler gauge inserted between the plunger and screw. The adjusting screw can then be screwed inwards until it begins to hold the feeler gauge, then the gauge withdrawn and the adjusting screw screwed in further as required.




FIGURE 36 SETTING THE TCU VALVE SCREW

ADJUSTMENTS

THREE — Setting the ramshaft cam

Remove cover plate from right-hand ramshaft bracket and lift linkage by hand. Hold the linkage in the fully raised position and engage the locking latch.

With linkage at full height check that roller at end of height control push rod is seated in the cam plate indentation. If not, release the two nuts then turn the cam plate in the required direction and re-tighten the nuts.




FIGURE 37 SETTING THE RAMSHAFT CAM




FIGURE 38 SETTING THE CONNECTING LINK NUT

FOUR — Setting the connecting link

Disengage lift latch, lower the linkage and remove cover plate from top of axle case. Remove cover from front of control lever housing and unscrew the Nyloc nut until it is level with the end of the connecting link. Release the spring carrier nut and slide carrier to the rear of quadrant slot. Place a small spanner between the control lever and rear finger guide, then move the finger guide rearwards until the control lever is pushed into the Select position and tighten the finger guide clamp nut to hold the control lever in this position. Rest a finger on top of the spool valve and with the control lever held in the Select position, flick selector knob from TCU/EXT. to Height and back to TCU/EXT. a few times. Flicking the selector knob in this manner will cause the spool valve to lift and when this movement can be felt — and it is useless to proceed until movement of the spool valve has been established — tighten nut further on to connecting rod. Recheck spool valve movement after each turn of nut, noting that the amount of valve movement will reduce as nut is tightened. Continue tightening nut until the point is reached where **spool valve movement just ceases**. As it is important to tighten the nut only to the point where valve movement ceases and not past this point, take extra care when reaching this position. Check valve movement more frequently and do not confuse a slight kick of the valve with actual movement. If in doubt, unscrew nut a little and try again.

Later tractors have a plug at the rear of the axle cover plate to enable spool valve movement to be checked with a dial gauge. If plug is removed and a dial gauge mounted so that its finger passes through the hole and rests on top of spool, valve movement will be shown when dial pointer is flicked from TCU/EXT. to Height and enable the nut to be tightened until movement just ceases. Do not confuse a slight kick of the needle with actual movement: if needle kicks but returns to its original position the valve is not actually moving.

When the nut has been set correctly, replace control lever housing cover, turning the lowering control knob so that spindle slot engages with the needle valve peg.

FIVE — Bleeding the system

Start engine and bleed the system by first removing the cover plate from the right-hand side of rear axle case, to gain access to the two plugs on the control valve; unscrew both plugs about two turns and place control lever in Select position until air-free oil is expelled. Move control lever forward, to make the pump inoperative, before firmly retightening the plugs; otherwise the pressure may prevent the washers from seating correctly and cause leakage later. Replace inspection cover on top of axle case and remove air from ram cylinder.

Unscrew the bleed valve at front of ram cylinder until air-free oil is expelled.




FIGURE 39 BLEEDING THE HYDRAULIC SYSTEM

SIX — Setting the quadrant spring

Check the movement of control lever; it should be free to move but not so slack that it can be moved by vibration. If necessary adjust the pivot tension by tightening, or releasing, the locknuts on the lever pivot shaft.




FIGURE 40 SETTING THE QUADRANT SPRING

Place the control lever in the Select position and turn selector knob into the Height position. Start the engine and allow linkage to rise. When the linkage reaches full height the pump relief valve will open and make a 'screaming' sound. When this occurs move control lever slowly forward until the 'screaming' stops, then release spring carrier nut and move spring carrier forward in its slot until it touches, but does not move the control lever, and tighten the nut. As overheating of the oil and premature wear of the pump will take place if pump relief valve is in continuous operation, ensure that the valve only operates when control lever is held against the spring and does not operate when the lever is released. If necessary make a slight adjustment to the spring carrier before finally tightening the clamp nut.

SEVEN — Setting the sensing unit cable

For this setting it is necessary to have weight on the lower links but the top link disconnected, so that no compression or tension load is applied to the sensing unit. This condition may be achieved in a number of ways; a bar across the link-ends so that a weight can be supported is ideal, but a plough can be used if it is first lifted normally, a support placed under the rear landside and then slowly lowered until the top link can be disconnected (placing the selector knob in Height control will enable this operation to be carried out quite easily).





FIGURE 41 SETTING THE SENSING UNIT CABLE

With weight on the lower links and top link disconnected, place selector knob in Depth control position. After releasing the locknut, screw cable adjuster fully inwards to ensure that there is slackness in the cable. Move control lever rearwards until it touches the quadrant spring and start engine. Allow linkage to rise to full height and reach the Hold position then stop engine. With control lever touching quadrant spring, screw the adjuster outwards until linkage commences to creep down then screw adjuster inwards five-and-a-quarter turns (9 series) or nine and a quarter turns (885) before tightening locknut.

ADJUSTMENTS

Q cab adjustments: On Q cab tractors all internal adjustments are identical to those listed for non-Q cab models but external control adjustments differ. Prior to carrying out adjustments, it is recommended that a 0-250kg/cm² (0-4000lb/in²) pressure gauge is fitted, with the 3-way valve lever in the L or L1 position to give an accurate indication of relief valve operation. If connecting link setting cannot be obtained using the following procedure, use method detailed for non-Q cab tractors.

Note: Before making any adjustment, ensure that friction lever select stop contacts its abutment bracket with quadrant lever held fully rearwards. Move quadrant select stop or adjust control rod length if necessary, to obtain this condition before proceeding.

ONE — Setting the ramshaft cam

Engine — Stopped
Dial selector — HEIGHT
Linkage — fully raised

Conditions prior to adjustment

Adjust height control so that push rod roller engages on the cam indentation.

TWO — Bleeding the system

Engine — Running
Dial selector — HEIGHT
Quadrant lever — SELECT
Bleed system as for non-Q cab models

THREE — Setting the connecting link

Engine — 800 r.p.m.
Dial selector — EXTERNAL
Linkage — Raised
Quadrant lever — SELECT

Adjust by screwing the connecting link Nyloc nut anti-clockwise until relief valve will not unseat. Then screw nut clockwise in stages of $\frac{1}{2}$ turn until relief valve just unseats positively when quadrant lever is moved slowly from LIFT to SELECT.

FOUR — Setting the quadrant lever spring

Engine — 800 r.p.m.
Dial selector — HEIGHT
Linkage — raised
Quadrant lever — SELECT

Adjust friction lever locknuts to obtain maximum drag whilst permitting positive return of lever from Select position. Check action only with locknuts tight. Adjust select spring carrier to ensure that pump relief valve stops unseating when the hand lever is slowly released from Select position, but without the linkage dropping from its raised position.

FIVE — Setting the quadrant lever control rod

Engine — stopped
Dial selector — HEIGHT
Linkage — lowered
Quadrant lever — rod disconnected

Adjust control rod so that friction lever (Fig. 42) is held against lower stop when hand lever is 3mm ($\frac{1}{8}$ in) clear of forward end of quadrant slot. If there is insufficient drop on height control, file 3mm ($\frac{1}{8}$ in) off fixed stop pin and file forward end of slot to suit. Repeat rod adjustment checks on completion.

SIX — Setting quadrant select stop

Engine — 800 r.p.m.
Dial Selector — EXTERNAL
Linkage — raised
Quadrant lever — SELECT

Adjust select stop on quadrant so that it just contacts the hand lever when friction lever stop is against the select stop abutment with the relief valve unseated. If there is insufficient rearward adjustment available, file forward end of quadrant slot and repeat adjustments FIVE and SIX

SEVEN — Setting the sensing unit cable

Engine — stopped
Dial selector — DEPTH
Linkage — raised
Quadrant lever — LIFT
Adjust as for non-Q cab tractors.




FIGURE 42 Q CAB CONTROL ADJUSTMENT

UNIT REMOVAL AND REPLACEMENT

IMPORTANT

Before attempting to remove any plugs, covers or hydraulic system components it is essential that the surrounding area of the tractor is thoroughly cleaned.

Failure to observe this precaution will result in dirt entering the transmission oil and causing faulty operation of the hydraulic system after re-assembly.

Full Flow Filter: The paper element should be renewed every 500 hours, or if the warning lamp is not extinguished when engine is running at 1800 rev/min and oil is warm.

To renew filter it is first necessary to drain transmission oil, by removing cover drain plug: if oil is to be re-used drain it into a clean container and keep it covered.

After draining the oil, remove housing cover and filter assembly. Separate the filter from cover, wash the screen filter in clean fuel oil then clean with an air blast: ensuring that no particles are left adhering to the magnet. Do not attempt to clean a paper element and handle new element very carefully; the edges of the element are easily split when dry and a damaged element is useless.

Replace screen filter on a new paper element then after cleaning cover fit filter assembly on cover, ensuring the 'O' rings at top and bottom of element are correctly seated. Clean housing face, fit a new gasket then replace cover, tightening bolts evenly. Replace drain plug.

Refill transmission with oil. If original oil is being re-used, pour this through a funnel fitted with a fine screen filter and discard the last gallon, which will have accumulated any sediment.

Non Full Flow Filter: Early tractors not incorporating full flow filtration have a separate by-pass oil filter located on rear axle case. Screen and magnetic filter only are fitted in sump. Renew by-pass filter element every 500 hours and clean screen and magnetic filter at same time. Use clean paraffin for cleaning purposes and fit new sump cover gasket upon re-assembly. Tighten sump cover bolts evenly to avoid distortion of cover.




FIGURE 44 GAUZE AND MAGNETIC FILTER

A. Filter gauze B. Drain plug C. Sump cover




FIGURE 43
FULL FLOW TRANSMISSION OIL FILTER

A. Filter Housing B. Transmission Drain Plug
C. Rear Axle Drain




FIGURE 45 BY-PASS OIL FILTER

A. Filter bowl B. Bowl securing bolt

UNIT REMOVAL AND REPLACEMENT


Hydraulic Pump: Whilst draining the transmission oil, disconnect drawbar frame from hitch plates and lower the rear end of frame to ground.

When transmission is drained of oil, remove the vacuum switch adaptor from underside of the PTO case. (Switch is not fitted on early tractors). Disconnect the check chains, slacken sensing unit bolts, remove PTO flange bolts and install two guide studs ($\frac{7}{16}$ UNC \times 75mm). Free PTO unit from rear axle casing dowel and then remove sensing unit. Withdraw PTO unit rearwards clear of tractor.

The hydraulic pump is mounted on its support plate and is exposed when PTO unit is removed. To remove pump from its support, renew the four setscrews attaching oil inlet pipe to base of pump body then remove the two setscrews and nut from pump body, before carefully levering the pump off its dowels. Removing the pump will expose the

Running in a new pump: When a new, or overhauled pump is fitted, it should be run in for a minimum period of 10 minutes. To 'run in' a pump, place dial pointer in TCU/Ext position and control lever in Lower position. Start engine and run at approx. 1500 rev/min. whilst very slowly moving the control lever forwards so that after 8 or 9 minutes a position of full TCU is reached, then follow this with a minute of three-second periods in the Select position. Do not hold the control lever in the Select position for long periods otherwise the internal pump seals may be damaged.

If output pressure is correct, pump is suitable for normal service.



REAR AXLE WITH PTO UNIT REMOVED

- | | |
|----------------------|-----------------------|
| A. Hydraulic pump | B. Pump drive gear |
| C. PTO driving shaft | D. Pump support plate |
| E. PTO oil feed pipe | |

FIGURE 46
HYDRAULIC PUMP

pump outlet connection, which protrudes through the support plate and into the pump body.

Before refitting a pump, first fit new 'O' rings on pump outlet connection and inlet pipe flange, then carefully push pump into position on its dowels: DO NOT STRIKE, OR PUSH AGAINST THE DRIVE GEAR. Tighten the pump mounting bolts evenly then replace the four setscrews in end of pump inlet pipe.

Check that PTO cardan shaft is engaged in its clutch plate splines: turn and push coupling until shaft cannot be turned.

Smear a new gasket with grease and fit it on support plate. Screw two guide studs, $\frac{7}{16}$ UNC \times 3in (75mm) into two opposite axle case bolt holes. Lift PTO unit on to studs and slide it into position. Engage high ratio and turn PTO output shaft until input shaft splines are engaged into coupling splines. Do not use force to push the unit into position: if unit will not go "fully home", turn engine so that the pump driving gears are turned into mesh with stationary pump gear. Unscrew guide studs, fit retaining bolts and replace the vacuum switch adaptor (where fitted). Reconnect check chains and drawbar frame, replace drain plug and refill transmission with oil. If original oil is being re-used, pour it through a funnel fitted with a fine screen filter and discard the last gallon which will have accumulated any sediment. Replace sensing unit.

Pump Relief Valve: As this is attached to top of pump body it is therefore necessary to drain the transmission oil into clean containers and remove the PTO unit: not forgetting to first remove the vacuum switch adaptor from underside of the PTO case.

Withdrawing the PTO unit will expose the hydraulic pump and removing the three bolts from valve flange will enable the relief valve to be removed.

Before refitting a relief valve, fit a new 'O' ring in groove on pump body to face then fit valve and tighten the retaining bolts evenly.

Fit a new gasket on pump support plate, after smearing it with grease, screw two guide studs into axle case then check that PTO cardan shaft is engaged in its clutch plate splines, by pushing and turning shaft coupling until it locks.

Refit PTO unit, engaging high ratio and turning output shaft until input shaft engages in drive coupling splines. If necessary turn engine so that pump driving gear teeth are meshed correctly: it should not be necessary to force the PTO unit into position.

After bolting PTO unit in position, replace vacuum switch adaptor and refill transmission with oil. If original oil is being re-used, pour it through a funnel fitted with a fine screen filter and discard the last gallon, which will have accumulated any sediment.

Dump Valve: Dump valve is fitted through right-hand side of rear axle case; thoroughly clean this area before commencing valve removal. To remove valve, simply unscrew it from the control valve body, ensuring that no dirt falls inside the axle case.

When refitting valve, smear sealing ring with grease so that it will remain in position with valve inverted. With the hold plunger spring in centre of its bore, screw valve into place then firmly tighten.




FIGURE 47
DUMP VALVE

Sensing unit flexible cable: To remove the flexible cable remove cover from right-hand ramshaft bracket and disconnect cable from actuating lever. The cable can then be pulled out of the bracket casting. On 9 Series tractors, the cable end is threaded and it is necessary to remove the two locknuts and nipple in order to withdraw the cable, but on 885 tractors the inner cable nipple cannot be removed and the clevis pin must be removed so that the nipple can be hooked out of fork end. Re-adjust new cable after fitting (see page 29).

Three-Way Take-Off Valve: Bolted on the front end of the ram cylinder, the three-way valve can be removed after first lowering the linkage and any equipment, such as a loader, which is connected to the three-way valve.

Clean surrounding area before disconnecting take-off pipes from valve and feed pipe from distributor block. Remove the four bolts from valve body then lift valve from tractor.

When replacing valve, ensure that cylinder and valve faces are clean and 'O' ring is seated in ram cylinder face recess. Tighten the four bolts evenly, so that the valve body is not distorted, then reconnect pipes.

Sensing Unit: Bolted on top of the PTO case, where it provides the anchorage for the tractor end of the top link, the sensing unit should first be cleaned before removal.

Disconnect flexible cable, remove top link then remove bolts attaching unit to PTO case. Keep PTO case covered whilst unit is removed and when refitting unit refit the different length bolts in their original positions before firmly tightening. Reconnect and adjust flexible cable, (see page 29).




FIGURE 48
TOP LINK SENSING UNIT




FIGURE 49 REMOVING THREE-WAY VALVE




FIGURE 50 LINKAGE SUPPORT RAM

Linkage Support Ram: Mounted between ramshaft and right-hand side of drawbar frame, the ram can be removed by first lowering linkage, to ensure ram has minimum amount of oil in it, disconnecting oil pipe from ram then removing the upper and lower attachment bolts.

When refitting ram, smear both bushes with grease and ensure the two pivot bolts are fully tightened.

Live Take-Off Valve: Bolted on top of right-hand side of rear axle case, the surrounding area should first be cleaned before valve is removed. Disconnect pipes and remove the five cover bolts then lift valves off axle case. Note the different lengths of bolts so that they can be refitted in their original position.

When replacing valves ensure that faces are clean and all 'O' rings are in position. Replace bolts and tighten evenly: the valve spools are a very close fit in their bores and only a slight distortion of body could cause spools to bind.




FIGURE 51
REMOVING LIVE TAKE-OFF VALVE

Ramshaft: This is removed complete with right-hand ramshaft bracket and control valve.

Remove cover from control lever housing. This is attached by four screws and must be removed complete with lowering control knob. Remove Nyloc nut from connecting link and remove the three bolts attaching housing to rear axle case: two of these are positioned inside the housing but the third is outside, and it will be necessary to release the three quadrant bolts to provide sufficient clearance to remove this bolt. Disconnect hand brake lever so that it can be removed with housing. Withdraw housing, noting that a distance piece and spring are fitted on connecting link.

Release locknut on lubrication pipe clamp bolt and unscrew bolt approx. eight turns. Wire pipe to upper housing bolt hole, so that it will not come out of its connection at inner end and fall into axle case.

Disconnect flexible cable from sensing unit, then remove sensing unit. Cover top of PTO case to prevent any dirt entering.

Removing control lever housing will expose the pressure pipe connection and enable the two attachment bolts to be removed, so that when control valve is withdrawn rearwards the pipe connection will remain in position.

Disconnect levelling and lift levers from lower links and remove cover from right-hand ramshaft bracket.

Remove bolts attaching right-hand ramshaft bracket to axle case and left-hand cover to ram cylinder.

The cover joint is vertical and two of the cover bolts pass right through the axle case. When the cover is removed a small quantity (1 litre — 2 pints) of oil will be released.

Unscrew lowering control needle valve from front of control valve, to prevent it being damaged, then, whilst supporting the weight of the shaft with a portable crane, carefully withdraw the assembly rearwards until the control valve is clear of the axle case.

To separate ramshaft from its right-hand bracket, remove the two nuts attaching cam plate to ramshaft then slide bracket off shaft end.

Before commencing to replace the ramshaft, ensure that the lubrication pipe is in position inside the axle case and has not become detached at its left-hand (inner) end. Clean the joint faces and fit a new gasket on right-hand bracket.

Fit the two small 'O' rings into their positions at front of control valve: a smear of grease will help to maintain rings in position whilst ramshaft is being refitted.

Carefully raise ramshaft into position, guiding control valve into axle and ensuring that control lever rod passes through axle case. Place bearings in position on left-hand bracket then push shaft 'fully home'.

When shaft is in position, replace and tighten bracket bolts. Smear core plug with jointing compound before replacing it in left-hand bracket. Remove retaining wire from lubrication pipe then position pipe and tighten clamp bolt. Replace lowering control needle valve before bolting high pressure pipe connection to valve.

Refit control lever housing, using a new gasket. Spring and distance piece must be fitted on control valve rod as housing is replaced and an easy way of doing this is to place spring on rod, then temporarily fit a bolt through control lever pin so that distance piece can be held in position whilst it is pushed against spring. When housing is bolted in position replace second distance piece and set connecting link (see Adjustments).

Refit sensing unit, connect and adjust flexible cable, see page 29.




FIGURE 52 RAMSHAFT REMOVAL




FIGURE 53
RAM CYLINDER REMOVAL

Ram Cylinder: Housed inside the left-hand side of the rear axle case the ram cylinder must be removed rearwards

The ram cylinder body is a one-piece casting and after removing the ramshaft assembly it is only necessary to remove the three-way take-off valve, or connector, from the front end of the cylinder to enable the cylinder to be withdrawn rearwards out of the axle case.

When refitting the ram cylinder, ensure that axle case is clean and the large 'O' ring is in position on front of cylinder. Coat both sides of a new gasket with non-hardening jointing compound before fitting gasket on axle case. Smear cylinder 'O' ring with grease then slide cylinder into position and align bolt holes. Refit ramshaft before replacing take-off valve.

Remove the three-way take-off valve from front end of ram cylinder. Disconnect clutch hand lever, remove lever pivot bolt then remove the lever side brackets from footplate. This will enable hand lever to be moved and provide sufficient clearance for removal of cylinder front-end cover.

When end cover has been removed, pull the cylinder flange forward to remove cylinder from axle case. The flange is a loose fit on cylinder but is usually tight enough to bring the sleeve with it when pulled forward.

Refit cylinder, complete with piston and flange, into axle case. Enter connecting link into cylinder and ensure that oil port through flange has an 'O' ring in it and is positioned opposite the hole in axle case. Refit end cover, tightening the bolts evenly until they are fully tight. Replace take-off valve and clutch hand lever.




FIGURE 54 CONTROL VALVE AND RAMSHAFT BRACKET

Selectomatic Control Valve: As this valve is bolted to the front of the right-hand ramshaft bracket it is first necessary to remove the ramshaft and then remove the control valve from the ramshaft bracket.

Having removed the right-hand ramshaft bracket, remove the guide bracket; this is attached by two bolts, one of which is also the pivot for the cable actuating lever. Removing the guide bracket will expose a valve securing bolt and when this bolt and the two nuts are removed the valve assembly can be tapped off its dowels and separated from the ramshaft bracket.

When refitting a valve assembly, guide the rocker lever into position over abutment block whilst fitting valve onto dowels then replace bolt and nuts, tightening them evenly and firmly.

When valve is in position on bracket, check the settings of abutment block and TCU screw (see page 27).

Selector Dial Pointer Mechanism: Housed inside the right-hand ramshaft bracket this mechanism is accessible when bracket is removed.

After removing ramshaft (see page 37) and control valve, remove the two nuts attaching height control cam to ramshaft. Then slide bracket off ramshaft. Remove cam from inside bracket.

When replacing ramshaft bracket, smear bush with grease and ensure 'O' ring is in position on ramshaft. Replace bracket on ramshaft, lift arms towards rear of bracket, then refit cam. Replace flat washers, spring washers and nuts but do not fully tighten nuts: these can be tightened when assembly is completed and cam position has been set, (see Adjustments).




FIGURE 55 RIGHT-HAND RAMSHAFT BRACKET

UNIT MAINTENANCE AND REPAIR

Recommended Lubricants

The hydraulic system and transmission utilise a common oil reservoir and it is therefore essential to use a fluid (lubricant) suitable for both applications.

The following lubricants are approved for use in the transmission/hydraulic system but if none of these are available refer to the notes on alternative lubricants.

The oil reservoir should be drained and refilled with new lubricant every 1000 hours.

Alternative Hydraulic/Transmission Lubricants

It is emphasised that to safeguard the performance and reliability of the tractor, only the approved lubricants listed should be used.

It is particularly important that EP or ATF oils are not used in the transmission/hydraulic reservoir. If the recommended multi-grade oil is not available, a straight mineral gear oil of SAE 80 viscosity should be used: do not use SAE 80 EP extreme pressure or mild EP SAE 80 oils sold for car gearboxes, or automatic transmission fluid.

Extreme pressure transmission lubricants

These lubricants are intended for use in hypoid rear axles. Extreme pressure additives are not normally formulated for use in hydraulic systems and may be subject to breakdown resulting in corrosion of non-ferrous parts and gum formation. In addition these oils reduce sliding friction, excessive slip could therefore occur on the Hydra-Shift clutch plates and brake bands, resulting in excessive heat and wear.

Automatic Transmission Fluids

These are light viscosity fluids formulated for use in torque converters and automatic transmissions. They are not able to withstand the loads occurring in tractor transmissions. A number of oil companies are developing similar fluids for tractor use, which may be an advantage in arctic conditions and are necessary to prevent filter restriction on tractors fitted with a tandem hydraulic pump. Before using any of these fluids it is essential to contact your David Brown Distributor — who will obtain further advice from Service Department, Meltham.

Approved Lubricants

(except in arctic conditions)

United Kingdom

BP Tractor Oil Universal
Agricastrol Multi-use or MP
Esso Tractor Universal or Unifarm
Mobil Mobiland Universal
Shell Tractor Oil Universal
Duckhams Farm Master
Total Super Universal Tractor Oil

North America

Case TFD

Except U.K. and North America

Amoco HD-M Motor Oil 20W/30
BP Tractor Oil Universal
or BP Vanellus M20-50
Agricastrol Multi-use 20W/30
Esso Tractorlube Universal 20W/30
or Unifarm
Mobiland Special 20W/40
Shell Rotella SX Oil 20W/40

(under arctic conditions)

North America only

Case TFD

Worldwide except North America

Amoco 303 fluid
BP Tractran 9
Agricastrol MD
Esso Torque Fluid 56
Mobil Tractor Fluid 303
Shell 6332

In some countries the approved lubricants may be marketed under different designations from those listed above: if any doubt exists, consult your David Brown Distributor.

UNIT MAINTENANCE AND REPAIR

Full flow Filter: The only maintenance required is the fitting of a new paper element every 500 hours, or if the warning lamp is illuminated at engine speeds above 1800 rev/min when oil is warm. Paper elements must not be cleaned and new elements must be handled very carefully. Elements are easily damaged when dry and a damaged element is useless. Except for cleaning the screen and magnetic filter, no attempt should be made to strip the screen filter. The by-pass valve cannot be adjusted and if faulty operation is suspected a new unit should be fitted. Ensure that the screen is transferred from the old to the new element.




FIGURE 56
COMPONENTS OF FULL FLOW FILTER

Hydraulic Pump: The most important item of pump maintenance is keeping the transmission oil clean. If the transmission oil is allowed to be contaminated with dirt, or water, premature pump wear will take place.

To dismantle a Plessey pump for examination:

1. Prepare a clean workbench where components can be laid out in order of removal.
2. Scribe marks on the mounting flange, body and end cover to aid correct re-assembly. Remove gear with suitable puller. Do not hammer shaft to facilitate removal.
3. Remove the nuts and washers from the mounting flange and lift flange off dowel bolts. Tap the flange with a mallet if hard to remove — do not attempt to separate by using a screwdriver.

4. Withdraw gears and bearings from body, carefully noting their positions. To facilitate correct reassembly mark bearings with a felt tipped pen. Do not use a metal tool for marking.
5. Remove through bolts and end cover. Remove 'O' rings from cover and flange. Unscrew blanking plug and 'O' ring.

Inspection and Rectification: Pump body should be examined for wear or damage. It is normal for the gears to cut a light track on inlet side of the body bores. If bores are in good condition without excessive scoring the body is serviceable. The only rectification required is to remove any burrs from the edges of the rotor track, so that it cannot interfere with the balancing action of the bearings. Very carefully remove any burrs with a sharp scraper or fine emery cloth. If the rotors have worn a deep groove in the body bores, due to worn bearings allowing the rotors to be pushed towards inlet side of pump, the pump should be scrapped. Fitting new bearings in a worn body will hold rotors clear of the wear tracks and allow internal oil leakage to occur, resulting in loss of pump output.

Ensure that bearings are not damaged or embedded with particles of foreign matter. Examine each bearing for wear on the face and in the bores. If necessary lightly polish the outer diameters of bearings to obtain free movement in body.

If bearing faces are not excessively worn they may be salvaged by polishing. Place a sheet of 'O' grade emery paper on a truly flat surface, lubricate with paraffin and polish bearing surface using a light rotary motion. Bearing thickness must not vary by more than 0.005mm (0.0002in).

The bearings must not be worn sufficiently to prevent the sealing rings from being compressed when body bolts are tightened. Temporarily assemble rotors and bearings then measure distance between outer faces of bearings: this should be 0.076mm to 0.178mm (0.003 to 0.007in) less than width of body.




FIGURE 57 CHECKING BEARING WEAR




FIGURE 58 PLESSEY PUMP BEARINGS AND SEALS

Rotors should be inspected for worn, or scored, side faces and journals, damaged teeth or surface cracks. Slight wear or scoring on journals can be erased by mounting rotor between lathe centres and polishing with 'O' grade emery cloth lubricated with paraffin. Only polish the journal surfaces, do not reduce their diameters: for satisfactory pump performance the journal diameters must be paired within 0.013mm (0.0005in) and gear widths paired within 0.005mm (0.0002in).

Re-assembling Pump: Carry out re-assembly on a clean workbench. Wash all components in paraffin or fuel oil and thoroughly dry with an air blast. Cleaning solvents likely to attack the synthetic rubber seals must not be used. All machined surfaces should be free from burrs and bruise marks. Ensure that bearing lubrication scrolls are clean and free from damage. Bearings have two features which facilitate their correct re-location; a Y-shaped recess on the suction (inlet) side and relieved area on pressure (outlet) side.

1. Grease and fit new shaft seal into the end cover (seal spring facing outwards).
2. Fit new 'O' rings into the mounting flange and end cover grooves.
3. Assemble cover to body with the two dowel bolts.
4. Place pump on bench, cover end down and inlet side towards you.
5. Lubricate the bores and faces of bearings with clean transmission oil.
6. Fit the cover end bearing into body and slide gently to base of bores.
7. Insert the gears into their respective bores (with inlet side towards you the drive gear is on the right).

8. Place the top bearing over gear shafts and into location against gear faces.
9. Mount the flange over the drive gear (taking care not to damage the shaft seal on the keyway) and dowel bolts.
10. Insert remaining through bolts, spring washers and nuts. (Lubricate threads with thin oil before fitting.)
11. Tighten nuts down evenly and apply recommended torque loading of 5.53 to 6.22kg metres (40/45lb. ft.).
12. Refit blanking plug, using new 'O' ring. (If pump is not being refitted immediately, seal all parts with plugs or adhesive tape.)
13. Fit the drive shaft key in position and gently ease the gear onto the shaft. Ensure that keyway is aligned with key and use the shaft nut to pull gear onto shaft taper.
14. Fit new tabwasher, tighten shaft nut to 5.53kg metres (40lb ft) and lock the nut. Do not hammer or press the gear into position otherwise bearing damage will result.

Unserviceable Parts: Should the pump be worn beyond salvageable limits, satisfactory repair becomes uneconomical and it will be necessary to fit a new unit. Always clean out the hydraulic system before fitting a new pump. Worn components can be renewed but the following points should be noted.

1. New components in a worn body may not restore full efficiency because of internal losses.
2. New bearings will tend to prevent the gears bottoming in their tracks, thereby increasing internal losses.




FIGURE 59 COMPONENTS OF DOWTY PUMP

To dismantle a **Dowty** pump for examination:

1. Remove shaft nut and draw gear off taper using suitable puller. Do not hammer shaft.
2. Remove top cover and relief valve complete. Note position of different length bolts to ensure correct re-assembly.
3. Remove end cover and extract rotors and bushes from body. These should slide out freely but if tight, invert body and tap it on a wooden block. Note location of bushes to ensure that they are refitted in their original positions upon re-assembly.
4. Discard all 'O' rings.
5. Clean all parts and lay them out on a clean bench. If more than one pump is being dismantled, take care not to interchange components.

Inspection and Rectification: Pump body should be examined for wear or damage. It is normal for the rotors to cut a light track on the inlet side of pump body but if wear of the bushes, or journals, has allowed the rotors to form a deep wear track the pump should be scrapped. It is no use fitting new bushes into a body with deep wear track as the increased rotor tip clearance will allow increased internal oil leakage.

If the wear track is not deep but the rotor tips have raised a burr at the sides of the track the burr should be carefully polished out, otherwise it may prevent the bushes being held against the rotor side faces and allow internal oil leakage.

Erosion of the pump body may occur due to oil cavitation, caused by operating the pump with a restriction in the pump oil supply or an air leak on the inlet side of pump. If this occurs the pump output and pressure will be affected.

Examine the bush bores for signs of wear and the bush faces adjacent to the rotor teeth for scoring or pitting. Slight scoring of the bush faces is acceptable provided the pump operates satisfactorily at full pressure.

The bushes are paired so that lengths of the major diameters are equal to within 0.005mm (0.0002in), and can only be renewed in pairs. A set of four new bushes should be modified by chamfering the edge on the low pressure side as shown (Fig. 60). This will allow the bushes to override any burrs and thus prevent any interference with the balancing action of the bushes.




FIGURE 60 CHAMFERING THE INNER ROTOR BUSHES

- A Inlet
B Chamfers tapering to zero at 120°

Apply a small quantity of clean oil into the pump body and fit the two bushes into their respective bores. The bushes should slide into position quite freely until the 'O' rings come up against the body shoulder. Apply clean oil to rotor journals and assemble rotors to pump body. Fit outer bushes in their original positions and place body end cover in position to check the cover to body clearance. With the cover resting on the bushes, the clearance between the cover and the body should be not less than 0.38mm (0.015in) otherwise the 'O' rings will be unable to make a seal and pump will be incapable of producing full pressure.

Once the internal condition of the pump has been assessed, it may be considered more economical to fit a new unit than replace worn components.

Re-assembling Dowty Pump: Prepare a clean work bench, wash all components in cleaning solvent or clean hydraulic oil. Cleaning solvents likely to attack the synthetic rubber seals must not be used.

1. Apply a small quantity of clean oil to pump bore, bushes, rotors and new 'O' rings. Assemble inner bushes, 'O' rings and backing washers into pump bores and insert rotors.

Note: On later pumps (Fig. 61), the bush tails are not concentric with the bores. This gives a more uniform pressure balancing action and it is essential that bushes are correctly located as shown. Where backing washers are fitted, fit 'O' rings before backing washers.

2. Fit outer bushes and end covers. Replace cover bolts noting that two bolts are shorter where cover section is thinnest.
3. Tighten down the cover bolts evenly and by diagonal selection (to prevent distortion) to 5.53kg metres (40lb ft). Do not overtighten the bolts as the body is of soft alloy.
4. Replace the shaft key and gear followed by the lockwasher and nut. Do not tap the gear on to the shaft or the bushes will be damaged. Use the shaft nut to pull the gear into position after checking that key and keyway are aligned. Tighten the shaft nut to 6.22kg metres (45lb ft) then lock with tabwasher.
5. Check that the pump can be turned by hand: the rotors should have a constant drag without roughness or tight spots.
6. Refit top cover, fitting new 'O' rings and noting that the two longer bolts are fitted adjacent to the body plug. Tighten the bolts to 3.5kg metres (25lb ft) and refit the relief valve, noting that a sealing washer should be fitted on each side of the shroud.
7. If the pump is not for immediate use, seal the ports to prevent dirt entering the pump.




FIGURE 61 ROTOR BUSHES (later type pump only)

- A Bushes
B 'O' rings
C Inlet
D Outlet

UNIT MAINTENANCE AND REPAIR

Selectamatic Control Valve: As the main valve plungers are match-ground to their bores they cannot be replaced. The valve assembly can, however, be stripped, cleaned and re-assembled and as faulty operation is probably due to sticking caused by dirt, a valve should not be regarded as unserviceable unless it is found faulty during this examination.

Dismantling the control valve:

Prepare a clean workbench, where components can be laid out and not mixed with components from any other valves being dismantled.

1. Remove the abutment plate, taking care of the shims.
2. Remove the two locknuts from the spool valve and withdraw the spool. Do not attempt to remove the spool valve sleeve as this must not be replaced without special equipment to check that it is correctly sealed.
3. Remove hold valve from top of valve and lift out the spring, then turn valve upside down so that hold valve plunger falls out: the small steel ball inside hold valve plunger will also fall out. If plunger does not fall out, insert a piece of 12mm ($\frac{1}{2}$ in) diameter wood, or plastic, dowel into plunger so that it can be pulled out. Repeat procedure to remove by-pass valve assembly, ensuring that valve parts are not interchanged.

4. Remove relief valve plug and extract the spring, plunger, shims, seat and restrictor washer, taking care of the shims as these must be refitted as removed in order to maintain the original pressure setting.
5. Remove the two plugs from left-hand side of body and extract the non-return and lowering control plungers.
6. Remove plug from front of body and extract latching valve.
7. Finally unscrew ferrule from underneath valve and allow TCU plunger, spring and ball to fall out.

The valve is now dismantled as the remaining plugs and seats should not be disturbed.




FIGURE 62 SELECTAMATIC CONTROL VALVE ASSEMBLY

Inspection and Rectification: Wash all components in paraffin (do not use a cleaning solvent likely to attack the synthetic rubber seals) and dry with an air blast. Do not use cloths as fibres may be left and cause trouble later. If by-pass plunger does not have a metering pin it will incorporate a small screen filter and this must be cleaned. Do not attempt to remove the filter but remove the small plug and restrictor washer from inside plunger then use an air jet to blow downwards, i.e. from inside to outside of plunger, so that any dirt on outside of filter will be blown away and not forced through filter screen. When filter is clear replace restrictor washer, ensuring that this is also clear, then replace and tighten plug. Check that the by-pass and hold plungers are free to slide and rotate with light finger pressure. If there are any signs of sticking the plungers may be lapped in with metal polish or jeweller's rouge mixed to a paste with paraffin or light oil. **Grinding paste must**

not be used for lapping-in the plungers. If the plungers or bores, are scored or any of the seal faces worn, the valve is unserviceable and should be replaced with a new assembly as plungers are not supplied separately.

Assembling the control valve: After thoroughly cleaning the valve chest, taking special care to remove all traces of lapping compound, lay all components on a sheet of clean paper.

1. Fit thrust spring on lower end of spool valve, smear valve with clean oil then refit in its bore. Push spool against spring, fit flat washer and screw the two locknuts in position with fingers: they will be adjusted later.

CONTROL VALVE ASSEMBLY

- A By-pass plunger
- a Recess depth
- B Nylon filter
- C Restrictor washer
- c Hole diameter
- D Screwed plug
- d Length of plug
- E Spring
- F Flanged plug
- f Recess depth
- G Metering pin
- H Guide washer — pin
- J Ball retainer
- K Steel ball

K915356 (S2).	K944678 (S3)	K947765 (S4 vertical grooves)	K947765 (S4 inclined grooves)
Type 1	Type 2	Type 2	Type 3
31.75mm (1.25in)	25.4mm (1.00in)	25.4mm (1.00in)	25.4mm (1.00in)
K921154	—	K921154	K921154
K913621	K944289	K913621	K913621
0.51mm (0.020in)	1.75mm (0.069in)	0.51mm (0.020in)	0.51mm (0.020in)
—	K943899	—	—
K919634	K943901	K947759	K947759
11.81mm (0.465in)	9.02mm (0.355in)	5.71mm (0.225in)	5.71mm (0.225in)
K24832	K24832	K24832	K24832
K913242 (use K942892)	K942892	K942892	K948067
8.7mm ($\frac{11}{32}$ in)	7.9mm ($\frac{5}{16}$ in)	7.9mm ($\frac{5}{16}$ in)	10.3mm ($\frac{13}{32}$ in)
—	K944290	—	—
—	K626917	—	—
—	—	—	K947977
—	—	—	K11548

FIGURE 63 IDENTIFICATION OF BY-PASS VALVE PLUNGERS

UNIT MAINTENANCE AND REPAIR

2. Smear by-pass and hold valve plungers with oil before placing them in their respective bores. Place the small steel ball inside hold plunger followed by ball retainer, then replace springs, sealing washers and plugs. Ensure sealing washers are in good condition and plugs are fully tightened.
3. Lightly oil latching valve plunger before fitting it in its bore. Replace spring and screw plunger tightly into position.
4. After lightly coating non-return valve plunger with clean oil, place plunger in its bore then replace spring and plug. Firmly tighten plug.
5. Place restrictor washer in relief valve port and place seat on top of washer. Refit shims, plunger, spring and cap, ensuring that shims are replaced exactly as removed so that the original pressure setting is maintained. If the relief valve plunger or seat are not in good condition a new relief valve assembly should be fitted. This assembly is supplied complete with the shims required to give the correct valve opening pressure and must be fitted complete, otherwise an incorrect pressure setting will be obtained.
6. Turn valve over, so that TCU valve port is towards top, then place steel ball in port followed by spring and plunger. Screw ferrule loosely into valve to hold plunger in position.




FIGURE 64 COMPONENTS OF SELECTAMATIC CONTROL VALVE

Setting valve after assembling: After assembling the control valve it is necessary to set the TCU valve ferrule and the spool valve locknuts in their correct positions. All TCU valves are set to the same amount of travel but each spool valve requires an individual setting. This setting is determined during manufacture and is then etched on the spool so that if subsequently disturbed the original setting can be restored.

1. Hold valve assembly in a vice, positioned so that spool is horizontal and mount a dial gauge so that when spool is pushed inwards against its spring the amount of spool movement is shown on gauge. Ensure that the gauge is mounted directly in line with spool and makes firm contact with ground face on spool.




FIGURE 65
SETTING THE SPOOL VALVE

2. Push spool fully inwards so that spool spring is fully compressed and hold in this position whilst setting gauge to zero.
3. Slowly release spool and observe gauge reading. If gauge reading is greater than the dimension etched on end of spool the spool has too much travel and the locknuts require tightening. If the reading is less then the setting dimension the locknuts require unscrewing to give the spool more movement. After adjusting the locknuts to bring the gauge reading to the setting dimension etched on spool, lock the nuts by tightening them against each other.
4. When the locknuts have been tightened make a final check by holding spool fully inwards, setting dial to zero and then slowly releasing spool. If gauge reading is more than $+0.025\text{mm}$ (0.001in) from the setting dimension etched on spool re-adjust locknuts then re-check spool travel. When the gauge reading is not more than $+0.025\text{mm}$ (0.001in) from dimension etched on spool the setting is satisfactory. A minus spool setting is not acceptable.
5. Turn valve assembly over, so that TCU valve is towards the top and screw ferrule inwards until valve plunger lift almost disappears then unscrew ferrule two-thirds of a turn.
6. Mount gauge vertically over TCU valve plunger and, using a pair of tweezers or thin-nosed pliers, lift plunger upwards until it comes against ferrule then set gauge to zero. Release plunger and observe the gauge reading: this should be $0.86 - 1.00\text{mm}$ ($0.034 - 0.040\text{in}$) and if not within this limit adjust by turning the ferrule slightly. Tighten ferrule to reduce plunger movement and unscrew ferrule to increase plunger movement.

7. When plunger movement has been checked and found correct, remove dial gauge and secure ferrule by peening valve body against ferrule threads with a centre punch. The control valve is now ready and should be placed in a clean bag, to protect it from dirt, until it is required for fitting to the ramshaft bracket.




FIGURE 66
SETTING THE TCU VALVE

Dump Valve: No maintenance or adjustment is required and the only reason for dismantling the dump valve is to renew the oil seals. If oil leaks from spindle, strip valve as follows:




FIGURE 67
DUMP VALVE

Carefully grip body in a vice, unscrew the special nut then pull knob to remove spindle and locating bush. Remove pin attaching knob to spindle, taking care not to bend spindle, then pull knob from spindle and remove locating bush. Remove the 'O' rings and clean the parts. Fit a new small 'O' ring in spindle groove, smear with grease then replace locating bush. Fit a new 'O' ring on outside of bush and a new sealing ring on top of bush. Fit nut on top of sealing ring then fit knob and carefully replace pin. Fit second small 'O' ring on lower end of spindle and larger 'O' ring further up, smear these with grease then fit spindle assembly into body. Screw nut tightly on to body, check that knob can be operated correctly then fit a new 'O' ring on outside of body.




FIGURE 68 DIAL POINTER MECHANISM

Selector Dial Pointer Mechanism: Not requiring any adjustment or maintenance this mechanism need only be disturbed if wear, or damage causes malfunctioning.

1. Drive spring pin from selector fork, taking care not to bend shaft.
2. Remove plug from left-hand side of bracket: early tractors have a core plug here, which can be removed by driving a small punch into centre of plug then levering out. Using a small drift through plug hole, drive selector shaft out until it will allow fork to be removed. After removing fork, push selector rod out of bracket, noting that a detent ball and spring are located under the rod and will be displaced when rod is finally withdrawn. When shaft has been removed extract spring from its hole by inverting bracket and allowing spring to fall out, or hooking spring out with a piece of bent wire.
3. Remove rocker shaft locating screw, this is on front face of bracket and may be covered if gasket is still adhering to face. Slide rocker arm off shaft then turn shaft until arm pin is towards centre of bracket and remove by sliding shaft sideways into bracket. It is not necessary to remove core plug sealing rocker shaft hole in the side of bracket.
4. Remove spring pin from dial pointer and pull pointer off its shaft. Shaft can then be withdrawn downwards out of bracket. Remove the two screws holding indicator panel on top of bracket, lift off panel, remove breather pad and 'O' ring.
5. Ramshaft bush need not be removed unless it is to be renewed but if worn can be removed by driving it inwards into bracket.

Assembly Selector Mechanism

1. After cleaning all components, commence assembly by fitting a new ramshaft bearing bush. Press bush carefully into bracket, positioning hole through bush in line with grease nipple and split in bush towards rear axle case side of bracket.
2. Replace spring anchor, breather pad and 'O' ring in their positions on top of bracket then replace indicator panel. Smear selector rod with oil before fitting it into position. Turn rod so that crank is pointing inwards into bracket then fit dial pointer and secure with spring pin. After fitting pin, check that dial pointer can be turned quite freely.
3. Smear rocker shaft with oil then slide it into position, turning shaft so that crank clears inside of bracket. Fit rocker lever on to shaft, longer end of lever outward and flange on bush towards rocker shaft, then fit locating screw to retain shaft in position. Fit a new core plug to seal rocker shaft hole in outside of bracket if original plug has been removed.
4. Place detent spring in hole in face of bracket and place detent ball on top of spring. Smear selector shaft with oil and push plain end of shaft into right-hand side of case until it touches detent ball. Using a small punch to hold ball against its spring, push shaft until it rides over ball and allows punch to be removed. Fit selector fork over rocker lever and engage selector shaft into fork so that when fork is held stationary and the shaft pushed inwards it is pushed through fork. Align shaft and fork pin holes then replace pin. Turn dial pointer to each of the three positions, to check that it operates freely then replace plug in left-hand side. This plug is a stop for the selector shaft and should be smeared with Loctite before screwing into case. Turn dial pointer to TCU/EXT position and tightening plug until it just contacts selector shaft then unscrew it quarter-of-a-turn and lock by peening case against plug threads with a centre punch. Fit new core plug in right-hand side of bracket.




FIGURE 69 RAM CYLINDER

Ram Cylinder: Subject to availability of oversize pistons, a cylinder with worn or damaged bore may be reconditioned by reboring and a 0-020in oversize piston fitted. As a bored finish is too rough for the 'O' ring to operate against, **the cylinder must be honed after boring.** The bore must be honed to a surface finish not greater than 16 micro-inches, centre line average, which is a highly polished finish; otherwise the 'O' ring will fail to make a seal after a short period of service. Oversize sealing rings are not available: oversize pistons are made to utilise standard sealing rings, which can easily accommodate the small increase in bore size.


Do not attempt to remove the two needle rollers unless they are to be renewed, and take care that they are not damaged by careless handling of cover: the rollers are hard and will break before bending.

Piston seals: The rubber 'O' ring is backed by a leather ring, which prevents the 'O' ring from being extruded into the clearance between piston and bore. The anti-extrusion ring must, therefore, always be fitted on the skirt (non-pressure) side of the 'O' ring.

When fitting new piston seals, soak leather anti-extrusion ring in thin oil for thirty minutes. Clean the piston and fit leather ring first, taking care not to stretch ring further than necessary and positioning ring so that rough side of leather is towards piston crown, i.e. on the 'O' ring side. Fit a new 'O' ring on crown side of leather ring and when 'O' ring is in position examine leather ring to ensure that it stands proud of piston all the way round its circumference. Allow leather ring to settle after being stretched over piston.

Clean bore and piston then smear piston with clean oil before fitting it into ram cylinder. Edge of bore is chamfered to assist entry of sealing rings and if cylinder is installed on tractor open the vent valve, to prevent air being trapped behind piston.

Locking Latch: The ram cylinder cover incorporates a latch which, when released, engages under the ramshaft arm and locks the linkage in the raised position. To strip the locking latch, turn operating lever into 'engage' position and remove circlip from end of latch pin. Removing operating lever and dirt excluder will then expose another circlip. Remove locating screw from cover boss then remove the second circlip and push the latch pin inwards out of the cover. Remove 'O' ring, spacer and spring from pin.

FIGURE 70
LINKAGE LOCKING LATCH

UNIT MAINTENANCE AND REPAIR

In the event of a roller being broken in the cover, two new holes should be drilled as the rollers are too hard to be drilled out. When fitting new rollers press them into the cover until ends of rollers are 18.49 – 18.24mm (0.728 – 0.718in) from cover face. If roller protrusion is outside these limits the latch pin will either not disengage or have insufficient hold on ramshaft arm to support heavy loads on linkage.




FIGURE 71
RE-DRILLING RAM CYLINDER COVER

Drill two holes 4.5mm ($\frac{9}{64}$ in) diameter and 19.05mm ($\frac{3}{4}$ in) deep at positions shown then ream to 4.37 – 4.75mm (0.1865 – 0.1870in) and 15.9mm ($\frac{5}{8}$ in) deep.

- | | |
|--|--------------------------------|
| A. Original holes | B. New holes |
| C. 17.46 – 17.48mm (0.6875 – 0.6885in) | |
| D. 34.92 – 34.97mm (1.375 – 1.377in) | |
| E. 15.7mm ($\frac{5}{8}$ in) | F. 19.05mm ($\frac{3}{4}$ in) |

To assemble the cover, fit spring, spacer ring and 'O' ring on latch pin, taking care that 'O' ring is not damaged as it passes over circlip grooves. Smear pin with clean oil and refit inside cover, aligning the pin groove with locating screw hole in cover boss. Clean locating screw, smear threads with Loctite (hydraulic seal grade) then screw it in until it touches bottom of pin groove and **unscrew** a quarter turn. Push pin into position to compress spring and expose inner circlip groove. Replace circlip, smear pin and needle rollers with grease then refit dirt excluder. Push latch, to compress spring, then refit operating lever, in 'engage' position and replace outer circlip. Finally turn operating lever several times to check that latch pin slides freely.

Ramshaft arm: The ramshaft arm is splined and shrunk on to the ramshaft. A new arm may be fitted, if a new part is available and provided that—

1. The original position of the arm is clearly marked and the assembly marks on arm and shaft splines are visible.
2. The arm is first cut so that it can be split to release its grip on shaft, before being removed. Removing an arm without first splitting it will reduce the shaft interference fit and allow the new arm to work loose.
3. Heat the splined end of the new arm to 500°C (900°F) before pressing it on shaft until it reaches the exact position of the original. Do not heat the spherical seat end of the arm: this will destroy the heat treatment and soften the seat surface.

Three-Point Linkage: The fork ends, adjusting screws and gear housing should be lubricated with grease every 60 hours.

Pivot Pins: On early tractors the pivot pins attaching the lift rod and levelling lever to the fork ends were retained by a circlip at each end of pin but on later tractors the pins are drilled and secured with spring pins. The later type pins (948353) and spring pins (623740) can be used to replace earlier type pins.

Lift Rod: This can be dismantled by simply unscrewing the adjusting nut and removing the fork pivot pin, which should be tight in the rod and free in the fork. The tube is secured by being peened into the rod groove at three equally-spaced points.

Hitch Brackets: The lower link hitch brackets must be firmly attached to the axle case. If the brackets are removed ensure that both faces are clean when refitted and the bolts tightened evenly to the correct torque and locked with tabwashers.

Levelling Lever: Dismantle this by unscrewing the adjusting nut then removing the four cover bolts and separating the cover and housing.

Turn the housing over so that the screw and thrust bearing will drop out. To remove handle, drive retaining pin out of pinion then drive handle out of pinion with a small punch. Smear all parts with grease before re-assembly. Pack the housing with grease before fitting the cover and tightening bolts evenly to the correct torque.




FIGURE 72 LEVELLING LEVER

Linkage Support Ram: Clamp the ram horizontally in a vice. Holding it in the centre and not gripping it tight enough to distort the ram case. Insert a screwdriver blade under the lip of the scraper seal, lift seal from its retaining groove then slide it along ram rod.

Insert a pair of circlip pliers into cut-out in sleeve and compress the circlip. Whilst holding circlip central in sleeve, pull ram rod past the end of its stroke so that it pulls the sleeve with it and moves circlip clear of its groove. When circlip has been displaced from its groove, pull ram rod and sleeve out of case.

To remove sleeve from ram rod remove the two circlips and stop ring from inner end of rod then slide sleeve off rod. **Do not grip the ram rod between vice jaws**, unless they are fitted with soft jaw grips.

Ram seals: The sleeve has seals both outside and inside. The outer seal consists of an 'O' ring with a leather anti-extrusion ring and prevents oil leaking between sleeve and cylinder. The inner ram rod seals consist of an 'O' ring with leather anti-extrusion ring plus a separate Nu-lip sealing ring and an external scraper seal.

Clean the sleeve, after removing the old seals. Soak the leather rings in engine oil for at least 30 minutes, to allow them to be stretched without damage, and fit these first. Place the rings so that the rough (hair grain) side of ring is towards the inner end of sleeve then fit 'O' rings against the rough side. The 'O' rings should then be on the inner (pressure) side of the leather rings and the leather rings positioned


with the rough side against the 'O' ring. Ensure that 'O' rings are pressed down into bottom of groove but do not press them into position with anything sharp, such as a screwdriver as this may cut the ring, roll them into position with finger pressure. Fit the Nu-lip seal in its groove, taking care not to damage the seal corners.

Assembling the Ram: Wipe ram rod clean, then smear with clean oil and slide a new scraper seal on to rod. Smear inside of sleeve with oil then carefully slide sleeve, with circlip in position, on to ram rod. End of ram rod is chamfered but take care to ensure that seals are not damaged as they pass over rod end. After fitting sleeve on ram rod, replace stop ring and **both** circlips.

Clamp the ram case horizontally in a vice holding it in the centre but not gripping it tight enough to distort case.

Fill circlip groove in case with thick grease and smear outside of sleeve with oil. Fit ram rod into case and slide sleeve into case end. Take special care when pushing sleeve seals past the circlip groove: the groove corner is chamfered and the grease will also assist the seals to pass the groove without being damaged.

Compress circlip and hold it central so that sleeve can be pushed 'fully home' and circlip seated in its groove. Finally slide scraper seal along rod and carefully push it on to sleeve until seal inner lip engages on to sleeve shoulder.



R76 126

FIGURE 73 COMPONENTS OF LINKAGE SUPPORT RAM

UNIT MAINTENANCE AND REPAIR

Sensing Unit

The sensing unit and flexible cable should be lubricated every 60 hours through the grease nipples in centre of cable and sensing unit housing.

When stripping a sensing unit for examination always examine the flexible cable. With cable disconnected from sensing unit, grip cable nipple with a pair of pliers and whilst holding outer cable stationary, pull inner cable against its spring. If spring withdraws the cable as soon as it is released the cable is satisfactory but if cable is not withdrawn by spring, or if it is too tight to be pulled out, the cable should be renewed.

Single rate sensing unit

To dismantle unit, remove the four setscrews from end-plate and insert a bar through link pin hole then pull shaft, complete with end-plate, out of housing. Do not drive a screwdriver between end-plate and housing as this will damage the shims.

Check that the end-plate is free to slide on shaft sleeve and the end collar is free to slide in housing bore.

To dismantle shaft, drive pin out of collar and shaft then tap thrust washer and collar off shaft. Do not attempt to remove collar and spring by pressing shaft out of end-plate — the end-plate cannot be removed until sleeve is removed from shaft. The sleeve is screwed on to shaft and can be removed by holding the two flats on sleeve between vice jaws then turning the shaft by means of a bar through the link pin hole.

To assemble unit, clean shaft and sleeve threads before applying a few drops of Loctite (grade 270). Fit a new 'O' ring inside end-plate bore, smear with grease and place end-plate on sleeve before screwing sleeve firmly on to shaft. Replace spring, thrust washer and collar on shaft then fit retaining pin through collar. When pin is in position check spring end float; if this is more than 0.25mm (0.010in) remove collar pin and fit a thicker thrust washer so that end float is reduced to a minimum without spring being compressed.

Thrust washer details:

Part No.	Thickness
K915112	9.02mm (0.355in)
K915113	9.27mm (0.365in)
K915101	9.52mm (0.375in)
K915114	9.78mm (0.385in)
K915115	10.23mm (0.395in)
K915116	10.29mm (0.405in)

When collar is finally fitted, check that pin protrudes equally through both sides of collar and pin ends are not damaged. Pin must slide freely in the housing slots and, if necessary, clean ends of pin with a file.

Smear shaft collar with grease and replace shims on end plate. Fit shaft assembly in housing and replace the four end-plate set screws. Check shaft end float whilst evenly tightening the screws and note that it reaches a minimum when screws are fully tightened. If tightening setscrews does not reduce shaft end float to less than 0.25mm (0.010in) the shim thickness is too great. If tightening the setscrews reduces but then increases the shaft end float as the screws are fully tightened the spring is being compressed, due to an insufficient thickness of shims.

End-plate shims:

Part No.	Thickness
K915096	0.13mm (0.005in)
K915097	0.25mm (0.010in)
K915098	0.76mm (0.030in)

Pack end of housing bore with grease, smear core plug with jointing compound then refit plug. Apply a few shots of grease through the housing grease nipple.




FIGURE 74 COMPONENTS OF SINGLE RATE SENSING UNIT

Selective Sensing Unit: To dismantle unit, lever out core plug from top of housing and place selector lever in vertical position. Remove the four end-plate bolts and withdraw shaft assembly by placing a bar through the link pin hole. When shaft has been withdrawn far enough for rack to be disengaged from pinion turn shaft 45° anti-clockwise to bring rack teeth opposite cut-out in housing then draw shaft assembly out of housing.

Selector pinion can be removed, if necessary, by removing the grub screw from housing and withdrawing the detent spring and plunger. Turn pinion so that its retaining pin can be driven out — taking care not to bend the spindle — then, using a thin spanner, unscrew the screwed bush to withdraw handle and spindle.

To dismantle shaft assembly, remove pin attaching end collar to shaft then slide the springs, carrier and thrust washer off the shaft, taking care of the shims fitted between the springs.

End-plate can be removed by holding the two flats on sleeve between vice jaws then using a bar through link pin hole to unscrew the shaft.

Commence re-assembly by fitting the end-plate on shaft. If plate bush or oil seal are damaged or worn they should first be renewed. Smear bush and oil seal with grease and sleeve threads with Loctite (grade 270) before fitting end-plate and firmly tightening sleeve on to shaft. Fit the springs on their carrier then check that ends of both springs protrude 0.13 – 0.26mm (0.005 to 0.010in) over ends of carrier. If not, remove springs and change the thickness of shims.

Place large thrust washer on to end plate dowels. If the thrust washer dowels are offset the washer can only be fitted the correct way round but on early units the dowels were opposite each other and it is therefore essential that the washer is fitted the correct way round, otherwise the spring carrier slots will not be in the required position and the unit will not operate correctly. Washers with dowel holes opposite each other therefore have an identification groove on one side and washer must be assembled with the groove side towards the spring.

Assemble carrier, with springs, thrust washer and collar on shaft. Tap the retaining pin into position then check the end float of the spring carrier, this must not exceed 0.30mm (0.012in) and can be adjusted by changing the thickness of the small thrust washer. The collar is also provided with two pin holes which are 0.84mm (0.033in) apart so that using the appropriate hole and selecting a suitable thickness of thrust washer enables the end-float to be reduced to the required limit. When shaft has been assembled check that the collar pin protrudes equally through each side of collar and is free to slide in housing slots; if necessary trim the pin ends with a file.

Thrust washer details:

Part No.	Thickness
K940039	9.63mm (0.379in)
K940040	9.35mm (0.368in)
K940041	9.07mm (0.357in)

Hold pinion in housing and smear spindle with grease before fitting it in position. Carefully tap a new pin through pinion then replace detent plunger and spring. Smear grub screw threads with Loctite (grade 270) before screwing it into housing and set the screw by turning pinion so that plunger is out of a detent groove then tightening screw until it becomes solid and unscrewing it three-quarters of a turn. Fit shaft assembly into housing, temporarily without shims, and measure the gap between housing and end-plate. Hold end-plate against housing, with hand pressure, so that shaft is pushed 'fully home' and gap is equal all the way round whilst checking gap with a feeler gauge. Remove shaft, fit shims of the same thickness as the measured gap on to end-plate then refit shaft. Place selector lever in vertical position and ensure that rack is central; this can be checked by observing that rack protrudes an equal distance on both sides when viewed from underneath. Tighten end-plate bolts evenly then check that selector lever can be turned into all three positions. Coat pinion with grease then smear a new core plug with jointing compound and fit into housing. Pack shaft end with grease then fit a new core plug.




FIGURE 75 COMPONENTS OF SELECTIVE SENSING UNIT

UNIT MAINTENANCE AND REPAIR

Three-Way Take-Off Valve: To dismantle the valve, push the spool into its lowest position with the control lever then remove the control lever. Insert a large screwdriver into the cover and lever the spool down until the detent balls are disengaged and the spool protrudes through lower end of body far enough to expose the spool lower 'O' ring; the end cap will be pushed out by the spool.

Remove 'O' ring from spool then remove the three cover screws and withdraw cover, taking care of the detent balls. Push the spool upwards out of the body then remove upper 'O' ring from spool.

Assembling the valve. First carefully examine the spool to ensure there are no deep score marks across the lands then check that it is a free sliding fit in valve body. Do not attempt to clean a spool with abrasive tape; this would not only destroy the sharp corners on the lands but also reduce the diameter of the spool and increase any oil leakage. If the spool is scored a new matched spool and body is required as the only permissible rectification is lightly lapping the spool into the valve body with metal polish.

Having thoroughly cleaned the body and spool fit a new 'O' ring on upper end of spool then smear spool with clean oil. Fit spool into top of body and push it down only far enough to expose the lower 'O' ring groove then fit a new lower 'O' ring and push spool up into its working position.

Caution — the spool must not now be moved from its working position as this will allow the 'O' rings to be trapped and damaged by the sharp edges of body oil ports.

Fit a new breather pad into body recess then smear a new gasket with grease and place it in position. Remove the detent spring grub screw from cover then fit the first detent spring and ball in position. Hold the body vertically on bench, so that spool will not be pushed downwards out of body, then fit the cover, holding detent ball against its spring with a screwdriver inserted through control lever aperture, until ball is engaged over the spool: take care not to allow ball to enter the hole for the control lever.

When detent ball is engaged, refit the cover screws then coat control lever pivot ball with grease and replace the control lever. Check that spool operates correctly then fit the second detent ball and spring. Smear grub screw with Loctite (grade 270), screw it in until it touches the spring then screw it inwards a further $2\frac{1}{2}$ turns.

Replace end cap; using a suitable socket, or tube to expand it until tight.

Seal the housing ports with masking tape.




FIGURE 76 ASSEMBLING THREE-WAY VALVE

Double-Acting Live Take-off: It will not normally be necessary to completely dismantle a valve. The spool seals can be replaced without disturbing the pressure kick-out device and the kick-out mechanism can be dismantled without disturbing the spool seals.

Valve spool seals: To replace the spool seals, unscrew the end cap clear of body threads then disconnect spool from control lever spindle. On later valves this can be done by removing the spring link but on earlier valves it will be necessary to remove the pin from end of valve spool and whilst doing this it is essential to support the spool end, to avoid any possibility of bending the spool.


Remove any paint or dirt from spool end, so that it will not damage the body bore then grip the end cap and pull spool out of body: end cap will remain attached to spool and hold the detent balls in place.

Carefully remove the 'O' ring and wiper seal from control lever end of spool bore then remove the loose cap from other end and extract the 'O' ring.

Fit new 'O' ring and wiper seal into control lever end of spool bore and smear these with grease. Fit new 'O' ring on to shoulder of the loose cap — this will enable ring to be passed over the sharp corners of spool lands — then slide cap on spool before returning 'O' ring to its correct position at front of cap. Coat spool with clean oil then insert it into valve body. Replace connecting link or fit a new pin, supporting spool end as during removal. Screw end cap into body and tighten firmly then check for free operation of spool and detent mechanism.

Resetting Kick-out Mechanism: Unless a test rig is available this should be done with valve mounted on tractor.

Clean area round valve then disconnect pipes from valve and connect a pressure gauge and screw type valve between the two valve ports.



R76 132

FIGURE 77 FITTING NEW SPOOL SEALS

UNIT MAINTENANCE AND REPAIR

Start engine and allow oil to reach working temperature then move control lever into detent position. Slowly close the valve and note the rise in pressure. Observe the gauge reading reached before control lever kicks-off and returns to neutral; this should be 1750–2000lb/sq in and if not may be reset as follows:-

1. Unscrew cap from body, then jerk operating lever to rear whilst preparing to catch the detent balls. Pull cap from spool.

2. Unscrew retainer from spool, using a spanner on spool flats to prevent it turning.

The kick-out shims are fitted at the end of the retainer and if retainer end is flat simply smear a shim with grease, place it on end of retainer, then replace the retainer.

On later type units the end of retainer is recessed for location of spring and on these units the valve spring should be removed, coated with grease and then replaced. If a shim is then smeared with grease and fitted in retainer recess the spring will be held central by the grease and will enter recess when retainer is refitted.

3. After screwing retainer in position, smear detent balls with grease, hold control lever vertical then push cap over the balls and screw it tight into body.
4. Retest as previously to check that kick-out pressure is satisfactory.

Dismantling kick-out mechanism: Unscrew end-cap, then jerk operating lever to rear whilst preparing to catch the detent balls. Pull end-cap off the spool.

Remove circlip, disc and spring from spool then unscrew retainer, whilst holding spool with a spanner on the two flats.


Dismantle retainer by shaking the plunger out then push piston out with a piece of stiff wire. Extract any shims, spring and valve from inside the spool then wash all parts.

Commence re-assembly by fitting the valve inside the spool: some units have a plunger type valve and others have a steel ball. Coat the valve spring with grease before replacing it in spool. If a spring guide was fitted replace this against spring; the grease will hold spring central so that it will enter recess in guide.

Replace return spring and washers on retainer then smear shims with grease and fit these on end of retainer; if retainer end is flat — some are recessed — ensure that shims are placed centrally, so that they are clear of threads. Screw retainer into spool then replace piston, plunger spring, disc and circlip.

Smear detent balls with grease and place these in position, then whilst holding control lever vertical push cap over detent balls and screw it into valve housing.

Check that spool moves freely and detent engages correctly.



R76 133

FIGURE 78 AUTOMATIC KICK-OUT MECHANISM

SPECIFICATIONS AND DATA

Full-flow Filter

Element — (K920522)	AC Delco 7973324
Element filtration	40 microns
Element flow — when passing Shell TOW 20W/30 at 40°C and with a maximum pressure drop across element of 27.9mm (1.1in) HG element K920522	22.7litre/min (5gal/min)
By-pass valve and screen assembly	K920521
By-pass valve opening vacuum	200 – 220mm (7.8 – 8.7in) Hg
Tightening torques: cover bolts — $\frac{3}{8}$ UNC.	2.1kg metre (15lb ft)

Hydraulic Pump

Pump type:		
K962635	Plessey 550/8/16013	
K917541	Dowty PA(C) 6844A(-1)	
Output at 2,000 rev/min engine speed and 1,500kg/cm ² (500lb/in ²) at 45°C oil temp.		
pumps K962635	24litre/min (5.3gal/min)	
pumps K917541	25litre/min (5.5gal/min)	
Outputs quoted are for new pumps: worn pumps are acceptable if output is not less than 90% of a new pump.		
Tightening torques:		
body through bolts (Plessey) — $\frac{3}{4}$ UNF	(5.5-6)kg metres (40-45lb ft)	
body through bolts (Dowty) — $\frac{3}{4}$ UNF	(5.2-5.5)kg metres (38-40lb ft)	
drive shaft nut — $\frac{7}{8}$ UNF	6.2kg metres (45lb ft)	

Pump Relief Valve

Shim adjustment	0.5mm (0.020") shim = 7kg/cm ² (100lb/in ²)
Valve closing pressure	141kg/cm ² (2000lb/in ²)
Valve opening pressure	154kg/cm ² (2200lb/in ²)
Tightening torques: valve body to pump cover	2.7kg metres (20lb ft)

Selectamatic Control Valve

Hold relief valve spring free length	18.6mm (0.73in)
Hold relief valve spring rate	21.8kg/cm (122lb/in)
Hold relief valve opening pressure	17.6kg/cm ² (2500lb/in ²)
Latching valve spring free length	19mm (0.75in)
Latching valve spring rate	3.04kg/cm (171lb/in)
Rate of lowering spring free length	35.6mm (1.40in)
Rate of lowering spring rate	2.34kg/cm (13.2lb/in)
TCU spring free length	20.3mm (0.80in)
TCU spring rate	33.0kg/cm (185lb/in)
TCU pressure (maximum)	52.7kg/cm ² (750lb/in ²)
Steel ball diameters:	
TCU (K17063)	6.3mm (0.25in)
by-pass plunger (K11548)	3.2mm (0.125in)
hold valve plunger (K11548)	3.2mm (0.125in)
Tightening torques:	
valve-to-bracket bolt and nuts — $\frac{3}{8}$ UNC	2.1kg metre (15lb ft)
valve-to-pipe connector bolts — $\frac{3}{8}$ UNC	2.1kg metre (15lb ft)

SPECIFICATIONS AND DATA

Ram Cylinder

Ram cylinder bore — 990 (standard)	88.9mm (3.501in)
Ram cylinder bore — 990 (oversize)	89.43mm (3.521in)
Ram cylinder bore — 885 (standard)	79.4mm (3.125in)
Piston stroke — 990	139mm (5 $\frac{1}{2}$ in)
Piston stroke — 885	114mm (4 $\frac{3}{4}$ in)
Piston diameter — 990 (standard)	88.87mm (3.499in)
Piston diameter — 990 (oversize)	89.38mm (3.519in)
Piston diameter — 885 (standard)	79.3mm (3.996in)
Tightening torques —							
ram cylinder cover bolts — $\frac{1}{2}$ UNC	9.0kg metre (65lb ft)
ram cylinder-to-axle bolts — $\frac{1}{2}$ UNC	19.4kg metre (140lb ft)
ram cylinder-to-axle bolts — $\frac{1}{2}$ UNC	10.4kg metre (75lb ft)
ram cylinder bleed valve — $\frac{1}{4}$ BSP	1.1kg metre (8lb ft)

Linkage Support Ram

Ram rod diameter	44.45mm (1.750in)
Ram stroke	27.9cm (11in)
Ram sleeve diameter	63.5mm (2.503in)
Ram sleeve bore	44.50mm (1.752in)

Sensing Unit (Single Rate)

Spring free length	108mm (4.25in)
Spring rate (990)	1930kg/cm (10,800lb/in)
Operating force — maximum							
compression	1500kg (3300lb)
tension	625kg (1350lb)
Spring rate (885)	893kg/cm (5000lb/in)

Sensing Unit (Selective)

Spring free length	} heavy spring light spring	70.64mm (2.781in)
Spring rate		3750kg/cm (21,000lb/in)
Spring free length		56.36mm (2.219in)
Spring rate		1930kg/cm (10,800lb/in)
Operating force — maximum							
light draught (compression)	907kg (2000lb)
light draught (tension)	478kg (1100lb)
medium draught (compression)	1360kg (3000lb)
medium draught (tension)	725kg (1600lb)
heavy draught (compression)	2721kg (6000lb)
heavy draught (tension)	1496kg (3300lb)
Tightening torques:							
end plate-to-housing bolts — $\frac{1}{2}$ UNC	4.2kg metre (30lb ft)
housing-to-PTO unit bolts — $\frac{1}{2}$ UNC	10.5kg metre (75lb ft)

Three-point Linkage

Levelling lever lengths							
maximum	} U1384-5 linkages	451mm (17 $\frac{3}{4}$ in)
minimum		352.5mm (13 $\frac{7}{8}$ in)
maximum	} U1504 linkage	546mm (21 $\frac{1}{2}$ in)
minimum		429mm (16 $\frac{7}{8}$ in)
Lift rod lengths							
maximum	} U1384-5 linkages	444.5mm (17 $\frac{1}{2}$ in)
minimum		391mm (15 $\frac{3}{8}$ in)
maximum	} U1504 linkage	533mm (21in)
minimum		432mm (17in)
Tightening torques:							
levelling lever gear housing bolts — $\frac{7}{8}$ UNC	4.2kg metre (30lb ft)
hitch brackets-to-axle case bolts — $\frac{1}{2}$ UNF	19.4kg metre (140lb ft)

Three-way Take-off Valve

Take-off pipe connections	$\frac{1}{2}$ UNF
Tightening torque — valve body bolts — $\frac{1}{2}$ UNC	3.5kg metre (25lb ft)

Double Acting Live Take-off Valve

Take-off pipe connections	$\frac{1}{2}$ UNF
Kick-out operating pressure	158kg/cm ² (2250lb/in ²)
Tightening torque—valve body bolts — $\frac{1}{2}$ UNC	3.5kg metre (25lb ft)

SUMMARY OF DESIGN CHANGES

Details of change	When introduced
Sensing unit changes from single-acting (compression only) to double-acting compression and tension. Height control push rod operated by cam on ramshaft instead of connecting link as previously.	770/383397 (April 1966)
Hydraulic pump modified to give rotor bushes a more uniform balancing action. Part number of pump changed from K913394 to K917541. Pumps, but not components, are interchangeable.	990/488989 880/534055 770/584078 (June 1966)
Lower links and top links lengthened, 990 tractors to increase implement clearance. With 12-38 tyres 917420 lower link, 38½in (97.8cm) 917429 screw and housing, 8½in (21.6cm)	(June 1966)
Diameter of bolts attaching cap to levelling lever gear housing increased from $\frac{3}{8}$ UNC to $\frac{7}{16}$ UNC. New assembly (K919619) interchangeable with previous levelling lever K915775.	990/492888 880/536971 (October 1966)
Ramshaft bracket fitted with $\frac{3}{8}$ UNF plug in place of core plug (K24711), to prevent over-selection of dial pointer mechanism into TCU/Ext position.	990/505153 880/545679 780/600894 770/588585 (March) 1968
Check chain anchor bracket setscrews K603042 changed to K603039. Both setscrews are $\frac{7}{16}$ UNC but K603039 has a larger ($\frac{3}{8}$ AF) head to give an improved conical seat.	990/803189 (June 1968)
Check chain anchorage changed from PTO case to top of drawbar frame. Check chains strengthened and fitted with an adjustable link.	990/804700 (September 1968)
Ram cylinder bolts K601280 fitted with hardened steel washers, (K626874), to ensure that initial tightening torque is maintained. Fitting of bonded sealing washers (K623515) discontinued.	990/805220 (October 1968)
Double-acting take-off valve levers fitted with key (K622382) to ensure more positive clamping of lever on shaft.	990/813092 880/554040 780/603808 (August 1969)
Sensing unit shaft (K919726) changed to include machined boss at clevis end, and thus dispense with separate distance pieces (K915260). Part number of shaft unchanged.	990/812383 (August 1969)
Hydraulic pump drive gear changed from spur to helical teeth. Part number of gear changed from 914466 to 927097. Magnetic filter K904390 fitted inside filter by-pass valve, K920521, to arrest any particles which by-pass the paper element when valve is open.	990/819580 880/557477 780/608867 (October 1970) 990/828205 880/561606 780/610076 (March 1971)

SUMMARY OF DESIGN CHANGES

Details of change	When introduced
Levelling lever assembly, K929332, changed to friction welded assembly K940508. Complete assemblies fully interchangeable.	996/980046 995/922030 990/851155 885/620065 (April 1972)
By-pass plunger in control valve changed. Nylon filter and restrictor washer with 0.022in (0.56mm) dia. hole deleted and 0.069in (1.8mm) washer fitted with self-centring metering pin.	996/980826 995/923250 990/852760 885/622599 (September 1972)
Magnetic plug (K947236) fitted in connector housing K917127, in place of standard, $\frac{1}{4}$ UNF plug K920826.	996/983571 995/927514 990/857828 885/629289 (October 1973)
Ram cylinder supply pipe (K928511) fitted with 'O' ring, to prevent oil leakage where pipe protrudes through rear axle case.	996/983571 995/927514 990/857828 885/628722 (October 1973)
Double-acting take-off control levers changed from forgings to fabricated construction. Method of attaching levers to valve spindle changed from clamp bolt to locating screw.	(November 1973)
Selective sensing unit thrust washer dowels offset, so that washer cannot be assembled incorrectly. New end plate K947300 and thrust washers must be used together.	(February 1974)
Linkage pivot pins (K940000) changed to pins K94835 which are located by spring pins (K623740) instead of circlips, as previously.	996/984571 995/929586 990/861167 885/633322 (July 1974)
By-pass plunger in control valve changed so that it rotates in service; flutes angled and spring retainer fitted with steel ball at its centre. Metering pin deleted and original orifice washer with nylon filter refitted.	996/984571 995/929540 990/860534 885/632189 (November 1974)
Check chain attachment plate bolted between hitchplates (previously welded to drawbar support), to facilitate the introduction of 885 type pick-up hitch. Also new support ram introduced. (Support ram and pick-up hitch cannot be used together).	990/865634 995/93332 996/987257 (August 1975)
By-pass filter aperture cover modified to ensure that external service oil is returned to gearbox lubrication system.	885 Narrow (August 1975)
Revised hydraulic control valve adjustment procedure issued for tractors fitted with Q cabs.	(September 1976)

Other David Brown Tractors publications on hydraulics are obtainable through your DB Dealer or from Publications section, David Brown Tractors Ltd., Meltham, Huddersfield, England, HD7 3AR.

Repair Manual section. Hydraulic system — Selectamatic tractors	9-37211
Repair Manual section. Hydraulic system — Front mounted pump	9-37241
Repair Manual complete: Tractors with Implematic ® hydraulic system	9-38100
Reprints from "Farm Mechanization": Selectamatic system	9-42721
Implematic system	9-42731
Wallcharts — operation and adjustment of: Selectamatic system	9-38201
Take-off valves for external equipment	9-38301
Implematic system	9-38291
Instructional drawings: Selectamatic system	9-38532
• Flow diagrams	9-38631
• Circuit diagram, 1200 and 1400 series tractors	9-38632

Some of these publications are available in other languages — please ask for details.

HYDRAULICS—REAR MOUNTED PUMP (Synchro mesh tractors)

David Brown®

Service Repair Manual Electrical Equipment

Section H1 (Pub. 9-37222) August 1978



David Brown Tractors Ltd
A Tenneco Company
Affiliate of J I Case





This is a safety symbol which indicates important safety messages in this manual. When you see this symbol carefully read the message that follows. The safety symbol is shown when possible injury or death can occur.

Written in **Clear
And
Simple
English**

David Brown Tractors Ltd., will continue to improve their products. As a result, the specification details can have changed after this issue was made. Also, as the David Brown tractor is made to variable specifications for different uses and countries, this manual may give details of items which are not part of any specific tractor.

CONTENTS

	Page
Battery	
Safety Rules	H1
How it works	H2
Fault finding	H3
Maintenance and repair	H4
Alternator	
How it works	H8
Fault finding	H9
Maintenance and repair	H15
Dynamo	
How it works	H29
Fault finding	H30
Maintenance and repair	H32
Voltage regulator	H40
Starter Motor	
How it works	H44
Fault finding	H47
Maintenance and repair	H49
Wiper Motor	
How it works	H62
Fault finding	H63
Maintenance and repair	H65
Gauges	
How they work	H69
Fault finding	H70
Warning Lamps	
How they work	H72
Thermostart	
How it works	H73
Fault finding	H74
Wiring	
General description	H75
Colour coding	H76
Connectors and terminals	H79
Wiring diagrams	H84
Specifications and data	H117
Summary of changes	H122

SAFETY RULES



DANGER: Batteries release gases, keep sparks, flames and cigarettes away from batteries. Make sure there is a good movement of air in the area, especially when giving a battery a charge. If these instructions are not followed, combustion of the gases will occur and cause injury.



WARNING: When you remove a battery, disconnect the ground cable first. When installing a battery, connect the ground cable last. Failure to follow this procedure will cause sparks. These will cause combustion of the gases released from the battery and cause injury.



WARNING: Battery acid can cause bad burns. If acid comes into contact with any part of the body, wash with water. Flush eyes with water for 15 minutes. Permanent damage to the eyes will occur if these instructions are not followed.

For internal treatment, drink large quantities of water or milk. See a doctor as soon as possible.

Keep batteries away from children.



CAUTION: Electricity flows through metal. Never have a ring or metal watch band on your body when working near electrical equipment. Injury to the body will occur if these items come into contact with electrical connections.

BATTERY

HOW IT WORKS

The battery is made of groups of positive and groups of negative plates separated by insulation plates made of plastic.

All these are put into an electrolyte solution of sulphuric acid and distilled water inside a plastic case. The battery is given an electrical charge by connecting an external current supply to the terminals. The current moves from positive to negative. The positive plates change to lead peroxide and the negative change to spongy lead.

The battery keeps the charge in storage until needed. There will be a gradual loss of charge if the battery is not used. Internal damage will occur if the battery is kept in storage and not given a charge.


When an electrical circuit is connected to the battery terminals an electrical current flows from the battery. The current moves in the opposite direction to the charging current.

This is caused by a reaction between the electrolyte and the charged lead plates.


While the battery is releasing current the electrolyte is putting a deposit of sulphate on the plates. This causes the electrolyte to become weak and the battery voltage to decrease.

The battery must be given an electrical charge again to return the battery to a full charge. This is done by the dynamo or alternator while on the vehicle.

The battery is best given a charge from an external current, when the charge condition is less than 70%.



R78.33



R78.34

Figure H1
MATERIAL CHANGES

- | | |
|-----------------------------------|-----------------------------------|
| A. Charged battery. | D. Discharged battery. |
| B. Positive plate, lead peroxide. | E. Positive plate, lead sulphate. |
| C. Negative plate, spongy lead. | F. Negative plate, lead sulphate. |

FAULT FINDING

Equipment Needed

Hydrometer.
D.C. moving coil voltmeter (0–40 volts).
D.C. moving coil ammeter (5–60 amps).
Heavy Discharge Tester.
An extra battery, in good condition.

TEST 1: Specific Gravity

Use an hydrometer A to check the specific gravity of the electrolyte in each cell. The test will not show correct results if distilled water has just been added. The solution must be completely mixed.

Temperature correction

For every 10° Celcius **less** than 15° Celcius, subtract 0.007 from the specific gravity shown on the hydrometer.

For every 10° Celcius **more** than 15° Celcius, add 0.007 to the specific gravity shown.

For every 10° Fahrenheit **less** than 60° Fahrenheit, subtract 0.004 from the specific gravity shown.

For every 10° Fahrenheit **more** than 60° Fahrenheit add 0.004 to the specific gravity shown.

Example:

Specific gravity corrected to 15° Celcius (60° Fahrenheit) for temperatures **less** than 25° Celcius (77° Fahrenheit).

Full charge 1.270–1.290.

70% charge 1.230–1.250.

Discharged 1.110–1.130.

For temperatures **more** than 25° Celcius (77° Fahrenheit).

Full charge 1.210–1.230.

70% charge 1.170–1.190.

Discharged 1.050–1.070.

The battery must be given a charge if less than 70% charge is shown. If there is a difference of more than 0.040 between cells make a complete check of the battery.




Figure H2
TEST METERS




Figure H3
SPECIFIC GRAVITY TEST
A. Hydrometer

TEST 2: Discharge Rate

This test can be done to check battery condition if the results of TEST 1 are not acceptable.

1. Connect a Heavy Discharge Tester to the battery terminals.
Positive to positive, negative to negative.
2. Set the tester to an ampere setting three times the 20 hour rate of the battery.

Example: Battery capacity is 96 AH (ampere hour) at the 20 hour rate. Multiply the ampere hour by 3, the result is 288. Set the meter to 290 amperes.

3. After 15 seconds discharge at this rate, read the voltmeter.

If the voltmeter shows more than 9.6 volts after 15 seconds the battery is in good condition. If less than 9.6 volts, install a new battery or have it checked by a battery specialist.




Figure H4
BATTERY DISCHARGE TESTER

R7837

MAINTENANCE AND REPAIR

MAINTENANCE

1. Check the level of the electrolyte every 60 hours. Add only distilled water to the level of the splash guard.
2. Keep the battery clean and dry at all times, especially the top.
3. Apply petroleum jelly to the terminals to prevent oxidation. Corrosion between terminal and battery post will give a bad connection and bad starting. Make sure the terminals are tight.
4. Make sure the battery holding clamp is tight. Any vibrations can cause internal damage and a loss of battery efficiency.
5. Keep the battery tray clean. Wash off all corrosion with a solution of ammonia or soda and hot water. Apply acid resistance paint to all metal parts after all corrosion is removed.
6. Batteries in storage must be given a charge from time to time to keep a full charge. Damage will occur if a battery is in storage for a long time in a discharged condition. A discharged battery will freeze in cold conditions.
7. Batteries in use on vehicles must also be given a charge from an external supply every six months. A battery is not kept at full charge by the vehicle generating equipment.

BATTERY CHARGING

Rate: Set the equipment to $\frac{1}{10}$ th of the 20 hour rate of the battery.

Example: The battery is $60\text{AH} \div 10 = 6$ amperes setting.

Filler Caps: These must be removed when giving a battery a charge.

Connections: Make sure the battery and equipment connections are clean and dry.

Make sure the connections are tight and safe from making sparks.



WARNING: When you remove a battery, disconnect the ground cable first. When installing a battery, connect the ground cable last. Failure to follow this procedure will cause sparks. These will cause combustion of the gases released from the battery and cause injury.

Electrolyte: Keep the electrolyte at the correct level, during the charge. Add only distilled water to the electrolyte. Fill to level of splash guard. Keep the top of the battery dry and free from electrolyte.

Stop the charge before trying to clean the battery top.



WARNING: Battery acid can cause bad burns. If acid comes into contact with any part of the body, wash with water. Flush eyes with water for 15 minutes. Permanent damage to the eyes will occur if these instructions are not followed.

For internal treatment, drink large quantities of water or milk. See a doctor as soon as possible.

Keep batteries away from children.

Specific Gravity: Check this with an hydrometer at one hour intervals during the charge. When

the specific gravity shows the same results on three checks following each other, the charge is complete.

Voltage: Check the battery voltage just before and after the start of the charge. If the voltage has not increased check the polarity of the connections.

Temperatures of Electrolyte: For batteries which operate in air temperatures of less than 25°C (77°F), keep the electrolyte temperature to less than 38°C (100°F).

For batteries which operate in air temperatures of more than 25°C (77°F), keep the electrolyte temperature to less than 50°C (120°F).

Gassing: This is the name for the release of oxygen and hydrogen gases from the battery. It increases when the battery is given a charge. All possible causes of sparks or flame must be kept away. Also make sure there is a good movement of air through the area.



DANGER: Batteries release gases, keep sparks, flames and cigarettes away from batteries. Make sure there is a good movement of air in the area, especially when giving a battery a charge. If these instructions are not followed, combustion of the gases will occur and cause injury.

Fast Charging

This must only be done in an emergency. It **must not** be repeated at regular intervals or damage will occur to the battery. The life of the battery will be decreased.

The battery temperature must not increase to more than 43°C (110°F) during the charge. If the air temperature is more than this amount, a fast charge **must not** be given.

ELECTRICAL EQUIPMENT

A fast rate of charge can be used to increase the charge in a battery to 70%–80%. The rate of charge must be decreased gradually during the charge. The temperature will increase to more than the limit if this is not done. A normal rate of charge must be used to complete the charge, but the battery must first cool to 32° Celcius (90° Fahrenheit).

Spacing: There must be a space of not less than 25mm (1in) around all batteries.



DANGER: Before removing the connections from the battery always turn the equipment switch to 'OFF'. If the connections are removed first, a spark will occur and cause combustion of the gases.

Installing: Make sure the battery is clean and dry and the filler caps are installed correctly. The battery can then be installed on the tractor.



CAUTION: Electricity flows through metal. Never have a ring or metal watch band on your body when working near electrical equipment. Injury to the body will occur if these items come into contact with electrical connections.




Figure H5
METHODS OF BATTERY CHARGING

- | | |
|-------------------------------------|---------------------------------|
| A. Batteries connected in series. | D. 110 volt DC supply. |
| B. Batteries connected in parallel. | E. Resistance. |
| C. Ammeter. | F. Constant 110 volt DC supply. |

NEW BATTERIES

Dry without a charge

Before the battery is given a charge it must be filled with electrolyte of the correct specific gravity.

Specific gravity changes with operating temperature, see FAULT FINDING, page H3. Manufacturers also give instructions with new batteries and these must be followed exactly.

When adding the electrolyte it must be done in two stages to prevent damage to the case. When the acid makes contact with moisture in the plates, heat is generated which can cause the damage.

First, the battery must be approximately half filled and then let it cool for 6–12 hours. Then add electrolyte to the correct level and let it cool for 2 hours. Then give the battery a charge as follows:

Set the charging rate to $\frac{1}{15}$ th of the 20 hour rate. Example: Battery 128AH $\div 15 = 8$ amperes charging rate.

The current must be kept constant and not interrupted for the period of the charge. The minimum period is about 48 hours. Check the specific gravity at one hour intervals. When

there is not any change after 5 checks following each other, the charge is complete.

Temperatures must not be more than the limits shown in the normal charge section, page H5.

Dry with a charge

These batteries are sent from the manufacturer with a full charge but without the electrolyte. The charge can decrease in storage.

Fill each cell with electrolyte of the correct strength according to the operating temperature. Check the specific gravity of the electrolyte after 20 minutes. The battery can be used immediately if the following conditions are correct.

Specific gravity has not decreased more than 0.010 and temperature has not increased more than 6° Celcius (10° Fahrenheit).

If the conditions are not correct the battery must be given a charge at the normal rate. The charge will be complete when the specific gravity shows no change after 3 checks at one hour intervals.

NOTE: For battery testing and temperature corrections see the FAULT FINDING section, page H3.

ALTERNATOR

HOW IT WORKS

When the starter key A is turned to the 'ACC' position, current from the battery H illuminates the 'no charge' warning lamp B. The current then goes through the slip rings and brushes to the rotor (field windings) C and returns to the battery.

NOTE: The field windings are on the rotor and not on the body as in the dynamo. The name for the stationary windings is stator.

When the rotor turns, the current in the windings generate an AC current in the stator windings F. This is changed into a DC current

by the rectifier bridge, it then goes to the battery. The AC voltage is changed by the diode trio E to a DC voltage which is sent to the regulator G. The diode trio also prevents the charge returning from the battery to ground through the alternator. A transistor circuit in the regulator controls the flow of DC current which flows through the rotor. When there is an increase in voltage, there is a decrease in current. When there is a decrease in voltage, there is an increase in current. In this way the regulator controls the output voltage of the alternator to keep the battery charge correct.




Figure H6
ALTERNATOR CHARGING CIRCUIT

- | | |
|------------------------------|---------------------|
| A. Starter key. | F. Stator windings. |
| B. Warning lamp. | G. Regulator. |
| C. Rotor windings. | H. Battery. |
| D. Diodes, rectifier bridge. | J. Solenoid. |
| E. Diode trio. | |

FAULT FINDING

LUCAS ALTERNATOR

(see page H13 for AC-Delco)

Equipment Needed

Voltmeter

Ammeter

Jumper wire

Check the condition of the battery before testing the alternator. A battery in good condition must be used.

IMPORTANT: Never disconnect wires when the alternator is running.

Make sure starter switch is in "off" position when the engine is not running. Always check polarity before connecting wires in an alternator circuit, especially battery terminals.

Never run the alternator with the wires disconnected.

Disconnect the alternator if electrical welding is to be done on the tractor.

TEST 1: Drive Belt

Check the belt for wear and damage. If wear or damage is found install a new drive belt.

Check the tension of the drive belt. This must be set to 1cm ($\frac{3}{8}$ in) of movement at the position shown in Figure H7. When checking this movement use only medium finger pressure.

A loose drive belt will decrease the efficiency of the alternator, and cause wear to the belt. A tight drive belt will cause damage to the bearings of the alternator.

TEST 2: Connections

Check that all wires are connected correctly and are clean and tight.

TEST 3: Wires

1. Disconnect the connector plug from the alternator.
2. Turn the starter key to the 'ACC' position.
3. Use a voltmeter to check if battery voltage is reaching the 'IND' (warning lamp) and '+' (positive) connections.

If the voltmeter does not show any voltage this is an indication that the circuit is broken. Repair before continuing the test.

4. If the voltmeter does not show a voltage at the 'IND' connection, it can be a failure of the warning lamp bulb. Install new bulb.




Figure H7
DRIVE BELT ADJUSTMENT
A. Fastening bolts.

R78.41




Figure H8
CHECKING FOR SUPPLY AT PLUG
A. Alternator plug. B. Voltmeter.

R78.42

5. If a voltage is shown at both connections reconnect the plug to the alternator.
6. If the warning lamp illuminates, do the next test.
7. If the lamp does not illuminate, the alternator must be removed and the field circuit checked.

TEST 4: Output

1. Run the engine until normal running temperature is reached.
2. Stop the engine and disconnect the ground cable from the battery.
3. Disconnect the alternator output wire from the solenoid connection.
4. Disconnect the plug from the alternator and remove the plastic cover.
5. Connect an ammeter to the output wire of the alternator and to the solenoid terminal.
6. On Lucas alternators with the 8TRD regulator, connect a jumper wire from the green wire to ground as shown in Figure H10.
7. On Lucas alternators with the 14TR regulator, connect a jumper wire between the case and ground as shown in Figure H11.
8. Reconnect the alternator plug and the battery cable.
9. Turn the starter key to the 'ACC' position. Check that the warning lamp illuminates.
Start the engine and increase speed slowly. The ammeter will show 28 amperes at 1500 engine r/min if the alternator is working correctly.
10. If the output is less than 28 amperes **stop the engine** and disconnect the surge protection diode. See Figure H12.




Figure H9
CHECKING ALTERNATOR OUTPUT
A. Alternator. B. Ammeter.
C. Starter solenoid. D. Battery.




Figure H10
8TRD REGULATOR
A. Jumper wire. B. Green wire.
C. Yellow wire. D. Red wire.





Figure H11
14TR REGULATOR
A. Black wire. B. Field link.
C. Jumper wire. D. Yellow wire.

11. Start the engine again and increase speed to 1500 r/min. If the ammeter now shows 28 amperes, install a new surge protection diode.
12. If the output is still less than 28 amperes after installing the surge diode, remove the alternator. See the MAINTENANCE AND REPAIR section for disassembly and checking procedures.
13. If the output is correct, **stop the engine**. Remove the jumper wire from the regulator. Remove the ammeter and reconnect all connections.

IMPORTANT: Never disconnect or connect wires or test meters to an alternator while it is running. Damage can occur to internal parts.


TEST 5: Circuit Resistance

1. Connect a voltmeter between the alternator output terminal and the battery positive post; **not** to the battery terminal.
2. Put the tractor lighting switch to the main beam position.
3. Start the engine and increase speed to 1500 r/min. The voltmeter must show less than 0.5 volts.
4. Stop the engine and connect the voltmeter between the alternator body and the battery negative post.
5. Start the engine and increase the speed to 1500 r/min. The voltmeter must show less than 0.25 volts.
6. If the voltages are more than these limits; disconnect all connections and clean, especially the battery terminals.
Make sure all connections are tight when reconnected.
7. Repeat steps 1 to 5.



R7846

Figure H12
DISCONNECTING SURGE PROTECTION DIODE
A. Surge protection diode. B. Diode connection.



R7847

Figure H13
CHECKING RESISTANCE IN THE CIRCUIT
A. Alternator. B. Voltmeter.
C. Solenoid. D. Battery.

TEST 6: Regulator Setting

Make sure the battery is in good condition with a full charge before doing this test.

1. Disconnect the ground cable from the battery.
2. Disconnect the alternator output wire from the alternator and starter solenoid.
3. Connect an ammeter between the alternator and the starter solenoid to those connections.
4. Connect a voltmeter between the battery terminals and reconnect the ground cable to the battery.
5. Start the engine and increase the speed to 1500 r/min. When the ammeter shows less than 10 amps read the voltmeter. The voltmeter must show between 13.6 to 14.4 volts. If the voltage is not between these voltages install a new regulator.
6. Stop the engine and reconnect all connections if voltages are correct.




Figure H13
CHECKING VOLTAGE REGULATOR

A. Alternator.
B. Ammeter.
C. Voltmeter.
D. Solenoid.
E. Battery.


FAULT FINDING

(See page H9 for Lucas)

AC-DELCO ALTERNATOR

TEST 1: Engine Stopped: Switch 'OFF'
Lamp Illuminated

1. Disconnect the wire from the starter switch A to the warning lamp B.
 - (a) If the lamp stops illuminating, check the switch and replace with a new switch if necessary.
 - (b) If the lamp still illuminates with the switch wire disconnected, disconnect the 'IND' wire from the alternator C.
 - (c) If the lamp still illuminates, check for a connection between the 'IND' and '+' wires.
 - (d) If the lamp stops illuminating when the 'IND' wire is disconnected install a new rectifier bridge.
2. Check that the lamp now operates correctly and check the condition of the battery after tests.




R78.49

Figure H15
ALTERNATOR CIRCUIT

A. Starter switch.
B. Warning lamp.
C. Alternator.
D. Solenoid.
E. Battery.

TEST 2: Engine Stopped: Switch 'ON'
Lamp Not Illuminated

1. Disconnect the wire from the 'IND' terminal of the alternator and connect it to a good ground.
 - (a) If the lamp does not illuminate; check lamp, bulb socket, wires and fuses.
 - (b) If the lamp illuminates; install a new wire between the 'IND' terminal and the warning lamp.
2. Put the special rod shown in Figure H16 in through the test hole C shown in Figure H17.
 - (a) If the lamp illuminates, install a new regulator and check the rotor windings. See REPAIR section.
 - (b) If the lamp does not illuminate, check the 'IND' terminal connections. Check the brushes, slip rings, and field windings for an open circuit if the connections are correct. See REPAIR section.
3. If all these parts are found in good condition, install a new rectifier bridge.



R78.50

Figure H16
TOOL FOR CONNECTING BRUSH HOUSING TO GROUND
Make from welding rod

**TEST 3: Engine Running, Switch 'ON'
Lamp Illuminated**

1. Check the tension of the drive belt. Adjust if necessary.
2. Make sure all connections are clean and tight.
3. Check for broken wires.
4. Turn the starter key to 'ACC' and connect a voltmeter from the alternator '+' terminal A to a good ground.
 - (a) If the voltmeter shows zero, check for a broken circuit between the battery and the alternator '+' terminal.
5. Connect a voltmeter from the alternator 'IND' terminal B to a good ground.
 - (a) If the voltmeter shows zero, check for a broken circuit between the battery and the 'IND' terminal.




Figure H17
CHECKING FOR SUPPLY

- A. Positive terminal.
B. 'IND' terminal.
C. Test hole.

R7851

MAINTENANCE AND REPAIR

LUCAS ALTERNATOR

(see page H21 for AC-Delco)

The alternator is of the machine sensed type, complete with an internal regulator. All the inside connections are soldered.


IMPORTANT:

Never connect or disconnect wires in the alternator circuit when the alternator is running. Make sure the starter switch is in the 'OFF' position when the engine is not running.

Always check the polarity before connecting wires in the alternator circuit, especially the battery terminals.

Never run the alternator with the wires disconnected.

Disconnect the alternator if electrical welding is to be done on the tractor.



R78.52

Figure H18
LUCAS ALTERNATOR

Equipment Needed

Soldering iron.

Hammer.

Voltmeter.

Pliers (long nose).

Piece of steel tube.


Glass paper.

Ammeter.

MAINTENANCE

1. Check the tension of the drive belt every 125 and 500 hours. Make sure the adjustment is correct or damage will occur, see page H9, FAULT FINDING.
2. Make sure all connections are clean and tight and connected correctly.
3. Check the tightness of the bolts A which fasten the alternator to the engine.

NOTE: The bearings are filled with lubricant by the manufacturer and need no maintenance.



R78.64

Figure H19
DRIVE BELT ADJUSTMENT
A. Fastening bolts.

DISASSEMBLY

(Figure H20)

1. After the alternator has been removed from the tractor, remove the two screws A from the end cover J. Remove the cover.
2. Use a soldering iron to disconnect the three connections B which connect the stator N to the rectifier R. Use a pair of long nose pliers on the diodes as shown in Figure H25. This will prevent heat causing damage to the diodes. Make a note of the wire positions for correct assembly.
3. Remove the two screws which fasten the brush holder to the regulator P.
4. Loosen the nut C of the rectifier ground bolt.
5. Remove the screw D which fastens the regulator to the end frame K.
6. Remove the brush holder S and rectifier R together complete with wire.
7. Remove the three bolts E which hold the

- two halves of the alternator together.
8. Make a mark across the junction of the two halves before separating to make sure of correct assembly.
9. Use a piece of steel tube which will just go over the slip-ring moulding F. Put the end of the tube on the outer ring of the bearing G. Carefully remove any solder which causes a restriction to the tube, with a file.
10. Hold the alternator with the drive pulley H down. Carefully hit the tube to push the bearing out of the slip-ring end frame. Make sure the drive end has some support when doing this operation.
11. Remove the drive pulley nut T, washer U, pulley H, fan V and key.
12. Push the rotor M out of the drive end frame L.




Figure H20
LUCAS ALTERNATOR ASSEMBLY

- | | |
|---------------------------|---------------------|
| A. Screws, end cover. | L. Drive end frame. |
| B. Stator connections. | M. Rotor. |
| C. Nut, rectifier ground. | N. Stator. |
| D. Screw, regulator. | P. Regulator. |
| E. Through bolt. | R. Rectifier. |
| F. Slip-ring moulding. | S. Brush holder. |
| G. Rear bearing. | T. Pulley nut. |
| H. Pulley. | U. Washer. |
| J. Plastic cover. | V. Fan. |
| K. Slip-ring end frame. | |

R7862

TEST AND REPAIR

Brushes

1. Measure the amount that the brushes show out of the holder.
2. If this measurement is less than 8mm ($\frac{3}{10}$ in), install new brushes.
3. When installing new brushes, make sure the small leaf spring at the side of the inner brush does not get lost.
4. Use a push type gauge to check the brush spring pressures as follows: Push the brush into the holder until the end of the brush is level with the holder. The gauge will show between 255–368g (9–13oz) if the springs are in good condition.
5. If the pressure is less than 255g (9oz), install new springs.
6. If the pressure is more than 368g (13oz), check for a restriction of the brushes in the holder. Clean the brushes with a small amount of petrol on a cloth or carefully with a smooth file. DO NOT use emery or similar abrasives.




Figure H21
CHECKING ROTOR WINDING RESISTANCE
A. Ammeter. B. Slip-rings.

Rotor

1. Connect an ohmmeter or a 12volt battery and an ammeter between the slip-rings. The resistance of the windings must be as follows:
pink windings: 4.3 ohms or 2.8 amperes.
purple windings: 3.3 ohms or 3.6 amperes.
2. Use a 110volt AC supply to check the insulation. Connect a 15 watt test lamp between the slip-rings and the poles as shown. If the lamp illuminates, install a new rotor.

NOTE: The poles must not be machined. DO NOT try to correct any distortion of the shaft; install a new rotor.




Figure H22
TESTING INSULATION OF ROTOR WINDINGS
A. 15W test lamp. B. 110 volt supply.

Slip-rings

1. Clean any dirt, oil or grease from the slip-ring surfaces with a small amount of petrol on a cloth.
2. Remove scratches or other surface damage with smooth glass paper. DO NOT use emery cloth, similar abrasive or a machine for this purpose.

Diodes

Disconnect all the diodes with a soldering iron and proceed as follows:

NOTE: Use a pair of pliers to remove the heat away from the diodes, see Figure H25.

1. Connect one of the nine diodes in series with a 1.5 watt test lamp and 12volt battery. See Figure H24.
2. Connect the other battery terminal to the heat sink to which the diode being tested is fastened. Make a note of the results.
3. Now change the connections with each other. If the lamp shows the same result install a new rectifier assembly. The lamp must only illuminate in one direction.
4. Repeat 1 to 3 on all nine diodes.
5. Check the surge protection diode in the same way. The lamp must only illuminate when connected in one way.




Figure H23
DIODE PACK

A. Ind connection. D. Output diode.
B. Earth connection. E. Positive (+) connections.
C. Field diode.




Figure H24
CHECKING DIODE

IMPORTANT: When using the soldering iron to connect or disconnect the diodes use pliers as shown to remove the heat. Use only 'M' grade solder (45-55 tin-lead) with resin core and do the job as fast as possible.





Figure H25
APPLYING SOLDER TO DIODE CONNECTION

Stator

Use a 12volt battery and a test lamp of not less than 36 watts to check the windings.

1. Connect the test lamp between any two of the windings, as shown.
2. Repeat the test on all connections. Failure of the lamp to illuminate is an indication of a broken circuit. Install a new stator.




R7860

Figure H26
CHECKING CONTINUITY OF STATOR WINDINGS

- A. 12volt battery.
B. Test lamp, 36 watt.
C. Stator.

Use a 110volt AC supply and a 15 watt test lamp to check the stator insulation as follows:

1. Connect the lamp between any one of the wires and the laminations as shown.
2. Repeat on the other two wires. If the lamp illuminates there is a failure in the stator windings. Install a new stator.



R7861

Figure H27
TESTING INSULATION OF STATOR WINDINGS

- A. Supply of 110 volts AC.
B. Test lamp, 15 watt.
C. Stator laminations.

BEARING REPLACEMENT

Slip-ring End
Figure H28.

1. Use a soldering iron to disconnect the slip-ring wires. Remove the slip-ring moulding F from the rotor shaft.
2. Pull the bearing G from the shaft with an acceptable puller.
3. Clean the shaft and position the new bearing with the shield nearest the slip-ring moulding.
4. Push the bearing on to the shaft as far as it can go.
5. Install the slip-ring moulding and use 'M' grade solder to reconnect the rotor winding wires.

Drive End

1. Remove the circlip and push the bearing out of the drive end frame.
2. Press the new bearing into the end frame.

Fit the circlip and make sure it has fully entered the groove all the way round.

ASSEMBLY
Figure H28

Assemble the alternator in the opposite sequence to disassembly. Make sure the following instructions are followed when assembling.

1. Push the bearing G at the slip-ring end on to the shaft as far as it can go.
2. Put the brushes into the holder before installing the holder in the alternator.
3. Use a steel tube as a support on the inner ring of the drive end bearing. Install the rotor. DO NOT use the drive-end frame as a support when installing the rotor.
4. Tighten the three-bolts E which hold the two halves of the alternator together, to 75Nm (8kgm) (55lbin).




Figure H28
LUCAS ALTERNATOR ASSEMBLY

- | | |
|---------------------------|---------------------|
| A. Screws, end cover. | L. Drive end frame. |
| B. Stator connections. | M. Rotor. |
| C. Nut, rectifier ground. | N. Stator. |
| D. Screw, regulator. | P. Regulator. |
| E. Through bolt. | R. Rectifier. |
| F. Slip-ring moulding. | S. Brush holder. |
| G. Rear bearing. | T. Pulley nut. |
| H. Pulley. | U. Washer. |
| J. Plastic cover. | V. Fan. |
| K. Slip-ring end frame. | |

MAINTENANCE AND REPAIR

AC-DELCO ALTERNATOR

(see page H15 for Lucas)

The alternator is of the machine sensed type complete with regulator. All internal connections are fastened by screws or nuts and easily removed.

IMPORTANT

Never connect or disconnect wires in the alternator circuit when the alternator is running. Always make sure the starter switch is in the 'OFF' position if the engine is not running.

Always check the polarity before connecting wires in the alternator circuit, especially battery terminals.

Never run the alternator with the wires disconnected.

Disconnect the alternator if electrical welding is to be done on the tractor.

EQUIPMENT NEEDED

$\frac{15}{16}$ AF and 8mm open end spanners.
 $\frac{5}{16}$ in Allen key.
 $\frac{9}{16}$ AF, 8mm and 10mm sockets.
 Pozidriv screwdriver.
 Long nose pliers.
 Ohmmeter and test lamp.
 Hammer and punch.

MAINTENANCE

1. Check the drive belt tension every 125 and 500 hours.
2. Keep the alternator clean, especially around the connections.
3. Check the tightness of the bolts A which fasten the alternator to the engine.
4. Make sure all electrical connections are clean, tight and connected correctly.

NOTE: The bearings are filled with lubricant by the manufacturer and do not need maintenance.




Figure H29
AC-DELCO ALTERNATOR

R78.63




Figure H30
DRIVE BELT ADJUSTMENT
A. Fastening bolts.

R78.53

DISASSEMBLY**Slip-Ring end**

1. Make a mark across the junction of the two halves of the alternator. This will make sure the halves are assembled in the same position.
2. Remove the three bolts which hold the two halves together.
3. Carefully separate the two halves and look for the brush springs which can fall out.
4. Put a piece of tape over the bearing A in the slip-ring end frame B. This will prevent dirt from entering.
5. Put a piece of tape on the bearing surface of the rotor shaft to give it protection from damage.
6. Remove the three nuts C which hold the stator wires to the rectifier bridge D.
7. Carefully remove the stator from the end frame. Put the stator on the bench with the terminal lugs up.
8. Use an ohmmeter to check the insulation of the diode trio E before removing it. Connect the ohmmeter between the link F and the frame B. If the ohmmeter shows a low resistance then a new fastening screw G must be installed when assembling.
9. Remove the Pozidrive screw G holding the diode trio E and remove the diode trio.
10. Use an ohmmeter to check the insulation of the screw H holding the brush assembly. Connect the ohmmeter between the brush assembly clip and the frame B. If a low resistance is shown, install a new screw H when assembling.
11. Remove the Pozidrive screw H holding the brush assembly and remove the brush assembly J.
12. Remove the two screws K and L holding the rectifier bridge and remove the rectifier bridge D.
13. Remove the Pozidrive screw M holding the regulator N and remove the regulator.





Figure H31
SLIP-RING END FRAME

- A. Bearing, roller type.
- B. Frame, slip-ring end.
- C. Rectifier terminals.
- D. Rectifier bridge.
- E. Diode trio.
- F. Link, diode trio.
- G. Diode trio screw, with insulation.
- H. Brush holder screw, with insulation.
- J. Brush holder.
- K. Rectifier screw.
- L. Rectifier screw, with insulation.
- M. Regulator screw.
- N. Regulator.

R78.65

Drive End

1. Put a $\frac{5}{16}$ in Allen Key in the drive end of the rotor shaft A to prevent it from turning. Use a $\frac{15}{16}$ AF spanner to loosen the pulley nut B.
2. Remove the nut B, washer C, pulley D, fan E and outer spacer F from the rotor shaft.
3. Carefully remove the rotor G from the end frame H. Remove the inner spacer J from the rotor shaft.



R78.66

Figure H32
DRIVE END FRAME

- | | |
|------------|------------------|
| A. Shaft. | F. Outer spacer. |
| B. Nut. | G. Rotor. |
| C. Washer. | H. End Frame. |
| D. Pulley. | J. Inner spacer. |
| E. Fan. | |


TEST AND REPAIR

NOTE: Test procedures for the stator, rotor and slip-rings are the same as for the Lucas alternator.


Rectifier Bridge

Use a ohmmeter or test lamp to check the rectifier bridge in the following way.

1. Connect the positive wire of the test equipment to the insulated heat sink A.
2. Connect the negative wire of the test equipment to each terminal C of the rectifier, one at a time. Make a note of each result.
3. Now connect the negative wire to the heat sink A and the positive wire to the terminals C. Make a note of each result.
4. Install a new rectifier bridge if the same result is shown when the wires are connected in both ways.
5. Repeat steps 1 to 4 on the heat sink B which has no insulation.



R78.67.1



R78.67.2

Figure H33
TESTING THE RECTIFIER BRIDGE

- | |
|----------------------------------|
| A. Heat sink with insulation. |
| B. Heat sink with no insulation. |
| C. Terminals. |

Diode Trio

Use the following method to test the diode trio.

1. Connect the positive wire of the test equipment to the brush holder connection A. Now connect the negative wire to each of the three rectifier connections B. Make a note of each result.
2. Now connect the negative to the brush holder connection A and the positive to each of the other wires B. Make a note of each result.
3. Install a new diode trio, if any connection shows the same result when connected in both ways.




Figure H34
TESTING THE DIODE TRIO
A. Brush holder connection.
B. Rectifier connections.

Brushes

1. Remove the brushes from the holder.
2. Measure the length of the brushes. Install new brushes if less than 10mm.
3. Clean the brushes with a small amount of petrol on a cloth before installing into the holder.
4. Get a pin, approximately 2.38mm x 50mm (3/16 in x 2 in) and made of a material which is not a conductor. Push the brushes down into the holder. Put the pin through the hole in the holder to hold the brushes down. The pin is removed after the alternator has been completely assembled.




Figure H35
INSTALLING THE BRUSHES
A. Brush holder.
B. Pin, made of a material which is not a conductor.

Regulator

To check the regulator it must be connected into a circuit with a variable DC voltage. Use a supply with a maximum of 18 volts.

1. Make a test circuit as shown in Figure H36.
2. Set the supply voltage D to 10 volts. Check the voltmeter E; if showing 1.5 volts continue with test. If showing 10 volts, install a new regulator.
3. Set the supply voltage D to between 14 and 15.5 volts. Check the voltmeter E; if showing supply voltage continue with test. If showing a different reading, install a new regulator.
4. Decrease the supply voltage D until the voltmeter E shows 1.5 volts. Check the supply voltage; it will be between 14.2 and 15.1 volts if the regulator is working correctly.




Figure H36

REGULATOR TEST CIRCUIT

- A. Regulator.
- B. 18 volt supply DC.
- C. Variable resistor.
- D. Supply voltmeter.
- E. Output voltmeter.
- F. Resistor, 3 ohms 5 amp capacity.

BEARING REPLACEMENT

Slip-ring End

1. Use a piece of steel tube A 50mm (2in) in diameter as a support for the inside of the frame.
2. Use a piece of steel tube D with an outside diameter of 16.6mm ($\frac{11}{16}$ in). Push the bearing out of the frame from the outside.
3. Heat the frame B to about 50° Celcius. Push the new bearing C into the frame from the outside until it is level with the frame.
4. Put tape on the bearing to stop dirt entering. Remove when ready for assembling.





Figure H37

REMOVING AND INSTALLING SLIP-RING END BEARING


- A. 50mm (2in) steel tube.
- B. End frame.
- C. Roller bearing.
- D. 16.6mm ($\frac{11}{16}$ in) steel tube.

Drive End

1. Remove the three screws from the retainer plate which keeps the bearing in place. Remove the plate.
2. Use a piece of steel tube A 50mm (2in) diameter as a support on the inside of the frame.
3. Using a piece of steel tube B the same size as the inner ring of the bearing. Push the bearing out of the frame, from the outside of the frame.
4. Heat the frame to about 50° Celcius. Using a piece of tube C the same size as the outer ring of the bearing. Push the new bearing into the frame, with the tube, from the inside of the frame.



R78.72



R78.73

Figure H38
REMOVING AND INSTALLING DRIVE END BEARING
A. 50mm (2in) steel tube.
B. Steel tube, same size as bearing inner ring.
C. Steel tube, same size as bearing outer ring.
D. Drive end frame.
E. A press.

ASSEMBLY**Slip-ring End**

1. Fasten the regulator N loosely into position with the screw M which has no insulation.
2. Install the insulation sleeve P to the rectifier bridge D.
3. Install the rectifier bridge into the frame. Align the terminals in the centre of the terminal opening. Install and tighten the screws L and K.
4. Put the brush holder J on to the regulator. Make sure the pin R which holds the brushes in place, goes through the hole in the end frame.
5. Install the insulated screw H but do not tighten.
6. Install the diode trio E and the other insulated screw G but do not tighten.
7. Move the brush holder towards the outside of the frame and tighten the screws. Now tighten the regulator screw M.
8. Put the stator into the frame. Connect the three wires to the rectifier and tighten the nuts. Make sure the three terminals C are not making contact with the heat sink. Bend clear if necessary.
9. Remove the tape from the bearing in the end frame and from the rotor shaft. Clean off any deposit remaining.




Figure H39
SLIP-RING END FRAME

- | | |
|----------------------------|---|
| A. Bearing. | K. Rectifier screw, without insulation. |
| B. Frame. | L. Rectifier screw, with insulation. |
| C. Terminals of rectifier. | M. Regulator screw, without insulation. |
| D. Rectifier. | N. Regulator. |
| E. Diode trio. | P. Insulation sleeve. |
| F. Diode trio link. | R. Pin, brushes. |
| G. Screw with insulation. | |
| H. Screw with insulation. | |
| J. Brush holder. | |

R78.74

Drive End

1. Clean all the parts.
2. Put the larger of the two spacers J on the drive end of the rotor shaft A. Make sure the chamfer is towards the end of the shaft.
3. Install the rotor G into the end frame bearing K.
4. Put the outer spacer F on the armature shaft.
5. Put the fan E, pulley D, washer C and nut B on to the shaft in that sequence.
6. Tighten the pulley nut B to a torque of 54–80Nm (5.5–8.3kgm) (40–60lbf ft).
7. Make sure the slip-rings are clean, then enter the rotor shaft into the slip-ring frame bearing.
8. Align the marks made on the two halves of the frame and push the halves together.
9. Install the three bolts which hold the two halves together and tighten to a torque of 40–68Nm (4–7kgm) (30–50lbf in).
10. Remove the pin R, Figure H39, which is holding the brushes into the holder.




Figure H40
DRIVE END FRAME

- | | |
|------------|------------------|
| A. Shaft. | F. Outer spacer. |
| B. Nut. | G. Rotor. |
| C. Washer. | H. End Frame. |
| D. Pulley. | J. Inner spacer. |
| E. Fan. | K. Bearing. |

R78.75

DYNAMO

HOW IT WORKS

When the starter key A is turned to the ACC position the 'no charge' warning lamp J is illuminated. Battery current goes through the brushes and armature windings B to ground.

When the engine is started a current is generated in the armature windings. This is caused by the armature turning in a magnetic field made by the field magnets C. The current goes from the armature to the field windings. This current in the field winding increases the strength of the magnetic field. The effect is to increase the armature current. Both currents increase with armature speed. When the armature output reaches 13 volts the cut-out contacts D of the regulator close. This connects the dynamo to the battery and charging starts. When the output decreases to 12 volts the contacts open to prevent the current returning through the dynamo.

When the dynamo output voltage increases the voltage difference at the warning lamp terminals decreases. This causes the lamp to stop illuminating.

The maximum output of the armature is regulated by another set of contacts E. These open, at a set maximum and interrupts the current to the field windings. Field current decreases causing armature current to decrease and the contacts close again. All this occurs at a fast rate, keeping output limited to a set amount. Charging current is controlled by the battery charge condition. A discharged battery will take a high rate of charge. A charged battery will take a low rate of charge.




Figure H41

DYNAMO CIRCUIT

- A. Starter key.
- B. Commutator.
- C. Field magnets.
- D. Cut-out contacts.
- E. Regulator contacts.
- F. Field connection.
- G. Battery.
- H. Starter solenoid.
- J. Warning lamp.
- K. RB108 type regulator.

FAULT FINDING

Equipment Needed

Voltmeter
Jumper wires

TEST 1: Output

1. Check that the drive belt is adjusted correctly. Check for wear and damage.
2. Disconnect both the wires from the dynamo terminals and connect a jumper wire from one terminal to the other as shown Figure H42.
3. Connect a voltmeter from the jumper lead to ground. Start the engine and let it run at idle speed. The voltmeter must show between 10 and 13 volts and increase with engine speed at a rapid rate. Do not let the voltage increase more than 20 volts or damage can occur to the dynamo.

If the voltage is less than 10 volts or does not increase at a rapid rate remove the dynamo.

4. Disassemble the dynamo and check all parts. See MAINTENANCE AND REPAIR section for procedures.
5. If the voltage is correct reconnect the dynamo wires.




Figure H42
CHECKING DYNAMO OUTPUT

A. Dynamo	D. Positive wire.
B. Voltmeter.	E. Ground connection.
C. Jumper wire.	F. Field wire.

R78.77

TEST 2: Wiring

1. Disconnect the wires from the D and F terminals of the voltage regulator and connect the wires together. Make sure the wires do not make contact to ground.
2. Connect a voltmeter between the ends of the wires and earth.
3. Start the engine and let it run at idle speed. The voltmeter must show a voltage of 10 to 13 volts. If the voltmeter does not show any voltage, check for a break in the wires. Check for loose or dirty connections.




Figure H43
CHECKING DYNAMO WIRING

A. Black wire.	E. Ground.
B. Brown wire.	F. Brown/Green wire.
C. Jumper wire.	G. Brown/Yellow wire.
D. Voltmeter.	H. Regulator.

R78.78

4. Disconnect the D & F wires from the dynamo. Use a jumper wire to connect one end of the D wire to the battery positive terminal. Connect a voltmeter between the other end of the D wire and ground. The voltmeter must show battery voltage or there is a break in the wire. Do the same with the F wire.
5. Connect one end of the D wire to the battery positive terminal. Connect the voltmeter from the F wire to ground. If a voltage is shown on the voltmeter there is a leakage from D to F. Reconnect all wires if correct.




Figure H44
CHECKING DYNAMO WIRING

- | | |
|-----------------------|-------------------------------------|
| A. Regulator. | E. Jumper wire to battery positive. |
| B. Voltmeter. | F. Brown/Green wire. |
| C. Dynamo. | |
| D. Brown/Yellow wire. | |

TEST 3: Regulator

1. Make sure the black wire from the E terminal of the regulator is making a good connection to ground.
2. Disconnect the wire from the A terminal of the regulator. Make sure the wire does not make contact to ground.
3. Connect a voltmeter to the D terminal of the regulator and to ground. Do not disconnect the D wire from the regulator.
4. Start the engine and increase the speed to 2000 r/min. The voltmeter must show 16 to 16.6 volts at 20° Celcius (68° Fahrenheit).
5. If the voltage is more, connect a jumper wire from the E terminal to a good ground. Do the check again. If the voltage then decreases, the E wire is not making a good connection to ground.
6. If the voltage is not correct the regulator can be adjusted.

To increase the voltage turn the screw nearest the F terminal clockwise. See Figure H46.

To decrease the voltage turn the screw counterclockwise.




Figure H45
CHECKING DYNAMO OUTPUT

- | | |
|----------------|----------------------------------|
| A. Regulator. | D. Brown/Yellow wire connection. |
| B. Voltmeter. | E. Black wire, to ground. |
| C. Brown wire. | F. Field wire. |

IMPORTANT: Use a screwdriver which has insulation on the blade. Output voltage flows through the adjusting screws and the case is connected to ground.

Make sure the test is done without delay or heat will cause the voltages to change.

7. Reconnect the wire to the A terminal and connect the voltmeter from D to ground.
8. Put the tractor lighting switch to the main beam position and start the engine. The voltage must increase to between 12.7 to 13.3 volts then decrease a small amount.
9. If the voltage is not correct adjust the screw nearest the D terminal. Turn the screw clockwise to increase the voltage or counter-clockwise to decrease the voltage.




Figure H46
VOLTAGE REGULATOR ADJUSTMENT
A. Regulator. C. Screwdriver.
B. Voltmeter. D. & E. Adjusting screws.

R78.99

MAINTENANCE AND REPAIR

Two models of dynamo are installed on David Brown tractors. These are the Lucas C40A and C40T models.

MAINTENANCE

1. Every 125 hours check the tension of the drive belt. Adjust if necessary.
2. Every 500 hours apply a small amount of engine oil to the felt pad in the commutator end plate. Remove the rubber plug, apply oil through the hole and install plug again.
3. Check the tightness of the bolts A which fasten the dynamo to the engine.
4. Make sure the electrical connections are clean, tight and correctly connected.
5. Clean the dynamo, especially around the electrical connections.




Figure H47
FAN BELT ADJUSTMENT
A. Dynamo fastening bolts

R78.82

DISASSEMBLY

After the dynamo has been removed from the tractor use the following procedure to disassemble.

1. Remove the two bolts A which hold the assembly together.
2. If an early type dynamo, remove the nut and washers from the field connection B.
3. Remove the end bracket C at the commutator end of the dynamo.
4. Remove the drive end bracket D complete with pulley and armature E from the yoke F.




Figure H48
DYNAMO ASSEMBLY

- | | |
|----------------------------|----------------------|
| A. Through bolt. | H. Ball bearing. |
| B. Field terminal. | J. Circlip. |
| C. Commutator end bracket. | K. Seals. |
| D. Drive end bracket. | L. Pulley spacer. |
| E. Armature. | M. Felt oil pad. |
| F. Yoke. | N. C40T end bracket. |
| G. Bush. | |

R78.83

TEST AND REPAIR

Brushes

1. Remove the brushes from the holders and measure the length. If less than 8mm ($\frac{5}{16}$ in), install new brushes.

On the C40T model, measure to the shoulder of the brush.

2. Clean the brushes with a small amount of petrol on a cloth. Make sure the brushes can move easily in the holders after installing.
3. Apply a small amount of engine oil to the brush pivot arms of the C40T model.
4. Install the end plate complete with brushes on to the commutator.
5. Use a spring-balance to check the brush spring tension with the brushes in the working position.

6. Install new springs if the tensions are not inside the following limits:

C40A model: 368–850g (13–30oz)

C40T model: 567–680g (20–24oz)

NOTE: When installing new springs in the C40A model, make sure the spring is as shown in Figure H49.




Figure H49
INSTALLING BRUSH SPRINGS

A. Correct.

B. Wrong.

Armature

1. Check for damage or movement of solder connections, caused by heat.
2. Check for movement of commutator segments.
3. Install a new armature if any of the above damage is found. Look for possible cause before running the dynamo again.
4. Check for any indication of armature to field winding contact. If any is found, check bearings for wear. Check the tightness of the screws which fasten the pole shoes to the yoke.
5. Clean the commutator with a small amount of petrol on a cloth. Remove small surface damage with smooth glass paper. Do NOT use emery or similar abrasive.
6. If the damage is deep, a lathe can be used to remove the damage. First check what type of commutator is used, fabricated or moulded, see Figure H50.




Figure H50
IDENTIFICATION OF COMMUTATORS
A. Moulded commutator.
B. Fabricated commutator.
C. Insulation cone.
D. Metal roll over.

Before doing any repair make sure the armature windings are in good condition.

1. Use a 110 volt AC supply and a 15 watt test lamp to check the insulation as follows:
Connect the supply to the armature shaft and the test lamp to one of the segments. Repeat the test on all segments. If the lamp illuminates, install a new armature.
2. Connect an ohmmeter between two segments next to each other. Continue this check all round the commutator until all segments have been checked. The reading must be the same for all segments. If a zero or low reading is shown, install a new armature.

If the armature is in good condition the following procedures must be followed for a repair.

1. For fabricated commutators the segments must not be decreased to less than a thickness of 1.5mm ($\frac{1}{16}$ in). Cut the insulation to 0.8mm ($\frac{1}{32}$ in) below the segments.
2. For moulded commutators the diameter of the commutator must not be decreased to less than 37mm (1.45in). DO NOT cut the insulation away between the segments. It is made to a set depth by the manufacturer.
3. Use a very fine glass paper to get a smooth finish. Clean away particles with an air jet.

NOTE: Make sure all particles of copper are removed from between the segments after a repair.




Figure H51
CHECKING INSULATION OF ARMATURE WINDINGS
A. 110 volt AC supply.
B. 15 watt test lamp.





Figure H52
CHECKING CONTINUITY OF ARMATURE WINDINGS
A. Commutator segments.
B. Ohmmeter.

Field Windings

1. Check the tightness of the pole shoe screws.
2. Make an inspection of the windings for any indication of contact with the armature.
3. Check for damage to insulation material.
4. Check for damage to the wire which connects the two windings together.
5. Check the windings for damage caused by heat. Install new windings if damage is found. Look for the possible cause before running the dynamo after assembly.
6. Connect an ohmmeter between the field winding connection and a good ground connection on the yoke. The resistance shown must be 6 ohms, if less look for a short circuit. If the reading is more, check for bad ground connection between the windings and the yoke.


NOTE: This test can also be done by using an ammeter as shown in Figure H53. The reading will be 2 amperes if the windings are in good condition.

7. To remove the windings, use a drill to remove the rivet which connects the windings to the yoke. Then remove the screws which fasten the pole shoes to the yoke. Remove the windings and shoes.
8. When new windings are to be installed, clean and install old pole shoes to new windings. If a threaded terminal is used, this must be fastened to the new windings. Make a note of the arrangement and colour of the wires before disconnecting.
9. Use a shoe expander to install the shoes to the yoke as shown in Figure H54.
10. Install and tighten the screws which fasten the shoes to the yoke to 41Nm (4kgm) (30lbft).
11. Fasten the windings to the yoke with a new rivet.
12. The wire which connects the windings together must be set in the following positions. See Figure H55.
 - (a) If the wire has an insulation sleeve, put it in the position shown in Figure H55C.
 - (b) If the wire is without an insulation sleeve and is connected in the middle, set as in Figure H55B.
 - (c) If the wire is without an insulation sleeve and connected next to a winding, set as in Figure H55B.




R 78 88

Figure H53
CHECKING RESISTANCE OF FIELD WINDING
A. 12 volt battery.
B. Ammeter.
C. Field terminal.
D. Yoke.



R 78 89

Figure H54
INSTALLING FIELD WINDINGS
A. Field shoe expander.
B. Wheel type screwdriver.
C. Field windings.



R 78 90

Figure H55
FIELD LINK POSITIONS
A. Through bolts.
B. Link wire early type.
C. Link wire later type.

BEARING REPLACEMENT

Drive End

1. To check the condition of the drive end bearing do the following: Hold the drive end bracket complete with armature vertical and turn the armature by hand. Repeat this with the armature held horizontal.
2. To remove the bearing from the end bracket first remove the pulley nut. Remove the pulley and key from the shaft.
3. Press the shaft out of the end bracket.
4. Use a drill to remove the rivets which fasten the bearing retainer plate to the end bracket.
5. Use a hammer and punch to remove the rivets from the end plate.
6. Press the bearing out of the end plate.
7. Clean around the area and press the new bearing into the end bracket.
8. Use new rivets to install the bearing retainer plate.
9. Press the armature through the bearing of the end bracket as far as it can go.

10. Install the key, pulley, washer and nut to the shaft. Tighten the nut to a torque of 34Nm (3.5 kgm) (25 lbft).

Commutator End

1. Put the new bush in engine oil for 24 hours.
2. Turn a $\frac{5}{16}$ in thread tap into the old bush and pull the bush out of the end bracket.
3. Remove the disc and felt oil pad from the bush hole; clean the hole.
4. Apply engine oil to the felt pad and install with the disc into the end bracket.
5. Use a mandrel with a shoulder to press the new bush into the end bracket. The mandrel must be 0.002in larger than the armature shaft.

DO NOT put a reamer through the bush after it has been installed. This will decrease the lubrication quality of the bush.

ASSEMBLY

1. Install the armature complete with drive end bracket and pulley into the yoke.
2. Install the end bracket to the commutator end.

On the C40A type, hold the brushes up in the holders with the springs as shown at A, Figure H56. Push the bracket on to the armature, pull the springs up on to the top of the brushes.

Use the special tool shown in Figure H57 for this purpose.

On the C40T type, hold the brush pivot arms outwards with your fingers, while you push the bracket on. Release the arms slowly when the brushes are over the commutator.

3. Make sure both end brackets are correctly installed. Install the two through bolts and tighten to 8Nm (0.8kgm) (6lbft).
4. Check the output, see FAULT FINDING, page H30.

5. If test equipment is not available check the dynamo as follows:

Make a connection between the field and output terminals. Then connect these to the positive terminal of a 12 volt battery. Connect the negative of the battery to a good ground connection on the yoke.

If assembled correctly the dynamo will run as a motor.

IMPORTANT: Make sure the polarity is correct before making the connections.

6. To correct the polarity of a dynamo fitted to a tractor use the following procedure:

Connect a jumper wire to the battery positive terminal. Put the other end of the wire against the field terminal several times. Hold it in contact with the terminal for part of a second only, each time.




Figure H56
INSTALLING BRUSHES BEFORE FITTING END PLATE
C40A DYNAMO
A. Brush held with spring.
B. Brush in working position.

R 78 91




Figure H57
BRUSH SPRING HOOKING TOOL

R 78 92




Figure H58
USING BRUSH SPRING TOOL
A. Brush. B. Spring. C. Tool.

R 78 93

VOLTAGE REGULATOR

Tractors with the Lucas C40A dynamo installed, use the Lucas RB108, Despatch number 37394A or 37398A. David Brown Part number K90890. Tractors with the Lucas C40T dynamo installed use the Lucas RB108, Despatch number 37467. David Brown Part number K928729.

MAINTENANCE

The only maintenance needed is a regular check of the connections, especially the wire between 'E' and ground.

The regulator will not operate correctly if there is a bad connection to ground. The result of this can be an increase in the operating temperature of the dynamo, causing damage. The charge rate will also increase to more than the battery needs.

TEST AND REPAIR

Before doing the following tests and adjustments do tests in the FAULT FINDING section. If the fault is not corrected, proceed as follows:

1. Remove the four wires and two fastening screws. Remove the regulator from the tractor.
2. Remove the regulator cover by bending the edge of the cover away from the baseplate.
3. Remove any dust with a dry brush. Use methylated spirits to remove dirt which cannot be removed with a dry brush, if necessary.
4. Clean the voltage regulator contacts with a smooth carborundum stone or silicon carbide paper, if necessary.
5. Clean the cut-out contacts with a fine glass paper. DO NOT use emery cloth or a carborundum stone.




Figure H59
RB108 VOLTAGE REGULATOR
A. Regulator armature.
B. Cut out armature.

R 78 84

Regulator Contacts Gap

This is set by the manufacturer and normally does not need setting. If it is necessary to set the gap, use the following procedure.

1. Loosen the fixed contact locknut F and turn the fixed contact screw B counter-clockwise away from the armature C.
2. Loosen the screws A which fasten the armature.
3. Put a feeler gauge D of 0.50mm (0.020in) thickness between the armature and the coil core face.
4. Press the armature down against the feeler gauge and tighten the screws A which fasten the armature.
5. With the feeler gauge still in position, turn the fixed contact screw B clockwise. Continue turning until the fixed contact is just against the armature. Lock the fixed contact in this position with the locknut.
6. Reset the voltage adjustment screw E.




Figure H60
REGULATOR GAP SETTING
A. Armature fastening screws.
B. Fixed contact.
C. Armature.
D. Feler gauge.
E. Voltage adjustment screw.
F. Fixed contact locknut.

R78.95

Cut-out Contacts Gap

This is also set by the manufacturer but can be set as follows if necessary:

1. Loosen the screws A which fasten the cut-out armature C.
2. Press the armature down against the coil core face and tighten the fastening screws.
3. Hold the armature down in this position and measure the gap F between the armature and the stop arm D. The gap must be 0.60–1.01mm (0.025–0.040in) and can be adjusted by bending the stop arm.
4. Release the armature and measure the gap F between the cut-out contacts. This must be 0.25–0.51mm (0.010–0.020in) and can be adjusted by bending the fixed contact blade B.
5. Reset the voltage adjustment screw E.




Figure H61
CUT-OUT GAP SETTING
A. Armature fastening screws.
B. Fixed contact blade.
C. Armature.
D. Stop arm.
E. Voltage adjustment screw.
F. Gap.

R78.96

Cut-out Adjustment

1. Connect a voltmeter A between the voltage adjustment screw B on the cut-out and a good ground connection.
2. Start the engine and gradually increase speed. The voltage must increase to 12.7 to 13.3 volts and then decrease a small amount.
3. Make a note of the voltage at which the voltage decreases. If this is not between 12.7 and 13.3 volts adjust by turning the adjustment screw B.
4. Check the cut-in voltage again after the adjustment has been made. Let the engine run at idle speed and then increase the speed gradually until the voltage decreases.
5. Disconnect the wire from the 'A' terminal and make sure it does not connect with ground.
6. Connect a voltmeter A between the 'A' terminal and a good ground connection.
7. Start the engine and increase the speed to 1500 r/min, then decrease speed slowly and read the voltmeter.
8. Make a note of the voltage at which the needle returns to zero. This is an indication of the cut-out contacts opening and must occur at 8.5 to 10 volts.
9. If the contacts open outside these limits, remove the cover. Bend the fixed contact blade B, Figure H61, page H41. Bend the blade towards the armature to decrease the voltage at which the contacts open. Bend the blade away from the armature to increase the voltage at which the contacts open.
10. When all adjustments have been completed and all voltages are correct, reconnect the wire to the 'A' terminal. Put the cover in position and bend the edges over the base-plate.




Figure H62
CHECKING CUT-IN SETTING OF CUT-OUT
A. Voltmeter.
B. Cut out adjustment screw.

R78.97




Figure H63
CHECKING CUT-OUT DROP-OFF VOLTAGE
A. Voltmeter.

R78.98


Regulator Voltage Adjustment.

If a test bench is not available, install the regulator on the tractor and use the following procedure.

1. Make sure all connections are clean and tight, especially the ground wire connections.
2. Remove the wire to the 'A' terminal. Make sure it is prevented from making contact with ground.
3. Start the engine and run it at 1500 r/min.
4. Connect a voltmeter B between the regulator adjustment screw D and a good ground connection.
5. Turn the adjustment screw E clockwise to increase the voltage and counter-clockwise to decrease it.
6. The voltage must be set to the following values shown:

Air Temperature	Voltage:
10° Celcius (50° Fahrenheit)	Open Circuit 16.1 to 16.7
20° Celcius (68° Fahrenheit)	16.0 to 16.6
30° Celcius (86° Fahrenheit)	15.9 to 16.5
40° Celcius (104° Fahrenheit)	15.8 to 16.4

NOTE: Do the adjustment as fast as possible or the coils will generate heat and change the readings.
7. When the voltage is correct, stop the engine. Start the engine again after a short period and check the voltage. If it is still correct reconnect the 'A' terminal wire.



R78.99

Figure H64
CHECKING DYNAMO OPEN-CIRCUIT VOLTAGE
 A. Voltage regulator.
 B. Voltmeter.
 C. Screwdriver with insulation on the blade.
 D. Regulator adjustment screw.
 E. Cut-out adjustment screw.

STARTER

HOW IT WORKS

Lucas M.50 Model

Before the starter can be operated the starter safety switch has to be closed. This is done by putting the range lever (Hydra-Shift) or gear lever (Syncromesh) in the neutral position.

When the starter-key is turned to the START position battery current energises the solenoid coils. The solenoid plunger A is retracted and the pinion B is engaged with the flywheel ring gear C.

The solenoid has two sets of contacts. The first set D to close are connected to only one field-winding E. The second set F is connected to the other three. If the teeth of the pinion and flywheel are not aligned only the first set close. This gives enough power to turn the armature to align the teeth. The engagement spring G then engages the pinion with the flywheel and closes the second contacts. With both contacts closed full power is available to turn the engine.

When the starter key is released the current to the solenoid is interrupted and the plunger is released. The return spring H disengages the pinion from the flywheel and opens both sets of contacts.

To prevent the engine turning the starter when the key is released a one-way clutch is installed. This is part of the pinion assembly and has rollers which lock in one direction only, Figure H69.

To stop the starter as soon as the key is released a centrifugal brake is installed. Two shoes are fastened to the commutator end of the armature with springs. The shoes move outwards and make contact with end plate as the armature speed increases. The brake also prevents the starter speed increasing above a set rate if the load is low.




Figure H65
PINION DISENGAGED

A. Plunger.
B. Drive pinion.
C. Flywheel gear.




Figure H66
TOOTH TO TOOTH CONTACT

D. First contacts.
E. Field winding.
F. Second contacts.




Figure H67
PINION ENGAGED
G. Engagement spring.
H. Return spring.

Lucas M45 Model

Before the starter will operate the safety switch must be closed. This is done by putting the range lever (Hydra-Shift) or gear lever (Synchromesh) in the neutral position.

After the safety switch A has been closed the starter key B is turned to the START position. Battery current then energises the solenoid coil C which retracts the plunger D.

As the plunger is retracted it engages the pinion with the flywheel ring gear. When the plunger is fully retracted it closes a set of contacts E. Battery current now goes to the armature and field windings F. Full power is available to turn the engine.

If the teeth of the pinion and flywheel are not aligned the engagement spring coils close. The plunger can then complete the movement to close the contacts to give current to turn the armature. The engagement spring engages the pinion when the teeth are aligned. A one-way clutch prevents the engine turning the starter when the engine starts, see Figure H69.

Early starters had multi-plate clutches but later models have a roller type, as installed on the M50 model.




Figure H68
LUCAS M45G STARTER

- | | |
|----------------------|--------------------|
| A. Safety switch. | D. Plunger. |
| B. Starter switch. | E. Contacts. |
| C. Solenoid winding. | F. Field windings. |




Figure H69
ROLLER CLUTCH ASSEMBLY

- | |
|--------------------|
| A. Lock direction. |
| B. Free direction. |
| C. Rollers. |




Figure H70
PLATE CLUTCH ASSEMBLY

- | |
|-------------------|
| A. Clutch plates |
| B. Driving sleeve |
| C. Moving member |

Starter for Gasoline Engine

The safety switch A is closed with the gear lever in neutral. When the ignition key B is turned to START battery current energises the solenoid C and closes a set of contacts D. Current then goes through the contacts to the armature E and field windings F to give full power.

The pinion is not directly connected to the armature but moves along a spiral sleeve on the armature. The sleeve has a large external spiral which fits an internal spiral of the pinion. When the armature turns, the sleeve turns and the pinion moves along the sleeve towards the flywheel. The sleeve is prevented from moving along the armature shaft by a strong spring. This spring absorbs any shocks when the pinion first engages the flywheel.

When the starter key is released the armature stops turning. The flywheel moves the pinion along the sleeve in the opposite direction until it disengages.




Figure H71
STARTER CIRCUIT GASOLINE ENGINE

- | | |
|--------------------|---------------------|
| A. Safety switch. | F. Field windings. |
| B. Starter switch. | G. Battery. |
| C. Solenoid. | J. Pinion assembly. |
| D. Contacts. | K. Flywheel gear. |
| E. Armature. | |




Figure H72
DRIVE PINION ASSEMBLY

- | |
|------------------------|
| A. Anti rattle spring. |
| B. Drive pinion. |
| C. Spiral sleeve. |
| D. Drive spring. |

FAULT FINDING

Make sure the battery has a full charge and that all connections are clean and tight before starting the tests.

Before operating the starter:

- (a) Put the gear-lever (Syncromesh) or range-lever (Hydra-Shift) in the neutral position.
- (b) Put the engine stop control in the stop position.

TEST 1: Switch Circuit

If the starter does not operate when the starter switch is turned to START proceed as follows:

1. Connect a new switch in between the solenoid and the battery positive terminal as shown in Figure H73.
2. Close the switch; if the starter works check for dirty, loose or broken connections in the switch circuit.
3. Check the starter switch and safety switch for correct operation if all wires and connections are correct.
4. Install new switches if necessary and test again.
5. If starter turns slowly do the next test.




Figure H73
CHECKING STARTER SWITCH CIRCUIT
A. Starter motor.
B. Battery.
C. New switch.
D. Jumper wire.

R 78.108

TEST 2: Battery Voltage

1. Connect a voltmeter between the battery posts, **not** the cable terminals.
2. Operate the starter by turning the starter key. The voltmeter must show 9.5 to 10.5 volts, with the engine warm.
3. If the voltage is less than 9.5 volts or the starter turning speed is still slow do the next test.




Figure H74
CHECKING BATTERY VOLTAGE WITH LOAD
A. Starter motor.
B. Battery.
C. Voltmeter.

R 78.109

TEST 3: Starter Cable

1. Connect the voltmeter between the insulated terminal on the starter body and the battery positive post as shown.
2. Turn the starter key to the 'ACC' position. The voltmeter must show battery voltage.
3. Operate the starter and read the voltmeter. If the voltmeter now shows more than 0.5 volts check all battery, starter and solenoid connections. Make sure a cable of the correct capacity has been installed.




Figure H75
CHECKING SUPPLY CABLE

R 78.110

TEST 4: Solenoid

1. Connect a voltmeter between the solenoid terminals as shown.
2. Operate the starter and read the voltmeter. The voltmeter must show zero when the starter is operating. If the meter shows a voltage, the solenoid contacts must be checked.




Figure H76
CHECKING THE SOLENOID CONTACTS

R 78.111

TEST 5: Ground Connections

1. Connect a voltmeter between the battery ground post and the commutator end bracket as shown.
2. Operate the starter and read the voltmeter. If more than 0.5 volts are shown, check the connections from the starter and battery to ground.
3. If tests show that the wiring and battery are correct, remove the starter for more checks. See MAINTENANCE AND REPAIR.




Figure H77
CHECKING GROUND CONNECTIONS
A. Starter motor.
B. Battery.
C. Voltmeter.

R 78.112

MAINTENANCE AND REPAIR

TYPES AND TRACTORS

Lucas M50, 1412 and 1410 tractors. Despatch Number 26379A. David Brown Part Number K919752.

Lucas M45, 1212, 1210, 996, 995, 990 tractors. Despatch Number 26278. David Brown Part Number K89772.

Lucas M45, 880, 780, 885 tractors with diesel engines. Despatch Number 26215. David Brown Part Number K913007.

Lucas 3M100, 885 tractor with gasoline engines — from January 1973. Despatch Number 25679A. David Brown Part Number K944488.

Lucas M45G, 4600, 3800, and 885 tractors to December 1972. Despatch Number 26277. David Brown Part Number K922703.

Bosch 0-001-362-060, all 4cyl models from August 1977, not all tractors. David Brown Part Number K954700.

MAINTENANCE

Check the tightness of the bolts which fasten the starter motor to the engine.

Make sure the connections are clean and tight.

NOTE: Lubrication is not needed while the starter is in use.

DISASSEMBLY

Lucas M50 and M45

1. Disconnect the battery and remove the starter from the tractor.
2. Remove the link A which connects the starter to the solenoid R.
3. Remove the nuts and washers or Bolts B which fasten the solenoid to the starter.
4. Pull the solenoid away from the starter. Disconnect the engagement fork K from the end of the plunger C. Remove the solenoid from the starter.




Figure H78
LUCAS M45 STARTER MOTOR

- | | |
|----------------------------|--------------------------|
| A. Link to solenoid. | K. Engagement fork. |
| B. Bolts to solenoid. | L. Armature. |
| C. Solenoid plunger. | M. Drive assembly. |
| D. Metal band. | N. Intermediate bracket. |
| E. Field brush. | P. Yoke. |
| F. Through bolts. | R. Solenoid. |
| G. Commutator end bracket. | S. Ground brush. |
| H. Drive end bracket. | T. Field windings. |
| J. Pivot pin. | |

5. On the M45 types, remove the metal band D from the yoke. Remove the field brushes E from the holders. Remove the two bolts F which hold the assembly together and remove the end bracket G.

On the M50 type, first remove the two bolts F which go through the starter to hold the assembly together. Move the end bracket G away from the yoke and pull the field brushes D out of the holders. Remove the end bracket G.

6. Remove the brake shoe assembly and thrust washers from the end bracket. Make a note of the positions of the washers for correct assembly.
7. Remove the rubber seal from the commutator bracket on the M50 type.

8. Loosen the locknut of the pivot pin J for the engagement fork K. Use a screwdriver to remove the pin from the end bracket H.
9. Remove the end bracket H and the engagement fork K.
10. Remove armature L complete with drive assembly M and intermediate bracket N from the yoke P.
11. Hold the armature in a vice with soft jaws. Push the thrust collar away from the circlip at the drive end.
Remove the circlip and remove the thrust collar and drive assembly from the shaft.
12. Remove the intermediate bracket and any shims from the armature shaft. Keep the shims safe for correct assembly.
13. Clean all parts ready for checking.

Lucas M45G Starter




Figure H79
LUCAS M45G TYPE STARTER MOTOR

- | | |
|-----------------------|----------------------------|
| A. Ground brush. | H. Yoke. |
| B. Bush bearing. | J. Armature. |
| C. Field terminal. | K. Metal band. |
| D. Field brush. | L. Commutator end bracket. |
| E. Field winding. | M. Cap. |
| F. Drive end bracket. | N. Through bolts. |
| G. Drive assembly. | |

R78114

Lucas 3M100 Starter

1. Disconnect the battery and starter. Remove the starter from the tractor.
 2. Remove the cap A over the end of the shaft in the commutator end bracket D.
 3. Use a small, sharp chisel to remove the claws of the retainer ring B on the end of the shaft. Remove the ring.
 4. Remove the terminal nut and washers C.
 5. Remove the two bolts which holds the starter assembly together.
 6. Separate the end bracket D at the commutator end from the yoke E. Remove the two field brushes F from the holders. Remove the end bracket D completely.
 7. Remove the bracket G, drive assembly and armature M complete, from the yoke E.
 8. Remove the retainer ring H from the end of the drive shaft. Remove the collar J, spring K and drive assembly L.
- NOTE: Some starters have a split pin and nut at the end of the shaft.




Figure H80
LUCAS STARTER MOTOR TYPE 3M100


- A. Cap.
- B. Retainer ring.
- C. Terminal nut and washers.
- D. Commutator end bracket.
- E. Yoke.
- F. Field brushes.
- G. Drive end bracket.
- H. Retaining ring drive assembly.
- J. Thrust collar.
- K. Drive spring.
- L. Drive assembly.
- M. Armature.

R78,115

TEST AND REPAIR

Brushes

1. Measure the length of each brush. If less than 14mm ($\frac{9}{16}$ in) on M50 and M45 types or 9.5mm ($\frac{3}{8}$ in) on 3M100 type, install new brushes.
2. Use a soldering iron to install new ground brushes on to the end bracket.
3. To install new field brushes, first cut the brush wires 3mm ($\frac{1}{8}$ in) from the connection to the field. Open the loop of the new brush and put solder on it. Put solder on the end of the field wire. Put the cut end through the loop of the brush wire and close the loop with pliers. Complete the connection by heating with a soldering iron.
4. Make sure the brushes can move easily in the holders. Clean brushes and holders if necessary.
5. Check the pressures of the brush springs as shown in Figure H81. If the pressure is less than 1.22kg (43oz) M50 and M45 types or 1.02kg (36oz) 3M100 type, install new springs.
6. On 3M100 type starter remove the springs with long nose pliers. To install new springs, close the coils of the spring and put it down into the holder. Move the spring in to the operating position with a small screwdriver.



R78.116

R78.117

Figure H81
CHECKING BRUSH SPRING PRESSURE
A. Pull type gauge for M50 and M45 starters.
B. Brush springs.
C. Push type gauge for 3M100 starter.

7. To check the field brush holder insulation on the M45G type, use a 110 volt supply. Connect the supply to the end bracket and a 15 watt test lamp to the holder. Repeat on the other holder. The lamp must not illuminate.
8. Check the spring insulation of the 3M100 type as follows. Connect the supply to the end bracket and the test lamp to the spring. Repeat on the other spring. The lamp must not illuminate.

NOTE: Make sure the brush wires do not contact the bracket during the test.




Figure H82
TESTING BRUSH HOLDER INSULATION
A. 110 volt AC supply.
B. 15 watt test lamp.
C. Earth brush.
D. Brush holder.

R78.118

Commutator

1. Clean the surface with a small amount of petrol on a cloth.
2. Use a fine glass paper to remove small amounts of damage.
3. If the damage can not be removed by glass paper, use a lathe. Run the lathe at a fast speed and take the smallest cut possible. Make sure the cutting tool is sharp.

DO NOT decrease the diameter of the M50 and M45 commutators to less than 38.1mm (1.50in).

DO NOT decrease the thickness of the segments on the 3M100 type commutator to less than 3.5mm (0.140in).

Use a fine glass paper to get a smooth finish after cutting.

DO NOT cut the insulation below the segments.




Figure H83
COMMUTATOR
A. Type used on M50 and M45 starters.

R78.119

Field Windings

1. Make an inspection of the inside of the yoke. Look for any indication of the armature making contact with the windings.
2. Look for burn marks on the insulation of the windings. This shows a high operating temperature. Look for cause before you install new windings.
3. Check the insulation on the M50 starter by connecting a 110 volt supply A to the field terminal D. Connect a 15 watt test lamp B to a clean connection on the yoke E. Make sure the brushes C do not contact the yoke during the test. The lamp must not illuminate.

On the M45G type starter connect the supply to the yoke and the lamp to each brush one at a time. Then connect the lamp to the field terminal. The lamp must not illuminate. Make sure the brush wires do not contact the yoke during the test.

On the 3M100 type starter the rivet which connects the windings to the yoke must be removed. Make sure the test is necessary before removing this rivet.

After the rivet has been removed, connect a test lamp to the end which has been disconnected. Connect the supply to a clean part of the yoke. The lamp must not illuminate.

4. To remove the field windings, first remove the rivet from the 3M100 type starter with a drill. Then remove the four screws which fasten the pole shoes to the yoke.
5. Clean the inside of the yoke and put the new windings in position. Install the screws but do not tighten.
6. Install the through bolt insulation pieces and tighten the screws to a torque of 41Nm (4kgm) (30lb ft).

NOTE: Put the insulation pieces at 180 degrees to each other and at 90 degrees to the field brushes.

7. Install a new rivet on the 3M100 type starter.




Figure H84
TESTING FIELD WINDING INSULATION
A. 110 volt AC supply.
B. 15 watt test lamp.
C. Field brushes.
D. Field terminal.
E. Yoke.




Figure H85
M45 STARTER
A. 15 watt test lamp.
B. 110 volt AC supply.
C. Field brush.
D. Yoke.
E. Field terminal.

Bearings: Bush Type

1. Measure the internal diameter of the bearings.
If more than the following, install new bearings.

M50 and M45	Commutator end	12.83mm (0.505in)
	Intermediate	28.63mm (1.127in)
	Drive end	17.14mm (0.675in)

3M100 Commutator end 11.2mm (0.441in)
type Drive end 12.1mm (0.476in)

NOTE: Put bushes in clean engine oil for 24 hours before installing.

2. Remove old bearings from the end brackets.
3. Use a mandrel which has a shoulder and which fits into the bearing with a small clearance. Install the new bearings.

Mandrel sizes for M50 and M45 starters are as follows:

Commutator end	12.71mm (0.5005in)
Intermediate	28.52mm (1.123in)
Drive end	17.03mm (0.6705in)

IMPORTANT: Do NOT put a reamer through the bushes after installing. This will decrease the lubrication quality of the bearing.




Figure H86
BEARING REPLACEMENT
A. Mandrel.
B. Bush.
C. End bracket.

R78,122

Armature

1. Look for movement of the segments. Movement here can be caused by an increase in operating speed, check clutch and brake assemblies.
2. Look for damage or movement of solder connections. If there is any indication of a high operating temperature, look for cause before you install a new armature.
3. Check for any indication of armature to field winding contact. If damage is found, check the tightness of the screws which fasten the pole shoes. Make an inspection of the bearings for wear.

Check the armature shaft for distortion. DO NOT try to correct any distortion of the shaft, install a new armature.

4. Connect a 110 volt supply and use a 15 watt test lamp to check the insulation as shown. Repeat the test on all segments of the commutator. If the lamp illuminates install a new armature. Make sure the circuit is not being completed through dirt.
5. Check the windings with 'growler' equipment according to manufacturers instructions.




Figure H87
TESTING ARMATURE INSULATION
A. 110 volt AC supply.
B. 15 watt test lamp.
C. Armature shaft.
D. Commutator segments.

R78123

Roller Clutch

1. Check that the clutch locks in one direction C only and turns freely in the opposite direction B.
 2. Make sure the assembly can move freely on the armature shaft.
 3. Install a new unit when a defect is found. The unit is sealed and cannot be repaired.
- IMPORTANT:** Do NOT wash the unit in cleaning fluid or apply any lubrication.
4. Apply the following greases to the splines of the unit.
Cold climates: Shell SB 2628
Hot climates: Shell Retinax A




Figure H88
ROLLER CLUTCH ASSEMBLY

- A. Rollers.
B. Free direction.
C. Locked direction.

R78.124

Plate Clutch

1. Hold the starter armature in a vice with soft jaw grips.
2. Put the plate clutch on to the armature shaft temporary.
3. Use a torque wrench to turn the pinion D counter-clockwise. The clutch will lose grip at 9–11kgm (66–80lbft) if set correctly.
4. To adjust the setting, disassemble the clutch and install or remove shims. These are between the backing ring and 1st outer plate F.





Figure H89
PLATE CLUTCH ASSEMBLY

- A. Clutch plate inner.
B. Driving sleeve.
C. Moving member.
D. Pinion.
E. Shims.
F. Outer clutch plate.
G. Backing ring.

R78.125

Inertia Drive

1. Check the pinion teeth for wear and damage. Check flywheel ring gear also when damage is found.
2. To remove the assembly from the shaft, hold the armature in a vice by the square end.
3. Remove the split pin and nut or circlip and collar from the end of the shaft.
4. Remove spring, pinion and sleeve assembly.
5. Wash all parts in paraffin.
6. Make sure the pinion moves easily on the sleeve and the sleeve moves easily on the shaft. DO NOT put any lubricant on the assembly.




R78126

Figure H90
INERTIA DRIVE ASSEMBLY

- | | |
|------------------------|----------------------|
| A. Anti Rattle spring. | E. Thrust collar. |
| B. Pinion. | F. Spring retainers. |
| C. Sleeve. | G. Buffer washer. |
| D. Drive spring. | |

Solenoid

1. Check the springs for damage and weakness. The internal spring can be checked by pulling on the inner plunger.
2. To replace the contacts separate the terminal assembly from the body. Use a hot soldering iron to disconnect the two solder connections. Hit the terminals on the bench to remove the solder.
3. Put the solenoid in a vice with the terminals up.
4. Apply heat with the soldering iron to the terminals while pulling on the cover until free.
5. When assembling the terminals make sure the connections are clean and dry. Make sure the temperature of connections is correct before applying the solder.
6. Install the two screws which fasten the terminal assembly to the body. Tighten the screws to a torque of 2.5Nm (0.25kgm) (2lbft).



R78127

Figure H91
SOLENOID MODEL 19S

- | |
|--------------------------|
| A. Coil connections. |
| B. Body. |
| C. Plunger spring. |
| D. Inner plunger spring. |
| E. Plunger. |
| F. Contact assembly. |
| G. Terminal assembly. |
| H. Main terminals. |

ASSEMBLY Figure H


1. Make sure all parts are clean and have been checked.
2. Put the shims and intermediate bracket N (M50 and M45) onto the armature.
3. Install drive end bracket H on to the armature shaft.
4. Install armature L complete with drive end bracket into the yoke P.
5. Put the commutator end bracket into position on the end of the shaft. Make sure the thrust washers and brake shoes are assembled correctly.
6. Install field brushes E into the holders and push the end bracket fully into position. Make sure brush wires are not between end bracket and yoke.
7. Install the two bolts F, which holds the complete assembly together, through the starter.

Tighten the bolts to a torque setting of:

$\frac{1}{4}$ in bolts 11Nm, 1kgm, 8lb ft.

$\frac{5}{16}$ in bolts 13Nm, 1.3kgm, 10lb ft.

8. Install a new retainer ring on the shaft end of the 3M100 type starter. Install end cap.
9. Use a dial gauge to check the amount of free movement at the end of the shaft. (M50 and M45 types.)
The amount must be from 0.13 to 0.51mm (0.005 to 0.020in). Adjust by adding or subtracting shims from between the intermediate bracket N and the armature.
10. When the movement is correct, remove the bolts F which fasten the assembly together. Remove the end bracket H.
11. Install the drive pinion assembly M on to the shaft.



12. Install the engagement fork and end bracket. Install the two fastening bolts. Install the pivot pin for the fork but do not lock it.
13. Adjust the drive pinion to bracket clearances as follows (M50 and M45 types).
 - (a) Connect a 6 volt battery to the starter. This will prevent damage to the solenoid during the adjustment.
 - (b) Measure the gap as shown in Figure H93, between the pinion and the end bracket.
 - (c) The gap must be set to the following dimensions.

Starter Type	Gap Setting
M45 roller clutch:	0.13–0.38mm (0.005–0.015in)
M45 plate clutch:	0.51–0.76mm (0.020–0.030in)
M50 roller clutch:	0.13–1.14mm (0.005–0.045in)
 - (d) Adjust by turning the pivot pin. The arrow on the pin must not be moved beyond the arrows on the bracket. Hold the pinion towards the armature, with a small amount of pressure, while adjusting.
 - (e) Tighten the locknut of the pivot pin when the clearance is correct. Apply paint or Loctite to the threads of the pin.
14. Install the solenoid to M50 and M45 starters.




Figure H93
PINION SETTING DISTANCE
A. Pivot pin.
B. Clearance.
C. 6 volt battery.

R78 129

BOSCH STARTER MOTOR

The Bosch starter motor has been installed on some tractors. All four cylinder engines can have a Bosch or a Lucas starter motor.

On 14 series tractors a 0.060in shim is installed between the starter flange and the engine.

IMPORTANT: DO NOT replace a Lucas starter with a Bosch starter on the 14 series tractor.

To install a Bosch starter to other models the terminal holes have to be increased to 10.3mm ($\frac{13}{32}$ in).

Contact any Bosch dealer for service information.

Repair information is included in Bosch publications:

VDT-WPE 510/2-6B
VDT-WPE 510/2B-AL




Figure H94
BOSCH STARTER CONNECTIONS
A. Battery cable.
B. Brown wire.
C. Solenoid.
D. Starter motor.

R 78.130

WIPER MOTOR

HOW IT WORKS

Two permanent magnets A are used for the field supply of the motor. The armature B receives a supply of current from the battery when the operator closes the wiper switch. This actuates the motor.

The armature shaft has a worm-gear C on the commutator end. This is engaged with a gear-wheel D in the gearbox of the motor. The gear-wheel is connected to a cable-rack E by a connecting rod F. The cable rack is free to move inside a tube G which is fastened at each end. The other end of the cable rack is engaged with a gear-wheel and spindle assembly H. The wiper arm and blade are fastened to the spindle.

When the armature turns, it turns the gear wheel. The connecting rod moves the cable rack backwards and forwards through the tube. The movement of the cable rack causes the gear wheel and spindle assembly to make a part turn one way then the other. This moves the arm and blade across the windscreen.


Limit Switch

This is installed in the terminal assembly J of some wiper motors to provide a parking facility.

It permits the current to continue to the motor after the wiper switch has been put to 'OFF'. When the wiper arm reaches one side of the windscreen the limit switch stops the motor.

The switch is actuated by a cam on the gear-wheel pushing against the plunger of the switch. The plunger opens a set of contacts which interrupts the circuit and stops the motor.

Figure H95
THE WIPER MOTOR ASSEMBLY
A. Magnets.
B. Armature.
C. Worm gear.
D. Gear wheel.
E. Cable rack.
F. Connecting rod.
G. Cable tube.
H. Drive spindle.
J. Terminal assembly.



FAULT FINDING

TEST 1: Slow Operating Speed

1. Make sure the windscreen is wet enough.
2. Check that the arm can move away from the windscreen.
3. Check that the correct arm tension spring is installed.
4. If these checks are correct, disconnect the cable-rack from the motor.
5. Remove the arm and blade assembly from the wheel-box spindle.
6. Push the cable-rack completely into the tube.
7. Connect a spring-balance A to the end of the cable-rack B.
8. Pull the cable-rack out of the tube with the spring-balance. The maximum force needed must not be more than 27N (6lbf).
9. If the force needed is more than this amount, check the tube and cable-rack for damage. If any damage is found, install new parts.
10. If the cable-rack and tube are in good condition: Disconnect the rack from the wheel-box and check the spindle for seizure.
11. When all mechanical parts are checked and found acceptable, check the motor. Connect an ammeter in series with the motor to check the current it is using. Compare this with the amount shown in the DATA SECTION.

Remove the cover from the gearbox and check the gearwheel revolutions against time.

12. Compare the speed of the gearwheel with that shown in the DATA SECTION.

TEST 2: Wiper will not operate

1. Check the circuit fuse, if a failure is found, look for possible cause before installing new fuse.
2. Check other circuits which use the same fuse.
3. Make sure all connections are clean and tight, especially ground connection.
4. Use a voltmeter or test lamp to check for a connection between the supply and ground as follows: Connect the test equipment from a supply to the positive terminal of the wiper motor.

If the lamp illuminates or the voltmeter shows a reading, the supply wire is making a connection to ground.





Figure H96
CHECKING CABLE-RACK
A. Spring-balance.
B. Cable rack.



CHECKING CURRENT USED
A. Wiper motor.
B. Ammeter.
C. Wiper switch.

R 78 132

R 78.133

5. To check the supply, disconnect the harness plug from the motor.
 6. Put the wiper switch to the 'on' position.
 7. Check for a supply voltage between terminals 1 and 5 of the harness plug.
 8. If there is no indication of voltage, disconnect the equipment from terminal 1 and connect it to ground.
- If the test equipment now shows a voltage there is a failure in the ground wire.
9. Check for supply voltage at both terminals of the wiper switch. If there is supply in and not out, with switch 'on', install a new switch. If there is no supply check for broken, dirty or loose connections.
 10. If the supply voltage is coming out of the switch but not reaching the motor check wire. Install a new wire if necessary.

TEST 3: Arm not parking.

This facility is only installed on some motors. Check if yours is of this type.

1. Put wiper switch to 'OFF' position.
2. Disconnect the harness plug from the motor.
3. Use a voltmeter or test lamp to check the voltage between terminals 1 and 4 of the plug. This voltage must be the same as the supply voltage.
4. Check connection at the supply if no voltage is shown.
5. Now connect the test equipment between terminals 1 and 5 of the plug. Connect a jumper wire between 2 and 4 as shown.

The test lamp will illuminate or the voltmeter will show the supply voltage if limit switch has a failure.

NOTE: To test internal parts of the motor, see REPAIR SECTION.




Figure H98
CHECKING THE SUPPLY CIRCUIT

R 78.134




Figure H99
CHECKING SUPPLY TO TERMINAL 4

R 78.135




Figure H100
CHECKING LIMIT SWITCH

R 78.136

A. Wiper motor.
B. Voltmeter.
C. Wiper switch.

MAINTENANCE AND REPAIR

TYPE: Lucas 14W single speed, self parking on De-Luxe cab.

MAINTENANCE

1. Check the tightness of the bolts which fasten the motor to the cab.
2. Make sure the wire connections are clean and tight, especially the ground wire.
3. Check the condition of the blade at regular intervals.

DISASSEMBLY

1. Remove the arm and blade K.
2. Disconnect the terminal assembly J.
3. Remove the bolts which fasten the wiper motor to the cab.
4. Remove the gearbox cover screws.
5. Remove the circlip which fastens the connecting rod to the crank pin.
6. Remove the connecting rod F from the gear-wheel D and cable-rack E.
7. Remove the flat washer from the crankpin.
8. Disconnect the cable-rack from the gearbox and remove the motor from the tractor.
9. Remove the circlip from the end of the gear-wheel shaft. Make sure the shaft has no sharp edges before pulling it through the bearing.
10. Remove the dished washer under the gear-wheel.
11. Remove the two bolts which fasten the yoke to the gearbox.
12. Remove the yoke and armature B from the gearbox.
13. Put the yoke away from metal particles which can be pulled on to the pole magnets.
14. Remove the brush and terminal assemblies from the gearbox.




Figure H101
WIPER MOTOR

- A. Magnets.
- B. Armature.
- C. Worm gear.
- D. Gearwheel.
- E. Cable-rack.
- F. Connecting rod.
- G. Cable tube.
- H. Drive spindle.
- J. Terminal assembly.
- K. Arm and blade.

TEST AND REPAIR

Armature

1. Check the armature insulation as follows:
Connect a 110 volt supply to the armature shaft. Connect a 15 watt test lamp to a segment of the commutator. Repeat test on all segments. Install a new armature if the lamp illuminates.
2. Check the commutator for damage and wear. Remove small amounts of damage with fine glass paper. Deep damage can be removed with a lathe but the smallest possible cut must be taken. Remove particles of copper from between the segments after cutting.
3. Check for damage to windings, solder connections and worm gear. Install a new armature if any damage is found.





Figure H102
ARMATURE INSULATION TEST
A. 110 volt AC supply.
B. 15 watt test lamp.
C. Armature.


R78 138

Brushes

1. Check brushes for damage.
2. Measure the length of the brushes. If 5mm ($\frac{3}{16}$ in) or less install new brushes.
3. Make sure the brushes move easily in the holders.
4. Check brush spring pressure with a push type gauge as shown or a dial gauge.
Push brush to broken line and check the reading. The pressure must be 1.7Nm (170g f) (6oz f).



R78 139/1




R77 139/2

Figure H103
CHECKING BRUSH SPRING PRESSURE
A. Early type.
B. Later type.

Gearwheel Assembly

1. Check the teeth for wear and damage.
2. Check the shaft for distortion, wear and damage.
3. Make sure the crankpin is installed in the correct position if the wheel and shaft have been separated. See Figure H104.

NOTE: The gearwheel and shaft are supplied as an assembly if it is necessary to install a new item.




R78140

Figure H104
ALTERNATIVE POSITIONS OF CRANKPIN
A. Parking with cable rack retracted.
B. Parking with cable rack extended.
C. Crankpin positions.

Limit Switch

1. Remove switch from motor by lifting retaining post end of switch and moving it in direction of arrow.
2. Push the plunger of the switch fully in. Let it return to the original position. Measure the plunger. The plunger must be 7mm ($\frac{9}{32}$ in) out of the switch.
3. See FAULT FINDING for electrical checks.



R78141

Figure H105
LATER DESIGN LIMIT SWITCH
A. Negative (–) terminal.
B. Positive (+) terminal.
C. Plunger.
D. Retainer clip.
E. Terminal connector.
F. Retainer post.

ASSEMBLY

1. Fasten the brush and terminal assemblies to the gearbox.
2. Apply Shell Turbo 41 oil to the bearings and armature shaft bearing surfaces.
3. Apply Ragosine Listate grease to the worm-gear on the armature.
4. Install the armature into the gearbox.
5. Make sure the inside of the yoke is clean. Make sure the thrust disc and oil pad are in position inside the yoke bearing. The disc goes in first with the felt oil pad on top.
6. Install the yoke on to the armature and gearbox.

IMPORTANT: Align the mark on the yoke with the arrow on the gearbox to make sure of correct rotation.

7. Install and tighten the two bolts which holds the assembly together. Tighten to a torque of 1.35–1.80Nm (0.138–0.184kgm) (12–16 lb in).
8. Adjust the armature end movement if an adjustment screw is installed.

Turn the adjustment screw clockwise until it contacts the end of the armature.

Then turn the screw counterclockwise $\frac{1}{4}$ of a turn. Tighten the locknut of the adjustment screw.




Figure H106
WIPER MOTOR ASSEMBLY
A. Terminal assembly.
B. Brush plate.
C. Armature.
D. Gearbox.

R78.142

GAUGES

HOW THEY WORK THE FUEL GAUGE

The fuel gauge circuit is energised when the starter key A is turned to the 'ACC' position.

The gauge circuit has two coils. One pulls the needle towards the full mark. The other pulls the needle towards the empty mark. The needle moves towards the coil with the most current going through it.

The fuel tank unit has a rheostat B activated by the movement of the float. When the tank is empty the resistance of the rheostat is at a minimum.

This puts a low resistance across the full coil. This reduces the current through the full coil C. The empty coil D then pulls the needle to the empty mark. When fuel is added to the tank the float moves up with the fuel. It increases the rheostat resistance across the full coil. Current starts to move through the full coil and the needle moves towards FULL (F). All positions in between FULL and EMPTY are shown by a balance between the currents in the two coils.




Figure H107
FUEL GAUGE CIRCUIT

- | | |
|-----------------|-----------------------|
| A. Starter key. | D. Empty coil. |
| B. Rheostat. | E. Voltage stabiliser |
| C. Full coil. | 885 model only. |

R 78.143

THE TEMPERATURE GAUGE

The sender unit A installed in the engine coolant system has a resistor inside. The resistor reacts to temperature decreasing resistance when the coolant temperature increases.

The resistance of the sender is between the hot coil and ground. As the temperature increases, the current through the cold coil increases. This lets the hot coil pull the needle towards the hot mark. When the temperature of the coolant decreases, more current flows through the cold coil. This pulls the needle more strongly towards the cold mark. The pull of the cold coil being stronger than the pull of the hot coil.




Figure H108
TEMPERATURE GAUGE CIRCUIT

- A. Sender unit.

R 78.144

FAULT FINDING

FUEL GAUGE

TEST 1: Tank Full

1. Turn the starter key to the 'ACC' position.
2. If the needle does not move check for broken or disconnected wire between switch and gauge.
3. If the needle moves to EMPTY check the wire from the gauge to the tank unit for a connection to ground.
4. If the gauge to tank unit wire is good make sure the gauge has a good connection to ground through the instrument panel.

IMPORTANT: Do not connect the two wires on the gauge together, this will cause damage to the tank unit.

TEST 2: Tank Not Full

1. If the needle moves to FULL when the starter switch is turned to the 'ACC' position. Make sure the tank unit has a good connection to ground.
2. Check the wire between the gauge and the tank unit for dirty or loose connections. Check for a break in the wire.
3. If the gauge does not show a reading, remove tank unit from tank. Keep the wire to the gauge connected.
4. Make a good connection to ground from the unit. Move the float up and down by hand and look at the gauge. This will show if the gauge is working correctly.

TEST 3: 885 Tractors only

On the 885 tractor a voltage stabiliser A is included in the circuit. The stabiliser has two connections; 'B' from the battery, 'I' to the gauge. The unit is connected to ground through the bracket.

1. Check the voltage at 'B' with a voltmeter. This must be battery voltage.

NOTE: This does not include the 885Q and 885N models, which have different gauges.

2. Check the voltage at 'I'; if zero voltage is shown the unit must be replaced with a new unit.

IMPORTANT: Do not connect gauge wires together; this will cause damage to the tank unit.

Gauges, tank units and stabilisers are not adjustable. Do not try to disassemble.




Figure H109
FUEL GAUGE CIRCUIT
A. Voltage stabiliser.

TEMPERATURE GAUGE

TEST 1: Engine Hot

If the needle does not move towards HOT when the engine temperature increases:

1. Disconnect the wire A from the sender unit and connect the wire to ground.
2. If the needle then moves to HOT the sender unit must be replaced with a new unit.
3. If the needle does not move, check the wiring for breaks or bad connections.

TEST 2: Engine Cold

If the needle moves to HOT when the starter key is turned to the 'ACC' position:

1. Check the wire from the gauge to the sender unit for a connection to ground.
2. Check that the gauge is making a good connection to ground through the instrument panel.
3. Install a new gauge to compare results with the old gauge and to check other parts.




Figure H110
TEMPERATURE GAUGE CIRCUIT
A. Wire to sender unit.

WARNING LAMPS

HOW THEY WORK

ENGINE OIL PRESSURE

Battery current illuminates the lamp A when the starter key is turned to the ACC position. The circuit is connected to earth through the pressure switch B contacts. When the engine is started the oil pressure opens the contacts. This interrupts the circuit and the lamp stops illuminating. If the oil pressure decreases below the setting of the pressure switch the contacts close and the lamp illuminates.

HYDRAULIC OIL FILTER

Battery current illuminates the lamp C when the starter key is turned to the ACC position. The circuit is connected to ground through the dynamo or alternator. When the engine is started the dynamo or alternator output causes the lamp to stop illuminating.

The output current is prevented from going through the warning lamp by a diode D included in the circuit.

If the hydraulic filter becomes restricted the contacts of the vacuum switch E close. This re-connects the circuit to ground illuminating the warning lamp again.

The vacuum switch is installed in the oil pump suction pipe.

NOTE: This is not installed on later tractors with external hydraulic filter.

NO CHARGE

Battery current illuminates lamp F when the starter key is turned to ACC. The circuit is completed to ground through the dynamo or alternator. When these start to charge the voltage difference at the warning lamp terminals decreases. This causes the lamp to stop illuminating.




Figure H111
CIRCUIT WITH DYNAMO




Figure H112
CIRCUIT WITH ALTERNATOR

- | | |
|--------------------------|-----------------------|
| A. Oil pressure warning. | D. Diode. |
| E. Oil pressure switch. | E. Vacuum switch. |
| C. Hydraulic warning. | F. No charge warning. |

THERMOSTART

HOW IT WORKS

When the starter key A is turned to the HEAT position current energises the unit B in the inlet manifold.

Current heats a coil C which opens the fuel valve D and then changes the fuel into vapour. Another coil E causes the vapour to burn which warms the air going into the cylinders. This makes the engine easier to start in very cold weather.

The unit is still energised when the starter is being operated.

IMPORTANT: Always disconnect the thermostart wire if ether or similar fluid is used for starting.



WARNING — Ether or similar starting fluid must not be used without first following the procedure below. The Thermostart heater is energised when the starter is operated. Ether or starting fluid can cause an explosion or fire if it comes into contact with the Thermostart coil. This can cause injury.




Figure H113
THE THERMOSTART CIRCUIT

- A. Starter key.
- B. Thermostart unit.
- C. Valve coil.
- D. Fuel valve.
- E. Burner coil.
- F. Starter safety switch.
- G. Starter solenoid.

PROCEDURE, ETHER

If ether starting fluid has to be used in an emergency, the following procedure and sequence **must** be followed.

1. Disconnect the electrical supply wire from the Thermostart heater.
2. Operate the starter motor for 10 seconds, **with the stop control in the stop position**, to remove any fuel before using ether.
3. Put a small amount of ether in the air cleaner inlet while the starter is being operated.

Do not put ether in the intake unless the starter motor is rotating the engine.

Do not use ether with the Thermostart connected.

Do not use ether if the battery is discharged.

Damage will occur if ether is used carelessly.

FAULT FINDING

TEST 1

1. Remove the pipe between the air cleaner and the inlet manifold.
2. Turn the starter key to 'HEAT' and hold this position for 10 to 25 seconds.
3. Make sure the gear levers are in the neutral position, then operate the starter.
4. Get assistance to look into the manifold to see if the thermostart is working. This will be shown by light from the burning fuel.
5. If the unit is not working return the key to 'OFF' and do test 2.

TEST 2

1. Connect a voltmeter between the terminal on the thermostart and ground.
2. Turn the starter key to 'HEAT' and check the voltmeter.
If the voltmeter does not show a voltage check the wire and connections to the starter switch.
3. If current is reaching the thermostart disconnect the fuel pipe A and check for a restriction of the fuel flow.




Figure H114
CHECKING CURRENT SUPPLY

A. Fuel pipe connection.
B. Voltmeter.

WIRING

GENERAL DESCRIPTION

The tractor wiring is divided into three main harnesses. These are: Engine harness; Instrument panel harness; Rear harness. A fourth harness is added when a cab is added to a tractor. When a repair has to be made to the wiring it can be easier to replace one or two wires. If the defect includes more than one or two wires it is best to install a harness.

To make vehicle wiring flexible it is made with a number of single thin wires of the same thickness. The amount of single wires and the thickness of each is shown by the wire size number. Example: 44/012 is an indication that the wire has 44 single wires and each single wire has a thickness of 0.012in. This is the same as 44/030, 44 single wires of 0.30mm thickness.

The wire sizes shown in the chart will normally be those used on a tractor. This does not include the starter cables and H.T. ignition cables on gasoline engines.

The diameter of a wire used is controlled by the amount of current flowing in the circuit. Also the voltage being used must not decrease by more than 10% after going through a wire. For a 12 volt system for example, the voltage must not decrease by more than 1.2 volts.

Never replace the original wire of a circuit with a wire of a smaller diameter. Use a micrometer to measure the single wires and make a count of the amount. Use the next largest size if the correct size is not available.

A large decrease in voltage will cause a decrease in the performance of the electrical unit.



CAUTION Always use the correct size wire for the job. A smaller wire will cause resistance to current. This will increase the temperature of the wire and cause the wire to burn and start a fire.

WIRE DETAILS

Number and diameter of wires		Cross-section area of conductor		Resistance per metre at 20° Celcius	Approximate current rating	Nearest American gauge size
mm.	inches	sq. mm.	sq. inches	ohms	amperes	
14/0.25	14/010	0.69	0.0011	0.0271	6.00	19
14/0.30	14/012	0.99	0.0015	0.0188	8.75	17
28/0.30	28/012	1.98	0.0031	0.0094	17.50	14
44/0.30	44/012	3.11	0.0048	0.0060	27.50	12
65/0.30	65/012	4.59	0.0071	0.0041	35.00	10
84/0.30	84/012	5.94	0.0092	0.0031	45.00	9
97/0.30	97/012	6.86	0.0106	0.0027	50.00	8
120/0.30	120/012	8.48	0.0131	0.0022	60.00	8

When installing wiring make a note of the following details.

- (a) Make sure all wiring is clear of any part of the tractor which gets hot.
- (b) Keep the wiring away from sharp edges.
- (c) Make sure the wiring is clear when assembling and installing parts of the tractor.
- (d) Fasten the wiring correctly and make sure the wires are not putting tension on the connections.
- (e) Always use the correct type of connectors for the job. Make sure the crimp type connector is the correct size before you fit it. Make sure connections made with solder are clean, dry and the correct amount of heat is applied.
- (f) All wires have a colour code for easy identification. Letters or words can be used on wiring diagrams.
- (g) The first letter or word is the main colour and the second is the line. Example: G/B = Green/Black. This is a green wire with a black line.

WIRING COLOUR CODE

B = Black
G = Green
K = Pink
N = Brown
P = Purple
R = Red
S = Slate (Grey)
U = Blue
W = White
Y = Yellow
LG = Light Green

CIRCUIT COLOUR CODE

The wiring is divided into a number of circuits and each circuit uses a colour for identification.

Examples:

Brown is used for the main supply. Current flows at all times in this circuit.

Brown/Yellow is used for the alternator circuit.

Green is used for the engine auxiliaries. This circuit only has current flowing when the starter key is in the 'ACC' position.

Green/Blue is used for the temperature gauge circuit.

Red is used for the side and rear lamp circuits.

Blue is used for the headlamp circuit.

White is used for the warning lamp circuit.

Black is used for all ground connections.

NOTE: The colour of a wire does not give any indication of the capacity of the wire. Do not confuse with wiring colour code.

WIRE SIZE	COLOURS		APPLICATION
	Main	— Line	
14/0.25mm (14/0.010in)	Green	— White	Flasher switch to 7-way connector Right-hand flasher light and 7-point socket
	Green	— Red	Flasher switch to 7-way connector Left-hand flasher light and 7-point socket
	Black	— Lt. Green	Hydraulic filter switch light to 7-way connector
	Green	— Blue	Temperature gauge to 10-way connector 10-way connector to temperature sender
	Green	— Black	Fuel gauge to 10-way connector 7-way connector to vacuum switch 10-way connector to tank gauge unit
	White	— Brown	Oil warning light to 10-way connector 10-way connector to oil warning switch
	Purple	— Black	Horn push to 10-way connector 10-way connector to horn
	Brown	— Yellow	Hydraulic filter and charge lamps to 10-way connector 10-way connector to alternator
	White		Starter switch to charge and oil warning lamps
	Green		To hydraulic filter warning light To temperature gauge, to fuel gauge, to horn, to flasher unit or hazard warning switch, flasher unit to trailer indicator light, flasher unit to flasher switch
	Black		All ground (chassis) connections
	Red		To tail lights, 7-point socket and rear number plate light
28/0.30mm (28/0.012in)	White	— Red	10-way connector to starter solenoid Starter switch to 7-way connector 7-way connector starter safety switch 7-way to 10-way, 10-way connector to starter safety switch
	Brown	— Red	Starter switch to 10-way connector 10-way connector to Thermostart
	Green	— Brown	Flasher unit to flasher switch
32/0.20mm (32/0.008 in)	Red		Lighting switch to 7-way connector
	Green		7-way connector to harness
	Blue	— White	Lighting switch to 10-way connector 10-way connector to headlamps (main beam)
	Blue	— Red	10-way connector to headlamps (dip) Lighting switch to 10-way connector
	Green		7-way connector to main harness to stop lamp switch
	Green	— Purple	Stop lamp switch to main harness to stop light connectors to 7-point socket
44/0.30mm (44/0.012in)	Brown		Starter to main harness Harness to alternator and 10-way connector Harness to starter switch and fuse Fuse to lighting switch
	Green		Starter switch to fuse

ELECTRICAL EQUIPMENT

There are differences between wiring of each tractor according to the specifications. Changes occur with the type of fender used. Changes also occur where the hazard warning

system is installed. Tractors with cabs have several items of extra electrical equipment.




Figure H115
TYPES OF FENDER USED

1. Full fender, reinforced.
2. Full fender, light duty.
3. Shell or fan fender.

CRIMP CONNECTIONS

1. Use the stripper part of the tool A to remove 1cm of the insulation from the end of the wire.
2. Push the wire into the snap-in connector as far as it can go.
3. Use the crimping part of the tool B to make two crimps. One on the wire and one to grip the insulation.

Make sure the jaws of the tool close completely at C.

The tool can be used for the following sizes:


14/0.25mm (14/0.010in):

14/0.30mm (14/0.012in):

28/0.30mm (28/0.012in):

35/0.30mm (35/0.012in).

NOTE: A kit complete with pliers is available from your David Brown dealer, part number K.964626.




R78151

Figure H116
MAKING A CONNECTION USING A CRIMPING TOOL

A. Stripper jaws. C. Jaw stop.
B. Crimping jaws.

SOLDER CONNECTIONS





1. Put the insulation cover A over the wire as shown.
2. Remove about 1cm of insulation from the end of the wire B.
3. Push the end of the wire through the slot in the Lucar connector C. Bend the end of the wire D backwards and flat on to the connector.
4. Bend the lugs E at the rear of the connector around the insulation of the wire.
5. Use solder to connect the wire to the connector.
6. Let the connector cool, then push the insulation cover F over the connector.








R78152

Figure H117
MAKING A CONNECTION USING SOLDER

LUCAR CONNECTORS

3/16" (.187") LUCAR MATERIAL: BRASS. FOR CRIMPING OR SOLDERING			
Connector Lucas Part No.	Approximate Rating	Application (Cable Size)	Insulating Cover P.V.C. Lucas Part No.
 54190972	6 amps	1-14/0.25mm (14/.010")	 54190680
 54954279		1-28/0.30mm (28/.012") 2-14/0.25mm (14/.010")	 54190953

1/4" (.250") LUCAR MATERIAL: BRASS. FOR CRIMPING OR SOLDERING			
Connector Lucas Part No.	Approximate Rating	Application (Cable Size)	Insulating Cover P.V.C. Lucas Part No.
 54960660	17½ amps	1-14/0.25mm (14/.010")	 54959401 For details see below
 54960661		1-28/0.30mm (28/.012") 2-14/0.25mm (14/.010")	

3/8" (.375") LUCAR MATERIAL: PHOSPHOR BRONZE. FOR SOLDERING			
Connector Lucas Part No.	Approximate Rating	Application (Cable Size)	Insulating Cover P.V.C. Lucas Part No.
 549420779	35 amps	1-28/0.30mm (28/.012") 1-44/0.30mm (44/.012") 1-65/0.30mm (65/.012")	 54190043

R78 154

INSULATION COVER

Lucas Part Number 54959401.

This cover can be used on the complete range of ¼in straight Lucar connectors.

It can be used for wire sizes from 14/.025mm (14/.010in) to 44/0.30mm (44/.012in).

To install the cover, push it over the terminal until the locking lug goes into the location.





Figure H118
LUCAR CONNECTORS
A. Connector.
B. Cover.

R78 155





BLADE TERMINALS AND INSULATORS



R78156

Figure H119
BLADE TERMINALS - BS SIZES

SNAP-IN CONNECTORS AND TERMINALS

	Description	Packets of	Lucas Part No.
	2-way snap-in (may be used with 9/32" single cable clip)	10	900288
	4-way. (Double)	1	850641
	6-way. (Three 2-way)	1	850344
	10-way. (Five 2-way)	1	850832

SNAP-IN (BULLET) TERMINAL ENDS
 (For use with the above connectors)












	Description	Packets of	Lucas Part No.
 	Solder type. For cable size 28/0-30mm (28/-012") P.T. and S.P.T.	10	900269
 	Hexagonal crimp type. For cable size 14/0-25mm (14/-010") P.T. and S.P.T.	10	54941384
 	Hexagonal crimp type. For cable size 14/0-30mm (14/-012") P.T.	10	54944088
 	Hexagonal crimp type. For cable size 28/0-30mm (28/-012") P.T.	10	54944095
 	Hexagonal crimp type. For cable sizes 44/0-30mm (44/-012") or 65/0-30mm (65/-012") P.T.	10	54946098
	3/16" (0-188") diameter ferrule	10	188818

 Figure H120
 SNAP-IN CONNECTORS

9-37222

H82

HAZARD WARNING SWITCHES

Two different types of hazard warning switches were installed up to the following serial numbers.

885/633680

996/985304

990/862037

1210/727072

395/930639

1212/1003291




Figure H121
EARLY TYPE
Part Number K9446644

1. Hazard flasher unit.
2. Connections to L and R terminals of the direction indicator switch.
3. Connection to 49 + terminal of the direction flasher unit.
4. To green wire in the harness next to flasher unit.
5. Connection to terminal 1 of the starter switch.

R78159





Figure H122
LATER TYPE
Part Number K950431

1. Connections to L and R terminals of the flasher unit.
2. Connection to ground.
3. Connection to 49 + terminal of direction
4. To green wire in the harness next to flasher unit.
5. To number 1 terminal of the starter switch.

R78160




R78161

Figure H123
ARRANGEMENT OF WIRING
Tractors with full fenders, dynamo and early type wiring harness.

- | | |
|------------------------------|---------------------------------|
| 1. Battery. | 17. Front direction indicators. |
| 2. Starter Solenoid. | 18. Rear direction indicators. |
| 3. Temperature sender unit. | 19. Rear lamps. |
| 4. Dynamo. | 20. Stop lamps. |
| 5. Horn. | 21. Flood lamp. |
| 6. Thermostart. | 22. Number plate lamp. |
| 7. Fuel tank unit. | 23. Trailer socket. |
| 8. 10-way connector. | |
| 9. Oil pressure switch. | |
| 10. To headlamps. | |
| 11. Regulator. | |
| 12. Instrument panel. | |
| 13. Starter safety switch. | |
| 14. Stop lamp switch. | |
| 15. Hydraulic filter switch. | |
| 16. Side lamps. | |

TRAILER SOCKET


- 54G. Extra position.
58L Left-hand, side and rear lamps.
58R. Right-hand, side and rear lamps.
54. Stop lamps.
31. Ground
R. Right hand indicators.
L. Left hand indicators.



R 78-162

Figure H124
 ARRANGEMENT OF WIRING
 Tractors with full fenders, alternator and early type of wiring harness.


- | | |
|---------------------------------|--------------------------------|
| 1. Battery. | 17. Rear direction indicators. |
| 2. Starter solenoid. | 18. Rear lamps. |
| 3. Temperature sender unit. | 19. Stop lamps. |
| 4. Alternator socket. | 20. Number plate lamp. |
| 5. Horn. | 21. Trailer socket. |
| 6. Thermostart. | 22. Flood lamp. |
| 7. Fuel tank unit. | TRAILER SOCKET |
| 8. 10-way connector. | 54g. Extra position. |
| 9. Oil pressure switch. | 58L. Left-hand, side and rear |
| 10. To headlamps. | lamps. |
| 11. Instrument panel. | 58R. Right-hand, side and |
| 12. Starter safety switch. | rear lamps. |
| 13. Hydraulic filter switch. | 54. Stop lamps. |
| 14. Stop lamp switch. | 31. Ground. |
| 15. Side lamps. | R. Right hand indicators. |
| 16. Front direction indicators. | L. Left hand indicators. |



R78-163

Figure H125
ARRANGEMENT OF WIRING
Tractors with full fenders, alternator and later type wiring harness.


- | | |
|---------------------------------|---------------------------------------|
| 1. Battery. | 18. Rear direction indicators. |
| 2. Starter solenoid. | 19. Rear lamps. |
| 3. Temperature sender unit. | 20. Stop lamps. |
| 4. Alternator socket. | 21. Flood lamp. |
| 5. Horn. | 22. Number plate lamp. |
| 6. Thermostart. | 23. Trailer socket. |
| 7. Fuel tank unit. | TRAILER SOCKET |
| 8. 10-way connector. | 54g. Extra position. |
| 9. Oil pressure switch. | 58L. Left-hand, side and rear lamps. |
| 10. To headlamps. | 58R. Right-hand, side and rear lamps. |
| 11. 7-way socket. | 54. Stop lights. |
| 12. Instrument panel. | 31. Ground. |
| 13. Hydraulic filter switch. | R. Right hand indicators. |
| 14. Starter safety switch. | L. Left hand indicators. |
| 15. Stop lamp switch. | |
| 16. Side lamps. | |
| 17. Front direction indicators. | |



R78 164

Figure H126
ARRANGEMENT OF WIRING
For tractors with Q-Cab.


- | | |
|------------------------------|---------------------------------------|
| 1. Battery. | 20. Number plate lamp. |
| 2. Starter solenoid. | 21. Trailer socket. |
| 3. To headlamps. | 22. Flood lamp. |
| 4. Temperature sender unit. | 23. Oil pressure switch. |
| 5. Alternator socket. | 24. Wiper motor. |
| 6. Horn. | 25. Interior lamp. |
| 7. Thermostart. | 26. Fan switch. |
| 8. Fuel tank unit. | 27. Heater unit. |
| 9. 11-way connector. | TRAILER SOCKET |
| 10. 2-way connector. | 54g. Extra position. |
| 11. 7-way connector. | 58L. Left-hand, side and rear lamps. |
| 12. Instrument panel. | 58R. Right-hand, side and rear lamps. |
| 13. Hydraulic filter switch. | 54. Stop lamps. |
| 14. Starter safety switch. | 31. Ground. |
| 15. Stop lamp switch. | R. Right hand indicators. |
| 16. Side lamps. | L. Left hand indicators. |
| 17. Direction indicators. | |
| 18. Rear lamps. | |
| 19. Stop lamps. | |



R78-165

Figure H127
ARRANGEMENT OF WIRING
Tractors with de-luxe cab and Sekura cab.

- | | |
|-------------------------------|---|
| 1. Battery. | 18. Number plate lamp. |
| 2. Starter solenoid. | 19. 7-point trailer socket. |
| 3. Temperature sender. | 20. Rear flood lamp. |
| 4. Alternator socket. | 21. Dip beam. |
| 5. Horn. | 22. Main beam. |
| 6. Thermostart. | 23. Oil pressure switch. |
| 7. Fuel tank unit. | 24. Windshield wiper motor. |
| 8. 11-way connector. | 25. Cab interior lamp. |
| 9. 2-way connector. | 26. Fan unit. |
| 10. 7-way connector. | 27. Washer motor. |
| 11. Instrument panel. | 28. Fan switch. |
| 12. Starter safety switch. | 29. Wiper switch. |
| 13. Stop lamp switch. | 30. Washer switch. |
| 14. Side lamp. | 31. Floodlamp switch. |
| 15. Direction indicator lamp. | 32. Hydraulic filter switch, installed on 8, 9 and 12 |
| 16. Rear lamp. | series tractors only. |
| 17. Stop lamp. | |



R78-166

Figure H128
ENGINE HARNESS


For tractors with a dynamo, up to the following serial numbers:

885: 633680
990: 862037
995: 930639

996: 985304
1210: 727072
1212: 1003291

1. Battery.
2. Starter.
3. Dynamo.
4. Headlamp, main.
5. Headlamp, dip.

6. Temperature sender unit.
7. Oil pressure switch.
8. Headlamp connector, 4-way.
9. 8-way connector to instrument panel.



R 78.167

Figure H129
ENGINE HARNESS

For tractors with an alternator, from the following serial numbers:

885:629959	996:983735
885Q:11000001	996Q:11070001
990:558824	1210Q } 11150001
990Q:11070001	1212Q }
995:927997	1410Q } 11200001
995Q:11070001	1412Q }

- | | |
|--------------------|--|
| 1. Battery. | 7. Temperature sender unit. |
| 2. Starter. | 8. Oil pressure switch. |
| 3. Alternator. | 9. Thermostat. |
| 4. Headlamp. main. | 10. Headlamp connector, 2-way. |
| 5. Headlamp. dip. | 11. 9-way connector to instrument panel. |
| 6. Horn. | |




Figure H130
ENGINE HARNESS

For 12 and 14 series tractors without cab only, from the following serial numbers:

1210:727072
1212:1003291

1410 1050001
1412

1. Battery.
2. Starter.
3. Alternator.
4. Headlamp, main.
5. Headlamp, dip.
6. Horn.

7. Temperature sender unit.
8. Oil pressure switch.
9. Thermostart.
10. Headlamp connector, 2-way.
11. Fuel tank unit.
12. 10-way connector to instrument panel.

R 78.168




Figure H131
ENGINE HARNESS
For tractors with Q-cab, de-luxe cab, and Sekura cab, from the following serial numbers:

885:1100001
990 } 1107001
995 }
996 }

1210 } 11150001
1212 }
1410 } 11200001
1412 }

- | | |
|-----------------------------|--|
| 1. Battery. | 7. Oil pressure switch. |
| 2. Starter. | 8. Thermostart. |
| 3. Alternator. | 9. Console harness. |
| 4. Headlamp. | 10. Stop lamp switch. |
| 5. Horn. | 11. 9-way connector, to console harness. |
| 6. Temperature sender unit. | 12. 11-way connector, to instrument panel. |

R 78.169




Figure H132

INSTRUMENT PANEL HARNESS


For tractors with shell fenders, up to the following serial numbers:

- | | |
|--------------------------------------|--------------------------------------|
| 885:633680 | 996:985304 |
| 990:860237 | 1210:727072 |
| 995:930639 | 1212:1003291 |
| 1. Lighting switch. | 11. Double connector. |
| 2. Regulator. | 12. Connector 3-way. |
| 3. Starter safety switch. | 13. Temperature gauge. |
| 4. Diode. | 14. Fuel gauge. |
| 5. Double connector. | 15. Voltage stabiliser, 885 only. |
| 6. Hydraulic filter lamp, yellow. | 16. Horn button. |
| 7. Charge warning lamp, red. | 17. Horn. |
| 8. Oil pressure warning lamp, green. | 18. Fuel tank unit. |
| 9. Fuse. | 19. Connector 3-way to rear harness. |
| 10. Starter/Isolating switch. | 20. Hydraulic filter switch. |

9-37222

H93

R 78, 170



R78 171


Figure H133
INSTRUMENT PANEL HARNESS

For tractors with shell fenders, from the following serial numbers:

885:633680
990:862037
995:930639

996:985304
1210:727072
1212:1003291

- | | |
|--------------------------------------|--|
| 1. Horn button. | 10. Connection for extra equipment. |
| 2. Temperature gauge. | 11. Hydraulic filter lamp, yellow. |
| 3. Fuel gauge. | 12. Lighting switch. |
| 4. Fuel tank unit. | 13. Voltage stabiliser, 885 only. |
| 5. Charge warning lamp, red. | 14. Connection to fuel tank unit in engine harness, 12 series tractor. |
| 6. Oil pressure warning lamp, green. | 15. 10-way connector, to engine harness. |
| 7. Isolating/Starter switch. | 16. 4-way connector to rear harness. |
| 8. Fuses. | |
| 9. Diode. | |




R78 172

Figure H134
INSTRUMENT PANEL HARNESS
For tractors with full fenders, from the following serial numbers:

885:633680	1210:727072
990:862037	1212:1003291
995:930639	1410 }
996:985304	1412 } 1050001

- | | | |
|--------------------------------------|---|--|
| 1. Horn button. | 8. Direction indicator switch. | 15. Fuses. |
| 2. Temperature gauge. | 9. Hazard warning switch. | 16. Voltage stabiliser, 885 only. |
| 3. Fuel gauge. | 10. Flasher unit. | 17. 7-way connector, to rear harness. |
| 4. Fuel tank sender unit. | 11. Warning lamp, trailer direction indicators. | 18. 9-way connector, to engine harness. |
| 5. Charge warning lamp, red. | 12. Lighting switch. | 19. Connection to fuel tank unit, 12 and 14 series only. |
| 6. Oil pressure warning lamp, green. | 13. Hydraulic filter warning lamp, yellow. | 20. Connection for extra equipment. |
| 7. Isolating/Starter switch. | 14. Diode. | |



R78173

Figure H135
INSTRUMENT PANEL HARNESS

For 12 and 14 series tractors, with full fenders, from the following serial numbers:

1210 } 11152567
1212 }

1410 11200752
1412

- | | |
|--------------------------------------|---|
| 1. Horn button. | 8. Direction indicator switch. |
| 2. Temperature gauge. | 9. Hazard warning switch. |
| 3. Fuel contents gauge. | 10. Flasher unit. |
| 4. Fuses. | 11. Warning lamp, trailer direction indicators. |
| 5. Charge warning lamp, red. | 12. Lighting switch. |
| 6. Oil pressure warning lamp, green. | 13. 10-way connector, to engine harness. |
| 7. Isolating/starter switch. | 14. 6-way connector, to rear harness. |




Figure H136
INSTRUMENT PANEL HARNESS
For tractors with Q-cab, from the following serial numbers:

Without console harness:

885Q: 11000001
990Q }
995Q } 11070001
996Q }

1210Q } 11150001
121Q }
1410Q } 11200001
1412Q }

With console harness:

885Q: 11006680
990Q }
995Q } 11083020
996Q }

1210Q } 11156513
1212Q }
1410Q } 11202423
1412Q }

1. Lighting switches.
2. Isolating/starter switch.
3. Fuel gauge.
4. Temperature gauge.
5. Charge warning lamp, red.
6. Oil pressure warning lamp, green.
7. Hydraulic filter lamp, yellow.
8. Diode.

9. Fuses.
10. Hazard warning switch.
11. Direction indicator switch.
12. Flasher unit.
13. Warning lamp, trailer direction indicators.
14. Horn button.
15. Wiper switch.
16. Panel lamps.

17. Fuel tank unit.
18. Console harness, not on early tractors with cab.
19. 11-way connector, to engine console harness.
20. 2-way connector, to cab harness.
21. 7-way connector, to rear harness.
22. 7-way connector, to console harness.

NOTE: Items 7 and 8 are not installed on 12 series from 11152617 and 14 series from 11200752.




Figure H137
INSTRUMENT PANEL HARNESS


For tractors with Q-cab from the following serial numbers:

885Q:11010300
990 }
995 } 11088300
996 }

1210 } 111558600
1212 }
1410 } 11203600
1412 }

1. Lighting switches.
2. Isolating/starter switch.
3. Fuel gauge.
4. Temperature gauge.
5. Charge warning lamp, red.
6. Oil pressure warning lamp, green.
7. Hydraulic filter lamp, yellow.
8. Diode.
9. Fuses.
10. Hazard warning switch.
11. Direction indicator switch.
12. Flasher unit.

13. Warning lamp, trailer direction indicators.
14. Horn button.
15. Wiper/Washer switch.
16. Panel lamps.
17. Fuel tank unit.
18. Console harness.
19. 11-way connector, to engine console harness.
20. 2-way connector, to cab harness.
21. 7-way connector, to console harness.
22. 7-way connector, to rear harness.
23. Windshield washer motor.



R78-176


Figure H138
INSTRUMENT PANEL HARNESS
For tractors with a de-luxe cab and Sekura cab, from the following serial numbers:

885:	11010509	1210	11158982
990		1212	
995	11088651	1410	11203600
996		1412	

1. Lighting switches.
2. Isolating/Starter switch.
3. Fuel gauge.
4. Temperature gauge.
5. Charge warning lamp, red.
6. Oil pressure warning lamp, green.
7. Hydraulic filter lamp, yellow.
8. Diode.

9. Fuses.
10. Hazard warning switch.
11. Direction indicator switch.
12. Flasher unit.
13. Warning lamp, trailer direction indicators.
14. Horn button.
15. Single connector.
16. Panel lamps.

17. Fuel tank unit.
18. Main headlamp warning, blue.
19. 11-way connector, to engine console harness.
20. 2-way connector, to cab harness.
21. 7-way connector, to rear harness.



R78-177

Figure H139
INSTRUMENT PANEL HARNESS
For tractor without cab, Germany.

- | | |
|---------------------------------------|---|
| 1. 4-way connector to headlamps. | 10. Oil pressure warning lamp, green. |
| 2. 9-way connector to engine harness. | 11. Isolation/Starter switch. |
| 3. 2-way connector to headlamps. | 12. Direction indicators switch. |
| 4. Fuse box, 8 fuses. | 13. Hazard warning switch. |
| 5. Horn button. | 14. Flasher unit. |
| 6. Temperature gauge. | 15. Warning lamp, trailer direction indicators. |
| 7. Fuel gauge. | 16. Light switch. |
| 8. Fuel tank unit. | 17. Hydraulic filter warning, yellow. |
| 9. Charge warning lamp, red. | 18. 7-way connector to rear harness. |


Figure H140
INSTRUMENT PANEL HARNESS

For tractors for Germany with de-luxe cab (Sekura), from the following serial numbers:


990 }
995 } 11087366
996 }

1210 }
1212 } 11158779
1410 }
1412 } 11203833

- | | |
|--------------------------------------|--|
| 1. Lighting switches. | 12. Flasher unit. |
| 2. Isolating/Starter switch. | 13. Warning lamps, trailer direction indicators. |
| 3. Fuel gauge. | 14. Horn button. |
| 4. Temperature gauge. | 15. Single connector. |
| 5. Charge warning lamp, red. | 16. Panel. |
| 6. Oil pressure warning lamp, green. | 17. Fuel tank unit. |
| 7. Hydraulic filter lamp, yellow. | 18. Main headlamp warning, blue. |
| 8. Diode. | 19. 11-way connector to engine harness. |
| 9. Fuses. | 20. Connection to console harness. |
| 10. Hazard warning switch. | 21. Connection to cab harness. |
| 11. Direction indicator switch. | 22. 7-way connector to rear harness. |



R78-178



R 78.179


Figure H141
REAR HARNESS

For tractors with shell fenders up to the following serial numbers:

885:833680
990:862037
995:930639

996:985304
1210:727072
1212:1003291

- | | |
|---------------------|---|
| 1. 3-way connector. | 5. Number plate lamp. |
| 2. Side lamps. | 6. Single side/rear lamp as installed on some tractor models. |
| 3. Rear lamps. | |
| 4. Flood lamp. | |



R 78, 180

Figure H142
REAR HARNESS

For tractors with shell fenders, from the following serial numbers:

885:633680
990:862037
995:930639

996:985304
1210:727072
1212:1003291

- | | |
|-----------------------------|---|
| 1. 4-way connector. | 6. Number plate lamp. |
| 2. Starter safety switch. | 7. 2-pin trailer socket. |
| 3. Hydraulic filter switch. | 8. Flood lamp. |
| 4. Side lamps. | 9. Single side/rear lamp, installed on some tractor models. |
| 5. Rear lamps. | |




Figure H143
REAR HARNESS

For tractors with light duty type full fenders, from the following serial numbers:

885:630292
990:859162
995:928254

996:985304
1210:723842
1212:1002144

- | | |
|-------------------------------|------------------------------|
| 1. 4-way connector. | 7. Rear direction indicator. |
| 2. Flasher unit. | 8. Rear lamps. |
| 3. Indicator switch. | 9. Stop lamps. |
| 4. Starter safety switch. | 10. Flood lamp. |
| 5. Side lamps. | 11. Trailer socket. |
| 6. Front direction indicator. | 12. Wire to lighting switch. |

R 78.181




Figure H144
REAR HARNESS


For tractors with reinforced full fenders, from the following serial numbers:

885:633680
990:862037
995:930639
996:985304

1210:727072
1212:1003291
1410 } up to
1412 } 11200752

- | | |
|--------------------------------|-------------------------------|
| 1. 7-way connector. | 7. Rear direction indicators. |
| 2. Starter safety switch. | 8. Rear lamps. |
| 3. Stop lamps switch. | 9. Stop lamps. |
| 4. Hydraulic filter switch. | 10. Flood lamp. |
| 5. Side lamps. | 11. Number plate lamp. |
| 6. Front direction indicators. | 12. Trailer socket. |

R 78.182



R 78.183

Figure H145
REAR HARNESS


For 12 and 14 series tractors with full fenders, from the following serial numbers:

1210, 1212:11152567

1410, 1412:11200752

1. 6-way connector.
2. Starter safety switch.
3. Stop lamp switch.
4. Side lamps.
5. Front direction indicator.
6. Rear direction indicator.

7. Rear lamps.
8. Stop lamps.
9. Flood lamp.
10. Number plate lamps.
11. Trailer socket.



R 78.184

Figure H146
REAR HARNESS


For tractors with Q-cab up to the following serial numbers:

885: 11006680
990 }
995 } 11083020
996 }

1210 } 11156513
1212 }
1410 } 11202423
1412 }

- | | |
|--------------------------------|-------------------------------|
| 1. 11-way connector. | 7. Rear direction indicators. |
| 2. Starter safety switch. | 8. Rear lamps. |
| 3. Hydraulic filter switch. | 9. Stop lamps. |
| 4. Front direction indicators. | 10. Number plate lamp. |
| 5. Side lamps. | 11. Trailer socket. |
| 6. Flood lamp. | |

NOTE: Item 3 is not installed on 12 series tractors from 11152617 and 14 series from 11200752.




R78.185

Figure H147
REAR HARNESS

For tractors with Q-cab from the following serial numbers:

885:11006680	1210	11156513
990	1212	
995:11083020	1410	11202423
996	1412	


- | | |
|--------------------------------|-------------------------------|
| 1. 8-way connector. | 7. Rear direction indicators. |
| 2. Starter safety switch. | 8. Rear lamps. |
| 3. Hydraulic filter switch. | 9. Stop lamps. |
| 4. Front direction indicators. | 10. Number plate lamp. |
| 5. Side lamps. | 11. Trailer socket. |
| 6. Flood lamp. | |



R 78.186

Figure H148
REAR HARNESS
For tractors with de-luxe cab and Sekura cab.

- | | |
|-----------------------------|---|
| 1. Starter safety switch. | 7. Tail lamps. |
| 2. Hydraulic filter switch. | 8. Stop lamps. |
| 3. Flood lamp switch. | 9. Trailer socket. |
| 4. Flood lamp. | 10. Connector, 11-way, to instrument panel. |
| 5. Direction indicators. | 11. Number plate lamp. |
| 6. Side lamps. | |



R7B.1B7

Figure H149
CAB HARNESS

For tractors with Q-cab, from the following serial numbers:

885:11000001	1210	} 11150001
990	1212	
995 } 11070001	1410	} 11200001
996	1412	

- | | |
|--------------------------|---|
| 1. Wiper motor. | 6. Connector, 2-way, to instrument panel harness. |
| 2. Cab light and switch. | 7. Connector, 2-way, cab to console harness. |
| 3. Heater fan switch. | 8. Use for radio connection with inline fuse. |
| 4. Heater fan unit. | |
| 5. Console harness. | |




Figure H150
CAB HARNESS

For tractors with Q-cab, from the following serial numbers:

885:11010300
990 }
995 } 11088300
996 }

1210 }
1212 } 11158600
1410 }
1412 } 11203600

1. Wiper motor, 2 speed.
2. Cab light and switch.
3. Heater fan switch, 3 positions.
4. Heater fan unit.
5. Console harness.
6. 2-way connector, to instrument panel harness.
7. Connector, 2-way, cab harness to console harness.
8. Use for radio connection with inline fuse.

R78-188



1. Heater motor.
2. Interior lamp.
3. Connector, 2-way.
4. Wiper motor.
5. Flood lamp.
6. Washer motor.
7. Heater switch.
8. Wiper switch.
9. Flood lamp switch.
10. Washer switch.
11. Connector to instrument panel.
12. Rear harness connector.
13. Interior lamp switch.




Figure H152
REPLACING A DYNAMO WITH A MACHINE SENSED ALTERNATOR

1. Disconnect and remove the dynamo.
2. Fasten the alternator to the engine, install a new drive belt and adjust the tension.
3. Disconnect and remove the regulator.
4. Cut both ends off the Brown/Green field wire. Fasten it to the harness with tape. This wire will not be used.
5. Remove the Brown wire which is connected between the 'A' terminal of the regulator and the 4-way connector.
6. Make sure the two Brown/Yellow wires are correctly connected together. Put tape around the connection for insulation.
7. Put tape around the end of the Black (ground) wire for insulation.
8. Disconnect the battery. Connect the Brown wire from the alternator to the starter solenoid. Use the same terminal which has a brown wire connected to it. Reconnect the battery.
9. Connect the Brown/Yellow wire, which was disconnected from the dynamo, to the alternator socket.
10. Connect the socket to the alternator and turn the starter key to the 'ACC' position. Check that the warning lamp illuminates. Start the engine, check that the lamp stops illuminating. This will show that the alternator is making a charge.
11. Make sure the operator is told of the procedure to protect the alternator. See important note on pages H15 and H21.

ELECTRICAL EQUIPMENT

SPECIFICATION AND DATA

BATTERY

K929951 (Exide 6/RHAZ 17R) standard duty	1412, 1410
K929951 (Exide 6/RHAZ 17R) heavy duty	1212, 1210
K918881 (Exide 6/TXAZ 15R) standard duty	996, 995
K907789 (Exide 6/TXMZ 15L) standard duty	990, 885
K929951 (Exide 6/RHAZ 17R) heavy duty	885 gasoline
K923878 (Exide 6/TXAZ 11L) heavy duty	

Capacities at 25° Celcius (77° Fahrenheit)

K918881	—	96 amp hours at 20 hour rate
K929951	—	128 amp hours at 20 hour rate
K907789	—	96 amp hours at 20 hour rate
K923878	—	71 amp hours at 20 hour rate

Specific Gravity of electrolyte—initial filling

dry) (below 25° Celcius (77° Fahrenheit)	...	1.270 to 1.260
uncharged) (above 25° Celcius (77° Fahrenheit)	...	1.240 to 1.230
dry) (below 25° Celcius (77° Fahrenheit)	...	1.260
charged) (above 25° Celcius (77° Fahrenheit)	...	1.210

Specific Gravity of electrolyte—corrected to 15°C (60°F)

S. G. of filling	fully charged	70% charged	discharged
acid			
1.260	1.290—1.270	1.250—1.230	1.130—1.110
1.250	1.270—1.250	1.230—1.210	1.110—1.090
1.210	1.230—1.210	1.190—1.170	1.070—1.050

Electrolyte temperature correction—Celcius scale

For every 10° Celcius below 15° subtract 0.007 from the hydrometer reading.
For every 10° Celcius above 15° add 0.007 to the hydrometer reading.

Electrolyte temperature correction—Fahrenheit scale

For every 10° Fahrenheit below 60° Fahrenheit subtract 0.004 from the hydrometer reading.
For every 10° Fahrenheit above 60° Fahrenheit add 0.004 to the hydrometer reading.

Freezing temperature of battery electrolyte

Specific gravity	Freezing point
1.130	— 10° Celcius (—13° Fahrenheit)
1.200	— 30° Celcius (—22° Fahrenheit)
1.280	— 67° Celcius (—90°F)

ALTERNATOR

Lucas type 15 ACR. Machine sensed unit with European Termination

Alternator (without fan and pulley). Lucas despatch number (23700)	...	23774 (parts replacement)
Polarity	...	negative earth
Voltage (nominal)	...	12.0
Voltage (maximum)	...	14.4
Output (at maximum voltage)	...	28 amp
Rotor winding resistance (at 20° Celcius)	...	4.13—4.53 ohms
Brush spring tension (with brush face flush with brush box housing)	...	255—368g (9—13oz)
Brush length (new)	...	12.6mm (½in)
Brush protrusion (minimum when free)	...	5mm (0.2in)
Regulator—8TRD or 14TR	...	Lucas 37565
Rectifier pack	...	Lucas 83166
Surge protection diode	...	Lucas 54486144

AC-Delco type DN460, 35 amp. Machine sensed

AC-Delco number	...	7982952
Polarity	...	negative ground
Voltage, nominal	...	12 volts
Output, maximum	...	35 amp
Rotor winding resistance	...	2.6—3.0 ohm
Brush spring tension	...	226.8—368.5g (8—13oz)
Brush length, new	...	13.2mm (0.5in)
Minimum brush length	...	10mm (0.4in)
Rotation	...	clockwise from the front

DYNAMO

Lucas type C40A (non-ventilation) } Alternatives Lucas type C40T (ventilated) } all models

Lucas despatch number C40A (22733)	...	22703 (parts replacement)
Lucas despatch number C40T (22758)	...	22756 (parts replacement)
Polarity	...	negative earth
Voltage (nominal)	...	12 volts
Voltage (maximum)	...	13.5 volts
Output (at maximum voltage) C40A	...	11 amp
Output (at maximum voltage) C40T	...	22 amp
Field winding resistance	...	6.0 ohms
Brush length (minimum)	...	8mm (5/16in)
Brush spring pressure, C40A	...	369—850g (13—30oz)
Brush spring pressure, C40T	...	567—680g (20—24oz)

Commutator: details—

Minimum diameter (moulded commutator)	...	37mm (1 29/64in)
Minimum thickness of segments	...	1.5mm (1/16in)
Depth of undercut	...	0.8mm (1/32in)

VOLTAGE REGULATOR

Lucas type R.B 108			
Lucas despatch number. When used with C40A dynamo	37408 (parts replacement)
Lucas despatch number. When used with C40T dynamo	37467 (parts replacement)

Regulator voltage setting

Ambient temperature	open-circuit voltage
10° Celcius (50° Fahrenheit)	16.1 to 16.7
20° Celcius (68° Fahrenheit)	16.0 to 16.6
30° Celcius (86° Fahrenheit)	15.9 to 16.5
40° Celcius (104° Fahrenheit)	15.8 to 16.4

Cut-out voltage settings

Cut-in voltage	12.7 to 13.3 volts
Drop-off voltage	8.5 to 10.0 volts
Regulator gap setting	0.5mm (0.020in)
Cut-out armature movement	0.6–1.0mm (0.025–0.040in)
Cut-out contact blade deflection	0.25–0.5mm (0.10–0.20in)
Regulator field resistance:					
Carbon resistance	60–75 ohms
Wire wound resistance	55–65 ohms
Shunt winding resistance (checked between 'D' and 'E' terminals)	50–56 ohms

STARTER MOTORS

1412, 1410: Part No. K919752 (Lucas M50. No. 26379A)
 1212, 1210, 1200, 996, 995, 990: Part No. K89772 (Lucas M45G. No. 26278)
 885 diesel, 880, 780: Part No. K913007 (Lucas M45G. No. 29215)
 885 gasoline from January 1973: Part No. K944488 (Lucas 3M100. No. 25679A)
 4600, 3800, 885 gasoline to January 1973: Part No. K922703 (Lucas No. M45G. No. 26277)
 Alternative starter on:
 1210, 1212 from Serial No. 11157537 and 1410, 1412, 996, 995, 990, all from August 1977:
 Part No. K954700 (Bosch No. 00-001-362-060)

Brush length (minimum) M45 and M50	14mm (5/16in)
Brush length (minimum) 3M100	9.5mm (3/8in)
Brush spring tension:					
M45 and M50 (with new brush)	1.47kg (52oz)
3M100 with new brush protruding 0.06in (1.5mm)	1.22kg (43oz)
Commutator diameter (minimum) M45 and M50	38.1mm (1.50in)
Bearing bush diameters (maximum)					
Commutator end	} M45 and M50	12.83mm (0.505in)
Intermediate		28.63mm (1.127in)
Drive end		17.14mm (0.675in)
Drive end	} 3M100	11.2mm (0.441in)
Commutator end		12.1mm (0.476in)
Armature end-float	0.13 to 0.26mm (0.005 to 0.010in)
Multi-plate clutch slip torque	9.25–11kg metres (800–950lb in)
Pinion setting distance (diesel starters)					
M45G roller clutch	0.13–0.38mm (0.005–0.015in)
M45G multi-plate clutch	0.51–0.76mm (0.020–0.030in)
M50 roller clutch	0.13–1.143mm (0.005–0.045in)
Solenoid details					
919752 starter	type 18S
26278 starter	type 19S
26215 starter	type 7S
25679 and 26277 starters	type 4ST
Closing (series) winding resistance	0.25–0.27 ohms
Hold-on (shunt) winding resistance	0.76–0.80 ohms
Both windings in series	1.01–1.07 ohms

FUEL GAUGE

Tank Unit—1412, 1410, 1212, 1210, 1200—K916755	(AC-Delco 7967414)
Tank Unit—996, 995, 990—K946158	(AC-Delco E/PG 163902)
Tank Unit—996, 995, 990, 880, 780, 770—K916635	(AC-Delco 7967410)
Tank Unit—885, 885G—K946184	(Smiths Ex 15601)
Tank Unit—885, 885G—K943347	(Smiths TBS 1514/008)
Instrument—all models except 885—K921147	(AC-Delco 7974119)
Instrument—885, 885G—K942442	(Smiths BR/2100/02)
Voltage Stabiliser—885, 885G—K942740	(Smiths BR/1300/01A)

TEMPERATURE GAUGE

Sender unit—all models—K921149	(AC-Delco 7966281)
Instrument—all models—K921148	(AC-Delco 7966282)

WARNING LAMP SWITCHES

Oil filter switch—all models—K921317	(AC-Delco 7954473)
Operating vacuum oil filter switch	19.7–222mm (7½–8½in) Hg.
Oil pressure switch—all models—K903851	(AC-Delco 7954181)
Operating pressure, oil pressure switch	0.6–0.9kg/sq cm (9–13lb/sq in)

WIPER MOTOR

Lucas model 14W, 12 volts	Lucas 54071929
Brush length	Minimum 4.8mm (3/16in)
Brush spring pressure	17Nm, 6ozf or 170gf
Armature end movement	0.05–0.25mm (0.002–0.010in)
Yoke bolts, torque	1.35–1.80Nm, 0.138–0.184kgm, 12–16ft lb




Figure H153
TYPES OF BULBS

LAMP BULBS

	Description	Qty.	Remarks
A	Sealed Beam 12V-40/40W 3 pin Butler Part No. 1720-40 G.E.C. Part No. GE 4440	2	Headlamp-Inboard K915874
B	Sealed Beam 12V-35W 2 pin Butler Part No. 1720-38 G.E.C. Part No. GE 4411	2	Headlamp-Inboard K915141
C	Double Contact 12V-35/35W Unified European Cap Hella Part No. B 1235/35	2	Headlamp-Inboard European K917233
D	Double Contact 12V-35/35W B.P.F. British Pre-Focus Butler Part No. B 275 Lucas Part No. 350	2	Headlamps-Outboard U.K. K921082 K921083
E	Double Filament 12V-45/40W Duplo 'D' Continental Pre-Focus Butler Part No. B 268 Lucas Part No. 410 Butler Part No. B 295 Lucas Part No. 411	2	Headlamps-Outboard Continental K944729 K944730 K944731 K944723
F	Single Contact 12V-35W B.P.F. British Pre-Focus Butler Part No. B 165 Lucas Part No. 162	1	Rear Flood Lamp K943976 K943977 K921081
G	Single Contact 12V-21W S.C.C. Small Bayonet Cap Butler Part No. B 364 Lucas Part No. 382	6	Combined Lamps Flasher & Stop K948815/6 K929166/7 K929168/9 K929172/3 K948813/4
H	Single Contact 12V/5W S.C.C. Butler Part No. B 370 Lucas Part No. 223 (14V/7W)	4	Side & Tail
J	Double Contact 12V/5W S.B.C. Small Bayonet Cap Butler Part No. B 201 Lucas Part No. 218 (14V/7W)	2 or 4	Side Tail Lamp K921079/80 K921233/4 K921235/6
K	Single Contact 12V/5W M.C.C. Small Bayonet Cap Butler Part No. B 267 Lucas Part No. 989	1 or 2	Rear Number Plate Lamp 943308 K773358 K921076 Hazard Warning Switch K944664
L	Single Contact 12V/2W B.A.7s Miniature Bayonet Cap Lucas Part No. 281 Philips Part No. 12829	5	Warning Lamp & Indicator Switch K917370/1 K921367 K94364 K913565
M	Capless 12V/5W 5mm Panel Double Contact Lucas Part No. 286 Philips Part No. 12516	1	Hazard Warning Switch K947482
N	Halogen, 12V/55W	1	Flood Lamp. De-luxe and Sekura cab
P	Festoon 12V/5W	4	Side and rear lamps later tractors
	Festoon 12V/10W	1	Cab Lamp

SUMMARY OF DESIGN CHANGES

Details of Change

Colour code of wiring changed to conform to British Standard practice.
Isolating switch changed from K961975 (AC-Delco) to K920923 (Lucas)

Starter safety switch (K918672) changed to plunger operated switch (K916479) operated directly from clutch pedal

Lighting switch (K912388, 5-position) changed to a 4-position switch (K902464).
Vacuum switch wiring re-routed through conduit on gearbox top

Voltage regulator earth lead (K921174) changed to lead K924142, which has two earthing points. One under regulator mounting bolt and another under fuel tank support

Stop lamp switch (K917301) changed to switch K929737, which is positioned on left-hand brake pedal so that stop lamps do not operate when hand brake is applied

Combined stop/rear/direction indicator lamps fitted to tractors with full fenders instead of the separate lamps fitted previously

Fuse incorporated in accessories lead, to provide protection for equipment which is operative when isolating switch is turned 'on', e.g. windscreen wiper, instruments, etc.

Starter K922703 (Lucas M45G) changed to Lucas 3M100 starter (K944488). The new starter, which has a face type commutator and window-less yoke, is interchangeable with previous starter

Flasher unit (K913564—18 watt rating) changed to a 21 watt unit K945512. Units are interchangeable and later unit should always be used as a replacement

Models and Serial Numbers

770/588498
880/544392
990/504027
1200/703305
(November, 1967)

880/547055
990/800751
(March, 1968)

770/589439
780/601520
880/547986
990/802575
1200/705856
(May, 1968)

770/590006
780/602231
880/549153
990/804700
1200/706430
4600/900196
(October, 1968)

1200/718062
(November, 1971)

780/610673
880/562338
990/829679
1200/717256
(October, 1971)

885/620001
885G/651001
885N/646001
990/850689
995/920003
1210/720001
1212/100049
(July, 1972)

885G/651141
(December, 1972)

885/624732
885G/651239
990/854925
995/925509
996/981938
1210/722546
1212/100125
(March, 1973)

SUMMARY OF DESIGN CHANGES

Details of Change

Isolating switch K920923, changed to switch K945294, which has a larger connector blade on input terminal

Fuel tank unit position changed from front to top of fuel tank. Part number of tank unit changed from K916635 to K946158

Fuel gauge tank unit position changed from front to top of fuel tank. Part number of tank unit changed from K943347 to K946184

Alternator mounting bracket changed from K912758, which was also used for mounting dynamo, to bracket K947375, which can only be used for alternator

Wiring harness changed to include two multi-pin sockets, to facilitate instrument panel removal. Hazard warning switch K944664 changed to K947482 and flasher unit changed from K945512 to K948611

New battery clamp frame K947080 with vertical studs and wing nuts installed

Latest type wiring with multi-pin sockets installed on German models for easier removal and servicing

Bayonet type bulb holders installed in Butler side and rear lamps

Hazard warning switch installed. 5-way female connector for flasher unit installed

Hydraulic filter warning system removed from 12 and 14 series tractors

Capless type bulbs and holders installed for instrument panel

AC-Delco Alternator installed on some tractors

Front console harnesses added to wiring on tractors with Q-Cabs

Models and Serial Numbers

885/626173
885G/651239
885N/646322
990/855819
995/926076
996/982318
1210/732932
1212/1001467
(April, 1973)

996/983083
995/926701
990/856494
(June, 1973)

885/626877
885G/651280
(June, 1973)

All Models
(June, 1974)

1212/1002145
1210/723843
996/985305
995/928255
990/959163
885/630293
(February, 1975)

885 } June 1975
885N }
990/866452
995/934315
996/987778
1210/730832
1212/1004792

885G/638731
990G/868010
995G/835195
996G/988358
(October, 1975)

885/11000001
990 }
995 } 11070001
996 }
1210 } 11150457
1212 }
1410 } 11200001
1412 }
(January, 1976)

885/11001375
(April, 1976)

1210 } 11152576 Series 1
1212 } 11152617 Series 2
1410 } 11200752
1412 }
(June, 1976)

1210 } 11150721
1212 }
1410 } 11200162
1412 }
(April, 1976)

(April, 1977)

8 series/1100680
9 series/11083020
12 series/11156513
14 series/11202423
(April, 1977)

ELECTRICAL EQUIPMENT

Details of Change

Thermostart installed as normal equipment on tractors with Q-Cabs

Festoon type bulbs installed in Butler side and tail lamps.

Bosch pre-engaged starter installed on some four cylinder engines

Warning lamp for headlamp main beam installed on Sekura cabs for Scandinavia

Models and Serial Numbers

885/11007594
990 }
995 } 11157412
996 }
1210 } 11084956
1212 }
(June, 1977)

8 series 11007544
9 series 11084517
12 series 11157259
14 series 11202741
(June, 1977)

(July, 1977)

8 series/11011842
9 series/11090489
12 series/11660275
14 series/11204265
(March, 1978)



DAVID BROWN

Service Information

1410, 1412 TRACTORS

Including 'Q'-Cab Models

Pub 9-38127 November 1978 Reprinted March 1983

David Brown Tractors Ltd

Affiliate of J I Case

INTRODUCTION

This publication is intended to provide information which may be required when servicing DB 1410 and 1412 tractors. It is not a comprehensive repair manual but is a summary of service information with emphasis on features which are new, or different, from previous DB models.

For convenient reference the publication is divided into the usual sections, i.e. engine, transmission, etc. These sections are arranged in the same order as the service manual sections and will, in due course, be updated and incorporated in the regular service manual.

Clutch, front axle and steering, the hydraulic system, electrical equipment and PTO are not included as the respective sections of the service repair manual include information on 1410 and 1412 tractors.

This edition includes information previously given in:

- Pub. 9-38124 (Preliminary Service Information, issued May 1976, reprinted November 1976)
- Pub. 9-38151 (updated pages A5, 7, 11 and 13)
- Pub. 9-38175 (updated pages D5 and section F)
- Pub. 9-38162 'Q'-Cab Preliminary Service Information — (certain information only)
- Pub. 9-38184 (updated pages A11/12)

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

CONTENTS

SECTION	DETAILS	PAGE
Turbocharged Engine		
	How it works	A1
	Unit removal and replacement	A2
	Unit maintenance and repair	A6
	Specifications and data	A11
Transmission		
	How it works	C1
	Unit removal and replacement	C1
	Unit maintenance and repair	C6
	Specifications and data	C7
Final Drive Reductions		
	How it works	D1
	Unit removal and replacement	D2
	Unit maintenance and repair	D3
	Specifications and data	D7
Brakes		
	How it works	F1
	Unit removal and replacement	F3
	Unit maintenance and repair	F5
	Specifications and data	F6
	Brake Hydraulic System	
	How it works	F7
	Unit removal and replacement	F7
	Unit maintenance and repair	F8
	Specifications and data	F9

HOW IT WORKS—TURBOCHARGED ENGINE

The power output of an engine is determined by the amount of fuel that can be burnt in a given time. For proper combustion the fuel needs an adequate supply of air so that for an increased power output more air is required.

The volume of the engine cylinders is fixed but the air supply can be increased by using a blower to fill the cylinders with air which is denser and therefore capable of burning more fuel.

A turbocharger is a simple turbine-driven compressor which utilises energy in the exhaust, and which would otherwise be wasted, to compress the air before it enters the engine cylinders. This enables more fuel to be burnt efficiently and thus more power produced. When the engine is running, exhaust gas expelled from the cylinders passes through the exhaust manifold and enters the turbine housing. The gas then flows from the circumference of the housing through a narrow slot to the turbine blades. This causes the turbine to rotate at very high speed and the gas leaves the turbine at its centre and into the atmosphere through the silencer. Air drawn through the air cleaner in the normal way enters at the centre of the com-

pressor and as the compressor wheel is attached to the end of the turbine shaft, and therefore revolving at the same high speed, air is expelled radially into the compressor housing. Air in the compressor housing is thus maintained under pressure and flows into the engine cylinders via the inlet manifold.

The very high rotational speed of the turbocharger, which can approach 100,000 rev/min, requires a pressure oil feed from the engine lubrication system to lubricate the shaft bearing and cool the unit. A large drain pipe is also provided so that any air entering the oil from the compressor is released before the oil is returned to the sump.

To maintain reliability it is necessary for the structural strength, lubrication and coolant flow of the engine to be matched to the higher engine power. The air cleaner must also be of adequate capacity for the increased air flow. A turbocharged engine must therefore be designed from the outset as a turbocharged unit and is not a naturally aspirated engine which has been fitted with a turbocharger.




FIGURE A1. TURBOCHARGER

9-38127

A1

UNIT REMOVAL AND REPLACEMENT

Turbocharger

After removing silencer and bonnet top, disconnect air pipes from air cleaner and inlet manifold. Disconnect turbo oil feed pipe and remove upper half of oil drain pipe. Unscrew adaptor from drain hole in turbo body—this will provide more room for removing the adjacent mounting nut—then remove turbo, complete with exhaust outlet pipe, from manifold. Outlet pipe to silencer has a ground spigot—no gasket—into turbo body and can be separated after removal.

Seal turbo oil pipe connections immediately after removal, to prevent dirt reaching turbo bearing.

Replace turbocharger in opposite way to removal; fitting outlet pipe into turbo body before bolting turbo to exhaust manifold.

Before connecting oil feed pipe, fill turbo oil chamber with clean engine oil; to provide initial lubrication.




FIGURE A2. REMOVING TURBOCHARGER

Fan Belt

Slacken alternator mounting bolts, so that alternator can be pushed down to release fan belt tension. Remove the four bolts attaching hydraulic driveshaft coupling to crankshaft pulley and screw two of the bolts into the tapped holes in coupling to separate coupling from pulley. Push coupling on driveshaft and remove rubber distance piece from end of driveshaft. Manipulate new belt over fan blades then past driveshaft end and over crankshaft and alternator pulleys. Position alternator to adjust belt tension then fully tighten mounting bolts. Replace rubber distance piece at end of driveshaft then bolt coupling flange to crankshaft pulley, and replace 'O' ring inside coupling.




FIGURE A3. FAN BELT ADJUSTMENT

Thermostat

Drain cooling system. Disconnect air pipe from cleaner to turbo and remove bolts attaching cover to thermostat housing. Remove air cleaner, complete with thermostat housing, then lift out thermostat.

Replace in reverse order of removal, fitting a new 'O' ring under thermostat.




FIGURE A4. THERMOSTAT REMOVAL

Water Pump

Release fan belt tension by slackening alternator mounting bolts and pushing alternator downwards. After draining cooling system, remove pump inlet hose and remove the four bolts attaching fan to pump pulley. Lift fan from pulley and stow it in radiator shroud then remove bolts attaching pump to cylinder block. Pump assembly may then be removed by pivoting pump body downwards on the remaining stud until the by-pass seal is clear of thermostat housing.

Replace pump in opposite way to removal, fitting a new 'O' ring at rear of pump body. After sliding pump on to mounting stud, place new rubber by-pass seal in body recess then pivot pump upwards to compress seal and allow bolts to be screwed into cylinder block. Refit drive belt before bolting fan to pump pulley.




FIGURE A5. WATER PUMP REMOVAL

Radiator

Remove bonnet top and drain cooling system. Disconnect and remove battery. If front chassis ballast weights are fitted, lower frame on to front axle. Remove the four nuts from front extension and six bolts into radiator then disconnect headlamp wiring and lift off bonnet front.

Disconnect inlet and outlet pipes from hydraulic pump, so that pump can be removed complete with mounting bracket and oil cooler. Remove driveshaft coupling from crankshaft pulley; if coupling is not easily separated from pulley, screw two of the bolts into tapped holes in coupling flange. Disconnect inlet and outlet hoses from radiator then remove mounting bolts and lift radiator off with driveshaft through lower tank.

Replace radiator in reverse order of removal, first fitting driveshaft through lower tank and replacing rubber distance piece on shaft end before bolting coupling to crankshaft pulley. Take special care to ensure that no dirt is allowed to enter the open pump or pipe connections.




FIGURE A6. RADIATOR REMOVAL

Fuel Tank

As a full fuel tank is very heavy, the less fuel there is in the tank the easier it is to lift off. Disconnect lower end of hand throttle lever so that lever can be pulled upwards out of instrument panel. Disconnect tractorometer cable at engine end then pull cable out so that it can be removed with panel. Remove injector leak-off pipe. Disconnect leak-off and feed pipes from tank. Disconnect wiring harness at multi-pin connectors and remove pin from Hydra-Shift lever link. Remove mounting bolts then lift tank off with instrument panel attached. Tank and panel can then be separated after removal. Replace tank in reverse order of removal.




FIGURE A7. FUEL TANK REMOVAL

Fuel Injection Pump

First check that marks on pump body and carrier plate are aligned: if any doubt exists, make new marks so that pump can be refitted in its original position. Drain cooling system and remove radiator outlet hose. Remove stop control and throttle rod complete with pump bracket. Remove turbocharger oil feed and drain pipes. Disconnect and remove injector pipes. Remove inspection plate from timing cover then unlock and remove nut from pump drive gear. Remove bolts attaching pump to carrier plate then use a small three-jaw extractor to draw gear from pump camshaft, so that pump can be withdrawn rearwards. Pump gear will remain in case but ensure that it remains in correct mesh, otherwise pump timing will be altered.

Replace pump in reverse order of removal, ensuring that marks on pump and carrier plate are aligned, so that original pump timing is obtained. Fully tighten drive gear nut before locking with tabwasher.





FIGURE A8. INJECTION PUMP

Timing Gears

After removing bonnet front and radiator, remove fan blades and fan belt. Remove crankshaft pulley—nut is right-hand thread—and timing cover to expose timing gears. Before disturbing timing gears turn engine so that gear marks are aligned: this will assist aligning marks when refitting gears. Injection pump, power steering, pump and camshaft gears



can be removed with suitable extractor—take special care when removing steering pump gear; do not strike extractor with a hammer or use a lever behind gear as this may cause the pump rotors to damage the softer bearings. Intermediate gear will slide off its shaft after removing bracket. Intermediate shaft can be pulled out of block and, if tight, remove plug from front end and screw a $\frac{1}{4}$ UNC bolt into shaft to assist extraction.

As the crankshaft gear cannot be removed without risk of being damaged, do not remove this gear unless it is to be renewed.

Do not turn crankshaft or camshaft unless gears are correctly meshed as damage could be caused by pistons fouling valve heads.

Reassemble gears in reverse order of removal. If intermediate shaft has been removed ensure that the grub screws in both ends of shaft are secured with Loctite (Grade 270) and staked in position. Fit shims between bracket and block to give inter gear 0.002 to 0.004 in (0.05 to 0.10 mm) end float. Ensure that markings on gears are correctly aligned and retaining bolts or nuts are fully tightened. After replacing timing cover, loosely fit all bolts then use Service Tool K962560 to centralise cover with crankshaft before fully tightening cover bolts.




FIGURE A9. REFITTING TIMING CASE

FIGURE A10. TIMING GEAR MARKINGS

Engine Camshaft

This can be removed with engine in situ. After removing radiator and timing cover, remove valve rocker cover and rocker shaft. Lift out push rods and remove the two push rod covers from right-hand side of cylinder block. Remove the two mounting bolts from fuel feed pump so that pump can be moved far enough to allow pump push rod to be removed from cylinder block.

Drain and remove engine sump. Disconnect pipe from oil pump then remove pump locating screw—this is lower of the two screws on right-hand side of cylinder block—so that pump can be removed.

Remove the three bolts from locating plate—these are behind camshaft gear but can be removed by turning engine to bring one of gear holes opposite a bolt. When bolts have been removed turn engine to bring camshaft and intermediate gear markings in line.

Hold valve tappets upwards, by jamming them with pieces of rubber or making some simple clips, then pull camshaft forwards out of cylinder block. Camshaft should not need forcing; if it cannot be pulled out easily this will be due to a valve tappet dropping and fouling against a shaft journal or cam lobe.

Replace in reverse order of removal, ensuring that *all eight tappets are held in position and do not drop out* as shaft is being refitted. Align gear marks before meshing teeth and fitting locating plate bolts—plate holes are not symmetrical and plate will only fit in one position.

Cylinder Head

Drain cooling system. Remove exhaust manifold complete with turbocharger. Plug turbo oil holes, to prevent dirt reaching bearing. Remove air cleaner, then rocker cover. Remove rocker shaft and push rods. Disconnect top hose and oil feed pipe then remove cylinder head bolts and nuts.

Replace cylinder head in reverse order of removal. Fit a new gasket, dry—no jointing compound—and tighten bolts in the correct order and in three stages. Adjust valve clearances after fitting rocker shaft. Prime turbo oil chamber with *clean* engine oil before connecting oil feed pipe.

Cylinder head bolts should be tightened and valve clearances checked (cold) after engine has run for approximately one hour.

Tighten bolts and nuts in order shown and in four stages of 30, 60, 80 and finally 100 lb ft. (4, 8, 11 and 13.75 kg metre).




FIGURE A11. CYLINDER HEAD TIGHTENING SEQUENCE

Pistons and Connecting Rods

With cylinder head removed, drain oil and remove engine sump. Remove big-end bearing caps—taking care that these are identified so that they can be refitted in same position—then remove bolts and push pistons out of cylinder bores. Pistons must be refitted in their original bore and the original way round. The bearing shells—if not renewed—and bearing caps must also be refitted in their original position. Oil the bores, space out the ring gaps and after compressing rings with a suitable compressor push piston down into the bore. Fit bearing shells—smeared with oil—replace caps, bolts and nuts. If nuts can be screwed fully on with the fingers the self-locking ring is not effective and nuts should be renewed. Tighten the nuts evenly, to the correct torque.

Crankshaft

To remove crankshaft it is first necessary to remove the engine unit and then remove carrier plate, with injection pump attached. Remove main and big-end bearing caps—ensuring that these are marked for re-fitting in their original positions—then lift out crankshaft.

When refitting crankshaft, ensure that all bearings and journals are clean and smeared with oil: if original bearings are being replaced these must be fitted in their original positions.

New bearing bolt lockwashers should be used and the surface washers fitted between lockwashers and bolt heads. Tighten bolts evenly to the correct torque.

When refitting clutch assembly use pilot shaft to centralise drive plates before bolting clutch to flywheel (Fig. B3).

Engine Unit

Before the engine unit can be lifted from the main frame it is necessary to separate the gearbox and clutch, and easiest way of doing this is to 'split' the tractor as for clutch removal (see page 82).

After 'splitting' tractor, so that clutch driveshaft is withdrawn from clutch, drain cooling system and remove both radiator hoses. Remove fan blade and stow this in radiator shroud. Remove pump driveshaft coupling from crankshaft pulley and remove rubber distance piece from driveshaft end. Remove valve rocker cover and, using two lifting nuts, attach engine lifting bracket to two of cylinder head studs. After removing bolts attaching cylinder block to frame—four of these are fitted upwards from underside of main frame—lift engine vertically out of frame: taking care not to damage the lubricating oil pump, which is some distance below cylinder block face.

Before refitting engine, ensure that main frame and cylinder block faces are clean. Fit new gaskets on main frame face and new rubber seals on main bearing caps. Take care not to damage oil pump when handling engine and fit two guide studs so that engine can be correctly positioned before being lowered on to main frame.

UNIT MAINTENANCE AND REPAIR

Turbocharger

The only maintenance requirements for a turbocharger are: ensuring an adequate supply of *clean* lubricating oil, an unrestricted supply of *clean* air and the rectification of any air or exhaust leaks. Any faulty gaskets must be renewed immediately as only a small amount of leakage will have an adverse effect on the operation of the turbocharger.

When a major engine overhaul is carried out the turbocharger should be stripped and cleaned (by a CAV agent), to ensure maximum life and performance.

If engine oil and filter element are renewed as recommended in the tractor instruction book and the engine lubricating oil pressure does not fall below 10 lb/in² (0.7kg/cm²) when idling, the turbocharger lubrication will be satisfactory.

If air cleaner is allowed to become choked, the turbocharger will be unable to supply the engine with an adequate supply of air, resulting in loss of power, excessive exhaust smoke and the possibility of oil leakage from the turbocharger.

The air cleaner therefore incorporates a warning device to indicate when the cleaner element is choked. To check filter

condition, press button on restriction indicator 'in' with engine running at idling speed then gradually increase speed. If indicator shows red, the element is choked and requires servicing.

Air leakage between turbocharger and engine cylinders will also result in loss of power. The manifold and connecting pipe must, therefore be airtight and any leakage rectified immediately. If loss of power is experienced and the air cleaner indicator does not show a choked filter, first ensure that this is not caused by leaking manifold gaskets or air pipe connections.

Loss of power, excess smoke and high fuel consumption are faults which are often wrongly attributed to the turbocharger. It is worth remembering that the turbocharger is basically a simple device, consisting of two rotors on a common shaft and rotating in a plain bearing. If the turbocharger operates without excessive vibration or noise and there are *no air or exhaust leaks*, the usual engine and fuel injection equipment checks should be carried out as it is very doubtful if loss of engine performance is caused by a faulty turbocharger.

If it is definitely established that a turbocharger is faulty, and the easiest way of doing this is by substitution, no attempt should be made to dismantle it but the unit should be removed and forwarded to a CAV agent for stripping and examination.




FIGURE A12. TURBOCHARGER

9-38127

A6

Water Pump

To dismantle pump, remove backplate and press pulley off shaft to expose locating screw. Remove bearing locating screw then, whilst supporting pump body, press shaft and bearing forwards out of body and impeller. Gland seal is fitted in body and can be pushed out rearwards after removing impeller.

Examine bearing and renew if it shows any signs of roughness or excessive play. Always fit a new gland seal.

To assemble pump, press bearing into body until locating holes are in line then fit locating screw and lock with tab-washer. Whilst supporting impeller end of shaft, press pulley on shaft until shaft end is level with edge of pulley bore. Turn pump over and fit new gland seal into pump body. Smear gland face with anti-scuffing paste before pressing impeller on to shaft. Press impeller on shaft until blades are 0.005in (0.01mm) clear of pump body, and support shaft on a $\frac{3}{4}$ in (20mm) diameter distance piece, so that pulley is not pushed further on to shaft. Check that pump can be turned by hand and gland seal has a slight drag, then refit backplate, using a new gasket.

Fuel Injection Pump

The only maintenance required on the injection pump is maintaining sufficient clean, undiluted engine oil in the pump cam box. The oil should be drained and refilled to the level plug with clean engine oil every 125 hours.

Fuel Injection Pump Timing

When refitting an injection pump it is most important that it is correctly timed so that the injection, or 'spill' point occurs at the correct crankshaft position.

To obtain the correct timing, the scribe mark on the injection pump flange must be aligned with the scribe mark on the engine carrier plate. The pump flange is slotted to allow pump body to be turned to bring marks into alignment.

If it is suspected that the timing obtained by this simple method is incorrect or if either of the scribe marks are obliterated it will be necessary to carry out a more basic check on the pump 'spill timing'.

Reconditioned Injectors

Undertake the following tests before installation of reconditioned injectors with BDLL 140S 6592 nozzles.

1. Pressure Test

Adjust injector springs to the correct breaking pressure:

New springs : 190 Ats ; 196 kg/cm² ; 2793 lb/in²

Used springs : 180 Ats ; 186 kg/cm² ; 2646 lb/in²

2. Back Leakage Test

Time the "leak past" between needle and nozzle bore (with dry tip) from 150 to 100 Ats (154 to 104 kg/cm² ; 2205 to 1470 lb/in²). This must be between 5 and 15 seconds. Injectors with a slower "leak rate" (e.g. 15 to 25 seconds) would be subject to sticking causing intermittent black smoke and power loss.




FIGURE A13. WATER PUMP

Checking Pump Spill Timing

To spill time a pump to an engine it is necessary to:

1. Fit a capillary tube to number one injector pipe outlet, so that pump spill point can be observed.
2. Locate exact position of crankshaft when pump reaches its spill point. This can be done in two different ways:
 - (a) Inserting a timing peg through 'SP' hole in clutch housing to locate in flywheel dimple.
 - (b) Measuring piston movement—which is directly related to crankshaft position—by lowering an inlet valve on to piston and using a dial gauge to measure valve movement.




FIGURE A14. PUMP CAPILLARY TUBE

Spill Timing (Timing peg method)


1. Move pump into fully retarded position (release mounting nuts then pull top of pump away from cylinder block).
2. Remove injectors, blanking open end of leak-off pipe. Place stop control in run position and throttle control in maximum speed position. Install capillary tube on to No. 1 injection port outlet. Bleed fuel system *thoroughly*. It will be necessary to rotate engine with starter motor to bleed the high pressure galleries in the injection pump.

3. Slacken the capillary tube union nut with one finger over the end of the tube. Allow fuel level to drop but still remain visible. Tighten union nut and remove finger from tube. Rotate engine in normal direction of rotation and check that there is now a fuel column with an air bubble visible in the tube (if not, repeat this operation to introduce an air bubble).
4. Rotate engine manually in *normal direction of rotation* until the timing rod, inserted through the 'SP' hole in the flywheel cover, engages with the flywheel timing drilling on No. 1 compression stroke.
5. Prime the fuel lift pump to ensure an adequate flow of fuel to the injection pump. Rotate pump body slowly towards the advanced position (top of pump towards block) until the column of fuel in the capillary tube *JUST commences to rise* then tighten nuts attaching pump to timing case.
6. CHECK as follows—Prime fuel lift pump by hand, rotate engine manually in *normal direction of rotation* $1\frac{1}{2}$ crankshaft revolutions. Continue to rotate slowly, applying hand pressure on timing rod and note that the column of fuel must *JUST commence to rise* when the rod drops into the flywheel drilling. Adjust if necessary and recheck until correct.
7. REMOVE TIMING ROD FROM FLYWHEEL HOUSING. File off the timing mark on pump and scribe a new line to coincide with the mark on timing case.

Spill Timing (Dial gauge method)

1. Move the pump into the fully retarded position (release mounting nuts) then pull top of pump away from cylinder block as far as slotted holes will allow.
2. Remove injectors, blank open end of injector leak-off pipe. Place stop control in run position and throttle control in maximum speed position. Install capillary tube on to No. 1 injection port outlet. Bleed fuel system *thoroughly*. It will be necessary to rotate engine with starter motor to bleed the high pressure galleries in the injection pump.
3. Slacken the capillary tube union nut with one finger over the end of the tube. Allow fuel level to drop but still remain visible. Tighten union nut and remove finger from tube. Rotate engine in normal direction of rotation and check that there is now a fuel column with an air bubble visible in the tube (if not, repeat this operation to introduce an air bubble).
4. Remove bonnet top and valve rocker cover.
5. Turn engine until number four inlet valve commences to open (number one piston will then be at top of a compression stroke).
6. Release and unscrew adjusting screw on number one inlet valve rocker so that valve push rod can be removed.

7. Remove cotters, cup and spring from number one inlet valve. This can be done by placing a suitable socket on valve cup and giving it a sharp tap with a hammer—piston will hold valve upwards. Fit a small 'O' ring in the valve stem groove, to prevent valve accidentally dropping into cylinder.
8. Mount a dial gauge on cylinder head so that vertical movement of number one inlet valve (which is now resting on piston top) can be measured.



MEASURING VALVE MOVEMENT WITH DIAL GAUGE

9. Rotate engine slowly backwards and forwards, whilst applying a slight pressure to ensure valve is held down against piston, until T.D.C. position of piston has been found and dial gauge set to zero at this position.
10. Rotate engine in an anti-clockwise direction until piston is 0.50in (12.7mm) from T.D.C.—if piston is moved further then this inlet valve will have to be secured to prevent it falling into cylinder. An 'O' ring fitted on stem could be used.
11. Rotate engine manually in *normal direction of rotation* until dial gauge shows that piston is 0.1565in (3.975mm) before T.D.C. (this is equal to 19 degrees before T.D.C.) Prime fuel lift pump to ensure an adequate flow of fuel to the injection pump. Rotate pump body slowly towards the advanced position (top of pump towards block) until the column of fuel in capillary tube *JUST commences to rise* then tighten nuts attaching pump to timing case.
12. Check by turning engine backwards until piston is 0.50in (12.7mm) before T.D.C. then prime lift pump by hand and rotate engine slowly in its normal direction of rotation. Immediately the column of fuel in capillary tube commences to rise check piston position by noting the

dial gauge reading. This should be 0.1565in (3.975mm) before T.D.C. and if not, release pump mounting bolts and turn pump body. Clockwise (direction of engine rotation) to retard and anti-clockwise (opposite to engine rotation) to advance, then recheck.

13. When timing is correct, remove capillary tube and replace injectors. Set piston to T.D.C. to hold valve upwards, then replace valve spring cup and cotters. Refit push rod and set valve clearance. Replace valve rocker cover and bonnet top.

Cylinder Head

The cylinder head and valve gear are of orthodox construction and the usual servicing procedures apply. The valve seats are shrunk in and then secured by 'staking', at four equally spaced places, with a $\frac{1}{16}$ in (1.2 mm) square-ended punch.

Note that for the 'staking' to be effective the inserts must be recessed 0.005 - 0.010in (0.13 - 0.25mm) below the cylinder head face.

The exhaust valves are of special material to withstand the higher operating temperatures and are *not* therefore interchangeable with the inlet valves K928622. Exhaust valve K950100 can be identified by the hemispherical indentation at centre of valve head.




FIGURE A16. IDENTIFICATION OF VALVES

Pistons and Rings

The top compression ring has a chrome insert and all three compression rings are taper faced: rings must therefore be fitted so that the word 'TOP' stamped on each ring is towards the piston crown.

As the pistons have a larger combustion chamber (16:1—compression ratio) and a cast-iron insert for the top ring they are not interchangeable with 1212 pistons.

If the piston skirt marking is uneven, check connecting rods for alignment. Renew any faulty rods, do not attempt to straighten a distorted connecting rod.

Crankshaft and Bearings

Once they have run against a journal, bearing shells are not interchangeable and, if not renewed, must only be refitted in their original position. Bearing caps and shells are very accurately machined and no attempt should be made to file a bearing cap or scrape a bearing. Connecting-rod caps must only be used with their original connecting rod and main bearing caps must only be fitted to their original cylinder blocks.

Crankshaft rear bearing is sealed by an oil retainer bolted to both cap and block. Retainer is in two halves and fitted with asbestos packings which make positive contact with crankshaft. Worn or damaged packings should be renewed. Remove old packings and clean out retainer grooves. Smear one of packings with adhesive, to prevent it turning during service, then press packings carefully into retainer grooves. Roll packings into position with a smooth bar then trim ends so that they protrude 0.030in (0.76mm) above retainer face and press corners into a chamfer, so that they will not spread out between retainer faces. Clamp retainer on to a 2.620in (66.5mm) diameter mandrel to press packings into position and check that halves of retainer seat squarely together.

To ensure that there is no possibility of oil leakage between the two halves of the retainer, or between the retainer and cylinder block, refit the retainer as follows:

1. Polish crankshaft, with worn 320 grade emery cloth, to a highly polished finish.
2. Trim each half gasket so that edges will touch but not overlap. Smear retainer faces with a medium texture non-hardening jointing compound.
3. Do not fit spring washers on socket screws or setscrews, but fit copper washers and tighten in the following order:
 - (a) Tighten socket screws then unscrew half-a-turn.




FIGURE A17. CRANKSHAFT REAR OIL SEAL

- A. Check that Allen screws have sufficient clearance to permit both halves to be in line.
- B. Ensure that ends of packings do not cause gap between halves of retainer.
- C. Check mounting face for distortion and if necessary correct by filing.
 - (b) Tighten setscrews then firmly tighten socket screws.
 - (c) Unscrew all setscrews half-a-turn then retighten evenly and firmly.
 - (d) Ensure that crankcase breather is clear.
 - (e) Check that crankshaft and float is not excessive, this should be not more than 0.010in (0.25mm).

SPECIFICATIONS AND DATA—ENGINE

Tightening Torques	lb ft	kg metre
Big-end bearing nuts	50	6.92
Breather cover nut	10	1.38
Camshaft gear bolt	40	5.53
Camshaft locating plate bolts	25	3.46
Carrier plate to cylinder block bolts	25	3.46
Clutch housing to main frame bolts	75	10.5
Clutch housing to starter support bolts	30	4.15
Crankshaft pulley nut	140	19.3
Cylinder block to main frame bolts	30	4.15
Cylinder head nuts and bolts	100	13.75
Cylinder head studs into cylinder block	25	3.46
Fan blade bolts	25	3.46
Flywheel nuts	50	6.92
Injection pump drive gear nut	45	6.22
Intermediate timing gear bracket bolts	25	3.46
Main bearing cap bolts—Front	160	22.12
Main bearing cap bolts—Centre	220	30.4
Main bearing cap bolts—Rear	160	22.12
Main frame to engine bolts	30	4.15
Oil filter bowl bolt	10	1.38
Sump to main frame bolts	20	2.76
Valve rocker adjusting screw locknuts	14	1.94
Turbocharger		
Turbine shaft locknut	13	1.8
Compressor housing bolts	5	0.7
Locknut-turbine housing 'V' clamp	10	1.4

The following figures apply to bolts of standard material with either UNC or UNF threads and may be used for all nuts and bolts not listed in the previous table.

	Thread diameter (in)	lb ft	kg metre
	$\frac{1}{4}$	7	0.97
	$\frac{1}{8}$	15	2.07
	$\frac{3}{8}$	25	3.46
	$\frac{1}{2}$	45	6.22
	$\frac{3}{4}$	65	8.98
	$\frac{7}{8}$	110	15.2
	1	140	19.3
Capacities	Imperial	U.S.	Metric
Cooling system	24 pints	14½ qt	13.7 litre
Engine lubricating oil	13 pints	8 qt	7.4 litre
Steering reservoir (refill)	2½ pints	1½ qt	1.4 litre
Steering system (initial)	4½ pints	2½ qt	2.4 litre
Fuel tank	18 gal	21½ gal	81.8 litre
Transmission (refill)	9½ gal	11 gal	42.0 litre
Transmission (initial)	10½ gal	12½ gal	47.7 litre
Reduction units (per side)	13 pints	8 qt	7.4 litre

	Inches		Millimetres	
	Max	Min	Max	Min
Cylinder Block				
Cylinder bores : standard	3.9396	3.9388	100.066	100.046
" " + 0.020in	3.9596	3.9588	100.573	100.554
" " + 0.040in	3.9796	3.9788	101.081	101.062
" " : surface finish (honed)	20 to 40 micro inch C.L.A.			
Main bearing bore dia, in block	2.792	2.791	70.916	70.891
Centre main bearing width	1.686	1.684	42.824	42.774
Core plug aperture diameter	1.760	1.755	44.70	44.58
Intermediate timing gear shaft dia	1.001	1.0005	25.425	25.413
Intermediate gear shaft press fit into block	0.0012	0.0002	0.030	0.006
Camshaft				
Journal diameter — front	1.872	1.8707	47.548	47.516
" " — intermediate	1.827	1.825	46.405	46.355
" " — centre	1.8113	1.8100	46.007	45.974
" " — intermediate	1.765	1.763	44.831	44.780
" " — rear	1.7488	1.7475	44.419	44.387
Bearing clearance— front, centre and rear	0.0035	0.0015	0.088	0.039
" " — front intermediate	0.019	0.012	0.482	0.305
" " — rear intermediate	0.017	0.010	0.432	0.254
Inlet cam overall diameter	1.450	(nom)	36.830	(nom)
Inlet cam lift	0.290	"	7.366	"
Exhaust cam overall diameter	1.410	"	35.814	"
Exhaust cam lift	0.250	"	6.350	"
End float—camshaft	0.020	0.010	0.508	0.254
Lubricating Oil Pump				
Spindle length	15 $\frac{1}{2}$	(nom)	390.5	(nom)
Bracket length	10 $\frac{1}{2}$	"	262	"
Housing depth	1 $\frac{1}{2}$	"	34.9	"
Spindle bush bore (installed)	0.4925	0.4905	12.509	12.459
Spindle clearance	0.003	0.0005	0.076	0.013
Rotor width	1.374	1.373	34.899	34.875
Rotor end float	0.0035	0.001	0.088	0.026
Rotor teeth backlash	0.026	0.020	0.66	0.51
Oil pressure (engine hot)				
At 1800 rev/min (lb/in ²)	55	45		
" " " (kg/cm ²)	—	—	3.8	3.1
At 700 rev/min (lb/in ²)	—	30		2.1
" " " (kg/cm ²)	—	—		
Filter by-pass valve setting (back press lb/in ²)	20	15		
" " " " " " " (kg/cm ²)			1.4	1.1
Oil warning switch pressure setting (lb/in ²)	13	9		
" " " " " " " (kg/cm ²)			0.9	0.6

	Inches		Millimetres	
	Max	Min	Max	Min
Pistons & Piston Rings				
Piston skirt diameter—measured $\frac{1}{2}$ in above, or below, scraper ring groove and at 90° to gudgeon pin axis	3.932	(nom)	99.87	(nom)
Piston skirt ovality	0.006	"	0.15	"
Piston ring groove width—compression	0.097	0.096	2.463	2.438
" " " " scraper	0.190	0.189	4.826	4.801
Piston ring width—compression	0.0937	0.0928	2.379	2.358
" " " " scraper	0.1875	0.1865	4.762	4.737
Piston ring gap—new (all rings)	0.016	0.011	0.40	0.28
Piston ring clearance in groove—compression	0.004	0.002	0.102	0.051
" " " " scraper	0.0035	0.0015	0.089	0.038
Piston height—gudgeon pin axis to top of crown	2.375	(nom)	60.3	(nom)
Valve recess diameter in piston crown	1.580	"	40.1	"
Valve recess depth in piston crown	0.218	"	5.54	"
Combustion chamber diameter	2 $\frac{1}{16}$	"	58.7	"
Gudgeon pin diameter	1.2500	1.2498	31.75	31.745
Connecting Rods				
Length—centre small end to centre big end	7.875	(nom)	200.0	(nom)
Width	1.492	1.490	37.89	37.846
Diameter, small end—bush removed	1.4382	1.4372	36.53	36.505
" " " " bush fitted and reamed	1.2515	1.2505	31.788	31.763
Clearance, small end bush to gudgeon pin	0.0017	0.0005	0.431	0.013
Diameter, big end—bearings removed	2.6455	2.6445	67.195	67.171
Alignment, max. out of parallel or twist per inch of checking mandrel length	0.0005	—	—	—
Per 100mm of checking mandrel length	—	—	0.05	—
Crankshaft				
Identification stamped on front end of shaft	55T			
Main bearing journal diameter : Standard	2.6245	2.6240	66.662	66.650
" " " " : 0.010 in	2.6145	2.6140	66.408	66.396
" " " " : 0.020 in	2.6045	2.6040	66.154	66.142
Thrust face width : Standard	1.876	1.874	47.650	47.600
" " " " —0.010 in	1.886	1.884	47.904	47.854
" " " " —0.040 in	1.916	1.914	48.666	48.616
Big end journal diameter : Standard	2.4985	2.4980	63.461	63.450
" " " " : 0.010 in	2.4885	2.4880	63.207	63.196
" " " " : 0.020 in	2.4785	2.4780	62.953	62.942
Big end journal width	1.5015	1.4995	38.13	38.09
Fillet radii—all journals	0.160	0.150	4.06	3.81
Alignment : Max. dial gauge reading, when placed against centre journal	0.004	—	0.10	—
Journal finish—max. CLA reading	10 micro inch			
Diameter of rear journal oil seal land	2.524	2.519	64.649	64.523
Bearing thickness (standard) — mains	0.082	(nom)	2.08	(nom)
" " " " — big ends	0.072	"	1.83	"
" " " " — thrust washers	0.092	"	2.34	"
Bearing width—mains	1.50	"	38.100	"
" " " " —big ends	1.15	"	29.210	"
Bearing clearance—mains	0.004	0.002	0.102	0.051
" " " " —big ends	0.004	0.002	0.102	0.051
End float—centre main bearing	0.010	0.002	0.254	0.051
Side clearance—big end bearings	0.0115	0.0075	0.292	0.191

Valve Mechanism	Inches		Millimetres	
	Max	Min	Max	Min
Valve head diameter (inlet and exhaust)	1.5	(nom)	38	(nom)
Valve seat angle	45		45	
Valve length—overall (inlet and exhaust)	0.890	(nom)	124.0	(nom)
Valve stem diameter	0.3732	0.3722	9.479	9.451
Valve guide bore	0.3755	0.3745	9.537	9.512
Valve guide clearance	0.0033	0.0013	0.0838	0.033
Seat insert diameter	1.631	1.630	41.427	41.02
Seat insert thickness (inlet) *	0.160	0.155	4.064	4.038
" " " (exhaust) *	0.150	0.148	3.810	3.760
Insert seat angle		45		45
Insert seat width	0.055	0.045	1.397	1.143
Insert counterbore diameter in cylinder head	1.626	1.625	40.792	40.767
Insert counterbore depth in cylinder head *	0.159	0.156	4.038	3.962

Inserts shrunk in with "Drikold" then cylinder head face ground *

Secure all inserts with four indentations spaced 90° apart $\frac{1}{16} \times \frac{1}{16}$ 1.60 x 1.60

*See text under 'Cylinder Head'.

Valve tappet diameter	0.624	0.623	15.825	15.649
Valve tappet clearance in cylinder block	0.003	0.001	0.076	0.026

Water Pump

Bearing bore diameter in housing	1.1808	1.1798	29.992	29.967
Clearance — impeller to body	0.005	(nom)	0.13	(nom)
Thermostat — starts opening	181 F	174 F	83 C	79 C
" — fully open	205 F	199 F	96 C	93 C

Fuel Injection Pump

Maximum fuel setting—Injection pump P5169AS. (Temporary data, subject to amendment.)

Use CAV test sheet P5169 Issue 2, but set maximum fuel to 18.0ccs MAX per 200 shots at 800 pump rev/min, on a Hartridge 800 or 1100 test machine.

Injectors—Use only CAV injectors, part number 5253807 with BDLL 140S 6592F nozzles. If these are not available select reconditioned injectors with BDLL 140S 6592 nozzles and ensure the following test figures are complied with.

Pressure test—Adjust springs to give breaking pressure of 190 Ats (196 kg/cm²) (2793 lb/in²) with new springs or 180 Ats (186 kg/cm²) (2646 lb/in²) with used springs.

Back leakage test—Leak past between needle and nozzle bore (with drytip) from 150 to 100 Ats (154 to 104 kg/cm²) (2205 to 1470 lb/in²) must be 5 to 15 seconds. Nozzles with a slower leak rate, e.g. 15 to 25 seconds, will be subject to sticking, causing intermittent black smoke and power loss.

TRANSMISSION—1412 TRACTORS

HOW IT WORKS

The 1412 transmission is identical in operation to the 1212 Hydra-Shift tractor transmission. The only constructional differences being changes to range gearbox ratios, a four-pinion differential and a larger differential-lock sleeve.

UNIT REMOVAL AND REPLACEMENT

As the clutch driveshaft is integral with the gearbox it is necessary to 'split' the tractor when removing the gearbox.

For gearbox servicing the easiest method of 'splitting' the tractor is to separate the rear axle from the main frame, after removing the Quiet cab when fitted.

To remove the four-speed (Hydra-Shift) section only, the rear axle can be removed complete with reduction units and gearbox attached, the four-speed section can then be removed without detaching the range section from the rear axle.

To remove the range section, or complete gearbox, the reduction units must first be removed then the rear axle case removed whilst the gearbox remains in situ. The complete gearbox can be withdrawn rearwards and the range and four-speed sections separated.

Removing the four-speed (Hydra-Shift) section

First clean the outside of clutch housing, gearbox top, rear axle, main frame and power take-off unit. When tractor is clean and this is important otherwise dirt may enter the main frame and affect the hydraulic system after re-assembly, move tractor on to a piece of clean, firm and level ground.

Drain transmission oil into clean containers, capacity approx. 10½ gallons (47.7 litres), by removing drain plugs from main frame and rear axle case.

Remove silencer and bonnet top. Disconnect wiring, throttle and gear change linkage, so that fuel tank can be removed with instrument panel attached: if fuel tank is full drain some fuel off as a full tank is very heavy.

Disconnect steering pipes from servo valve then remove steering column complete with mounting brackets: taking care not to damage Hydra-Shift valve spool.

Remove gearbox cover bolts, some of these pass through front of cover into clutch housing and others come through rear axle case, then lift off cover; this is heavy and must be guided round the steering pipes.




FIGURE C1. TRACTOR 'SPLIT' FOR GEARBOX REMOVAL

9-38127

C1

Remove the gearbox rear mounting bolts and withdraw the two locating bushes.

Remove the Hydra-Shift oil filter screen

This is situated on underside of main frame adjacent to the hydraulic system oil filter.

Disconnect and remove the rear half of the hydraulic pump-to-distributor block oil feed pipe. Remove drawbar frame and drawbar. Remove seat and seat support bracket.

Disconnect and remove pipe to hydraulic take-off coupling then remove sensing unit.

Remove power take-off unit and withdraw cardan shaft from gearbox.

Bolt the two support legs to the tractor frame and bolt the steady bracket on the front face of rear axle. This bracket is to hold the gearbox and axle case at right-angles and the two setscrews must be screwed down until they come into contact with the gearbox mounting lugs.

Remove all bolts attaching rear axle case to main frame and remove the bolts attaching fenders to footplates. Disconnect both brake rods. Fit the lifting bracket on to gearbox and using a suitable portable crane or gantry, support the weight of the gearbox so that the rear axle can be pushed off its dowels and the two halves separated far enough apart to allow sufficient working room.

To separate Hydra-Shift section from range section

Place a suitable support under the front end-plate of range section, so that gearbox remains level when crane is lowered.

Remove oil pipe connecting pump to control valve then remove control valve.

Place a sling round the Hydra-Shift section and take the weight but do not lift it. Remove the four front end-plate nuts but do not remove the two setscrews.

Separate the two sections by *levering the rear planet carrier forward* until it is clear of the range section then slide the complete Hydra-Shift section forward off the four long studs.




FIGURE C2. GEARBOX TO REAR AXLE STEADY BRACKET

- | | |
|-----------------|---|
| A. 1in (25.4mm) | G. 12½in (324mm) |
| B. 7¼in (200mm) | H. 15½in (400mm) |
| C. ¾in (15.8mm) | J. Drill ¾in (15.8mm) dia. |
| D. 2in (50mm) | K. To rear axle case |
| E. 3in (75mm) | L. Drill ¾in (15.8mm) dia. |
| F. 1½in (38mm) | weld ¾in nuts underneath plate to align with holes. |

To refit the Hydra-Shift section.

As it is necessary to turn the rear planet carrier, to engage it into the freewheel, when fitting the two halves together, the rear brake band must be pushed into the disengaged position. This can be done with oil, or air provided that it is free of water droplets and does not exceed 80 lb/in² (5.6 kg/cm²).

Remove the rear clutch pipe, complete with sequence valve then replace the control valve. Screw a suitable adaptor into the control valve connection normally occupied by the rear clutch pipe, so that oil or air pressure can be applied.

Lift the section on to the four long studs, using a crane and sling to support the weight as during removal. Slide the section rearwards whilst turning input shaft to engage the rear planetary unit on to the range gearbox splines. When gap is reduced to half-an-inch (25mm) place valve spool in upper (1st gear) position and apply pressure through adaptor until rear brake band is released. Whilst maintaining pressure to hold brake band 'off', rotate carrier in direction of engine rotation and push the two sections together, starting the threads on pump outlet pipe union at the same time.

When sections are 'fully home' check that carrier can be turned in direction of engine rotation but cannot be turned in opposite direction then release pressure. Remove adaptor, refit clutch pipe and replace the four stud nuts. Fully tighten pump outlet pipe union.

If air is used to pressurise the brake cylinder this will introduce air into the system which can cause temporary difficulty in engaging third and fourth gears. The system will however vent itself if engine is run at a fast idling speed and the gear lever moved slowly but continuously between second and third gear positions.

Before commencing to re-assemble the tractor, remove the hydraulic system filter and clean out the main frame.

Smear axle case face with jointing compound then fit a new gasket into position.

Screw four $\frac{3}{8}$ UNC guide studs into axle case: two at top and two at bottom. Do not make the guide studs the same length but let them vary by about $\frac{1}{2}$ in. (6mm) so that they don't all have to be entered into the main frame holes at the same time.

Smear support snout and clutch shaft splines with grease then bring the two halves of the tractor together. *Ensure that gearbox is level and in line with main frame and don't forget that clutch shaft splines will have to be aligned with clutch plate splines. Carefully lever one of the front planet pinions round until it becomes solid, which shows that shaft has entered into clutch plate.*

As the two halves are being brought together ensure that hand brake operating lever enters the hand lever fork and the diff-lock pedal is positioned to engage underneath the operating lever on rear axle. Also check that the gearbox lubricating oil pipe enters its feed pipe in axle case. Check that axle and frame faces are parallel and engage the guide studs. Continue bringing the two halves together until bolts can be fitted to pull frame on to dowels. Do not use more force to bring the two halves together than was required to separate them: *if the two halves are correctly aligned excessive force will not be necessary.*

When axle case is 'fully home' check that diff-lock pedal is engaged under operating lever on axle case then remove guide studs, refit and fully tighten main frame bolts.

Remove lifting bracket and axle steady bracket. Replace gearbox mounting bushes and bolts, and check that gearbox lubricating pipe is correctly connected. Fit new gaskets on main frame then replace gearbox cover, passing it under steering pipes and ensuring that range gear lever is correctly engaged in its selectors. Lightly tighten bolts into main frame then fully tighten bolts through axle case. Finally fully tighten bolts down into main frame before replacing wedge. Tap the wedge into position then replace and tighten bolts into clutch housing.

Push Hydra-Shift valve into its lowest position then replace steering column, complete with servo valve and bracket. Refit starter safety switch harness.

Smear splined end of cardan shaft with grease then fit shaft through gearbox and into clutch. Turn shaft until it is felt to engage in clutch plate splines then push shaft into flywheel spigot bearing.

Tap the two dowels back into the power take-off case then screw two guide studs into axle case. Fit a new gasket on axle case, using a thin film of grease to hold it in position, then replace power take-off unit. Turn output shaft until it is engaged on cardan shaft splines then push unit 'home' and loosely fit retaining bolts. Tap the two dowels into axle case then remove guide studs and fully tighten the bolts.

Replace Selectamatic oil filter and also the Hydra-Shift filter. Refill transmission with oil; this is easier if poured through top of PTO case before sensing unit is refitted.

Reconnect and adjust brakes. Refit drawbar frame. Rebolt fenders to footplates, fitting the plastic strip between them.

Before starting the engine, refill the steering reservoir with clean oil and when engine is running vent the system. Top up the oil reservoir after stopping engine.

Removing the Complete Gearbox (or range section)

After thoroughly cleaning the gearbox cover, rear axle case, power take-off unit and reduction units, to minimise the possibility of dirt entering the main frame and affecting the hydraulic system after re-assembly, move tractor to a piece of firm and level ground.

Remove drawbar frame then raise rear of tractor and remove both rear wheels.

Remove fenders, seat and seat support bracket, not 'Q' cab tractors.

Drain oil from reduction units and, using suitable lifting tackle, withdraw both units.

Drain transmission oil into clean containers by removing drain plugs from filter housing and rear axle case, approximate capacity 10 $\frac{1}{2}$ gallons (47.7 litres). Remove bonnet top. Disconnect wiring, throttle and gear change lever so that fuel tank can be removed with instrument panel attached.

Disconnect and remove the rear half of the pump-to-distributor block oil pipe.

Disconnect and remove pipe to hydraulic take-off coupling then remove sensing unit. Remove power take-off unit and withdraw cardan shaft from gearbox.

Place suitable supports under rear of main frame and place a sling round the ramshaft so that a portable crane can be used to remove the axle case.

Remove the bolts attaching axle case to main frame and whilst supporting axle weight on crane, push axle off its dowels. As the diff-lock spring must remain in the differential, but the sleeve removed with the axle case, it will be necessary to hold the spring compressed with a tyre lever, or similar flat bar until the front flange of axle case has passed over spring.

When axle is clear of differential spring, lift it clear and lower it to ground.

Disconnect steering pipes from servo valve then remove steering column complete with mounting bracket. Push Hydra-Shift valve downwards to avoid it being damaged when steering column is removed.

Remove the gearbox cover bolts: some of these pass through front of cover into clutch housing and others come through the rear axle case, then lift off the cover: this is quite heavy and must be passed round the steering pipes. Remove the gearbox mounting bolts and withdraw the bushes. Remove

the Hydra-Shift oil filter screen: this is situated adjacent to the hydraulic system oil filter.

Fit lifting bracket on gearbox and using crane to support but not lift the gearbox, withdraw complete gearbox rearwards.

Refitting the complete gearbox

Remove all traces of gaskets from axle and main frame faces, clean out main frame and inside of axle case. Remove element from Selectamatic oil filter.

Smear support snout and shaft splines with grease then lift gearbox, ensuring that it hangs level. Slide gearbox into position, carefully rotating the front planetary gear so that driveshaft is turned until it engages into clutch plate splines. When gearbox is located over its mounting holes replace locating bushes and bolts.

Ensure that the diff-lock sleeve is positioned inside the rear axle case and the sleeve spring is in the differential.

Lift the axle assembly so that it hangs vertical and swing it into position towards the main frame. Insert a piece of flat bar, such as a tyre lever, through axle case so that spring can be compressed into differential whilst front flange of axle case is passed over it.

When axle is past diff-lock spring, lift handbrake operating lever into hand lever fork and position diff-lock pedal so that it will be underneath operating lever in axle case. As axle is engaged on the dowels ensure that the gearbox lubricating oil pipe is correctly located in its feed pipe inside axle.




FIGURE C3. LIFTING BRACKET - GEARBOX

- | | |
|--|---------------------------------------|
| A. 8in (203.2mm) | E. 9in (228.6mm) |
| B. Bolt, $\frac{1}{2}$ UNC x $4\frac{1}{2}$ in | F. $\frac{3}{4}$ in (19.0mm) diameter |
| C. 3in (76.2mm) | G. $3\frac{1}{2}$ in (88.9mm) |
| D. $24\frac{1}{2}$ in (621.3mm) | |

After fully tightening axle case bolts, push the diff-lock sleeve against its spring and engage the pedal fork in sleeve groove. Refit both reduction units, fitting the brake cam levers on camshafts before units are pushed 'fully home'.

Smear splined end of cardan shaft with grease then slide it through gearbox. Turn shaft to engage it in clutch plate splines then push shaft into flywheel spigot bearing. Refit power take-off unit, using a new gasket.

Fit new gaskets on main frame, then replace gearbox cover. Passing it round steering pipes and ensuring that range gear lever is correctly engaged in its selectors. Lightly tighten cover bolts down into frame then firmly tighten bolts through axle case before fully tightening main frame bolts. Finally fit wedge and shims between cover and clutch housing then firmly tighten clutch housing bolts.

Replace the Selectamatic and Hydra-Shift oil filters. Refit the distributor block feed pipe. Fill transmission with oil, this is best done by pouring it into the PTO case before replacing sensing unit.

Replace Quiet cab if fitted, otherwise replace steering column and fuel tank. Refill reduction units with oil, replace fenders and drawbar

Before starting engine, refill the steering reservoir with clean oil and when engine is running vent the steering system. Top up oil reservoir after stopping engine.

Removing Differential Assembly

After removing the rear axle case, as for complete gearbox removal, mark the two bearing caps then unlock the tab-washers and release the four bolts. Whilst supporting the differential this is quite heavy, remove the bolts, bearing caps and adjusters then lift the differential off gearbox end plate.

Replacing the differential

First check the marks made on the bearing caps so that caps will be refitted in their original position, then lift the assembly on to the end plate, crown wheel on right-hand side of pinion. Replace bearing caps and screw bearing adjusters into position before tightening cap bolts.

Adjusting differential bearing end-float

To ensure the correct setting is obtained the following precautions must be observed.

1. Always loosen the cap bolts before turning the bearing adjusters.
2. Before tightening the cap bolts, after turning the bearing adjusters, strike the caps a sharp blow with a copper hammer to re-align the bearings, then tighten the bolts.
3. Always check bearings for free rotation or drag with the cap bolts tight.




FIGURE C4. DIFFERENTIAL ASSEMBLY

Adjustment sequence:

Fully unscrew right-hand bearing adjuster and screw left-hand adjuster inwards to push diff cage as far as possible to the right, so that maximum backlash is obtained between crown wheel and pinion teeth.

Tighten right-hand adjuster until the bearings have a slight drag. This can be established by placing a plastic-handled screwdriver, with a 12in (30cm) blade across two of the diff-cage bolts. If the screwdriver is horizontal and its weight is sufficient to turn the cage, within the limit of the teeth backlash, end play is present but if screwdriver does not turn the cage the bearings have drag.

Unscrew the right-hand adjuster half-a-turn and check for drag. Repeat this operation—ensuring that precautions 1, 2 and 3 are observed—until the weight of the screwdriver is just sufficient to rotate the diff cage. To ensure no tight spots exist, check for rotation at three equi-distant positions.

Having obtained the correct bearing setting, clearly mark the position of the two bearing adjusters then turn both adjusters an equal amount (left-hand outwards and right-hand inwards) until backlash between crown wheel and pinions is reduced to 0.007 to 0.009in (0.18 to 0.23mm). Check the backlash at three equally spaced teeth and if readings vary slightly use the smallest reading. Mark tooth with smallest reading and take all subsequent readings from this tooth. Measure the backlash with a dial gauge mounted at right angles to a crown wheel tooth and when correct tighten cap bolts to 120 lb ft (16.6 kg metre). Recheck tooth backlash after tightening bolts, re-adjust if necessary then lock clamp bolts with tabwashers and bearing adjusters with the locking plates.

Differential-lock Sleeve Removal

The differential-lock sleeve cannot be removed through the right-hand side of the axle case and it is, therefore necessary to remove the reduction units and rear axle case, as during gearbox removal. The sleeve can then be extracted through the centre of the rear axle case.

UNIT MAINTENANCE AND REPAIR

Dismantling Differential Assembly

Mark both halves of differential cage then unlock and remove the twelve bolts. Separate end plate and remove crown wheel then 'Split' the cage and remove the bevel gears.

The side bearings are pressed into position and should not be removed unless they are to be renewed. If the side bearings are renewed ensure that the new bearings are fitted the correct way round; they are angular contact bearings and *must* be fitted so that the word THRUST stamped on the outer track will be against the bearing adjuster (Fig C4).

Re-assembling differential

With the side bearings in position and diff-lock gear ring secured with its circlip, place end plate, crown wheel and half the diff cage on bench, using two bolts to align holes. Fit bevel gear, with thrust washer underneath it, in cage. Smear spider arms and spherical faces of bevel pinions with anti-scuffing paste then fit pinions on spider and place spider in case. Fit remaining bevel gear, with thrust washer on it, then fit other half of cage; assembly marks in line. Replace bolts, from crown wheel side, fit new tabwashers and tighten nuts evenly to 75 lb ft (10 kg metre) then securely lock with the tabwashers.




FIGURE C5. COMPONENTS OF DIFFERENTIAL

9-38127

C5

SPECIFICATIONS AND DATA—TRANSMISSION

Tightening Torques	Thread dia.	lb ft	kg metre
Brake band cylinder bolts	$\frac{1}{4}$ in	20	2.75
Clutch cover-to-main-frame bolts	$\frac{1}{2}$ in	75	10.5
Clutch cylinder to planet carrier bolts	$\frac{1}{4}$ in	20	2.75
Diff. ring nut locking plate bolts	$\frac{1}{4}$ in	20	2.75
Transmission pump to connection	$\frac{1}{4}$ in	20	2.75
Diff. cap bolts	$\frac{1}{2}$ in	120	16.5
Free-wheel housing bolts (2nd reduction)	$\frac{1}{2}$ in	30	4.0
Front end-plate nuts	$\frac{1}{2}$ in	75	10.5
Gearbox cover to main frame bolts	$\frac{1}{2}$ in	75	10.5
Gearbox mounting bolts	$\frac{3}{8}$ in	100	13.75
Pinion bearing support plate bolt	$\frac{3}{8}$ in	30	4.00
Pinion nut	$1\frac{1}{4}$ in	200	27.5
Planet carrier end-cover bolts	$\frac{3}{8}$ in	30	4.00
Range unit end-plate bolt	$\frac{3}{8}$ in	30	4.00
Rear axle case to main frame bolts	$\frac{1}{2}$ in	75	10.5
Rear wheel nuts	$\frac{3}{4}$ in	150	19.5
Reduction units to axle case bolts	$\frac{1}{2}$ in	75	10.5
Support sleeve cap bolts	$\frac{1}{2}$ in	9	1.25
Support snout bolts	$\frac{1}{2}$ in	9	1.25

Pinion shaft bearing setting

0.002in (0.050mm) preload to

0.002in (0.050mm) end-float

Crown wheel teeth backlash

0.007 - 0.009in (0.18 - 0.23mm)

Differential side bearing setting

no pre-load to

0.002in (0.050mm) end-float

Layshaft bearing end-float

0.002 - 0.004in (0.05 - 0.10 mm)

Oil pump relief valve setting

70 lb/in² (4.9 kg/cm²)

Pinion shaft setting distance

6.3125in (160.337mm)

Special tools

DB8440 Connector and Adaptors—comprising

DB8440/1 main connector

DB8440/2 right angle special adaptor

DB8440/3 male/male adaptor

DB8267 Pressure Gauge 0 - 100 lb/in² (0 - 7 kg/cm²)

DB8208 Pinion Setting Gauge

83
Z71825

HOW IT WORKS—FINAL DRIVE REDUCTION UNITS

Bolted to the ends of the rear axle case the final drive reduction units consist of a housing which contain the final driveshafts, spur pinion shafts and disc brake assemblies.

The spur pinion shafts are splined into the differential at their inner ends and supported by tapered roller bearings in the reduction housings at their outer ends. The spur pinions are integral with their shafts and in permanent mesh with drive gears on the final driveshafts. As the wheels are bolted to the final driveshafts the spur pinion shafts must always revolve with the wheels. To permit the final drive gears to spread the load equally across the full width of the teeth the final drive-shaft gear is not rigidly attached to the driveshaft but is carried on crown-shaved splines and located between two circlips.

Final Driveshaft Oil Seal

This consists of an external dirt shield and two oil seals. The outer oil seal has a double lip and the inner seal a single lip. Grease will therefore pass the inner seal more easily than the outer seal.

Lubrication of the outer driveshaft bearing is by means of grease, which can be pumped into the cavity between the seals through the grease nipple at rear of housing.

In service it is only necessary to pump two shots of grease through housing nipple at 60-hour intervals.

The disc brake units are also enclosed in the reduction unit oil bath and operate on the spur pinion shafts.




FIGURE D1. FINAL DRIVE REDUCTION GEARS

UNIT REMOVAL AND REPLACEMENT

Reduction Unit

Raise rear of tractor, place suitable supports under hitch brackets and remove wheel. Drain oil from reduction unit and remove the three bolts attaching fender support to reduction case, otherwise raise rear of Quiet cab.

If right-hand reduction unit is being removed, depress differential lock pedal and wire lever, or rear end of pedal upwards in engaged position, so that diff-lock sleeve is held in engagement and will not be displaced when reduction unit is withdrawn.

Disconnect brake rod and remove nut from cam lever cotter pin. Tap pin free then tap cam lever towards end of shaft, to make sure that it is free.

Remove nuts from axle case flange then pass a sling round reduction so that a portable crane can be used to support reduction. If fender has been removed the lifting bracket shown in figure D2 can be used. Do not attempt to remove reduction without equipment to support it: the unit weighs approx. 500 lb (225 kg).

Whilst supporting the weight but not lifting the unit, first lever unit off dowels then pull unit horizontally away from

rear axle whilst pushing brake camshaft away so that it is withdrawn with reduction.

Remove unit horizontally until spur pinion shaft is clear of axle case: taking care not to damage oil seal in axle case housing.

To replace a reduction unit, first ensure that the large 'O' ring is fitted in reduction case recess and smaller 'O' ring is fitted against camshaft bush in axle case, then smear camshaft bushes with grease.

Raise unit with lifting equipment so that it hangs with spur pinion shaft level. Use lifting bracket if fender is removed, otherwise use a suitable sling and after entering spur pinion shaft into axle case, push unit inwards and enter brake camshaft into axle case. Turn final driveshaft until shaft splines enter differential and before dowels are reached slide cam lever onto camshaft. Fit cotter pin through cam lever, with nut slack, then slide lever onto shaft: there is insufficient room to do this when unit is "fully home".

When case has been pushed onto dowels, replace axle case nuts and fender bolts. Slide cam lever as far as possible onto camshaft then tighten cotter pin, refit brake rod and adjust. Refill unit with new oil of the recommended grade. Refit rear of Quiet cab, if fitted.

Replace wheel and lower tractor to ground.




FIGURE D2. LIFTING BRACKET - REDUCTION UNIT

UNIT MAINTENANCE AND REPAIR

Maintenance

Each final drive unit has its own oil reservoir, which should be maintained to the filler/level plug with the recommended grade of oil. The final driveshaft outer bearings are grease lubricated and require a few shots of grease pumping through the nipples in rear of oil seal housings every 60 hours.

Final Driveshaft

This may be removed without removing reduction unit. Raise rear of tractor and place suitable supports under hitch brackets. Remove wheel and drain oil from reduction case. Remove cover from rear of case and lift circlip from its groove at inner end of driveshaft. Remove bolts attaching seal housing to case, these are accessible through holes in driveshaft flange, then lever shaft and housing away from case. As gear and circlip will remain in case whilst shaft is withdrawn it will be necessary to lever inner bearing off shaft with a large screwdriver, otherwise bearing rollers could be pushed out of cage as bearing is jammed against gear.

Having withdrawn shaft and housing, remove gear, circlip and bearing from case.

To remove shaft seals and outer bearing, first slide circlip off shaft then remove locking screw from shaft lock ring. After unscrewing locking, with special spanner (Service Tool DB8009), support housing whilst pressing shaft out of bearing, alternatively screw two extractor bolts (Service Tool 900207) through holes in shaft flange—having first screwed a $\frac{1}{2}$ BSF tap through shaft holes to clean up threads—and tighten bolts to push housing off shaft. Remove seals by prising them out of housing; discard seals as they will be damaged by removal.

Replacing final driveshaft

If the collar has been removed from shaft, replace this, ensuring that the thin 'O' ring is first fitted on shaft. Replace bearing in housing then press inner seal into housing recess, ensuring that lip is towards outside of housing and seal is not distorted. Turn housing over and press outer seal in position also positioning seal lip towards outside and taking care not to distort seal.

Pack inside of seals and bearing with HMP grease then push shaft, complete with collar and dirt shield, into housing. Hold




FIGURE D3. FINAL DRIVESHAFT AND BEARINGS

shaft flange in vice and screw locking ring on shaft; ensure that dirt shield is located on collar shoulder then tighten locking ring to clamp assembly firmly together. After firmly tightening locking ring with special spanner, smear locking screw with Loctite (grade 270) then fit screw into collar hole which is opposite a spline groove. Ensure surface of locking ring is not damaged as this would damage oil seal. Replace shaft circlip and ensure 'O' ring is fitted on seal housing.

Smear shaft inner bearing with grease then place bearing in case. Place gear inside case and fit shaft through case and gear. Fit circlip on shaft and enter shaft into bearing. Position seal housing so that grease nipple is pointing directly towards rear and replace three housing bolts: do not fit shims at this stage.

Tighten housing bolts evenly to push shaft into bearing and after ensuring that bearing is seated against shaft shoulder strike centre of shaft flange with a soft-faced hammer, to settle bearing.

Driveshaft bearing setting

With shaft in position and inner bearing fully seated tighten the three housing bolts evenly until shaft bearings become tight enough to prevent shaft being 'rocked' against gear backlash. Do not overtighten bolts and distort flange but tighten evenly so that when a feeler gauge is inserted at three equally spaced points, the gap is equal all the way round.

Having measured the gap between housing and case select shims 0.005in (0.127mm) less than gap. Remove bolts, lever housing away from case and fit shims. Replace all six bolts, tighten evenly and fully. The shaft bearings will then have the required pre-load.

Having fully tightened housing bolts, check that circlip is placed in shaft groove at inside of gear then pump grease through housing nipple until seal cavity is filled and grease is forced passed seal on inside of housing.

Refit cover, using a new gasket and refill unit with the recommended grade of oil. Refit road wheel and lower tractor to ground.

Dismantling Reduction Unit

Lay unit on floor so that it is resting on final driveshaft flange and pinion shaft is pointing upwards.

Remove small cover plate from reduction inner housing. This will expose the special shouldered clevis pin which should be removed; pin should not be tight but is tapped $\frac{1}{2}$ UNC so that a bolt can be screwed in to assist extraction. Remove the thirteen bolts attaching inner housing to reduction case then lift housing off: connecting link must be removed with housing but pivot lever remains in case and it may be necessary to release adjusting nut, to prevent lever fouling housing.




FIGURE D4. REMOVING REDUCTION CASE HOUSING

After removing inner housing to expose brake mechanism, remove circlip from brake links then lift off brake discs, noting order. Remove brake actuator then remove remaining plates, also placing them on bench in order of removal.

Remove cover from case then lift assembly onto bench, or a suitable packing case.

Lift circlip from its groove at inner end of drive-shaft then remove oil seal housing bolts: these are accessible through holes in driveshaft flange.

Pull shaft out of housing and gear but lever the inner bearing off shaft at same time: otherwise tapered rollers may be pushed out of cage by gear. After extracting shaft, remove gear, circlip and bearing from inside case.

To dismantle final driveshaft, remove grub screw from shaft locking ring then unscrew locking ring—this is right-hand thread—with special spanner.

Clean threads in shaft extraction holes, by screwing a $\frac{1}{2}$ BSF tap through holes, then screw two extraction bolts (Service Tool K900207) through shaft holes.* Place two flat pieces of metal across housing flange, to protect extractor bolts from damage, then tighten extractor bolts evenly to push housing and bearing off shaft. An alternative method is to support housing with two flat plates across bed of a press then press shaft out of housing.

* Later tractors do not have these holes. For these tractors it is necessary to fabricate a jacking plate, Fig. D6. This should be used in conjunction with extraction bolts (K900207) as shown, Fig. D7.




FIGURE D5. REDUCTION UNIT ASSEMBLY

To remove bearing from housing, lever out seals and discard—seals will be distorted by removal and should be renewed—then press bearing out of housing.

Spur Pinion Shaft Removal

Having removed brake mechanism and final driveshaft, remove circlip from spur pinion bearing cover then tap splined end of pinion with a soft-faced hammer or wooden block, to push shaft, outer bearing and cover out of case.

Outer track of inner bearing will remain in case and can be removed by tapping inwards with a soft drift.




FIGURE D6. JACKING PLATE—FINAL DRIVES

- A. 114.3mm ($4\frac{1}{2}$ in)
- B. 57.1mm ($2\frac{1}{4}$ in)
- C. 93.7mm ($3\frac{3}{4}$ in)
- D. 38.9mm ($1\frac{1}{2}$ in)
- E. 85.7mm ($3\frac{3}{4}$ in)
- J. Drill 4 holes 20.5mm ($\frac{13}{16}$ in) ϕ
- L. Drill 2 holes 11.1mm ($\frac{7}{16}$ in) ϕ and tap $\frac{1}{4}$ -16 BSF*

* Alternatively if BSF taps are not available, thread to suit jacking bolts, minimum 20mm ($\frac{3}{4}$ in) ϕ .




FIGURE D7—EXTRACTING FINAL DRIVES

Brake disc hub is keyed to spur pinion shaft and provided with a groove for extraction purposes.

To remove hub make plate to dimensions shown in figure D6 then attach plate to end of brake drum extractor (Service Tool K960618).

When refitting a hub ensure that bearing, distance piece and both keys are already on shaft; position hub with chamfered end of keyways towards gear then press hub hard against distance piece.

Replacing Spur Pinion Shaft

Ensure that track of inner bearing is in case bore, smear bearings with grease and fit shaft into case. Replace track of outer bearing then refit 'O' ring in case bore. Replace shims and cover before refitting circlip. As shaft bearings should have a pre-load, turn shaft to settle bearings then check that there is no end float: if there is, remove circlip and fit additional shims under cover. Ensure that cover circlip is correctly fitted in its groove.

Replacing Final Driveshaft

If collar has been removed from shaft, replace this, ensuring that the thin 'O' ring is first fitted on shaft. Replace bearing in housing then press inner seal into housing recess: ensure bearing is not distorted by being pressed into position and seal lip is towards outside of housing. Turn housing over and carefully press outer seal into position, also positioned with seal lip towards outside of housing and taking care not to distort seal.

Pack cavity inside seals with HMP grease, wipe inside of dirt shield then push housing onto driveshaft. Hold shaft flange

in vice and screw locking ring on shaft: ensure that dirt shield is located on collar shoulder then tighten locking ring to clamp whole assembly together. Firmly tighten locking ring with special spanner, smear locking screw with Loctite (grade 270) then fit screw into the hole which comes opposite a spline groove. Firmly tighten locking screw. Replace circlip in shaft outer groove and fit 'O' ring into housing groove.

Smear shaft inner bearing with grease then fit bearing into case. Place gear inside case and fit shaft through case gear. Fit circlip on shaft end then fit shaft into bearing. Position seal housing so that grease nipple is towards rear and fit three housing bolts, in alternate holes: do not fit shims at this stage. Tighten bolts evenly to pull shaft into bearing and when bearing is seated against shaft shoulder, strike centre of shaft flange with a soft-faced hammer, to settle the bearings.

Driveshaft bearing setting

With shaft in position and inner bearing fully seated against shaft shoulder, tighten the three housing bolts evenly until bearings become tight enough to prevent shaft being 'rocked' against gear backlash. Do not overtighten bolts and distort housing flange but tighten evenly so that when a feeler gauge is inserted at three equally spaced points the gap is equal all the way round. Having measured gap between case and flange select shims that are 0.005in (0.12mm) less than gap then remove housing bolts and fit shims. Fit all six housing bolts and tighten evenly. The shaft bearings will then have the required amount of pre-load.

Having fully tightened housing bolts, check that circlip is placed in shaft groove at inside of gear then pump grease through housing nipple until seal cavity is filled and grease is forced past seal on inside of housing. Refit cover, using a new gasket.




FIGURE D8.
TOOL FOR REMOVING DISC BRAKE HUB

- A. $4\frac{1}{2}$ in (105mm) centres
- B. $\frac{3}{4}$ in (20mm)
- C. $6\frac{1}{2}$ in (170mm) diameter
- D. $3\frac{1}{2}$ in (79mm) diameter
- E. $\frac{1}{4}$ in (3.2mm) recess
- F. $\frac{1}{8}$ in (1.6mm) radius
- G. $2\frac{1}{2}$ in (67.5mm)
- H. $\frac{1}{2}$ UNC

SPECIFICATIONS AND DATA—FINAL DRIVE REDUCTIONS

Reduction ratio	11/58
Oil capacity (each unit)	13 pints
Oil grade	Mobil 422
Spur pinion shaft bearing preload	0.001 - 0.003in (0.02 - 0.08mm)
Final driveshaft bearing preload	0.005 - 0.007in (0.13 - 0.18mm)
Spur wheel-to-pinion backlash (new)	0.006 - 0.010in (0.15 - 0.25mm)

Tightening torques

Housing to rear axle case nuts ($\frac{1}{2}$ UNC)	75 lb ft (10.5 kg metre)
Housing to reduction case bolts ($\frac{1}{2}$ UNC)	75 lb ft (10.5 kg metre)
Case rear cover bolts ($\frac{3}{8}$ UNC)	30 lb ft (4.2 kg metre)
Housing cover bolts ($\frac{3}{8}$ UNC)	9 lb ft (1.3 kg metre)
Oil seal housing to case bolts ($\frac{7}{16}$ UNC)	50 lb ft (6.9 kg metre)
Drain plug ($\frac{1}{2}$ BSP)	60 lb ft (8.4 kg metre)
Driveshaft locking ring ($3\frac{3}{8}$ in special)	75 lb ft (10.5 kg metre)
Wheel nuts ($\frac{3}{4}$ UNF)	150 lb ft (21 kg metre)

HOW IT WORKS—BRAKE MECHANISM

The disc brake units are mounted inside the final drive housings and operate on the spur pinion shafts. They consist of an actuator, four stationary plain discs and six rotating discs with sintered friction facings. The actuating units consist of two actuating plates, held together by tension springs and separated by six steel balls. The steel balls sit in recesses with inclined seats and the plates are connected by linkage to the brake pedals. When the brake pedal is depressed the operating linkage turns the actuator plates towards each other. The steel balls therefore roll up the inclined seats, which pushes the plates apart and clamps the two sets of plates (stationary and revolving) together to give a braking action.

The actuators have a revolving disc at each side of them and when the actuator expands to clamp the plates together the revolving plates tend to turn the actuator in the same direction. The two actuator plates are, therefore, restrained from turning by lugs on plates contacting a housing stop. As the actuator plates turn, the trailing plate lug contacts the housing stop but the leading plate is allowed to remain free. The leading plate thus tends to turn, relative to the trailing plate, which applies the brakes harder without additional pedal pressure being required. The brakes are therefore self-energising, which allows maximum braking effort to be obtained with very light pedal pressure.

When the brake pedal is released the linkage turning the actuator plates is released. The pull-off springs then pull the actuator plates together and the discs are allowed to run free.

As it is necessary for the brakes to be capable of independent operation for turning purposes, separate pedals and linkage are used for each side. For normal braking a third pedal is provided, which operates both brakes through a compensating linkage. Even braking is thus obtained irrespective of any difference in adjustment caused by using the brakes independently.




FIGURE F2. ACTUATOR AND DISCS




FIGURE F1. BRAKE ACTUATOR




FIGURE F3. ARRANGEMENT OF BRAKE MECHANISM

UNIT REMOVAL AND REPLACEMENT

Disc Brake Units

As the discs are housed inside the reduction case it is necessary to first remove the complete reduction unit from the tractor (see page D2).

Turn reduction unit so that it is supported on drive-shaft flange and pinion shaft is pointing upwards. Remove four bolts from housing cover then extract clevis pin from connecting link: pin should not be tight but is threaded $\frac{1}{2}$ UNC so that one of cover bolts may be screwed into pin to assist extraction. Remove the thirteen bolts attaching housing to reduction case then lift off housing, with link and camshaft, to expose brake mechanism. Remove discs and actuator then remaining discs and lay them on bench in order of removal.

To dismantle actuator, remove fork pin to disconnect linkage then remove tension springs. Plates can then be separated, taking care of the six steel balls.

Assembling the brake mechanism

Lay an actuating plate on bench with ball seats uppermost. Place all six balls in their seats then place other actuating plate on top of balls. Ensure that connecting links are in their correct position and all the balls are seated in both plates then fit new pull-off springs and reconnect links to fork.

Place an inner disc on splined hub followed by an outer plain disc. Repeat this with two more pairs of plates then fit an inner plate: this should make four inner plates and three outer plates. Replace actuator followed by an inner plate, outer plate and finally another inner plate.

Check that discs, actuator and linkage are correctly assembled and operating lever is quite free. Fit a new gasket on case, check that connecting link is in position in housing then fit housing on case. Tighten bolts evenly then refit clevis pin through connecting link before refitting reduction unit.

Disc hub

This is keyed to spur pinion shaft and need not be removed unless it is to be renewed. To remove hub from shaft make a plate to the dimensions shown in figure F5 then bolt brake drum actuator (Service Tool K960618) to plate and pull hub from shaft. Before replacing hub, ensure that both keys are in position on shaft and place chamfered end of hub keyways against keys then press hub on shaft until it is firmly against distance piece.

Brake Cross Shaft and Pedals

The brake cross shaft passes through a tube in tractor main frame and is supported by a bush at each end of tube. To remove cross shaft disconnect wires from stop lamp switch and brake rods from pedal and left-hand lever. Remove circlip from right-hand end of shaft and pin from left-hand pedal then top shaft out from right-hand side. Pedals and operating lever can then be removed.

Place in reverse order of removal, ensuring that centre and right-hand pedals are free on shaft and operating lever is entered into hand brake lever stirrup before cross shaft is pushed through pedals.




FIGURE F4. BRAKE ACTUATOR AND DISCS

9-38127

F3





FIGURE F5.
TOOL FOR REMOVING DISC BRAKE HUBS

- A. $4\frac{1}{2}$ in (105mm) centres
- B. $\frac{3}{8}$ in (20mm)
- C. $6\frac{1}{2}$ in (170mm) diameter
- D. $3\frac{1}{2}$ in (79mm) diameter
- E. $\frac{1}{8}$ in (3.2mm) recess
- F. $\frac{1}{16}$ in (1.6mm) radius
- G. $2\frac{1}{2}$ in (67.5mm)
- H. $\frac{1}{8}$ UNC



A. $25\text{mm} \pm 1\text{mm}$ ($1\text{in} \pm \frac{1}{16}\text{in}$)

FIGURE F6. BRAKE ADJUSTMENT

UNIT MAINTENANCE AND REPAIR

Lubrication

Grease fittings are provided on the centre pedal, compensator beam, left-hand pedal and brake housing; these should be lubricated every 60 hours. The cross-shaft bushes are oil impregnated and do not require lubricating in service.

Adjustment

To ensure adequate pedal travel as the brake discs wear, the initial travel has been reduced to 32 to 38mm ($1\frac{1}{2}$ to $1\frac{1}{2}$ in). This requires a revised method of setting as follows:—

1. Place tractor on level ground and block wheels to prevent tractor movement.
2. Release handbrake fully then release bolts securing stop plate to right-hand footplate. Hold centre pedal upright (to ensure that pedal and operating lever are in line) then slide stop plate up to pedal and tighten bolts.
3. Clean dirt from rear and inner faces of reduction housings then remove cover plates and blanking plugs to reveal the clevis pins and adjusting nuts—Fig. F6.
4. Draw a line between the centres of the front stud holes, and measure the distance between this line and the front edge of the clevis pin. This should be 25mm (1in), if incorrect, adjust as described in operation 5, if correct proceed to operation 6.

NOTE: If the user has attempted to compensate for brake wear by adjusting the external pull rods, or if the tractor is an early model set to 65mm ($2\frac{1}{2}$ in) pedal travel, the clevis pin setting will not be 25mm (1in). It is therefore, essential to carry out this check before attempting to adjust mechanically operated brakes.

5. Unscrew the internal adjusting nuts 3 full turns, then with the pedals fully up, adjust the length of the external pull rods (by their adjusting nuts at the cross shaft under the foot plates—Fig. F7) until the clevis pin setting is 25mm (1in). When set, lock these adjusting nuts and do not disturb again. This setting is not affected by brake wear.
6. When the clevis pin is correctly adjusted, screw down the internal self-locking adjusting nuts until a pedal travel (full off to full on) of 32 to 38mm ($1\frac{1}{2}$ to $1\frac{1}{2}$ in) is obtained.
7. Repeat operations 4 to 6 on opposite side then refit cover plates and blanking plugs to reduction housings.

On tractors with correctly set clevis pins, any brake wear should be taken up by adjusting the internal self-locking adjusting nuts **ONLY**, to give the correct pedal travel.

Even with correctly adjusted brakes and the approved final drive lubricant, brake grab or fierceness sometimes occurs. This has been found to happen when the disc housing is deeper than normal. It is often possible to correct this condition by installing an additional stationary steel disc as follows:

Having set clevis pin position on both brake units, check that brakes are equally adjusted by depressing the centre pedal. Check the clearance at 'C'—Fig. F8, with the brakes clean and dry and with serviceable discs in good condition. Only if the clearance exceeds 3.12mm (0.123in) fit a extra stationary steel disc, K945755 as shown at 'D'. With this disc added, depth 'C' must not be less than 0.43mm (0.017in).





FIGURE F7. EXTERNAL PULL ROD ADJUSTMENT



- A Rotating (Bronze) plate
- B Stationary (steel) plate
- C Clearance of brake plate below housing joint
- D Additional steel plate K945755

FIGURE F8. DISC BRAKE ASSEMBLY

SPECIFICATIONS AND DATA—BRAKE MECHANISM

Brake type	wet discs
Brake operation	foot operated through independent pedals or together using central master pedal
Disc diameter	22.2cm (8 $\frac{7}{8}$ in)
Number of rotating discs	6 per side
Friction area (total)	2683cm ² (416in ²)
Rotating disc dimensions:	
Thickness (new)	4.9–4.75mm (0.193–0.187in)
Parallelism of Friction faces (max out of true)	0.075mm (0.003in)
Flatness of Friction faces (max out of true)	0.125mm (0.005in)
Radial groove depth (min)	0.125mm (0.005in)
Stationary disc dimensions:	
Thickness (new)	2.7–2.6mm (0.106–0.101in)
Parallelism of Friction area (max out of true)	0.075mm (0.003in)
Flatness of Friction area (max out of true)	0.205mm (0.008in)
Flatness of non-Friction area (max out of true)	0.380mm (0.015in)

HOW IT WORKS—HYDRAULIC BRAKING SYSTEM

NOTE: This information does not apply to tractors fitted with brakes to all four wheels.

The disc brake units are identical to those fitted to non-'Q'-cab tractors except that they are hydraulically operated using a mineral oil system. Cylinders are colour coded with a blue band and only mineral oil type replacement components available from DB Parts Dept., must be used.

DANGER—The only fluid approved for use in brake and clutch reservoirs is Shell Tellus 27—this is clearly marked on the reservoir covers. Fluids normally described as brake fluids, power steering fluids, automatic transmission fluids or universal tractor oils are definitely **NOT** compatible and **MUST NOT** be used.

A single reservoir supplies separate master cylinders for right-hand and left-hand circuits. The master cylinders provide free

return of oil to the reservoir when the pedal is released. Slave cylinder retraction is by external return springs.

Brake master cylinders are mounted to the right-hand side of the bulkhead and the slave cylinders are externally mounted on the final drives. There is no residual pressure maintained in the system when brakes are released.

A brake balance valve is fitted beneath the cab. This contains a piston with limited travel; one end of which is connected to the left-hand circuit and the other to the right-hand circuit. As no oil can pass this piston the brakes will operate independently when the pedals are disconnected but when connected for road work the piston will move to balance pressure in both brake circuits.

This accommodates slight variation in brake wear between the left-hand and right-hand side.

UNIT REMOVAL AND REPLACEMENT

Brake Master Cylinders—Fig. F9

Cylinders may be removed individually after disconnecting inlet pipe, outlet pipe and pedal push-rod.

Replace by first bolting cylinder to bulkhead then set position of fork on push rod so that with both pedals locked together and in the fully off position, the holes in fork and pedal are exactly opposite permitting the clevis pin to be fitted without moving the cylinder piston. Refit inlet and outlet pipes, top up reservoir with Shell Tellus 27 fluid, then bleed the system (page F8.).

Brake Slave Cylinders—Fig. F10

The slave cylinders are mounted on the final drive units. To remove, first disconnect the return spring and remove clevis pin, disconnect brake pipe then remove two nuts and bolts securing cylinder to final drive unit.

Replacement is the reversal of the removal procedure except that the reservoir should be topped up with Shell Tellus 27 fluid and the system bled (page F8.).

Brake Balance Valve—Fig. F11

The brake balance valve is mounted beneath cab on the front cross member. To remove, note the positions of and disconnect the two flexible brake pipes. Disconnect the two rigid brake pipes and remove the two bolts securing the valve to the cross member.

Replacement is the reversal of the removal procedure except that the reservoir should be topped up with Shell Tellus 27 fluid and the system bled (page F8.).




FIGURE F9. BRAKE MASTER CYLINDER




FIGURE F10. BRAKE SLAVE CYLINDER




FIGURE F11. BRAKE BALANCE VALVE

UNIT MAINTENANCE AND REPAIR

Maintain oil level in reservoir to full mark using only Shell Tellus 27 hydraulic fluid.

If any loss of fluid occurs from the system rectify the cause immediately. Ensure that pedals have a firm feel without sponginess and adjust brakes well before pedals can be bottomed.

Ensure that brake pipes do not chafe against tractor chassis, note that cab can move relative to chassis in normal operation.

Adjustment—Fig. F12

1. Block front wheels securely and raise one rear wheel clear of the ground, supporting tractor with a stand. Release handbrake fully and ensure that brake slave cylinders are fully retracted and are not being restricted by the hand-brake cables.
2. Remove access plug from rear of final drive unit. Tighten adjusting nut until brake just locks the wheel then slacken exactly $2\frac{1}{2}$ turns.
3. Repeat adjustment on opposite wheel, lower tractor to the ground.




FIGURE F12. BRAKE ADJUSTMENT

Check to ensure that hand brake is fully applied on 3rd ratchet from off position. If necessary adjust cables at compensator bar ensuring that bar remains level.

Check that there is equal travel on left-hand and right-hand brake pedals when operated independently, and road test to ensure brakes operate evenly when pedals are connected together. Make fine adjustments if necessary, replace access plugs.

If brakes do not operate evenly after carrying out the above adjustments, check the operation of the balance valve as follows: If valve is functioning correctly it will be found that when the pedals are operated separately, but with one foot on each pedal, it will be possible to lift the right-hand pedal by pushing down on the left-hand pedal and vice versa. If this action cannot be obtained the balance piston is seized.

NOTE: The balance valve is only obtainable as a complete assembly.

Brake Bleeding

Brake bleeding should be carried out with the pedal lock disconnected, and each side bled separately. Release the bleed

screws (these are 13mm and can be released without removing the dirt shield) fitted at the top of the slave cylinders and bleed as follows:

Attach a 1 metre length of 5mm bore plastic or nitrile rubber tube to the bleed screw and immerse the free end in a clean jar containing Shell Tellus 27 fluid.

Slacken the bleed screw while an assistant pushes the pedal slowly over full length of travel but tighten bleed screw before pedal bottoms, release pedal.

Repeat this procedure, maintaining the reservoir full of clean Shell Tellus 27 fluid until no air bubbles are appearing from end of tube. Tighten bleed screw (do not overtighten) and repeat the procedure on other side. If the system has been drained it is possible to fill the system by pumping fluid through the bleed tube with a pressure oil-can filled with Shell Tellus 27 fluid (and kept specially for this purpose). Fill half the reservoir through one slave cylinder and the remainder through the opposite cylinder. The oil-can must not be removed from the bleed tube or allowed to empty during the filling cycle as this will introduce air into the system. If the pedals are firm in operation after filling in this way, no further bleeding will be required.

Brake System Faults

If the pedals remain spongy after correct bleeding, or if sponginess returns in service, isolate the slave cylinder from the master cylinder using a Girling T3 hose clamp on the flexible brake hose. If sponginess is eliminated with the clamp fitted, air is entering the slave cylinder past the seals. If sponginess remains the master cylinder or reservoir connections may be at fault. Brake drag or failure to release fully may be caused by faulty slave cylinder seals or by an incorrectly adjusted master cylinder push rod.

Even with correctly adjusted brakes and the approved final drive lubricant, brake grab or fierceness sometimes occurs. This has been found to happen when the disc housing is deeper than normal. It is often possible to correct this condition by installing an additional stationary steel disc as follows:

Check the clearance at 'C'—Fig. F13 with the brakes clean and dry and with serviceable discs in good condition. Only if the clearance exceeds 3.12mm (0.123in) fit an extra stationary steel disc, K945755 as shown at 'D'. With this disc added, depth 'C' must not be less than 0.43mm (0.017in).




FIGURE F13. DISC BRAKE ASSEMBLY

SPECIFICATIONS AND DATA

HYDRAULIC BRAKING SYSTEM

Brake type	wet disc
Brake operation	foot operated through Girling mineral type hydraulic cylinders, using independent pedals or together using pedal lock
Hydraulic brake fluid	Shell Tellus 27
Number of rotating discs	6 per side
Friction area (total)	2883cm ² (416in ²)
Rotating disc dimensions	
Thickness (new)	4.9-4.75mm (0.193-0.187in)
Parallelism of Friction faces (max out of true)	0.075mm (0.003in)
Flatness of Friction faces (max out of true)	0.125mm (0.005in)
Radial groove depth (min)	0.125mm (0.005in)
Stationary disc dimensions	
Thickness (new)	2.7-2.6mm (0.106-0.101in)
Parallelism of Friction faces (max out of true)	0.075mm (0.003in)
Flatness of Friction area (max out of true)	0.205mm (0.008in)
Flatness of non-Friction area (max out of true)	0.380mm (0.015in)



DAVID BROWN  **case**

Preliminary Service Information Tractors with Q-Cab

Pub. 9-38162 February 1977

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



INTRODUCTION

This publication is intended to provide information which may be required when servicing a tractor with a DB Q-cab. It is not a comprehensive repair manual but is a summary of service information with emphasis on features which are new, or different, from previous DB models.

This publication includes manufacturing instructions for Q-cab lifting bracket, previously issued as Pub. 9-39805 which is now superseded. Technical Bulletins TBL2 Brakes and TB88 Miscellaneous are also superseded.

CONTENTS

GENERAL	1
Q-CAB REMOVAL	2
SERVICE & REPAIR									
Brakes	5
Clutch	8
CAB LIFTING BRACKET	10

David Brown policy is one of continuous development and improvement and therefore the specification details may have been altered since this manual went to press.

Moreover, as the David Brown tractor is offered in a variety of forms to cover a large number of markets and applications, this manual may contain details of items not applicable to the particular tractor with which it is being used.

⚠ DANGER — THIS PUBLICATION DOES NOT APPLY TO TRACTORS WITH FOUR WHEEL BRAKES. THESE HAVE AN AUTOMOTIVE TYPE BRAKE AND CLUTCH SYSTEM.

GENERAL It is normally necessary to remove the complete cab only for access to the transmission or for removal of the rear axle.

Access to the fuel tank, orbitrol steering unit and throttle controls can be obtained by raising the front of the cab 150mm (6ins approx) using a jack under both steps. Follow the procedure for cab removal, noting that it will not be necessary to disconnect the following controls unless they become tight during the raising procedure:- Cab steps, steering pipes, PTO clutch cable, brake cables, flexible brake pipes.

Complete cab removal and replacement should not exceed 5 man hours, raising the front of the cab 2 man hours.

CLUTCH REMOVAL is by splitting on all models

885 only The cab must be raised at the front to clear the clutch slave cylinder. It should also be noted that the 885 clutch cover casting remains attached to the front main frame during splitting and 4 bolts inside the main frame, accessible through the clutch pit cover, must be removed to split the tractor.

During reassembly, the release bearing carrier must be located between the release fork and release plate and carefully engaged with the support snout key as the tractor halves are brought together.

TAKE CARE. All models

The PTO cardan shaft must be a free sliding fit in the flywheel pilot bearing to prevent end loading on the crankshaft during assembly.

If the shaft does not slide out easily, polish the bearing location on the shaft with 180 grit emery tape.

Q CAB REMOVAL

The following instructions detail removal of the Q cab and it is suggested that if two men are working on the tractor, maximum efficiency will be obtained if one man carries out operations A & B and the second man carries out operations C & D in that order.

All controls and pipes disconnected should be wired in position under the cab to ensure correct location on replacement.

- A. Remove cab doors, retaining spacing washers.
Disconnect battery.
Drain cooling system if fitted with heater.
Remove bonnet or bonnet top (as applicable).

B. Left hand side of tractor

Drain fuel tank by syphon or pump if fuel tank will be removed from cab.
Disconnect power steering hoses as follows marking location of hose before removal.

Note: Orbitrol unit connections are as follows:

Bottom left (from front of tractor) - pump pressure
Top left (looking from front of tractor) - return to reservoir

Transverse ram - disconnect hose at cab

Side mounted ram - disconnect outer hose complete with elbow,
disconnect inner hose less elbow.

885 pump hoses - disconnect pump hoses after marking location.

Disconnect throttle control at turnbuckle (avoid twisting rod at cab end as this could cause ball joint to disconnect) and remove bolts holding bonnet spring retaining plate to clutch housing.

Disconnect stop control at turnbuckle (avoid twisting rod at cab end) except on 885 where it should be disconnected at pump, releasing all clips.

Disconnect fuel leak-off pipe to tank.

Remove step (and earth lead to step if fitted).

Disconnect heater pipe to cab.

Remove LH cab mounting bolt.

Block rear wheels to prevent tractor rolling.

Disconnect PTO clutch cable (if applicable) at bottom clevis and free cable from hand lever.

Disconnect hand brake cables at hand brake.

Remove clutch slave cylinder complete without disconnecting hose, except 885 where hose must be disconnected and reservoir drained.

Synchromesh transmission - Engage neutral on all gears, remove range gear lever extensions and remove cover plate from under cab below range selector.

Hydra-Shift - remove steering wheel and instrument panel, wiring harness plug locating plate, and console plate. Disconnect and remove Hydra-Shift connecting rod.

C. Right hand side

Disconnect pipe, lift pump to fuel tank.

Disconnect tractor meter cable together with cable clips.

Disconnect engine wiring harness at front of cab.

Disconnect power steering hoses to pump after marking locations.

With transverse steering ram disconnect RH pipe at front of cab.

Disconnect heater pipe to cab.

Remove RH cab step.

Remove RH front mounting bolt.

Disconnect diff lock pedal.

Disconnect hydraulic control rod.

Disconnect vacuum switch lead if fitted (at rear on some models)

D. Rear end

Remove nuts from cab rear mounting bolts.

Disconnect starter safety switch lead

Fit Girling T3 brake pipe clamps to flexible brake pipes and remove from steel pipes. Lift flex pipes clear of rear axle after disconnecting pipe bracket from axle.

Disconnect PTO operating rod at front.

Disconnect 14 series dump valve at quick release pin.

Disconnect lift latch rod where fitted.

Disconnect 3 way valve rod at lever end.

Disconnect pick-up hitch cable.

Disconnect select rod at quick release pin.

Disconnect dump valve rod at quick release pin (except 14)

Disconnect remote valve rods where fitted

- E. Check that all controls are disconnected, by double checking the list A to D, and any additional accessories which are fitted. Remove cab with approved lifting bracket and roll tractor clear of cab, placing cab safely on stands until required.

Cab replacement

Replace cab in reverse order of removal, first ensuring that a large washer is fitted on each cab mounting and the recess in washer is downwards, towards the mounting.

Lower cab and fit two mounting bolts through cab rear brackets, to assist aligning cab over mountings. Whilst carefully lowering cab on to mountings, check that the wiring harness under centre of cab floor falls into the space between the gear lever housings. Also ensure that the lower end of main gear lever enters hole in end of operating arm. Before finally lowering cab, locate the dump valve control rod: this will enable control to be connected without having to disturb the rod adjustment.

When cab is resting on its mountings, check that nothing is trapped or fouling, then tighten the mounting bolts and reconnect all pipes, wires etc. Top up reservoirs and bleed steering, brakes and clutch.

Heater is self bleeding providing heater valve at water pump is open and heater switched on. After several minutes running top up radiator, taking care to remove cap slowly to avoid any chance of accidental scalding due to sudden pressure release.

Finally, check that there are no oil leaks and brake and clutch pipes are not in contact with any components which could cause chafing.

SERVICE & REPAIR OPERATIONSBRAKES

N.B. This information does not apply to 4 wheel brakes

The brakes are hydraulically operated using a mineral oil system. Cylinders are colour coded with a blue band and only mineral oil type replacements available from DB Parts Dept must be used.



DANGER — The only fluid approved for use in brake and clutch reservoirs is Shell Tellus 27 — this is clearly marked on the reservoir covers. Fluids normally described as brake fluids, power steering fluids, automatic transmission fluids or universal tractor oils are definitely *NOT* compatible and *MUST NOT* be used.

Distributors and dealers must ensure that Shell Tellus 27 is available to the operator at the time the tractor is delivered.

- Note (1) Shell Tellus 27 may be used in all DBT power steering systems.
 (2) Any additional fluids approved at a later date will be advised by bulletin.
 (3) Highway tractors with 4-wheel brakes, and not fitted with a Quiet Cab, continue to require Castrol Girling Crimson brake fluid.

Pipes are ~~6mm~~ steel pipes and are not interchangeable with automotive type hydraulic brake pipes.

OPERATION

A single reservoir supplies separate master cylinders for RH and LH circuits. The master cylinders provide free return of oil to the reservoir when the pedal is released. Slave cylinder retraction is by external return springs.

Brake master cylinders are bolted to right-hand side of bulkhead.

Cylinder removal: After removing the common inlet pipe, disconnecting outlet pipe and pedal push rod, either cylinder can be removed from the bulkhead.

When refitting cylinder, bolt cylinder to bulkhead then set position of fork on push rod so that with both pedals locked together and in the fully "off" position, holes in fork and pedal are exactly opposite, permitting the clevis pin to be fitted without moving the cylinder piston.

Brake balance valve is located under the cab. This contains a piston with limited travel, one end of which is connected to the LH brake circuit and the other end to the RH brake circuit. As no oil can pass this piston the brakes will operate independently when the pedals are disconnected, but when connected for road work the piston will move to balance pressure in both brake circuits. This accommodates slight variation in brake wear between RH and LH side.

If the balance valve is functioning normally it will be found that when the pedals are operated separately but with one foot on each pedal it will be possible to lift the right hand pedal by pushing down on the left hand pedal. If this action cannot be obtained the balance piston is seized. (The balance valve is only available as a complete assembly).

Brake slave cylinders are externally mounted on Final drives. Cylinder retraction is by external return springs. There is no residual pressure maintained in system when brakes are released.

Routine checks

Maintain oil level in reservoir to full mark using only Shell Tellus 27 hydraulic fluid.

If any loss of fluid occurs from the system rectify the cause immediately. Ensure that pedals have a firm feel without sponginess and adjust brakes well before pedals can be bottomed.

Ensure that brake pipes do not chafe against tractor chassis noting that cab can move relative to chassis in normal operation.

Adjustment

1. Block the tractor front wheels securely and raise one rear wheel clear of the ground, supporting the tractor on a stand. Release the hand brake and ensure the brake slave cylinders are fully retracted and are not being restricted by the hand brake cables.

2. All models except 1410/12

Release the locknut and tighten the 15/16 AF adjuster on the brake camshaft very carefully until the brake binds. Slacken adjuster bolt 1/12 turn (half a flat) and lock the locknut. Check that wheel rotates freely.

3. 1410/12

Remove the access plug from the final drive. Tighten cleveloc nut with a 3/4 AF tube spanner until the brake just locks the wheel. Slacken exactly 2½ turns.

4. All models

Repeat adjustment on opposite wheel.

Check to ensure that hand brake is fully applied on the 3rd ratchet from off position. If necessary adjust cables at compensator bar ensuring that bar remains level.

Check that there is equal travel on ~~Left-hand~~ and Right-hand brake pedal when operated independently and road test to ensure brakes operate evenly when pedals are connected together. Make fine adjustment if necessary (and replace access plugs on 1410/12 tractors).

Brake bleeding should be done with the pedal lock disconnected, and each side bled separately. Release the bleed screws (these are 13mm AF and can be released without removing the dirt shield) fitted at the top of the slave cylinders and bleed as follows:-

Attach a 1 metre length of 5mm bore plastic or nitrile rubber tube to the bleed screw and immerse the free end in a clean jar containing Shell Tellus 27 fluid.

Slacken the bleed screw while an assistant pushes pedal down slowly over full length of stroke, but tighten bleed screw before pedal bottoms. Release pedal.

Repeat this procedure, maintaining the reservoir full of clean Shell Tellus 27 fluid until no air bubbles are appearing from end of tube. Tighten bleed screw (do not overtighten) and repeat procedure on other wheel.

If the system had been drained it is possible to fill the system by pumping oil through the bleed tube with a pressure oil can filled with Shell Tellus 27 fluid (and kept specially for this purpose). Fill half the reservoir through one slave cylinder and the remainder through the opposite cylinder. The oil can must not be removed from the bleed tube or allowed to empty during the filling cycle as this will introduce air into the system. If the pedals are firm in operation after filling in this way no further bleeding will be required.

Brake system faults

If the pedals remain spongy after correct bleeding or if sponginess returns in service isolate the slave cylinder from the master cylinder using a Girling T3 hose clamp on the flexible brake hose. If sponginess is eliminated with the clamp fitted air is entering the slave cylinder past the seals. If sponginess remains the master cylinder or reservoir connections may be at fault.

Brake drag or failure to release fully may be caused by faulty slave cylinder seals or by an incorrectly adjusted master cylinder push rod.

Cylinders and seal kits are available under the following part numbers. Ensure that any cylinder installed has a blue identification band as this indicates the unit is suitable for a mineral oil system. THESE PARTS ARE NOT AVAILABLE FROM GIRLING AGENTS. NO ATTEMPT MUST BE MADE TO FIT SEAL KITS OR CYLINDERS OBTAINED FROM GIRLING AGENTS AS MINERAL TYPE UNITS (COLOUR CODED BLUE) ARE ONLY AVAILABLE FROM DAVID BROWN PARTS DEPT.

Master Cylinder	- 8/9/12 & 14 series tractors	K950544
seal kit - master cylinder		. K964572

Slave cylinder	- 8 & 9 series tractors	K950557
seal kit - slave cylinder		. K964573

Slave cylinder	- 1210/12 & 1410/12	K950549
seal kit - slave cylinder		. K964574

Balance valve	- 8/9/12 & 14 series	K950547
---------------	----------------------	---------

Warranty procedure - If any brake cylinder fails as a result of defective manufacture or assembly, the unit must be returned to David Brown Claims Department complete without being dismantled, washed or drained. Transit plugs supplied with replacement cylinders must be transferred to the failed unit to prevent leakage and the unit should be packed in a clean plastic bag.

⚠ WARNING — This information does not apply to Highway models

CLUTCH

The transmission clutch is hydraulically operated using similar (or identical in some instances) cylinders to the brake system. All cylinders and seals are colour coded blue and only Shell Tellus 27 hydraulic fluid may be used. Refer also to brake section and TB12 brakes.

OPERATION:

A reservoir supplies oil to the master cylinder which is operated by the clutch pedal through a pushrod. The master cylinder feeds oil to the slave cylinder mounted on the side of the main frame, except 885 where the slave cylinder is mounted on the clutch housing.

PEDAL FREE TRAVEL ADJUSTMENT

Check at least every 60 hrs and NEVER OPERATE WITH INSUFFICIENT PEDAL FREE TRAVEL.

The shape of the clutch pedal prevents accurate measurement of free travel at the pedal pad so the free travel should be checked at the master cylinder pushrod.

Measure the travel of the pushrod from the "pedal at rest" position to the point at which all free travel is taken up (ie. the release bearing is contacting the clutch release plate).

This must be maintained as follows:-

885	* Maximum travel 10mm, Minimum travel 5mm
990/995	* Maximum travel 8mm, Minimum travel 5mm
996/12/14	* Maximum travel 12mm, Minimum travel 6mm

Adjustment is provided at the slave cylinder pushrod on 996, 12 and 14 series tractors (two $\frac{1}{2}$ AF open end spanners required) and on the adjusting bolt on the clutch cross-shaft lever on 990, 995 and 885 tractors ($\frac{3}{4}$ AF open ended spanner). On 885 this bolt is accessible from underneath the RH side of the cab.

Note* The maximum free travel quoted should be used where possible but first check to ensure that the PTO clutch frees on 885, 990, 995 when the pedal is fully depressed.

PTO Clutch adjustment 885, 990, 995

The only adjustment available is at the 3 Allen screws on the clutch cover assembly. Weld a short handle to the end of a $\frac{1}{2}$ AF Tube spanner so that a long $\frac{5}{32}$ AF Allen key can be entered down the tube.

With engine stopped and stop control in "Stop" position rotate flywheel (do not insert lever between spring cups to rotate flywheel as this will damage clutch) until one Allen screw is at the bottom. Slacken locknut with tube spanner and turn screw clockwise to just contact pressure plate. Slacken screw exactly $1\frac{1}{2}$ turns and tighten locknut. Repeat on remaining 2 screws.

This procedure will give 1.82mm (0.72in) allen screw clearance.

Note. $\frac{1}{4}$ turn of screw will vary adjustment by 0.25mm (.010in)

PTO clutch adjustment 996, 12 & 14 series

Check every 60 hours. Adjust the threaded abutment at the bottom end of the PTO clutch operating cable to maintain 2.5mm - 5mm slack in the cable. This can be measured between the cable abutment and cable clevis by applying hand pressure on the cross-shaft lever to take up free travel.

Master Cylinder and slave cylinder

These are similar to brake components which are detailed in brake section.

If a master cylinder or clutch pedal is disturbed the following adjustment must be carried out.

1. With foot pedal against the rear stop the master cylinder push rod clevis pin must freely enter the hole in the pedal. Adjust threaded end on pushrod to obtain correct adjustment.
2. Carefully depress pedal until master cylinder is bottomed. Adjust stop bolt in pedal to contact the console and then turn stop bolt 1 further full turn anti-clockwise to prevent master cylinder from bottoming in service.

Clutch bleeding. Remove all free travel from release bearing and bleed in same way as brake circuit. Do not bottom release levers during this operation as this will cause damage to clutch. Re-adjust free travel to specs.

Slave cylinder. To gain access to slave cylinder on 885 tractors it is necessary to raise the front of the cab.

Clutch system faults. If a variable free travel is obtained on 996, 12 and 14 series tractors due to the slave cylinder not retracting fully, first check master cylinder pushrod adjustment and if necessary fit a stronger slave cylinder return spring part number K624954.

Replacement parts. Cylinders and seal kits are available under the following part numbers. Ensure that any cylinder fitted has a blue identification band as this indicates the unit is suitable for a mineral oil system. THESE PARTS ARE NOT AVAILABLE FROM GIRLING AGENTS. NO ATTEMPT MUST BE MADE TO FIT SEAL KITS OR CYLINDERS OBTAINED FROM GIRLING AGENTS AS MINERAL TYPE UNITS (COLOUR CODED BLUE) ARE ONLY AVAILABLE FROM DAVID BROWN PARTS DEPARTMENT.

Master cylinder 8/9/12 & 14 - series	K950544
Seal kit, master cylinder	*K964572
Slave cylinder 885	K951527
Seal kit, slave cylinder	*K964575
Slave cylinder 990,995	K952267
Seal kit, slave cylinder	*K964573
Slave cylinder, 996, 1210, 1212, 1410, 1412	K950550
Seal kit, slave cylinder	*K964576

Warranty procedure - Refer to brake section

CAB LIFTING BRACKET

The completed bracket must be tested by an authorised specialist to comply with the requirements of the Factories Act, to a safe working load of 750Kg. The following materials and parts will be required to fabricate the lifting bracket as shown in figure 1 opposite.

Material required

Steel plate should be 30 ton grade weldable structural steel.

Steel plate	1200mm x 100mm x 16mm	Qty 1
Steel plate	360mm x 160mm x 5mm	Qty 2
Mild steel strip	1100mm x 16mm x 16mm	Qty 2
Additional David Brown parts required.		

<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
K921914	fork end	2
K901963	bush	2
K 19476	washer, $\frac{1}{2}$ in	2
K601411	bolt, $\frac{1}{2}$ in UNC x $3\frac{1}{4}$ in	2
K607446	Cleaveloc nut, $\frac{1}{2}$ UNC	2
K948353	Pivot pin	2
K623740	spring pin $3/16$ in x $7/8$ in	2
K771626	spring clip	2

Manufacture and assemble the brackets as shown in figure 1 opposite, noting the method of attachment of the side plate hangers (left hand side shown).

The quickest method of attachment of bracket to cab is to locate the side plates on the cab lifting bolts allowing them to rest in the roof guttering. Then lower the centre beam and attach the hangers to the centre beam by means of the quick release pins.

ALL DIMENSIONS ARE GIVEN IN MILLIMETRES

1








FIGURE 1 CAB LIFTING BRACKET

CAB LIFTING BRACKET (SEKURA CAB)



ALL DIMENSIONS ARE GIVEN IN MILLIMETRES



DAVID BROWN



David Browns

Preliminary Service Information

Highway Tractors with Q-Cabs

Pub. 9-38194 August 1978

David Brown Tractors Ltd

A Tenneco Company

Affiliate of J I Case



David Brown Tractors Ltd. will continue to improve their products.
As a result, the specification can have changed after this issue
was made.

Printed and Published in England by David Brown Tractors Ltd.

INTRODUCTION

This publication is intended to provide information which may be required when servicing a Highway tractor with a DB Q-cab. It is not a comprehensive repair manual but is a summary of service information with emphasis on features which are new, or different, from previous DB models.

This publication includes manufacturing instructions for Q-cab lifting bracket, previously issued as Pub. 9-39805 which is now superseded.

CONTENTS

GENERAL	2
Q-CAB REMOVAL	3
SERVICE & REPAIR									
Brakes	6
Clutch	10
CAB LIFTING BRACKET	14

GENERAL It is normally necessary to remove the complete cab only for access to the transmission or for removal of the rear axle.

Access to the fuel tank, orbitrol steering unit and throttle controls can be obtained by raising the front of the cab 150mm (6in approx) using a jack under both steps. Follow the procedure for cab removal, noting that it will not be necessary to disconnect the following controls unless they become tight during the raising procedure:- Cab steps, steering pipes, PTO clutch cable, brake cables, flexible brake pipes.

Complete cab removal and replacement should not exceed 5 man hours, raising the front of the cab 2 man hours.

CLUTCH REMOVAL is by splitting the tractor.

885 only The cab must be raised at the front to clear the clutch slave cylinder. It should also be noted that the 885 clutch cover casting remains attached to the front main frame during splitting and 4 bolts inside the main frame, accessible through the clutch pit cover, must be removed to split the tractor.

During reassembly, the release bearing carrier must be located between the release fork and release plate and carefully engaged with the support snout key as the tractor halves are brought together.

TAKE CARE - All models

The PTO cardan shaft must be a free sliding fit in the flywheel pilot bearing to prevent end loading on the crankshaft during assembly.

If the shaft does not slide out easily, polish the bearing location on the shaft with 180 grit emery tape.

Q CAB REMOVAL

The following instructions detail removal of the Q cab and it is suggested that if two men are working on the tractor, maximum efficiency will be obtained if one man carries out operations A & B and the second man carries out operations C & D in that order.

All controls and pipes disconnected should be wired in position under the cab to ensure correct location on replacement.

- A. Remove cab doors, retaining spacing washers
Disconnect battery
Drain cooling system if fitted with heater
Remove bonnet or bonnet top (as applicable)

- B. Left-hand side of tractor

Drain fuel tank by syphon or pump if fuel tank will be removed from cab.
Disconnect power steering hoses as follows marking location of hose before removal.

Note: Orbitrol unit connections are as follows:

Bottom left (from front of tractor) - pump pressure
Top left (looking from front of tractor) - return to reservoir

Transverse ram - disconnect hose at cab

Side mounted ram - disconnect outer hose complete with elbow,
disconnect inner hose less elbow.

885 pump hoses - disconnect pump hoses after marking location.

Disconnect throttle control at turnbuckle (avoid twisting rod at cab end as this could cause ball joint to disconnect) and remove bolts holding bonnet spring retaining plate to clutch housing.

Disconnect stop control at turnbuckle (avoid twisting rod at cab end) except on 885 where it should be disconnected at pump, releasing all clips.

Disconnect fuel leak-off pipe to tank.

Remove step (and earth lead to step if fitted).

Disconnect heater pipe to cab.

Remove LH cab mounting bolt.

Block rear wheels to prevent tractor rolling.

Disconnect PTO clutch cable (if applicable) at bottom clevis and free cable from hand lever.

Disconnect hand brake cables at hand brake.

Remove clutch slave cylinder complete without disconnecting hose, except 885 where hose must be disconnected and reservoir drained.

Synchromesh transmission - Engage neutral on all gears, remove range gear lever extensions and remove cover plate from under cab below range selector.

C. Right hand side

Disconnect pipe, lift pump to fuel tank.

Disconnect tractor meter cable together with cable clips.

Disconnect engine wiring harness at front of cab.

Disconnect power steering hoses to pump after marking locations.

With transverse steering ram disconnect RH pipe at front of cab.

Disconnect heater pipe to cab.

Remove RH cab step.

Remove RH front mounting bolt.

Disconnect diff lock pedal.

Disconnect hydraulic control rod.

Disconnect vacuum switch lead if fitted (at rear on some models)

D. Rear end

Remove nuts from cab rear mounting bolts.

Disconnect starter safety switch lead

Fit Girling T3 brake pipe clamps to flexible brake pipes and remove from steel pipes. Lift flexible pipes clear of rear axle after disconnecting pipe bracket from axle.

Disconnect PTO operating rod at front.

Disconnect lift latch rod where fitted.

Disconnect 3-way valve rod at lever end.

Disconnect pick-up hitch cable.

Disconnect select rod at quick release pin.

Disconnect dump valve rod at quick release pin

Disconnect remote valve rods where fitted

- E. Check that all controls are disconnected, by double checking the list A to D, and any additional accessories which are fitted. Remove cab with approved lifting bracket and roll tractor clear of cab, placing cab safely on stands until required.

Cab replacement

Replace cab in reverse order of removal, first ensuring that a large washer is fitted on each cab mounting and the recess in washer is downwards, towards the mounting.

Lower cab and fit two mounting bolts through cab rear brackets, to assist aligning cab over mountings. Whilst carefully lowering cab on to mountings, check that the wiring harness under centre of cab floor falls into the space between the gear lever housings. Also ensure that the lower end of main gear lever enters hole in end of operating arm. Before finally lowering cab, locate the dump valve control rod: this will enable control to be connected without having to disturb the rod adjustment.

When cab is resting on its mountings, check that nothing is trapped or fouling, then tighten the mounting bolts and reconnect all pipes, wires etc. Top up reservoirs and bleed steering, brakes and clutch.

Heater is self bleeding providing heater valve at water pump is open and heater switched on. After several minutes running, top up radiator, taking care to remove cap slowly to avoid any change of accidental scalding due to sudden pressure release.

Finally, check that there are no oil leaks and brake and clutch pipes are not in contact with any components which could cause chafing.

SERVICE AND REPAIR OPERATIONS

BRAKES

The brakes are hydraulically operated using a vegetable base oil system. Cylinders are colour coded with a black band and only vegetable oil type replacements must be used.

WARNING The only fluid approved for use in the clutch and brake system of David Brown Highway tractors with Q cabs is Castrol Girling Universal Green. This is a vegetable-base oil; no other fluids are to be added to it and no alternatives are recommended. The seals used in brake and clutch systems will fail if incorrect fluid is used.

Operation

David Brown Highway tractors are fitted with hydraulically-actuated front wheel brakes. The brakes are operated from a single pedal which also operates the rear wheel brakes at the same time. Front and rear wheel brakes are interconnected diagonally as shown in fig. 1. A stoplight pressure-switch is included in the system.




FIGURE 1. HYDRAULIC BRAKE SYSTEM

Brake master cylinders are bolted to right-hand side of bulkhead.

Cylinder removal: After removing the common inlet pipe, disconnecting outlet pipe and pedal push rod, either cylinder can be removed from the bulkhead.

When refitting cylinder, bolt cylinder to bulkhead then set position of fork on push rod so that with pedal in the fully "off" position, holes in fork and pedal are exactly opposite, permitting the clevis pin to be fitted without moving the cylinder piston.

Brake balance valve is located under the cab. This contains a piston with limited travel, one end of which is connected to the left-hand brake circuit and the other end to the right-hand brake circuit. As no oil can pass this piston, the piston will move to balance pressure in both brake circuits when the brakes are applied.

Brake slave cylinders are externally mounted on Final drives. Cylinder retraction is by external return springs. There is no residual pressure maintained in system when brakes are released.

Routine checks

Maintain oil level in reservoir to full mark using only CASTROL GIRLING UNIVERSAL GREEN hydraulic fluid.

If any loss of fluid occurs from the system rectify the cause immediately. Ensure that the pedal has a firm feel without sponginess and adjust brakes well before the pedal can be bottomed.

Make sure that brake pipes do not touch the tractor chassis. Remember that the cab can move relative to the chassis in normal operation.

Brake Adjustment

As the brake linings wear, the brake pedal travel will become excessive. It is then necessary to adjust each brake assembly individually to restore correct brake pedal travel. The rear wheels (and handbrake) are adjusted as detailed in the Operator's Manual. Adjust front wheel brakes as follows:-

- (1) Apply handbrake securely and jack wheel clear of ground.
- (2) Turn hexagon-head adjuster on brake backplate (Figure 2) clockwise until brake starts to bind, then back-off the adjuster two clicks.
- (3) Check that wheel rotates freely then repeat procedure on opposite front wheel.
- (4) Check level in fluid reservoirs and top up if necessary. Lubricate pedal pivots and road test the tractor to check brake operation.




FIGURE 2. FRONT WHEEL BRAKE ADJUSTMENT
A. Adjuster B. Vent screw

Venting Brake System

After any disturbance of the brake hydraulic-system, vent at each wheel cylinder in the following order: left-hand rear, right-hand front (replenishing left-hand reservoir) then right-hand rear and left-hand front (replenishing right-hand reservoir).

- (1) At wheel; remove rubber dust cover and attach a length of rubber tubing to wheel cylinder vent screw. Place opposite end of tube in a glass jar containing sufficient Castrol Girling Universal (Green) brake fluid to cover end of tube.
- (2) Slacken vent screw and slowly pump the brake pedal, holding it down at end of each stroke and tightening vent screw before returning pedal.
- (3) Repeat pumping procedure until air-free oil is expelled from tube, tighten vent screw and repeat venting procedure in sequence indicated above.

CAUTION - Do not permit fluid level to fall below reservoir danger markings at any time.

- (4) On completion, top up reservoirs and carry out road test to check brake operation.

CAUTION - Venting should only be necessary after rectification of a faulty system. The need for venting in normal service is itself a fault and the cause of inadvertent air admission (felt as a 'spongy' brake pedal) should be investigated.




FIGURE 3. BRAKE AND CLUTCH FLUID RESERVOIRS

A. Clutch Fluid Reservoir B and C. Brake Fluid Reservoirs

Brake system faults

If the pedals remain spongy after correct bleeding or if sponginess returns in service isolate the slave cylinder from the master cylinder using a Girling T3 hose clamp on the flexible brake hose. If sponginess is eliminated with the clamp fitted air is entering the slave cylinder past the seals. If sponginess remains the master cylinder or reservoir connections may be at fault.

Brake drag or failure to release fully may be caused by faulty slave cylinder seals or by an incorrectly adjusted master cylinder push rod.

Cylinders and seal kits for all models are available under the following part numbers. Ensure that any cylinder installed has a black identification band as this indicates the unit is suitable for a vegetable oil system.

Master Cylinder	K953287
Seal kit for master cylinder	K964484
Slave cylinder, front, left-hand	K964511
Slave cylinder, front, right-hand	K964512
Seal kit - slave cylinder, front	K964513
Slave cylinder - rear	K949123
Seal kit - rear slave cylinder	K964783
Balance valve	K949122

Warranty procedure - If any brake cylinder fails as a result of defective manufacture or assembly, the unit must be returned to David Brown Claims Department complete without being dismantled, washed or drained. Transit plugs supplied with replacement cylinders must be transferred to the failed unit to prevent leakage and the unit should be packed in a clean plastic bag.

CLUTCH

The transmission clutch is hydraulically operated using similar cylinders to the brake system. All cylinders and seals are colour coded black and only CASTROL GIRLING UNIVERSAL GREEN hydraulic fluid may be used.

Operation:

A reservoir supplies Fluid to the master cylinder which is operated by the clutch pedal through a pushrod. The master cylinder feeds fluid to the slave cylinder mounted on the side of the main frame, except 885 where the slave cylinder is mounted on the clutch housing.

CLUTCH RELEASE LINKAGE

The release linkage is NOT automatically adjusted and must be checked and adjusted if necessary at regular intervals.

It is a recommendation that this job is done at intervals of not more than weekly or every 60 hours.

If this is not done, and the tractor is operated with no free movement in the release linkage, the result will be clutch slip and rapid wear of the clutch facings and pressure plate.

Checking the Free Movement

See Figures 4 and 5

1. Use a screwdriver as a lever and move the cross shaft lever away from the slave cylinder until all movement is stopped.
2. Immediately estimate the clearance between the end of the slave cylinder push rod and the socket in the lever. Then release the lever.
3. If the clearance is less than 2mm on 885 or 1.5mm on 990 and 995 tractors, adjust as follows.

Adjusting the Clearance

1. Loosen the locknut and turn the adjuster until there is no free movement between the end of the push rod and the socket in the lever. Check the clearance.
2. Turn the adjust in the opposite direction $1\frac{1}{2}$ turns on 885 and 1 turn on 990, 995 tractors. This will give the correct amount of clearance.
3. Tighten the locknut.

PTO Clutch adjustment 885, 990, 995

The only adjustment available is at the 3 Allen screws on the clutch cover assembly. Weld a short handle to the end of a $\frac{1}{2}$ AF Tube spanner so that a long $5/32$ AF Allen key can be entered down the tube.




FIGURE 4 885 CLUTCH SLAVE CYLINDER




FIGURE 5 990, 995 CLUTCH SLAVE CYLINDER

With engine stopped and stop control in "Stop" position rotate flywheel (do not insert lever between spring cups to rotate flywheel as this will damage clutch) until one Allen screw is at the bottom. Slacken locknut with tube spanner and turn screw clockwise to just contact pressure plate. Slacken screw clockwise to just contact pressure plate. Slacken screw exactly 1.3/4 turns and tighten locknut. Repeat on remaining 2 screws.

This procedure will give 1.82mm (0.72in) Allen screw clearance.

Note 1/4 turn of screw will vary adjustment by 0.25mm (0.010in)

Master Cylinder and slave cylinder

These are similar to brake components which are detailed in brake section.

If a master cylinder or clutch pedal is disturbed the following adjustment must be carried out.

1. With foot pedal against the rear stop the master cylinder push rod clevis pin must freely enter the hole in the pedal. Adjust threaded end on push rod to obtain correct adjustment.
2. Carefully depress pedal until master cylinder is bottomed. Adjust stop bolt in pedal to contact the console and then turn stop bolt 1 further full turn anticlockwise to prevent master cylinder from bottoming in service.

Clutch bleeding Remove all free travel from release bearing and bleed in same way as brake circuit. Do not bottom release levers during this operation as this will cause damage to clutch. Re-adjust free travel to specifications.

Slave cylinder To gain access to slave cylinder on 885 tractors it is necessary to raise the front of the cab.

Replacement parts Cylinders and seal kits are available under the following part numbers. Ensure that any cylinder fitted has a black identification band as this indicates the unit is suitable for a vegetable oil system.

Master cylinder 8 & 9 series	K949121
Seal kit, master cylinder	K964780
Slave cylinder 885	K950235
Seal kit, slave cylinder	K964778
Slave cylinder 990, 995	K949123
Seal kit, slave cylinder	K964783

Warranty procedure - Refer to brake section

CAB LIFTING BRACKET

The completed bracket must be tested by an authorised specialist to comply with the requirements of the Factories Act, to a maximum load of 1000kg. The following materials and parts will be required to fabricate the lifting bracket as shown in figure 6 opposite.

Material required

Steel plate should be 30 ton grade weldable structural steel.

Steel plate	1200mm x 100mm x 16mm	Qty 1
Steel plate	360mm x 160mm x 5mm	Qty 2

Additional David Brown parts required.

<u>Part No</u>	<u>Description</u>	<u>Qty</u>
K921914	fork end	2
K901963	bush	2
K19476	washer, 3/4in	2
K601411	bolt, 3/4in UNC x	2
K607446	Cleveloc nut, 3/4 UNC	2
K948353	Pivot pin	2
K923740	spring pin 3/16in x 7/8in	2
K624874	spring clip	2

Manufacture and assemble the bracket as shown in figure 6 opposite, noting the method of attachment of the side plate hangers (left-hand side shown).

The quickest method of attachment of bracket to cab is to locate the side plates on the cab lifting bolts allowing them to rest in the roof guttering. Then lower the centre beam and attach the hangers to the centre beam by means of the quick release pins.

All dimensions are given in millimetres

